



# MCUXpresso SDK Documentation

Release 25.09.00-pvw2



NXP  
Aug 12, 2025

# Table of contents

<b>1</b>	<b>LPCXpresso824MAX</b>	<b>3</b>
1.1	Overview . . . . .	3
1.2	Getting Started with MCUXpresso SDK Package . . . . .	3
1.2.1	Getting Started with MCUXpresso SDK Package . . . . .	3
1.3	Getting Started with MCUXpresso SDK GitHub . . . . .	55
1.3.1	Getting Started with MCUXpresso SDK Repository . . . . .	55
1.4	Release Notes . . . . .	68
1.4.1	MCUXpresso SDK Release Notes . . . . .	68
1.5	ChangeLog . . . . .	71
1.5.1	MCUXpresso SDK Changelog . . . . .	71
1.6	Driver API Reference Manual . . . . .	100
1.7	Middleware Documentation . . . . .	100
1.7.1	FreeMASTER . . . . .	100
<b>2</b>	<b>LPC824</b>	<b>101</b>
2.1	Clock Driver . . . . .	101
2.2	CRC: Cyclic Redundancy Check Driver . . . . .	110
2.3	DMA: Direct Memory Access Controller Driver . . . . .	113
2.4	FLEXCOMM: FLEXCOMM Driver . . . . .	130
2.5	FLEXCOMM Driver . . . . .	130
2.6	I2C: Inter-Integrated Circuit Driver . . . . .	131
2.7	I2C DMA Driver . . . . .	131
2.8	I2C Driver . . . . .	132
2.9	I2C Master Driver . . . . .	137
2.10	I2C Slave Driver . . . . .	149
2.11	IAP: In Application Programming Driver . . . . .	161
2.12	INPUTMUX: Input Multiplexing Driver . . . . .	167
2.13	Common Driver . . . . .	169
2.14	LPC_ACOMP: Analog comparator Driver . . . . .	181
2.15	ADC: 12-bit SAR Analog-to-Digital Converter Driver . . . . .	184
2.16	GPIO: General Purpose I/O . . . . .	195
2.17	IOCON: I/O pin configuration . . . . .	198
2.18	MRT: Multi-Rate Timer . . . . .	198
2.19	PINT: Pin Interrupt and Pattern Match Driver . . . . .	203
2.20	Power Driver . . . . .	211
2.21	Reset Driver . . . . .	216
2.22	SCTimer: SCTimer/PWM (SCT) . . . . .	218
2.23	SPI: Serial Peripheral Interface Driver . . . . .	235
2.24	SPI Driver . . . . .	235
2.25	SWM: Switch Matrix Module . . . . .	247
2.26	SYSCON: System Configuration . . . . .	253
2.27	USART: Universal Asynchronous Receiver/Transmitter Driver . . . . .	255
2.28	USART DMA Driver . . . . .	255
2.29	USART Driver . . . . .	257
2.30	WKT: Self-wake-up Timer . . . . .	279
2.31	WWDT: Windowed Watchdog Timer Driver . . . . .	281

<b>3 Middleware</b>	<b>285</b>
3.1 Motor Control . . . . .	285
3.1.1 FreeMASTER . . . . .	285
<b>4 RTOS</b>	<b>323</b>
4.1 FreeRTOS . . . . .	323
4.1.1 FreeRTOS kernel . . . . .	323
4.1.2 FreeRTOS drivers . . . . .	323
4.1.3 backoffalgorithm . . . . .	323
4.1.4 corehttp . . . . .	323
4.1.5 corejson . . . . .	323
4.1.6 coremqtt . . . . .	324
4.1.7 coremqtt-agent . . . . .	324
4.1.8 corepkcs11 . . . . .	324
4.1.9 freertos-plus-tcp . . . . .	324

This documentation contains information specific to the lpcxpresso824max board.




# Chapter 1

## LPCXpresso824MAX

### 1.1 Overview

LPC800 family boards and devices are fully supported by NXPs MCUXpresso suite of free software and tools, which include an Eclipse-based IDE, configuration tools and extensive SDK drivers/examples available at <https://mcuxpresso.nxp.com>. All boards in this series include an on-board CMSIS-DAP debug probe based on the LPC11U35 debug probe, with the option for an external debug probe such as those from SEGGER and PE Micro. Popular Arduino UNO shield boards can be used on these boards, enabling quick and easy prototyping. The LPC82x family is fully supported by NXPs MCUXpresso suite of free software and tools, which include an Eclipse-based IDE, configuration tools and extensive SDK drivers/examples available at <https://mcuxpresso.nxp.com>. MCUXpresso SDK includes project files for use with IDEs from lead partners Keil and IAR, and these IDEs are also fully supported by the MCUXpresso pin, clock and peripheral configuration tools.



MCU device and part on board is shown below:

- Device: LPC824
- PartNumber: LPC824M201JHI33

### 1.2 Getting Started with MCUXpresso SDK Package

#### 1.2.1 Getting Started with MCUXpresso SDK Package


##### Overview

The NXP MCUXpresso software and tools offer comprehensive development solutions designed to optimize, ease, and help accelerate embedded system development of applications based on

general purpose, crossover, and Bluetooth-enabled MCUs from NXP. The MCUXpresso SDK includes a flexible set of peripheral drivers designed to speed up and simplify development of embedded applications. Along with the peripheral drivers, the MCUXpresso SDK provides an extensive and rich set of example applications covering everything from basic peripheral use case examples to full demo applications. The MCUXpresso SDK contains optional RTOS integrations such as FreeRTOS and Azure RTOS, and various other middleware to support rapid development.

For supported toolchain versions, see *MCUXpresso SDK Release Notes* (document MCUXSDKRNN).

For more details about MCUXpresso SDK, see [MCUXpresso Software Development Kit \(SDK\)](#).



## MCUXpresso SDK board support package folders

MCUXpresso SDK board support package provides example applications for NXP development and evaluation boards for Arm Cortex-M cores including Freedom, Tower System, and LPCXpresso boards. Board support packages are found inside the top-level boards folder and each supported board has its own folder (an MCUXpresso SDK package can support multiple boards). Within each `<board_name>` folder, there are various subfolders to classify the type of examples it contains. These include (but are not limited to):


- `cmsis_driver_examples`: Simple applications intended to show how to use CMSIS drivers.
- `demo_apps`: Full-featured applications that highlight key functionality and use cases of the target MCU. These applications typically use multiple MCU peripherals and may leverage stacks and middleware.
- `driver_examples`: Simple applications that show how to use the MCUXpresso SDK's peripheral drivers for a single use case. These applications typically only use a single peripheral but there are cases where multiple peripherals are used (for example, SPI conversion using DMA).
- `emwin_examples`: Applications that use the emWin GUI widgets.
- `rtos_examples`: Basic FreeRTOS OS examples that show the use of various RTOS objects (semaphores, queues, and so on) and interfaces with the MCUXpresso SDK's RTOS drivers
- `usb_examples`: Applications that use the USB host/device/OTG stack.

**Example application structure** This section describes how the various types of example applications interact with the other components in the MCUXpresso SDK. To get a comprehensive

understanding of all MCUXpresso SDK components and folder structure, see *MCUXpresso SDK API Reference Manual*.

Each <board\_name> folder in the boards directory contains a comprehensive set of examples that are relevant to that specific piece of hardware. Although we use the hello\_world example (part of the demo\_apps folder), the same general rules apply to any type of example in the <board\_name> folder.

In the hello\_world application folder you see the following contents:



All files in the application folder are specific to that example, so it is easy to copy and paste an existing example to start developing a custom application based on a project provided in the MCUXpresso SDK.

**Locating example application source files** When opening an example application in any of the supported IDEs, various source files are referenced. The MCUXpresso SDK devices folder is the central component to all example applications. It means that the examples reference the same source files and, if one of these files is modified, it could potentially impact the behavior of other examples.

The main areas of the MCUXpresso SDK tree used in all example applications are:

- devices/<device\_name>: The device's CMSIS header file, MCUXpresso SDK feature file, and a few other files
- devices/<device\_name>/cmsis\_drivers: All the CMSIS drivers for your specific MCU
- devices/<device\_name>/drivers: All of the peripheral drivers for your specific MCU
- devices/<device\_name>/<tool\_name>: Toolchain-specific startup code, including vector table definitions
- devices/<device\_name>/utilities: Items such as the debug console that are used by many of the example applications
- devices/<device\_name>/project: Project template used in CMSIS PACK new project creation

For examples containing middleware/stacks or an RTOS, there are references to the appropriate source code. Middleware source files are located in the middleware folder and RTOSes are in the rtos folder. The core files of each of these are shared, so modifying one could have potential impacts on other projects that depend on that file.

## Run a demo using MCUXpresso IDE


**Note:** Ensure that the MCUXpresso IDE toolchain is included when generating the MCUXpresso SDK package.

This section describes the steps required to configure MCUXpresso IDE to build, run, and debug example applications. The hello\_world demo application targeted for the hardware platform is used as an example, though these steps can be applied to any example application in the MCUXpresso SDK.


**Select the workspace location** Every time MCUXpresso IDE launches, it prompts the user to select a workspace location. MCUXpresso IDE is built on top of Eclipse which uses workspace to store information about its current configuration, and in some use cases, source files for the projects are in the workspace. The location of the workspace can be anywhere, but it is recommended that the workspace be located outside the MCUXpresso SDK tree.

**Build an example application** To build an example application, follow these steps.


1. Drag and drop the SDK zip file into the **Installed SDKs** view to install an SDK. In the window that appears, click **OK** and wait until the import has finished.



2. On the **Quickstart Panel**, click **Import SDK example(s)....**



3. Expand the demo\_apps folder and select hello\_world.
4. Click **Next**.




5. Ensure **Redlib**: **Use floating-point version of printf** is selected if the example prints floating-point numbers on the terminal for demo applications such as adc\_basic, adc\_burst, adc\_dma, and adc\_interrupt. Otherwise, it is not necessary to select this option. Then, click **Finish**.

**Run an example application** For more information on debug probe support in the MCUXpresso IDE, see [community.nxp.com](http://community.nxp.com).


To download and run the application, perform the following steps:

1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via a USB cable.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug serial port number (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in board.h file)
  2. No parity

## 3. 8 data bits



4. On the **Quickstart Panel**, click **Debug** to launch the debug session.
5. The first time you debug a project, the **Debug Emulator Selection** dialog is displayed, showing all supported probes that are attached to your computer. Select the probe through which you want to debug and click **OK**. (For any future debug sessions, the stored probe selection is automatically used, unless the probe cannot be found.)



6. The application is downloaded to the target and automatically runs to `main()`.
7. Start the application by clicking **Resume**.




The `hello_world` application is now running and a banner is displayed on the terminal. If not, check your terminal settings and connections.


A screenshot of a PuTTY terminal window. The title bar says 'COM4 - PuTTY'. The main window is black with white text. It displays the message 'hello world.' followed by a small green square icon. There are scroll bars on the right side of the window.

**Build a multicore example application** This section describes the steps required to configure MCUXpresso IDE to build, run, and debug multicore example applications. The following steps can be applied to any multicore example application in the MCUXpresso SDK. Here, the dual-core version of hello\_world example application targeted for the LPCXpresso54114 hardware platform is used as an example.

1. Multicore examples are imported into the workspace in a similar way as single core applications, explained in **Build an example application**. When the SDK zip package for LPCXpresso54114 is installed and available in the **Installed SDKs** view, click **Import SDK example(s)...** on the Quickstart Panel. In the window that appears, expand the **LPCxx** folder and select **LPC54114J256**. Then, select **lpcxpresso54114** and click **Next**.
2. Expand the multicore\_examples/hello\_world folder and select **cm4**. The cm0plus counterpart project is automatically imported with the cm4 project, because the multicore examples are linked together and there is no need to select it explicitly. Click **Finish**.




3. Now, two projects should be imported into the workspace. To start building the multicore application, highlight the `lpcxpresso54114_multicore_examples_hello_world_cm4` project (multicore master project) in the Project Explorer. Then choose the appropriate build target, **Debug** or **Release**, by clicking the downward facing arrow next to the hammer icon, as shown in the figure. For this example, select **Debug**.






The project starts building after the build target is selected. Because of the project reference settings in multicore projects, triggering the build of the primary core application (cm4) also causes the referenced auxiliary core application (cm0plus) to build.


**Note:** When the **Release** build is requested, it is necessary to change the build configuration of both the primary and auxiliary core application projects first. To do this, select both projects in the Project Explorer view and then right click which displays the context-sensitive menu. Select **Build Configurations -> Set Active -> Release**. This alternate navigation using the menu item is **Project -> Build Configuration -> Set Active -> Release**. After switching to the **Release** build configuration, the build of the multicore example can be started by triggering the primary core application (cm4) build.




**Run a multicore example application** The primary core debugger handles flashing of both the primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform all steps as described in **Run an example application**. These steps are common for both single-core applications and the primary side of dual-core applications, ensuring both sides of the multicore application are properly loaded and started. However, there is one additional dialogue that is specific to multicore examples which requires selecting the target core. See the following figures as reference.









After clicking the “Resume All Debug sessions” button, the hello\_world multicore application runs and a banner is displayed on the terminal. If this is not the case, check your terminal settings and connections.




An LED controlled by the auxiliary core starts flashing, indicating that the auxiliary core has been released from the reset and running correctly. It is also possible to debug both sides of the multicore application in parallel. After creating the debug session for the primary core, perform same steps also for the auxiliary core application. Highlight the lpcxpresso54114\_multicore\_examples\_hello\_world\_cm0plus project (multicore slave project) in the Project Explorer. On the Quickstart Panel, click “Debug ‘lpcxpresso54114\_multicore\_examples\_hello\_world\_cm0plus’ [Debug]” to launch the second debug

session.







Now, the two debug sessions should be opened, and the debug controls can be used for both debug sessions depending on the debug session selection. Keep the primary core debug session selected by clicking the “Resume” button. The hello\_world multicore application then starts running. The primary core application starts the auxiliary core application during runtime, and the auxiliary core application stops at the beginning of the main() function. The debug session of the auxiliary core application is highlighted. After clicking the “Resume” button, it is applied to the auxiliary core debug session. Therefore, the auxiliary core application continues its execution.




At this point, it is possible to suspend and resume individual cores independently. It is also possible to make synchronous suspension and resumption of both the cores. This is done either by selecting both opened debug sessions (multiple selections) and clicking the “Suspend” / “Resume” control button, or just using the “Suspend All Debug sessions” and the “Resume All Debug sessions” buttons.






**Build a TrustZone example application** This section describes the steps required to configure MCUXpresso IDE to build, run, and debug TrustZone example applications. The TrustZone version of the hello\_world example application targeted for the MIMXRT595-EVK hardware platform is used as an example, though these steps can be applied to any TrustZone example application in the MCUXpresso SDK.

1. TrustZone examples are imported into the workspace in a similar way as single core applications. When the SDK zip package for MIMXRT595-EVK is installed and available in the **Installed SDKs** view, click **Import SDK example(s)...** on the Quickstart Panel. In the window that appears, expand the **MIMXRT500** folder and select **MIMXRT595**. Then, select **evkmimxrt595** and click **Next**.
2. Expand the **trustzone\_examples/** folder and select **hello\_world\_s**. Because TrustZone examples are linked together, the non-secure project is automatically imported with the secure project, and there is no need to select it explicitly. Then, click **Finish**.




3. Now, two projects should be imported into the workspace. To start building the TrustZone application, highlight the evkmimxrt595\_hello\_world\_s project (TrustZone master project) in the Project Explorer. Then, choose the appropriate build target, **Debug** or **Release**, by clicking the downward facing arrow next to the hammer icon, as shown in following figure. For this example, select the **Debug** target.




The project starts building after the build target is selected. It is requested to build the application for the secure project first, because the non-secure project must know the secure project since CMSE library when running the linker. It is not possible to finish the non-secure project linker when the secure project since CMSE library is not ready.

**Note:** When the **Release** build is requested, it is necessary to change the build configuration of both the secure and non-secure application projects first. To do this, select both projects in the Project Explorer view by clicking to select the first project, then using shift-click or control-click to select the second project. Right click in the Project Explorer view to display the context-sensitive menu and select **Build Configurations > Set Active > Release**. This is also possible by using the menu item of **Project > Build Configuration > Set Active > Release**. After switching to the **Release** build configuration. Build the application for the secure project first.



**Run a TrustZone example application** To download and run the application, perform all steps as described in **Run an example application**. These steps are common for single core, and TrustZone applications, ensuring <board\_name>\_hello\_world\_s is selected for debugging.

In the Quickstart Panel, click **Debug** to launch the second debug session.



Now, the TrustZone sessions should be opened. Click **Resume**. The `hello_world` TrustZone application then starts running, and the secure application starts the non-secure application during runtime.

## Run a demo application using IAR

This section describes the steps required to build, run, and debug example applications provided in the MCUXpresso SDK.

**Note:** IAR Embedded Workbench for Arm version 8.32.3 is used in the following example, and the IAR toolchain should correspond to the latest supported version, as described in the *MCUXpresso SDK Release Notes*.

**Build an example application** Do the following steps to build the `hello_world` example application.


1. Open the desired demo application workspace. Most example application workspace files can be located using the following path:

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/iar
```


Other example applications may have additional folders in their path.

2. Select the desired build target from the drop-down menu.

For this example, select **hello\_world – debug**.




3. To build the demo application, click **Make**, highlighted in red in following figure.



4. The build completes without errors.

**Run an example application** To download and run the application, perform these steps:


1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via USB cable.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug COM port (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in the board.h file)
  2. No parity
  3. 8 data bits



4. In IAR, click the **Download and Debug** button to download the application to the target.



5. The application is then downloaded to the target and automatically runs to the main() function.



6. Run the code by clicking the **Go** button.



7. The hello\_world application is now running and a banner is displayed on the terminal. If it does not appear, check your terminal settings and connections.



**Build a multicore example application** This section describes the steps to build and run a dual-core application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/multicore_examples/<application_name>/<core_type>/iar
```

Begin with a simple dual-core version of the Hello World application. The multicore Hello World IAR workspaces are located in this folder:

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm0plus/iar/hello_world_cm0plus.eww
```

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm4/iar/hello_world_cm4.eww
```

Build both applications separately by clicking the **Make** button. Build the application for the auxiliary core (cm0plus) first, because the primary core application project (cm4) must know the auxiliary core application binary when running the linker. It is not possible to finish the primary core linker when the auxiliary core application binary is not ready.


**Run a multicore example application** The primary core debugger handles flashing both primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform steps 1 – 4 as described in **Run an example application**. These steps are common for both single core and dual-core applications in IAR.

After clicking the “Download and Debug” button, the auxiliary core project is opened in the separate EWARM instance. Both the primary and auxiliary images are loaded into the device flash memory and the primary core application is executed. It stops at the default C language entry point in the `*main()*`function.

Run both cores by clicking the “Start all cores” button to start the multicore application.



During the primary core code execution, the auxiliary core is released from the reset. The hello\_world multicore application is now running and a banner is displayed on the terminal. If this does not appear, check the terminal settings and connections.



An LED controlled by the auxiliary core starts flashing, indicating that the auxiliary core has been released from the reset and is running correctly. When both cores are running, use the “Stop all cores”, and “Start all cores” control buttons to stop or run both cores simultaneously.



**Build a TrustZone example application** This section describes the particular steps that must be done in order to build and run a TrustZone application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/iar/
↪<application_name>_ns/iar
```

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/iar/
↪<application_name>_s/iar
```

Begin with a simple TrustZone version of the Hello World application. The TrustZone Hello World IAR workspaces are located in this folder:


```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_ns/iar/hello_world_
↪ns.eww
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/iar/hello_world_s.
↪eww
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/iar/hello_world.eww
```

This project hello\_world.eww contains both secure and non-secure projects in one workspace and it allows the user to easily transition from one project to another. Build both applications separately by clicking **Make**. It is requested to build the application for the secure project first, because the non-secure project must know the secure project, since the CMSE library is running the linker. It is not possible to finish the non-secure project linker with the secure project since CMSE library is not ready.

**Run a TrustZone example application** The secure project is configured to download both secure and non-secure output files, so debugging can be fully managed from the secure project. To download and run the TrustZone application, switch to the secure application project and perform steps 1 – 4 as described in **Run an example application**. These steps are common for both single core, and TrustZone applications in IAR. After clicking **Download and Debug**, both the secure and non-secure images are loaded into the device memory, and the secure application is executed. It stops at the `Reset_Handler` function.



```

__Vectors_End

__Vectors EQU __vector_table
__Vectors_Size EQU __Vectors_End - __Vectors

;;;;; Default interrupt handlers.

;

THUMB

PUBWEAK Reset_Handler
SECTION .text:CODE:REORDER:NOROOT(2)
Reset_Handler
    CPSID I ; Mask interrupts
    LDR R0, =sfb(CSTACK)
    MSR MSPSLIM, R0
    LDR R0, =SystemInit
    BLX R0
    CPSIE I ; Unmask interrupts
    LDR R0, =_iar_program_start
    BX R0


PUBWEAK NMI_Handler
SECTION .text:CODE:REORDER:NOROOT(1)
NMI_Handler
    B .

PUBWEAK HardFault_Handler
SECTION .text:CODE:REORDER:NOROOT(1)
HardFault_Handler
    B .

```

Run the code by clicking **Go** to start the application.

The TrustZone hello\_world application is now running and a banner is displayed on the terminal. If this is not true, check your terminal settings and connections.




```

Hello from secure world!
Entering normal world.
Welcome in normal world!
This is a text printed from normal world!
Comparing two string as a callback to normal world
String 1: Test1
String 2: Test2
Both strings are not equal!

```

**Note:** If the application is running in RAM (debug/release build target), in **Options**\*\*>\*\***Debugger** > **Download** tab, disable **Use flash loader(s)**. This can avoid the `_ns` download issue on i.MXRT500.




## Run a demo using Keil MDK/μVision

This section describes the steps required to build, run, and debug example applications provided in the MCUXpresso SDK.

**Install CMSIS device pack** After the MDK tools are installed, Cortex Microcontroller Software Interface Standard (CMSIS) device packs must be installed to fully support the device from a debug perspective. These packs include things such as memory map information, register definitions, and flash programming algorithms. Follow these steps to install the appropriate CMSIS pack.

1. Open the MDK IDE, which is called μVision. In the IDE, select the **Pack Installer** icon.



2. After the installation finishes, close the Pack Installer window and return to the μVision IDE.

## Build an example application

1. Open the desired example application workspace in:

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/mdk
```

The workspace file is named as <demo\_name>.uvmpw. For this specific example, the actual path is:


2. To build the demo project, select **Rebuild**, highlighted in red.



3. The build completes without errors.

**Run an example application** To download and run the application, perform these steps:


1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via USB cable using USB connector.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm and connect to the debug serial port number (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in the board.h file)
  2. No parity
  3. 8 data bits




4. In μVision, after the application is built, click the **Download** button to download the application to the target.




5. After clicking the **Download** button, the application downloads to the target and is running. To debug the application, click the **Start/Stop Debug Session** button, highlighted in red.



6. Run the code by clicking the **Run** button to start the application.



The `hello_world` application is now running and a banner is displayed on the terminal. If this does not appear, check your terminal settings and connections.



**Build a multicore example application** This section describes the steps to build and run a dual-core application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/multicore_examples/<application_name>/<core_type>/mdk
```

Begin with a simple dual-core version of the Hello World application. The multicore Hello World Keil MSDK/μVision workspaces are located in this folder:


```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm0plus/mdk/hello_world_
→cm0plus.uvmpw
```

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm4/mdk/hello_world_cm4.uvmpw
```

Build both applications separately by clicking the **Rebuild** button. Build the application for the auxiliary core (cm0plus) first because the primary core application project (cm4) must know the auxiliary core application binary when running the linker. It is not possible to finish the primary core linker when the auxiliary core application binary is not ready.


**Run a multicore example application** The primary core debugger flashes both the primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform steps 1 – 5 as described in **Run an example application**. These steps are common for both single-core and dual-core applications in μVision.

Both the primary and the auxiliary image is loaded into the device flash memory. After clicking the “Run” button, the primary core application is executed. During the primary core code execution, the auxiliary core is released from the reset. The hello\_world multicore application is now running and a banner is displayed on the terminal. If this does not appear, check your terminal settings and connections.



An LED controlled by the auxiliary core starts flashing indicating that the auxiliary core has been released from the reset and is running correctly.

Attach the running application of the auxiliary core by opening the auxiliary core project in the second µVision instance and clicking the “Start/Stop Debug Session” button. After this, the second debug session is opened and the auxiliary core application can be debugged.



Arm describes multicore debugging using the NXP LPC54114 Cortex-M4/M0+ dual-core processor and Keil uVision IDE in Application Note 318 at [www.keil.com/appnotes/docs/apnt\\_318.asp](http://www.keil.com/appnotes/docs/apnt_318.asp). The associated video can be found [here](#).

**Build a TrustZone example application** This section describes the particular steps that must be done in order to build and run a TrustZone application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/<application_name>_ns/
↳ mdk
```

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/<application_name>_s/
↳ mdk
```

Begin with a simple TrustZone version of the Hello World application. The TrustZone Hello World Keil MSDK/µVision workspaces are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_ns/mdk/hello_world_-
↳ ns.uvmpw
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/mdk/hello_world_-
↳ uvmpw
```


```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/mdk/hello_world.uvmpw
```

This project hello\_world.uvmpw contains both secure and non-secure projects in one workspace and it allows the user to easily transition from one project to another.

Build both applications separately by clicking **Rebuild**. It is requested to build the application for the secure project first, because the non-secure project must know the secure project since CMSE library is running the linker. It is not possible to finish the non-secure project linker with the secure project because CMSE library is not ready.


**Run a TrustZone example application** The secure project is configured to download both secure and non-secure output files so debugging can be fully managed from the secure project.

To download and run the TrustZone application, switch to the secure application project and perform steps as described in **Run an example application**. These steps are common for single core, dual-core, and TrustZone applications in  $\mu$ Vision. After clicking **Download and Debug**, both the secure and non-secure images are loaded into the device flash memory, and the secure application is executed. It stops at the main() function.



Run the code by clicking **Run** to start the application.

The hello\_world application is now running and a banner is displayed on the terminal. If not, check your terminal settings and connections.



## Run a demo using Arm GCC

This section describes the steps to configure the command-line Arm GCC tools to build, run, and debug demo applications and necessary driver libraries provided in the MCUXpresso SDK. The hello\_world demo application is targeted which is used as an example.

**Set up toolchain** This section contains the steps to install the necessary components required to build and run an MCUXpresso SDK demo application with the Arm GCC toolchain, as supported by the MCUXpresso SDK. There are many ways to use Arm GCC tools, but this example focuses on a Windows operating system environment.


**Install GCC Arm Embedded tool chain** Download and run the installer from GNU Arm Embedded Toolchain. This is the actual toolset (in other words, compiler, linker, and so on). The GCC toolchain should correspond to the latest supported version, as described in [MCUXpresso SDK Release Notes](#).

**Install MinGW (only required on Windows OS)** The Minimalist GNU for Windows (MinGW) development tools provide a set of tools that are not dependent on third-party C-Runtime DLLs (such as Cygwin). The build environment used by the MCUXpresso SDK does not use the MinGW build tools, but does leverage the base install of both MinGW and MSYS. MSYS provides a basic shell with a Unix-like interface and tools.


1. Download the latest MinGW mingw-get-setup installer from [MinGW](#).
2. Run the installer. The recommended installation path is C:\MinGW, however, you may install to any location.

**Note:** The installation path cannot contain any spaces.

3. Ensure that the **mingw32-base** and **msys-base** are selected under **Basic Setup**.



4. In the **Installation** menu, click **Apply Changes** and follow the remaining instructions to complete the installation.




5. Add the appropriate item to the Windows operating system path environment variable. It can be found under **Control Panel->System and Security->System->Advanced System Settings** in the **Environment Variables...** section. The path is:

<mingw\_install\_dir>\bin

Assuming the default installation path, C:\MinGW, an example is shown below. If the path is not set correctly, the toolchain will not work.

**Note:** If you have C:\MinGW\msys\x.x\bin in your PATH variable (as required by Kinetis SDK 1.0.0), remove it to ensure that the new GCC build system works correctly.




**Add a new system environment variable for ARMGCC\_DIR** Create a new *system* environment variable and name it as ARMGCC\_DIR. The value of this variable should point to the Arm GCC Embedded tool chain installation path. For this example, the path is:

C:\Program Files (x86)\GNU Tools\Arm Embedded\8 2018-q4-major

See the installation folder of the GNU Arm GCC Embedded tools for the exact pathname of your installation.

Short path should be used for path setting, you could convert the path to short path by running command for %I in (.) do echo %~sI in above path.


```
C:\Program Files (x86)\GNU Tools Arm Embedded\8 2018-q4-major>for %I in (.) do echo %~sI
C:\Program Files (x86)\GNU Tools Arm Embedded\8 2018-q4-major>echo C:\PROGRA~2\GNUTOO~1\82018~1
```



## Install CMake

### Windows OS

1. Download CMake 3.0.x from [www.cmake.org/cmake/resources/software.html](http://www.cmake.org/cmake/resources/software.html).
2. Install CMake, ensuring that the option **Add CMake to system PATH** is selected when installing. The user chooses to select whether it is installed into the PATH for all users or just the current user. In this example, it is installed for all users.



3. Follow the remaining instructions of the installer.
4. You may need to reboot your system for the PATH changes to take effect.
5. Make sure sh.exe is not in the Environment Variable PATH. This is a limitation of mingw32-make.


**Linux OS** It depends on the distributions of Linux Operation System. Here we use Ubuntu as an example.

Open shell and use following commands to install cmake and its version. Ensure the cmake version is above 3.0.x.

```
$ sudo apt-get install cmake
$ cmake --version
```

**Build an example application** To build an example application, follow these steps.

1. Open a GCC Arm Embedded tool chain command window. To launch the window, from the Windows operating system **Start** menu, go to **Programs > GNU Tools Arm Embedded <version>** and select **GCC Command Prompt**.



2. Change the directory to the example application project directory which has a path similar to the following:

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/armgcc
```

For this example, the exact path is:

**Note:** To change directories, use the `cd` command.


3. Type `build_debug.bat` on the command line or double click on `build_debug.bat` file in Windows Explorer to build it. The output is as shown in following figure.

```
[ 84%] Building C object CMakeFiles/hello_world.elf.dir/C:/nxp/SDK_2.0_FRDM-K64F/devices/MK64F12/drivers/fsl_smc.c.obj
[ 92%] Building C object CMakeFiles/hello_world.elf.dir/C:/nxp/SDK_2.0_FRDM-K64F/devices/MK64F12/drivers/fsl_clock.c.obj
[100%] Linking C executable debug\hello_world.elf
[100%] Built target hello_world.elf
C:\nxp\SDK_2.0_FRDM-K64F\boards\frdmk64f\demo_apps\hello_world\armgcc>IF "" == ""
"pause"
Press any key to continue . . .
```

**Run an example application** This section describes steps to run a demo application using J-Link GDB Server application. To install J-Link host driver and update the on-board debugger firmware to Jlink firmware, see [On-board debugger](#).

After the J-Link interface is configured and connected, follow these steps to download and run the demo applications:

1. Connect the development platform to your PC via USB cable between the on-board debugger USB connector and the PC USB connector. If using a standalone J-Link debug pod, connect it to the SWD/JTAG connector of the board.
2. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug serial port number (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in board.h file)
  2. No parity
  3. 8 data bits
  4. 1 stop bit




3. To launch the application, open the Windows **Start** menu and select **Programs > SEGGER > J-Link <version> J-Link GDB Server**.

**Note:** It is assumed that the J-Link software is already installed.


The **SEGGER J-Link GDB Server Config** settings dialog appears.

4. Make sure to check the following options.


1. **Target interface:** The debug connection on board uses internal SWD signaling. In case of a wrong setting J-Link is unable to communicate with device under test.
2. **Script file:** If required, a J-Link init script file can be used for board initialization. The file with the “.jlinkscript” file extension is located in the <install\_dir>/boards/<board\_name>/ directory.
3. Under the **Server settings**, check the GDB port for connection with the gdb target remote command. For more information, see step 9.
4. There is a command line version of J-Link GDB server “JLinkGDBServerCL.exe”. Typical path is C:\Program Files\SEGGER\JLink\. To start the J-Link GDB server with the same settings as are selected in the UI, you can use these command line options.



5. After it is connected, the screen should look like this figure:



6. If not already running, open a GCC Arm Embedded tool chain command window. To launch the window, from the Windows operating system Start menu, go to **Programs - GNU Tools Arm Embedded <version>** and select **GCC Command Prompt**.




7. Change to the directory that contains the example application output. The output can be found in using one of these paths, depending on the build target selected:

<install\_dir>/boards/<board\_name>/<example\_type>/<application\_name>/armgcc/debug

<install\_dir>/boards/<board\_name>/<example\_type>/<application\_name>/armgcc/release

8. Run the `arm-none-eabi-gdb.exe <application_name>.elf` command. For this example, it is `arm-none-eabi-gdb.exe hello_world.elf`.



```
— □ ×
GCC Command Prompt - arm-none-eabi-gdb.exe C:\Users\nxa12829\Desktop\k3213\boards\frdmk3213a6\demo_apps\hello_world\cm4\armgcc\debu...
C:\Program Files (x86)\GNU Tools ARM Embedded\8 2018-q4-major>arm-none-eabi-gdb.exe C:\Users\nxa12829\Desktop\k3213\boards\frdmk3213a6\demo_apps\hello_world\cm4\armgcc\debug\hello_world_demo_cm4.elf
C:\Program Files (x86)\GNU Tools ARM Embedded\8 2018-q4-major\bin\arm-none-eabi-gdb.exe: warning: Couldn't determine a path for the index cache directory.
GNU gdb (GNU Tools for Arm Embedded Processors 8-2018-q4-major) 8.2.50.20181213-git
Copyright (C) 2018 Free Software Foundation, Inc.
License GPLv3+: GNU GPL version 3 or later <http://gnu.org/licenses/gpl.html>
This is free software: you are free to change and redistribute it.
There is NO WARRANTY, to the extent permitted by law.
Type "show copying" and "show warranty" for details.
This GDB was configured as "--host=i686-w64-mingw32 --target=arm-none-eabi".
Type "show configuration" for configuration details.
For bug reporting instructions, please see:
<http://www.gnu.org/software/gdb/bugs/>.
Find the GDB manual and other documentation resources online at:
  <http://www.gnu.org/software/gdb/documentation/>.

For help, type "help".
Type "apropos word" to search for commands related to "word"...
Reading symbols from C:\Users\nxa12829\Desktop\k3213\boards\frdmk3213a6\demo_apps\hello_world\cm4\armgcc\debug\hello_world_demo_cm4.elf...
(gdb)
```

### 9. Run these commands:

1. target remote localhost:2331
2. monitor reset
3. monitor halt
4. load
5. monitor reset

### 10. The application is now downloaded and halted. Execute the monitor go command to start the demo application.

The hello\_world application is now running and a banner is displayed on the terminal. If this does not appear, check your terminal settings and connections.



```
— □ ×
COM4 - PuTTY
hello world.
█
```

**Build a multicore example application** This section describes the steps to build and run a dual-core application. The demo application build scripts are located in this folder:

```
<install_dir>/boards/<board_name>/multicore_examples/<application_name>/<core_type>/armgcc
```

Begin with a simple dual-core version of the Hello World application. The multicore Hello World GCC build scripts are located in this folder:

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm0plus/armgcc/build_debug.bat
```

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm4/armgcc/build_debug.bat
```

Build both applications separately following steps for single core examples as described in **Build an example application**.

```
ca: GCC Command Prompt - build_debug.bat
[ 47%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/drivers/fsl_common.c.obj
[ 52%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/drivers/fsl_msmc.c.obj
[ 56%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/debug_console/fsl_debug_console.c.obj
[ 60%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/fsl_assert.c.obj
[ 65%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/str/fsl_str.c.obj
[ 69%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/uart/lpuart_adapter.c.obj
[ 73%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/serial_manager/serial_manager.c.obj
[ 78%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/serial_manager/serial_port_uart.c.obj
[ 82%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/lists/generic_list.c.obj
[ 86%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/system_K32L3A60_cm0plus.c.obj
[ 91%] Building ASM object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/gcc/startup_K32L3A60_cm0plus.S.obj
[ 95%] Building C object CMakeFiles/hello_world_cm0plus.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/middleware/multicore/mcmgr/src/mcmgr.c.obj
[100%] Linking C executable debug\hello_world_cm0plus.elf
[100%] Built target hello_world_cm0plus.elf

c:\packages\SDK_2.6.0_FRDM-K32L3A6_RC1\boards\frdmk32l3a6\multicore_examples\hello_world\cm0plus\armgcc>IF "" == "" (pause)
Press any key to continue . . .
```

```
ca: GCC Command Prompt - build_debug.bat
[ 50%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/drivers/fsl_lpuart.c.obj
[ 54%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/drivers/fsl_common.c.obj
[ 58%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/drivers/fsl_msmc.c.obj
[ 62%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/str/fsl_str.c.obj
[ 66%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/fsl_assert.c.obj
[ 70%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/utilities/debug_console/fsl_debug_console.c.obj
[ 75%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/uart/lpuart_adapter.c.obj
[ 79%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/serial_manager/serial_port_uart.c.obj
[ 83%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/serial_manager/serial_manager.c.obj
[ 87%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/components/lists/generic_list.c.obj
[ 91%] Building C object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/system_K32L3A60_cm4.c.obj
[ 95%] Building ASM object CMakeFiles/hello_world_cm4.elf.dir/C:/packages/SDK_2.6.0_FRDM-K32L3A6_RC1/devices/K32L3A60/gcc/startup_K32L3A60_cm4.S.obj
[100%] Linking C executable debug\hello_world_cm4.elf
[100%] Built target hello_world_cm4.elf


c:\packages\SDK_2.6.0_FRDM-K32L3A6_RC1\boards\frdmk32l3a6\multicore_examples\hello_world\cm4\armgcc>IF "" == "" (pause)
Press any key to continue . . .
```

**Run a multicore example application** When running a multicore application, the same prerequisites for J-Link/J-Link OpenSDA firmware, and the serial console as for the single-core application, applies, as described in **Run an example application**.

The primary core debugger handles flashing of both the primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform steps 1 to 10, as described in **Run an example application**. These steps are common for both single-core and dual-core applications in Arm GCC.

Both the primary and the auxiliary image is loaded into the SPI flash memory. After execution of the monitor go command, the primary core application is executed. During the primary core code execution, the auxiliary core code is reallocated from the flash memory to the RAM, and the auxiliary core is released from the reset. The hello\_world multicore application is now running

and a banner is displayed on the terminal. If this is not true, check your terminal settings and connections.



```

Administrator: GCC Command Prompt

c:\D\SDK_2.0_LPCXpresso54114\boards\lpcxpresso54114\multicore_examples\hello_world\cm4\armgcc>IF "" == "" <pause>
Press any key to continue . . .


c:\D\SDK_2.0_LPCXpresso54114\boards\lpcxpresso54114\multicore_examples\hello_world\cm4\armgcc>cd debug

c:\D\SDK_2.0_LPCXpresso54114\boards\lpcxpresso54114\multicore_examples\hello_world\cm4\armgcc\debug>arm-none-eabi-gdb.exe hello_world_cm4.elf
GNU gdb (GNU Tools for ARM Embedded Processors 6-2017-q2-update) 7.12.1.20170417-git
Copyright (C) 2017 Free Software Foundation, Inc.
License GPLv3+: GNU GPL version 3 or later <http://gnu.org/licenses/gpl.html>.
This is free software: you are free to change and redistribute it.
There is NO WARRANTY, to the extent permitted by law. Type "show copying"
and "show warranty" for details.
This GDB was configured as "--host=i686-w64-mingw32 --target=arm-none-eabi".
Type "show configuration" for configuration details.
For bug reporting instructions, please see:
<http://www.gnu.org/software/gdb/bugs/>.
Find the GDB manual and other documentation resources online at:
<http://www.gnu.org/software/gdb/documentation/>.
For help, type "help".
Type "apropos word" to search for commands related to "word"...
Reading symbols from hello_world_cm4.elf...done.
(gdb) target remote localhost:2331
Remote debugging using localhost:2331
0x00004290 in ?? { }
(gdb) monitor reset
Resetting target
(gdb) monitor halt
(gdb) load
Loading section .interrupts, size 0xe0 lma 0x0
Loading section .text, size 0x3614 lma 0xe4
Loading section .ARM, size 0x8 lma 0x36f8
Loading section .init_array, size 0x4 lma 0x3700
Loading section .fini_array, size 0x4 lma 0x3704
Loading section .data, size 0x68 lma 0x3708
Loading section .m0code, size 0x1f64 lma 0x30000
Start address 0x1d8, load size 22224
Transfer rate: 1973 KB/sec, 3174 bytes/write.
(gdb) monitor reset
Resetting target
(gdb) monitor go
(gdb) q
A debugging session is active.

Inferior 1 [Remote target] will be killed.

Quit anyway? <y or n> y
c:\D\SDK_2.0_LPCXpresso54114\boards\lpcxpresso54114\multicore_examples\hello_world\cm4\armgcc\debug>

```



```

COM17:115200baud - Tera Term VT
File Edit Setup Control Window KanjiCode Help
Starting Secondary core.

Hello World from the Primary Core!

Press the SW1 button to Stop Secondary core.
Press the SW2 button to Start Secondary core.
Secondary core is in startup code.
Secondary core is in exception number 3.

```

**Build a TrustZone example application** This section describes the steps to build and run a TrustZone application. The demo application build scripts are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/
→<application_name>_ns/armgcc
```

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/
→<application_name>_s/armgcc
```

Begin with a simple TrustZone version of the Hello World application. The TrustZone Hello World GCC build scripts are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_ns/armgcc/build_
→debug.bat
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/armgcc/build_
→debug.bat
```

Build both applications separately, following steps for single core examples as described in **Build an example application**. It is requested to build the application for the secure project first, because the non-secure project must know the secure project, since CMSE library is running the linker. It is not possible to finish the non-secure project linker with the secure project because the CMSE library is not ready.

```
C:\WINDOWS\system32\cmd.exe
[ 55%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/utilities/fs...
l_assert.c.obj
[ 59%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/uart/usart_adapter.c...
.obj
[ 62%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
flexspi.c.obj
[ 66%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
cache.c.obj
[ 70%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/serial_manager/seria...
l_manager.c.obj
[ 74%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/serial_manager/seria...
l_port_uart.c.obj
[ 77%] Building ASM object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/gcc/startu...
p_MIMXRT595S_cm33.S.obj
[ 81%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/lists/generic_list.c...
.obj
[ 85%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
usart.c.obj
[ 88%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
flexcomm.c.obj
[ 92%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
gpio.c.obj
[ 96%] Building C object CMakeFiles/hello_world_s.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl...
iap.c.obj
[100%] Linking C executable debug\hello_world_s.elf
[100%] Built target hello_world_s.elf

C:\nxp\SDK_2.6.0_EVK-MIMXRT595\boards\evkmimxrt595\trustzone_examples\hello_world\hello_world_s\armgcc>IF "" == "" (paus...
e)
Press any key to continue . . .
```

```

C:\WINDOWS\system32\cmd.exe
[ 52%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/uart/usart_adapter.c.obj
[ 56%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/utilities/fsi_assert.c.obj
[ 60%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_flexspi.c.obj
[ 64%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_cache.c.obj
[ 68%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/serial_manager/serial_manager.c.obj
[ 72%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/serial_manager/serial_port_uart.c.obj
[ 76%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_usart.c.obj
[ 80%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/components/lists/generic_list.c.obj
[ 84%] Building ASM object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/gcc/startup_MIMXRT595S_cm33.S.obj
[ 88%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_flexcomm.c.obj
[ 92%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_gpio.c.obj
[ 96%] Building C object CMakeFiles/hello_world_ns.elf.dir/C_nxp/SDK_2.6.0_EVK-MIMXRT595/devices/MIMXRT595S/drivers/fsl_jap.c.obj
[100%] Linking C executable debug\hello_world_ns.elf
[100%] Built target hello_world_ns.elf
C:\nxp\SDK_2.6.0_EVK-MIMXRT595\boards\evkmimxrt595\trustzone_examples\hello_world\hello_world_ns\armgcc>IF "" == "" (pause)
Press any key to continue . . .

```


**Run a TrustZone example application** When running a TrustZone application, the same prerequisites for J-Link/J-Link OpenSDA firmware, and the serial console as for the single core application, apply, as described in [Run an example application](#).

To download and run the TrustZone application, perform steps 1 to 10, as described in [Run an example application](#). These steps are common for both single core and TrustZone applications in Arm GCC.

Then, run these commands:

1. arm-none-eabi-gdb.exe
2. target remote localhost:2331
3. monitor reset
4. monitor halt
5. monitor exec SetFlashDLNoRMWThreshold = 0x20000
6. load <install\_dir>/boards/evkmimxrt595/trustzone\_examples/hello\_world/hello\_world\_ns/armgcc/debug/hello\_world\_ns.elf
7. load <install\_dir>/boards/evkmimxrt595/trustzone\_examples/hello\_world/hello\_world\_s/armgcc/debug/hello\_world\_s.elf
8. monitor reset

The application is now downloaded and halted. Execute the `c` command to start the demo application.




```

C:\npx\SDK_2.6.0_EVK-MIMXRT595\boards\evkmmimxrt595\trustzone_examples\hello_world\arm-none-eabi-gdb
C:\Program Files (x86)\GNU Tools Arm Embedded\8 2018-q4-major\bin\arm-none-eabi-gdb.exe: warning: Couldn't determine a path for the index cache directory.
GNU gdb (GNU Tools for Arm Embedded Processors 8-2018-q4-major) 8.2.50.20181213-git
Copyright (C) 2018 Free Software Foundation, Inc.
License GPLv3+: GNU GPL version 3 or later <http://gnu.org/licenses/gpl.html>
This is free software: you are free to change and redistribute it.
There is NO WARRANTY, to the extent permitted by law.
Type "show copying" and "show warranty" for details.
This GDB was configured as "--host=i686-w64-mingw32 --target=arm-none-eabi".
Type "show configuration" for configuration details.
For bug reporting instructions, please see:
<http://www.gnu.org/software/gdb/bugs/>.
Find the GDB manual and other documentation resources online at:
<http://www.gnu.org/software/gdb/documentation/>.

For help, type "help".
Type "apropos word" to search for commands related to "word".
(gdb) target remote localhost:2331
Remote debugging using localhost:2331
warning: No executable has been specified and target does not support
determining executable automatically. Try using the "file" command.
0x00001c04a in ?? ()
(gdb) load hello_world_ns/armgcc/debug/hello_world_ns.elf
Loading section .interrupts, size 0x168 lma 0xc0000
Loading section .text, size 0x1d30 lma 0xc0180
Loading section .ARM, size 0x8 lma 0xc1eb0
Loading section .init_array, size 0x4 lma 0xc1eb8
Loading section .fini_array, size 0x4 lma 0xc1ebc
Loading section .data, size 0x60 lma 0xc1ec0
Start address 0xc0234, load size 7944
Transfer rate: 74 KB/sec, 1324 bytes/write.
(gdb) load hello_world_s/armgcc/debug/hello_world.s.elf
Loading section .flash_config, size 0x200 lma 0x1007f400
Loading section .interrupts, size 0x168 lma 0x10080000
Loading section .text, size 0x4d54 lma 0x10080180
Loading section .ARM, size 0x8 lma 0x10084ed4
Loading section .init_array, size 0x4 lma 0x10084edc
Loading section .fini_array, size 0x4 lma 0x10084ee0
Loading section .data, size 0x68 lma 0x10084ee4
Loading section .gnu.sgstubs, size 0x20 lma 0x100bfe00
Start address 0x10080234, load size 20820
Transfer rate: 123 KB/sec, 2313 bytes/write.
(gdb) c
Continuing.

```



```

Hello from secure world!
Entering normal world.
Welcome in normal world!
This is a text printed from normal world!
Comparing two string as a callback to normal world
String 1: Test1
String 2: Test2
Both strings are not equal!

```

## MCUXpresso Config Tools

MCUXpresso Config Tools can help configure the processor and generate initialization code for the on chip peripherals. The tools are able to modify any existing example project, or create a new configuration for the selected board or processor. The generated code is designed to be used with MCUXpresso SDK version 24.12.00 or later.

Following table describes the tools included in the MCUXpresso Config Tools.

Config Tool	Description	Image
<b>Pins tool</b>	For configuration of pin routing and pin electrical properties.	
<b>Clock tool</b>	For system clock configuration	
<b>Peripherals tools</b>	For configuration of other peripherals	
<b>TEE tool</b>	Configures access policies for memory area and peripherals helping to protect and isolate sensitive parts of the application.	
<b>Device Configuration tool</b>	Configures Device Configuration Data (DCD) contained in the program image that the Boot ROM code interprets to set up various on-chip peripherals prior to the program launch.	

MCUXpresso Config Tools can be accessed in the following products:

- **Integrated** in the MCUXpresso IDE. Config tools are integrated with both compiler and debugger which makes it the easiest way to begin the development.
- **Standalone version** available for download from [www.nxp.com/mcuxpresso](http://www.nxp.com/mcuxpresso). Recommended for customers using IAR Embedded Workbench, Keil MDK µVision, or Arm GCC.
- **Online version** available on [mcuxpresso.nxp.com](http://mcuxpresso.nxp.com). Recommended doing a quick evaluation of the processor or use the tool without installation.

Each version of the product contains a specific *Quick Start Guide* document MCUXpresso IDE Config Tools installation folder that can help start your work.

## How to determine COM port

This section describes the steps necessary to determine the debug COM port number of your NXP hardware development platform. All NXP boards ship with a factory programmed, onboard debug interface, whether it is based on MCU-Link or the legacy OpenSDA, LPC-Link2, P&E Micro OSJTAG interface. To determine what your specific board ships with, see [Default debug interfaces](#).

1. **Linux:** The serial port can be determined by running the following command after the USB Serial is connected to the host:

```
$ dmesg | grep "ttyUSB"
[503175.307873] usb 3-12: cp210x converter now attached to ttyUSB0
[503175.309372] usb 3-12: cp210x converter now attached to ttyUSB1
```

There are two ports, one is for core0 debug console and the other is for core1.

2. **Windows:** To determine the COM port open Device Manager in the Windows operating system. Click the Start menu and type **Device Manager** in the search bar.

In the Device Manager, expand the **Ports (COM & LPT)** section to view the available ports. The COM port names are different for all the NXP boards.


1. **CMSIS-DAP/mbed/DAPLink interface:**



## 2. P&E Micro:




## 3. J-Link:



## 4. P&E Micro OSJTAG:



## 5. MRB-KW01:



## On-board Debugger

This section describes the on-board debuggers used on NXP development boards.

**On-board debugger MCU-Link** MCU-Link is a powerful and cost effective debug probe that can be used seamlessly with MCUXpresso IDE, and is also compatible with 3rd party IDEs that support CMSIS-DAP protocol. MCU-Link also includes a USB to UART bridge feature (VCOM) that can be used to provide a serial connection between the target MCU and a host computer. MCU-Link features a high-speed USB interface for high performance debug. MCU-Link is compatible with Windows, MacOS and Linux. A free utility from NXP provides an easy way to install firmware updates.

On-board MCU-Link debugger supports CMSIS-DAP and J-Link firmware. See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**

- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](http://developer.mbed.org/handbook/Windows-serial-configuration) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.
- If using J-Link with either a standalone debug pod or MCU-Link, install the J-Link software (drivers and utilities) from [www.segger.com/jlink-software.html](http://www.segger.com/jlink-software.html).

**Updating MCU-Link firmware** This firmware in this debug interface may be updated using the host computer utility called MCU-Link. This typically used when switching between the default debugger protocol (CMSIS-DAP) to SEGGER J-Link, or for updating this firmware with new releases of these. This section contains the steps to reprogram the debug probe firmware.

**Note:** If MCUXpresso IDE is used and the jumper making DFUlink is installed on the board (JP5 on some boards, but consult the board user manual or schematic for specific jumper number), MCU-Link debug probe boots to DFU mode, and MCUXpresso IDE automatically downloads the

CMSIS-DAP firmware to the probe before flash memory programming (after clicking **Debug**). Using DFU mode ensures that most up-to-date/compatible firmware is used with MCUXpresso IDE.

NXP provides the MCU-Link utility, which is the recommended tool for programming the latest versions of CMSIS-DAP and J-Link firmware onto MCU-Link or NXP boards. The utility can be downloaded from [MCU-Link](#).

These steps show how to update the debugger firmware on your board for Windows operating system.

1. Install the MCU-Link utility.
2. Unplug the board's USB cable.
3. Make the DFU link (install the jumper labeled DFUlink).
4. Connect the probe to the host via USB (use Link USB connector).
5. Open a command shell and call the appropriate script located in the MCU-Link installation directory (<MCU-Link install dir>).
  1. To program CMSIS-DAP debug firmware: <MCU-Link install dir>/scripts/program\_CMSIS
  2. To program J-Link debug firmware: <MCU-Link install dir>/scripts/program\_JLINK
6. Remove DFU link (remove the jumper installed in Step 3).
7. Repower the board by removing the USB cable and plugging it in again.

**On-board debugger LPC-Link** LPC-Link 2 is an extensible debug probe that can be used seamlessly with MCUXpresso IDE, and is also compatible with 3rd party IDEs that support CMSIS-DAP protocol. MCU-Link also includes a USB to UART bridge feature (VCOM) that can be used to provide a serial connection between the target MCU and a host computer. LPC-Link 2 is compatible with Windows, MacOS and Linux. A free utility from NXP provides an easy way to install firmware updates.

On-board LPC-Link 2 debugger supports CMSIS-DAP and J-Link firmware. See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**

- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](#) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.
- If using J-Link with either a standalone debug pod or MCU-Link, install the J-Link software (drivers and utilities) from [www.segger.com/jlink-software.html](http://www.segger.com/jlink-software.html).

**Updating LPC-Link firmware** The LPCXpresso hardware platform comes with a CMSIS-DAP-compatible debug interface (known as LPC-Link2). This firmware in this debug interface may be updated using the host computer utility called LPCScrypt. This typically used when switching between the default debugger protocol (CMSIS-DAP) to SEGGER J-Link, or for updating this firmware with new releases of these. This section contains the steps to reprogram the debug probe firmware.

**Note:** If MCUXpresso IDE is used and the jumper making DFUlink is installed on the board (JP5 on some boards, but consult the board user manual or schematic for specific jumper number), LPC-Link2 debug probe boots to DFU mode, and MCUXpresso IDE automatically downloads the CMSIS-DAP firmware to the probe before flash memory programming (after clicking **Debug**). Using DFU mode ensures that most up-to-date/compatible firmware is used with MCUXpresso IDE.

NXP provides the LPCScrypt utility, which is the recommended tool for programming the latest versions of CMSIS-DAP and J-Link firmware onto LPC-Link2 or MCUXpresso boards. The utility can be downloaded from [LPCScrypt](#).

These steps show how to update the debugger firmware on your board for Windows operating system. For Linux OS, follow the instructions described in [LPCScrypt user guide](#) ([LPCScrypt](#), select **LPCScrypt**, and then the documentation tab).

1. Install the LPCScript utility.
2. Unplug the board's USB cable.
3. Make the DFU link (install the jumper labeled DFUlink).
4. Connect the probe to the host via USB (use Link USB connector).
5. Open a command shell and call the appropriate script located in the LPCScrypt installation directory (<LPCScrypt install dir>).
  1. To program CMSIS-DAP debug firmware: <LPCScrypt install dir>/scripts/program\_CMSIS
  2. To program J-Link debug firmware: <LPCScrypt install dir>/scripts/program\_JLINK
6. Remove DFU link (remove the jumper installed in Step 3).
7. Repower the board by removing the USB cable and plugging it in again.

**On-board debugger OpenSDA** OpenSDA/OpenSDAv2 is a serial and debug adapter that is built into several NXP evaluation boards. It provides a bridge between your computer (or other USB host) and the embedded target processor, which can be used for debugging, flash programming, and serial communication, all over a simple USB cable.

The difference is the firmware implementation: OpenSDA: Programmed with the proprietary P&E Micro developed bootloader. P&E Micro is the default debug interface app. OpenSDAv2: Programmed with the open-sourced CMSIS-DAP/mbed bootloader. CMSIS-DAP is the default debug interface app.

See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**

- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](#) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.
- For boards with a P&E Micro interface, see [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.


**Updating OpenSDA firmware** Any NXP hardware platform that comes with an OpenSDA-compatible debug interface has the ability to update the OpenSDA firmware. This typically means to switch from the default application (either CMSIS-DAP or P&E Micro) to a SEGGER J-Link. This section contains the steps to switch the OpenSDA firmware to a J-Link interface. However, the steps can be applied to restoring the original image also. For reference, OpenSDA firmware files can be found at the links below:

- J-Link: Download appropriate image from [www.segger.com/opensda.html](#). Choose the appropriate J-Link binary based on the table in [Default debug interfaces](#). Any OpenSDA v1.0 interface should use the standard OpenSDA download (in other words, the one with no version). For OpenSDA 2.0 or 2.1, select the corresponding binary.
- CMSIS-DAP: CMSIS-DAP OpenSDA firmware is available at [www.nxp.com/opensda](#).

- P&E Micro: Downloading P&E Micro OpenSDA firmware images requires registration with P&E Micro ([www.pemicro.com](http://www.pemicro.com)).

Perform the following steps to update the OpenSDA firmware on your board for Windows and Linux OS users:

1. Unplug the board's USB cable.
2. Press the **Reset** button on the board. While still holding the button, plug the USB cable back into the board.
3. When the board re-enumerates, it shows up as a disk drive called **MAINTENANCE**.



4. Drag and drop the new firmware image onto the MAINTENANCE drive.

**Note:** If for any reason the firmware update fails, the board can always reenter maintenance mode by holding down **Reset** button and power cycling.

These steps show how to update the OpenSDA firmware on your board for Mac OS users.

1. Unplug the board's USB cable.
2. Press the **Reset** button of the board. While still holding the button, plug the USB cable back into the board.
3. For boards with OpenSDA v2.0 or v2.1, it shows up as a disk drive called **BOOTLOADER** in **Finder**. Boards with OpenSDA v1.0 may or may not show up depending on the bootloader version. If you see the drive in **Finder**, proceed to the next step. If you do not see the drive in Finder, use a PC with Windows OS 7 or an earlier version to either update the OpenSDA firmware, or update the OpenSDA bootloader to version 1.11 or later. The bootloader update instructions and image can be obtained from P&E Microcomputer website.
4. For OpenSDA v2.1 and OpenSDA v1.0 (with bootloader 1.11 or later) users, drag the new firmware image onto the **BOOTLOADER** drive in **Finder**.
5. For OpenSDA v2.0 users, type these commands in a Terminal window:

```
> sudo mount -u -w -o sync /Volumes/BOOTLOADER
> cp -X <path to update file> /Volumes/BOOTLOADER
```

**Note:** If for any reason the firmware update fails, the board can always reenter bootloader mode by holding down the **Reset** button and power cycling.

**On-board debugger Multilink** An on-board Multilink debug circuit provides a JTAG interface and a power supply input through a single micro-USB connector. It is a hardware interface that allows PC software to debug and program a target processor through its debug port.

**The host driver must be installed before debugging.**

- See [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.

**On-board debugger OSJTAG** An on-board OSJTAG debug circuit provides a JTAG interface and a power supply input through a single micro-USB connector. It is a hardware interface that allows PC software to debug and program a target processor through its debug port.

**The host driver must be installed before debugging.**

- See [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.

## Default debug interfaces

The MCUXpresso SDK supports various hardware platforms that come loaded with various factory programmed debug interface configurations. The following table lists the hardware platforms supported by the MCUXpresso SDK, their default debug firmware, and any version information that helps differentiate a specific interface configuration.

Hardware platform	Default debugger firmware	On-board debugger probe
EVK-MCIMX7ULP	N/A	N/A
EVK-MIMX8MM	N/A	N/A
EVK-MIMX8MN	N/A	N/A
EVK-MIMX8MNDDR3L	N/A	N/A
EVK-MIMX8MP	N/A	N/A
EVK-MIMX8MQ	N/A	N/A
EVK-MIMX8ULP	N/A	N/A
EVK-MIMXRT1010	CMSIS-DAP	LPC-Link2
EVK-MIMXRT1015	CMSIS-DAP	LPC-Link2
EVK-MIMXRT1020	CMSIS-DAP	LPC-Link2
EVK-MIMXRT1064	CMSIS-DAP	LPC-Link2
EVK-MIMXRT595	CMSIS-DAP	LPC-Link2
EVK-MIMXRT685	CMSIS-DAP	LPC-Link2
EVK9-MIMX8ULP	N/A	N/A
EVKB-IMXRT1050	CMSIS-DAP	LPC-Link2
FRDM-K22F	CMSIS-DAP	OpenSDA v2
FRDM-K32L2A4S	CMSIS-DAP	OpenSDA v2
FRDM-K32L2B	CMSIS-DAP	OpenSDA v2
FRDM-K32L3A6	CMSIS-DAP	OpenSDA v2
FRDM-KE02Z40M	P&E Micro	OpenSDA v1
FRDM-KE15Z	CMSIS-DAP	OpenSDA v2
FRDM-KE16Z	CMSIS-DAP	OpenSDA v2
FRDM-KE17Z	CMSIS-DAP	OpenSDA v2
FRDM-KE17Z512	CMSIS-DAP	MCU-Link
FRDM-MCXA153	CMSIS-DAP	MCU-Link
FRDM-MCXA156	CMSIS-DAP	MCU-Link
FRDM-MCXA346	CMSIS-DAP	MCU-Link
FRDM-MCXC041	CMSIS-DAP	MCU-Link
FRDM-MCXC242	CMSIS-DAP	MCU-Link
FRDM-MCXC444	CMSIS-DAP	MCU-Link
FRDM-MCXE247	CMSIS-DAP	MCU-Link
FRDM-MCXN236	CMSIS-DAP	MCU-Link
FRDM-MCXN947	CMSIS-DAP	MCU-Link
FRDM-MCXW23	CMSIS-DAP	MCU-Link
FRDM-MCXW71	CMSIS-DAP	MCU-Link
FRDM-MCXW72	CMSIS-DAP	MCU-Link
FRDM-RW612	CMSIS-DAP	MCU-Link
IMX943-EVK	N/A	N/A
IMX95LP4XEVK-15	N/A	N/A
IMX95LPD5EVK-19	N/A	N/A
IMX95VERDINEVK	N/A	N/A
KW45B41Z-EVK	CMSIS-DAP	MCU-Link
KW45B41Z-LOC	CMSIS-DAP	MCU-Link
KW47-EVK	CMSIS-DAP	MCU-Link
KW47-LOC	CMSIS-DAP	MCU-Link
LPC845BREAKOUT	CMSIS-DAP	LPC-Link2
LPCXpresso51U68	CMSIS-DAP	LPC-Link2
LPCXpresso54628	CMSIS-DAP	LPC-Link2

continues on next page

Table 1 – continued from previous page

Hardware platform	Default debugger firmware	On-board debugger probe
LPCXpresso54S018	CMSIS-DAP	LPC-Link2
LPCXpresso54S018M	CMSIS-DAP	LPC-Link2
LPCXpresso55S06	CMSIS-DAP	LPC-Link2
LPCXpresso55S16	CMSIS-DAP	LPC-Link2
LPCXpresso55S28	CMSIS-DAP	LPC-Link2
LPCXpresso55S36	CMSIS-DAP	MCU-Link
LPCXpresso55S69	CMSIS-DAP	LPC-Link2
LPCXpresso802	CMSIS-DAP	LPC-Link2
LPCXpresso804	CMSIS-DAP	LPC-Link2
LPCXpresso824MAX	CMSIS-DAP	LPC-Link2
LPCXpresso845MAX	CMSIS-DAP	LPC-Link2
LPCXpresso860MAX	CMSIS-DAP	LPC-Link2
MC56F80000-EVK	P&E Micro	Multilink
MC56F81000-EVK	P&E Micro	Multilink
MC56F83000-EVK	P&E Micro	OSJTAG
MCIMX93-EVK	N/A	N/A
MCIMX93-QSB	N/A	N/A
MCIMX93AUTO-EVK	N/A	N/A
MCX-N5XX-EVK	CMSIS-DAP	MCU-Link
MCX-N9XX-EVK	CMSIS-DAP	MCU-Link
MCX-W71-EVK	CMSIS-DAP	MCU-Link
MCX-W72-EVK	CMSIS-DAP	MCU-Link
MIMXRT1024-EVK	CMSIS-DAP	LPC-Link2
MIMXRT1040-EVK	CMSIS-DAP	LPC-Link2
MIMXRT1060-EVKB	CMSIS-DAP	LPC-Link2
MIMXRT1060-EVKC	CMSIS-DAP	MCU-Link
MIMXRT1160-EVK	CMSIS-DAP	LPC-Link2
MIMXRT1170-EVKB	CMSIS-DAP	MCU-Link
MIMXRT1180-EVK	CMSIS-DAP	MCU-Link
MIMXRT685-AUD-EVK	CMSIS-DAP	LPC-Link2
MIMXRT700-EVK	CMSIS-DAP	MCU-Link
RD-RW612-BGA	CMSIS-DAP	MCU-Link
TWR-KM34Z50MV3	P&E Micro	OpenSDA v1
TWR-KM34Z75M	P&E Micro	OpenSDA v1
TWR-KM35Z75M	CMSIS-DAP	OpenSDA v2
TWR-MC56F8200	P&E Micro	OSJTAG
TWR-MC56F8400	P&E Micro	OSJTAG

### How to define IRQ handler in CPP files

With MCUXpresso SDK, users could define their own IRQ handler in application level to override the default IRQ handler. For example, to override the default PIT\_IRQHandler define in startup\_DEVICE.s, application code like app.c can be implement like:

```
// c
void PIT_IRQHandler(void)
{
    // Your code
}
```

When application file is CPP file, like app.cpp, then extern "C" should be used to ensure the function prototype alignment.

```
// cpp
extern "C" {
    void PIT_IRQHandler(void);
}
void PIT_IRQHandler(void)
{
    // Your code
}
```

## 1.3 Getting Started with MCUXpresso SDK GitHub


### 1.3.1 Getting Started with MCUXpresso SDK Repository

#### Installation

##### NOTE

If the installation instruction asks/selects whether to have the tool installation path added to the PATH variable, agree/select the choice. This option ensures that the tool can be used in any terminal in any path. *Verify the installation* after each tool installation.

**Install Prerequisites with MCUXpresso Installer** The MCUXpresso Installer offers a quick and easy way to install the basic tools needed. The MCUXpresso Installer can be obtained from <https://github.com/nxp-mcuxpresso/vscode-for-mcux/wiki/Dependency-Installation>. The MCUXpresso Installer is an automated installation process, simply select MCUXpresso SDK Developer from the menu and click install. If you prefer to install the basic tools manually, refer to the next section.



## Alternative: Manual Installation

### Basic tools

**Git** Git is a free and open source distributed version control system. Git is designed to handle everything from small to large projects with speed and efficiency. To install Git, visit the official [Git website](#). Download the appropriate version(you may use the latest one) for your operating system (Windows, macOS, Linux). Then run the installer and follow the installation instructions.

User `git --version` to check the version if you have a version installed.

Then configure your username and email using the commands:

```
git config --global user.name "Your Name"  
git config --global user.email "youremail@example.com"
```

**Python** Install python 3.10 or latest. Follow the [Python Download](#) guide.

Use `python --version` to check the version if you have a version installed.

**West** Please use the west version equal or greater than 1.2.0

```
# Note: you can add option '--default-timeout=1000' if you meet connection issue. Or you may set a different  
# source using option '-i'.  
# for example, in China you could try: pip install -U west -i https://pypi.tuna.tsinghua.edu.cn/simple  
pip install -U west
```

### Build And Configuration System

**CMake** It is strongly recommended to use CMake version equal or later than 3.30.0. You can get latest CMake distributions from [the official CMake download page](#).

For Windows, you can directly use the .msi installer like [cmake-3.31.4-windows-x86\\_64.msi](#) to install.

For Linux, CMake can be installed using the system package manager or by getting binaries from [the official CMake download page](#).

After installation, you can use `cmake --version` to check the version.

**Ninja** Please use the ninja version equal or later than 1.12.1.

By default, Windows comes with the Ninja program. If the default Ninja version is too old, you can directly download the [ninja binary](#) and register the ninja executor location path into your system path variable to work.

For Linux, you can use your system package manager or you can directly download the [ninja binary](#) to work.

After installation, you can use `ninja --version` to check the version.

**Kconfig** MCUXpresso SDK uses Kconfig python implementation. We customize it based on our needs and integrate it into our build and configuration system. The Kconfiglib sources are placed under `mcuxsdk/scripts/kconfig` folder.

Please make sure [python](#) environment is setup ready then you can use the Kconfig.

**Ruby** Our build system supports IDE project generation for iar, mdk, codewarrior and xtensa to provide OOB from build to debug. This feature is implemented with ruby. You can follow the guide ruby environment setup to setup the ruby environment. Since we provide a built-in portable ruby, it is just a simple one cmd installation.

If you only work with CLI, you can skip this step.

**Toolchain** MCUXpresso SDK supports all mainstream toolchains for embedded development. You can install your used or interested toolchains following the guides.

Toolchain	Download and Installation Guide	Note
Armgcc	<a href="#">Arm GNU Toolchain Install Guide</a>	ARMGCC is default toolchain
IAR	<a href="#">IAR Installation and Licensing quick reference guide</a>	
MDK	<a href="#">MDK Installation</a>	
Armclang	<a href="#">Installing Arm Compiler for Embedded</a>	
Zephyr	<a href="#">Zephyr SDK</a>	
Codewarrior	<a href="#">NXP CodeWarrior</a>	
Xtensa	<a href="#">Tensilica Tools</a>	
NXP S32Compiler RISC-V Zen-V	<a href="#">NXP Website</a>	

After you have installed the toolchains, register them in the system environment variables. This will allow the west build to recognize them:

Toolchain	Environment Variable	Example	Cmd Line Argument
Armgcc	ARMGCC_DIR	C:\armgcc for windows/usr for Linux. arm-none-eabi-* is installed under /usr/bin	– toolchain armgcc
IAR	IAR_DIR	C:\iar\ewarm-9.60.3 for Windows/opt/iar/systems/bxarm-9.60.3 for Linux	– toolchain iar
MDK	MDK_DIR	C:\Keil_v5 for Windows.MDK IDE is not officially supported with Linux.	– toolchain mdk
Armclang	ARM-CLANG_DIR	C:\ArmCompilerforEmbedded6.22 for Windows/opt/ArmCompilerforEmbedded6.21 for Linux	– toolchain mdk
Zephyr	ZEPHYR_SHELL	c:\NXP\zephyr-sdk-<version> for windows/opt/zephyr-sdk-<version> for Linux	– toolchain zephyr
CodeWarrior	CW_DIR	C:\Freescale\CW MCU v11.2 for windowsCodeWarrior is not supported with Linux	– toolchain code-warrior
Xtensa	XCC_DIR	C:\xtensa\XtDevTools\install\tools\RI-2023.11-win32\XtensaTools for windows/opt/xtensa/XtDevTools/install/tools/RI-2023.11-Linux/XtensaTools for Linux	– toolchain xtensa
NXP RISC-V S32Compiler	RISCV-LVM_DIR	C:\riscv-llvm-win32_b298_b298_2024.08.12 for Windows/opt/riscv-llvm-Linux-x64_b298_b298_2024.08.12 for Linux	– toolchain riscv-lvm

- The <toolchain>\_DIR is the root installation folder, not the binary location folder. For IAR, it is directory containing following installation folders:

-  arm
-  common
-  install-info

- MDK IDE using armclang toolchain only officially supports Windows. In Linux, please directly use armclang toolchain by setting ARMCLANG\_DIR. In Windows, since most Keil users will install MDK IDE instead of standalone armclang toolchain, the MDK\_DIR has higher priority than ARMCLANG\_DIR.
- For Xtensa toolchain, please set the XTENSA\_CORE environment variable. Here's an example list:

Device Core	XTENSA_CORE
RT500 fusion1	nxp_rt500_RI23_11_newlib
RT600 hifi4	nxp_rt600_RI23_11_newlib
RT700 hifi1	rt700_hifi1_RI23_11_nlib
RT700 hifi4	t700_hifi4_RI23_11_nlib
i.MX8ULP fusion1	fusion_nxp02_dsp_prod

- In Windows, the short path is used in environment variables. If any toolchain is using the long path, you can open a command window from the toolchain folder and use below command to get the short path: for %i in (.) do echo %~fsi

**Tool installation check** Once installed, open a terminal or command prompt and type the associated command to verify the installation.

If you see the version number, you have successfully installed the tool. Else, check whether the tool's installation path is added into the PATH variable. You can add the installation path to the PATH with the commands below:

- Windows: Open command prompt or powershell, run below command to show the user PATH variable.

```
reg query HKEY_CURRENT_USER\Environment /v PATH
```

The tool installation path should be C:\Users\xxx\AppData\Local\Programs\Git\cmd. If the path is not seen in the output from above, append the path value to the PATH variable with the command below:

```
reg add HKEY_CURRENT_USER\Environment /v PATH /d "%PATH%;C:\Users\xxx\AppData\Local\Programs\Git\cmd"
```

Then close the command prompt or powershell and verify the tool command again.

- Linux:

1. Open the \$HOME/.bashrc file using a text editor, such as vim.
2. Go to the end of the file.
3. Add the line which appends the tool installation path to the PATH variable and export PATH at the end of the file. For example, export PATH="/Directory1:\$PATH".
4. Save and exit.
5. Execute the script with source .bashrc or reboot the system to make the changes live. To verify the changes, run echo \$PATH.

- macOS:

1. Open the \$HOME/.bash\_profile file using a text editor, such as nano.
2. Go to the end of the file.
3. Add the line which appends the tool installation path to the PATH variable and export PATH at the end of the file. For example, export PATH="/Directory1:\$PATH".
4. Save and exit.
5. Execute the script with source .bash\_profile or reboot the system to make the changes live. To verify the changes, run echo \$PATH.

## Get MCUXpresso SDK Repo

**Establish SDK Workspace** To get the MCUXpresso SDK repository, use the west tool to clone the manifest repository and checkout all the west projects.

```
# Initialize west with the manifest repository
west init -m https://github.com/nxp-mcuxpresso/mcuxsdk-manifests/ mcuxpresso-sdk

# Update the west projects
cd mcuxpresso-sdk
west update

# Allow the usage of west extensions provided by MCUXpresso SDK
west config commands.allow_extensions true
```

**Install Python Dependency(If do tool installation manually)** To create a Python virtual environment in the west workspace core repo directory mcuxsdk, follow these steps:

1. Navigate to the core directory:

```
cd mcuxsdk
```

2. [Optional] Create and activate the virtual environment: If you don't want to use the python virtual environment, skip this step. **We strongly suggest you use venv to avoid conflicts with other projects using python.**

```
python -m venv .venv

# For Linux/MacOS
source .venv/bin/activate

# For Windows
.\venv\Scripts\activate
# If you are using powershell and see the issue that the activate script cannot be run.
# You may fix the issue by opening the powershell as administrator and run below command:
powershell Set-ExecutionPolicy RemoteSigned
# then run above activate command again.
```

Once activated, your shell will be prefixed with (.venv). The virtual environment can be deactivated at any time by running deactivate command.

**Remember to activate the virtual environment every time you start working in this directory.** If you are using some modern shell like zsh, there are some powerful plugins to help you auto switch venv among workspaces. For example, `zsh-autoswitch-virtualenv`.

3. Install the required Python packages:

```
# Note: you can add option '--default-timeout=1000' if you meet connection issue. Or you may set a
# different source using option '-i'.
# for example, in China you could try: pip3 install -r mcuxsdk/scripts/requirements.txt -i https://pypi.
# tuna.tsinghua.edu.cn/simple
pip install -r scripts/requirements.txt
```

## Explore Contents

This section helps you build basic understanding of current fundamental project content and guides you how to build and run the provided example project in whole SDK delivery.

**Folder View** The whole MCUXpresso SDK project, after you have done the west init and west update operations follow the guideline at [Getting Started Guide](#), have below folder structure:

Folder	Description
manifests	Manifest repo, contains the manifest file to initialize and update the west workspace.
mcuxsdk	The MCUXpresso SDK source code, examples, middleware integration and script files.

All the projects record in the [Manifest repo](#) are checked out to the folder mcuxsdk/, the layout of mcuxsdk folder is shown as below:

Folder	Description
arch	Arch related files such as ARM CMSIS core files, RISC-V files and the build files related to the architecture.
cmake	The cmake modules, files which organize the build system.
components	Software components.
devices	Device support package which categorized by device series. For each device, header file, feature file, startup file and linker files are provided, also device specific drivers are included.
docs	Documentation source and build configuration for this sphinx built online documentation.
drivers	Peripheral drivers.
examples	Various demos and examples, support files on different supported boards. For each board support, there are board configuration files.
middleware	Middleware components integrated into SDK.
rtos	Rtos components integrated into SDK.
scripts	Script files for the west extension command and build system support.
svd	Svd files for devices, this is optional because of large size. Customers run west manifest config group.filter +optional and west update mcux-soc-svd to get this folder.

**Examples Project** The examples project is part of the whole SDK delivery, and locates in the folder mcuxsdk/examples of west workspace.

Examples files are placed in folder of <example\_category>, these examples include (but are not limited to)

- demo\_apps: Basic demo set to start using SDK, including hello\_world and led\_blinky.
- driver\_examples: Simple applications that show how to use the peripheral drivers for a single use case. These applications typically only use a single peripheral but there are cases where multiple peripherals are used (for example, SPI transfer using DMA).

Board porting layers are placed in folder of \_boards/<board\_name> which aims at providing the board specific parts for examples code mentioned above.

### Run a demo using MCUXpresso for VS Code


This section explains how to configure MCUXpresso for VS Code to build, run, and debug example applications. This guide uses the hello\_world demo application as an example. However, these

steps can be applied to any example application in the MCUXpresso SDK.

**Build an example application** This section assumes that the user has already obtained the SDK as outlined in [Get MCUXpresso SDK Repo](#).


To build an example application:

1. Import the SDK into your workspace. Click **Import Repository** from the **QUICKSTART PANEL**.




**Note:** You can import the SDK in several ways. Refer to [MCUXpresso for VS Code Wiki](#) for details.


Select **Local** if you've already obtained the SDK as seen in [Get MCUXpresso SDK Repo](#). Select your location and click **Import**.



2. Click **Import Example from Repository** from the **QUICKSTART PANEL**.




In the dropdown menu, select the MCUXpresso SDK, the Arm GNU Toolchain, your board, template, and application type. Click **Import**.



**Note:** The MCUXpresso SDK projects can be imported as **Repository applications** or **Free-standing applications**. The difference between the two is the import location. Projects imported as Repository examples will be located inside the MCUXpresso SDK, whereas Free-standing examples can be imported to a user-defined location. Select between these by designating your selection in the **App type** dropdown menu.

3. VS Code will prompt you to confirm if the imported files are trusted. Click **Yes**.
4. Navigate to the **PROJECTS** view. Find your project and click the **Build Project** icon.




The integrated terminal will open at the bottom and will display the build output.


```
[17/21] Building C object CMakeFiles/hello_world.dir/C_/Repos/mcux-sdk/mcux-sdk/components/debug_console_lite/fsl_debug_console.c.obj
[18/21] Building C object CMakeFiles/hello_world.dir/C_/Repos/mcux-sdk/mcux-sdk/devices/MCX/MCX444/drivers/fsl_clock.c.obj
[19/21] Building C object CMakeFiles/hello_world.dir/C_/Repos/mcux-sdk/mcux-sdk/drivers/1puart/fsl_1puart.c.obj
[20/21] Building C object CMakeFiles/hello_world.dir/C_/Repos/mcux-sdk/mcux-sdk/drivers/uart/fsl_uart.c.obj
[21/21] Linking C executable hello_world.elf
Memory region      Used Size  Region Size %age Used
  m_interrupts:      192 B      512 B   37.50%
  m_flash_config:     16 B       16 B  100.00%
  m_text:      7892 B    261104 B   3.02%
  m_data:       2128 B      32 KB   6.49%
build finished successfully.
* Terminal will be reused by tasks, press any key to close it.
```

**Run an example application** **Note:** for full details on MCUXpresso for VS Code debug probe support, see [MCUXpresso for VS Code Wiki](#).


1. Open the **Serial Monitor** from the VS Code's integrated terminal. Select the VCom Port for your device and set the baud rate to 115200.



2. Navigate to the **PROJECTS** view and click the play button to initiate a debug session.



The debug session will begin. The debug controls are initially at the top.




```

C hello_world.c ×
frdmmcx444_hello_world > examples > demo_apps > hello_world > C hello_... ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ | i→ ⌂
18  ****
19
20  ****
21  ****
22  ****
23  * Variables
24  ****
25
26  ****
27  * Code
28  ****
29  */
30  * @brief Main function
31  */
32  int main(void)
33  {
34      char ch;
35
36      /* Init board hardware. */
37      BOARD_InitHardware();
38
39      PRINTF("hello world.\r\n");
40
41      while (1)
42      {
43          ch = GETCHAR();
44          PUTCHAR(ch);
45      }
46  }
47

```

3. Click **Continue** on the debug controls to resume execution of the code. Observe the output on the **Serial Monitor**.



### Running a demo using ARMGCC CLI/IAR/MDK

**Supported Boards** Use the west extension west list\_project to understand the board support scope for a specified example. All supported build command will be listed in output:

```
west list_project -p examples/demo_apps/hello_world [-t armgcc]

INFO: [ 1][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b evk9mimx8ulp -Dcore_id=cm33]
INFO: [ 2][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b evkbimxrt1050]
INFO: [ 3][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b (continues on next page)
```

(continued from previous page)

```

↳ evkbmimxrt1060]
INFO: [ 4][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b
↳ evkbmimxrt1170 -Dcore_id=cm4]
INFO: [ 5][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b
↳ evkbmimxrt1170 -Dcore_id=cm7]
INFO: [ 6][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b
↳ evkcmimxrt1060]
INFO: [ 7][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b
↳ evkmcimx7ulp]
...

```

The supported toolchains and build targets for an example are decided by the example-self example.yml and board example.yml, please refer Example Toolchains and Targets for more details.

**Build the project** Use west build -h to see help information for west build command. Compared to zephyr's west build, MCUXpresso SDK's west build command provides following additional options for mcux examples:

- --toolchain: specify the toolchain for this build, default armgcc.
- --config: value for CMAKE\_BUILD\_TYPE. If not provided, build system will get all the example supported build targets and use the first debug target as the default one. Please refer Example Toolchains and Targets for more details about example supported build targets.

Here are some typical usages for generating a SDK example:

```

# Generate example with default settings, default used device is the mainset MK22F51212
west build -b frdmk22f examples/demo_apps/hello_world

# Just print cmake commands, do not execute it
west build -b frdmk22f examples/demo_apps/hello_world --dry-run

# Generate example with other toolchain like iar, default armgcc
west build -b frdmk22f examples/demo_apps/hello_world --toolchain iar

# Generate example with other config type
west build -b frdmk22f examples/demo_apps/hello_world --config release

# Generate example with other devices with --device
west build -b frdmk22f examples/demo_apps/hello_world --device MK22F12810 --config release

```

For multicore devices, you shall specify the corresponding core id by passing the command line argument -Dcore\_id. For example

```

west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config
↳ flexspi_nor_debug

```

For shield, please use the --shield to specify the shield to run, like

```

west build -b mimxrt700evk --shield a8974 examples/issdk_examples/sensors/fxls8974cf/fxls8974cf_poll -
↳ Dcore_id=cm33_core0

```

**Sysbuild(System build)** To support multicore project building, we ported Sysbuild from Zephyr. It supports combine multiple projects for compilation. You can build all projects by adding --sysbuild for main application. For example:

```

west build -b evkbmimxrt1170 --sysbuild ./examples/multicore_examples/hello_world/primary -Dcore_
↳ id=cm7 --config flexspi_nor_debug --toolchain=armgcc -p always

```

For more details, please refer to System build.

**Config a Project** Example in MCUXpresso SDK is configured and tested with pre-defined configuration. You can follow steps blow to change the configuration.

1. Run cmake configuration


```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world -Dcore_id=cm7 --cmake-only -p
```

Please note the project will be built without --cmake-only parameter.

2. Run guiconfig target

```
west build -t guiconfig
```

Then you will get the Kconfig GUI launched, like



```
Kconfig definition, with parent deps. propagated to 'depends on'
=====
At D:/sdk_next/mcux-sdk/devices/../devices/RT/RT1170/MIMXRT1176/drivers/Kconfig:5
Included via D:/sdk_next/mcux-sdk/examples/demo_apps/hello_world/Kconfig:6 ->
D:/sdk_next/mcux-sdk/Kconfig.mcuxpresso:9 -> D:/sdk_next/mcux-sdk/devices/Kconfig:1
-> D:/sdk_next/mcux-sdk/devices/../devices/RT/RT1170/MIMXRT1176/Kconfig:8
Menu path: (Top)
```

```
menu "Device specific drivers"
```

You can reconfigure the project by selecting/deselecting Kconfig options.

After saving and closing the Kconfig GUI, you can directly run west build to build with the new configuration.

**Flash Note:** Please refer Flash and Debug The Example to enable west flash/debug support.

Flash the hello\_world example:

```
west flash -r linkserver
```

**Debug** Start a gdb interface by following command:


```
west debug -r linkserver
```

**Work with IDE Project** The above build functionalities are all with CLI. If you want to use the toolchain IDE to work to enjoy the better user experience especially for debugging or you are already used to develop with IDEs like IAR, MDK, Xtensa and CodeWarrior in the embedded world, you can play with our IDE project generation functionality.

This is the cmd to generate the evkbmimxrt1170 hello\_world IAR IDE project files.

```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config ↵
 ↵flexspi_nor_debug -p always -t guiproject
```

By default, the IDE project files are generated in mcux-sdk/build/<toolchain> folder, you can open the project file with the IDE tool to work:



Note, please follow the [Installation](#) to setup the environment especially make sure that [ruby](#) has been installed.

## 1.4 Release Notes

### 1.4.1 MCUXpresso SDK Release Notes

#### Overview

The MCUXpresso SDK is a comprehensive software enablement package designed to simplify and accelerate application development with Arm Cortex-M-based devices from NXP, including its general purpose, crossover and Bluetooth-enabled MCUs. MCUXpresso SW and Tools for DSC

further extends the SDK support to current 32-bit Digital Signal Controllers. The MCUXpresso SDK includes production-grade software with integrated RTOS (optional), integrated enabling software technologies (stacks and middleware), reference software, and more.

In addition to working seamlessly with the MCUXpresso IDE, the MCUXpresso SDK also supports and provides example projects for various toolchains. The Development tools chapter in the associated Release Notes provides details about toolchain support for your board. Support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

Underscoring our commitment to high quality, the MCUXpresso SDK is MISRA compliant and checked with Coverity static analysis tools. For details on MCUXpresso SDK, see [MCUXpresso-SDK: Software Development Kit for MCUXpresso](#).

## MCUXpresso SDK

As part of the MCUXpresso software and tools, MCUXpresso SDK is the evolution of Kinetis SDK, includes support for LPC, DSC, PN76, and i.MX System-on-Chip (SoC). The same drivers, APIs, and middleware are still available with support for Kinetis, LPC, DSC, and i.MX silicon. The MCUXpresso SDK adds support for the MCUXpresso IDE, an Eclipse-based toolchain that works with all MCUXpresso SDKs. Easily import your SDK into the new toolchain to access to all of the available components, examples, and demos for your target silicon. In addition to the MCUXpresso IDE, support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

In order to maintain compatibility with legacy Freescale code, the filenames and source code in MCUXpresso SDK containing the legacy Freescale prefix FSL has been left as is. The FSL prefix has been redefined as the NXP Foundation Software Library.

## Development tools

The MCUXpresso SDK was tested with following development tools. Same versions or above are recommended.

- MCUXpresso IDE, Rev. 25.06.xx
- IAR Embedded Workbench for Arm, version is 9.60.4
- Keil MDK, version is 5.41
- MCUXpresso for VS Code v25.06
- GCC Arm Embedded Toolchain 14.2.x

## Supported development systems

This release supports board and devices listed in following table. The board and devices in bold were tested in this release.

Development boards	MCU devices
<b>LPCXpresso824MAJ</b>	LPC822M101JDH20, <b>LPC824M201JHI33</b> , LPC822M101JHI33, LPC824M201JDH20, LPC832M101FDH20, LPC834M101FHI33

## MCUXpresso SDK release package

The MCUXpresso SDK release package content is aligned with the silicon subfamily it supports. This includes the boards, CMSIS, devices, middleware, and RTOS support.

**Device support** The device folder contains the whole software enablement available for the specific System-on-Chip (SoC) subfamily. This folder includes clock-specific implementation, device register header files, device register feature header files, and the system configuration source files. Included with the standard SoC support are folders containing peripheral drivers, toolchain support, and a standard debug console. The device-specific header files provide a direct access to the microcontroller peripheral registers. The device header file provides an overall SoC memory mapped register definition. The folder also includes the feature header file for each peripheral on the microcontroller. The toolchain folder contains the startup code and linker files for each supported toolchain. The startup code efficiently transfers the code execution to the main() function.

**Board support** The boards folder provides the board-specific demo applications, driver examples, and middleware examples.

**Demo application and other examples** The demo applications demonstrate the usage of the peripheral drivers to achieve a system level solution. Each demo application contains a readme file that describes the operation of the demo and required setup steps. The driver examples demonstrate the capabilities of the peripheral drivers. Each example implements a common use case to help demonstrate the driver functionality.

## Middleware

**CMSIS DSP Library** The MCUXpresso SDK is shipped with the standard CMSIS development pack, including the prebuilt libraries.

**FreeMASTER** FreeMASTER communication driver for 32-bit platforms.

## Release contents

Provides an overview of the MCUXpresso SDK release package contents and locations.

Deliverable	Location
Boards	INSTALL_DIR/boards
Demo Applications	INSTALL_DIR/boards/<board_name>/demo_apps
Driver Examples	INSTALL_DIR/boards/<board_name>/driver_examples
eIQ examples	INSTALL_DIR/boards/<board_name>/eiq_examples
Board Project Template for MCUXpresso IDE NPW	INSTALL_DIR/boards/<board_name>/project_template
Driver, SoC header files, extension header files and feature header files, utilities	INSTALL_DIR/devices/<device_name>
CMSIS drivers	INSTALL_DIR/devices/<device_name>/cmsis_drivers
Peripheral drivers	INSTALL_DIR/devices/<device_name>/drivers
Toolchain linker files and startup code	INSTALL_DIR/devices/<device_name>/<toolchain_name>
Utilities such as debug console	INSTALL_DIR/devices/<device_name>/utilities
Device Project Template for MCUXpresso IDE NPW	INSTALL_DIR/devices/<device_name>/project_template
CMSIS Arm Cortex-M header files, DSP library source	INSTALL_DIR/CMSIS
Components and board device drivers	INSTALL_DIR/components
RTOS	INSTALL_DIR/rtos
Release Notes, Getting Started Document and other documents	INSTALL_DIR/docs
Tools such as shared cmake files	INSTALL_DIR/tools
Middleware	INSTALL_DIR/middleware

## Known issues

This section lists the known issues, limitations, and/or workarounds.

### Cannot add SDK components into FreeRTOS projects

It is not possible to add any SDK components into FreeRTOS project using the MCUXpresso IDE New Project wizard.

## 1.5 ChangeLog

### 1.5.1 MCUXpresso SDK Changelog

#### Board Support Files

##### board

##### [25.06.00]

- Initial version

##### clock\_config

##### [25.06.00]

- Initial version

##### pin\_mux

**[25.06.00]**

- Initial version

---

**LPC\_ACOMP**

**[2.1.0]**

- Bug Fixes
  - Fixed one wrong enum value for the hysteresis.
  - Fixed the violations of MISRA C-2012 rules:
    - \* Rule 10.1, 17.7.

**[2.0.2]**

- Bug Fixes
  - Fixed the out-of-bounds error of Coverity caused by missing an assert sentence to avoid the return value of ACOMP\_GetInstance() exceeding the array bounds.

**[2.0.1]**

- New Features
  - Added a control macro to enable/disable the CLOCK code in current driver.

**[2.0.0]**

- Initial version.

---

**LPC\_ADC**

**[2.6.0]**

- New Features
  - Added new feature macro to distinguish whether the GPADC\_CTRL0\_GPADC\_TSAMP control bit is on the device.
  - Added new variable extendSampleTimeNumber to indicate the ADC extend sample time.
- Bugfix
  - Fixed the bug that incorrectly sets the PASS\_ENABLE bit based on the sample time setting.

**[2.5.3]**

- Improvements
  - Release peripheral from reset if necessary in init function.

**[2.5.2]**

- Improvements
  - Integrated different sequence's sample time numbers into one variable.
- Bug Fixes
  - Fixed violation of MISRA C-2012 rule 20.9 .

**[2.5.1]**

- Bug Fixes
  - Fixed ADC conversion sequence priority misconfiguration issue in the ADC\_SetConvSeqAHighPriority() and ADC\_SetConvSeqBHighPriority() APIs.
- Improvements
  - Supported configuration ADC conversion sequence sampling time.

**[2.5.0]**

- Improvements
  - Add missing parameter tag of ADC\_DoOffsetCalibration().
- Bug Fixes
  - Removed a duplicated API with typo in name: ADC\_EnableShresholdCompareInterrupt().

**[2.4.1]**

- Bug Fixes
  - Enabled self-calibration after clock divider be changed to make sure the frequency update be taken.

**[2.4.0]**

- New Features
  - Added new API ADC\_DoOffsetCalibration() which supports a specific operation frequency.
- Other Changes
  - Marked the ADC\_DoSelfCalibration(ADC\_Type \*base) as deprecated.
- Bug Fixes
  - Fixed the violations of MISRA C-2012 rules:
    - \* Rule 10.1 10.3 10.4 10.7 10.8 17.7.

**[2.3.2]**

- Improvements
  - Added delay after enabling using the ADC GPADC\_CTRL0 LDO\_POWER\_EN bit for JN5189/QN9090.
- New Features
  - Added support for platforms which have only one ADC sequence control/result register.

### [2.3.1]

- Bug Fixes
  - Avoided writing ADC STARTUP register in ADC\_Init().
  - Fixed Coverity zero divider error in ADC\_DoSelfCalibration().

### [2.3.0]

- Improvements
  - Updated “ADC\_Init()” “ADC\_GetChannelConversionResult()” API and “adc\_resolution\_t” structure to match QN9090.
  - Added “ADC\_EnableTemperatureSensor” API.

### [2.2.1]

- Improvements
  - Added a brief delay in uSec after ADC calibration start.

### [2.2.0]

- Improvements
  - Updated “ADC\_DoSelfCalibration” API and “adc\_config\_t” structure to match LPC845.

### [2.1.0]

- Improvements
  - Renamed “ADC\_EnableShresholdCompareInterrupt” to “ADC\_EnableThresholdCompareInterrupt”.

### [2.0.0]

- Initial version.

---

## CLOCK

### [2.4.4]

- Bug Fixes
  - Fixed CLOCK\_GetUartClkFreq overflow issue.

### [2.4.3]

- Improvements
  - Added lost comments for some enumerations.

## [2.4.2]

- New feature:
  - Add CLOCK\_GetUartnClkFreq() API.
- Bug Fixes
  - Fixed the operands out of bounds in CLOCK\_GetUartClkFreq().

## [2.3.2]

- Improvements
  - Used “offsetof” macro to get the offset of the structure element from the beginning of the structure.

## [2.3.1]

- Bug Fixes
  - Fixed MISRA C-2012 rule 10.1, rule 10.3 and rule 10.4.
  - Fixed IAR warning Pa082 for the clock driver.

## [2.3.0]

- New feature:
  - Moved SDK\_DelayAtLeastUs function from clock driver to common driver.

## [2.2.0]

- Replace the delay function

## [2.1.0]

- New feature
  - Adding new API CLOCK\_DelayAtLeastUs() to implement a delay function which allows users to set delay in unit of microsecond.

## [2.0.4]

- Add value check in CLOCK\_InitSystemPll() and CLOCK\_SetUARTFRGClkFreq() to make sure divisor in the division expression is not 0.

## [2.0.3]

- add api to get uart clock frequency.
- add api to set fractional multiplier value.

## [2.0.2]

- some minor fixes.

**[2.0.0]**

- initial version.

---

**COMMON**

**[2.6.0]**

- Bug Fixes
  - Fix CERT-C violations.

**[2.5.0]**

- New Features
  - Added new APIs InitCriticalSectionMeasurementContext, DisableGlobalIRQEx and EnableGlobalIRQEx so that user can measure the execution time of the protected sections.

**[2.4.3]**

- Improvements
  - Enable irqs that mount under irqsteer interrupt extender.

**[2.4.2]**

- Improvements
  - Add the macros to convert peripheral address to secure address or non-secure address.

**[2.4.1]**

- Improvements
  - Improve for the macro redefinition error when integrated with zephyr.

**[2.4.0]**

- New Features
  - Added EnableIRQWithPriority, IRQ\_SetPriority, and IRQ\_ClearPendingIRQ for ARM.
  - Added MSDK\_EnableCpuCycleCounter, MSDK\_GetCpuCycleCount for ARM.

**[2.3.3]**

- New Features
  - Added NETC into status group.

**[2.3.2]**

- Improvements
  - Make driver aarch64 compatible

### [2.3.1]

- Bug Fixes
  - Fixed MAKE\_VERSION overflow on 16-bit platforms.

### [2.3.0]

- Improvements
  - Split the driver to common part and CPU architecture related part.

### [2.2.10]

- Bug Fixes
  - Fixed the ATOMIC macros build error in cpp files.

### [2.2.9]

- Bug Fixes
  - Fixed MISRA C-2012 issue, 5.6, 5.8, 8.4, 8.5, 8.6, 10.1, 10.4, 17.7, 21.3.
  - Fixed SDK\_Malloc issue that not allocate memory with required size.

### [2.2.8]

- Improvements
  - Included stddef.h header file for MDK tool chain.
- New Features:
  - Added atomic modification macros.

### [2.2.7]

- Other Change
  - Added MECC status group definition.

### [2.2.6]

- Other Change
  - Added more status group definition.
- Bug Fixes
  - Undef \_\_VECTOR\_TABLE to avoid duplicate definition in cmsis\_clang.h

### [2.2.5]

- Bug Fixes
  - Fixed MISRA C-2012 rule-15.5.

#### [2.2.4]

- Bug Fixes
  - Fixed MISRA C-2012 rule-10.4.

#### [2.2.3]

- New Features
  - Provided better accuracy of `SDK_DelayAtLeastUs` with DWT, use macro `SDK_DELAY_USE_DWT` to enable this feature.
  - Modified the Cortex-M7 delay count divisor based on latest tests on RT series boards, this setting lets result be closer to actual delay time.

#### [2.2.2]

- New Features
  - Added include `RTE_Components.h` for CMSIS pack RTE.

#### [2.2.1]

- Bug Fixes
  - Fixed violation of MISRA C-2012 Rule 3.1, 10.1, 10.3, 10.4, 11.6, 11.9.

#### [2.2.0]

- New Features
  - Moved `SDK_DelayAtLeastUs` function from clock driver to common driver.

#### [2.1.4]

- New Features
  - Added OTFAD into status group.

#### [2.1.3]

- Bug Fixes
  - MISRA C-2012 issue fixed.
    - \* Fixed the rule: rule-10.3.

#### [2.1.2]

- Improvements
  - Add `SUPPRESS_FALL_THROUGH_WARNING()` macro for the usage of suppressing fallthrough warning.

#### [2.1.1]

- Bug Fixes
  - Deleted and optimized repeated macro.

**[2.1.0]**

- New Features
  - Added IRQ operation for XCC toolchain.
  - Added group IDs for newly supported drivers.

**[2.0.2]**

- Bug Fixes
  - MISRA C-2012 issue fixed.
    - \* Fixed the rule: rule-10.4.

**[2.0.1]**

- Improvements
  - Removed the implementation of LPC8XX Enable/DisableDeepSleepIRQ0 function.
  - Added new feature macro switch “FSL\_FEATURE\_HAS\_NO\_NONCACHEABLE\_SECTION” for specific SoCs which have no noncacheable sections, that helps avoid an unnecessary complex in link file and the startup file.
  - Updated the align(x) to **attribute(aligned(x))** to support MDK v6 armclang compiler.

**[2.0.0]**

- Initial version.

---

**CRC**

**[2.1.1]**

- Fix MISRA issue.

**[2.1.0]**

- Add CRC\_WriteSeed function.

**[2.0.2]**

- Fix MISRA issue.

**[2.0.1]**

- Fixed KPSDK-13362. MDK compiler issue when writing to WR\_DATA with -O3 optimize for time.

**[2.0.0]**

- Initial version.

---

## LPC\_DMA

### [2.5.3]

- Improvements
  - Add assert in DMA\_SetChannelXferConfig to prevent XFERCOUNT value overflow.

### [2.5.2]

- Bug Fixes
  - Use separate “SET” and “CLR” registers to modify shared registers for all channels, in case of thread-safe issue.

### [2.5.1]

- Bug Fixes
  - Fixed violation of the MISRA C-2012 rule 11.6.

### [2.5.0]

- Improvements
  - Added a new api DMA\_SetChannelXferConfig to set DMA xfer config.

### [2.4.4]

- Bug Fixes
  - Fixed the issue that DMA\_IRQHandler might generate redundant callbacks.
  - Fixed the issue that DMA driver cannot support channel bigger then 32.
  - Fixed violation of the MISRA C-2012 rule 13.5.

### [2.4.3]

- Improvements
  - Added features FSL\_FEATURE\_DMA\_DESCRIPTOR\_ALIGN\_SIZEn/FSL\_FEATURE\_DMA0\_DESCRIPTOR\_ALIGN\_SIZE to support the descriptor align size not constant in the two instances.

### [2.4.2]

- Bug Fixes
  - Fixed violation of the MISRA C-2012 rule 8.4.

### [2.4.1]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 5.7, 8.3.

## [2.4.0]

- Improvements
  - Added new APIs DMA\_LoadChannelDescriptor/DMA\_ChannelIsBusy to support polling transfer case.
- Bug Fixes
  - Added address alignment check for descriptor source and destination address.
  - Added DMA\_ALLOCATE\_DATA\_TRANSFER\_BUFFER for application buffer allocation.
  - Fixed the sign-compare warning.
  - Fixed violations of the MISRA C-2012 rules 18.1, 10.4, 11.6, 10.7, 14.4, 16.3, 20.7, 10.8, 16.1, 17.7, 10.3, 3.1, 18.1.

## [2.3.0]

- Bug Fixes
  - Removed DMA\_HandleIRQ prototype definition from header file.
  - Added DMA\_IRQHandle prototype definition in header file.

## [2.2.5]

- Improvements
  - Added new API DMA\_SetupChannelDescriptor to support configuring wrap descriptor.
  - Added wrap support in function DMA\_SubmitChannelTransfer.

## [2.2.4]

- Bug Fixes
  - Fixed the issue that macro DMA\_CHANNEL\_CFER used wrong parameter to calculate DSTINC.

## [2.2.3]

- Bug Fixes
  - Improved DMA driver Deinit function for correct logic order.
- Improvements
  - Added API DMA\_SubmitChannelTransferParameter to support creating head descriptor directly.
  - Added API DMA\_SubmitChannelDescriptor to support ping pong transfer.
  - Added macro DMA\_ALLOCATE\_HEAD\_DESCRIPTOR/DMA\_ALLOCATE\_LINK\_DESCRIPTOR to simplify DMA descriptor allocation.

## [2.2.2]

- Bug Fixes
  - Do not use software trigger when hardware trigger is enabled.

### [2.2.1]

- Bug Fixes
  - Fixed Coverity issue.

### [2.2.0]

- Improvements
  - Changed API DMA\_SetupDMADescriptor to non-static.
  - Marked APIs below as deprecated.
    - \* DMA\_PrepareTransfer.
    - \* DMA\_Submit transfer.
  - Added new APIs as below:
    - \* DMA\_SetChannelConfig.
    - \* DMA\_PrepareChannelTransfer.
    - \* DMA\_InstallDescriptorMemory.
    - \* DMA\_SubmitChannelTransfer.
    - \* DMA\_SetChannelConfigValid.
    - \* DMA\_DoChannelSoftwareTrigger.
    - \* DMA\_LoadChannelTransferConfig.

### [2.0.1]

- Improvements
  - Added volatile for DMA descriptor member xfercfg to avoid optimization.

### [2.0.0]

- Initial version.

---

## GPIO

### [2.1.7]

- Improvements
  - Enhanced GPIO\_PinInit to enable clock internally.

### [2.1.6]

- Bug Fixes
  - Clear bit before set it within GPIO\_SetPinInterruptConfig() API.

### [2.1.5]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 3.1, 10.6, 10.7, 17.7.

**[2.1.4]**

- Improvements
  - Added API GPIO\_PortGetInterruptStatus to retrieve interrupt status for whole port.
  - Corrected typos in header file.

**[2.1.3]**

- Improvements
  - Updated “GPIO\_PinInit” API. If it has DIRCLR and DIRSET registers, use them at set 1 or clean 0.

**[2.1.2]**

- Improvements
  - Removed deprecated APIs.

**[2.1.1]**

- Improvements
  - API interface changes:
    - \* Refined naming of APIs while keeping all original APIs, marking them as deprecated. Original APIs will be removed in next release. The mainin change is updating APIs with prefix of \_PinXXX() and \_PorortXXX

**[2.1.0]**

- New Features
  - Added GPIO initialize API.

**[2.0.0]**

- Initial version.

---

**I2C****[2.2.1]**

- Bug Fixes
  - Fixed coverity issues.

**[2.2.0]**

- Removed lpc\_i2c\_dma driver.

**[2.1.0]**

- Bug Fixes
  - Fixed MISRA 8.6 violations.

## [2.0.4]

- Bug Fixes
  - Fixed wrong assignment for datasize in I2C\_InitTransferStateMachineDMA.
  - Fixed wrong working flow in I2C\_RunTransferStateMachineDMA to ensure master can work in no start flag and no stop flag mode.
  - Fixed wrong working flow in I2C\_RunTransferStateMachine and added kReceiveDataBeginState in \_i2c\_transfer\_states to ensure master can work in no start flag and no stop flag mode.
  - Fixed wrong handle state in I2C\_MasterTransferDMAHandleIRQ. After all the data has been transferred or nak is returned, handle state should be changed to idle.
  - Eliminated IAR Pa082 warning in I2C\_SlaveTransferHandleIRQ by assigning volatile variable to local variable and using local variable instead.
  - Fixed MISRA issues.
    - \* Fixed rules 4.7, 10.1, 10.3, 10.4, 11.1, 11.8, 14.4, 17.7.
- Improvements
  - Rounded up the calculated divider value in I2C\_MasterSetBaudRate.
  - Updated the I2C\_WAIT\_TIMEOUT macro to unified name I2C\_RETRY\_TIMES.

## [2.0.3]

- Bug Fixes
  - Fixed Coverity issue of unchecked return value in I2C\_RTOS\_Transfer.

## [2.0.2]

- New Features
  - Added macro gate “FSL\_SDK\_ENABLE\_I2C\_DRIVER\_TRANSACTIONAL\_APIS” to enable/disable the transactional APIs which will help reduce the code size when no non-blocking transfer is used. Default configuration is enabled.
  - Added a control macro to enable/disable the RESET and CLOCK code in current driver.

## [2.0.1]

- Improvements
  - Added I2C\_WAIT\_TIMEOUT macro to allow the user to specify the timeout times for waiting flags in functional API and blocking transfer API.

## [2.0.0]

- Initial version.

---

## IAP

## [2.0.7]

- Bug Fixes
  - Fixed IAP\_ReinvokeISP bug that can't support UART ISP auto baud detection.

## [2.0.6]

- Bug Fixes
  - Fixed IAP\_ReinvokeISP wrong parameter setting.

## [2.0.5]

- New Feature
  - Added support config flash memory access time.

## [2.0.4]

- Bug Fixes
  - Fixed the violations of MISRA 2012 rules 9.1

## [2.0.3]

- New Features
  - Added support for LPC 845's FAIM operation.
  - Added support for LPC 80x's fixed reference clock for flash controller.
  - Added support for LPC 5411x's Read UID command useless situation.
- Improvements
  - Improved the document and code structure.
- Bug Fixes
  - Fixed the violations of MISRA 2012 rules:
    - \* Rule 10.1 10.3 10.4 17.7

## [2.0.2]

- New Features
  - Added an API to read generated signature.
- Bug Fixes
  - Fixed the incorrect board support of IAP\_ExtendedFlashSignatureRead().

## [2.0.1]

- New Features
  - Added an API to read factory settings for some calibration registers.
- Improvements
  - Updated the size of result array in part APIs.

## [2.0.0]

- Initial version.

## INPUTMUX

### [2.0.9]

- Improvements
  - Use INPUTMUX\_CLOCKS to initialize the inputmux module clock to adapt to multiple inputmux instances.
  - Modify the API base type from INPUTMUX\_Type to void.

### [2.0.8]

- Improvements
  - Updated a feature macro usage for function INPUTMUX\_EnableSignal.

### [2.0.7]

- Improvements
  - Release peripheral from reset if necessary in init function.

### [2.0.6]

- Bug Fixes
  - Fixed the documentation wrong in API INPUTMUX\_AttachSignal.

### [2.0.5]

- Bug Fixes
  - Fixed build error because some devices has no sct.

### [2.0.4]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rule 10.4, 12.2 in INPUTMUX\_EnableSignal() function.

### [2.0.3]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.4, 10.7, 12.2.

### [2.0.2]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.4, 12.2.

### [2.0.1]

- Support channel mux setting in INPUTMUX\_EnableSignal().

**[2.0.0]**

- Initial version.

---

**IOCON**

**[2.0.2]**

- Bug Fixes
  - Fixed MISRA-C 2012 violations.

**[2.0.1]**

- Bug Fixes
  - Fixed out-of-range issue of the IOCON mode function when enabling DAC.

**[2.0.0]**

- Initial version.

---

**MRT**

**[2.0.5]**

- Bug Fixes
  - Fixed CERT INT31-C violations.

**[2.0.4]**

- Improvements
  - Don't reset MRT when there is not system level MRT reset functions.

**[2.0.3]**

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 10.1 and 10.4.
  - Fixed the wrong count value assertion in MRT\_StartTimer API.

**[2.0.2]**

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 10.4.

**[2.0.1]**

- Added control macro to enable/disable the RESET and CLOCK code in current driver.

**[2.0.0]**

- Initial version.

---

**PINT**

**[2.2.0]**

- Fixed
  - Fixed the issue that clear interrupt flag when it's not handled. This causes events to be lost.
- Changed
  - Used one callback for one PINT instance. It's unnecessary to provide different callbacks for all PINT events.

**[2.1.13]**

- Improvements
  - Added instance array for PINT to adapt more devices.
  - Used release reset instead of reset PINT which may clear other related registers out of PINT.

**[2.1.12]**

- Bug Fixes
  - Fixed coverity issue.

**[2.1.11]**

- Bug Fixes
  - Fixed MISRA C-2012 rule 10.7 violation.

**[2.1.10]**

- New Features
  - Added the driver support for MCXN10 platform with combined interrupt handler.

**[2.1.9]**

- Bug Fixes
  - Fixed MISRA-2012 rule 8.4.

**[2.1.8]**

- Bug Fixes
  - Fixed MISRA-2012 rule 10.1 rule 10.4 rule 10.8 rule 18.1 rule 20.9.

**[2.1.7]**

- Improvements
  - Added fully support for the SECPINT, making it can be used just like PINT.

**[2.1.6]**

- Bug Fixes
  - Fixed the bug of not enabling common pint clock when enabling security pint clock.

**[2.1.5]**

- Bug Fixes
  - Fixed issue for MISRA-2012 check.
    - \* Fixed rule 10.1 rule 10.3 rule 10.4 rule 10.8 rule 14.4.
  - Changed interrupt init order to make pin interrupt configuration more reasonable.

**[2.1.4]**

- Improvements
  - Added feature to control distinguish PINT/SECPINT relevant interrupt/clock configurations for PINT\_Init and PINT\_Deinit API.
  - Swapped the order of clearing PIN interrupt status flag and clearing pending NVIC interrupt in PINT\_EnableCallback and PINT\_EnableCallbackByIndex function.
- Bug Fixes
  - \* Fixed build issue caused by incorrect macro definitions.

**[2.1.3]**

- Bug fix:
  - Updated PINT\_PinInterruptClrStatus to clear PINT interrupt status when the bit is asserted and check whether was triggered by edge-sensitive mode.
  - Write 1 to IST corresponding bit will clear interrupt status only in edge-sensitive mode and will switch the active level for this pin in level-sensitive mode.
  - Fixed MISRA c-2012 rule 10.1, rule 10.6, rule 10.7.
  - Added FSL\_FEATURE\_SECPINT\_NUMBER\_OF\_CONNECTED\_OUTPUTS to distinguish IRQ relevant array definitions for SECPINT/PINT on lpc55s69 board.
  - Fixed PINT driver c++ build error and remove index offset operation.

**[2.1.2]**

- Improvement:
  - Improved way of initialization for SECPINT/PINT in PINT\_Init API.

**[2.1.1]**

- Improvement:
  - Enabled secure pint interrupt and add secure interrupt handle.

**[2.1.0]**

- Added PINT\_EnableCallbackByIndex/PINT\_DisableCallbackByIndex APIs to enable/disable callback by index.

**[2.0.2]**

- Added control macro to enable/disable the RESET and CLOCK code in current driver.

**[2.0.1]**

- Bug fix:
  - Updated PINT driver to clear interrupt only in Edge sensitive.

**[2.0.0]**

---

- Initial version.

**POWER**

**[2.1.0]**

- New features
  - Added BOD control APIs.

**[2.0.4]**

- Bug Fixes
  - Fixed the typo “Enbale”, correcting it as “Enable”.

**[2.0.3]**

- Bug Fixes
  - Fixed doxygen warnings(remove wrong character in annotation).

**[2.0.2]**

- New Features
  - Added the Enable/DisableDeepSleepIRQ() to enable/disable pin wake up.

**[2.0.1]**

- Improvements
  - Updated power drive to support PMU.

**[2.0.0]**

- initial version.

## RESET

### [2.4.0]

- Improvements
  - Add RESET\_ReleasePeripheralReset API.

### [2.0.1]

- Update component full\_name to “Reset Driver”.

### [2.0.0]

- initial version.

---

## SCTIMER

### [2.5.1]

- Bug Fixes
  - Fixed bug in SCTIMER\_SetupCaptureAction: When kSCTIMER\_Counter\_H is selected, events 12-15 and capture registers 12-15 CAPn\_H field can't be used.

### [2.5.0]

- Improvements
  - Add SCTIMER\_GetCaptureValue API to get capture value in capture registers.

### [2.4.9]

- Improvements
  - Supported platforms which don't have system level SCTIMER reset.

### [2.4.8]

- Bug Fixes
  - Fixed the issue that the SCTIMER\_UpdatePwmDutycycle() can't writes MATCH\_H bit and RELOADn\_H.

### [2.4.7]

- Bug Fixes
  - Fixed the issue that the SCTIMER\_UpdatePwmDutycycle() can't configure 100% duty cycle PWM.

#### [2.4.6]

- Bug Fixes
  - Fixed the issue where the H register was not written as a word along with the L register.
  - Fixed the issue that the SCTIMER\_SetCOUNTValue() is not configured with high 16 bits in unify mode.

#### [2.4.5]

- Bug Fixes
  - Fix SCT\_EV\_STATE\_STATEMSKn macro build error.

#### [2.4.4]

- Bug Fixes
  - Fix MISRA C-2012 issue 10.8.

#### [2.4.3]

- Bug Fixes
  - Fixed the wrong way of writing CAPCTRL and REGMODE registers in SCTIMER\_SetupCaptureAction.

#### [2.4.2]

- Bug Fixes
  - Fixed SCTIMER\_SetupPwm 100% duty cycle issue.

#### [2.4.1]

- Bug Fixes
  - Fixed the issue that MATCHn\_H bit and RELOADn\_H bit could not be written.

#### [2.4.0]

#### [2.3.0]

- Bug Fixes
  - Fixed the potential overflow issue of pulseperiod variable in SCTIMER\_SetupPwm/SCTIMER\_UpdatePwmDutycycle API.
  - Fixed the issue of SCTIMER\_CreateAndScheduleEvent API does not correctly work with 32 bit unified counter.
  - Fixed the issue of position of clear counter operation in SCTIMER\_Init API.
- Improvements
  - Update SCTIMER\_SetupPwm/SCTIMER\_UpdatePwmDutycycle to support generate 0% and 100% PWM signal.
  - Add SCTIMER\_SetupEventActiveDirection API to configure event activity direction.

- Update SCTIMER\_StartTimer/SCTIMER\_StopTimer API to support start/stop low counter and high counter at the same time.
- Add SCTIMER\_SetCounterState/SCTIMER\_GetCounterState API to write/read counter current state value.
- Update APIs to make it meaningful.
  - \* SCTIMER\_SetEventInState
  - \* SCTIMER\_ClearEventInState
  - \* SCTIMER\_GetEventInState

## [2.2.0]

- Improvements
  - Updated for 16-bit register access.

## [2.1.3]

- Bug Fixes
  - Fixed the issue of uninitialized variables in SCTIMER\_SetupPwm.
  - Fixed the issue that the Low 16-bit and high 16-bit work independently in SCTIMER driver.
- Improvements
  - Added an enumerable macro of unify counter for user.
    - \* kSCTIMER\_Counter\_U
  - Created new APIs for the RTC driver.
    - \* SCTIMER\_SetupStateLdMethodAction
    - \* SCTIMER\_SetupNextStateActionwithLdMethod
    - \* SCTIMER\_SetCOUNTValue
    - \* SCTIMER\_GetCOUNTValue
    - \* SCTIMER\_SetEventInState
    - \* SCTIMER\_ClearEventInState
    - \* SCTIMER\_GetEventInState
  - Deprecated legacy APIs for the RTC driver.
    - \* SCTIMER\_SetupNextStateAction

## [2.1.2]

- Bug Fixes
  - MISRA C-2012 issue fixed: rule 10.3, 10.4, 10.6, 10.7, 11.9, 14.2 and 15.5.

## [2.1.1]

- Improvements
  - Updated the register and macro names to align with the header of devices.

## [2.1.0]

- Bug Fixes
  - Fixed issue where SCT application level Interrupt handler function is occupied by SCT driver.
  - Fixed issue where wrong value for INSYNC field inside SCTIMER\_Init function.
  - Fixed issue to change Default value for INSYNC field inside SCTIMER\_GetDefaultConfig.

## [2.0.1]

- New Features
  - Added control macro to enable/disable the RESET and CLOCK code in current driver.

## [2.0.0]

- Initial version.

---

## SPI

### [2.0.8]

- Bug Fixes
  - Fixed coverity issue.

### [2.0.7]

- Bug Fixes
  - Fixed the txData from void \* to const void \* in transmit API.

### [2.0.6]

- Improvements
  - Changed SPI\_DUMMYDATA to 0x00.

### [2.0.5]

- Bug Fixes
  - Fixed bug that the transfer configuration does not take effect after the first transfer.

### [2.0.4]

- Bug Fixes
  - Fixed the issue that when transfer finish callback is invoked TX data is not sent to bus yet.

**[2.0.3]**

- Improvements
  - Added timeout mechanism when waiting certain states in transfer driver.
  - Fixed MISRA 10.4 issue.

**[2.0.2]**

- Bug Fixes
  - Fixed Coverity issue of incrementing null pointer in SPI\_MasterTransferNonBlocking.
  - Fixed MISRA issues.
    - \* Fixed rules 10.1, 10.3, 10.4, 10.6, 14.4.
- New Features
  - Added enumeration for dataWidth.

**[2.0.1]**

- Bug Fixes
  - Added wait mechanism in SPI\_MasterTransferBlocking() API, which checks if master SPI becomes IDLE when the EOT bit is set before returning. This confirms that all data will be sent out by SPI master.
  - Fixed the bug that the EOT bit couldn't be set when only one frame was sent in polling mode and interrupt transfer mode.
- New Features
  - Added macro gate “FSL\_SDK\_ENABLE\_SPI\_DRIVER\_TRANSACTIONAL\_APIS” to enable/disable the transactional APIs, which helps reduce the code size when no non-blocking transfer is used. Enabled default configuration.
  - Added a control macro to enable/disable the RESET and CLOCK code in current driver.

**[2.0.0]**

- Initial version.

**SWM****[2.1.2]**

- Improvements
  - Reduce RAM footprint.

**[2.1.1]**

- Bug Fixes
  - MISRA C-2012 issue fixed: rule 10.1 and 10.3.

## [2.1.0]

- New Features
  - Supported Flextimer function pin assign.

## [2.0.2]

- Bug Fixes
  - MISRA C-2012 issue fixed: rule 14.3.

## [2.0.1]

- Bug Fixes
  - MISRA C-2012 issue fixed: rule 10.1, 10.3, and 10.4.

## [2.0.0]

- Initial version.
- The API SWM\_SetFixedMovablePinSelect() is targeted at the device that has PINASSIGN-FIXED0 register, such as LPC804.

---

## SYSCON

## [2.0.1]

- Bug Fixes
  - Fixed issue for MISRA-2012 check.
  - Fixed rule 10.4.

## [2.0.0]

- Initial version.

---

## USART

## [2.5.2]

- Improvements
  - Fixed coverity issues.

## [2.5.1]

- Improvements
  - Fixed doxygen warning in USART\_SetRxIdleTimeout.

**[2.5.0]**

- New Features
  - Supported new feature of rx idle timeout.

**[2.4.0]**

- Improvements
  - Used separate data for TX and RX in usart\_transfer\_t.
- Bug Fixes
  - Fixed bug that when ring buffer is used, if some data is received in ring buffer first before calling USART\_TransferReceiveNonBlocking, the received data count returned by USART\_TransferGetReceiveCount is wrong.

**[2.3.0]**

- New Features
  - Modified usart\_config\_t, USART\_Init and USART\_GetDefaultConfig APIs so that the hardware flow control can be enabled during module initialization.

**[2.2.0]**

- Improvements
  - Added timeout mechanism when waiting for certain states in transfer driver.
  - Fixed MISRA 10.4 issues.

**[2.1.1]**

- Bug Fixes
  - Fixed the bug that in USART\_SetBaudRate best\_diff rather than diff should be used to compare with calculated baudrate.
  - Eliminated IAR pa082 warnings from USART\_TransferGetRxRingBufferLength and USART\_TransferHandleIRQ.
  - Fixed MISRA issues.
- Improvements
  - Rounded up the calculated sbr value in USART\_SetBaudRate to achieve more accurate baudrate setting.
  - Modified USART\_ReadBlocking so that if more than one receiver errors occur, all status flags will be cleared and the most severe error status will be returned.

**[2.1.0]**

- New Features
  - Added new APIs to allow users to configure the USART continuous SCLK feature in synchronous mode transfer.

### [2.0.1]

- Bug Fixes
  - Fixed the repeated reading issue of the STAT register while dealing with the IRQ routine.
- New Features
  - Added macro gate “FSL\_SDK\_ENABLE\_USART\_DRIVER\_TRANSACTIONAL\_APIS” to enable/disable the transactional APIs, which helps reduce the code size when no non-blocking transfer is used. Enabled default configuration.
  - Added a control macro to enable/disable the RESET and CLOCK code in current driver.
  - Added macro switch gate “FSL\_SDK\_USART\_DRIVER\_ENABLE\_BAUDRATE\_AUTO\_GENERATE” to enable/disable the baud rate to generate automatically. Disabling this feature will help reduce the code size to a certain degree. Default configuration enables auto generating of baud rate.
  - Added the check of baud rate while initializing the USART. If the baud rate calculated is not precise, the software assertion will be triggered.
  - Added a new API to allow users to enable the CTS, which determines whether CTS is used for flow control.

### [2.0.0]

- Initial version.

---

## WKT

### [2.0.2]

- Bug Fixes
  - Fixed violation of MISRA C-2012 rule 10.3.

### [2.0.1]

- New Features
  - Added control macro to enable/disable the RESET and CLOCK code in current driver.

### [2.0.0]

- Initial version.

---

## WWDT

### [2.1.9]

- Bug Fixes
  - Fixed violation of the MISRA C-2012 rule 10.4.

### [2.1.8]

- Improvements
  - Updated the “WWDT\_Init” API to add wait operation. Which can avoid the TV value read by CPU still be 0xFF (reset value) after WWDT\_Init function returns.

### [2.1.7]

- Bug Fixes
  - Fixed the issue that the watchdog reset event affected the system from PMC.
  - Fixed the issue of setting watchdog WDPROTECT field without considering the backwards compatibility.
  - Fixed the issue of clearing bit fields by mistake in the function of WWDT\_ClearStatusFlags.

### [2.1.5]

- Bug Fixes
  - deprecated a unusable API in WWWDT driver.
    - \* WWDT\_Disable

### [2.1.4]

- Bug Fixes
  - Fixed violation of the MISRA C-2012 rules Rule 10.1, 10.3, 10.4 and 11.9.
  - Fixed the issue of the inseparable process interrupted by other interrupt source.
    - \* WWDT\_Init

### [2.1.3]

- Bug Fixes
  - Fixed legacy issue when initializing the MOD register.

### [2.1.2]

- Improvements
  - Updated the “WWDT\_ClearStatusFlags” API and “WWDT\_GetStatusFlags” API to match QN9090. WDTOF is not set in case of WD reset. Get info from PMC instead.

### [2.1.1]

- New Features
  - Added new feature definition macro for devices which have no LCOK control bit in MOD register.
  - Implemented delay/retry in WWDT driver.

**[2.1.0]**

- Improvements
  - Added new parameter in configuration when initializing WWDT module. This parameter, which must be set, allows the user to deliver the WWDT clock frequency.

**[2.0.0]**

- Initial version.

---

## 1.6 Driver API Reference Manual

This section provides a link to the Driver API RM, detailing available drivers and their usage to help you integrate hardware efficiently.

[LPC824](#)

## 1.7 Middleware Documentation

Find links to detailed middleware documentation for key components. While not all onboard middleware is covered, this serves as a useful reference for configuration and development.

### 1.7.1 FreeMASTER

[freemaster](#)

# Chapter 2

## LPC824

### 2.1 Clock Driver

```
enum _clock_ip_name
    Clock gate name used for CLOCK_EnableClock/CLOCK_DisableClock.

    Values:
    enumerator kCLOCK_Sys
        Clock gate name: Sys.
    enumerator kCLOCK_Rom
        Clock gate name: Rom.
    enumerator kCLOCK_Ram0_1
        Clock gate name: Ram0_1.
    enumerator kCLOCK_Flashreg
        Clock gate name: Flashreg.
    enumerator kCLOCK_Flash
        Clock gate name: Flash.
    enumerator kCLOCK_I2c0
        Clock gate name: I2c0.
    enumerator kCLOCK_Gpio0
        Clock gate name: Gpio0.
    enumerator kCLOCK_Swm
        Clock gate name: Swm.
    enumerator kCLOCK_Sct
        Clock gate name: Sct.
    enumerator kCLOCK_Wkt
        Clock gate name: Wkt.
    enumerator kCLOCK_Mrt
        Clock gate name: Mrt.
    enumerator kCLOCK_Spi0
        Clock gate name: Spi0.
```

```
enumerator kCLOCK_Spi1
    Clock gate name: Spi1.
enumerator kCLOCK_Crc
    Clock gate name: Crc.
enumerator kCLOCK_Uart0
    Clock gate name: Uart0.
enumerator kCLOCK_Uart1
    Clock gate name: Uart1.
enumerator kCLOCK_Uart2
    Clock gate name: Uart2.
enumerator kCLOCK_Wwdt
    Clock gate name: Wwdt.
enumerator kCLOCK_Iocon
    Clock gate name: Iocon.
enumerator kCLOCK_Acmp
    Clock gate name: Acmp.
enumerator kCLOCK_I2c1
    Clock gate name: I2c1.
enumerator kCLOCK_I2c2
    Clock gate name: I2c2.
enumerator kCLOCK_I2c3
    Clock gate name: I2c3.
enumerator kCLOCK_Adc
    Clock gate name: Adc.
enumerator kCLOCK_Mtb
    Clock gate name: Mtb.
enumerator kCLOCK_Dma
    Clock gate name: Dma.

enum __clock_name
    Clock name used to get clock frequency.

    Values:
enumerator kCLOCK_CoreSysClk
    Cpu/AHB/AHB matrix/Memories,etc
enumerator kCLOCK_MainClk
    Main clock
enumerator kCLOCK_SysOsc
    Crystal Oscillator
enumerator kCLOCK_Irc
    IRC12M
enumerator kCLOCK_ExtClk
    External Clock
```

```

enumerator kCLOCK_PlOut
    PLL Output
enumerator kCLOCK_PlIn
    PLL Input
enumerator kCLOCK_WdtOsc
    Watchdog Oscillator

enum _clock_select
    Clock Mux Switches CLK_MUX_DEFINE(reg, mux) reg is used to define the mux register mux
    is used to define the mux value.

    Values:
    enumerator kSYSPLL_From_Irc
        Mux SYSPLL from Irc.
    enumerator kSYSPLL_From_SysOsc
        Mux SYSPLL from SysOsc.
    enumerator kSYSPLL_From_ExtClk
        Mux SYSPLL from ExtClk.
    enumerator kMAINCLK_From_Irc
        Mux MAINCLK from Irc.
    enumerator kMAINCLK_From_SysPllIn
        Mux MAINCLK from SysPllIn.
    enumerator kMAINCLK_From_WdtOsc
        Mux MAINCLK from WdtOsc.
    enumerator kMAINCLK_From_SysPll
        Mux MAINCLK from SysPll.
    enumerator kCLKOUT_From_Irc
        Mux CLKOUT from Irc.
    enumerator kCLKOUT_From_SysOsc
        Mux CLKOUT from SysOsc.
    enumerator kCLKOUT_From_WdtOsc
        Mux CLKOUT from WdtOsc.
    enumerator kCLKOUT_From_MainClk
        Mux clock out from Main clock.

enum _clock_divider
    Clock divider.

    Values:
    enumerator kCLOCK_DivUsartClk
        Usart Clock Divider.
    enumerator kCLOCK_DivClkOut
        Clk Out Divider.
    enumerator kCLOCK_DivUartFrg
        Uart Frg Divider.
    enumerator kCLOCK_IOCONCLKDiv6
        IOCON Clock Div6 Divider.

```

```
enumerator kCLOCK_IOCONCLKDiv5
    IOCON Clock Div5 Divider.
enumerator kCLOCK_IOCONCLKDiv4
    IOCON Clock Div4 Divider.
enumerator kCLOCK_IOCONCLKDiv3
    IOCON Clock Div3 Divider.
enumerator kCLOCK_IOCONCLKDiv2
    IOCON Clock Div2 Divider.
enumerator kCLOCK_IOCONCLKDiv1
    IOCON Clock Div1 Divider.
enumerator kCLOCK_IOCONCLKDiv0
    IOCON Clock Div0 Divider.

enum __clock_wdt_analog_freq
    watch dog analog output frequency
    Values:
    enumerator kCLOCK_WdtAnaFreq0HZ
        Watch dog analog output frequency is 0HZ.
    enumerator kCLOCK_WdtAnaFreq600KHZ
        Watch dog analog output frequency is 600KHZ.
    enumerator kCLOCK_WdtAnaFreq1050KHZ
        Watch dog analog output frequency is 1050KHZ.
    enumerator kCLOCK_WdtAnaFreq1400KHZ
        Watch dog analog output frequency is 1400KHZ.
    enumerator kCLOCK_WdtAnaFreq1750KHZ
        Watch dog analog output frequency is 1750KHZ.
    enumerator kCLOCK_WdtAnaFreq2100KHZ
        Watch dog analog output frequency is 2100KHZ.
    enumerator kCLOCK_WdtAnaFreq2400KHZ
        Watch dog analog output frequency is 2400KHZ.
    enumerator kCLOCK_WdtAnaFreq2700KHZ
        Watch dog analog output frequency is 2700KHZ.
    enumerator kCLOCK_WdtAnaFreq3000KHZ
        Watch dog analog output frequency is 3000KHZ.
    enumerator kCLOCK_WdtAnaFreq3250KHZ
        Watch dog analog output frequency is 3250KHZ.
    enumerator kCLOCK_WdtAnaFreq3500KHZ
        Watch dog analog output frequency is 3500KHZ.
    enumerator kCLOCK_WdtAnaFreq3750KHZ
        Watch dog analog output frequency is 3750KHZ.
    enumerator kCLOCK_WdtAnaFreq4000KHZ
        Watch dog analog output frequency is 4000KHZ.
```

```

enumerator kCLOCK_WdtAnaFreq4200KHZ
    Watch dog analog output frequency is 4200KHZ.

enumerator kCLOCK_WdtAnaFreq4400KHZ
    Watch dog analog output frequency is 4400KHZ.

enumerator kCLOCK_WdtAnaFreq4600KHZ
    Watch dog analog output frequency is 4600KHZ.

enum _clock_sys_pll_src
    PLL clock definition.

    Values:

    enumerator kCLOCK_SysPllSrcIrc
        system pll source from FRO

    enumerator kCLOCK_SysPllSrcSysosc
        system pll source from system osc

    enumerator kCLOCK_SysPllSrcExtClk
        system pll source from ext clkin

enum _clock_main_clk_src
    Main clock source definition.

    Values:

    enumerator kCLOCK_MainClkSrcIrc
        main clock source from FRO

    enumerator kCLOCK_MainClkSrcSysPllin
        main clock source from pll input

    enumerator kCLOCK_MainClkSrcWdtOsc
        main clock source from watchdog oscillator

    enumerator kCLOCK_MainClkSrcSysPll
        main clock source from system pll

typedef enum _clock_ip_name clock_ip_name_t
    Clock gate name used for CLOCK_EnableClock/CLOCK_DisableClock.

typedef enum _clock_name clock_name_t
    Clock name used to get clock frequency.

typedef enum _clock_select clock_select_t
    Clock Mux Switches CLK_MUX_DEFINE(reg, mux) reg is used to define the mux register mux
    is used to define the mux value.

typedef enum _clock_divider clock_divider_t
    Clock divider.

typedef enum _clock_wdt_analog_freq clock_wdt_analog_freq_t
    watch dog analog output frequency

typedef enum _clock_sys_pll_src clock_sys_pll_src
    PLL clock definition.

typedef enum _clock_main_clk_src clock_main_clk_src_t
    Main clock source definition.

typedef struct _clock_sys_pll clock_sys_pll_t
    PLL configuration structure.

```

volatile uint32\_t g\_Wdt\_Osc\_Freq  
watchdog oscillator clock frequency.

This variable is used to store the watchdog oscillator frequency which is set by CLOCK\_InitWdtOsc, and it is returned by CLOCK\_GetWdtOscFreq.

volatile uint32\_t g\_Ext\_Clk\_Freq  
external clock frequency.

This variable is used to store the external clock frequency which is include external oscillator clock and external clk in clock frequency value, it is set by CLOCK\_InitExtClkin when CLK IN is used as external clock or by CLOCK\_InitSysOsc when external oscillator is used as external clock ,and it is returned by CLOCK\_GetExtClkFreq.

FSL\_CLOCK\_DRIVER\_VERSION  
CLOCK driver version 2.4.4.

SDK\_DEVICE\_MAXIMUM\_CPU\_CLOCK\_FREQUENCY

ADC\_CLOCKS

Clock ip name array for ADC.

ACMP\_CLOCKS

Clock ip name array for ACMP.

SWM\_CLOCKS

Clock ip name array for SWM.

ROM\_CLOCKS

Clock ip name array for ROM.

SRAM\_CLOCKS

Clock ip name array for SRAM.

IOCON\_CLOCKS

Clock ip name array for IOCON.

GPIO\_CLOCKS

Clock ip name array for GPIO.

GPIO\_INT\_CLOCKS

Clock ip name array for GPIO\_INT.

DMA\_CLOCKS

Clock ip name array for DMA.

CRC\_CLOCKS

Clock ip name array for CRC.

WWDT\_CLOCKS

Clock ip name array for WWDT.

SCT\_CLOCKS

Clock ip name array for SCT0.

I2C\_CLOCKS

Clock ip name array for I2C.

USART\_CLOCKS

Clock ip name array for I2C.

SPI\_CLOCKS

Clock ip name array for SPI.

MTB\_CLOCKS

Clock ip name array for MTB.

MRT\_CLOCKS

Clock ip name array for MRT.

WKT\_CLOCKS

Clock ip name array for WKT.

CLK\_GATE\_DEFINE(*reg, bit*)

Internal used Clock definition only.

CLK\_GATE\_GET\_REG(*x*)

CLK\_GATE\_GET\_BITS\_SHIFT(*x*)

CLK\_MUX\_DEFINE(*reg, mux*)

CLK\_MUX\_GET\_REG(*x*)

CLK\_MUX\_GET\_MUX(*x*)

CLK\_MAIN\_CLK\_MUX\_DEFINE(*preMux, mux*)

CLK\_MAIN\_CLK\_MUX\_GET\_PRE\_MUX(*x*)

CLK\_MAIN\_CLK\_MUX\_GET\_MUX(*x*)

CLK\_DIV\_DEFINE(*reg*)

CLK\_DIV\_GET\_REG(*x*)

CLK\_WDT\_OSC\_DEFINE(*freq, regValue*)

CLK\_WDT\_OSC\_GET\_FREQ(*x*)

CLK\_WDT\_OSC\_GET\_REG(*x*)

SYS\_AHB\_CLK\_CTRL

static inline void CLOCK\_EnableClock(*clock\_ip\_name\_t clk*)

static inline void CLOCK\_DisableClock(*clock\_ip\_name\_t clk*)

static inline void CLOCK\_Select(*clock\_select\_t sel*)

static inline void CLOCK\_SetClkDivider(*clock\_divider\_t name, uint32\_t value*)

static inline uint32\_t CLOCK\_GetClkDivider(*clock\_divider\_t name*)

static inline void CLOCK\_SetCoreSysClkDiv(*uint32\_t value*)

void CLOCK\_SetMainClkSrc(*clock\_main\_clk\_src\_t src*)

Set main clock reference source.

### Parameters

- *src* – Refer to *clock\_main\_clk\_src\_t* to set the main clock source.

static inline void CLOCK\_SetFRGClkMul(*uint32\_t mul*)

*uint32\_t CLOCK\_GetMainClkFreq(void)*

Return Frequency of Main Clock.

### Returns

Frequency of Main Clock.

static inline uint32\_t CLOCK\_GetCoreSysClkFreq(void)

    Return Frequency of core.

**Returns**

    Frequency of core.

uint32\_t CLOCK\_GetClockOutClkFreq(void)

    Return Frequency of ClockOut.

**Returns**

    Frequency of ClockOut

uint32\_t CLOCK\_GetIrcFreq(void)

    Return Frequency of IRC.

**Returns**

    Frequency of IRC

uint32\_t CLOCK\_GetSysOscFreq(void)

    Return Frequency of SYSOSC.

**Returns**

    Frequency of SYSOSC

uint32\_t CLOCK\_GetUartClkFreq(void)

    Get UART0 frequency.

**Return values**

    UART0 – frequency value.

uint32\_t CLOCK\_GetUart0ClkFreq(void)

    Get UART0 frequency.

**Return values**

    UART0 – frequency value.

uint32\_t CLOCK\_GetUart1ClkFreq(void)

    Get UART1 frequency.

**Return values**

    UART1 – frequency value.

uint32\_t CLOCK\_GetUart2ClkFreq(void)

    Get UART2 frequency.

**Return values**

    UART2 – frequency value.

uint32\_t CLOCK\_GetFreq(*clock\_name\_t* *clockName*)

    Return Frequency of selected clock.

**Returns**

    Frequency of selected clock

uint32\_t CLOCK\_GetSystemPLLInClockRate(void)

    Return System PLL input clock rate.

**Returns**

    System PLL input clock rate

static inline uint32\_t CLOCK\_GetSystemPLLFreq(void)

    Return Frequency of System PLL.

**Returns**

    Frequency of PLL

static inline uint32\_t CLOCK\_GetWdtOscFreq(void)

Get watch dog OSC frequency.

**Return values**

watch – dog OSC frequency value.

static inline uint32\_t CLOCK\_GetExtClkFreq(void)

Get external clock frequency.

**Return values**

external – clock frequency value.

void CLOCK\_InitSystemPll(const *clock\_sys\_pll\_t* \*config)

System PLL initialize.

**Parameters**

- config – System PLL configurations.

static inline void CLOCK\_DeinitSystemPll(void)

System PLL Deinitialize.

void CLOCK\_InitExtClkin(uint32\_t clkInFreq)

Init external CLK IN, select the CLKIN as the external clock source.

**Parameters**

- clkInFreq – external clock in frequency.

void CLOCK\_InitSysOsc(uint32\_t oscFreq)

Init SYS OSC.

**Parameters**

- oscFreq – oscillator frequency value.

void CLOCK\_InitXtalIn(uint32\_t xtalInFreq)

XTALIN init function system oscillator is bypassed, sys\_osc\_clk is fed directly from the XTALIN.

**Parameters**

- xtalInFreq – XTALIN frequency value

**Returns**

Frequency of PLL

static inline void CLOCK\_DeinitSysOsc(void)

Deinit SYS OSC.

void CLOCK\_InitWdtOsc(*clock\_wdt\_analog\_freq\_t* wdtOscFreq, uint32\_t wdtOscDiv)

Init watch dog OSC Any setting of the FREQSEL bits will yield a Fclkana value within 40% of the listed frequency value. The watchdog oscillator is the clock source with the lowest power consumption. If accurate timing is required, use the FRO or system oscillator. The frequency of the watchdog oscillator is undefined after reset. The watchdog oscillator frequency must be programmed by writing to the WDTOSCCTRL register before using the watchdog oscillator. Watchdog osc output frequency = wdtOscFreq / wdtOscDiv, should in range 9.3KHZ to 2.3MHZ.

**Parameters**

- wdtOscFreq – watch dog analog part output frequency, reference \_wdt\_analog\_output\_freq.
- wdtOscDiv – watch dog analog part output frequency divider, shoule be a value >= 2U and multiple of 2

```
static inline void CLOCK_DeinitWdtOsc(void)
    Deinit watch dog OSC.
bool CLOCK_SetUARTFRGClkFreq(uint32_t freq)
    Set UARTFRG.
```

*Deprecated:*

Do not use this function. Refer to CLOCK\_SetFRGClkMul().

**Parameters**

- freq – UART clock src.

```
void CLOCK_UpdateClkOUTsrc(void)
    updates the clock source of the CLKOUT
static inline void CLOCK_SetUARTFRGMULT(uint32_t mul)
    Set UARTFRGMULT.
```

**Parameters**

- mul – UARTFRGMULT.

```
uint32_t targetFreq
    System pll fclk output frequency, the output frequency should be lower than 100MHZ
clock_sys_pll_src src
    System pll clock source
struct _clock_sys_pll
    #include <fsl_clock.h> PLL configuration structure.
```

## 2.2 CRC: Cyclic Redundancy Check Driver

FSL\_CRC\_DRIVER\_VERSION

CRC driver version. Version 2.1.1.

Current version: 2.1.1

Change log:

- Version 2.0.0
  - initial version
- Version 2.0.1
  - add explicit type cast when writing to WR\_DATA
- Version 2.0.2
  - Fix MISRA issue
- Version 2.1.0
  - Add CRC\_WriteSeed function
- Version 2.1.1
  - Fix MISRA issue

enum \_crc\_polynomial  
 CRC polynomials to use.

*Values:*

enumerator kCRC\_Polynomial\_CRC\_CCITT  
 $x^{16}+x^{12}+x^5+1$

enumerator kCRC\_Polynomial\_CRC\_16  
 $x^{16}+x^{15}+x^2+1$

enumerator kCRC\_Polynomial\_CRC\_32  
 $x^{32}+x^{26}+x^{23}+x^{22}+x^{16}+x^{12}+x^{11}+x^{10}+x^8+x^7+x^5+x^4+x^2+x+1$

typedef enum \_crc\_polynomial crc\_polynomial\_t  
 CRC polynomials to use.

typedef struct \_crc\_config crc\_config\_t  
 CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

void CRC\_Init(CRC\_Type \*base, const crc\_config\_t \*config)  
 Enables and configures the CRC peripheral module.

This functions enables the CRC peripheral clock in the LPC SYSCON block. It also configures the CRC engine and starts checksum computation by writing the seed.

#### Parameters

- base – CRC peripheral address.
- config – CRC module configuration structure.

static inline void CRC\_Deinit(CRC\_Type \*base)  
 Disables the CRC peripheral module.

This functions disables the CRC peripheral clock in the LPC SYSCON block.

#### Parameters

- base – CRC peripheral address.

void CRC\_Reset(CRC\_Type \*base)  
 resets CRC peripheral module.

#### Parameters

- base – CRC peripheral address.

void CRC\_WriteSeed(CRC\_Type \*base, uint32\_t seed)  
 Write seed to CRC peripheral module.

#### Parameters

- base – CRC peripheral address.
- seed – CRC Seed value.

void CRC\_GetDefaultConfig(crc\_config\_t \*config)  
 Loads default values to CRC protocol configuration structure.

Loads default values to CRC protocol configuration structure. The default values are:

```
config->polynomial = kCRC_Polynomial_CRC_CCITT;
config->reverseIn = false;
config->complementIn = false;
config->reverseOut = false;
config->complementOut = false;
config->seed = 0xFFFFU;
```

### Parameters

- config – CRC protocol configuration structure

`void CRC_GetConfig(CRC_Type *base, crc_config_t *config)`

Loads actual values configured in CRC peripheral to CRC protocol configuration structure.

The values, including seed, can be used to resume CRC calculation later.

### Parameters

- base – CRC peripheral address.
- config – CRC protocol configuration structure

`void CRC_WriteData(CRC_Type *base, const uint8_t *data, size_t dataSize)`

Writes data to the CRC module.

Writes input data buffer bytes to CRC data register.

### Parameters

- base – CRC peripheral address.
- data – Input data stream, MSByte in data[0].
- dataSize – Size of the input data buffer in bytes.

`static inline uint32_t CRC_Get32bitResult(CRC_Type *base)`

Reads 32-bit checksum from the CRC module.

Reads CRC data register.

### Parameters

- base – CRC peripheral address.

### Returns

final 32-bit checksum, after configured bit reverse and complement operations.

`static inline uint16_t CRC_Get16bitResult(CRC_Type *base)`

Reads 16-bit checksum from the CRC module.

Reads CRC data register.

### Parameters

- base – CRC peripheral address.

### Returns

final 16-bit checksum, after configured bit reverse and complement operations.

`CRC_DRIVER_USE_CRC16_CCITT_FALSE_AS_DEFAULT`

Default configuration structure filled by `CRC_GetDefaultConfig()`. Uses CRC-16/CCITT-FALSE as default.

`struct _crc_config`

`#include <fsl_crc.h>` CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

**Public Members**

*crc\_polynomial\_t* polynomial  
 CRC polynomial.

bool reverseIn  
 Reverse bits on input.

bool complementIn  
 Perform 1's complement on input.

bool reverseOut  
 Reverse bits on output.

bool complementOut  
 Perform 1's complement on output.

uint32\_t seed  
 Starting checksum value.

## 2.3 DMA: Direct Memory Access Controller Driver

void DMA\_Init(DMA\_Type \*base)

Initializes DMA peripheral.

This function enable the DMA clock, set descriptor table and enable DMA peripheral.

**Parameters**

- base – DMA peripheral base address.

void DMA\_Deinit(DMA\_Type \*base)

Deinitializes DMA peripheral.

This function gates the DMA clock.

**Parameters**

- base – DMA peripheral base address.

void DMA\_InstallDescriptorMemory(DMA\_Type \*base, void \*addr)

Install DMA descriptor memory.

This function used to register DMA descriptor memory for linked transfer, a typical case is ping pong transfer which will request more than one DMA descriptor memory space, although current DMA driver has a default DMA descriptor buffer, but it support one DMA descriptor for one channel only.

**Parameters**

- base – DMA base address.
- addr – DMA descriptor address

static inline bool DMA\_ChannelIsActive(DMA\_Type \*base, uint32\_t channel)

Return whether DMA channel is processing transfer.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

**Returns**

True for active state, false otherwise.

static inline bool DMA\_ChannelIsBusy(DMA\_Type \*base, uint32\_t channel)

Return whether DMA channel is busy.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

**Returns**

True for busy state, false otherwise.

static inline void DMA\_EnableChannelInterrupts(DMA\_Type \*base, uint32\_t channel)

Enables the interrupt source for the DMA transfer.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_DisableChannelInterrupts(DMA\_Type \*base, uint32\_t channel)

Disables the interrupt source for the DMA transfer.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_EnableChannel(DMA\_Type \*base, uint32\_t channel)

Enable DMA channel.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_DisableChannel(DMA\_Type \*base, uint32\_t channel)

Disable DMA channel.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_EnableChannelPeriphRq(DMA\_Type \*base, uint32\_t channel)

Set PERIPHREQEN of channel configuration register.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_DisableChannelPeriphRq(DMA\_Type \*base, uint32\_t channel)

Get PERIPHREQEN value of channel configuration register.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

**Returns**

True for enabled PeriphRq, false for disabled.

---

```
void DMA_ConfigureChannelTrigger(DMA_Type *base, uint32_t channel, dma_channel_trigger_t
                                *trigger)
```

Set trigger settings of DMA channel.

*Deprecated:*

Do not use this function. It has been superceded by DMA\_SetChannelConfig.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- trigger – trigger configuration.

```
void DMA_SetChannelConfig(DMA_Type *base, uint32_t channel, dma_channel_trigger_t
                           *trigger, bool isPeriph)
```

set channel config.

This function provide a interface to configure channel configuration reisters.

#### Parameters

- base – DMA base address.
- channel – DMA channel number.
- trigger – channel configurations structure.
- isPeriph – true is periph request, false is not.

```
static inline uint32_t DMA_SetChannelXferConfig(bool reload, bool clrTrig, bool intA, bool intB,
                                              uint8_t width, uint8_t srcInc, uint8_t dstInc,
                                              uint32_t bytes)
```

DMA channel xfer transfer configurations.

#### Parameters

- reload – true is reload link descriptor after current exhaust, false is not
- clrTrig – true is clear trigger status, wait software trigger, false is not
- intA – enable interruptA
- intB – enable interruptB
- width – transfer width
- srcInc – source address interleave size
- dstInc – destination address interleave size
- bytes – transfer bytes

#### Returns

The vaule of xfer config

```
uint32_t DMA_GetRemainingBytes(DMA_Type *base, uint32_t channel)
```

Gets the remaining bytes of the current DMA descriptor transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

#### Returns

The number of bytes which have not been transferred yet.

```
static inline void DMA_SetChannelPriority(DMA_Type *base, uint32_t channel, dma_priority_t  
priority)
```

Set priority of channel configuration register.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- priority – Channel priority value.

```
static inline dma_priority_t DMA_GetChannelPriority(DMA_Type *base, uint32_t channel)
```

Get priority of channel configuration register.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

#### Returns

Channel priority value.

```
static inline void DMA_SetChannelConfigValid(DMA_Type *base, uint32_t channel)
```

Set channel configuration valid.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

```
static inline void DMA_DoChannelSoftwareTrigger(DMA_Type *base, uint32_t channel)
```

Do software trigger for the channel.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

```
static inline void DMA_LoadChannelTransferConfig(DMA_Type *base, uint32_t channel, uint32_t  
xfer)
```

Load channel transfer configurations.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- xfer – transfer configurations.

```
void DMA_CreateDescriptor(dma_descriptor_t *desc, dma_xfercfg_t *xfercfg, void *srcAddr, void  
*dstAddr, void *nextDesc)
```

Create application specific DMA descriptor to be used in a chain in transfer.

#### *Deprecated:*

Do not use this function. It has been superceded by DMA\_SetupDescriptor.

#### Parameters

- desc – DMA descriptor address.
- xfercfg – Transfer configuration for DMA descriptor.
- srcAddr – Address of last item to transmit

- dstAddr – Address of last item to receive.
- nextDesc – Address of next descriptor in chain.

```
void DMA_SetupDescriptor(dma_descriptor_t *desc, uint32_t xfercfg, void *srcStartAddr, void
*dstStartAddr, void *nextDesc)
```

setup dma descriptor

Note: This function do not support configure wrap descriptor.

#### Parameters

- desc – DMA descriptor address.
- xfercfg – Transfer configuration for DMA descriptor.
- srcStartAddr – Start address of source address.
- dstStartAddr – Start address of destination address.
- nextDesc – Address of next descriptor in chain.

```
void DMA_SetupChannelDescriptor(dma_descriptor_t *desc, uint32_t xfercfg, void *srcStartAddr,
void *dstStartAddr, void *nextDesc, dma_burst_wrap_t
wrapType, uint32_t burstSize)
```

setup dma channel descriptor

Note: This function support configure wrap descriptor.

#### Parameters

- desc – DMA descriptor address.
- xfercfg – Transfer configuration for DMA descriptor.
- srcStartAddr – Start address of source address.
- dstStartAddr – Start address of destination address.
- nextDesc – Address of next descriptor in chain.
- wrapType – burst wrap type.
- burstSize – burst size, reference `_dma_burst_size`.

```
void DMA_LoadChannelDescriptor(DMA_Type *base, uint32_t channel, dma_descriptor_t
*descriptor)
```

load channel transfer descriptor.

This function can be used to load desscriptor to driver internal channel descriptor that is used to start DMA transfer, the head descriptor table is defined in DMA driver, it is useful for the case:

- a. for the polling transfer, application can allocate a local descriptor memory table to prepare a descriptor firstly and then call this api to load the configured descriptor to driver descriptor table.

```
DMA_Init(DMA0);
DMA_EnableChannel(DMA0, DEMO_DMA_CHANNEL);
DMA_SetupDescriptor(desc, xferCfg, s_srcBuffer, &s_destBuffer[0], NULL);
DMA_LoadChannelDescriptor(DMA0, DEMO_DMA_CHANNEL, (dma_descriptor_t *)desc);
DMA_DoChannelSoftwareTrigger(DMA0, DEMO_DMA_CHANNEL);
while(DMA_ChannelIsBusy(DMA0, DEMO_DMA_CHANNEL))
{}
```

#### Parameters

- base – DMA base address.

- channel – DMA channel.
- descriptor – configured DMA descriptor.

`void DMA_AbortTransfer(dma_handle_t *handle)`

Abort running transfer by handle.

This function aborts DMA transfer specified by handle.

#### Parameters

- handle – DMA handle pointer.

`void DMA_CreateHandle(dma_handle_t *handle, DMA_Type *base, uint32_t channel)`

Creates the DMA handle.

This function is called if using transaction API for DMA. This function initializes the internal state of DMA handle.

#### Parameters

- handle – DMA handle pointer. The DMA handle stores callback function and parameters.
- base – DMA peripheral base address.
- channel – DMA channel number.

`void DMA_SetCallback(dma_handle_t *handle, dma_callback callback, void *userData)`

Installs a callback function for the DMA transfer.

This callback is called in DMA IRQ handler. Use the callback to do something after the current major loop transfer completes.

#### Parameters

- handle – DMA handle pointer.
- callback – DMA callback function pointer.
- userData – Parameter for callback function.

`void DMA_PrepTransfer(dma_transfer_config_t *config, void *srcAddr, void *dstAddr, uint32_t byteWidth, uint32_t transferBytes, dma_transfer_type_t type, void *nextDesc)`

Prepares the DMA transfer structure.

#### *Deprecated:*

Do not use this function. It has been superceded by DMA\_PrepChannelTransfer. This function prepares the transfer configuration structure according to the user input.

---

**Note:** The data address and the data width must be consistent. For example, if the SRC is 4 bytes, so the source address must be 4 bytes aligned, or it shall result in source address error(SAE).

---

#### Parameters

- config – The user configuration structure of type `dma_transfer_t`.
- srcAddr – DMA transfer source address.
- dstAddr – DMA transfer destination address.
- byteWidth – DMA transfer destination address width(bytes).
- transferBytes – DMA transfer bytes to be transferred.

- type – DMA transfer type.
- nextDesc – Chain custom descriptor to transfer.

```
void DMA_PrepChannelTransfer(dma_channel_config_t *config, void *srcStartAddr, void
                             *dstStartAddr, uint32_t xferCfg, dma_transfer_type_t type,
                             dma_channel_trigger_t *trigger, void *nextDesc)
```

Prepare channel transfer configurations.

This function used to prepare channel transfer configurations.

#### Parameters

- config – Pointer to DMA channel transfer configuration structure.
- srcStartAddr – source start address.
- dstStartAddr – destination start address.
- xferCfg – xfer configuration, user can reference DMA\_CHANNEL\_XFER about to how to get xferCfg value.
- type – transfer type.
- trigger – DMA channel trigger configurations.
- nextDesc – address of next descriptor.

```
status_t DMA_SubmitTransfer(dma_handle_t *handle, dma_transfer_config_t *config)
```

Submits the DMA transfer request.

*Deprecated:*

Do not use this function. It has been superceded by DMA\_SubmitChannelTransfer.

This function submits the DMA transfer request according to the transfer configuration structure. If the user submits the transfer request repeatedly, this function packs an unprocessed request as a TCD and enables scatter/gather feature to process it in the next time.

#### Parameters

- handle – DMA handle pointer.
- config – Pointer to DMA transfer configuration structure.

#### Return values

- kStatus\_DMA\_Success – It means submit transfer request succeed.
- kStatus\_DMA\_QueueFull – It means TCD queue is full. Submit transfer request is not allowed.
- kStatus\_DMA\_Busy – It means the given channel is busy, need to submit request later.

```
void DMA_SubmitChannelTransferParameter(dma_handle_t *handle, uint32_t xferCfg, void
                                         *srcStartAddr, void *dstStartAddr, void *nextDesc)
```

Submit channel transfer paramter directly.

This function used to configue channel head descriptor that is used to start DMA transfer, the head descriptor table is defined in DMA driver, it is useful for the case:

- a. for the single transfer, application doesn't need to allocate descriptor table, the head descriptor can be used for it.

```

DMA_SetChannelConfig(base, channel, trigger, isPeriph);
DMA_CreateHandle(handle, base, channel)
DMA_SubmitChannelTransferParameter(handle, DMA_CHANNEL_XFER(reload, clrTrig,
    ↪intA, intB, width, srcInc, dstInc,
    bytes), srcStartAddr, dstStartAddr, NULL);
DMA_StartTransfer(handle)

```

b. for the linked transfer, application should responsible for link descriptor, for example, if 4 transfer is required, then application should prepare three descriptor table with macro , the head descriptor in driver can be used for the first transfer descriptor.

```

define link descriptor table in application with macro
DMA_ALLOCATE_LINK_DESCRIPTOR(nextDesc[3]);

DMA_SetupDescriptor(nextDesc0, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
    ↪srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc1);
DMA_SetupDescriptor(nextDesc1, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
    ↪srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc2);
DMA_SetupDescriptor(nextDesc2, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
    ↪srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, NULL);
DMA_SetChannelConfig(base, channel, trigger, isPeriph);
DMA_CreateHandle(handle, base, channel)
DMA_SubmitChannelTransferParameter(handle, DMA_CHANNEL_XFER(reload, clrTrig,
    ↪intA, intB, width, srcInc, dstInc,
    bytes), srcStartAddr, dstStartAddr, nextDesc0);
DMA_StartTransfer(handle);

```

## Parameters

- handle – Pointer to DMA handle.
- xferCfg – xfer configuration, user can reference DMA\_CHANNEL\_XFER about to how to get xferCfg value.
- srcStartAddr – source start address.
- dstStartAddr – destination start address.
- nextDesc – address of next descriptor.

void DMA\_SubmitChannelDescriptor(*dma\_handle\_t* \*handle, *dma\_descriptor\_t* \*descriptor)

Submit channel descriptor.

This function used to configue channel head descriptor that is used to start DMA transfer, the head descriptor table is defined in DMA driver, this functiono is typical for the ping pong case:

a. for the ping pong case, application should responsible for the descriptor, for example, application should prepare two descriptor table with macro.

```

define link descriptor table in application with macro
DMA_ALLOCATE_LINK_DESCRIPTOR(nextDesc[2]);

DMA_SetupDescriptor(nextDesc0, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
    ↪srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc1);
DMA_SetupDescriptor(nextDesc1, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
    ↪srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc0);

```

(continues on next page)

(continued from previous page)

```
DMA_SetChannelConfig(base, channel, trigger, isPeriph);
DMA_CreateHandle(handle, base, channel)
DMA_SubmitChannelDescriptor(handle, nextDesc0);
DMA_StartTransfer(handle);
```

## Parameters

- handle – Pointer to DMA handle.
- descriptor – descriptor to submit.

*status\_t* DMA\_SubmitChannelTransfer(*dma\_handle\_t* \**handle*, *dma\_channel\_config\_t* \**config*)  
Submits the DMA channel transfer request.

This function submits the DMA transfer request according to the transfer configuration structure. If the user submits the transfer request repeatedly, this function packs an unprocessed request as a TCD and enables scatter/gather feature to process it in the next time. It is used for the case:

- a. for the single transfer, application doesn't need to allocate descriptor table, the head descriptor can be used for it.

```
DMA_CreateHandle(handle, base, channel)
DMA_PrepChannelTransfer(config, srcStartAddr, dstStartAddr, xferCfg, type, trigger, NULL);
DMA_SubmitChannelTransfer(handle, config)
DMA_StartTransfer(handle)
```

- b. for the linked transfer, application should responsible for link descriptor, for example, if 4 transfer is required, then application should prepare three descriptor table with macro , the head descriptor in driver can be used for the first transfer descriptor.

```
define link descriptor table in application with macro
DMA_ALLOCATE_LINK_DESCRIPTOR(nextDesc);
DMA_SetupDescriptor(nextDesc0, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
→ srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc1);
DMA_SetupDescriptor(nextDesc1, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
→ srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc2);
DMA_SetupDescriptor(nextDesc2, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
→ srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, NULL);
DMA_CreateHandle(handle, base, channel)
DMA_PrepChannelTransfer(config, srcStartAddr, dstStartAddr, xferCfg, type, trigger,
→ nextDesc0);
DMA_SubmitChannelTransfer(handle, config)
DMA_StartTransfer(handle)
```

- c. for the ping pong case, application should responsible for link descriptor, for example, application should prepare two descriptor table with macro , the head descriptor in driver can be used for the first transfer descriptor.

```
define link descriptor table in application with macro
DMA_ALLOCATE_LINK_DESCRIPTOR(nextDesc);
DMA_SetupDescriptor(nextDesc0, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
→ srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc1);
DMA_SetupDescriptor(nextDesc1, DMA_CHANNEL_XFER(reload, clrTrig, intA, intB, width,
→ srcInc, dstInc, bytes),
srcStartAddr, dstStartAddr, nextDesc0);
```

(continues on next page)

(continued from previous page)

```

DMA_CreateHandle(handle, base, channel)
DMA_PrepChannelTransfer(config,srcStartAddr,dstStartAddr,xferCfg,type,trigger,
→nextDesc0);
DMA_SubmitChannelTransfer(handle, config)
DMA_StartTransfer(handle)

```

## Parameters

- handle – DMA handle pointer.
- config – Pointer to DMA transfer configuration structure.

## Return values

- kStatus\_DMA\_Success – It means submit transfer request succeed.
- kStatus\_DMA\_QueueFull – It means TCD queue is full. Submit transfer request is not allowed.
- kStatus\_DMA\_Busy – It means the given channel is busy, need to submit request later.

void DMA\_StartTransfer(*dma\_handle\_t* \*handle)

DMA start transfer.

This function enables the channel request. User can call this function after submitting the transfer request. It will trigger transfer start with software trigger only when hardware trigger is not used.

## Parameters

- handle – DMA handle pointer.

void DMA\_IRQHandler(*DMA\_Type* \*base)

DMA IRQ handler for descriptor transfer complete.

This function clears the channel major interrupt flag and call the callback function if it is not NULL.

## Parameters

- base – DMA base address.

FSL\_DMA\_DRIVER\_VERSION

DMA driver version.

Version 2.5.3.

*\_dma\_transfer\_status* DMA transfer status

*Values:*

enumerator kStatus\_DMA\_Busy

Channel is busy and can't handle the transfer request.

*\_dma\_addr\_interleave\_size* dma address interleave size

*Values:*

enumerator kDMA\_AddressInterleave0xWidth

dma source/destination address no interleave

enumerator kDMA\_AddressInterleave1xWidth

dma source/destination address interleave 1xwidth

```
enumerator kDMA_AddressInterleave2xWidth
    dma source/destination address interleave 2xwidth
enumerator kDMA_AddressInterleave4xWidth
    dma source/destination address interleave 3xwidth

_dma_transfer_width dma transfer width
Values:
enumerator kDMA_Transfer8BitWidth
    dma channel transfer bit width is 8 bit
enumerator kDMA_Transfer16BitWidth
    dma channel transfer bit width is 16 bit
enumerator kDMA_Transfer32BitWidth
    dma channel transfer bit width is 32 bit

enum _dma_priority
    DMA channel priority.
Values:
enumerator kDMA_ChannelPriority0
    Highest channel priority - priority 0
enumerator kDMA_ChannelPriority1
    Channel priority 1
enumerator kDMA_ChannelPriority2
    Channel priority 2
enumerator kDMA_ChannelPriority3
    Channel priority 3
enumerator kDMA_ChannelPriority4
    Channel priority 4
enumerator kDMA_ChannelPriority5
    Channel priority 5
enumerator kDMA_ChannelPriority6
    Channel priority 6
enumerator kDMA_ChannelPriority7
    Lowest channel priority - priority 7

enum _dma_int
    DMA interrupt flags.
Values:
enumerator kDMA_IntA
    DMA interrupt flag A
enumerator kDMA_IntB
    DMA interrupt flag B
enumerator kDMA_IntError
    DMA interrupt flag error
```

`enum _dma_trigger_type`

DMA trigger type.

*Values:*

`enumerator kDMA_NoTrigger`

Trigger is disabled

`enumerator kDMA_LowLevelTrigger`

Low level active trigger

`enumerator kDMA_HighLevelTrigger`

High level active trigger

`enumerator kDMA_FallingEdgeTrigger`

Falling edge active trigger

`enumerator kDMA_RisingEdgeTrigger`

Rising edge active trigger

`_dma_burst_size` DMA burst size

*Values:*

`enumerator kDMA_BurstSize1`

burst size 1 transfer

`enumerator kDMA_BurstSize2`

burst size 2 transfer

`enumerator kDMA_BurstSize4`

burst size 4 transfer

`enumerator kDMA_BurstSize8`

burst size 8 transfer

`enumerator kDMA_BurstSize16`

burst size 16 transfer

`enumerator kDMA_BurstSize32`

burst size 32 transfer

`enumerator kDMA_BurstSize64`

burst size 64 transfer

`enumerator kDMA_BurstSize128`

burst size 128 transfer

`enumerator kDMA_BurstSize256`

burst size 256 transfer

`enumerator kDMA_BurstSize512`

burst size 512 transfer

`enumerator kDMA_BurstSize1024`

burst size 1024 transfer

`enum _dma_trigger_burst`

DMA trigger burst.

*Values:*

```

enumerator kDMA_SingleTransfer
    Single transfer
enumerator kDMA_LevelBurstTransfer
    Burst transfer driven by level trigger
enumerator kDMA_EdgeBurstTransfer1
    Perform 1 transfer by edge trigger
enumerator kDMA_EdgeBurstTransfer2
    Perform 2 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer4
    Perform 4 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer8
    Perform 8 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer16
    Perform 16 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer32
    Perform 32 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer64
    Perform 64 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer128
    Perform 128 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer256
    Perform 256 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer512
    Perform 512 transfers by edge trigger
enumerator kDMA_EdgeBurstTransfer1024
    Perform 1024 transfers by edge trigger

enum _dma_burst_wrap
    DMA burst wrapping.

    Values:
    enumerator kDMA_NoWrap
        Wrapping is disabled
    enumerator kDMA_SrcWrap
        Wrapping is enabled for source
    enumerator kDMA_DstWrap
        Wrapping is enabled for destination
    enumerator kDMA_SrcAndDstWrap
        Wrapping is enabled for source and destination

enum _dma_transfer_type
    DMA transfer type.

    Values:
    enumerator kDMA_MemoryToMemory
        Transfer from memory to memory (increment source and destination)

```

enumerator kDMA\_PeripheralToMemory  
Transfer from peripheral to memory (increment only destination)

enumerator kDMA\_MemoryToPeripheral  
Transfer from memory to peripheral (increment only source)

enumerator kDMA\_StaticToStatic  
Peripheral to static memory (do not increment source or destination)

typedef struct *dma\_descriptor* dma\_descriptor\_t  
DMA descriptor structure.

typedef struct *dma\_xfercfg* dma\_xfercfg\_t  
DMA transfer configuration.

typedef enum *dma\_priority* dma\_priority\_t  
DMA channel priority.

typedef enum *dma\_int* dma\_irq\_t  
DMA interrupt flags.

typedef enum *dma\_trigger\_type* dma\_trigger\_type\_t  
DMA trigger type.

typedef enum *dma\_trigger\_burst* dma\_trigger\_burst\_t  
DMA trigger burst.

typedef enum *dma\_burst\_wrap* dma\_burst\_wrap\_t  
DMA burst wrapping.

typedef enum *dma\_transfer\_type* dma\_transfer\_type\_t  
DMA transfer type.

typedef struct *dma\_channel\_trigger* dma\_channel\_trigger\_t  
DMA channel trigger.

typedef struct *dma\_channel\_config* dma\_channel\_config\_t  
DMA channel trigger.

typedef struct *dma\_transfer\_config* dma\_transfer\_config\_t  
DMA transfer configuration.

typedef void (\*dma\_callback)(struct *dma\_handle* \*handle, void \*userData, bool transferDone, uint32\_t intmode)  
Define Callback function for DMA.

typedef struct *dma\_handle* dma\_handle\_t  
DMA transfer handle structure.

DMA\_MAX\_TRANSFER\_COUNT  
DMA max transfer size.

FSL\_FEATURE\_DMA\_NUMBER\_OF\_CHANNELS<sub>n</sub>(x)  
DMA channel numbers.

FSL\_FEATURE\_DMA\_MAX\_CHANNELS

FSL\_FEATURE\_DMA\_ALL\_CHANNELS

FSL\_FEATURE\_DMA\_LINK\_DESCRIPTOR\_ALIGN\_SIZE  
DMA head link descriptor table align size.

DMA\_ALLOCATE\_HEAD\_DESCRIPTOR(name, number)

DMA head descriptor table allocate macro To simplify user interface, this macro will help allocate descriptor memory, user just need to provide the name and the number for the allocate descriptor.

#### Parameters

- name – Allocate descriptor name.
- number – Number of descriptor to be allocated.

DMA\_ALLOCATE\_HEAD\_DESCRIPTOR\_AT\_NONCACHEABLE(name, number)

DMA head descriptor table allocate macro at noncacheable section To simplify user interface, this macro will help allocate descriptor memory at noncacheable section, user just need to provide the name and the number for the allocate descriptor.

#### Parameters

- name – Allocate descriptor name.
- number – Number of descriptor to be allocated.

DMA\_ALLOCATE\_LINK\_DESCRIPTOR(name, number)

DMA link descriptor table allocate macro To simplify user interface, this macro will help allocate descriptor memory, user just need to provide the name and the number for the allocate descriptor.

#### Parameters

- name – Allocate descriptor name.
- number – Number of descriptor to be allocated.

DMA\_ALLOCATE\_LINK\_DESCRIPTOR\_AT\_NONCACHEABLE(name, number)

DMA link descriptor table allocate macro at noncacheable section To simplify user interface, this macro will help allocate descriptor memory at noncacheable section, user just need to provide the name and the number for the allocate descriptor.

#### Parameters

- name – Allocate descriptor name.
- number – Number of descriptor to be allocated.

DMA\_ALLOCATE\_DATA\_TRANSFER\_BUFFER(name, width)

DMA transfer buffer address need to align with the transfer width.

DMA\_CHANNEL\_GROUP(channel)

DMA\_CHANNEL\_INDEX(base, channel)

DMA\_COMMON\_REG\_GET(base, channel, reg)

DMA linked descriptor address align size.

DMA\_COMMON\_CONST\_REG\_GET(base, channel, reg)

DMA\_COMMON\_REG\_SET(base, channel, reg, value)

DMA\_DESCRIPTOR\_END\_ADDRESS(start, inc, bytes, width)

DMA descriptor end address calculate.

#### Parameters

- start – start address
- inc – address interleave size
- bytes – transfer bytes

- width – transfer width

DMA\_CHANNEL\_XFER(reload, clrTrig, intA, intB, width, srcInc, dstInc, bytes)

struct \_dma\_descriptor  
#include <fsl\_dma.h> DMA descriptor structure.

### Public Members

volatile uint32\_t xfercfg  
Transfer configuration

void \*srcEndAddr  
Last source address of DMA transfer

void \*dstEndAddr  
Last destination address of DMA transfer

void \*linkToNextDesc  
Address of next DMA descriptor in chain

struct \_dma\_xfercfg  
#include <fsl\_dma.h> DMA transfer configuration.

### Public Members

bool valid  
Descriptor is ready to transfer

bool reload  
Reload channel configuration register after current descriptor is exhausted

bool swtrig  
Perform software trigger. Transfer if fired when ‘valid’ is set

bool clrtrig  
Clear trigger

bool intA  
Raises IRQ when transfer is done and set IRQA status register flag

bool intB  
Raises IRQ when transfer is done and set IRQB status register flag

uint8\_t byteWidth  
Byte width of data to transfer

uint8\_t srcInc  
Increment source address by ‘srcInc’ x ‘byteWidth’

uint8\_t dstInc  
Increment destination address by ‘dstInc’ x ‘byteWidth’

uint16\_t transferCount  
Number of transfers

struct \_dma\_channel\_trigger  
#include <fsl\_dma.h> DMA channel trigger.

**Public Members***dma\_trigger\_type\_t* type

Select hardware trigger as edge triggered or level triggered.

*dma\_trigger\_burst\_t* burst

Select whether hardware triggers cause a single or burst transfer.

*dma\_burst\_wrap\_t* wrap

Select wrap type, source wrap or dest wrap, or both.

struct \_dma\_channel\_config

#include &lt;fsl\_dma.h&gt; DMA channel trigger.

**Public Members**

void \*srcStartAddr

Source data address

void \*dstStartAddr

Destination data address

void \*nextDesc

Chain custom descriptor

uint32\_t xferCfg

channel transfer configurations

*dma\_channel\_trigger\_t* \*trigger

DMA trigger type

bool isPeriph

select the request type

struct \_dma\_transfer\_config

#include &lt;fsl\_dma.h&gt; DMA transfer configuration.

**Public Members**

uint8\_t \*srcAddr

Source data address

uint8\_t \*dstAddr

Destination data address

uint8\_t \*nextDesc

Chain custom descriptor

*dma\_xfercfg\_t* xfercfg

Transfer options

bool isPeriph

DMA transfer is driven by peripheral

struct \_dma\_handle

#include &lt;fsl\_dma.h&gt; DMA transfer handle structure.

### Public Members

```
dma_callback callback
    Callback function. Invoked when transfer of descriptor with interrupt flag finishes
void *userData
    Callback function parameter
DMA_Type *base
    DMA peripheral base address
uint8_t channel
    DMA channel number
```

## 2.4 FLEXCOMM: FLEXCOMM Driver

### 2.5 FLEXCOMM Driver

```
FSL_FLEXCOMM_DRIVER_VERSION
```

FlexCOMM driver version 2.0.2.

```
enum FLEXCOMM_PERIPH_T
```

FLEXCOMM peripheral modes.

*Values:*

```
enumerator FLEXCOMM_PERIPH_NONE
```

No peripheral

```
enumerator FLEXCOMM_PERIPH_USART
```

USART peripheral

```
enumerator FLEXCOMM_PERIPH_SPI
```

SPI Peripheral

```
enumerator FLEXCOMM_PERIPH_I2C
```

I2C Peripheral

```
enumerator FLEXCOMM_PERIPH_I2S_TX
```

I2S TX Peripheral

```
enumerator FLEXCOMM_PERIPH_I2S_RX
```

I2S RX Peripheral

```
typedef void (*flexcomm_irq_handler_t)(void *base, void *handle)
```

Typedef for interrupt handler.

```
IRQn_Type const kFlexcommIrqs[]
```

Array with IRQ number for each FLEXCOMM module.

```
uint32_t FLEXCOMM_GetInstance(void *base)
```

Returns instance number for FLEXCOMM module with given base address.

```
status_t FLEXCOMM_Init(void *base, FLEXCOMM_PERIPH_T periph)
```

Initializes FLEXCOMM and selects peripheral mode according to the second parameter.

```
void FLEXCOMM_SetIRQHandler(void *base, flexcomm_irq_handler_t handler, void
                             *flexcommHandle)
```

Sets IRQ handler for given FLEXCOMM module. It is used by drivers register IRQ handler according to FLEXCOMM mode.

## 2.6 I2C: Inter-Integrated Circuit Driver

### 2.7 I2C DMA Driver

```
void I2C_MasterTransferCreateHandleDMA(I2C_Type *base, i2c_master_dma_handle_t *handle,
                                      i2c_master_dma_transfer_callback_t callback, void
                                      *userData, dma_handle_t *dmaHandle)
```

Init the I2C handle which is used in transactional functions.

#### Parameters

- base – I2C peripheral base address
- handle – pointer to i2c\_master\_dma\_handle\_t structure
- callback – pointer to user callback function
- userData – user param passed to the callback function
- dmaHandle – DMA handle pointer

```
status_t I2C_MasterTransferDMA(I2C_Type *base, i2c_master_dma_handle_t *handle,
                               i2c_master_transfer_t *xfer)
```

Performs a master dma non-blocking transfer on the I2C bus.

#### Parameters

- base – I2C peripheral base address
- handle – pointer to i2c\_master\_dma\_handle\_t structure
- xfer – pointer to transfer structure of i2c\_master\_transfer\_t

#### Return values

- kStatus\_Success – Sucessully complete the data transmission.
- kStatus\_I2C\_Busy – Previous transmission still not finished.
- kStatus\_I2C\_Timeout – Transfer error, wait signal timeout.
- kStatus\_I2C\_ArbitrationLost – Transfer error, arbitration lost.
- kStatus\_I2C\_Nak – Transfer error, receive Nak during transfer.

```
status_t I2C_MasterTransferGetCountDMA(I2C_Type *base, i2c_master_dma_handle_t *handle,
                                       size_t *count)
```

Get master transfer status during a dma non-blocking transfer.

#### Parameters

- base – I2C peripheral base address
- handle – pointer to i2c\_master\_dma\_handle\_t structure
- count – Number of bytes transferred so far by the non-blocking transaction.

```
void I2C_MasterTransferAbortDMA(I2C_Type *base, i2c_master_dma_handle_t *handle)
```

Abort a master dma non-blocking transfer in a early time.

#### Parameters

- base – I2C peripheral base address
- handle – pointer to i2c\_master\_dma\_handle\_t structure

FSL\_I2C\_DMA\_DRIVER\_VERSION

I2C DMA driver version.

```
typedef struct _i2c_master_dma_handle i2c_master_dma_handle_t
I2C master dma handle typedef.

typedef void (*i2c_master_dma_transfer_callback_t)(I2C_Type *base, i2c_master_dma_handle_t
*handle, status_t status, void *userData)
I2C master dma transfer callback typedef.

typedef void (*flexcomm_i2c_dma_master_irq_handler_t)(I2C_Type *base,
i2c_master_dma_handle_t *handle)
Typedef for master dma handler.

I2C_MAX_DMA_TRANSFER_COUNT
Maximum lenght of single DMA transfer (determined by capability of the DMA engine)

struct _i2c_master_dma_handle
#include <fsl_i2c_dma.h> I2C master dma transfer structure.
```

### Public Members

```
uint8_t state
Transfer state machine current state.

uint32_t transferCount
Indicates progress of the transfer

uint32_t remainingBytesDMA
Remaining byte count to be transferred using DMA.

uint8_t *buf
Buffer pointer for current state.

bool checkAddrNack
Whether to check the nack signal is detected during addressing.

dma_handle_t *dmaHandle
The DMA handler used.

i2c_master_transfer_t transfer
Copy of the current transfer info.

i2c_master_dma_transfer_callback_t completionCallback
Callback function called after dma transfer finished.

void *userData
Callback parameter passed to callback function.
```

## 2.8 I2C Driver

FSL\_I2C\_DRIVER\_VERSION

I2C driver version.

FSL\_I2C\_DRIVER\_VERSION

I2C driver version.

I2C status return codes.

*Values:*

`enumerator kStatus_I2C_Busy`

The master is already performing a transfer.

`enumerator kStatus_I2C_Idle`

The slave driver is idle.

`enumerator kStatus_I2C_Nak`

The slave device sent a NAK in response to a byte.

`enumerator kStatus_I2C_InvalidParameter`

Unable to proceed due to invalid parameter.

`enumerator kStatus_I2C_BitError`

Transferred bit was not seen on the bus.

`enumerator kStatus_I2C_ArbitrationLost`

Arbitration lost error.

`enumerator kStatus_I2C_NoTransferInProgress`

Attempt to abort a transfer when one is not in progress.

`enumerator kStatus_I2C_DmaRequestFail`

DMA request failed.

`enumerator kStatus_I2C_StartStopError`

Start and stop error.

`enumerator kStatus_I2C_UnexpectedState`

Unexpected state.

`enumerator kStatus_I2C_Addr_Nak`

NAK received during the address probe.

`enumerator kStatus_I2C_Timeout`

Timeout polling status flags.

I2C status return codes.

*Values:*

`enumerator kStatus_I2C_Busy`

The master is already performing a transfer.

`enumerator kStatus_I2C_Idle`

The slave driver is idle.

`enumerator kStatus_I2C_Nak`

The slave device sent a NAK in response to a byte.

`enumerator kStatus_I2C_InvalidParameter`

Unable to proceed due to invalid parameter.

`enumerator kStatus_I2C_BitError`

Transferred bit was not seen on the bus.

`enumerator kStatus_I2C_ArbitrationLost`

Arbitration lost error.

`enumerator kStatus_I2C_NoTransferInProgress`

Attempt to abort a transfer when one is not in progress.

enumerator kStatus\_I2C\_DmaRequestFail  
DMA request failed.

enumerator kStatus\_I2C\_StartStopError  
Start and stop error.

enumerator kStatus\_I2C\_UnexpectedState  
Unexpected state.

enumerator kStatus\_I2C\_Timeout  
Timeout when waiting for I2C master/slave pending status to set to continue transfer.

enumerator kStatus\_I2C\_Addr\_Nak  
NAK received for Address

enumerator kStatus\_I2C\_EventTimeout  
Timeout waiting for bus event.

enumerator kStatus\_I2C\_SclLowTimeout  
Timeout SCL signal remains low.

enum \_i2c\_status\_flags  
I2C status flags.

---

**Note:** These enums are meant to be OR'd together to form a bit mask.

---

*Values:*

enumerator kI2C\_MasterPendingFlag  
The I2C module is waiting for software interaction. bit 0

enumerator kI2C\_MasterArbitrationLostFlag  
The arbitration of the bus was lost. There was collision on the bus. bit 4

enumerator kI2C\_MasterStartStopErrorFlag  
There was an error during start or stop phase of the transaction. bit 6

enumerator kI2C\_MasterIdleFlag  
The I2C master idle status. bit 5

enumerator kI2C\_MasterRxReadyFlag  
The I2C master rx ready status. bit 1

enumerator kI2C\_MasterTxReadyFlag  
The I2C master tx ready status. bit 2

enumerator kI2C\_MasterAddrNackFlag  
The I2C master address nack status. bit 7

enumerator kI2C\_MasterDataNackFlag  
The I2C master data nack status. bit 3

enumerator kI2C\_SlavePendingFlag  
The I2C module is waiting for software interaction. bit 8

enumerator kI2C\_SlaveNotStretching  
Indicates whether the slave is currently stretching clock (0 = yes, 1 = no). bit 11

enumerator kI2C\_SlaveSelected  
Indicates whether the slave is selected by an address match. bit 14

```

enumerator kI2C_SaveDeselected
    Indicates that slave was previously deselected (deselect event took place, w1c). bit 15
enumerator kI2C_SlaveAddressedFlag
    One of the I2C slave's 4 addresses is matched. bit 22
enumerator kI2C_SlaveReceiveFlag
    Slave receive data available. bit 9
enumerator kI2C_SlaveTransmitFlag
    Slave data can be transmitted. bit 10
enumerator kI2C_SlaveAddress0MatchFlag
    Slave address0 match. bit 20
enumerator kI2C_SlaveAddress1MatchFlag
    Slave address1 match. bit 12
enumerator kI2C_SlaveAddress2MatchFlag
    Slave address2 match. bit 13
enumerator kI2C_SlaveAddress3MatchFlag
    Slave address3 match. bit 21
enumerator kI2C_MonitorReadyFlag
    The I2C monitor ready interrupt. bit 16
enumerator kI2C_MonitorOverflowFlag
    The monitor data overrun interrupt. bit 17
enumerator kI2C_MonitorActiveFlag
    The monitor is active. bit 18
enumerator kI2C_MonitorIdleFlag
    The monitor idle interrupt. bit 19
enumerator kI2C_EventTimeoutFlag
    The bus event timeout interrupt. bit 24
enumerator kI2C_SclTimeoutFlag
    The SCL timeout interrupt. bit 25
enumerator kI2C_MasterAllClearFlags
enumerator kI2C_SlaveAllClearFlags
enumerator kI2C_CommonAllClearFlags

enum _i2c_interrupt_enable
    I2C interrupt enable.

```

---

**Note:** These enums are meant to be OR'd together to form a bit mask.

---

*Values:*

```

enumerator kI2C_MasterPendingInterruptEnable
    The I2C master communication pending interrupt.
enumerator kI2C_MasterArbitrationLostInterruptEnable
    The I2C master arbitration lost interrupt.

```

enumerator kI2C\_MasterStartStopErrorInterruptEnable  
The I2C master start/stop timing error interrupt.

enumerator kI2C\_SlavePendingInterruptEnable  
The I2C slave communication pending interrupt.

enumerator kI2C\_SlaveNotStretchingInterruptEnable  
The I2C slave not stretching interrupt, deep-sleep mode can be entered only when this interrupt occurs.

enumerator kI2C\_SlaveDeselectedInterruptEnable  
The I2C slave deselection interrupt.

enumerator kI2C\_MonitorReadyInterruptEnable  
The I2C monitor ready interrupt.

enumerator kI2C\_MonitorOverflowInterruptEnable  
The monitor data overrun interrupt.

enumerator kI2C\_MonitorIdleInterruptEnable  
The monitor idle interrupt.

enumerator kI2C\_EventTimeoutInterruptEnable  
The bus event timeout interrupt.

enumerator kI2C\_SclTimeoutInterruptEnable  
The SCL timeout interrupt.

enumerator kI2C\_MasterAllInterruptEnable

enumerator kI2C\_SlaveAllInterruptEnable

enumerator kI2C\_CommonAllInterruptEnable

I2C\_RETRY\_TIMES  
Retry times for waiting flag.

I2C\_STAT\_MSTCODE\_IDLE  
Master Idle State Code

I2C\_STAT\_MSTCODE\_RXREADY  
Master Receive Ready State Code

I2C\_STAT\_MSTCODE\_TXREADY  
Master Transmit Ready State Code

I2C\_STAT\_MSTCODE\_NACKADR  
Master NACK by slave on address State Code

I2C\_STAT\_MSTCODE\_NACKDAT  
Master NACK by slave on data State Code

I2C\_STAT\_SLVST\_ADDR

I2C\_STAT\_SLVST\_RX

I2C\_STAT\_SLVST\_TX

I2C\_RETRY\_TIMES  
Retry times for waiting flag.

I2C\_MASTER\_TRANSMIT\_IGNORE\_LAST\_NACK  
Whether to ignore the nack signal of the last byte during master transmit.

I2C\_STAT\_MSTCODE\_IDLE  
     Master Idle State Code  
 I2C\_STAT\_MSTCODE\_RXREADY  
     Master Receive Ready State Code  
 I2C\_STAT\_MSTCODE\_TXREADY  
     Master Transmit Ready State Code  
 I2C\_STAT\_MSTCODE\_NACKADR  
     Master NACK by slave on address State Code  
 I2C\_STAT\_MSTCODE\_NACKDAT  
     Master NACK by slave on data State Code  
 I2C\_STAT\_SLVST\_ADDR  
 I2C\_STAT\_SLVST\_RX  
 I2C\_STAT\_SLVST\_TX

## 2.9 I2C Master Driver

`void I2C_MasterGetDefaultConfig(i2c_master_config_t *masterConfig)`

Provides a default configuration for the I2C master peripheral.

This function provides the following default configuration for the I2C master peripheral:

```
masterConfig->enableMaster      = true;
masterConfig->baudRate_Bps     = 1000000U;
masterConfig->enableTimeout     = false;
```

After calling this function, you can override any settings in order to customize the configuration, prior to initializing the master driver with `I2C_MasterInit()`.

### Parameters

- `masterConfig` – **[out]** User provided configuration structure for default values. Refer to `i2c_master_config_t`.

`void I2C_MasterInit(I2C_Type *base, const i2c_master_config_t *masterConfig, uint32_t srcClock_Hz)`

Initializes the I2C master peripheral.

This function enables the peripheral clock and initializes the I2C master peripheral as described by the user provided configuration. A software reset is performed prior to configuration.

### Parameters

- `base` – The I2C peripheral base address.
- `masterConfig` – User provided peripheral configuration. Use `I2C_MasterGetDefaultConfig()` to get a set of defaults that you can override.
- `srcClock_Hz` – Frequency in Hertz of the I2C functional clock. Used to calculate the baud rate divisors, filter widths, and timeout periods.

```
void I2C_MasterDeinit(I2C_Type *base)
```

Deinitializes the I2C master peripheral.

This function disables the I2C master peripheral and gates the clock. It also performs a software reset to restore the peripheral to reset conditions.

#### Parameters

- `base` – The I2C peripheral base address.

```
uint32_t I2C_GetInstance(I2C_Type *base)
```

Returns an instance number given a base address.

If an invalid base address is passed, debug builds will assert. Release builds will just return instance number 0.

#### Parameters

- `base` – The I2C peripheral base address.

#### Returns

I2C instance number starting from 0.

```
static inline void I2C_MasterReset(I2C_Type *base)
```

Performs a software reset.

Restores the I2C master peripheral to reset conditions.

#### Parameters

- `base` – The I2C peripheral base address.

```
static inline void I2C_MasterEnable(I2C_Type *base, bool enable)
```

Enables or disables the I2C module as master.

#### Parameters

- `base` – The I2C peripheral base address.
- `enable` – Pass true to enable or false to disable the specified I2C as master.

```
static inline uint32_t I2C_GetStatusFlags(I2C_Type *base)
```

Gets the I2C status flags.

A bit mask with the state of all I2C status flags is returned. For each flag, the corresponding bit in the return value is set if the flag is asserted.

A bit mask with the state of all I2C status flags is returned. For each flag, the corresponding bit in the return value is set if the flag is asserted.

#### See also:

[\\_i2c\\_master\\_flags](#)

#### See also:

[\\_i2c\\_status\\_flags](#).

#### Parameters

- `base` – The I2C peripheral base address.
- `base` – The I2C peripheral base address.

#### Returns

State of the status flags:

- 1: related status flag is set.
- 0: related status flag is not set.

### Returns

State of the status flags:

- 1: related status flag is set.
- 0: related status flag is not set.

`static inline void I2C_MasterClearStatusFlags(I2C_Type *base, uint32_t statusMask)`

Clears the I2C master status flag state.

The following status register flags can be cleared:

- `kI2C_MasterArbitrationLostFlag`
- `kI2C_MasterStartStopErrorFlag`

Attempts to clear other flags has no effect.

### See also:

`_i2c_master_flags`.

### Parameters

- `base` – The I2C peripheral base address.
- `statusMask` – A bitmask of status flags that are to be cleared. The mask is composed of `_i2c_master_flags` enumerators OR'd together. You may pass the result of a previous call to `I2C_GetStatusFlags()`.

`static inline void I2C_EnableInterrupts(I2C_Type *base, uint32_t interruptMask)`

Enables the I2C master interrupt requests.

### Parameters

- `base` – The I2C peripheral base address.
- `interruptMask` – Bit mask of interrupts to enable. See `_i2c_master_flags` for the set of constants that should be OR'd together to form the bit mask.

`static inline void I2C_DisableInterrupts(I2C_Type *base, uint32_t interruptMask)`

Disables the I2C master interrupt requests.

### Parameters

- `base` – The I2C peripheral base address.
- `interruptMask` – Bit mask of interrupts to disable. See `_i2c_master_flags` for the set of constants that should be OR'd together to form the bit mask.

`static inline uint32_t I2C_GetEnabledInterrupts(I2C_Type *base)`

Returns the set of currently enabled I2C master interrupt requests.

### Parameters

- `base` – The I2C peripheral base address.

### Returns

A bitmask composed of `_i2c_master_flags` enumerators OR'd together to indicate the set of enabled interrupts.

`void I2C_MasterSetBaudRate(I2C_Type *base, uint32_t baudRate_Bps, uint32_t srcClock_Hz)`

Sets the I2C bus frequency for master transactions.

The I2C master is automatically disabled and re-enabled as necessary to configure the baud rate. Do not call this function during a transfer, or the transfer is aborted.

#### Parameters

- `base` – The I2C peripheral base address.
- `srcClock_Hz` – I2C functional clock frequency in Hertz.
- `baudRate_Bps` – Requested bus frequency in bits per second.

`static inline bool I2C_MasterGetBusIdleState(I2C_Type *base)`

Returns whether the bus is idle.

Requires the master mode to be enabled.

#### Parameters

- `base` – The I2C peripheral base address.

#### Return values

- `true` – Bus is busy.
- `false` – Bus is idle.

`status_t I2C_MasterStart(I2C_Type *base, uint8_t address, i2c_direction_t direction)`

Sends a START on the I2C bus.

This function is used to initiate a new master mode transfer by sending the START signal. The slave address is sent following the I2C START signal.

#### Parameters

- `base` – I2C peripheral base pointer
- `address` – 7-bit slave device address.
- `direction` – Master transfer directions(transmit/receive).

#### Return values

- `kStatus_Success` – Successfully send the start signal.
- `kStatus_I2C_Busy` – Current bus is busy.

`status_t I2C_MasterStop(I2C_Type *base)`

Sends a STOP signal on the I2C bus.

#### Return values

- `kStatus_Success` – Successfully send the stop signal.
- `kStatus_I2C_Timeout` – Send stop signal failed, timeout.

`static inline status_t I2C_MasterRepeatedStart(I2C_Type *base, uint8_t address, i2c_direction_t direction)`

Sends a REPEATED START on the I2C bus.

#### Parameters

- `base` – I2C peripheral base pointer
- `address` – 7-bit slave device address.
- `direction` – Master transfer directions(transmit/receive).

#### Return values

- `kStatus_Success` – Successfully send the start signal.

- kStatus\_I2C\_Busy – Current bus is busy but not occupied by current I2C master.

*status\_t* I2C\_MasterWriteBlocking(I2C\_Type \*base, const void \*txBuff, size\_t txSize, uint32\_t flags)

Performs a polling send transfer on the I2C bus.

Sends up to *txSize* number of bytes to the previously addressed slave device. The slave may reply with a NAK to any byte in order to terminate the transfer early. If this happens, this function returns kStatus\_I2C\_Nak.

#### Parameters

- base – The I2C peripheral base address.
- txBuff – The pointer to the data to be transferred.
- txSize – The length in bytes of the data to be transferred.
- flags – Transfer control flag to control special behavior like suppressing start or stop, for normal transfers use kI2C\_TransferDefaultFlag

#### Return values

- kStatus\_Success – Data was sent successfully.
- kStatus\_I2C\_Busy – Another master is currently utilizing the bus.
- kStatus\_I2C\_Nak – The slave device sent a NAK in response to a byte.
- kStatus\_I2C\_ArbitrationLost – Arbitration lost error.

*status\_t* I2C\_MasterReadBlocking(I2C\_Type \*base, void \*rxBuff, size\_t rxSize, uint32\_t flags)

Performs a polling receive transfer on the I2C bus.

#### Parameters

- base – The I2C peripheral base address.
- rxBuff – The pointer to the data to be transferred.
- rxSize – The length in bytes of the data to be transferred.
- flags – Transfer control flag to control special behavior like suppressing start or stop, for normal transfers use kI2C\_TransferDefaultFlag

#### Return values

- kStatus\_Success – Data was received successfully.
- kStatus\_I2C\_Busy – Another master is currently utilizing the bus.
- kStatus\_I2C\_Nak – The slave device sent a NAK in response to a byte.
- kStatus\_I2C\_ArbitrationLost – Arbitration lost error.

*status\_t* I2C\_MasterTransferBlocking(I2C\_Type \*base, *i2c\_master\_transfer\_t* \*xfer)

Performs a master polling transfer on the I2C bus.

---

**Note:** The API does not return until the transfer succeeds or fails due to arbitration lost or receiving a NAK.

---

**Note:** The API does not return until the transfer succeeds or fails due to arbitration lost or receiving a NAK.

#### Parameters

- base – I2C peripheral base address.
- xfer – Pointer to the transfer structure.
- base – I2C peripheral base address.
- xfer – Pointer to the transfer structure.

#### Return values

- kStatus\_Success – Successfully complete the data transmission.
- kStatus\_I2C\_Busy – Previous transmission still not finished.
- kStatus\_I2C\_Timeout – Transfer error, wait signal timeout.
- kStatus\_I2C\_ArbitrationLost – Transfer error, arbitration lost.
- kStatus\_I2C\_Nak – Transfer error, receive NAK during transfer.
- kStatus\_Success – Successfully complete the data transmission.
- kStatus\_I2C\_Busy – Previous transmission still not finished.
- kStatus\_I2C\_Timeout – Transfer error, wait signal timeout.
- kStatus\_I2C\_ArbitrationLost – Transfer error, arbitration lost.
- kStatus\_I2C\_Nak – Transfer error, receive NAK during transfer.
- kStatus\_I2C\_Addr\_Nak – Transfer error, receive NAK during addressing.

```
void I2C_MasterTransferCreateHandle(I2C_Type *base, i2c_master_handle_t *handle,  
                                    i2c_master_transfer_callback_t callback, void *userData)
```

Creates a new handle for the I2C master non-blocking APIs.

The creation of a handle is for use with the non-blocking APIs. Once a handle is created, there is not a corresponding destroy handle. If the user wants to terminate a transfer, the I2C\_MasterTransferAbort() API shall be called.

#### Parameters

- base – The I2C peripheral base address.
- handle – **[out]** Pointer to the I2C master driver handle.
- callback – User provided pointer to the asynchronous callback function.
- userData – User provided pointer to the application callback data.

```
status_t I2C_MasterTransferNonBlocking(I2C_Type *base, i2c_master_handle_t *handle,  
                                       i2c_master_transfer_t *xfer)
```

Performs a non-blocking transaction on the I2C bus.

#### Parameters

- base – The I2C peripheral base address.
- handle – Pointer to the I2C master driver handle.
- xfer – The pointer to the transfer descriptor.

#### Return values

- kStatus\_Success – The transaction was started successfully.
- kStatus\_I2C\_Busy – Either another master is currently utilizing the bus, or a non-blocking transaction is already in progress.

---

`status_t I2C_MasterTransferGetCount(I2C_Type *base, i2c_master_handle_t *handle, size_t *count)`

Returns number of bytes transferred so far.

#### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to the I2C master driver handle.
- `count` – **[out]** Number of bytes transferred so far by the non-blocking transaction.

#### Return values

- `kStatus_Success` –
- `kStatus_I2C_Busy` –

`status_t I2C_MasterTransferAbort(I2C_Type *base, i2c_master_handle_t *handle)`

Terminates a non-blocking I2C master transmission early.

---

**Note:** It is not safe to call this function from an IRQ handler that has a higher priority than the I2C peripheral's IRQ priority.

---

**Note:** It is not safe to call this function from an IRQ handler that has a higher priority than the I2C peripheral's IRQ priority.

#### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to the I2C master driver handle.
- `base` – The I2C peripheral base address.
- `handle` – Pointer to the I2C master driver handle.

#### Return values

- `kStatus_Success` – A transaction was successfully aborted.
- `kStatus_I2C_Timeout` – Abort failure due to flags polling timeout.
- `kStatus_Success` – A transaction was successfully aborted.
- `kStatus_I2C_Timeout` – Timeout during polling for flags.

`void I2C_MasterTransferHandleIRQ(I2C_Type *base, void *i2cHandle)`

Reusable routine to handle master interrupts.

---

**Note:** This function does not need to be called unless you are reimplementing the non-blocking API's interrupt handler routines to add special functionality.

#### Parameters

- `base` – The I2C peripheral base address.
- `i2cHandle` – Pointer to the I2C master driver handle `i2c_master_handle_t`.

```
static inline void I2C_ClearStatusFlags(I2C_Type *base, uint32_t statusMask)
```

Clears the I2C status flag state.

Refer to `kI2C_CommonAllClearStatusFlags`, `kI2C_MasterAllClearStatusFlags` and `kI2C_SlaveAllClearStatusFlags` to see the clearable flags. Attempts to clear other flags has no effect.

#### See also:

`_i2c_status_flags`, `_i2c_master_status_flags` and `_i2c_slave_status_flags`.

#### Parameters

- `base` – The I2C peripheral base address.
- `statusMask` – A bitmask of status flags that are to be cleared. The mask is composed of the members in `kI2C_CommonAllClearStatusFlags`, `kI2C_MasterAllClearStatusFlags` and `kI2C_SlaveAllClearStatusFlags`. You may pass the result of a previous call to `I2C_GetStatusFlags()`.

```
void I2C_MasterSetTimeoutValue(I2C_Type *base, uint8_t timeout_Ms, uint32_t srcClock_Hz)
```

Sets the I2C bus timeout value.

If the SCL signal remains low or bus does not have event longer than the timeout value, `kI2C_SclTimeoutFlag` or `kI2C_EventTimeoutFlag` is set. This can indicate the bus is held by slave or any fault occurs to the I2C module.

#### Parameters

- `base` – The I2C peripheral base address.
- `timeout_Ms` – Timeout value in millisecond.
- `srcClock_Hz` – I2C functional clock frequency in Hertz.

```
void I2C_MasterTransferHandleIRQ(I2C_Type *base, i2c_master_handle_t *handle)
```

Reusable routine to handle master interrupts.

---

**Note:** This function does not need to be called unless you are reimplementing the non-blocking API's interrupt handler routines to add special functionality.

---

#### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to the I2C master driver handle.

`enum _i2c_master_flags`

I2C master peripheral flags.

---

**Note:** These enums are meant to be OR'd together to form a bit mask.

---

#### Values:

`enumerator kI2C_MasterPendingFlag`

The I2C module is waiting for software interaction.

`enumerator kI2C_MasterArbitrationLostFlag`

The arbitration of the bus was lost. There was collision on the bus

---

enumerator kI2C\_MasterStartStopErrorFlag

There was an error during start or stop phase of the transaction.

enum \_i2c\_direction

Direction of master and slave transfers.

*Values:*

enumerator kI2C\_Write

Master transmit.

enumerator kI2C\_Read

Master receive.

enum \_i2c\_master\_transfer\_flags

Transfer option flags.

---

**Note:** These enumerations are intended to be OR'd together to form a bit mask of options for the \_i2c\_master\_transfer::flags field.

*Values:*

enumerator kI2C\_TransferDefaultFlag

Transfer starts with a start signal, stops with a stop signal.

enumerator kI2C\_TransferNoStartFlag

Don't send a start condition, address, and sub address

enumerator kI2C\_TransferRepeatedStartFlag

Send a repeated start condition

enumerator kI2C\_TransferNoStopFlag

Don't send a stop condition.

enum \_i2c\_transfer\_states

States for the state machine used by transactional APIs.

*Values:*

enumerator kIdleState

enumerator kTransmitSubaddrState

enumerator kTransmitDataState

enumerator kReceiveDataBeginState

enumerator kReceiveDataState

enumerator kReceiveLastDataState

enumerator kStartState

enumerator kStopState

enumerator kWaitForCompletionState

enum \_i2c\_direction

Direction of master and slave transfers.

*Values:*

```
enumerator kI2C_Write
    Master transmit.
enumerator kI2C_Read
    Master receive.
enum _i2c_master_transfer_flags
    Transfer option flags.
```

---

**Note:** These enumerations are intended to be OR'd together to form a bit mask of options for the `_i2c_master_transfer::flags` field.

---

*Values:*

```
enumerator kI2C_TransferDefaultFlag
    Transfer starts with a start signal, stops with a stop signal.
enumerator kI2C_TransferNoStartFlag
    Don't send a start condition, address, and sub address
enumerator kI2C_TransferRepeatedStartFlag
    Send a repeated start condition
enumerator kI2C_TransferNoStopFlag
    Don't send a stop condition.
```

```
enum _i2c_transfer_states
    States for the state machine used by transactional APIs.
```

*Values:*

```
enumerator kIdleState
enumerator kTransmitSubaddrState
enumerator kTransmitDataState
enumerator kReceiveDataBeginState
enumerator kReceiveDataState
enumerator kReceiveLastDataState
enumerator kStartState
enumerator kStopState
enumerator kWaitForCompletionState
```

```
typedef enum _i2c_direction i2c_direction_t
    Direction of master and slave transfers.
```

```
typedef struct _i2c_master_config i2c_master_config_t
    Structure with settings to initialize the I2C master module.
```

This structure holds configuration settings for the I2C peripheral. To initialize this structure to reasonable defaults, call the `I2C_MasterGetDefaultConfig()` function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

```
typedef struct _i2c_master_transfer i2c_master_transfer_t
    I2C master transfer typedef.
```

```
typedef struct _i2c_master_handle i2c_master_handle_t
```

I2C master handle typedef.

```
typedef void (*i2c_master_transfer_callback_t)(I2C_Type *base, i2c_master_handle_t *handle, status_t completionStatus, void *userData)
```

Master completion callback function pointer type.

This callback is used only for the non-blocking master transfer API. Specify the callback you wish to use in the call to I2C\_MasterTransferCreateHandle().

**Param base**

The I2C peripheral base address.

**Param completionStatus**

Either kStatus\_Success or an error code describing how the transfer completed.

**Param userData**

Arbitrary pointer-sized value passed from the application.

```
typedef enum _i2c_direction i2c_direction_t
```

Direction of master and slave transfers.

```
typedef struct _i2c_master_config i2c_master_config_t
```

Structure with settings to initialize the I2C master module.

This structure holds configuration settings for the I2C peripheral. To initialize this structure to reasonable defaults, call the I2C\_MasterGetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

```
typedef struct _i2c_master_transfer i2c_master_transfer_t
```

I2C master transfer typedef.

```
typedef struct _i2c_master_handle i2c_master_handle_t
```

I2C master handle typedef.

```
typedef void (*i2c_master_transfer_callback_t)(I2C_Type *base, i2c_master_handle_t *handle, status_t completionStatus, void *userData)
```

Master completion callback function pointer type.

This callback is used only for the non-blocking master transfer API. Specify the callback you wish to use in the call to I2C\_MasterTransferCreateHandle().

**Param base**

The I2C peripheral base address.

**Param completionStatus**

Either kStatus\_Success or an error code describing how the transfer completed.

**Param userData**

Arbitrary pointer-sized value passed from the application.

```
struct _i2c_master_config
```

#include <fsl\_i2c.h> Structure with settings to initialize the I2C master module.

This structure holds configuration settings for the I2C peripheral. To initialize this structure to reasonable defaults, call the I2C\_MasterGetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

### Public Members

```
bool enableMaster
    Whether to enable master mode.

uint32_t baudRate_Bps
    Desired baud rate in bits per second.

bool enableTimeout
    Enable internal timeout function.

uint8_t timeout_Ms
    Event timeout and SCL low timeout value.
```

```
struct _i2c_master_transfer
```

```
#include <fsl_i2c.h> Non-blocking transfer descriptor structure.
```

This structure is used to pass transaction parameters to the I2C\_MasterTransferNonBlocking() API.

### Public Members

```
uint32_t flags
```

Bit mask of options for the transfer. See enumeration \_i2c\_master\_transfer\_flags for available options. Set to 0 or kI2C\_TransferDefaultFlag for normal transfers.

```
uint16_t slaveAddress
```

The 7-bit slave address.

```
i2c_direction_t direction
```

Either kI2C\_Read or kI2C\_Write.

```
uint32_t subaddress
```

Sub address. Transferred MSB first.

```
size_t subaddressSize
```

Length of sub address to send in bytes. Maximum size is 4 bytes.

```
void *data
```

Pointer to data to transfer.

```
size_t dataSize
```

Number of bytes to transfer.

```
uint8_t slaveAddress
```

The 7-bit slave address.

```
struct _i2c_master_handle
```

```
#include <fsl_i2c.h> Driver handle for master non-blocking APIs.
```

---

**Note:** The contents of this structure are private and subject to change.

---

### Public Members

```
uint8_t state
```

Transfer state machine current state.

```
uint32_t transferCount
```

Indicates progress of the transfer

```

uint32_t remainingBytes
    Remaining byte count in current state.

uint8_t *buf
    Buffer pointer for current state.

i2c_master_transfer_t transfer
    Copy of the current transfer info.

i2c_master_transfer_callback_t completionCallback
    Callback function pointer.

void *userData
    Application data passed to callback.

bool checkAddrNack
    Whether to check the nack signal is detected during addressing.

```

## 2.10 I2C Slave Driver

`void I2C_SlaveGetDefaultConfig(i2c_slave_config_t *slaveConfig)`

Provides a default configuration for the I2C slave peripheral.

This function provides the following default configuration for the I2C slave peripheral:

```

slaveConfig->enableSlave = true;
slaveConfig->address0.disable = false;
slaveConfig->address0.address = 0u;
slaveConfig->address1.disable = true;
slaveConfig->address2.disable = true;
slaveConfig->address3.disable = true;
slaveConfig->busSpeed = kI2C_SlaveStandardMode;

```

After calling this function, override any settings to customize the configuration, prior to initializing the master driver with `I2C_SlaveInit()`. Be sure to override at least the `address0.address` member of the configuration structure with the desired slave address.

### Parameters

- `slaveConfig` – **[out]** User provided configuration structure that is set to default values. Refer to `i2c_slave_config_t`.

`status_t I2C_SlaveInit(I2C_Type *base, const i2c_slave_config_t *slaveConfig, uint32_t srcClock_Hz)`

Initializes the I2C slave peripheral.

This function enables the peripheral clock and initializes the I2C slave peripheral as described by the user provided configuration.

### Parameters

- `base` – The I2C peripheral base address.
- `slaveConfig` – User provided peripheral configuration. Use `I2C_SlaveGetDefaultConfig()` to get a set of defaults that you can override.
- `srcClock_Hz` – Frequency in Hertz of the I2C functional clock. Used to calculate CLKDIV value to provide enough data setup time for master when slave stretches the clock.

```
void I2C_SlaveSetAddress(I2C_Type *base, i2c_slave_address_register_t addressRegister, uint8_t address, bool addressDisable)
```

Configures Slave Address n register.

This function writes new value to Slave Address register.

#### Parameters

- base – The I2C peripheral base address.
- addressRegister – The module supports multiple address registers. The parameter determines which one shall be changed.
- address – The slave address to be stored to the address register for matching.
- addressDisable – Disable matching of the specified address register.

```
void I2C_SlaveDeinit(I2C_Type *base)
```

Deinitializes the I2C slave peripheral.

This function disables the I2C slave peripheral and gates the clock. It also performs a software reset to restore the peripheral to reset conditions.

#### Parameters

- base – The I2C peripheral base address.

```
static inline void I2C_SlaveEnable(I2C_Type *base, bool enable)
```

Enables or disables the I2C module as slave.

#### Parameters

- base – The I2C peripheral base address.
- enable – True to enable or false to disable.

```
static inline void I2C_SlaveClearStatusFlags(I2C_Type *base, uint32_t statusMask)
```

Clears the I2C status flag state.

The following status register flags can be cleared:

- slave deselected flag

Attempts to clear other flags has no effect.

#### See also:

[\\_i2c\\_slave\\_flags](#).

#### Parameters

- base – The I2C peripheral base address.
- statusMask – A bitmask of status flags that are to be cleared. The mask is composed of [\\_i2c\\_slave\\_flags](#) enumerators OR'd together. You may pass the result of a previous call to [I2C\\_SlaveGetStatusFlags\(\)](#).

```
status_t I2C_SlaveWriteBlocking(I2C_Type *base, const uint8_t *txBuff, size_t txSize)
```

Performs a polling send transfer on the I2C bus.

The function executes blocking address phase and blocking data phase.

#### Parameters

- base – The I2C peripheral base address.
- txBuff – The pointer to the data to be transferred.

- txSize – The length in bytes of the data to be transferred.

**Returns**

kStatus\_Success Data has been sent.

**Returns**

kStatus\_Fail Unexpected slave state (master data write while master read from slave is expected).

*status\_t* I2C\_SlaveReadBlocking(I2C\_Type \*base, uint8\_t \*rxBuff, size\_t rxSize)

Performs a polling receive transfer on the I2C bus.

The function executes blocking address phase and blocking data phase.

**Parameters**

- base – The I2C peripheral base address.
- rxBuff – The pointer to the data to be transferred.
- rxSize – The length in bytes of the data to be transferred.

**Returns**

kStatus\_Success Data has been received.

**Returns**

kStatus\_Fail Unexpected slave state (master data read while master write to slave is expected).

*void* I2C\_SlaveTransferCreateHandle(I2C\_Type \*base, *i2c\_slave\_handle\_t* \*handle, *i2c\_slave\_transfer\_callback\_t* callback, void \*userData)

Creates a new handle for the I2C slave non-blocking APIs.

The creation of a handle is for use with the non-blocking APIs. Once a handle is created, there is not a corresponding destroy handle. If the user wants to terminate a transfer, the I2C\_SlaveTransferAbort() API shall be called.

**Parameters**

- base – The I2C peripheral base address.
- handle – **[out]** Pointer to the I2C slave driver handle.
- callback – User provided pointer to the asynchronous callback function.
- userData – User provided pointer to the application callback data.

*status\_t* I2C\_SlaveTransferNonBlocking(I2C\_Type \*base, *i2c\_slave\_handle\_t* \*handle, uint32\_t eventMask)

Starts accepting slave transfers.

Call this API after calling I2C\_SlaveInit() and I2C\_SlaveTransferCreateHandle() to start processing transactions driven by an I2C master. The slave monitors the I2C bus and pass events to the callback that was passed into the call to I2C\_SlaveTransferCreateHandle(). The callback is always invoked from the interrupt context.

If no slave Tx transfer is busy, a master read from slave request invokes kI2C\_SlaveTransmitEvent callback. If no slave Rx transfer is busy, a master write to slave request invokes kI2C\_SlaveReceiveEvent callback.

The set of events received by the callback is customizable. To do so, set the *eventMask* parameter to the OR'd combination of *i2c\_slave\_transfer\_event\_t* enumerators for the events you wish to receive. The kI2C\_SlaveTransmitEvent and kI2C\_SlaveReceiveEvent events are always enabled and do not need to be included in the mask. Alternatively, you can pass 0 to get a default set of only the transmit and receive events that are always enabled. In addition, the kI2C\_SlaveAllEvents constant is provided as a convenient way to enable all events.

### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to `i2c_slave_handle_t` structure which stores the transfer state.
- `eventMask` – Bit mask formed by OR'ing together `i2c_slave_transfer_event_t` enumerators to specify which events to send to the callback. Other accepted values are 0 to get a default set of only the transmit and receive events, and `kI2C_SlaveAllEvents` to enable all events.

### Return values

- `kStatus_Success` – Slave transfers were successfully started.
- `kStatus_I2C_Busy` – Slave transfers have already been started on this handle.

`status_t I2C_SlaveSetSendBuffer(I2C_Type *base, volatile i2c_slave_transfer_t *transfer, const void *txData, size_t txSize, uint32_t eventMask)`

Starts accepting master read from slave requests.

The function can be called in response to `kI2C_SlaveTransmitEvent` callback to start a new slave Tx transfer from within the transfer callback.

The set of events received by the callback is customizable. To do so, set the `eventMask` parameter to the OR'd combination of `i2c_slave_transfer_event_t` enumerators for the events you wish to receive. The `kI2C_SlaveTransmitEvent` and `kI2C_SlaveReceiveEvent` events are always enabled and do not need to be included in the mask. Alternatively, you can pass 0 to get a default set of only the transmit and receive events that are always enabled. In addition, the `kI2C_SlaveAllEvents` constant is provided as a convenient way to enable all events.

### Parameters

- `base` – The I2C peripheral base address.
- `transfer` – Pointer to `i2c_slave_transfer_t` structure.
- `txData` – Pointer to data to send to master.
- `txSize` – Size of `txData` in bytes.
- `eventMask` – Bit mask formed by OR'ing together `i2c_slave_transfer_event_t` enumerators to specify which events to send to the callback. Other accepted values are 0 to get a default set of only the transmit and receive events, and `kI2C_SlaveAllEvents` to enable all events.

### Return values

- `kStatus_Success` – Slave transfers were successfully started.
- `kStatus_I2C_Busy` – Slave transfers have already been started on this handle.

`status_t I2C_SlaveSetReceiveBuffer(I2C_Type *base, volatile i2c_slave_transfer_t *transfer, void *rxData, size_t rxSize, uint32_t eventMask)`

Starts accepting master write to slave requests.

The function can be called in response to `kI2C_SlaveReceiveEvent` callback to start a new slave Rx transfer from within the transfer callback.

The set of events received by the callback is customizable. To do so, set the `eventMask` parameter to the OR'd combination of `i2c_slave_transfer_event_t` enumerators for the events you wish to receive. The `kI2C_SlaveTransmitEvent` and `kI2C_SlaveReceiveEvent` events are always enabled and do not need to be included in the mask. Alternatively, you can pass 0 to get a default set of only the transmit and receive events that are always enabled. In

addition, the `kI2C_SlaveAllEvents` constant is provided as a convenient way to enable all events.

#### Parameters

- `base` – The I2C peripheral base address.
- `transfer` – Pointer to `i2c_slave_transfer_t` structure.
- `rxData` – Pointer to data to store data from master.
- `rxSize` – Size of `rxData` in bytes.
- `eventMask` – Bit mask formed by OR'ing together `i2c_slave_transfer_event_t` enumerators to specify which events to send to the callback. Other accepted values are 0 to get a default set of only the transmit and receive events, and `kI2C_SlaveAllEvents` to enable all events.

#### Return values

- `kStatus_Success` – Slave transfers were successfully started.
- `kStatus_I2C_Busy` – Slave transfers have already been started on this handle.

```
static inline uint32_t I2C_SlaveGetReceivedAddress(I2C_Type *base, volatile i2c_slave_transfer_t *transfer)
```

Returns the slave address sent by the I2C master.

This function should only be called from the address match event callback `kI2C_SlaveAddressMatchEvent`.

#### Parameters

- `base` – The I2C peripheral base address.
- `transfer` – The I2C slave transfer.

#### Returns

The 8-bit address matched by the I2C slave. Bit 0 contains the R/w direction bit, and the 7-bit slave address is in the upper 7 bits.

```
void I2C_SlaveTransferAbort(I2C_Type *base, i2c_slave_handle_t *handle)
```

Aborts the slave non-blocking transfers.

---

**Note:** This API could be called at any time to stop slave for handling the bus events.

---

#### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to `i2c_slave_handle_t` structure which stores the transfer state.

#### Return values

- `kStatus_Success` –
- `kStatus_I2C_Idle` –

```
status_t I2C_SlaveTransferGetCount(I2C_Type *base, i2c_slave_handle_t *handle, size_t *count)
```

Gets the slave transfer remaining bytes during a interrupt non-blocking transfer.

#### Parameters

- `base` – I2C base pointer.
- `handle` – pointer to `i2c_slave_handle_t` structure.

- count – Number of bytes transferred so far by the non-blocking transaction.

#### Return values

- kStatus\_InvalidArgument – count is Invalid.
- kStatus\_Success – Successfully return the count.

void I2C\_SlaveTransferHandleIRQ(I2C\_Type \*base, void \*i2cHandle)

Reusable routine to handle slave interrupts.

---

**Note:** This function does not need to be called unless you are reimplementing the non blocking API's interrupt handler routines to add special functionality.

---

#### Parameters

- base – The I2C peripheral base address.
- i2cHandle – Pointer to i2c\_slave\_handle\_t structure which stores the transfer state.

void I2C\_SlaveTransferHandleIRQ(I2C\_Type \*base, *i2c\_slave\_handle\_t* \*handle)

Reusable routine to handle slave interrupts.

---

**Note:** This function does not need to be called unless you are reimplementing the non blocking API's interrupt handler routines to add special functionality.

---

#### Parameters

- base – The I2C peripheral base address.
- handle – Pointer to i2c\_slave\_handle\_t structure which stores the transfer state.

enum \_i2c\_slave\_flags

I2C slave peripheral flags.

---

**Note:** These enums are meant to be OR'd together to form a bit mask.

---

*Values:*

enumerator kI2C\_SlavePendingFlag

The I2C module is waiting for software interaction.

enumerator kI2C\_SlaveNotStretching

Indicates whether the slave is currently stretching clock (0 = yes, 1 = no).

enumerator kI2C\_SlaveSelected

Indicates whether the slave is selected by an address match.

enumerator kI2C\_SaveDeselected

Indicates that slave was previously deselected (deselect event took place, w1c).

enum \_i2c\_slave\_address\_register

I2C slave address register.

*Values:*

enumerator kI2C\_SlaveAddressRegister0

Slave Address 0 register.

enumerator kI2C\_SlaveAddressRegister1  
 Slave Address 1 register.

enumerator kI2C\_SlaveAddressRegister2  
 Slave Address 2 register.

enumerator kI2C\_SlaveAddressRegister3  
 Slave Address 3 register.

enum \_i2c\_slave\_address\_qual\_mode  
 I2C slave address match options.

*Values:*

enumerator kI2C\_QualModeMask  
 The SLVQUAL0 field (qualAddress) is used as a logical mask for matching address0.

enumerator kI2C\_QualModeExtend  
 The SLVQUAL0 (qualAddress) field is used to extend address 0 matching in a range of addresses.

enum \_i2c\_slave\_bus\_speed  
 I2C slave bus speed options.

*Values:*

enumerator kI2C\_SlaveStandardMode

enumerator kI2C\_SlaveFastMode

enumerator kI2C\_SlaveFastModePlus

enumerator kI2C\_SlaveHsMode

enum \_i2c\_slave\_transfer\_event  
 Set of events sent to the callback for non blocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to I2C\_SlaveTransferNonBlocking() in order to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its *transfer* parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

*Values:*

enumerator kI2C\_SlaveAddressMatchEvent  
 Received the slave address after a start or repeated start.

enumerator kI2C\_SlaveTransmitEvent  
 Callback is requested to provide data to transmit (slave-transmitter role).

enumerator kI2C\_SlaveReceiveEvent  
 Callback is requested to provide a buffer in which to place received data (slave-receiver role).

enumerator kI2C\_SlaveCompletionEvent  
 All data in the active transfer have been consumed.

enumerator kI2C\_SlaveDeselectedEvent  
 The slave function has become deselected (SLVSEL flag changing from 1 to 0).

enumerator kI2C\_SlaveAllEvents

Bit mask of all available events.

enum \_i2c\_slave\_fsm

I2C slave software finite state machine states.

*Values:*

enumerator kI2C\_SlaveFsmAddressMatch

enumerator kI2C\_SlaveFsmReceive

enumerator kI2C\_SlaveFsmTransmit

enum \_i2c\_slave\_address\_register

I2C slave address register.

*Values:*

enumerator kI2C\_SlaveAddressRegister0

Slave Address 0 register.

enumerator kI2C\_SlaveAddressRegister1

Slave Address 1 register.

enumerator kI2C\_SlaveAddressRegister2

Slave Address 2 register.

enumerator kI2C\_SlaveAddressRegister3

Slave Address 3 register.

enum \_i2c\_slave\_address\_qual\_mode

I2C slave address match options.

*Values:*

enumerator kI2C\_QualModeMask

The SLVQUAL0 field (qualAddress) is used as a logical mask for matching address0.

enumerator kI2C\_QualModeExtend

The SLVQUAL0 (qualAddress) field is used to extend address 0 matching in a range of addresses.

enum \_i2c\_slave\_bus\_speed

I2C slave bus speed options.

*Values:*

enumerator kI2C\_SlaveStandardMode

enumerator kI2C\_SlaveFastMode

enumerator kI2C\_SlaveFastModePlus

enumerator kI2C\_SlaveHsMode

enum \_i2c\_slave\_transfer\_event

Set of events sent to the callback for non blocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to I2C\_SlaveTransferNonBlocking() in order to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its *transfer* parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

*Values:*

enumerator kI2C\_SlaveAddressMatchEvent

Received the slave address after a start or repeated start.

enumerator kI2C\_SlaveTransmitEvent

Callback is requested to provide data to transmit (slave-transmitter role).

enumerator kI2C\_SlaveReceiveEvent

Callback is requested to provide a buffer in which to place received data (slave-receiver role).

enumerator kI2C\_SlaveCompletionEvent

All data in the active transfer have been consumed.

enumerator kI2C\_SlaveDeselectedEvent

The slave function has become deselected (SLVSEL flag changing from 1 to 0).

enumerator kI2C\_SlaveAllEvents

Bit mask of all available events.

enum \_i2c\_slave\_fsm

I2C slave software finite state machine states.

*Values:*

enumerator kI2C\_SlaveFsmAddressMatch

enumerator kI2C\_SlaveFsmReceive

enumerator kI2C\_SlaveFsmTransmit

typedef enum \_i2c\_slave\_address\_register i2c\_slave\_address\_register\_t

I2C slave address register.

typedef struct \_i2c\_slave\_address i2c\_slave\_address\_t

Data structure with 7-bit Slave address and Slave address disable.

typedef enum \_i2c\_slave\_address\_qual\_mode i2c\_slave\_address\_qual\_mode\_t

I2C slave address match options.

typedef enum \_i2c\_slave\_bus\_speed i2c\_slave\_bus\_speed\_t

I2C slave bus speed options.

typedef struct \_i2c\_slave\_config i2c\_slave\_config\_t

Structure with settings to initialize the I2C slave module.

This structure holds configuration settings for the I2C slave peripheral. To initialize this structure to reasonable defaults, call the I2C\_SlaveGetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

typedef enum \_i2c\_slave\_transfer\_event i2c\_slave\_transfer\_event\_t

Set of events sent to the callback for non blocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to I2C\_SlaveTransferNonBlocking() in order to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its *transfer* parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

`typedef struct _i2c_slave_handle i2c_slave_handle_t`  
I2C slave handle typedef.

`typedef struct _i2c_slave_transfer i2c_slave_transfer_t`  
I2C slave transfer structure.

`typedef void (*i2c_slave_transfer_callback_t)(I2C_Type *base, volatile i2c_slave_transfer_t *transfer, void *userData)`

Slave event callback function pointer type.

This callback is used only for the slave non-blocking transfer API. To install a callback, use the `I2C_SlaveSetCallback()` function after you have created a handle.

**Param base**

Base address for the I2C instance on which the event occurred.

**Param transfer**

Pointer to transfer descriptor containing values passed to and/or from the callback.

**Param userData**

Arbitrary pointer-sized value passed from the application.

`typedef enum _i2c_slave_fsm i2c_slave_fsm_t`  
I2C slave software finite state machine states.

`typedef void (*i2c_isr_t)(I2C_Type *base, void *i2cHandle)`  
Typedef for interrupt handler.

`typedef enum _i2c_slave_address_register i2c_slave_address_register_t`  
I2C slave address register.

`typedef struct _i2c_slave_address i2c_slave_address_t`  
Data structure with 7-bit Slave address and Slave address disable.

`typedef enum _i2c_slave_address_qual_mode i2c_slave_address_qual_mode_t`  
I2C slave address match options.

`typedef enum _i2c_slave_bus_speed i2c_slave_bus_speed_t`  
I2C slave bus speed options.

`typedef struct _i2c_slave_config i2c_slave_config_t`  
Structure with settings to initialize the I2C slave module.

This structure holds configuration settings for the I2C slave peripheral. To initialize this structure to reasonable defaults, call the `I2C_SlaveGetDefaultConfig()` function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

`typedef enum _i2c_slave_transfer_event i2c_slave_transfer_event_t`  
Set of events sent to the callback for non blocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to `I2C_SlaveTransferNonBlocking()` in order to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its `transfer` parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

```

typedef struct _i2c_slave_handle i2c_slave_handle_t
    I2C slave handle typedef.

typedef struct _i2c_slave_transfer i2c_slave_transfer_t
    I2C slave transfer structure.

typedef void (*i2c_slave_transfer_callback_t)(I2C_Type *base, volatile i2c_slave_transfer_t
*transfer, void *userData)

    Slave event callback function pointer type.

    This callback is used only for the slave non-blocking transfer API. To install a callback, use
    the I2C_SlaveSetCallback() function after you have created a handle.

Param base
    Base address for the I2C instance on which the event occurred.

Param transfer
    Pointer to transfer descriptor containing values passed to and/or from the call-
    back.

Param userData
    Arbitrary pointer-sized value passed from the application.

typedef enum _i2c_slave_fsm i2c_slave_fsm_t
    I2C slave software finite state machine states.

typedef void (*flexcomm_i2c_master_irq_handler_t)(I2C_Type *base, i2c_master_handle_t
*handle)

    Typedef for master interrupt handler.

typedef void (*flexcomm_i2c_slave_irq_handler_t)(I2C_Type *base, i2c_slave_handle_t *handle)

    Typedef for slave interrupt handler.

struct _i2c_slave_address
    #include <fsl_i2c.h> Data structure with 7-bit Slave address and Slave address disable.


```

### Public Members

```

uint8_t address
    7-bit Slave address SLVADR.

bool addressDisable
    Slave address disable SADISABLE.

```

```
struct _i2c_slave_config
```

```
    #include <fsl_i2c.h> Structure with settings to initialize the I2C slave module.
```

This structure holds configuration settings for the I2C slave peripheral. To initialize this structure to reasonable defaults, call the I2C\_SlaveGetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration structure can be made constant so it resides in flash.

### Public Members

```

i2c_slave_address_t address0
    Slave's 7-bit address and disable.

i2c_slave_address_t address1
    Alternate slave 7-bit address and disable.

```

```
i2c_slave_address_t address2
    Alternate slave 7-bit address and disable.

i2c_slave_address_t address3
    Alternate slave 7-bit address and disable.

i2c_slave_address_qual_mode_t qualMode
    Qualify mode for slave address 0.

uint8_t qualAddress
    Slave address qualifier for address 0.

i2c_slave_bus_speed_t busSpeed
    Slave bus speed mode. If the slave function stretches SCL to allow for software response, it must provide sufficient data setup time to the master before releasing the stretched clock. This is accomplished by inserting one clock time of CLKDIV at that point. The busSpeed value is used to configure CLKDIV such that one clock time is greater than the tSU;DAT value noted in the I2C bus specification for the I2C mode that is being used. If the busSpeed mode is unknown at compile time, use the longest data setup time kI2C_SlaveStandardMode (250 ns)

bool enableSlave
    Enable slave mode.

struct _i2c_slave_transfer
    #include <fsl_i2c.h> I2C slave transfer structure.
```

## Public Members

```
i2c_slave_handle_t *handle
    Pointer to handle that contains this transfer.

i2c_slave_transfer_event_t event
    Reason the callback is being invoked.

uint8_t receivedAddress
    Matching address send by master. 7-bits plus R/nW bit0

uint32_t eventMask
    Mask of enabled events.

uint8_t *rxData
    Transfer buffer for receive data

const uint8_t *txData
    Transfer buffer for transmit data

size_t txSize
    Transfer size

size_t rxSize
    Transfer size

size_t transferredCount
    Number of bytes transferred during this transfer.

status_t completionStatus
    Success or error code describing how the transfer completed. Only applies for kI2C_SlaveCompletionEvent.
```

```
struct _i2c_slave_handle
#include <fsl_i2c.h> I2C slave handle structure.
```

---

**Note:** The contents of this structure are private and subject to change.

---

### Public Members

```
volatile i2c_slave_transfer_t transfer
    I2C slave transfer.

volatile bool isBusy
    Whether transfer is busy.

volatile i2c_slave_fsm_t slaveFsm
    slave transfer state machine.

i2c_slave_transfer_callback_t callback
    Callback function called at transfer event.

void *userData
    Callback parameter passed to callback.
```

## 2.11 IAP: In Application Programming Driver

*status\_t* IAP\_ReadPartID(*uint32\_t* \*partID)

Read part identification number.

This function is used to read the part identification number.

#### Parameters

- partID – Address to store the part identification number.

#### Return values

kStatus\_IAP\_Success – Api has been executed successfully.

*status\_t* IAP\_ReadBootCodeVersion(*uint32\_t* \*bootCodeVersion)

Read boot code version number.

This function is used to read the boot code version number.

note Boot code version is two 32-bit words. Word 0 is the major version, word 1 is the minor version.

#### Parameters

- bootCodeVersion – Address to store the boot code version.

#### Return values

kStatus\_IAP\_Success – Api has been executed successfully.

*void* IAP\_ReinvokeISP(*uint8\_t* ispType, *uint32\_t* \*status)

Reinvoke ISP.

This function is used to invoke the boot loader in ISP mode. It maps boot vectors and configures the peripherals for ISP.

**note** The error response will be returned when IAP is disabled or an invalid ISP type selection appears. The call won't return unless an error occurs, so there can be no status code.

### Parameters

- `ispType` – ISP type selection.
- `status` – store the possible status.

### Return values

`kStatus_IAP_ReinvokeISPConfig` – reinvoke configuration error.

`status_t IAP_ReadUniqueID(uint32_t *uniqueID)`

Read unique identification.

This function is used to read the unique id.

### Parameters

- `uniqueID` – store the uniqueID.

### Return values

`kStatus_IAP_Success` – Api has been executed successfully.

`status_t IAP_PreparesectorForWrite(uint32_t startSector, uint32_t endSector)`

Prepare sector for write operation.

This function prepares sector(s) for write/erase operation. This function must be called before calling the `IAP_CopyRamToFlash()` or `IAP_EraseSector()` or `IAP_ErasePage()` function. The end sector number must be greater than or equal to the start sector number.

### Parameters

- `startSector` – Start sector number.
- `endSector` – End sector number.

### Return values

- `kStatus_IAP_Success` – Api has been executed successfully.
- `kStatus_IAP_NoPower` – Flash memory block is powered down.
- `kStatus_IAP_NoClock` – Flash memory block or controller is not clocked.
- `kStatus_IAP_InvalidSector` – Sector number is invalid or end sector number is greater than start sector number.
- `kStatus_IAP_Busy` – Flash programming hardware interface is busy.

`status_t IAP_CopyRamToFlash(uint32_t dstAddr, uint32_t *srcAddr, uint32_t numOfBytes, uint32_t systemCoreClock)`

Copy RAM to flash.

This function programs the flash memory. Corresponding sectors must be prepared via `IAP_PreparesectorForWrite` before calling this function.

### Parameters

- `dstAddr` – Destination flash address where data bytes are to be written, the address should be multiples of `FSL_FEATURE_SYSCON_FLASH_PAGE_SIZE_BYTES` boundary.
- `srcAddr` – Source ram address from where data bytes are to be read.
- `numOfBytes` – Number of bytes to be written, it should be multiples of `FSL_FEATURE_SYSCON_FLASH_PAGE_SIZE_BYTES`, and ranges from `FSL_FEATURE_SYSCON_FLASH_PAGE_SIZE_BYTES` to `FSL_FEATURE_SYSCON_FLASH_SECTOR_SIZE_BYTES`.

- systemCoreClock – SystemCoreClock in Hz. It is converted to KHz before calling the rom IAP function. When the flash controller has a fixed reference clock, this parameter is bypassed.

#### Return values

- kStatus\_IAP\_Success – Api has been executed successfully.
- kStatus\_IAP\_NoPower – Flash memory block is powered down.
- kStatus\_IAP\_NoClock – Flash memory block or controller is not clocked.
- kStatus\_IAP\_SrcAddrError – Source address is not on word boundary.
- kStatus\_IAP\_DstAddrError – Destination address is not on a correct boundary.
- kStatus\_IAP\_SrcAddrNotMapped – Source address is not mapped in the memory map.
- kStatus\_IAP\_DstAddrNotMapped – Destination address is not mapped in the memory map.
- kStatus\_IAP\_CountError – Byte count is not multiple of 4 or is not a permitted value.
- kStatus\_IAP\_NotPrepared – Command to prepare sector for write operation has not been executed.
- kStatus\_IAP\_Busy – Flash programming hardware interface is busy.

`status_t IAP_EraseSector(uint32_t startSector, uint32_t endSector, uint32_t systemCoreClock)`

Erase sector.

This function erases sector(s). The end sector number must be greater than or equal to the start sector number.

#### Parameters

- startSector – Start sector number.
- endSector – End sector number.
- systemCoreClock – SystemCoreClock in Hz. It is converted to KHz before calling the rom IAP function. When the flash controller has a fixed reference clock, this parameter is bypassed.

#### Return values

- kStatus\_IAP\_Success – Api has been executed successfully.
- kStatus\_IAP\_NoPower – Flash memory block is powered down.
- kStatus\_IAP\_NoClock – Flash memory block or controller is not clocked.
- kStatus\_IAP\_InvalidSector – Sector number is invalid or end sector number is greater than start sector number.
- kStatus\_IAP\_NotPrepared – Command to prepare sector for write operation has not been executed.
- kStatus\_IAP\_Busy – Flash programming hardware interface is busy.

`status_t IAP_ErasePage(uint32_t startPage, uint32_t endPage, uint32_t systemCoreClock)`

Erase page.

This function erases page(s). The end page number must be greater than or equal to the start page number.

#### Parameters

- startPage – Start page number.

- `endPage` – End page number.
- `systemCoreClock` – `SystemCoreClock` in Hz. It is converted to KHz before calling the rom IAP function. When the flash controller has a fixed reference clock, this parameter is bypassed.

#### Return values

- `kStatus_IAP_Success` – Api has been executed successfully.
- `kStatus_IAP_NoPower` – Flash memory block is powered down.
- `kStatus_IAP_NoClock` – Flash memory block or controller is not clocked.
- `kStatus_IAP_InvalidSector` – Page number is invalid or end page number is greater than start page number.
- `kStatus_IAP_NotPrepared` – Command to prepare sector for write operation has not been executed.
- `kStatus_IAP_Busy` – Flash programming hardware interface is busy.

`status_t IAP_BankCheckSector(uint32_t startSector, uint32_t endSector)`

Blank check sector(s)

Blank check single or multiples sectors of flash memory. The end sector number must be greater than or equal to the start sector number. It can be used to verify the sector erasure after `IAP_EraseSector` call.

#### Parameters

- `startSector` – Start sector number.
- `endSector` – End sector number.

#### Return values

- `kStatus_IAP_Success` – One or more sectors are in erased state.
- `kStatus_IAP_NoPower` – Flash memory block is powered down.
- `kStatus_IAP_NoClock` – Flash memory block or controller is not clocked.
- `kStatus_IAP_SectorNotblank` – One or more sectors are not blank.

`status_t IAP_Compare(uint32_t dstAddr, uint32_t *srcAddr, uint32_t numOfBytes)`

Compare memory contents of flash with ram.

This function compares the contents of flash and ram. It can be used to verify the flash memory contents after `IAP_CopyRamToFlash` call.

#### Parameters

- `dstAddr` – Destination flash address.
- `srcAddr` – Source ram address.
- `numOfBytes` – Number of bytes to be compared.

#### Return values

- `kStatus_IAP_Success` – Contents of flash and ram match.
- `kStatus_IAP_NoPower` – Flash memory block is powered down.
- `kStatus_IAP_NoClock` – Flash memory block or controller is not clocked.
- `kStatus_IAP_AddrError` – Address is not on word boundary.
- `kStatus_IAP_AddrNotMapped` – Address is not mapped in the memory map.

- kStatus\_IAP\_CountError – Byte count is not multiple of 4 or is not a permitted value.
- kStatus\_IAP\_CompareError – Destination and source memory contents do not match.

## FSL\_IAP\_DRIVER\_VERSION

iap status codes.

*Values:*

enumerator kStatus\_IAP\_Success

    Api is executed successfully

enumerator kStatus\_IAP\_InvalidCommand

    Invalid command

enumerator kStatus\_IAP\_SrcAddrError

    Source address is not on word boundary

enumerator kStatus\_IAP\_DstAddrError

    Destination address is not on a correct boundary

enumerator kStatus\_IAP\_SrcAddrNotMapped

    Source address is not mapped in the memory map

enumerator kStatus\_IAP\_DstAddrNotMapped

    Destination address is not mapped in the memory map

enumerator kStatus\_IAP\_CountError

    Byte count is not multiple of 4 or is not a permitted value

enumerator kStatus\_IAP\_InvalidSector

    Sector/page number is invalid or end sector/page number is greater than start sector/page number

enumerator kStatus\_IAP\_SectorNotblank

    One or more sectors are not blank

enumerator kStatus\_IAP\_NotPrepared

    Command to prepare sector for write operation has not been executed

enumerator kStatus\_IAP\_CompareError

    Destination and source memory contents do not match

enumerator kStatus\_IAP\_Busy

    Flash programming hardware interface is busy

enumerator kStatus\_IAP\_ParamError

    Insufficient number of parameters or invalid parameter

enumerator kStatus\_IAP\_AddrError

    Address is not on word boundary

enumerator kStatus\_IAP\_AddrNotMapped

    Address is not mapped in the memory map

enumerator kStatus\_IAP\_NoPower

    Flash memory block is powered down

enumerator kStatus\_IAP\_NoClock

    Flash memory block or controller is not clocked

```
enumerator kStatus_IAP_ReinvokeISPConfig
    Reinvoke configuration error

enum _iap_commands
    iap command codes.

Values:

enumerator kIapCmd_IAP_ReadFactorySettings
    Read the factory settings

enumerator kIapCmd_IAP_PrepareSectorforWrite
    Prepare Sector for write

enumerator kIapCmd_IAP_CopyRamToFlash
    Copy RAM to flash

enumerator kIapCmd_IAP_EraseSector
    Erase Sector

enumerator kIapCmd_IAP_BankCheckSector
    Blank check sector

enumerator kIapCmd_IAP_ReadPartId
    Read part id

enumerator kIapCmd_IAP_Read_BootromVersion
    Read bootrom version

enumerator kIapCmd_IAP_Compare
    Compare

enumerator kIapCmd_IAP_ReinvokeISP
    Reinvoke ISP

enumerator kIapCmd_IAP_ReadUid
    Read Uid

enumerator kIapCmd_IAP_ErasePage
    Erase Page

enumerator kIapCmd_IAP_ReadSignature
    Read Signature

enumerator kIapCmd_IAP_ExtendedReadSignature
    Extended Read Signature

enumerator kIapCmd_IAP_ReadEEPROMPage
    Read EEPROM page

enumerator kIapCmd_IAP_WriteEEPROMPage
    Write EEPROM page

enum _flash_access_time
    Flash memory access time.

Values:

enumerator kFlash_IAP_OneSystemClockTime

enumerator kFlash_IAP_TwoSystemClockTime
    1 system clock flash access time

enumerator kFlash_IAP_ThreeSystemClockTime
    2 system clock flash access time
```

## 2.12 INPUTMUX: Input Multiplexing Driver

```
enum __inputmux_connection_t
    INPUTMUX connections type.

Values:
enumerator kINPUTMUX_AdcASeqaIrqToDma
    DMA ITRIG INMUX.

enumerator kINPUTMUX_AdcBSeqbIrqToDma

enumerator kINPUTMUX_SetDma0ToDma

enumerator kINPUTMUX_SetDma1ToDma

enumerator kINPUTMUX_AcmpOToDma

enumerator kINPUTMUX_PinInt0ToDma

enumerator kINPUTMUX_PinInt1ToDma

enumerator kINPUTMUX_DmaTriggerMux0ToDma

enumerator kINPUTMUX_DmaTriggerMux1ToDma
    DMA INMUX.

enumerator kINPUTMUX_DmaChannel0TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel1TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel2TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel3TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel4TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel5TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel6TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel7TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel8TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel9TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel10TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel11TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel12TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel13TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel14TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel15TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel16TrigoutToTriginChannels
enumerator kINPUTMUX_DmaChannel17TrigoutToTriginChannels
    SCT INMUX.
```

```
enumerator kINPUTMUX_SctPin0ToSct0
enumerator kINPUTMUX_SctPin1ToSct0
enumerator kINPUTMUX_SctPin2ToSct0
enumerator kINPUTMUX_SctPin3ToSct0
enumerator kINPUTMUX_AdcThcmpIrqToSct0
enumerator kINPUTMUX_AcmpOToSct0
enumerator kINPUTMUX_ArmTxevToSct0
enumerator kINPUTMUX_DebugHaltedToSct0

typedef enum _inputmux_connection_t inputmux_connection_t
    INPUTMUX connections type.
```

DMA\_ITRIG\_INMUX\_ID

Periphinmux IDs.

DMA\_OTRIG\_PMUX\_ID

SCT0\_INMUX\_ID

PMUX\_SHIFT

FSL\_INPUTMUX\_DRIVER\_VERSION

Group interrupt driver version for SDK.

void INPUTMUX\_Init(void \*base)

Initialize INPUTMUX peripheral.

This function enables the INPUTMUX clock.

#### Parameters

- base – Base address of the INPUTMUX peripheral.

#### Return values

None. –

void INPUTMUX\_AttachSignal(void \*base, uint32\_t index, *inputmux\_connection\_t* connection)

Attaches a signal.

This function attaches multiplexed signals from INPUTMUX to target signals. For example, to attach GPIO PORT0 Pin 5 to PINT peripheral, do the following:

```
INPUTMUX_AttachSignal(INPUTMUX, 2, kINPUTMUX_GpioPort0Pin5ToPintsel);
```

In this example, INTMUX has 8 registers for PINT, PINT\_SEL0~PINT\_SEL7. With parameter index specified as 2, this function configures register PINT\_SEL2.

#### Parameters

- base – Base address of the INPUTMUX peripheral.
- index – The serial number of destination register in the group of INPUTMUX registers with same name.
- connection – Applies signal from source signals collection to target signal.

#### Return values

None. –

void INPUTMUX\_Deinit(void \*base)  
 Deinitialize INPUTMUX peripheral.  
 This function disables the INPUTMUX clock.

**Parameters**

- base – Base address of the INPUTMUX peripheral.

**Return values**

None. –

## 2.13 Common Driver

FSL\_COMMON\_DRIVER\_VERSION  
 common driver version.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_NONE  
 No debug console.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_UART  
 Debug console based on UART.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_LPUART  
 Debug console based on LPUART.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_LPSCI  
 Debug console based on LPSCI.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_USBCDC  
 Debug console based on USBCDC.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_FLEXCOMM  
 Debug console based on FLEXCOMM.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_IUART  
 Debug console based on i.MX UART.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_VUSART  
 Debug console based on LPC\_VUSART.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_MINI\_USART  
 Debug console based on LPC\_USART.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_SWO  
 Debug console based on SWO.

DEBUG\_CONSOLE\_DEVICE\_TYPE\_QSCI  
 Debug console based on QSCI.

MIN(a, b)  
 Computes the minimum of *a* and *b*.

MAX(a, b)  
 Computes the maximum of *a* and *b*.

UINT16\_MAX  
 Max value of uint16\_t type.

UINT32\_MAX  
 Max value of uint32\_t type.

SDK\_ATOMIC\_LOCAL\_ADD(addr, val)

Add value *val* from the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_SUB(addr, val)

Subtract value *val* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_SET(addr, bits)

Set the bits specified by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_CLEAR(addr, bits)

Clear the bits specified by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_TOGGLE(addr, bits)

Toggle the bits specified by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_CLEAR\_AND\_SET(addr, clearBits, setBits)

For the variable at address *address*, clear the bits specified by *clearBits* and set the bits specified by *setBits*.

SDK\_ATOMIC\_LOCAL\_COMPARE\_AND\_SET(addr, expected, newValue)

For the variable at address *address*, check whether the value equal to *expected*. If value same as *expected* then update *newValue* to address and return **true** , else return **false** .

SDK\_ATOMIC\_LOCAL\_TEST\_AND\_SET(addr, newValue)

For the variable at address *address*, set as *newValue* value and return old value.

USEC\_TO\_COUNT(us, clockFreqInHz)

Macro to convert a microsecond period to raw count value

COUNT\_TO\_USEC(count, clockFreqInHz)

Macro to convert a raw count value to microsecond

MSEC\_TO\_COUNT(ms, clockFreqInHz)

Macro to convert a millisecond period to raw count value

COUNT\_TO\_MSEC(count, clockFreqInHz)

Macro to convert a raw count value to millisecond

SDK\_ISR\_EXIT\_BARRIER

SDK\_SIZEALIGN(var, alignbytes)

Macro to define a variable with L1 d-cache line size alignment

Macro to define a variable with L2 cache line size alignment

Macro to change a value to a given size aligned value

AT\_NONCACHEABLE\_SECTION(var)

Define a variable *var*, and place it in non-cacheable section.

AT\_NONCACHEABLE\_SECTION\_ALIGN(var, alignbytes)

Define a variable *var*, and place it in non-cacheable section, the start address of the variable is aligned to *alignbytes*.

AT\_NONCACHEABLE\_SECTION\_INIT(var)

Define a variable *var* with initial value, and place it in non-cacheable section.

AT\_NONCACHEABLE\_SECTION\_ALIGN\_INIT(var, alignbytes)

Define a variable *var* with initial value, and place it in non-cacheable section, the start address of the variable is aligned to *alignbytes*.

```
enum __status__groups
  Status group numbers.

  Values:
  enumerator kStatusGroup_Generic
    Group number for generic status codes.
  enumerator kStatusGroup_FLASH
    Group number for FLASH status codes.
  enumerator kStatusGroup_LPSPI
    Group number for LPSPI status codes.
  enumerator kStatusGroup_FLEXIO_SPI
    Group number for FLEXIO SPI status codes.
  enumerator kStatusGroup_DSPI
    Group number for DSPI status codes.
  enumerator kStatusGroup_FLEXIO_UART
    Group number for FLEXIO UART status codes.
  enumerator kStatusGroup_FLEXIO_I2C
    Group number for FLEXIO I2C status codes.
  enumerator kStatusGroup_LPI2C
    Group number for LPI2C status codes.
  enumerator kStatusGroup_UART
    Group number for UART status codes.
  enumerator kStatusGroup_I2C
    Group number for UART status codes.
  enumerator kStatusGroup_LPSCI
    Group number for LPSCI status codes.
  enumerator kStatusGroup_LPUART
    Group number for LPUART status codes.
  enumerator kStatusGroup_SPI
    Group number for SPI status code.
  enumerator kStatusGroup_XRDC
    Group number for XRDC status code.
  enumerator kStatusGroup_SEMA42
    Group number for SEMA42 status code.
  enumerator kStatusGroup_SDHC
    Group number for SDHC status code
  enumerator kStatusGroup_SDMMC
    Group number for SDMMC status code
  enumerator kStatusGroup_SAI
    Group number for SAI status code
  enumerator kStatusGroup_MCG
    Group number for MCG status codes.
```

enumerator kStatusGroup\_SCG  
    Group number for SCG status codes.

enumerator kStatusGroup\_SD SPI  
    Group number for SD SPI status codes.

enumerator kStatusGroup\_FLEXIO\_I2S  
    Group number for FLEXIO I2S status codes

enumerator kStatusGroup\_FLEXIO\_MCULCD  
    Group number for FLEXIO LCD status codes

enumerator kStatusGroup\_FLASHIAP  
    Group number for FLASHIAP status codes

enumerator kStatusGroup\_FLEXCOMM\_I2C  
    Group number for FLEXCOMM I2C status codes

enumerator kStatusGroup\_I2S  
    Group number for I2S status codes

enumerator kStatusGroup\_IUART  
    Group number for IUART status codes

enumerator kStatusGroup\_CSI  
    Group number for CSI status codes

enumerator kStatusGroup\_MIPI\_DSI  
    Group number for MIPI DSI status codes

enumerator kStatusGroup\_SDRAMC  
    Group number for SDRAMC status codes.

enumerator kStatusGroup\_POWER  
    Group number for POWER status codes.

enumerator kStatusGroup\_ENET  
    Group number for ENET status codes.

enumerator kStatusGroup\_PHY  
    Group number for PHY status codes.

enumerator kStatusGroup\_TRGMUX  
    Group number for TRGMUX status codes.

enumerator kStatusGroup\_SMARTCARD  
    Group number for SMARTCARD status codes.

enumerator kStatusGroup\_LMEM  
    Group number for LMEM status codes.

enumerator kStatusGroup\_QSPI  
    Group number for QSPI status codes.

enumerator kStatusGroup\_DMA  
    Group number for DMA status codes.

enumerator kStatusGroup\_EDMA  
    Group number for EDMA status codes.

enumerator kStatusGroup\_DMAMGR  
    Group number for DMAMGR status codes.

enumerator kStatusGroup\_FLEXCAN  
Group number for FlexCAN status codes.

enumerator kStatusGroup\_LTC  
Group number for LTC status codes.

enumerator kStatusGroup\_FLEXIO\_CAMERA  
Group number for FLEXIO CAMERA status codes.

enumerator kStatusGroup\_LPC\_SPI  
Group number for LPC\_SPI status codes.

enumerator kStatusGroup\_LPC\_USART  
Group number for LPC\_USART status codes.

enumerator kStatusGroup\_DMIC  
Group number for DMIC status codes.

enumerator kStatusGroup\_SDIF  
Group number for SDIF status codes.

enumerator kStatusGroup\_SPIFI  
Group number for SPIFI status codes.

enumerator kStatusGroup OTP  
Group number for OTP status codes.

enumerator kStatusGroup\_MCAN  
Group number for MCAN status codes.

enumerator kStatusGroup\_CAAM  
Group number for CAAM status codes.

enumerator kStatusGroup\_ECSPI  
Group number for ECSPI status codes.

enumerator kStatusGroup\_USDHC  
Group number for USDHC status codes.

enumerator kStatusGroup\_LPC\_I2C  
Group number for LPC\_I2C status codes.

enumerator kStatusGroup\_DCP  
Group number for DCP status codes.

enumerator kStatusGroup\_MSCAN  
Group number for MSCAN status codes.

enumerator kStatusGroup\_ESAI  
Group number for ESAI status codes.

enumerator kStatusGroup\_FLEXSPI  
Group number for FLEXSPI status codes.

enumerator kStatusGroup\_MMDC  
Group number for MMDC status codes.

enumerator kStatusGroup\_PDM  
Group number for MIC status codes.

enumerator kStatusGroup\_SDMA  
Group number for SDMA status codes.

enumerator kStatusGroup\_ICS  
Group number for ICS status codes.

enumerator kStatusGroup\_SPDIF  
Group number for SPDIF status codes.

enumerator kStatusGroup\_LPC\_MINISPI  
Group number for LPC\_MINISPI status codes.

enumerator kStatusGroup\_HASHCRYPT  
Group number for Hashcrypt status codes

enumerator kStatusGroup\_LPC\_SPI\_SSP  
Group number for LPC\_SPI\_SSP status codes.

enumerator kStatusGroup\_I3C  
Group number for I3C status codes

enumerator kStatusGroup\_LPC\_I2C\_1  
Group number for LPC\_I2C\_1 status codes.

enumerator kStatusGroup\_NOTIFIER  
Group number for NOTIFIER status codes.

enumerator kStatusGroup\_DebugConsole  
Group number for debug console status codes.

enumerator kStatusGroup\_SEMC  
Group number for SEMC status codes.

enumerator kStatusGroup\_ApplicationRangeStart  
Starting number for application groups.

enumerator kStatusGroup\_IAP  
Group number for IAP status codes

enumerator kStatusGroup\_SFA  
Group number for SFA status codes

enumerator kStatusGroup\_SPC  
Group number for SPC status codes.

enumerator kStatusGroup\_PUF  
Group number for PUF status codes.

enumerator kStatusGroup\_TOUCH\_PANEL  
Group number for touch panel status codes

enumerator kStatusGroup\_VBAT  
Group number for VBAT status codes

enumerator kStatusGroup\_XSPI  
Group number for XSPI status codes

enumerator kStatusGroup\_PNGDEC  
Group number for PNGDEC status codes

enumerator kStatusGroup\_JPEGDEC  
Group number for JPEGDEC status codes

enumerator kStatusGroup\_AUDMIX  
Group number for AUDMIX status codes

```
enumerator kStatusGroup_HAL_GPIO
    Group number for HAL GPIO status codes.
enumerator kStatusGroup_HAL_UART
    Group number for HAL UART status codes.
enumerator kStatusGroup_HAL_TIMER
    Group number for HAL TIMER status codes.
enumerator kStatusGroup_HAL_SPI
    Group number for HAL SPI status codes.
enumerator kStatusGroup_HAL_I2C
    Group number for HAL I2C status codes.
enumerator kStatusGroup_HAL_FLASH
    Group number for HAL FLASH status codes.
enumerator kStatusGroup_HAL_PWM
    Group number for HAL PWM status codes.
enumerator kStatusGroup_HAL_RNG
    Group number for HAL RNG status codes.
enumerator kStatusGroup_HAL_I2S
    Group number for HAL I2S status codes.
enumerator kStatusGroup_HAL_ADC_SENSOR
    Group number for HAL ADC SENSOR status codes.
enumerator kStatusGroup_TIMERMANAGER
    Group number for TiMER MANAGER status codes.
enumerator kStatusGroup_SERIALMANAGER
    Group number for SERIAL MANAGER status codes.
enumerator kStatusGroup_LED
    Group number for LED status codes.
enumerator kStatusGroup_BUTTON
    Group number for BUTTON status codes.
enumerator kStatusGroup_EXTERN_EEPROM
    Group number for EXTERN EEPROM status codes.
enumerator kStatusGroup_SHELL
    Group number for SHELL status codes.
enumerator kStatusGroup_MEM_MANAGER
    Group number for MEM MANAGER status codes.
enumerator kStatusGroup_LIST
    Group number for List status codes.
enumerator kStatusGroup_OSA
    Group number for OSA status codes.
enumerator kStatusGroup_COMMON_TASK
    Group number for Common task status codes.
enumerator kStatusGroup_MSG
    Group number for messaging status codes.
```

enumerator kStatusGroup\_SDK\_OCOTP

Group number for OCOTP status codes.

enumerator kStatusGroup\_SDK\_FLEXSPINOR

Group number for FLEXSPINOR status codes.

enumerator kStatusGroup\_CODEC

Group number for codec status codes.

enumerator kStatusGroup\_ASRC

Group number for codec status ASRC.

enumerator kStatusGroup\_OTFAD

Group number for codec status codes.

enumerator kStatusGroup\_SDIOSLV

Group number for SDIOSLV status codes.

enumerator kStatusGroup\_MECC

Group number for MECC status codes.

enumerator kStatusGroup\_ENET\_QOS

Group number for ENET\_QOS status codes.

enumerator kStatusGroup\_LOG

Group number for LOG status codes.

enumerator kStatusGroup\_I3CBUS

Group number for I3CBUS status codes.

enumerator kStatusGroup\_QSCI

Group number for QSCI status codes.

enumerator kStatusGroup\_ELEMU

Group number for ELEMU status codes.

enumerator kStatusGroup\_QUEUEDSPI

Group number for QSPI status codes.

enumerator kStatusGroup\_POWER\_MANAGER

Group number for POWER\_MANAGER status codes.

enumerator kStatusGroup\_IPED

Group number for IPED status codes.

enumerator kStatusGroup\_ELS\_PKC

Group number for ELS PKC status codes.

enumerator kStatusGroup\_CSS\_PKC

Group number for CSS PKC status codes.

enumerator kStatusGroup\_HOSTIF

Group number for HOSTIF status codes.

enumerator kStatusGroup\_CLIF

Group number for CLIF status codes.

enumerator kStatusGroup\_BMA

Group number for BMA status codes.

enumerator kStatusGroup\_NETC

Group number for NETC status codes.

```
enumerator kStatusGroup_ELE
    Group number for ELE status codes.
enumerator kStatusGroup_GLIKEY
    Group number for GLIKEY status codes.
enumerator kStatusGroup_AON_POWER
    Group number for AON_POWER status codes.
enumerator kStatusGroup_AON_COMMON
    Group number for AON_COMMON status codes.
enumerator kStatusGroup_ENDAT3
    Group number for ENDAT3 status codes.
enumerator kStatusGroup_HIPERFACE
    Group number for HIPERFACE status codes.
enumerator kStatusGroup_NPX
    Group number for NPX status codes.
enumerator kStatusGroup_ELA_CSEC
    Group number for ELA_CSEC status codes.
enumerator kStatusGroup_FLEXIO_T_FORMAT
    Group number for T-format status codes.
enumerator kStatusGroup_FLEXIO_A_FORMAT
    Group number for A-format status codes.
```

Generic status return codes.

*Values:*

```
enumerator kStatus_Success
    Generic status for Success.
enumerator kStatus_Fail
    Generic status for Fail.
enumerator kStatus_ReadOnly
    Generic status for read only failure.
enumerator kStatus_OutOfRange
    Generic status for out of range access.
enumerator kStatus_InvalidArgument
    Generic status for invalid argument check.
enumerator kStatus_Timeout
    Generic status for timeout.
enumerator kStatus_NoTransferInProgress
    Generic status for no transfer in progress.
enumerator kStatus_Busy
    Generic status for module is busy.
enumerator kStatus_NoData
    Generic status for no data is found for the operation.
```

```
typedef int32_t status_t
```

Type used for all status and error return values.

```
void *SDK_Malloc(size_t size, size_t alignbytes)
```

Allocate memory with given alignment and aligned size.

This is provided to support the dynamically allocated memory used in cache-able region.

#### Parameters

- size – The length required to malloc.
- alignbytes – The alignment size.

#### Return values

The – allocated memory.

```
void SDK_Free(void *ptr)
```

Free memory.

#### Parameters

- ptr – The memory to be release.

```
void SDK_DelayAtLeastUs(uint32_t delayTime_us, uint32_t coreClock_Hz)
```

Delay at least for some time. Please note that, this API uses while loop for delay, different run-time environments make the time not precise, if precise delay count was needed, please implement a new delay function with hardware timer.

#### Parameters

- delayTime\_us – Delay time in unit of microsecond.
- coreClock\_Hz – Core clock frequency with Hz.

```
static inline status_t EnableIRQ(IRQn_Type interrupt)
```

Enable specific interrupt.

Enable LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only enables the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

#### Parameters

- interrupt – The IRQ number.

#### Return values

- kStatus\_Success – Interrupt enabled successfully
- kStatus\_Fail – Failed to enable the interrupt

```
static inline status_t DisableIRQ(IRQn_Type interrupt)
```

Disable specific interrupt.

Disable LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only disables the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

#### Parameters

- interrupt – The IRQ number.

**Return values**

- kStatus\_Success – Interrupt disabled successfully
- kStatus\_Fail – Failed to disable the interrupt

static inline *status\_t* EnableIRQWithPriority(*IRQn\_Type* interrupt, *uint8\_t* priNum)

Enable the IRQ, and also set the interrupt priority.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL FEATURE NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

**Parameters**

- interrupt – The IRQ to Enable.
- priNum – Priority number set to interrupt controller register.

**Return values**

- kStatus\_Success – Interrupt priority set successfully
- kStatus\_Fail – Failed to set the interrupt priority.

static inline *status\_t* IRQ\_SetPriority(*IRQn\_Type* interrupt, *uint8\_t* priNum)

Set the IRQ priority.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL FEATURE NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

**Parameters**

- interrupt – The IRQ to set.
- priNum – Priority number set to interrupt controller register.

**Return values**

- kStatus\_Success – Interrupt priority set successfully
- kStatus\_Fail – Failed to set the interrupt priority.

static inline *status\_t* IRQ\_ClearPendingIRQ(*IRQn\_Type* interrupt)

Clear the pending IRQ flag.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL FEATURE NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

**Parameters**

- interrupt – The flag which IRQ to clear.

**Return values**

- kStatus\_Success – Interrupt priority set successfully

- kStatus\_Fail – Failed to set the interrupt priority.

```
static inline uint32_t DisableGlobalIRQ(void)
```

Disable the global IRQ.

Disable the global interrupt and return the current primask register. User is required to provided the primask register for the EnableGlobalIRQ0.

#### Returns

Current primask value.

```
static inline void EnableGlobalIRQ(uint32_t primask)
```

Enable the global IRQ.

Set the primask register with the provided primask value but not just enable the primask. The idea is for the convenience of integration of RTOS. some RTOS get its own management mechanism of primask. User is required to use the EnableGlobalIRQ0 and DisableGlobalIRQ0 in pair.

#### Parameters

- primask – value of primask register to be restored. The primask value is supposed to be provided by the DisableGlobalIRQ0.

```
void EnableDeepSleepIRQ(IRQn_Type interrupt)
```

Enable specific interrupt for wake-up from deep-sleep mode.

Enable the interrupt for wake-up from deep sleep mode. Some interrupts are typically used in sleep mode only and will not occur during deep-sleep mode because relevant clocks are stopped. However, it is possible to enable those clocks (significantly increasing power consumption in the reduced power mode), making these wake-ups possible.

---

**Note:** This function also enables the interrupt in the NVIC (EnableIRQ0 is called internally).

---

#### Parameters

- interrupt – The IRQ number.

```
void DisableDeepSleepIRQ(IRQn_Type interrupt)
```

Disable specific interrupt for wake-up from deep-sleep mode.

Disable the interrupt for wake-up from deep sleep mode. Some interrupts are typically used in sleep mode only and will not occur during deep-sleep mode because relevant clocks are stopped. However, it is possible to enable those clocks (significantly increasing power consumption in the reduced power mode), making these wake-ups possible.

---

**Note:** This function also disables the interrupt in the NVIC (DisableIRQ0 is called internally).

---

#### Parameters

- interrupt – The IRQ number.

```
static inline bool _SDK_AtomicLocalCompareAndSet(uint32_t *addr, uint32_t expected, uint32_t newValue)
```

```
static inline uint32_t _SDK_AtomicTestAndSet(uint32_t *addr, uint32_t newValue)
```

```
FSL_DRIVER_TRANSFER_DOUBLE_WEAK_IRQ
```

Macro to use the default weak IRQ handler in drivers.



In default configuration, the ACOMP's output would be used directly and switch as the voltages cross.

#### Parameters

- config – Pointer to the configuration structure.

```
void ACOMP_EnableInterrupts(ACOMP_Type *base, acomp_interrupt_enable_t enable)
```

Enable ACOMP interrupts.

#### Parameters

- base – ACOMP peripheral base address.
- enable – Enable/Disable interrupt feature.

```
static inline bool ACOMP_GetInterruptsStatusFlags(ACOMP_Type *base)
```

Get interrupts status flags.

#### Parameters

- base – ACOMP peripheral base address.

#### Returns

Reflect the state ACOMP edge-detect status, true or false.

```
static inline void ACOMP_ClearInterruptsStatusFlags(ACOMP_Type *base)
```

Clear the ACOMP interrupts status flags.

#### Parameters

- base – ACOMP peripheral base address.

```
static inline bool ACOMP_GetOutputStatusFlags(ACOMP_Type *base)
```

Get ACOMP output status flags.

#### Parameters

- base – ACOMP peripheral base address.

#### Returns

Reflect the state of the comparator output, true or false.

```
static inline void ACOMP_SetInputChannel(ACOMP_Type *base, uint32_t positiveInputChannel,  
                                      uint32_t negativeInputChannel)
```

Set the ACOMP positive and negative input channel.

#### Parameters

- base – ACOMP peripheral base address.
- positiveInputChannel – The index of positive input channel.
- negativeInputChannel – The index of negative input channel.

```
void ACOMP_SetLadderConfig(ACOMP_Type *base, const acomp_ladder_config_t *config)
```

Set the voltage ladder configuration.

#### Parameters

- base – ACOMP peripheral base address.
- config – The structure for voltage ladder. If the config is NULL, voltage ladder would be disabled, otherwise the voltage ladder would be configured and enabled.

FSL\_ACOMP\_DRIVER\_VERSION

ACOMP driver version 2.1.0.

**enum \_acomp\_ladder\_reference\_voltage**

The ACOMP ladder reference voltage.

*Values:*

enumerator kACOMP\_LadderRefVoltagePinVDD

Supply from pin VDD.

enumerator kACOMP\_LadderRefVoltagePinVDDCMP

Supply from pin VDDCMP.

**enum \_acomp\_interrupt\_enable**

The ACOMP interrupts enable.

*Values:*

enumerator kACOMP InterruptsFallingEdgeEnable

Enable the falling edge interrupts.

enumerator kACOMP InterruptsRisingEdgeEnable

Enable the rising edge interrupts.

enumerator kACOMP InterruptsBothEdgesEnable

Enable the both edges interrupts.

enumerator kACOMP InterruptsDisable

Disable the interrupts.

**enum \_acomp\_hysteresis\_selection**

The ACOMP hysteresis selection.

*Values:*

enumerator kACOMP\_HysteresisNoneSelection

None (the output will switch as the voltages cross).

enumerator kACOMP\_Hysteresis5MVSelection

5mV.

enumerator kACOMP\_Hysteresis10MVSelection

10mV.

enumerator kACOMP\_Hysteresis20MVSelection

20mV.

**typedef enum \_acomp\_ladder\_reference\_voltage** acomp\_ladder\_reference\_voltage\_t

The ACOMP ladder reference voltage.

**typedef enum \_acomp\_interrupt\_enable** acomp\_interrupt\_enable\_t

The ACOMP interrupts enable.

**typedef enum \_acomp\_hysteresis\_selection** acomp\_hysteresis\_selection\_t

The ACOMP hysteresis selection.

**typedef struct \_acomp\_config** acomp\_config\_t

The structure for ACOMP basic configuration.

**typedef struct \_acomp\_ladder\_config** acomp\_ladder\_config\_t

The structure for ACOMP voltage ladder.

**struct \_acomp\_config**

#include <fsl\_acomp.h> The structure for ACOMP basic configuration.

**Public Members**

`bool enableSyncToBusClk`

If true, Comparator output is synchronized to the bus clock for output to other modules.  
If false, Comparator output is used directly.

`acomp_hysteresis_selection_t hysteresisSelection`

Controls the hysteresis of the comparator.

`struct _acomp_ladder_config`

`#include <fsl_acomp.h>` The structure for ACOMP voltage ladder.

**Public Members**

`uint8_t ladderValue`

Voltage ladder value. 00000 = Vss, 00001 = 1\*Vref/31, ..., 11111 = Vref.

`acomp_ladder_reference_voltage_t referenceVoltage`

Selects the reference voltage(Vref) for the voltage ladder.

## 2.15 ADC: 12-bit SAR Analog-to-Digital Converter Driver

`void ADC_Init(ADC_Type *base, const adc_config_t *config)`

Initialize the ADC module.

**Parameters**

- `base` – ADC peripheral base address.
- `config` – Pointer to configuration structure, see to `adc_config_t`.

`void ADC_Deinit(ADC_Type *base)`

Deinitialize the ADC module.

**Parameters**

- `base` – ADC peripheral base address.

`void ADC_GetDefaultConfig(adc_config_t *config)`

Gets an available pre-defined settings for initial configuration.

This function initializes the initial configuration structure with an available settings. The default values are:

```
config->clockMode = kADC_ClockSynchronousMode;
config->clockDividerNumber = 0U;
config->resolution = kADC_Resolution12bit;
config->enableBypassCalibration = false;
config->sampleTimeNumber = 0U;
config->extendSampleTimeNumber = kADC_ExtendSampleTimeNotUsed;
```

**Parameters**

- `config` – Pointer to configuration structure.

`bool ADC_DoSelfCalibration(ADC_Type *base)`

Do the hardware self-calibration.

**Deprecated:**

Do not use this function. It has been superceded by ADC\_DoOffsetCalibration.

To calibrate the ADC, set the ADC clock to 500 kHz. In order to achieve the specified ADC accuracy, the A/D converter must be recalibrated, at a minimum, following every chip reset before initiating normal ADC operation.

**Parameters**

- base – ADC peripheral base address.

**Return values**

- true – Calibration succeed.
- false – Calibration failed.

`bool ADC_DoOffsetCalibration(ADC_Type *base, uint32_t frequency)`

Do the hardware offset-calibration.

To calibrate the ADC, set the ADC clock to no more then 30 MHz. In order to achieve the specified ADC accuracy, the A/D converter must be recalibrated, at a minimum, following every chip reset before initiating normal ADC operation.

**Parameters**

- base – ADC peripheral base address.
- frequency – The clock frequency that ADC operates at.

**Return values**

- true – Calibration succeed.
- false – Calibration failed.

`static inline void ADC_EnableConvSeqA(ADC_Type *base, bool enable)`

Enable the conversion sequence A.

In order to avoid spuriously triggering the sequence, the trigger to conversion sequence should be ready before the sequence is ready. when the sequence is disabled, the trigger would be ignored. Also, it is suggested to disable the sequence during changing the sequence's setting.

**Parameters**

- base – ADC peripheral base address.
- enable – Switcher to enable the feature or not.

`void ADC_SetConvSeqAConfig(ADC_Type *base, const adc_conv_seq_config_t *config)`

Configure the conversion sequence A.

**Parameters**

- base – ADC peripheral base address.
- config – Pointer to configuration structure, see to `adc_conv_seq_config_t`.

`static inline void ADC_DoSoftwareTriggerConvSeqA(ADC_Type *base)`

Do trigger the sequence's conversion by software.

**Parameters**

- base – ADC peripheral base address.

```
static inline void ADC_EnableConvSeqABurstMode(ADC_Type *base, bool enable)
```

Enable the burst conversion of sequence A.

Enable the burst mode would cause the conversion sequence to be continuously cycled through. Other triggers would be ignored while this mode is enabled. Repeated conversions could be halted by disabling this mode. And the sequence currently in process will be completed before conversions are terminated. Note that a new sequence could begin just before the burst mode is disabled.

#### Parameters

- base – ADC peripheral base address.
- enable – Switcher to enable this feature.

```
static inline void ADC_SetConvSeqAHighPriority(ADC_Type *base)
```

Set the high priority for conversion sequence A.

#### Parameters

- base – ADC peripheral base address.

```
static inline void ADC_EnableConvSeqB(ADC_Type *base, bool enable)
```

Enable the conversion sequence B.

In order to avoid spuriously triggering the sequence, the trigger to conversion sequence should be ready before the sequence is ready. When the sequence is disabled, the trigger would be ignored. Also, it is suggested to disable the sequence during changing the sequence's setting.

#### Parameters

- base – ADC peripheral base address.
- enable – Switcher to enable the feature or not.

```
void ADC_SetConvSeqBConfig(ADC_Type *base, const adc_conv_seq_config_t *config)
```

Configure the conversion sequence B.

#### Parameters

- base – ADC peripheral base address.
- config – Pointer to configuration structure, see to `adc_conv_seq_config_t`.

```
static inline void ADC_DoSoftwareTriggerConvSeqB(ADC_Type *base)
```

Do trigger the sequence's conversion by software.

#### Parameters

- base – ADC peripheral base address.

```
static inline void ADC_EnableConvSeqBBurstMode(ADC_Type *base, bool enable)
```

Enable the burst conversion of sequence B.

Enable the burst mode would cause the conversion sequence to be continuously cycled through. Other triggers would be ignored while this mode is enabled. Repeated conversions could be halted by disabling this mode. And the sequence currently in process will be completed before conversions are terminated. Note that a new sequence could begin just before the burst mode is disabled.

#### Parameters

- base – ADC peripheral base address.
- enable – Switcher to enable this feature.

static inline void ADC\_SetConvSeqBHighPriority(ADC\_Type \*base)

Set the high priority for conversion sequence B.

#### Parameters

- base – ADC peripheral base address.

bool ADC\_GetConvSeqAGlobalConversionResult(ADC\_Type \*base, *adc\_result\_info\_t* \*info)

Get the global ADC conversion information of sequence A.

#### Parameters

- base – ADC peripheral base address.
- info – Pointer to information structure, see to *adc\_result\_info\_t*;

#### Return values

- true – The conversion result is ready.
- false – The conversion result is not ready yet.

bool ADC\_GetConvSeqBGlobalConversionResult(ADC\_Type \*base, *adc\_result\_info\_t* \*info)

Get the global ADC conversion information of sequence B.

#### Parameters

- base – ADC peripheral base address.
- info – Pointer to information structure, see to *adc\_result\_info\_t*;

#### Return values

- true – The conversion result is ready.
- false – The conversion result is not ready yet.

bool ADC\_GetChannelConversionResult(ADC\_Type \*base, uint32\_t channel, *adc\_result\_info\_t* \*info)

Get the channel's ADC conversion completed under each conversion sequence.

#### Parameters

- base – ADC peripheral base address.
- channel – The indicated channel number.
- info – Pointer to information structure, see to *adc\_result\_info\_t*;

#### Return values

- true – The conversion result is ready.
- false – The conversion result is not ready yet.

static inline void ADC\_SetThresholdPair0(ADC\_Type \*base, uint32\_t lowValue, uint32\_t highValue)

Set the threshold pair 0 with low and high value.

#### Parameters

- base – ADC peripheral base address.
- lowValue – LOW threshold value.
- highValue – HIGH threshold value.

static inline void ADC\_SetThresholdPair1(ADC\_Type \*base, uint32\_t lowValue, uint32\_t highValue)

Set the threshold pair 1 with low and high value.

#### Parameters

- base – ADC peripheral base address.
- lowValue – LOW threshold value. The available value is with 12-bit.
- highValue – HIGH threshold value. The available value is with 12-bit.

static inline void ADC\_SetChannelWithThresholdPair0(ADC\_Type \*base, uint32\_t channelMask)

Set given channels to apply the threshold pare 0.

#### Parameters

- base – ADC peripheral base address.
- channelMask – Indicated channels' mask.

static inline void ADC\_SetChannelWithThresholdPair1(ADC\_Type \*base, uint32\_t channelMask)

Set given channels to apply the threshold pare 1.

#### Parameters

- base – ADC peripheral base address.
- channelMask – Indicated channels' mask.

static inline void ADC\_EnableInterrupts(ADC\_Type \*base, uint32\_t mask)

Enable interrupts for conversion sequences.

#### Parameters

- base – ADC peripheral base address.
- mask – Mask of interrupt mask value for global block except each channel, see to `_adc_interrupt_enable`.

static inline void ADC\_DisableInterrupts(ADC\_Type \*base, uint32\_t mask)

Disable interrupts for conversion sequence.

#### Parameters

- base – ADC peripheral base address.
- mask – Mask of interrupt mask value for global block except each channel, see to `_adc_interrupt_enable`.

static inline void ADC\_EnableThresholdCompareInterrupt(ADC\_Type \*base, uint32\_t channel, *adc\_threshold\_interrupt\_mode\_t* mode)

Enable the interrupt of threshold compare event for each channel.

#### Parameters

- base – ADC peripheral base address.
- channel – Channel number.
- mode – Interrupt mode for threshold compare event, see to `adc_threshold_interrupt_mode_t`.

static inline uint32\_t ADC\_GetStatusFlags(ADC\_Type \*base)

Get status flags of ADC module.

#### Parameters

- base – ADC peripheral base address.

#### Returns

Mask of status flags of module, see to `_adc_status_flags`.

```
static inline void ADC_ClearStatusFlags(ADC_Type *base, uint32_t mask)
```

Clear status flags of ADC module.

#### Parameters

- base – ADC peripheral base address.
- mask – Mask of status flags of module, see to `_adc_status_flags`.

FSL\_ADC\_DRIVER\_VERSION

ADC driver version 2.6.0.

enum `_adc_status_flags`

Flags.

*Values:*

enumerator `kADC_ThresholdCompareFlagOnChn0`

Threshold comparison event on Channel 0.

enumerator `kADC_ThresholdCompareFlagOnChn1`

Threshold comparison event on Channel 1.

enumerator `kADC_ThresholdCompareFlagOnChn2`

Threshold comparison event on Channel 2.

enumerator `kADC_ThresholdCompareFlagOnChn3`

Threshold comparison event on Channel 3.

enumerator `kADC_ThresholdCompareFlagOnChn4`

Threshold comparison event on Channel 4.

enumerator `kADC_ThresholdCompareFlagOnChn5`

Threshold comparison event on Channel 5.

enumerator `kADC_ThresholdCompareFlagOnChn6`

Threshold comparison event on Channel 6.

enumerator `kADC_ThresholdCompareFlagOnChn7`

Threshold comparison event on Channel 7.

enumerator `kADC_ThresholdCompareFlagOnChn8`

Threshold comparison event on Channel 8.

enumerator `kADC_ThresholdCompareFlagOnChn9`

Threshold comparison event on Channel 9.

enumerator `kADC_ThresholdCompareFlagOnChn10`

Threshold comparison event on Channel 10.

enumerator `kADC_ThresholdCompareFlagOnChn11`

Threshold comparison event on Channel 11.

enumerator `kADC_OverrunFlagForChn0`

Mirror the OVERRUN status flag from the result register for ADC channel 0.

enumerator `kADC_OverrunFlagForChn1`

Mirror the OVERRUN status flag from the result register for ADC channel 1.

enumerator `kADC_OverrunFlagForChn2`

Mirror the OVERRUN status flag from the result register for ADC channel 2.

enumerator `kADC_OverrunFlagForChn3`

Mirror the OVERRUN status flag from the result register for ADC channel 3.

```
enumerator kADC_OVERRUNFlagForChn4
    Mirror the OVERRUN status flag from the result register for ADC channel 4.
enumerator kADC_OVERRUNFlagForChn5
    Mirror the OVERRUN status flag from the result register for ADC channel 5.
enumerator kADC_OVERRUNFlagForChn6
    Mirror the OVERRUN status flag from the result register for ADC channel 6.
enumerator kADC_OVERRUNFlagForChn7
    Mirror the OVERRUN status flag from the result register for ADC channel 7.
enumerator kADC_OVERRUNFlagForChn8
    Mirror the OVERRUN status flag from the result register for ADC channel 8.
enumerator kADC_OVERRUNFlagForChn9
    Mirror the OVERRUN status flag from the result register for ADC channel 9.
enumerator kADC_OVERRUNFlagForChn10
    Mirror the OVERRUN status flag from the result register for ADC channel 10.
enumerator kADC_OVERRUNFlagForChn11
    Mirror the OVERRUN status flag from the result register for ADC channel 11.
enumerator kADC_GlobalOVERRUNFlagForSeqA
    Mirror the global OVERRUN status flag for conversion sequence A.
enumerator kADC_GlobalOVERRUNFlagForSeqB
    Mirror the global OVERRUN status flag for conversion sequence B.
enumerator kADC_ConvSeqAInterruptFlag
    Sequence A interrupt/DMA trigger.
enumerator kADC_ConvSeqBInterruptFlag
    Sequence B interrupt/DMA trigger.
enumerator kADC_ThresholdCompareInterruptFlag
    Threshold comparision interrupt flag.
enumerator kADC_OVERRUNInterruptFlag
    Overrun interrupt flag.

enum __adc_interrupt_enable
    Interrupts.
```

---

**Note:** Not all the interrupt options are listed here

---

*Values:*

```
enumerator kADC_ConvSeqAInterruptEnable
    Enable interrupt upon completion of each individual conversion in sequence A, or
    entire sequence.
enumerator kADC_ConvSeqBInterruptEnable
    Enable interrupt upon completion of each individual conversion in sequence B, or en-
    tire sequence.
enumerator kADC_OVERRUNInterruptEnable
    Enable the detection of an overrun condition on any of the channel data registers will
    cause an overrun interrupt/DMA trigger.
```

`enum _adc_clock_mode`

Define selection of clock mode.

*Values:*

`enumerator kADC_ClockSynchronousMode`

The ADC clock would be derived from the system clock based on “clockDividerNumber”.

`enumerator kADC_ClockAsynchronousMode`

The ADC clock would be based on the SYSCON block’s divider.

`enum _adc_resolution`

Define selection of resolution.

*Values:*

`enumerator kADC_Resolution6bit`

6-bit resolution.

`enumerator kADC_Resolution8bit`

8-bit resolution.

`enumerator kADC_Resolution10bit`

10-bit resolution.

`enumerator kADC_Resolution12bit`

12-bit resolution.

`enum _adc_voltage_range`

Definfe range of the analog supply voltage VDDA.

*Values:*

`enumerator kADC_HighVoltageRange`

`enumerator kADC_LowVoltageRange`

`enum _adc_trigger_polarity`

Define selection of polarity of selected input trigger for conversion sequence.

*Values:*

`enumerator kADC_TriggerPolarityNegativeEdge`

A negative edge launches the conversion sequence on the trigger(s).

`enumerator kADC_TriggerPolarityPositiveEdge`

A positive edge launches the conversion sequence on the trigger(s).

`enum _adc_priority`

Define selection of conversion sequence’s priority.

*Values:*

`enumerator kADC_PriorityLow`

This sequence would be preempted when another sequence is started.

`enumerator kADC_PriorityHigh`

This sequence would preempt other sequence even when it is started.

`enum _adc_seq_interrupt_mode`

Define selection of conversion sequence’s interrupt.

*Values:*

enumerator kADC\_InterruptForEachConversion

The sequence interrupt/DMA trigger will be set at the end of each individual ADC conversion inside this conversion sequence.

enumerator kADC\_InterruptForEachSequence

The sequence interrupt/DMA trigger will be set when the entire set of this sequence conversions completes.

enum \_adc\_threshold\_compare\_status

Define status of threshold compare result.

*Values:*

enumerator kADC\_ThresholdCompareInRange

LOW threshold <= conversion value <= HIGH threshold.

enumerator kADC\_ThresholdCompareBelowRange

conversion value < LOW threshold.

enumerator kADC\_ThresholdCompareAboveRange

conversion value > HIGH threshold.

enum \_adc\_threshold\_crossing\_status

Define status of threshold crossing detection result.

*Values:*

enumerator kADC\_ThresholdCrossingNoDetected

No threshold Crossing detected.

enumerator kADC\_ThresholdCrossingDownward

Downward Threshold Crossing detected.

enumerator kADC\_ThresholdCrossingUpward

Upward Threshold Crossing Detected.

enum \_adc\_threshold\_interrupt\_mode

Define interrupt mode for threshold compare event.

*Values:*

enumerator kADC\_ThresholdInterruptDisabled

Threshold comparison interrupt is disabled.

enumerator kADC\_ThresholdInterruptOnOutside

Threshold comparison interrupt is enabled on outside threshold.

enumerator kADC\_ThresholdInterruptOnCrossing

Threshold comparison interrupt is enabled on crossing threshold.

enum \_adc\_inforesultshift

Define the info result mode of different resolution.

*Values:*

enumerator kADC\_Resolution12bitInfoResultShift

Info result shift of Resolution12bit.

enumerator kADC\_Resolution10bitInfoResultShift

Info result shift of Resolution10bit.

enumerator kADC\_Resolution8bitInfoResultShift

Info result shift of Resolution8bit.

enumerator kADC\_Resolution6bitInfoResultShift  
 Info result shift of Resolution6bit.

enum \_adc\_tempsensor\_common\_mode  
 Define common modes for Temerature sensor.  
*Values:*

enumerator kADC\_HighNegativeOffsetAdded  
 Temperature sensor common mode: high negative offset added.

enumerator kADC\_IntermediateNegativeOffsetAdded  
 Temperature sensor common mode: intermediate negative offset added.

enumerator kADC\_NoOffsetAdded  
 Temperature sensor common mode: no offset added.

enumerator kADC\_LowPositiveOffsetAdded  
 Temperature sensor common mode: low positive offset added.

enum \_adc\_second\_control  
 Define source impedance modes for GPADC control.  
*Values:*

enumerator kADC\_Impedance621Ohm  
 Extand ADC sampling time according to source impedance 1: 0.621 kOhm.

enumerator kADC\_Impedance55kOhm  
 Extand ADC sampling time according to source impedance 20 (default): 55 kOhm.

enumerator kADC\_Impedance87kOhm  
 Extand ADC sampling time according to source impedance 31: 87 kOhm.

enumerator kADC\_NormalFunctionalMode  
 TEST mode: Normal functional mode.

enumerator kADC\_MultiplexeTestMode  
 TEST mode: Multiplexer test mode.

enumerator kADC\_ADCInUnityGainMode  
 TEST mode: ADC in unity gain mode.

typedef enum \_adc\_clock\_mode adc\_clock\_mode\_t  
 Define selection of clock mode.

typedef enum \_adc\_resolution adc\_resolution\_t  
 Define selection of resolution.

typedef enum \_adc\_voltage\_range adc\_vdda\_range\_t  
 Definfe range of the analog supply voltage VDDA.

typedef enum \_adc\_trigger\_polarity adc\_trigger\_polarity\_t  
 Define selection of polarity of selected input trigger for conversion sequence.

typedef enum \_adc\_priority adc\_priority\_t  
 Define selection of conversion sequence's priority.

typedef enum \_adc\_seq\_interrupt\_mode adc\_seq\_interrupt\_mode\_t  
 Define selection of conversion sequence's interrupt.

typedef enum \_adc\_threshold\_compare\_status adc\_threshold\_compare\_status\_t  
 Define status of threshold compare result.

```
typedef enum _adc_threshold_crossing_status adc_threshold_crossing_status_t
    Define status of threshold crossing detection result.

typedef enum _adc_threshold_interrupt_mode adc_threshold_interrupt_mode_t
    Define interrupt mode for threshold compare event.

typedef enum _adc_inforesultshift adc_inforesult_t
    Define the info result mode of different resolution.

typedef enum _adc_tempsensor_common_mode adc_tempsensor_common_mode_t
    Define common modes for Temperature sensor.

typedef enum _adc_second_control adc_second_control_t
    Define source impedance modes for GPADC control.

typedef struct _adc_config adc_config_t
    Define structure for configuring the block.

typedef struct _adc_conv_seq_config adc_conv_seq_config_t
    Define structure for configuring conversion sequence.

typedef struct _adc_result_info adc_result_info_t
    Define structure of keeping conversion result information.

struct _adc_config
    #include <fsl_adc.h> Define structure for configuring the block.
```

## Public Members

```
adc_clock_mode_t clockMode
    Select the clock mode for ADC converter.

uint32_t clockDividerNumber
    This field is only available when using kADC_ClockSynchronousMode for "clockMode" field. The divider would be plus by 1 based on the value in this field. The available range is in 8 bits.

adc_resolution_t resolution
    Select the conversion bits.

bool enableBypassCalibration
    By default, a calibration cycle must be performed each time the chip is powered-up. Re-calibration may be warranted periodically - especially if operating conditions have changed. To enable this option would avoid the need to calibrate if offset error is not a concern in the application.

uint32_t sampleTimeNumber
    By default, with value as "0U", the sample period would be 2.5 ADC clocks. Then, to plus the "sampleTimeNumber" value here. The available value range is in 3 bits.

bool enableLowPowerMode
    If disable low-power mode, ADC remains activated even when no conversions are requested. If enable low-power mode, The ADC is automatically powered-down when no conversions are taking place.

adc_vdda_range_t voltageRange
    Configure the ADC for the appropriate operating range of the analog supply voltage VDDA. Failure to set the area correctly causes the ADC to return incorrect conversion results.

struct _adc_conv_seq_config
    #include <fsl_adc.h> Define structure for configuring conversion sequence.
```

**Public Members****uint32\_t** channelMask

Selects which one or more of the ADC channels will be sampled and converted when this sequence is launched. The masked channels would be involved in current conversion sequence, beginning with the lowest-order. The available range is in 12-bit.

**uint32\_t** triggerMask

Selects which one or more of the available hardware trigger sources will cause this conversion sequence to be initiated. The available range is 6-bit.

*adc\_trigger\_polarity\_t* triggerPolarity

Select the trigger to launch conversion sequence.

**bool** enableSyncBypass

To enable this feature allows the hardware trigger input to bypass synchronization flip-flop stages and therefore shorten the time between the trigger input signal and the start of a conversion.

**bool** enableSingleStep

When enabling this feature, a trigger will launch a single conversion on the next channel in the sequence instead of the default response of launching an entire sequence of conversions.

*adc\_seq\_interrupt\_mode\_t* interruptMode

Select the interrupt/DMA trigger mode.

**struct** *\_adc\_result\_info*

#include <fsl\_adc.h> Define structure of keeping conversion result information.

**Public Members****uint32\_t** result

Keep the conversion data value.

*adc\_threshold\_compare\_status\_t* thresholdCompareStatus

Keep the threshold compare status.

*adc\_threshold\_crossing\_status\_t* thresholdCorssingStatus

Keep the threshold crossing status.

**uint32\_t** channelNumber

Keep the channel number for this conversion.

**bool** overrunFlag

Keep the status whether the conversion is overrun or not.

## 2.16 GPIO: General Purpose I/O

void GPIO\_PortInit(GPIO\_Type \*base, uint32\_t port)

Initializes the GPIO peripheral.

This function ungates the GPIO clock.

**Parameters**

- base – GPIO peripheral base pointer.
- port – GPIO port number.

```
void GPIO_PinInit(GPIO_Type *base, uint32_t port, uint32_t pin, const gpio_pin_config_t
*config)
```

Initializes a GPIO pin used by the board.

To initialize the GPIO, define a pin configuration, either input or output, in the user file. Then, call the `GPIO_PinInit()` function.

This is an example to define an input pin or output pin configuration:

```
Define a digital input pin configuration,
gpio_pin_config_t config =
{
  kGPIO_DigitalInput,
  0,
}

Define a digital output pin configuration,
gpio_pin_config_t config =
{
  kGPIO_DigitalOutput,
  0,
}
```

### Parameters

- `base` – GPIO peripheral base pointer(Typically GPIO)
- `port` – GPIO port number
- `pin` – GPIO pin number
- `config` – GPIO pin configuration pointer

`static inline void GPIO_PinWrite(GPIO_Type *base, uint32_t port, uint32_t pin, uint8_t output)`

Sets the output level of the one GPIO pin to the logic 1 or 0.

### Parameters

- `base` – GPIO peripheral base pointer(Typically GPIO)
- `port` – GPIO port number
- `pin` – GPIO pin number
- `output` – GPIO pin output logic level.
  - 0: corresponding pin output low-logic level.
  - 1: corresponding pin output high-logic level.

`static inline uint32_t GPIO_PinRead(GPIO_Type *base, uint32_t port, uint32_t pin)`

Reads the current input value of the GPIO PIN.

### Parameters

- `base` – GPIO peripheral base pointer(Typically GPIO)
- `port` – GPIO port number
- `pin` – GPIO pin number

### Return values

`GPIO` – port input value

- 0: corresponding pin input low-logic level.
- 1: corresponding pin input high-logic level.

`FSL_GPIO_DRIVER_VERSION`

LPC GPIO driver version.

---

```
enum __gpio__pin__direction
```

LPC GPIO direction definition.

*Values:*

enumerator kGPIO\_DigitalInput

    Set current pin as digital input

enumerator kGPIO\_DigitalOutput

    Set current pin as digital output

```
typedef enum __gpio__pin__direction gpio_pin_direction_t
```

LPC GPIO direction definition.

```
typedef struct __gpio__pin__config gpio_pin_config_t
```

The GPIO pin configuration structure.

Every pin can only be configured as either output pin or input pin at a time. If configured as a input pin, then leave the outputConfig unused.

```
static inline void GPIO_PortSet(GPIO_Type *base, uint32_t port, uint32_t mask)
```

Sets the output level of the multiple GPIO pins to the logic 1.

#### Parameters

- base – GPIO peripheral base pointer(Typically GPIO)
- port – GPIO port number
- mask – GPIO pin number macro

```
static inline void GPIO_PortClear(GPIO_Type *base, uint32_t port, uint32_t mask)
```

Sets the output level of the multiple GPIO pins to the logic 0.

#### Parameters

- base – GPIO peripheral base pointer(Typically GPIO)
- port – GPIO port number
- mask – GPIO pin number macro

```
static inline void GPIO_PortToggle(GPIO_Type *base, uint32_t port, uint32_t mask)
```

Reverses current output logic of the multiple GPIO pins.

#### Parameters

- base – GPIO peripheral base pointer(Typically GPIO)
- port – GPIO port number
- mask – GPIO pin number macro

```
struct __gpio__pin__config
```

*#include <fsl\_gpio.h>* The GPIO pin configuration structure.

Every pin can only be configured as either output pin or input pin at a time. If configured as a input pin, then leave the outputConfig unused.

### Public Members

*gpio\_pin\_direction\_t* pinDirection

    GPIO direction, input or output

*uint8\_t* outputLogic

    Set default output logic, no use in input

## 2.17 IOCON: I/O pin configuration

LPC\_IOCON\_DRIVER\_VERSION

IOCON driver version 2.0.2.

`typedef struct _iocon_group iocon_group_t`

Array of IOCON pin definitions passed to IOCON\_SetPinMuxing() must be in this format.

`__STATIC_INLINE void IOCON_PinMuxSet (IOCON_Type *base, uint8_t ionumber,  
uint32_t modefunc)`

IOCON function and mode selection definitions.

Sets I/O Control pin mux

---

**Note:** See the User Manual for specific modes and functions supported by the various pins.

---

### Parameters

- `base` – : The base of IOCON peripheral on the chip
- `ionumber` – : GPIO number to mux
- `modefunc` – : OR'ed values of type IOCON\_\*

### Returns

Nothing

`__STATIC_INLINE void IOCON_SetPinMuxing (IOCON_Type *base,  
const iocon_group_t *pinArray, uint32_t arrayLength)`

Set all I/O Control pin muxing.

### Parameters

- `base` – : The base of IOCON peripheral on the chip
- `pinArray` – : Pointer to array of pin mux selections
- `arrayLength` – : Number of entries in pinArray

### Returns

Nothing

FSL\_COMPONENT\_ID

`struct _iocon_group`

`#include <fsl_iocon.h>` Array of IOCON pin definitions passed to IOCON\_SetPinMuxing() must be in this format.

## 2.18 MRT: Multi-Rate Timer

`void MRT_Init(MRT_Type *base, const mrt_config_t *config)`

Ungates the MRT clock and configures the peripheral for basic operation.

---

**Note:** This API should be called at the beginning of the application using the MRT driver.

---

### Parameters

- base – Multi-Rate timer peripheral base address
- config – Pointer to user's MRT config structure. If MRT has MULTITASK bit field in MODCFG register, param config is useless.

`void MRT_Deinit(MRT_Type *base)`

Gate the MRT clock.

#### Parameters

- base – Multi-Rate timer peripheral base address

`static inline void MRT_GetDefaultConfig(mrt_config_t *config)`

Fill in the MRT config struct with the default settings.

The default values are:

`config->enableMultiTask = false;`

#### Parameters

- config – Pointer to user's MRT config structure.

`static inline void MRT_SetupChannelMode(MRT_Type *base, mrt_chnl_t channel, const mrt_timer_mode_t mode)`

Sets up an MRT channel mode.

#### Parameters

- base – Multi-Rate timer peripheral base address
- channel – Channel that is being configured.
- mode – Timer mode to use for the channel.

`static inline void MRT_EnableInterrupts(MRT_Type *base, mrt_chnl_t channel, uint32_t mask)`

Enables the MRT interrupt.

#### Parameters

- base – Multi-Rate timer peripheral base address
- channel – Timer channel number
- mask – The interrupts to enable. This is a logical OR of members of the enumeration `mrt_interrupt_enable_t`

`static inline void MRT_DisableInterrupts(MRT_Type *base, mrt_chnl_t channel, uint32_t mask)`

Disables the selected MRT interrupt.

#### Parameters

- base – Multi-Rate timer peripheral base address
- channel – Timer channel number
- mask – The interrupts to disable. This is a logical OR of members of the enumeration `mrt_interrupt_enable_t`

`static inline uint32_t MRT_GetEnabledInterrupts(MRT_Type *base, mrt_chnl_t channel)`

Gets the enabled MRT interrupts.

#### Parameters

- base – Multi-Rate timer peripheral base address
- channel – Timer channel number

**Returns**

The enabled interrupts. This is the logical OR of members of the enumeration `mrt_interrupt_enable_t`

`static inline uint32_t MRT_GetStatusFlags(MRT_Type *base, mrt_chnl_t channel)`

Gets the MRT status flags.

**Parameters**

- `base` – Multi-Rate timer peripheral base address
- `channel` – Timer channel number

**Returns**

The status flags. This is the logical OR of members of the enumeration `mrt_status_flags_t`

`static inline void MRT_ClearStatusFlags(MRT_Type *base, mrt_chnl_t channel, uint32_t mask)`

Clears the MRT status flags.

**Parameters**

- `base` – Multi-Rate timer peripheral base address
- `channel` – Timer channel number
- `mask` – The status flags to clear. This is a logical OR of members of the enumeration `mrt_status_flags_t`

`void MRT_UpdateTimerPeriod(MRT_Type *base, mrt_chnl_t channel, uint32_t count, bool immediateLoad)`

Used to update the timer period in units of count.

The new value will be immediately loaded or will be loaded at the end of the current time interval. For one-shot interrupt mode the new value will be immediately loaded.

---

**Note:** User can call the utility macros provided in `fsl_common.h` to convert to ticks

---

**Parameters**

- `base` – Multi-Rate timer peripheral base address
- `channel` – Timer channel number
- `count` – Timer period in units of ticks
- `immediateLoad` – true: Load the new value immediately into the TIMER register; false: Load the new value at the end of current timer interval

`static inline uint32_t MRT_GetCurrentTimerCount(MRT_Type *base, mrt_chnl_t channel)`

Reads the current timer counting value.

This function returns the real-time timer counting value, in a range from 0 to a timer period.

---

**Note:** User can call the utility macros provided in `fsl_common.h` to convert ticks to usec or msec

---

**Parameters**

- `base` – Multi-Rate timer peripheral base address
- `channel` – Timer channel number

**Returns**

Current timer counting value in ticks

---

static inline void MRT\_StartTimer(MRT\_Type \*base, *mrt\_chnl\_t* channel, *uint32\_t* count)

Starts the timer counting.

After calling this function, timers load period value, counts down to 0 and depending on the timer mode it will either load the respective start value again or stop.

---

**Note:** User can call the utility macros provided in *fsl\_common.h* to convert to ticks

---

#### Parameters

- *base* – Multi-Rate timer peripheral base address
- *channel* – Timer channel number.
- *count* – Timer period in units of ticks. Count can contain the LOAD bit, which control the force load feature.

static inline void MRT\_StopTimer(MRT\_Type \*base, *mrt\_chnl\_t* channel)

Stops the timer counting.

This function stops the timer from counting.

#### Parameters

- *base* – Multi-Rate timer peripheral base address
- *channel* – Timer channel number.

static inline *uint32\_t* MRT\_GetIdleChannel(MRT\_Type \*base)

Find the available channel.

This function returns the lowest available channel number.

#### Parameters

- *base* – Multi-Rate timer peripheral base address

FSL\_MRT\_DRIVER\_VERSION

**enum** *\_mrt\_chnl*

List of MRT channels.

*Values:*

enumerator kMRT\_Channel\_0

    MRT channel number 0

enumerator kMRT\_Channel\_1

    MRT channel number 1

enumerator kMRT\_Channel\_2

    MRT channel number 2

enumerator kMRT\_Channel\_3

    MRT channel number 3

**enum** *\_mrt\_timer\_mode*

List of MRT timer modes.

*Values:*

enumerator kMRT\_RepeatMode

    Repeat Interrupt mode

```
enumerator kMRT_OneShotMode
    One-shot Interrupt mode
enumerator kMRT_OneShotStallMode
    One-shot stall mode
enum __mrt_interrupt_enable
    List of MRT interrupts.
    Values:
        enumerator kMRT_TimerInterruptEnable
            Timer interrupt enable
enum __mrt_status_flags
    List of MRT status flags.
    Values:
        enumerator kMRT_TimerInterruptFlag
            Timer interrupt flag
        enumerator kMRT_TimerRunFlag
            Indicates state of the timer
typedef enum __mrt_chnl mrt_chnl_t
    List of MRT channels.
typedef enum __mrt_timer_mode mrt_timer_mode_t
    List of MRT timer modes.
typedef enum __mrt_interrupt_enable mrt_interrupt_enable_t
    List of MRT interrupts.
typedef enum __mrt_status_flags mrt_status_flags_t
    List of MRT status flags.
typedef struct __mrt_config mrt_config_t
    MRT configuration structure.

    This structure holds the configuration settings for the MRT peripheral. To initialize this
    structure to reasonable defaults, call the MRT_GetDefaultConfig() function and pass a
    pointer to your config structure instance.

    The config struct can be made const so it resides in flash

struct __mrt_config
    #include <fsl_mrt.h> MRT configuration structure.

    This structure holds the configuration settings for the MRT peripheral. To initialize this
    structure to reasonable defaults, call the MRT_GetDefaultConfig() function and pass a
    pointer to your config structure instance.

    The config struct can be made const so it resides in flash
```

## Public Members

```
bool enableMultiTask
    true: Timers run in multi-task mode; false: Timers run in hardware status mode
```

## 2.19 PINT: Pin Interrupt and Pattern Match Driver

```

FSL_PINT_DRIVER_VERSION

enum _pint_pin_enable
    PINT Pin Interrupt enable type.

    Values:
        enumerator kPINT_PinIntEnableNone
            Do not generate Pin Interrupt
        enumerator kPINT_PinIntEnableRiseEdge
            Generate Pin Interrupt on rising edge
        enumerator kPINT_PinIntEnableFallEdge
            Generate Pin Interrupt on falling edge
        enumerator kPINT_PinIntEnableBothEdges
            Generate Pin Interrupt on both edges
        enumerator kPINT_PinIntEnableLowLevel
            Generate Pin Interrupt on low level
        enumerator kPINT_PinIntEnableHighLevel
            Generate Pin Interrupt on high level

enum _pint_int
    PINT Pin Interrupt type.

    Values:
        enumerator kPINT_PinInt0
            Pin Interrupt 0

enum _pint_pmatch_input_src
    PINT Pattern Match bit slice input source type.

    Values:
        enumerator kPINT_PatternMatchInp0Src
            Input source 0
        enumerator kPINT_PatternMatchInp1Src
            Input source 1
        enumerator kPINT_PatternMatchInp2Src
            Input source 2
        enumerator kPINT_PatternMatchInp3Src
            Input source 3
        enumerator kPINT_PatternMatchInp4Src
            Input source 4
        enumerator kPINT_PatternMatchInp5Src
            Input source 5
        enumerator kPINT_PatternMatchInp6Src
            Input source 6
        enumerator kPINT_PatternMatchInp7Src
            Input source 7

```

```
enumerator kPINT_SecPatternMatchInp0Src
    Input source 0
enumerator kPINT_SecPatternMatchInp1Src
    Input source 1
enum __pint_pmatch_bslice
    PINT Pattern Match bit slice type.

    Values:
        enumerator kPINT_PatternMatchBSlice0
            Bit slice 0
enum __pint_pmatch_bslice_cfg
    PINT Pattern Match configuration type.

    Values:
        enumerator kPINT_PatternMatchAlways
            Always Contributes to product term match
        enumerator kPINT_PatternMatchStickyRise
            Sticky Rising edge
        enumerator kPINT_PatternMatchStickyFall
            Sticky Falling edge
        enumerator kPINT_PatternMatchStickyBothEdges
            Sticky Rising or Falling edge
        enumerator kPINT_PatternMatchHigh
            High level
        enumerator kPINT_PatternMatchLow
            Low level
        enumerator kPINT_PatternMatchNever
            Never contributes to product term match
        enumerator kPINT_PatternMatchBothEdges
            Either rising or falling edge

typedef enum __pint_pin_enable pint_pin_enable_t
    PINT Pin Interrupt enable type.

typedef enum __pint_int pint_pin_int_t
    PINT Pin Interrupt type.

typedef enum __pint_pmatch_input_src pint_pmatch_input_src_t
    PINT Pattern Match bit slice input source type.

typedef enum __pint_pmatch_bslice pint_pmatch_bslice_t
    PINT Pattern Match bit slice type.

typedef enum __pint_pmatch_bslice_cfg pint_pmatch_bslice_cfg_t
    PINT Pattern Match configuration type.

typedef struct __pint_status pint_status_t
    PINT event status.

typedef void (*pint_cb_t)(pint_pin_int_t pinr, pint_status_t *status)
    PINT Callback function.
```

```
typedef struct _pint_pmatch_cfg pint_pmatch_cfg_t
```

```
void PINT_Init(PINT_Type *base)
```

Initialize PINT peripheral.

This function initializes the PINT peripheral and enables the clock.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

None. –

```
void PINT_SetCallback(PINT_Type *base, pint_cb_t callback)
```

Set PINT callback.

This function set the callback for PINT interrupt handler.

#### Parameters

- `base` – Base address of the PINT peripheral.
- `callback` – Callback.

#### Return values

None. –

```
void PINT_PinInterruptConfig(PINT_Type *base, pint_pin_int_t intr, pint_pin_enable_t enable)
```

Configure PINT peripheral pin interrupt.

This function configures a given pin interrupt.

#### Parameters

- `base` – Base address of the PINT peripheral.
- `intr` – Pin interrupt.
- `enable` – Selects detection logic.

#### Return values

None. –

```
void PINT_PinInterruptGetConfig(PINT_Type *base, pint_pin_int_t pintr, pint_pin_enable_t *enable)
```

Get PINT peripheral pin interrupt configuration.

This function returns the configuration of a given pin interrupt.

#### Parameters

- `base` – Base address of the PINT peripheral.
- `pintr` – Pin interrupt.
- `enable` – Pointer to store the detection logic.

#### Return values

None. –

```
void PINT_PinInterruptClrStatus(PINT_Type *base, pint_pin_int_t pintr)
```

Clear Selected pin interrupt status only when the pin was triggered by edge-sensitive.

This function clears the selected pin interrupt status.

#### Parameters

- `base` – Base address of the PINT peripheral.
- `pintr` – Pin interrupt.

**Return values**

None. –

static inline uint32\_t PINT\_PinInterruptGetStatus(PINT\_Type \*base, *pint\_pin\_int\_t* pintr)

Get Selected pin interrupt status.

This function returns the selected pin interrupt status.

**Parameters**

- base – Base address of the PINT peripheral.
- pintr – Pin interrupt.

**Return values**

status – = 0 No pin interrupt request. = 1 Selected Pin interrupt request active.

void PINT\_PinInterruptClrStatusAll(PINT\_Type \*base)

Clear all pin interrupts status only when pins were triggered by edge-sensitive.

This function clears the status of all pin interrupts.

**Parameters**

- base – Base address of the PINT peripheral.

**Return values**

None. –

static inline uint32\_t PINT\_PinInterruptGetStatusAll(PINT\_Type \*base)

Get all pin interrupts status.

This function returns the status of all pin interrupts.

**Parameters**

- base – Base address of the PINT peripheral.

**Return values**

status – Each bit position indicates the status of corresponding pin interrupt.  
= 0 No pin interrupt request. = 1 Pin interrupt request active.

static inline void PINT\_PinInterruptClrFallFlag(PINT\_Type \*base, *pint\_pin\_int\_t* pintr)

Clear Selected pin interrupt fall flag.

This function clears the selected pin interrupt fall flag.

**Parameters**

- base – Base address of the PINT peripheral.
- pintr – Pin interrupt.

**Return values**

None. –

static inline uint32\_t PINT\_PinInterruptGetFallFlag(PINT\_Type \*base, *pint\_pin\_int\_t* pintr)

Get selected pin interrupt fall flag.

This function returns the selected pin interrupt fall flag.

**Parameters**

- base – Base address of the PINT peripheral.
- pintr – Pin interrupt.

**Return values**

flag – = 0 Falling edge has not been detected. = 1 Falling edge has been detected.

---

```
static inline void PINT_PinInterruptClrFallFlagAll(PINT_Type *base)
```

Clear all pin interrupt fall flags.

This function clears the fall flag for all pin interrupts.

**Parameters**

- *base* – Base address of the PINT peripheral.

**Return values**

None. –

```
static inline uint32_t PINT_PinInterruptGetFallFlagAll(PINT_Type *base)
```

Get all pin interrupt fall flags.

This function returns the fall flag of all pin interrupts.

**Parameters**

- *base* – Base address of the PINT peripheral.

**Return values**

*flags* – Each bit position indicates the falling edge detection of the corresponding pin interrupt. 0 Falling edge has not been detected. = 1 Falling edge has been detected.

```
static inline void PINT_PinInterruptClrRiseFlag(PINT_Type *base, pint_pin_int_t pintr)
```

Clear Selected pin interrupt rise flag.

This function clears the selected pin interrupt rise flag.

**Parameters**

- *base* – Base address of the PINT peripheral.
- *ptrin* – Pin interrupt.

**Return values**

None. –

```
static inline uint32_t PINT_PinInterruptGetRiseFlag(PINT_Type *base, pint_pin_int_t pintr)
```

Get selected pin interrupt rise flag.

This function returns the selected pin interrupt rise flag.

**Parameters**

- *base* – Base address of the PINT peripheral.
- *ptrin* – Pin interrupt.

**Return values**

*flag* – = 0 Rising edge has not been detected. = 1 Rising edge has been detected.

```
static inline void PINT_PinInterruptClrRiseFlagAll(PINT_Type *base)
```

Clear all pin interrupt rise flags.

This function clears the rise flag for all pin interrupts.

**Parameters**

- *base* – Base address of the PINT peripheral.

**Return values**

None. –

```
static inline uint32_t PINT_PinInterruptGetRiseFlagAll(PINT_Type *base)
```

Get all pin interrupt rise flags.

This function returns the rise flag of all pin interrupts.

**Parameters**

- base – Base address of the PINT peripheral.

**Return values**

flags – Each bit position indicates the rising edge detection of the corresponding pin interrupt. 0 Rising edge has not been detected. = 1 Rising edge has been detected.

```
void PINT_PatternMatchConfig(PINT_Type *base, pint_pmatch_bslice_t bslice, pint_pmatch_cfg_t *cfg)
```

Configure PINT pattern match.

This function configures a given pattern match bit slice.

**Parameters**

- base – Base address of the PINT peripheral.
- bslice – Pattern match bit slice number.
- cfg – Pointer to bit slice configuration.

**Return values**

None. –

```
void PINT_PatternMatchGetConfig(PINT_Type *base, pint_pmatch_bslice_t bslice, pint_pmatch_cfg_t *cfg)
```

Get PINT pattern match configuration.

This function returns the configuration of a given pattern match bit slice.

**Parameters**

- base – Base address of the PINT peripheral.
- bslice – Pattern match bit slice number.
- cfg – Pointer to bit slice configuration.

**Return values**

None. –

```
static inline uint32_t PINT_PatternMatchGetStatus(PINT_Type *base, pint_pmatch_bslice_t bslice)
```

Get pattern match bit slice status.

This function returns the status of selected bit slice.

**Parameters**

- base – Base address of the PINT peripheral.
- bslice – Pattern match bit slice number.

**Return values**

status – = 0 Match has not been detected. = 1 Match has been detected.

```
static inline uint32_t PINT_PatternMatchGetStatusAll(PINT_Type *base)
```

Get status of all pattern match bit slices.

This function returns the status of all bit slices.

**Parameters**

- base – Base address of the PINT peripheral.

**Return values**

status – Each bit position indicates the match status of corresponding bit slice.  
= 0 Match has not been detected. = 1 Match has been detected.

```
uint32_t PINT_PatternMatchResetDetectLogic(PINT_Type *base)
```

Reset pattern match detection logic.

This function resets the pattern match detection logic if any of the product term is matching.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

`pmstatus` – Each bit position indicates the match status of corresponding bit slice. = 0 Match was detected. = 1 Match was not detected.

```
static inline void PINT_PatternMatchEnable(PINT_Type *base)
```

Enable pattern match function.

This function enables the pattern match function.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

None. –

```
static inline void PINT_PatternMatchDisable(PINT_Type *base)
```

Disable pattern match function.

This function disables the pattern match function.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

None. –

```
static inline void PINT_PatternMatchEnableRXEV(PINT_Type *base)
```

Enable RXEV output.

This function enables the pattern match RXEV output.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

None. –

```
static inline void PINT_PatternMatchDisableRXEV(PINT_Type *base)
```

Disable RXEV output.

This function disables the pattern match RXEV output.

#### Parameters

- `base` – Base address of the PINT peripheral.

#### Return values

None. –

```
void PINT_EnableCallback(PINT_Type *base)
```

Enable callback.

This function enables the interrupt for the selected PINT peripheral. Although the pin(s) are monitored as soon as they are enabled, the callback function is not enabled until this function is called.

#### Parameters

- `base` – Base address of the PINT peripheral.

**Return values**

None. –

```
void PINT_DisableCallback(PINT_Type *base)
```

Disable callback.

This function disables the interrupt for the selected PINT peripheral. Although the pins are still being monitored but the callback function is not called.

**Parameters**

- base – Base address of the peripheral.

**Return values**

None. –

```
void PINT_Deinit(PINT_Type *base)
```

Deinitialize PINT peripheral.

This function disables the PINT clock.

**Parameters**

- base – Base address of the PINT peripheral.

**Return values**

None. –

```
void PINT_EnableCallbackByIndex(PINT_Type *base, pint_pin_int_t pintIdx)
```

enable callback by pin index.

This function enables callback by pin index instead of enabling all pins.

**Parameters**

- base – Base address of the peripheral.
- pintIdx – pin index.

**Return values**

None. –

```
void PINT_DisableCallbackByIndex(PINT_Type *base, pint_pin_int_t pintIdx)
```

disable callback by pin index.

This function disables callback by pin index instead of disabling all pins.

**Parameters**

- base – Base address of the peripheral.
- pintIdx – pin index.

**Return values**

None. –

PINT\_USE\_LEGACY\_CALLBACK

PININT\_BITSLICE\_SRC\_START

PININT\_BITSLICE\_SRC\_MASK

PININT\_BITSLICE\_CFG\_START

PININT\_BITSLICE\_CFG\_MASK

PININT\_BITSLICE\_ENDP\_MASK

PINT\_PIN\_INT\_LEVEL

```

PINT_PIN_INT_EDGE
PINT_PIN_INT_FALL_OR_HIGH_LEVEL
PINT_PIN_INT_RISE
PINT_PIN_RISE_EDGE
PINT_PIN_FALL_EDGE
PINT_PIN_BOTH_EDGE
PINT_PIN_LOW_LEVEL
PINT_PIN_HIGH_LEVEL

struct _pint_status
    #include <fsl_pint.h> PINT event status.

struct _pint_pmatch_cfg
    #include <fsl_pint.h>

```

## 2.20 Power Driver

```

enum pd_bits
    Values:
        enumerator kPDRUNCFG_PD_IRC_OUT
        enumerator kPDRUNCFG_PD_IRC
        enumerator kPDRUNCFG_PD_FLASH
        enumerator kPDRUNCFG_PD_BOD
        enumerator kPDRUNCFG_PD_ADC0
        enumerator kPDRUNCFG_PD_SYSOSC
        enumerator kPDRUNCFG_PD_WDT_OSC
        enumerator kPDRUNCFG_PD_SYSPLL
        enumerator kPDRUNCFG_PD_ACMP
        enumerator kPDRUNCFG_ForceUnsigned

enum _power_wakeup
    Deep sleep and power down mode wake up configurations.
    Values:
        enumerator kPDAWAKECFG_Wakeup_IRC_OUT
        enumerator kPDAWAKECFG_Wakeup_IRC
        enumerator kPDAWAKECFG_Wakeup_FLASH
        enumerator kPDAWAKECFG_Wakeup_BOD
        enumerator kPDAWAKECFG_Wakeup_ADC

```

```
enumerator kPDAWAKECFG_Wakeup_SYSOSC
enumerator kPDAWAKECFG_Wakeup_WDT_OSC
enumerator kPDAWAKECFG_Wakeup_SYSPLL
enumerator kPDAWAKECFG_Wakeup_ACMP

enum __power_deep_sleep_active
    Deep sleep/power down mode active part.

    Values:
    enumerator kPDSLEEPcfg_DeepSleepBODActive
    enumerator kPDSLEEPcfg_DeepSleepWDToscActive

enum __power_gen_reg
    pmu general purpose register index

    Values:
    enumerator kPmu_GenReg0
        general purpose register0
    enumerator kPmu_GenReg1
        general purpose register1
    enumerator kPmu_GenReg2
        general purpose register2
    enumerator kPmu_GenReg3
        general purpose register3
    enumerator kPmu_GenReg4
        DPDCTRL bit 31-4

enum __power_mode_config
    Values:
    enumerator kPmu_Sleep
    enumerator kPmu_Deep_Sleep
    enumerator kPmu_PowerDown
    enumerator kPmu_Deep_PowerDown

enum __power_bod_reset_level
    BOD reset level, if VDD below reset level value, the reset will be asserted.

    Values:
    enumerator kBod_ResetLevelReserved
        BOD Reset Level reserved.
    enumerator kBod_ResetLevel1
        BOD Reset Level1: 2.05V
    enumerator kBod_ResetLevel2
        BOD Reset Level2: 2.34V
    enumerator kBod_ResetLevel3
        BOD Reset Level3: 2.63V
```

```

enum __power_bod_interrupt_level
    BOD interrupt level, if VDD below interrupt level value, the BOD interrupt will be asserted.

Values:
enumerator kBod_InterruptLevelReserved
    BOD interrupt level reserved.

enumerator kBod_InterruptLevel1
    BOD interrupt level1: 2.25V.

enumerator kBod_InterruptLevel2
    BOD interrupt level2: 2.54V.

enumerator kBod_InterruptLevel3
    BOD interrupt level3: 2.85V.

typedef enum pd_bit_t
typedef enum __power_gen_reg power_gen_reg_t
    pmu general purpose register index

typedef enum __power_mode_config power_mode_cfg_t

typedef enum __power_bod_reset_level power_bod_reset_level_t
    BOD reset level, if VDD below reset level value, the reset will be asserted.

typedef enum __power_bod_interrupt_level power_bod_interrupt_level_t
    BOD interrupt level, if VDD below interrupt level value, the BOD interrupt will be asserted.

FSL_POWER_DRIVER_VERSION
    power driver version 2.1.0.

PMUC_PCON_RESERVED_MASK
    PMU PCON reserved mask, used to clear reserved field which should not write 1.

POWER_EnbaleLPO
POWER_EnbaleLPOInDeepPowerDownMode

static inline void POWER_EnablePD(pd_bit_t en)
    API to enable PDRUNCFG bit in the Syscon. Note that enabling the bit powers down the
    peripheral.

Parameters

- en – peripheral for which to enable the PDRUNCFG bit

Returns
    none

static inline void POWER_DisablePD(pd_bit_t en)
    API to disable PDRUNCFG bit in the Syscon. Note that disabling the bit powers up the pe-
    ripheral.

Parameters

- en – peripheral for which to disable the PDRUNCFG bit

Returns
    none

```

static inline void POWER\_WakeUpConfig(uint32\_t mask, bool powerDown)

API to config wakeup configurations for deep sleep mode and power down mode.

**Parameters**

- mask – wake up configurations for deep sleep mode and power down mode, reference `_power_wakeup`.
- powerDown – true is power down the mask part, false is powered part.

static inline void POWER\_DeepSleepConfig(uint32\_t mask, bool powerDown)

API to config active part for deep sleep mode and power down mode.

**Parameters**

- mask – active part configurations for deep sleep mode and power down mode, reference `_power_deep_sleep_active`.
- powerDown – true is power down the mask part, false is powered part.

static inline void POWER\_EnableDeepSleep(void)

API to enable deep sleep bit in the ARM Core.

**Returns**

none

static inline void POWER\_DisableDeepSleep(void)

API to disable deep sleep bit in the ARM Core.

**Returns**

none

void POWER\_EnterSleep(void)

API to enter sleep power mode.

**Returns**

none

void POWER\_EnterDeepSleep(uint32\_t activePart)

API to enter deep sleep power mode.

**Parameters**

- activePart – should be a single or combine value of `_power_deep_sleep_active`.

**Returns**

none

void POWER\_EnterPowerDown(uint32\_t activePart)

API to enter power down mode.

**Parameters**

- activePart – should be a single or combine value of `_power_deep_sleep_active`.

**Returns**

none

void POWER\_EnterDeepPowerDownMode(void)

API to enter deep power down mode.

**Returns**

none

static inline uint32\_t POWER\_GetSleepModeFlag(void)

API to get sleep mode flag.

**Returns**

sleep mode flag: 0 is active mode, 1 is sleep mode entered.

static inline void POWER\_ClrSleepModeFlag(void)

API to clear sleep mode flag.

static inline uint32\_t POWER\_GetDeepPowerDownModeFlag(void)

API to get deep power down mode flag.

**Returns**

sleep mode flag: 0 not deep power down, 1 is deep power down mode entered.

static inline void POWER\_ClrDeepPowerDownModeFlag(void)

API to clear deep power down mode flag.

static inline void POWER\_EnableNonDpd(bool enable)

API to enable non deep power down mode.

**Parameters**

- enable – true is enable non deep power down, otherwise disable.

static inline void POWER\_EnableLPO(bool enable)

API to enable LPO.

**Parameters**

- enable – true to enable LPO, false to disable LPO.

static inline void POWER\_EnableLPOInDeepPowerDownMode(bool enable)

API to enable LPO in deep power down mode.

**Parameters**

- enable – true to enable LPO, false to disable LPO.

static inline void POWER\_SetRetainData(*power\_gen\_reg\_t* index, uint32\_t data)

API to retore data to general purpose register which can be retain during deep power down mode. Note the kPMU\_GenReg4 can retore 3 byte data only, so the general purpose register can store 19bytes data.

**Parameters**

- index – general purpose data register index.
- data – data to restore.

static inline uint32\_t POWER\_GetRetainData(*power\_gen\_reg\_t* index)

API to get data from general purpose register which retain during deep power down mode. Note the kPMU\_GenReg4 can retore 3 byte data only, so the general purpose register can store 19bytes data.

**Parameters**

- index – general purpose data register index.

**Returns**

data stored in the general purpose register.

static inline void POWER\_EnableWktClkIn(bool enable, bool enHysteresis)

API to enable external clock input for self wake up timer.

**Parameters**

- enable – true is enable external clock input for self-wake-up timer, otherwise disable.
- enHysteresis – true is enable Hysteresis for the pin, otherwise disable.

static inline void POWER\_EnableWakeupPinForDeepPowerDown(bool enable, bool enHysteresis)  
API to enable wake up pin for deep power down mode.

#### Parameters

- enable – true is enable, otherwise disable.
- enHysteresis – true is enable Hysteresis for the pin, otherwise disable.

static inline void POWER\_SetBodLevel(*power\_bod\_reset\_level\_t* resetLevel,  
*power\_bod\_interrupt\_level\_t* interruptLevel, bool enable)

Set Bod interrupt level and reset level.

#### Parameters

- resetLevel – BOD reset threshold level, please refer to *power\_bod\_reset\_level\_t*.
- interruptLevel – BOD interrupt threshold level, please refer to *power\_bod\_interrupt\_level\_t*.
- enable – Used to enable/disable the BOD interrupt and BOD reset.

## 2.21 Reset Driver

enum \_SYSCON\_RSTn

Enumeration for peripheral reset control bits.

Defines the enumeration for peripheral reset control bits in PRESETCTRL/ASYNCPRESETCTRL registers

Values:

enumerator kSPI0\_RST\_N\_SHIFT\_RSTn  
SPI0 reset control.

enumerator kSPI1\_RST\_N\_SHIFT\_RSTn  
SPI1 reset control

enumerator kUARTFRG\_RST\_N\_SHIFT\_RSTn  
UARTFRG reset control

enumerator kUART0\_RST\_N\_SHIFT\_RSTn  
UART0 reset control

enumerator kUART1\_RST\_N\_SHIFT\_RSTn  
UART1 reset control

enumerator kUART2\_RST\_N\_SHIFT\_RSTn  
UART2 reset control

enumerator kI2C0\_RST\_N\_SHIFT\_RSTn  
I2C0 reset control

enumerator kMRT\_RST\_N\_SHIFT\_RSTn  
Multi-rate timer(MRT) reset control

```

enumerator kSCT_RST_N_SHIFT_RSTn
    SCT reset control

enumerator kWKT_RST_N_SHIFT_RSTn
    Self-wake-up timer(WKT) reset control

enumerator kGPIO0_RST_N_SHIFT_RSTn
    GPIO0 reset control

enumerator kFLASH_RST_N_SHIFT_RSTn
    Flash controller reset control

enumerator kACMP_RST_N_SHIFT_RSTn
    Analog comparator reset control

enumerator kCRC_RST_SHIFT_RSTn
    CRC reset control

enumerator kI2C1_RST_N_SHIFT_RSTn
    I2C1 reset control

enumerator kI2C2_RST_N_SHIFT_RSTn
    I2C2 reset control

enumerator kI2C3_RST_N_SHIFT_RSTn
    I2C3 reset control

enumerator kADC_RST_N_SHIFT_RSTn
    ADC reset control

enumerator kDMA_RST_N_SHIFT_RSTn
    DMA reset control

typedef enum _SYSCON_RSTn SYSCON_RSTn_t
    Enumeration for peripheral reset control bits.

    Defines the enumeration for peripheral reset control bits in PRESETCTRL/ASYNCPRESETCTRL registers

typedef SYSCON_RSTn_t reset_ip_name_t

void RESET_SetPeripheralReset(reset_ip_name_t peripheral)
    Assert reset to peripheral.

    Asserts reset signal to specified peripheral module.

Parameters
    • peripheral – Assert reset to this peripheral. The enum argument contains encoding of reset register and reset bit position in the reset register.

void RESET_ClearPeripheralReset(reset_ip_name_t peripheral)
    Clear reset to peripheral.

    Clears reset signal to specified peripheral module, allows it to operate.

Parameters
    • peripheral – Clear reset to this peripheral. The enum argument contains encoding of reset register and reset bit position in the reset register.

void RESET_PeripheralReset(reset_ip_name_t peripheral)
    Reset peripheral module.

    Reset peripheral module.

```

**Parameters**

- peripheral – Peripheral to reset. The enum argument contains encoding of reset register and reset bit position in the reset register.

```
static inline void RESET_ReleasePeripheralReset(reset_ip_name_t peripheral)
```

Release peripheral module.

Release peripheral module.

**Parameters**

- peripheral – Peripheral to release. The enum argument contains encoding of reset register and reset bit position in the reset register.

```
FSL_RESET_DRIVER_VERSION
```

reset driver version 2.4.0

```
FLASH_RSTS_N
```

Array initializers with peripheral reset bits

```
I2C_RSTS_N
```

```
GPIO_RSTS_N
```

```
SWM_RSTS_N
```

```
SCT_RSTS_N
```

```
WKT_RSTS_N
```

```
MRT_RSTS_N
```

```
SPI_RSTS_N
```

```
UART_RSTS_N
```

```
ACMP_RSTS_N
```

```
ADC_RSTS_N
```

```
DAC_RSTS_N
```

```
DMA_RSTS_N
```

## 2.22 SCTimer: SCTimer/PWM (SCT)

```
status_t SCTIMER_Init(SCT_Type *base, const sctimer_config_t *config)
```

Ungates the SCTimer clock and configures the peripheral for basic operation.

---

**Note:** This API should be called at the beginning of the application using the SCTimer driver.

---

**Parameters**

- base – SCTimer peripheral base address
- config – Pointer to the user configuration structure.

**Returns**

kStatus\_Success indicates success; Else indicates failure.

```
void SCTIMER_Deinit(SCT_Type *base)
```

Gates the SCTimer clock.

#### Parameters

- base – SCTimer peripheral base address

```
void SCTIMER_GetDefaultConfig(sctimer_config_t *config)
```

Fills in the SCTimer configuration structure with the default settings.

The default values are:

```
config->enableCounterUnify = true;
config->clockMode = kSCTIMER_System_ClockMode;
config->clockSelect = kSCTIMER_Clock_On_Rise_Input_0;
config->enableBidirection_l = false;
config->enableBidirection_h = false;
config->prescale_l = 0U;
config->prescale_h = 0U;
config->outInitState = 0U;
config->inputsync = 0xFU;
```

#### Parameters

- config – Pointer to the user configuration structure.

```
status_t SCTIMER_SetupPwm(SCT_Type *base, const sctimer_pwm_signal_param_t
                           *pwmParams, sctimer_pwm_mode_t mode, uint32_t
                           pwmFreq_Hz, uint32_t srcClock_Hz, uint32_t *event)
```

Configures the PWM signal parameters.

Call this function to configure the PWM signal period, mode, duty cycle, and edge. This function will create 2 events; one of the events will trigger on match with the pulse value and the other will trigger when the counter matches the PWM period. The PWM period event is also used as a limit event to reset the counter or change direction. Both events are enabled for the same state. The state number can be retrieved by calling the function `SCTIMER_GetCurrentStateNumber()`. The counter is set to operate as one 32-bit counter (unify bit is set to 1). The counter operates in bi-directional mode when generating a center-aligned PWM.

---

**Note:** When setting PWM output from multiple output pins, they all should use the same PWM mode i.e all PWM's should be either edge-aligned or center-aligned. When using this API, the PWM signal frequency of all the initialized channels must be the same. Otherwise all the initialized channels' PWM signal frequency is equal to the last call to the API's `pwmFreq_Hz`.

---

#### Parameters

- base – SCTimer peripheral base address
- pwmParams – PWM parameters to configure the output
- mode – PWM operation mode, options available in enumeration `sctimer_pwm_mode_t`
- pwmFreq\_Hz – PWM signal frequency in Hz
- srcClock\_Hz – SCTimer counter clock in Hz
- event – Pointer to a variable where the PWM period event number is stored

#### Returns

`kStatus_Success` on success `kStatus_Fail` If we have hit the limit in terms of number of events created or if an incorrect PWM dutycycle is passed in.

```
void SCTIMER_UpdatePwmDutycycle(SCT_Type *base, sctimer_out_t output, uint8_t
                                  dutyCyclePercent, uint32_t event)
```

Updates the duty cycle of an active PWM signal.

Before calling this function, the counter is set to operate as one 32-bit counter (unify bit is set to 1).

#### Parameters

- base – SCTimer peripheral base address
- output – The output to configure
- dutyCyclePercent – New PWM pulse width; the value should be between 1 to 100
- event – Event number associated with this PWM signal. This was returned to the user by the function SCTIMER\_SetupPwm().

```
static inline void SCTIMER_EnableInterrupts(SCT_Type *base, uint32_t mask)
```

Enables the selected SCTimer interrupts.

#### Parameters

- base – SCTimer peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration sctimer\_interrupt\_enable\_t

```
static inline void SCTIMER_DisableInterrupts(SCT_Type *base, uint32_t mask)
```

Disables the selected SCTimer interrupts.

#### Parameters

- base – SCTimer peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration sctimer\_interrupt\_enable\_t

```
static inline uint32_t SCTIMER_GetEnabledInterrupts(SCT_Type *base)
```

Gets the enabled SCTimer interrupts.

#### Parameters

- base – SCTimer peripheral base address

#### Returns

The enabled interrupts. This is the logical OR of members of the enumeration sctimer\_interrupt\_enable\_t

```
static inline uint32_t SCTIMER_GetStatusFlags(SCT_Type *base)
```

Gets the SCTimer status flags.

#### Parameters

- base – SCTimer peripheral base address

#### Returns

The status flags. This is the logical OR of members of the enumeration sctimer\_status\_flags\_t

```
static inline void SCTIMER_ClearStatusFlags(SCT_Type *base, uint32_t mask)
```

Clears the SCTimer status flags.

#### Parameters

- base – SCTimer peripheral base address
- mask – The status flags to clear. This is a logical OR of members of the enumeration sctimer\_status\_flags\_t

---

```
static inline void SCTIMER_StartTimer(SCT_Type *base, uint32_t countertoStart)
```

Starts the SCTimer counter.

---

**Note:** In 16-bit mode, we can enable both Counter\_L and Counter\_H, In 32-bit mode, we only can select Counter\_U.

---

### Parameters

- base – SCTimer peripheral base address
- countertoStart – The SCTimer counters to enable. This is a logical OR of members of the enumeration `sctimer_counter_t`.

```
static inline void SCTIMER_StopTimer(SCT_Type *base, uint32_t countertoStop)
```

Halts the SCTimer counter.

### Parameters

- base – SCTimer peripheral base address
- countertoStop – The SCTimer counters to stop. This is a logical OR of members of the enumeration `sctimer_counter_t`.

```
status_t SCTIMER_CreateAndScheduleEvent(SCT_Type *base, sctimer_event_t howToMonitor,
                                         uint32_t matchValue, uint32_t whichIO,
                                         sctimer_counter_t whichCounter, uint32_t *event)
```

Create an event that is triggered on a match or IO and schedule in current state.

This function will configure an event using the options provided by the user. If the event type uses the counter match, then the function will set the user provided match value into a match register and put this match register number into the event control register. The event is enabled for the current state and the event number is increased by one at the end. The function returns the event number; this event number can be used to configure actions to be done when this event is triggered.

### Parameters

- base – SCTimer peripheral base address
- howToMonitor – Event type; options are available in the enumeration `sctimer_interrupt_enable_t`
- matchValue – The match value that will be programmed to a match register
- whichIO – The input or output that will be involved in event triggering. This field is ignored if the event type is “match only”
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- event – Pointer to a variable where the new event number is stored

### Returns

`kStatus_Success` on success `kStatus_Error` if we have hit the limit in terms of number of events created or if we have reached the limit in terms of number of match registers

```
void SCTIMER_ScheduleEvent(SCT_Type *base, uint32_t event)
```

Enable an event in the current state.

This function will allow the event passed in to trigger in the current state. The event must be created earlier by either calling the function `SCTIMER_SetupPwm()` or function `SCTIMER_CreateAndScheduleEvent()`.

### Parameters

- base – SCTimer peripheral base address
- event – Event number to enable in the current state

`status_t SCTIMER_IncreaseState(SCT_Type *base)`

Increase the state by 1.

All future events created by calling the function `SCTIMER_ScheduleEvent()` will be enabled in this new state.

#### Parameters

- base – SCTimer peripheral base address

#### Returns

`kStatus_Success` on success `kStatus_Error` if we have hit the limit in terms of states used

`uint32_t SCTIMER_GetCurrentState(SCT_Type *base)`

Provides the current state.

User can use this to set the next state by calling the function `SCTIMER_SetupNextStateAction()`.

#### Parameters

- base – SCTimer peripheral base address

#### Returns

The current state

`static inline void SCTIMER_SetCounterState(SCT_Type *base, sctimer_counter_t whichCounter, uint32_t state)`

Set the counter current state.

The function is to set the state variable bit field of STATE register. Writing to the STATE\_L, STATE\_H, or unified register is only allowed when the corresponding counter is halted (HALT bits are set to 1 in the CTRL register).

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- state – The counter current state number (only support range from 0~31).

`static inline uint16_t SCTIMER_GetCounterState(SCT_Type *base, sctimer_counter_t whichCounter)`

Get the counter current state value.

The function is to get the state variable bit field of STATE register.

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.

#### Returns

The the counter current state value.

`status_t SCTIMER_SetupCaptureAction(SCT_Type *base, sctimer_counter_t whichCounter, uint32_t *captureRegister, uint32_t event)`

Setup capture of the counter value on trigger of a selected event.

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- captureRegister – Pointer to a variable where the capture register number will be returned. User can read the captured value from this register when the specified event is triggered.
- event – Event number that will trigger the capture

#### Returns

kStatus\_Success on success kStatus\_Error if we have hit the limit in terms of number of match/capture registers available

`void SCTIMER_SetCallback(SCT_Type *base, sctimer_event_callback_t callback, uint32_t event)`

Receive notification when the event trigger an interrupt.

If the interrupt for the event is enabled by the user, then a callback can be registered which will be invoked when the event is triggered

#### Parameters

- base – SCTimer peripheral base address
- event – Event number that will trigger the interrupt
- callback – Function to invoke when the event is triggered

`static inline void SCTIMER_SetupStateLdMethodAction(SCT_Type *base, uint32_t event, bool fgLoad)`

Change the load method of transition to the specified state.

Change the load method of transition, it will be triggered by the event number that is passed in by the user.

#### Parameters

- base – SCTimer peripheral base address
- event – Event number that will change the method to trigger the state transition
- fgLoad – The method to load highest-numbered event occurring for that state to the STATE register.
  - true: Load the STATEV value to STATE when the event occurs to be the next state.
  - false: Add the STATEV value to STATE when the event occurs to be the next state.

`static inline void SCTIMER_SetupNextStateActionwithLdMethod(SCT_Type *base, uint32_t nextState, uint32_t event, bool fgLoad)`

Transition to the specified state with Load method.

This transition will be triggered by the event number that is passed in by the user, the method decide how to load the highest-numbered event occurring for that state to the STATE register.

#### Parameters

- base – SCTimer peripheral base address
- nextState – The next state SCTimer will transition to
- event – Event number that will trigger the state transition

- `fgLoad` – The method to load the highest-numbered event occurring for that state to the `STATE` register.
  - `true`: Load the `STATEV` value to `STATE` when the event occurs to be the next state.
  - `false`: Add the `STATEV` value to `STATE` when the event occurs to be the next state.

```
static inline void SCTIMER_SetupNextStateAction(SCT_Type *base, uint32_t nextState, uint32_t event)
```

Transition to the specified state.

*Deprecated:*

Do not use this function. It has been superceded by `SCTIMER_SetupNextStateActionwithLdMethod`

This transition will be triggered by the event number that is passed in by the user.

**Parameters**

- `base` – SCTimer peripheral base address
- `nextState` – The next state SCTimer will transition to
- `event` – Event number that will trigger the state transition

```
static inline void SCTIMER_SetupEventActiveDirection(SCT_Type *base,  
                                                 sctimer_event_active_direction_t  
                                                 activeDirection, uint32_t event)
```

Setup event active direction when the counters are operating in BIDIR mode.

**Parameters**

- `base` – SCTimer peripheral base address
- `activeDirection` – Event generation active direction, see `sctimer_event_active_direction_t`.
- `event` – Event number that need setup the active direction.

```
static inline void SCTIMER_SetupOutputSetAction(SCT_Type *base, uint32_t whichIO, uint32_t event)
```

Set the Output.

This output will be set when the event number that is passed in by the user is triggered.

**Parameters**

- `base` – SCTimer peripheral base address
- `whichIO` – The output to set
- `event` – Event number that will trigger the output change

```
static inline void SCTIMER_SetupOutputClearAction(SCT_Type *base, uint32_t whichIO,  
                                                uint32_t event)
```

Clear the Output.

This output will be cleared when the event number that is passed in by the user is triggered.

**Parameters**

- `base` – SCTimer peripheral base address
- `whichIO` – The output to clear
- `event` – Event number that will trigger the output change

```
void SCTIMER_SetupOutputToggleAction(SCT_Type *base, uint32_t whichIO, uint32_t event)
```

Toggle the output level.

This change in the output level is triggered by the event number that is passed in by the user.

#### Parameters

- base – SCTimer peripheral base address
- whichIO – The output to toggle
- event – Event number that will trigger the output change

```
static inline void SCTIMER_SetupCounterLimitAction(SCT_Type *base, sctimer_counter_t  
whichCounter, uint32_t event)
```

Limit the running counter.

The counter is limited when the event number that is passed in by the user is triggered.

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- event – Event number that will trigger the counter to be limited

```
static inline void SCTIMER_SetupCounterStopAction(SCT_Type *base, sctimer_counter_t  
whichCounter, uint32_t event)
```

Stop the running counter.

The counter is stopped when the event number that is passed in by the user is triggered.

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- event – Event number that will trigger the counter to be stopped

```
static inline void SCTIMER_SetupCounterStartAction(SCT_Type *base, sctimer_counter_t  
whichCounter, uint32_t event)
```

Re-start the stopped counter.

The counter will re-start when the event number that is passed in by the user is triggered.

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- event – Event number that will trigger the counter to re-start

```
static inline void SCTIMER_SetupCounterHaltAction(SCT_Type *base, sctimer_counter_t  
whichCounter, uint32_t event)
```

Halt the running counter.

The counter is disabled (halted) when the event number that is passed in by the user is triggered. When the counter is halted, all further events are disabled. The HALT condition can only be removed by calling the SCTIMER\_StartTimer() function.

#### Parameters

- base – SCTimer peripheral base address

- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- event – Event number that will trigger the counter to be halted

```
static inline void SCTIMER_SetupDMATriggerAction(SCT_Type *base, uint32_t dmaNumber,  
                                              uint32_t event)
```

Generate a DMA request.

DMA request will be triggered by the event number that is passed in by the user.

#### Parameters

- base – SCTimer peripheral base address
- dmaNumber – The DMA request to generate
- event – Event number that will trigger the DMA request

```
static inline void SCTIMER_SetCOUNTValue(SCT_Type *base, sctimer_counter_t whichCounter,  
                                         uint32_t value)
```

Set the value of counter.

The function is to set the value of Count register, Writing to the COUNT\_L, COUNT\_H, or unified register is only allowed when the corresponding counter is halted (HALT bits are set to 1 in the CTRL register).

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- value – the counter value update to the COUNT register.

```
static inline uint32_t SCTIMER_GetCOUNTValue(SCT_Type *base, sctimer_counter_t  
                                             whichCounter)
```

Get the value of counter.

The function is to read the value of Count register, software can read the counter registers at any time..

#### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.

#### Returns

The value of counter selected.

```
static inline void SCTIMER_SetEventInState(SCT_Type *base, uint32_t event, uint32_t state)
```

Set the state mask bit field of EV\_STATE register.

#### Parameters

- base – SCTimer peripheral base address
- event – The EV\_STATE register be set.
- state – The state value in which the event is enabled to occur.

```
static inline void SCTIMER_ClearEventInState(SCT_Type *base, uint32_t event, uint32_t state)
```

Clear the state mask bit field of EV\_STATE register.

#### Parameters

- base – SCTimer peripheral base address

- event – The EV\_STATE register be clear.
- state – The state value in which the event is disabled to occur.

static inline bool SCTIMER\_\_GetEventInState(SCT\_Type \*base, uint32\_t event, uint32\_t state)  
Get the state mask bit field of EV\_STATE register.

---

**Note:** This function is to check whether the event is enabled in a specific state.

---

### Parameters

- base – SCTimer peripheral base address
- event – The EV\_STATE register be read.
- state – The state value.

### Returns

The the state mask bit field of EV\_STATE register.

- true: The event is enable in state.
- false: The event is disable in state.

static inline uint32\_t SCTIMER\_\_GetCaptureValue(SCT\_Type \*base, *sctimer\_counter\_t*  
whichCounter, uint8\_t capChannel)

Get the value of capture register.

This function returns the captured value upon occurrence of the events selected by the corresponding Capture Control registers occurred.

### Parameters

- base – SCTimer peripheral base address
- whichCounter – SCTimer counter to use. In 16-bit mode, we can select Counter\_L and Counter\_H, In 32-bit mode, we can select Counter\_U.
- capChannel – SCTimer capture register of capture channel.

### Returns

The SCTimer counter value at which this register was last captured.

void SCTIMER\_\_EventHandleIRQ(SCT\_Type \*base)  
SCTimer interrupt handler.

### Parameters

- base – SCTimer peripheral base address.

FSL\_SCTIMER\_DRIVER\_VERSION

Version

enum \_sctimer\_pwm\_mode

SCTimer PWM operation modes.

Values:

enumerator kSCTIMER\_\_EdgeAlignedPwm  
Edge-aligned PWM

enumerator kSCTIMER\_\_CenterAlignedPwm  
Center-aligned PWM

`enum _sctimer_counter`

SCTimer counters type.

*Values:*

`enumerator kSCTIMER_Counter_L`  
16-bit Low counter.

`enumerator kSCTIMER_Counter_H`  
16-bit High counter.

`enumerator kSCTIMER_Counter_U`  
32-bit Unified counter.

`enum _sctimer_input`

List of SCTimer input pins.

*Values:*

`enumerator kSCTIMER_Input_0`  
SCTIMER input 0

`enumerator kSCTIMER_Input_1`  
SCTIMER input 1

`enumerator kSCTIMER_Input_2`  
SCTIMER input 2

`enumerator kSCTIMER_Input_3`  
SCTIMER input 3

`enumerator kSCTIMER_Input_4`  
SCTIMER input 4

`enumerator kSCTIMER_Input_5`  
SCTIMER input 5

`enumerator kSCTIMER_Input_6`  
SCTIMER input 6

`enumerator kSCTIMER_Input_7`  
SCTIMER input 7

`enum _sctimer_out`

List of SCTimer output pins.

*Values:*

`enumerator kSCTIMER_Out_0`  
SCTIMER output 0

`enumerator kSCTIMER_Out_1`  
SCTIMER output 1

`enumerator kSCTIMER_Out_2`  
SCTIMER output 2

`enumerator kSCTIMER_Out_3`  
SCTIMER output 3

`enumerator kSCTIMER_Out_4`  
SCTIMER output 4

```

enumerator kSCTIMER_Out_5
    SCTIMER output 5
enumerator kSCTIMER_Out_6
    SCTIMER output 6
enumerator kSCTIMER_Out_7
    SCTIMER output 7
enumerator kSCTIMER_Out_8
    SCTIMER output 8
enumerator kSCTIMER_Out_9
    SCTIMER output 9

enum _sctimer_pwm_level_select
    SCTimer PWM output pulse mode: high-true, low-true or no output.

    Values:
    enumerator kSCTIMER_LowTrue
        Low true pulses
    enumerator kSCTIMER_HighTrue
        High true pulses

enum _sctimer_clock_mode
    SCTimer clock mode options.

    Values:
    enumerator kSCTIMER_System_ClockMode
        System Clock Mode
    enumerator kSCTIMER_Sampled_ClockMode
        Sampled System Clock Mode
    enumerator kSCTIMER_Input_ClockMode
        SCT Input Clock Mode
    enumerator kSCTIMER_Asynchronous_ClockMode
        Asynchronous Mode

enum _sctimer_clock_select
    SCTimer clock select options.

    Values:
    enumerator kSCTIMER_Clock_On_Rise_Input_0
        Rising edges on input 0
    enumerator kSCTIMER_Clock_On_Fall_Input_0
        Falling edges on input 0
    enumerator kSCTIMER_Clock_On_Rise_Input_1
        Rising edges on input 1
    enumerator kSCTIMER_Clock_On_Fall_Input_1
        Falling edges on input 1
    enumerator kSCTIMER_Clock_On_Rise_Input_2
        Rising edges on input 2

```

```
enumerator kSCTIMER_Clock_On_Fall_Input_2
    Falling edges on input 2
enumerator kSCTIMER_Clock_On_Rise_Input_3
    Rising edges on input 3
enumerator kSCTIMER_Clock_On_Fall_Input_3
    Falling edges on input 3
enumerator kSCTIMER_Clock_On_Rise_Input_4
    Rising edges on input 4
enumerator kSCTIMER_Clock_On_Fall_Input_4
    Falling edges on input 4
enumerator kSCTIMER_Clock_On_Rise_Input_5
    Rising edges on input 5
enumerator kSCTIMER_Clock_On_Fall_Input_5
    Falling edges on input 5
enumerator kSCTIMER_Clock_On_Rise_Input_6
    Rising edges on input 6
enumerator kSCTIMER_Clock_On_Fall_Input_6
    Falling edges on input 6
enumerator kSCTIMER_Clock_On_Rise_Input_7
    Rising edges on input 7
enumerator kSCTIMER_Clock_On_Fall_Input_7
    Falling edges on input 7

enum __sctimer_conflict_resolution
    SCTimer output conflict resolution options.
    Specifies what action should be taken if multiple events dictate that a given output should
    be both set and cleared at the same time

    Values:
    enumerator kSCTIMER_ResolveNone
        No change
    enumerator kSCTIMER_ResolveSet
        Set output
    enumerator kSCTIMER_ResolveClear
        Clear output
    enumerator kSCTIMER_ResolveToggle
        Toggle output

enum __sctimer_event_active_direction
    List of SCTimer event generation active direction when the counters are operating in BIDIR
    mode.

    Values:
    enumerator kSCTIMER_ActiveIndependent
        This event is triggered regardless of the count direction.
    enumerator kSCTIMER_ActiveInCountUp
        This event is triggered only during up-counting when BIDIR = 1.
```

```
enumerator kSCTIMER_ActiveInCountDown
    This event is triggered only during down-counting when BIDIR = 1.

enum __sctimer_event
    List of SCTimer event types.

    Values:
    enumerator kSCTIMER_InputLowOrMatchEvent
    enumerator kSCTIMER_InputRiseOrMatchEvent
    enumerator kSCTIMER_InputFallOrMatchEvent
    enumerator kSCTIMER_InputHighOrMatchEvent
    enumerator kSCTIMER_MatchEventOnly
    enumerator kSCTIMER_InputLowEvent
    enumerator kSCTIMER_InputRiseEvent
    enumerator kSCTIMER_InputFallEvent
    enumerator kSCTIMER_InputHighEvent
    enumerator kSCTIMER_InputLowAndMatchEvent
    enumerator kSCTIMER_InputRiseAndMatchEvent
    enumerator kSCTIMER_InputFallAndMatchEvent
    enumerator kSCTIMER_InputHighAndMatchEvent
    enumerator kSCTIMER_OutputLowOrMatchEvent
    enumerator kSCTIMER_OutputRiseOrMatchEvent
    enumerator kSCTIMER_OutputFallOrMatchEvent
    enumerator kSCTIMER_OutputHighOrMatchEvent
    enumerator kSCTIMER_OutputLowEvent
    enumerator kSCTIMER_OutputRiseEvent
    enumerator kSCTIMER_OutputFallEvent
    enumerator kSCTIMER_OutputHighEvent
    enumerator kSCTIMER_OutputLowAndMatchEvent
    enumerator kSCTIMER_OutputRiseAndMatchEvent
    enumerator kSCTIMER_OutputFallAndMatchEvent
    enumerator kSCTIMER_OutputHighAndMatchEvent

enum __sctimer_interrupt_enable
    List of SCTimer interrupts.

    Values:
    enumerator kSCTIMER_Event0InterruptEnable
        Event 0 interrupt
```

```
enumerator kSCTIMER_Event1InterruptEnable
    Event 1 interrupt
enumerator kSCTIMER_Event2InterruptEnable
    Event 2 interrupt
enumerator kSCTIMER_Event3InterruptEnable
    Event 3 interrupt
enumerator kSCTIMER_Event4InterruptEnable
    Event 4 interrupt
enumerator kSCTIMER_Event5InterruptEnable
    Event 5 interrupt
enumerator kSCTIMER_Event6InterruptEnable
    Event 6 interrupt
enumerator kSCTIMER_Event7InterruptEnable
    Event 7 interrupt
enumerator kSCTIMER_Event8InterruptEnable
    Event 8 interrupt
enumerator kSCTIMER_Event9InterruptEnable
    Event 9 interrupt
enumerator kSCTIMER_Event10InterruptEnable
    Event 10 interrupt
enumerator kSCTIMER_Event11InterruptEnable
    Event 11 interrupt
enumerator kSCTIMER_Event12InterruptEnable
    Event 12 interrupt

enum __sctimer_status_flags
    List of SCTimer flags.

    Values:
enumerator kSCTIMER_Event0Flag
    Event 0 Flag
enumerator kSCTIMER_Event1Flag
    Event 1 Flag
enumerator kSCTIMER_Event2Flag
    Event 2 Flag
enumerator kSCTIMER_Event3Flag
    Event 3 Flag
enumerator kSCTIMER_Event4Flag
    Event 4 Flag
enumerator kSCTIMER_Event5Flag
    Event 5 Flag
enumerator kSCTIMER_Event6Flag
    Event 6 Flag
```

```

enumerator kSCTIMER_Event7Flag
    Event 7 Flag
enumerator kSCTIMER_Event8Flag
    Event 8 Flag
enumerator kSCTIMER_Event9Flag
    Event 9 Flag
enumerator kSCTIMER_Event10Flag
    Event 10 Flag
enumerator kSCTIMER_Event11Flag
    Event 11 Flag
enumerator kSCTIMER_Event12Flag
    Event 12 Flag
enumerator kSCTIMER_BusErrorLFlag
    Bus error due to write when L counter was not halted
enumerator kSCTIMER_BusErrorHFlag
    Bus error due to write when H counter was not halted

typedef enum _sctimer_pwm_mode sctimer_pwm_mode_t
    SCTimer PWM operation modes.

typedef enum _sctimer_counter sctimer_counter_t
    SCTimer counters type.

typedef enum _sctimer_input sctimer_input_t
    List of SCTimer input pins.

typedef enum _sctimer_out sctimer_out_t
    List of SCTimer output pins.

typedef enum _sctimer_pwm_level_select sctimer_pwm_level_select_t
    SCTimer PWM output pulse mode: high-true, low-true or no output.

typedef struct _sctimer_pwm_signal_param sctimer_pwm_signal_param_t
    Options to configure a SCTimer PWM signal.

typedef enum _sctimer_clock_mode sctimer_clock_mode_t
    SCTimer clock mode options.

typedef enum _sctimer_clock_select sctimer_clock_select_t
    SCTimer clock select options.

typedef enum _sctimer_conflict_resolution sctimer_conflict_resolution_t
    SCTimer output conflict resolution options.

    Specifies what action should be taken if multiple events dictate that a given output should
    be both set and cleared at the same time

typedef enum _sctimer_event_active_direction sctimer_event_active_direction_t
    List of SCTimer event generation active direction when the counters are operating in BIDIR
    mode.

typedef enum _sctimer_event sctimer_event_t
    List of SCTimer event types.

typedef void (*sctimer_event_callback_t)(void)
    SCTimer callback typedef.

```

```
typedef enum _sctimer_interrupt_enable sctimer_interrupt_enable_t
```

List of SCTimer interrupts.

```
typedef enum _sctimer_status_flags sctimer_status_flags_t
```

List of SCTimer flags.

```
typedef struct _sctimer_config sctimer_config_t
```

SCTimer configuration structure.

This structure holds the configuration settings for the SCTimer peripheral. To initialize this structure to reasonable defaults, call the `SCTMR_GetDefaultConfig()` function and pass a pointer to the configuration structure instance.

The configuration structure can be made constant so as to reside in flash.

```
SCT_EV_STATE_STATEMSKn(x)
```

```
struct _sctimer_pwm_signal_param
```

`#include <fsl_sctimer.h>` Options to configure a SCTimer PWM signal.

## Public Members

```
sctimer_out_t output
```

The output pin to use to generate the PWM signal

```
sctimer_pwm_level_select_t level
```

PWM output active level select.

```
uint8_t dutyCyclePercent
```

PWM pulse width, value should be between 0 to 100 0 = always inactive signal (0% duty cycle) 100 = always active signal (100% duty cycle).

```
struct _sctimer_config
```

`#include <fsl_sctimer.h>` SCTimer configuration structure.

This structure holds the configuration settings for the SCTimer peripheral. To initialize this structure to reasonable defaults, call the `SCTMR_GetDefaultConfig()` function and pass a pointer to the configuration structure instance.

The configuration structure can be made constant so as to reside in flash.

## Public Members

```
bool enableCounterUnify
```

true: SCT operates as a unified 32-bit counter; false: SCT operates as two 16-bit counters. User can use the 16-bit low counter and the 16-bit high counters at the same time; for Hardware limit, user can not use unified 32-bit counter and any 16-bit low/high counter at the same time.

```
sctimer_clock_mode_t clockMode
```

SCT clock mode value

```
sctimer_clock_select_t clockSelect
```

SCT clock select value

```
bool enableBidirection_l
```

true: Up-down count mode for the L or unified counter false: Up count mode only for the L or unified counter

```

bool enableBidirection_h
    true: Up-down count mode for the H or unified counter false: Up count mode only for
    the H or unified counter. This field is used only if the enableCounterUnify is set to false

uint8_t prescale_l
    Prescale value to produce the L or unified counter clock

uint8_t prescale_h
    Prescale value to produce the H counter clock. This field is used only if the enable-
    CounterUnify is set to false

uint8_t outInitState
    Defines the initial output value

uint8_t inputsync
    SCT INSYNC value, INSYNC field in the CONFIG register; from bit9 to bit 16. it is used to
    define synchronization for input N: bit 9 = input 0 bit 10 = input 1 bit 11 = input 2 bit 12
    = input 3 All other bits are reserved (bit13 ~bit 16). How User to set the the value for the
    member inputsync. IE: delay for input0, and input 1, bypasses for input 2 and input
    3 MACRO definition in user level. #define INPUTSYNC0 (0U) #define INPUTSYNC1 (1U)
    #define INPUTSYNC2 (2U) #define INPUTSYNC3 (3U) User Code. sctimerInfo.inputsync
    = (1 « INPUTSYNC2) | (1 « INPUTSYNC3);

```

## 2.23 SPI: Serial Peripheral Interface Driver

### 2.24 SPI Driver

void SPI\_MasterGetDefaultConfig(*spi\_master\_config\_t* \*config)

Sets the SPI master configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in SPI\_MasterInit(). User may use the initialized structure unchanged in SPI\_MasterInit(), or modify some fields of the structure before calling SPI\_MasterInit(). After calling this API, the master is ready to transfer. Example:

```

spi_master_config_t config;
SPI_MasterGetDefaultConfig(&config);

```

#### Parameters

- config – pointer to master config structure

*status\_t* SPI\_MasterInit(*SPI\_Type* \*base, const *spi\_master\_config\_t* \*config, *uint32\_t* srcClock\_Hz)

Initializes the SPI with master configuration.

The configuration structure can be filled by user from scratch, or be set with default values by SPI\_MasterGetDefaultConfig(). After calling this API, the slave is ready to transfer. Example

```

spi_master_config_t config = {
    .baudRate_Bps = 500000,
    ...
};
SPI_MasterInit(SPI0, &config);

```

#### Parameters

- base – SPI base pointer

- config – pointer to master configuration structure
- srcClock\_Hz – Source clock frequency.

`void SPI_SlaveGetDefaultConfig(spi_slave_config_t *config)`

Sets the SPI slave configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in `SPI_SlaveInit()`. Modify some fields of the structure before calling `SPI_SlaveInit()`. Example:

```
spi_slave_config_t config;
SPI_SlaveGetDefaultConfig(&config);
```

### Parameters

- config – pointer to slave configuration structure

`status_t SPI_SlaveInit(SPI_Type *base, const spi_slave_config_t *config)`

Initializes the SPI with slave configuration.

The configuration structure can be filled by user from scratch or be set with default values by `SPI_SlaveGetDefaultConfig()`. After calling this API, the slave is ready to transfer. Example

```
spi_slave_config_t config = {
    .polarity = kSPI_ClockPolarityActiveHigh;
    .phase = kSPI_ClockPhaseFirstEdge;
    .direction = kSPI_MsbFirst;
    ...
};
SPI_SlaveInit(SPI0, &config);
```

### Parameters

- base – SPI base pointer
- config – pointer to slave configuration structure

`void SPI_Deinit(SPI_Type *base)`

De-initializes the SPI.

Calling this API resets the SPI module, gates the SPI clock. Disable the fifo if enabled. The SPI module can't work unless calling the `SPI_MasterInit/SPI_SlaveInit` to initialize module.

### Parameters

- base – SPI base pointer

`static inline void SPI_Enable(SPI_Type *base, bool enable)`

Enable or disable the SPI Master or Slave.

### Parameters

- base – SPI base pointer
- enable – or disable ( true = enable, false = disable)

`static inline uint32_t SPI_GetStatusFlags(SPI_Type *base)`

Gets the status flag.

### Parameters

- base – SPI base pointer

### Returns

SPI Status, use status flag to AND \_spi\_status\_flags could get the related status.

---

static inline void SPI\_ClearStatusFlags(SPI\_Type \*base, uint32\_t mask)

Clear the status flag.

**Parameters**

- base – SPI base pointer
- mask – SPI Status, use status flag to AND \_spi\_status\_flags could get the related status.

static inline void SPI\_EnableInterrupts(SPI\_Type \*base, uint32\_t irqs)

Enables the interrupt for the SPI.

**Parameters**

- base – SPI base pointer
- irqs – SPI interrupt source. The parameter can be any combination of the following values:
  - kSPI\_RxReadyInterruptEnable
  - kSPI\_TxReadyInterruptEnable

static inline void SPI\_DisableInterrupts(SPI\_Type \*base, uint32\_t irqs)

Disables the interrupt for the SPI.

**Parameters**

- base – SPI base pointer
- irqs – SPI interrupt source. The parameter can be any combination of the following values:
  - kSPI\_RxReadyInterruptEnable
  - kSPI\_TxReadyInterruptEnable

static inline bool SPI\_IsMaster(SPI\_Type \*base)

Returns whether the SPI module is in master mode.

**Parameters**

- base – SPI peripheral address.

**Returns**

Returns true if the module is in master mode or false if the module is in slave mode.

*status\_t* SPI\_MasterSetBaudRate(SPI\_Type \*base, uint32\_t baudrate\_Bps, uint32\_t srcClock\_Hz)

Sets the baud rate for SPI transfer. This is only used in master.

**Parameters**

- base – SPI base pointer
- baudrate\_Bps – baud rate needed in Hz.
- srcClock\_Hz – SPI source clock frequency in Hz.

static inline void SPI\_WriteData(SPI\_Type \*base, uint16\_t data)

Writes a data into the SPI data register directly.

**Parameters**

- base – SPI base pointer
- data – needs to be write.

static inline void SPI\_WriteConfigFlags(SPI\_Type \*base, uint32\_t configFlags)

Writes a data into the SPI TXCTL register directly.

#### Parameters

- base – SPI base pointer
- configFlags – control command needs to be written.

void SPI\_WriteDataWithConfigFlags(SPI\_Type \*base, uint16\_t data, uint32\_t configFlags)

Writes a data control info and data into the SPI TX register directly.

#### Parameters

- base – SPI base pointer
- data – value needs to be written.
- configFlags – control command needs to be written.

static inline uint32\_t SPI\_ReadData(SPI\_Type \*base)

Gets a data from the SPI data register.

#### Parameters

- base – SPI base pointer

#### Returns

Data in the register.

void SPI\_SetTransferDelay(SPI\_Type \*base, const *spi\_delay\_config\_t* \*config)

Set delay time for transfer. the delay uint is SPI clock time, maximum value is 0xF.

#### Parameters

- base – SPI base pointer
- config – configuration for delay option *spi\_delay\_config\_t*.

void SPI\_SetDummyData(SPI\_Type \*base, uint16\_t dummyData)

Set up the dummy data. This API can change the default data to be transferred when users set the tx buffer to NULL.

#### Parameters

- base – SPI peripheral address.
- dummyData – Data to be transferred when tx buffer is NULL.

*status\_t* SPI\_MasterTransferBlocking(SPI\_Type \*base, *spi\_transfer\_t* \*xfer)

Transfers a block of data using a polling method.

#### Parameters

- base – SPI base pointer
- xfer – pointer to *spi\_xfer\_config\_t* structure

#### Return values

- kStatus\_Success – Successfully start a transfer.
- kStatus\_InvalidArgument – Input argument is invalid.
- kStatus\_SPI\_Timeout – The transfer timed out and was aborted.

*status\_t* SPI\_MasterTransferCreateHandle(SPI\_Type \*base, *spi\_master\_handle\_t* \*handle,  
*spi\_master\_callback\_t* callback, void \*userData)

Initializes the SPI master handle.

This function initializes the SPI master handle which can be used for other SPI master transactional APIs. Usually, for a specified SPI instance, call this API once to get the initialized handle.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI handle pointer.
- callback – Callback function.
- userData – User data.

`status_t SPI_MasterTransferNonBlocking(SPI_Type *base, spi_master_handle_t *handle, spi_transfer_t *xfer)`

Performs a non-blocking SPI interrupt transfer.

#### Parameters

- base – SPI peripheral base address.
- handle – pointer to `spi_master_handle_t` structure which stores the transfer state
- xfer – pointer to `spi_xfer_config_t` structure

#### Return values

- `kStatus_Success` – Successfully start a transfer.
- `kStatus_InvalidArgument` – Input argument is invalid.
- `kStatus_SPI_Busy` – SPI is not idle, is running another transfer.

`status_t SPI_MasterTransferGetCount(SPI_Type *base, spi_master_handle_t *handle, size_t *count)`

Gets the master transfer count.

This function gets the master transfer count.

#### Parameters

- base – SPI peripheral base address.
- handle – Pointer to the `spi_master_handle_t` structure which stores the transfer state.
- count – The number of bytes transferred by using the non-blocking transaction.

#### Returns

status of `status_t`.

`void SPI_MasterTransferAbort(SPI_Type *base, spi_master_handle_t *handle)`

SPI master aborts a transfer using an interrupt.

This function aborts a transfer using an interrupt.

#### Parameters

- base – SPI peripheral base address.
- handle – Pointer to the `spi_master_handle_t` structure which stores the transfer state.

```
void SPI_MasterTransferHandleIRQ(SPI_Type *base, spi_master_handle_t *handle)
```

Interrupts the handler for the SPI.

#### Parameters

- base – SPI peripheral base address.
- handle – pointer to spi\_master\_handle\_t structure which stores the transfer state.

```
status_t SPI_SlaveTransferCreateHandle(SPI_Type *base, spi_slave_handle_t *handle,  
                                      spi_slave_callback_t callback, void *userData)
```

Initializes the SPI slave handle.

This function initializes the SPI slave handle which can be used for other SPI slave transactional APIs. Usually, for a specified SPI instance, call this API once to get the initialized handle.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI handle pointer.
- callback – Callback function.
- userData – User data.

```
status_t SPI_SlaveTransferNonBlocking(SPI_Type *base, spi_slave_handle_t *handle,  
                                      spi_transfer_t *xfer)
```

Performs a non-blocking SPI slave interrupt transfer.

---

**Note:** The API returns immediately after the transfer initialization is finished.

---

#### Parameters

- base – SPI peripheral base address.
- handle – pointer to spi\_master\_handle\_t structure which stores the transfer state
- xfer – pointer to spi\_xfer\_config\_t structure

#### Return values

- kStatus\_Success – Successfully start a transfer.
- kStatus\_InvalidArgument – Input argument is invalid.
- kStatus\_SPI\_Busy – SPI is not idle, is running another transfer.

```
static inline status_t SPI_SlaveTransferGetCount(SPI_Type *base, spi_slave_handle_t *handle,  
                                              size_t *count)
```

Gets the slave transfer count.

This function gets the slave transfer count.

#### Parameters

- base – SPI peripheral base address.
- handle – Pointer to the spi\_master\_handle\_t structure which stores the transfer state.
- count – The number of bytes transferred by using the non-blocking transaction.

**Returns**

status of `status_t`.

`static inline void SPI_SlaveTransferAbort(SPI_Type *base, spi_slave_handle_t *handle)`

SPI slave aborts a transfer using an interrupt.

This function aborts a transfer using an interrupt.

**Parameters**

- `base` – SPI peripheral base address.
- `handle` – Pointer to the `spi_slave_handle_t` structure which stores the transfer state.

`void SPI_SlaveTransferHandleIRQ(SPI_Type *base, spi_slave_handle_t *handle)`

Interrupts a handler for the SPI slave.

**Parameters**

- `base` – SPI peripheral base address.
- `handle` – pointer to `spi_slave_handle_t` structure which stores the transfer state

`FSL_SPI_DRIVER_VERSION`

SPI driver version.

`enum _spi_xfer_option`

SPI transfer option.

*Values:*

`enumerator kSPI_EndOfFrame`

Add delay at the end of each frame(the last clk edge).

`enumerator kSPI_EndOfTransfer`

Re-assert the CS signal after transfer finishes to deselect slave.

`enumerator kSPI_ReceiveIgnore`

Ignore the receive data.

`enum _spi_shift_direction`

SPI data shifter direction options.

*Values:*

`enumerator kSPI_MsbFirst`

Data transfers start with most significant bit.

`enumerator kSPI_LsbFirst`

Data transfers start with least significant bit.

`enum _spi_clock_polarity`

SPI clock polarity configuration.

*Values:*

`enumerator kSPI_ClockPolarityActiveHigh`

Active-high SPI clock (idles low).

`enumerator kSPI_ClockPolarityActiveLow`

Active-low SPI clock (idles high).

enum \_spi\_clock\_phase

SPI clock phase configuration.

*Values:*

enumerator kSPI\_ClockPhaseFirstEdge

First edge on SCK occurs at the middle of the first cycle of a data transfer.

enumerator kSPI\_ClockPhaseSecondEdge

First edge on SCK occurs at the start of the first cycle of a data transfer.

enum \_spi\_ssel

Slave select.

*Values:*

enumerator kSPI\_Ssel0Assert

Slave select 0

enumerator kSPI\_SselDeAssertAll

enum \_spi\_spol

ssel polarity

*Values:*

enumerator kSPI\_Spol0ActiveHigh

enumerator kSPI\_Spol1ActiveHigh

enumerator kSPI\_Spol2ActiveHigh

enumerator kSPI\_Spol3ActiveHigh

enumerator kSPI\_SpolActiveAllHigh

enumerator kSPI\_SpolActiveAllLow

enum \_spi\_data\_width

Transfer data width.

*Values:*

enumerator kSPI\_Data4Bits

4 bits data width

enumerator kSPI\_Data5Bits

5 bits data width

enumerator kSPI\_Data6Bits

6 bits data width

enumerator kSPI\_Data7Bits

7 bits data width

enumerator kSPI\_Data8Bits

8 bits data width

enumerator kSPI\_Data9Bits

9 bits data width

enumerator kSPI\_Data10Bits

10 bits data width

```
enumerator kSPI_Data11Bits
    11 bits data width
enumerator kSPI_Data12Bits
    12 bits data width
enumerator kSPI_Data13Bits
    13 bits data width
enumerator kSPI_Data14Bits
    14 bits data width
enumerator kSPI_Data15Bits
    15 bits data width
enumerator kSPI_Data16Bits
    16 bits data width
```

SPI transfer status.

*Values:*

```
enumerator kStatus_SPI_Busy
    SPI bus is busy
enumerator kStatus_SPI_Idle
    SPI is idle
enumerator kStatus_SPI_Error
    SPI error
enumerator kStatus_SPI_BaudrateNotSupport
    Baudrate is not support in current clock source
enumerator kStatus_SPI_Timeout
    SPI Timeout polling status flags.
```

enum \_spi\_interrupt\_enable

SPI interrupt sources.

*Values:*

```
enumerator kSPI_RxReadyInterruptEnable
    Rx ready interrupt
enumerator kSPI_TxReadyInterruptEnable
    Tx ready interrupt
enumerator kSPI_RxOverrunInterruptEnable
    Rx overrun interrupt
enumerator kSPI_TxUnderrunInterruptEnable
    Tx underrun interrupt
enumerator kSPI_SlaveSelectAssertInterruptEnable
    Slave select assert interrupt
enumerator kSPI_SlaveSelectDeassertInterruptEnable
    Slave select deassert interrupt
enumerator kSPI_AllInterruptEnable
```

```
enum _spi_status_flags
  SPI status flags.

  Values:
  enumerator kSPI_RxReadyFlag
    Receive ready flag.

  enumerator kSPI_TxReadyFlag
    Transmit ready flag.

  enumerator kSPI_RxOverrunFlag
    Receive overrun flag.

  enumerator kSPI_TxUnderrunFlag
    Transmit underrun flag.

  enumerator kSPI_SlaveSelectAssertFlag
    Slave select assert flag.

  enumerator kSPI_SlaveSelectDeassertFlag
    slave select deassert flag.

  enumerator kSPI_StallFlag
    Stall flag.

  enumerator kSPI_EndTransferFlag
    End transfer bit.

  enumerator kSPI_MasterIdleFlag
    Master in idle status flag.

typedef enum _spi_shift_direction spi_shift_direction_t
  SPI data shifter direction options.

typedef enum _spi_clock_polarity spi_clock_polarity_t
  SPI clock polarity configuration.

typedef enum _spi_clock_phase spi_clock_phase_t
  SPI clock phase configuration.

typedef enum _spi_ssel spi_ssel_t
  Slave select.

typedef enum _spi_spol spi_spol_t
  ssel polarity

typedef enum _spi_data_width spi_data_width_t
  Transfer data width.

typedef struct _spi_delay_config spi_delay_config_t
  SPI delay time configure structure.

typedef struct _spi_master_config spi_master_config_t
  SPI master user configure structure.

typedef struct _spi_slave_config spi_slave_config_t
  SPI slave user configure structure.

typedef struct _spi_transfer spi_transfer_t
  SPI transfer structure.
```

```

typedef struct _spi_master_handle spi_master_handle_t
    Master handle type.

typedef spi_master_handle_t spi_slave_handle_t
    Slave handle type.

typedef void (*spi_master_callback_t)(SPI_Type *base, spi_master_handle_t *handle, status_t
status, void *userData)
    SPI master callback for finished transmit.

typedef void (*spi_slave_callback_t)(SPI_Type *base, spi_slave_handle_t *handle, status_t status,
void *userData)
    SPI slave callback for finished transmit.

volatile uint16_t s_dummyData[]

uint32_t SPI_GetInstance(SPI_Type *base)
    Returns instance number for SPI peripheral base address.

SPI_DUMMYDATA
    SPI dummy transfer data, the data is sent while txBuff is NULL.

FSL_SDK_ENABLE_SPI_DRIVER_TRANSACTIONAL_APIS

SPI_RETRY_TIMES
    Retry times for waiting flag.

struct _spi_delay_config
    #include <fsl_spi.h> SPI delay time configure structure.

```

### Public Members

```

uint8_t preDelay
    Delay between SSEL assertion and the beginning of transfer.

uint8_t postDelay
    Delay between the end of transfer and SSEL deassertion.

uint8_t frameDelay
    Delay between frame to frame.

uint8_t transferDelay
    Delay between transfer to transfer.

struct _spi_master_config
    #include <fsl_spi.h> SPI master user configure structure.

```

### Public Members

```

bool enableLoopback
    Enable loopback for test purpose

bool enableMaster
    Enable SPI at initialization time

uint32_t baudRate_Bps
    Baud Rate for SPI in Hz

spi_clock_polarity_t clockPolarity
    Clock polarity

```

```
spi_clock_phase_t clockPhase
    Clock phase
spi_shift_direction_t direction
    MSB or LSB
uint8_t dataWidth
    Width of the data
spi_ssel_t sselNumber
    Slave select number
spi_spol_t sselPolarity
    Configure active CS polarity
spi_delay_config_t delayConfig
    Configure for delay time.

struct _spi_slave_config
#include <fsl_spi.h> SPI slave user configure structure.
```

### Public Members

```
bool enableSlave
    Enable SPI at initialization time
spi_clock_polarity_t clockPolarity
    Clock polarity
spi_clock_phase_t clockPhase
    Clock phase
spi_shift_direction_t direction
    MSB or LSB
uint8_t dataWidth
    Width of the data
spi_spol_t sselPolarity
    Configure active CS polarity

struct _spi_transfer
#include <fsl_spi.h> SPI transfer structure.
```

### Public Members

```
const uint8_t *txData
    Send buffer
uint8_t *rxData
    Receive buffer
size_t dataSize
    Transfer bytes
uint32_t configFlags
    Additional option to control transfer _spi_xfer_option.

struct _spi_master_handle
#include <fsl_spi.h> SPI transfer handle structure.
```

**Public Members**

```

const uint8_t *volatile txData
    Transfer buffer
uint8_t *volatile rxData
    Receive buffer
volatile size_t txRemainingBytes
    Number of data to be transmitted [in bytes]
volatile size_t rxRemainingBytes
    Number of data to be received [in bytes]
size_t totalByteCount
    A number of transfer bytes
volatile uint32_t state
    SPI internal state
spi_master_callback_t callback
    SPI callback
void *userData
    Callback parameter
uint8_t dataWidth
    Width of the data [Valid values: 1 to 16]
uint32_t lastCommand
    Last command for transfer.

```

## 2.25 SWM: Switch Matrix Module

```

enum _swm_port_pin_type_t
    SWM port_pin number.

    Values:
    enumerator kSWM_PortPin_P0_0
        port_pin number P0_0.
    enumerator kSWM_PortPin_P0_1
        port_pin number P0_1.
    enumerator kSWM_PortPin_P0_2
        port_pin number P0_2.
    enumerator kSWM_PortPin_P0_3
        port_pin number P0_3.
    enumerator kSWM_PortPin_P0_4
        port_pin number P0_4.
    enumerator kSWM_PortPin_P0_5
        port_pin number P0_5.
    enumerator kSWM_PortPin_P0_6
        port_pin number P0_6.

```

```
enumerator kSWM_PortPin_P0_7
    port_pin number P0_7.
enumerator kSWM_PortPin_P0_8
    port_pin number P0_8.
enumerator kSWM_PortPin_P0_9
    port_pin number P0_9.
enumerator kSWM_PortPin_P0_10
    port_pin number P0_10.
enumerator kSWM_PortPin_P0_11
    port_pin number P0_11.
enumerator kSWM_PortPin_P0_12
    port_pin number P0_12.
enumerator kSWM_PortPin_P0_13
    port_pin number P0_13.
enumerator kSWM_PortPin_P0_14
    port_pin number P0_14.
enumerator kSWM_PortPin_P0_15
    port_pin number P0_15.
enumerator kSWM_PortPin_P0_16
    port_pin number P0_16.
enumerator kSWM_PortPin_P0_17
    port_pin number P0_17.
enumerator kSWM_PortPin_P0_18
    port_pin number P0_18.
enumerator kSWM_PortPin_P0_19
    port_pin number P0_19.
enumerator kSWM_PortPin_P0_20
    port_pin number P0_20.
enumerator kSWM_PortPin_P0_21
    port_pin number P0_21.
enumerator kSWM_PortPin_P0_22
    port_pin number P0_22.
enumerator kSWM_PortPin_P0_23
    port_pin number P0_23.
enumerator kSWM_PortPin_P0_24
    port_pin number P0_24.
enumerator kSWM_PortPin_P0_25
    port_pin number P0_25.
enumerator kSWM_PortPin_P0_26
    port_pin number P0_26.
enumerator kSWM_PortPin_P0_27
    port_pin number P0_27.
```

```
enumerator kSWM_PortPin_P0_28
    port_pin number P0_28.
enumerator kSWM_PortPin_Reset
    port_pin reset number.

enum _swm_select_movable_t
    SWM movable selection.

Values:
enumerator kSWM_USART0_TXD
    Movable function as USART0_TXD.
enumerator kSWM_USART0_RXD
    Movable function as USART0_RXD.
enumerator kSWM_USART0_RTS
    Movable function as USART0_RTS.
enumerator kSWM_USART0_CTS
    Movable function as USART0_CTS.
enumerator kSWM_USART0_SCLK
    Movable function as USART0_SCLK.
enumerator kSWM_USART1_TXD
    Movable function as USART1_TXD.
enumerator kSWM_USART1_RXD
    Movable function as USART1_RXD.
enumerator kSWM_USART1_RTS
    Movable function as USART1_RTS.
enumerator kSWM_USART1_CTS
    Movable function as USART1_CTS.
enumerator kSWM_USART1_SCLK
    Movable function as USART1_SCLK.
enumerator kSWM_USART2_TXD
    Movable function as USART2_TXD.
enumerator kSWM_USART2_RXD
    Movable function as USART2_RXD.
enumerator kSWM_USART2_RTS
    Movable function as USART2_RTS.
enumerator kSWM_USART2_CTS
    Movable function as USART2_CTS.
enumerator kSWM_USART2_SCLK
    Movable function as USART2_SCLK.
enumerator kSWM_SPI0_SCK
    Movable function as SPI0_SCK.
enumerator kSWM_SPI0_MOSI
    Movable function as SPI0_MOSI.
```

```
enumerator kSWM_SPI0_MISO
    Movable function as SPI0_MISO.
enumerator kSWM_SPI0_SSEL0
    Movable function as SPI0_SSEL0.
enumerator kSWM_SPI0_SSEL1
    Movable function as SPI0_SSEL1.
enumerator kSWM_SPI0_SSEL2
    Movable function as SPI0_SSEL2.
enumerator kSWM_SPI0_SSEL3
    Movable function as SPI0_SSEL3.
enumerator kSWM_SPI1_SCK
    Movable function as SPI1_SCK.
enumerator kSWM_SPI1_MOSI
    Movable function as SPI1_MOSI.
enumerator kSWM_SPI1_MISO
    Movable function as SPI1_MISO.
enumerator kSWM_SPI1_SSEL0
    Movable function as SPI1_SSEL0.
enumerator kSWM_SPI1_SSEL1
    Movable function as SPI1_SSEL1.
enumerator kSWM_SCT_PIN0
    Movable function as SCT_PIN0.
enumerator kSWM_SCT_PIN1
    Movable function as SCT_PIN1.
enumerator kSWM_SCT_PIN2
    Movable function as SCT_PIN2.
enumerator kSWM_SCT_PIN3
    Movable function as SCT_PIN3.
enumerator kSWM_SCT_OUT0
    Movable function as SCT_OUT0.
enumerator kSWM_SCT_OUT1
    Movable function as SCT_OUT1.
enumerator kSWM_SCT_OUT2
    Movable function as SCT_OUT2.
enumerator kSWM_SCT_OUT3
    Movable function as SCT_OUT3.
enumerator kSWM_SCT_OUT4
    Movable function as SCT_OUT4.
enumerator kSWM_SCT_OUT5
    Movable function as SCT_OUT5.
enumerator kSWM_I2C1_SDA
    Movable function as I2C1_SDA.
```

```
enumerator kSWM_I2C1_SCL
    Movable function as I2C1_SCL.
enumerator kSWM_I2C2_SDA
    Movable function as I2C2_SDA.
enumerator kSWM_I2C2_SCL
    Movable function as I2C2_SCL.
enumerator kSWM_I2C3_SDA
    Movable function as I2C3_SDA.
enumerator kSWM_I2C3_SCL
    Movable function as I2C3_SCL.
enumerator kSWM_ADC_PINTRIG0
    Movable function as PINTRIG0.
enumerator kSWM_ADC_PINTRIG1
    Movable function as PINTRIG1.
enumerator kSWM_ACMP_OUT
    Movable function as ACMP_OUT.
enumerator kSWM_CLKOUT
    Movable function as CLKOUT.
enumerator kSWM_GPIO_INT_BMAT
    Movable function as GPIO_INT_BMAT.
enumerator kSWM_MOVABLE_NUM_FUNCS
    Movable function number.

enum __swm_select_fixed_pin_t
    SWM fixed pin selection.

    Values:
enumerator kSWM_ACMP_INPUT1
    Fixed-pin function as ACMP_INPUT1.
enumerator kSWM_ACMP_INPUT2
    Fixed-pin function as ACMP_INPUT2.
enumerator kSWM_ACMP_INPUT3
    Fixed-pin function as ACMP_INPUT3.
enumerator kSWM_ACMP_INPUT4
    Fixed-pin function as ACMP_INPUT4.
enumerator kSWM_SWCLK
    Fixed-pin function as SWCLK.
enumerator kSWM_SWDIO
    Fixed-pin function as SWDIO.
enumerator kSWM_XTALIN
    Fixed-pin function as XTALIN.
enumerator kSWM_XTALOUT
    Fixed-pin function as XTALOUT.
```

```
enumerator kSWM_RESETN
    Fixed-pin function as RESETN.

enumerator kSWM_CLKIN
    Fixed-pin function as CLKIN.

enumerator kSWM_VDDCMP
    Fixed-pin function as VDDCMP.

enumerator kSWM_I2C0_SDA
    Fixed-pin function as I2C0_SDA.

enumerator kSWM_I2C0_SCL
    Fixed-pin function as I2C0_SCL.

enumerator kSWM_ADC_CHN0
    Fixed-pin function as ADC_CHN0.

enumerator kSWM_ADC_CHN1
    Fixed-pin function as ADC_CHN1.

enumerator kSWM_ADC_CHN2
    Fixed-pin function as ADC_CHN2.

enumerator kSWM_ADC_CHN3
    Fixed-pin function as ADC_CHN3.

enumerator kSWM_ADC_CHN4
    Fixed-pin function as ADC_CHN4.

enumerator kSWM_ADC_CHN5
    Fixed-pin function as ADC_CHN5.

enumerator kSWM_ADC_CHN6
    Fixed-pin function as ADC_CHN6.

enumerator kSWM_ADC_CHN7
    Fixed-pin function as ADC_CHN7.

enumerator kSWM_ADC_CHN8
    Fixed-pin function as ADC_CHN8.

enumerator kSWM_ADC_CHN9
    Fixed-pin function as ADC_CHN9.

enumerator kSWM_ADC_CHN10
    Fixed-pin function as ADC_CHN10.

enumerator kSWM_ADC_CHN11
    Fixed-pin function as ADC_CHN11.

enumerator kSWM_FIXEDPIN_NUM_FUNCS
    Fixed-pin function number.

typedef enum _swm_port_pin_type_t swm_port_pin_type_t
    SWM port_pin number.

typedef enum _swm_select_movable_t swm_select_movable_t
    SWM movable selection.

typedef enum _swm_select_fixed_pin_t swm_select_fixed_pin_t
    SWM fixed pin selection.
```

FSL\_SWM\_DRIVER\_VERSION

LPC SWM driver version.

void SWM\_SetMovablePinSelect(SWM\_Type \*base, *swm\_select\_movable\_t* func,  
*swm\_port\_pin\_type\_t* *swm\_port\_pin*)

Assignment of digital peripheral functions to pins.

This function will selects a pin (designated by its GPIO port and bit numbers) to a function.

**Parameters**

- base – SWM peripheral base address.
- func – any function name that is movable.
- *swm\_port\_pin* – any pin which has a GPIO port number and bit number.

void SWM\_SetFixedPinSelect(SWM\_Type \*base, *swm\_select\_fixed\_pin\_t* func, bool enable)

Enable the fixed-pin function.

This function will enables a fixed-pin function in PINENABLE0 or PINENABLE1.

**Parameters**

- base – SWM peripheral base address.
- func – any function name that is fixed pin.
- enable – enable or disable.

## 2.26 SYSCON: System Configuration

enum \_\_syscon\_connection\_t

SYSCON connections type.

*Values:*

enumerator kSYSCON\_GpioPort0Pin0ToPintsel  
 Pin Interrupt.  
 enumerator kSYSCON\_GpioPort0Pin1ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin2ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin3ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin4ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin5ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin6ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin7ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin8ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin9ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin10ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin11ToPintsel  
 enumerator kSYSCON\_GpioPort0Pin12ToPintsel

```
enumerator kSYSCON_GpioPort0Pin13ToPintsel
enumerator kSYSCON_GpioPort0Pin14ToPintsel
enumerator kSYSCON_GpioPort0Pin15ToPintsel
enumerator kSYSCON_GpioPort0Pin16ToPintsel
enumerator kSYSCON_GpioPort0Pin17ToPintsel
enumerator kSYSCON_GpioPort0Pin18ToPintsel
enumerator kSYSCON_GpioPort0Pin19ToPintsel
enumerator kSYSCON_GpioPort0Pin20ToPintsel
enumerator kSYSCON_GpioPort0Pin21ToPintsel
enumerator kSYSCON_GpioPort0Pin22ToPintsel
enumerator kSYSCON_GpioPort0Pin23ToPintsel
enumerator kSYSCON_GpioPort0Pin24ToPintsel
enumerator kSYSCON_GpioPort0Pin25ToPintsel
enumerator kSYSCON_GpioPort0Pin26ToPintsel
enumerator kSYSCON_GpioPort0Pin27ToPintsel
enumerator kSYSCON_GpioPort0Pin28ToPintsel

typedef enum _syscon_connection_t syscon_connection_t
    SYSCON connections type.

PINTSEL_ID
    Periphinmux IDs.

SYSCON_SHIFT

FSL_SYSON_DRIVER_VERSION
    Group syscon driver version for SDK.
    Version 2.0.1.

void SYSCON_AttachSignal(SYSCON_Type *base, uint32_t index, syscon_connection_t
    connection)
    Attaches a signal.
    This function gates the SYSCON clock.

Parameters

- base – Base address of the SYSCON peripheral.
- index – Destination peripheral to attach the signal to.
- connection – Selects connection.

Return values
    None. –
```

## 2.27 USART: Universal Asynchronous Receiver/Transmitter Driver

### 2.28 USART DMA Driver

```
status_t USART_TransferCreateHandleDMA(USART_Type *base, usart_dma_handle_t *handle,
                                       usart_dma_transfer_callback_t callback, void
                                       *userData, dma_handle_t *txDmaHandle,
                                       dma_handle_t *rxDmaHandle)
```

Initializes the USART handle which is used in transactional functions.

#### Parameters

- base – USART peripheral base address.
- handle – Pointer to usart\_dma\_handle\_t structure.
- callback – Callback function.
- userData – User data.
- txDmaHandle – User-requested DMA handle for TX DMA transfer.
- rxDmaHandle – User-requested DMA handle for RX DMA transfer.

```
status_t USART_TransferSendDMA(USART_Type *base, usart_dma_handle_t *handle,
                               usart_transfer_t *xfer)
```

Sends data using DMA.

This function sends data using DMA. This is a non-blocking function, which returns right away. When all data is sent, the send callback function is called.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- xfer – USART DMA transfer structure. See usart\_transfer\_t.

#### Return values

- kStatus\_Success – if succeed, others failed.
- kStatus\_USART\_TxBusy – Previous transfer on going.
- kStatus\_InvalidArgument – Invalid argument.

```
status_t USART_TransferReceiveDMA(USART_Type *base, usart_dma_handle_t *handle,
                                 usart_transfer_t *xfer)
```

Receives data using DMA.

This function receives data using DMA. This is a non-blocking function, which returns right away. When all data is received, the receive callback function is called.

#### Parameters

- base – USART peripheral base address.
- handle – Pointer to usart\_dma\_handle\_t structure.
- xfer – USART DMA transfer structure. See usart\_transfer\_t.

#### Return values

- kStatus\_Success – if succeed, others failed.
- kStatus\_USART\_RxBusy – Previous transfer on going.

- kStatus\_InvalidArgument – Invalid argument.

```
void USART_TransferAbortSendDMA(USART_Type *base, usart_dma_handle_t *handle)
```

Aborts the sent data using DMA.

This function aborts send data using DMA.

#### Parameters

- base – USART peripheral base address
- handle – Pointer to usart\_dma\_handle\_t structure

```
void USART_TransferAbortReceiveDMA(USART_Type *base, usart_dma_handle_t *handle)
```

Aborts the received data using DMA.

This function aborts the received data using DMA.

#### Parameters

- base – USART peripheral base address
- handle – Pointer to usart\_dma\_handle\_t structure

```
status_t USART_TransferGetReceiveCountDMA(USART_Type *base, usart_dma_handle_t *handle, uint32_t *count)
```

Get the number of bytes that have been received.

This function gets the number of bytes that have been received.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- count – Receive bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No receive in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
status_t USART_TransferGetSendCountDMA(USART_Type *base, usart_dma_handle_t *handle, uint32_t *count)
```

Get the number of bytes that have been sent.

This function gets the number of bytes that have been sent.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- count – Sent bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No receive in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

FSL\_USART\_DMA\_DRIVER\_VERSION

USART dma driver version.

```
typedef struct_usart_dma_handle usart_dma_handle_t
```

```
typedef void (*uart_dma_transfer_callback_t)(USART_Type *base, usart_dma_handle_t *handle,
status_t status, void *userData)
```

UART transfer callback function.

```
struct _uart_dma_handle
#include <fsl_usart_dma.h> UART DMA handle.
```

### Public Members

USART\_Type \*base

UART peripheral base address.

uart\_dma\_transfer\_callback\_t callback

Callback function.

void \*userData

UART callback function parameter.

size\_t rxDataSizeAll

Size of the data to receive.

size\_t txDataSizeAll

Size of the data to send out.

dma\_handle\_t \*txDmaHandle

The DMA TX channel used.

dma\_handle\_t \*rxDmaHandle

The DMA RX channel used.

volatile uint8\_t txState

TX transfer state.

volatile uint8\_t rxState

RX transfer state

## 2.29 USART Driver

```
uint32_t USART_GetInstance(USART_Type *base)
```

Returns instance number for USART peripheral base address.

```
status_t USART_Init(USART_Type *base, const usart_config_t *config, uint32_t srcClock_Hz)
```

Initializes a USART instance with user configuration structure and peripheral clock.

This function configures the USART module with the user-defined settings. The user can configure the configuration structure and also get the default configuration by using the USART\_GetDefaultConfig() function. Example below shows how to use this API to configure USART.

```
usart_config_t usartConfig;
usartConfig.baudRate_Bps = 115200U;
usartConfig.parityMode = kUSART_ParityDisabled;
usartConfig.stopBitCount = kUSART_OneStopBit;
USART_Init(USART1, &usartConfig, 20000000U);
```

### Parameters

- base – USART peripheral base address.

- config – Pointer to user-defined configuration structure.
- srcClock\_Hz – USART clock source frequency in HZ.

#### Return values

- kStatus\_USART\_BaudrateNotSupport – Baudrate is not support in current clock source.
- kStatus\_InvalidArgument – USART base address is not valid
- kStatus\_Success – Status USART initialize succeed

`void USART_Deinit(USART_Type *base)`

Deinitializes a USART instance.

This function waits for TX complete, disables the USART clock.

This function waits for TX complete, disables TX and RX, and disables the USART clock.

#### Parameters

- base – USART peripheral base address.
- config – USART peripheral base address.

`void USART_GetDefaultConfig(usart_config_t *config)`

Gets the default configuration structure.

This function initializes the USART configuration structure to a default value. The default values are: `usartConfig->baudRate_Bps = 9600U; usartConfig->parityMode = kUSART_ParityDisabled; usartConfig->stopBitCount = kUSART_OneStopBit; usartConfig->bitCountPerChar = kUSART_8BitsPerChar; usartConfig->loopback = false; usartConfig->enableTx = false; usartConfig->enableRx = false; ...`

This function initializes the USART configuration structure to a default value. The default values are: `usartConfig->baudRate_Bps = 115200U; usartConfig->parityMode = kUSART_ParityDisabled; usartConfig->stopBitCount = kUSART_OneStopBit; usartConfig->bitCountPerChar = kUSART_8BitsPerChar; usartConfig->loopback = false; usartConfig->enableTx = false; usartConfig->enableRx = false;`

#### Parameters

- config – Pointer to configuration structure.
- config – Pointer to configuration structure.

`status_t USART_SetBaudRate(USART_Type *base, uint32_t baudrate_Bps, uint32_t srcClock_Hz)`

Sets the USART instance baud rate.

This function configures the USART module baud rate. This function is used to update the USART module baud rate after the USART module is initialized by the `USART_Init`.

`USART_SetBaudRate(USART1, 115200U, 20000000U);`

#### Parameters

- base – USART peripheral base address.
- baudrate\_Bps – USART baudrate to be set.
- srcClock\_Hz – USART clock source frequency in HZ.

#### Return values

- kStatus\_USART\_BaudrateNotSupport – Baudrate is not support in current clock source.
- kStatus\_Success – Set baudrate succeed.
- kStatus\_InvalidArgument – One or more arguments are invalid.

static inline uint32\_t USART\_GetStatusFlags(USART\_Type \*base)

Get USART status flags.

This function get all USART status flags, the flags are returned as the logical OR value of the enumerators \_uart\_flags. To check a specific status, compare the return value with enumerators in \_uart\_flags. For example, to check whether the RX is ready:

```
if (kUSART_RxReady & USART_GetStatusFlags(USART1))
{
    ...
}
```

### Parameters

- base – USART peripheral base address.

### Returns

USART status flags which are ORed by the enumerators in the \_uart\_flags.

static inline void USART\_ClearStatusFlags(USART\_Type \*base, uint32\_t mask)

Clear USART status flags.

This function clear supported USART status flags For example:

```
USART_ClearStatusFlags(USART1, kUSART_HardwareOverrunFlag)
```

### Parameters

- base – USART peripheral base address.
- mask – status flags to be cleared.

static inline void USART\_EnableInterrupts(USART\_Type \*base, uint32\_t mask)

Enables USART interrupts according to the provided mask.

This function enables the USART interrupts according to the provided mask. The mask is a logical OR of enumeration members. See \_uart\_interrupt\_enable. For example, to enable TX ready interrupt and RX ready interrupt:

```
USART_EnableInterrupts(USART1, kUSART_RxReadyInterruptEnable | kUSART_TxReadyInterruptEnable);
```

### Parameters

- base – USART peripheral base address.
- mask – The interrupts to enable. Logical OR of \_uart\_interrupt\_enable.

static inline void USART\_DisableInterrupts(USART\_Type \*base, uint32\_t mask)

Disables USART interrupts according to a provided mask.

This function disables the USART interrupts according to a provided mask. The mask is a logical OR of enumeration members. See \_uart\_interrupt\_enable. This example shows how to disable the TX ready interrupt and RX ready interrupt:

```
USART_DisableInterrupts(USART1, kUSART_TxReadyInterruptEnable | kUSART_RxReadyInterruptEnable);
```

**Parameters**

- `base` – USART peripheral base address.
- `mask` – The interrupts to disable. Logical OR of `_uart_interrupt_enable`.

`static inline uint32_t USART_GetEnabledInterrupts(USART_Type *base)`

Returns enabled USART interrupts.

This function returns the enabled USART interrupts.

**Parameters**

- `base` – USART peripheral base address.

`static inline void USART_EnableContinuousSCLK(USART_Type *base, bool enable)`

Continuous Clock generation. By default, SCLK is only output while data is being transmitted in synchronous mode. Enable this function, SCLK will run continuously in synchronous mode, allowing characters to be received on `Un_RxD` independently from transmission on `Un_TxD`.

**Parameters**

- `base` – USART peripheral base address.
- `enable` – Enable Continuous Clock generation mode or not, true for enable and false for disable.

`static inline void USART_EnableAutoClearSCLK(USART_Type *base, bool enable)`

Enable Continuous Clock generation bit auto clear. While enable this function, the Continuous Clock bit is automatically cleared when a complete character has been received. This bit is cleared at the same time.

**Parameters**

- `base` – USART peripheral base address.
- `enable` – Enable auto clear or not, true for enable and false for disable.

`static inline void USART_EnableCTS(USART_Type *base, bool enable)`

Enable CTS. This function will determine whether CTS is used for flow control.

**Parameters**

- `base` – USART peripheral base address.
- `enable` – Enable CTS or not, true for enable and false for disable.

`static inline void USART_EnableTx(USART_Type *base, bool enable)`

Enable the USART transmit.

This function will enable or disable the USART transmit.

**Parameters**

- `base` – USART peripheral base address.
- `enable` – true for enable and false for disable.

`static inline void USART_EnableRx(USART_Type *base, bool enable)`

Enable the USART receive.

This function will enable or disable the USART receive. Note: if the transmit is enabled, the receive will not be disabled.

**Parameters**

- `base` – USART peripheral base address.
- `enable` – true for enable and false for disable.

static inline void USART\_WriteByte(USART\_Type \*base, uint8\_t data)

Writes to the TXDAT register.

This function will writes data to the TXDAT automaty. The upper layer must ensure that TXDATA has space for data to write before calling this function.

#### Parameters

- base – USART peripheral base address.
- data – The byte to write.

static inline uint8\_t USART\_ReadByte(USART\_Type \*base)

Reads the RXDAT directly.

This function reads data from the RXDAT automaty. The upper layer must ensure that the RXDAT is not empty before calling this function.

#### Parameters

- base – USART peripheral base address.

#### Returns

The byte read from USART data register.

*status\_t* USART\_WriteBlocking(USART\_Type \*base, const uint8\_t \*data, size\_t length)

Writes to the TX register using a blocking method.

This function polls the TX register, waits for the TX register to be empty.

This function polls the TX register, waits for the TX register to be empty or for the TX FIFO to have room and writes data to the TX buffer.

#### Parameters

- base – USART peripheral base address.
- data – Start address of the data to write.
- length – Size of the data to write.
- base – USART peripheral base address.
- data – Start address of the data to write.
- length – Size of the data to write.

#### Return values

- kStatus\_USART\_Timeout – Transmission timed out and was aborted.
- kStatus\_Success – Successfully wrote all data.
- kStatus\_USART\_Timeout – Transmission timed out and was aborted.
- kStatus\_InvalidArgument – Invalid argument.
- kStatus\_Success – Successfully wrote all data.

*status\_t* USART\_ReadBlocking(USART\_Type \*base, uint8\_t \*data, size\_t length)

Read RX data register using a blocking method.

This function polls the RX register, waits for the RX register to be full.

This function polls the RX register, waits for the RX register to be full or for RX FIFO to have data and read data from the TX register.

#### Parameters

- base – USART peripheral base address.
- data – Start address of the buffer to store the received data.
- length – Size of the buffer.
- base – USART peripheral base address.
- data – Start address of the buffer to store the received data.
- length – Size of the buffer.

#### Return values

- kStatus\_USART\_FramingError – Receiver overrun happened while receiving data.
- kStatus\_USART\_ParityError – Noise error happened while receiving data.
- kStatus\_USART\_NoiseError – Framing error happened while receiving data.
- kStatus\_USART\_RxError – Overflow or underflow happened.
- kStatus\_USART\_Timeout – Transmission timed out and was aborted.
- kStatus\_Success – Successfully received all data.
- kStatus\_USART\_FramingError – Receiver overrun happened while receiving data.
- kStatus\_USART\_ParityError – Noise error happened while receiving data.
- kStatus\_USART\_NoiseError – Framing error happened while receiving data.
- kStatus\_USART\_RxError – Overflow or underflow rxFIFO happened.
- kStatus\_USART\_Timeout – Transmission timed out and was aborted.
- kStatus\_Success – Successfully received all data.

```
status_t USART_TransferCreateHandle(USART_Type *base, usart_handle_t *handle,  
                                    usart_transfer_callback_t callback, void *userData)
```

Initializes the USART handle.

This function initializes the USART handle which can be used for other USART transactional APIs. Usually, for a specified USART instance, call this API once to get the initialized handle.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- callback – The callback function.
- userData – The parameter of the callback function.

```
status_t USART_TransferSendNonBlocking(USART_Type *base, usart_handle_t *handle,  
                                       usart_transfer_t *xfer)
```

Transmits a buffer of data using the interrupt method.

This function sends data using an interrupt method. This is a non-blocking function, which returns directly without waiting for all data to be written to the TX register. When all data is written to the TX register in the IRQ handler, the USART driver calls the callback function and passes the kStatus\_USART\_TxIdle as status parameter.

This function sends data using an interrupt method. This is a non-blocking function, which returns directly without waiting for all data to be written to the TX register. When all data

is written to the TX register in the IRQ handler, the USART driver calls the callback function and passes the `kStatus_USART_TxIdle` as status parameter.

---

**Note:** The `kStatus_USART_TxIdle` is passed to the upper layer when all data is written to the TX register. However it does not ensure that all data are sent out. Before disabling the TX, check the `kUSART_TransmissionCompleteFlag` to ensure that the TX is finished.

---

### Parameters

- `base` – USART peripheral base address.
- `handle` – USART handle pointer.
- `xfer` – USART transfer structure. See `uart_transfer_t`.
- `base` – USART peripheral base address.
- `handle` – USART handle pointer.
- `xfer` – USART transfer structure. See `uart_transfer_t`.

### Return values

- `kStatus_Success` – Successfully start the data transmission.
- `kStatus_USART_TxBusy` – Previous transmission still not finished, data not all written to TX register yet.
- `kStatus_InvalidArgument` – Invalid argument.
- `kStatus_Success` – Successfully start the data transmission.
- `kStatus_USART_TxBusy` – Previous transmission still not finished, data not all written to TX register yet.
- `kStatus_InvalidArgument` – Invalid argument.

`void USART_TransferStartRingBuffer(USART_Type *base, usart_handle_t *handle, uint8_t *ringBuffer, size_t ringBufferSize)`

Sets up the RX ring buffer.

This function sets up the RX ring buffer to a specific USART handle.

When the RX ring buffer is used, data received are stored into the ring buffer even when the user doesn't call the `USART_TransferReceiveNonBlocking()` API. If there is already data received in the ring buffer, the user can get the received data from the ring buffer directly.

This function sets up the RX ring buffer to a specific USART handle.

When the RX ring buffer is used, data received are stored into the ring buffer even when the user doesn't call the `USART_TransferReceiveNonBlocking()` API. If there is already data received in the ring buffer, the user can get the received data from the ring buffer directly.

---

**Note:** When using the RX ring buffer, one byte is reserved for internal use. In other words, if `ringBufferSize` is 32, then only 31 bytes are used for saving data.

---



---

**Note:** When using the RX ring buffer, one byte is reserved for internal use. In other words, if `ringBufferSize` is 32, then only 31 bytes are used for saving data.

---

### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- ringBuffer – Start address of the ring buffer for background receiving. Pass NULL to disable the ring buffer.
- ringBufferSize – size of the ring buffer.
- base – USART peripheral base address.
- handle – USART handle pointer.
- ringBuffer – Start address of the ring buffer for background receiving. Pass NULL to disable the ring buffer.
- ringBufferSize – size of the ring buffer.

`void USART_TransferStopRingBuffer(USART_Type *base, usart_handle_t *handle)`

Aborts the background transfer and uninstalls the ring buffer.

This function aborts the background transfer and uninstalls the ring buffer.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.

`size_t USART_TransferGetRxRingBufferLength(usart_handle_t *handle)`

Get the length of received data in RX ring buffer.

#### Parameters

- handle – USART handle pointer.

#### Returns

Length of received data in RX ring buffer.

`void USART_TransferAbortSend(USART_Type *base, usart_handle_t *handle)`

Aborts the interrupt-driven data transmit.

This function aborts the interrupt driven data sending. The user can get the remainBties to find out how many bytes are still not sent out.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.

`status_t USART_TransferGetSendCount(USART_Type *base, usart_handle_t *handle, uint32_t *count)`

Get the number of bytes that have been written to USART TX register.

Get the number of bytes that have been sent out to bus.

This function gets the number of bytes that have been written to USART TX register by interrupt method.

This function gets the number of bytes that have been sent out to bus by interrupt method.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- count – Send bytes count.
- base – USART peripheral base address.

- handle – USART handle pointer.
- count – Send bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No send in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;
- kStatus\_NoTransferInProgress – No send in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
status_t USART_TransferReceiveNonBlocking(USART_Type *base, usart_handle_t *handle,
                                         usart_transfer_t *xfer, size_t *receivedBytes)
```

Receives a buffer of data using an interrupt method.

This function receives data using an interrupt method. This is a non-blocking function, which returns without waiting for all data to be received. If the RX ring buffer is used and not empty, the data in the ring buffer is copied and the parameter receivedBytes shows how many bytes are copied from the ring buffer. After copying, if the data in the ring buffer is not enough to read, the receive request is saved by the USART driver. When the new data arrives, the receive request is serviced first. When all data is received, the USART driver notifies the upper layer through a callback function and passes the status parameter kStatus\_USART\_RxIdle. For example, the upper layer needs 10 bytes but there are only 5 bytes in the ring buffer. The 5 bytes are copied to the xfer->data and this function returns with the parameter receivedBytes set to 5. For the left 5 bytes, newly arrived data is saved from the xfer->data[5]. When 5 bytes are received, the USART driver notifies the upper layer. If the RX ring buffer is not enabled, this function enables the RX and RX interrupt to receive data to the xfer->data. When all data is received, the upper layer is notified.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- xfer – USART transfer structure, see usart\_transfer\_t.
- receivedBytes – Bytes received from the ring buffer directly.

#### Return values

- kStatus\_Success – Successfully queue the transfer into transmit queue.
- kStatus\_USART\_RxBusy – Previous receive request is not finished.
- kStatus\_InvalidArgument – Invalid argument.

```
void USART_TransferAbortReceive(USART_Type *base, usart_handle_t *handle)
```

Aborts the interrupt-driven data receiving.

This function aborts the interrupt-driven data receiving. The user can get the remainBytes to find out how many bytes not received yet.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.

```
status_t USART_TransferGetReceiveCount(USART_Type *base, usart_handle_t *handle, uint32_t
                                         *count)
```

Get the number of bytes that have been received.

This function gets the number of bytes that have been received.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.
- count – Receive bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No receive in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
void USART_TransferHandleIRQ(USART_Type *base, usart_handle_t *handle)
```

USART IRQ handle function.

This function handles the USART transmit and receive IRQ request.

#### Parameters

- base – USART peripheral base address.
- handle – USART handle pointer.

```
status_t USART_Enable32kMode(USART_Type *base, uint32_t baudRate_Bps, bool enableMode32k, uint32_t srcClock_Hz)
```

Enable 32 kHz mode which USART uses clock from the RTC oscillator as the clock source.

Please note that in order to use a 32 kHz clock to operate USART properly, the RTC oscillator and its 32 kHz output must be manually enabled by user, by calling RTC\_Init and setting SYSCON\_RTCOSCCTRL\_EN bit to 1. And in 32kHz clocking mode the USART can only work at 9600 baudrate or at the baudrate that 9600 can evenly divide, eg: 4800, 3200.

#### Parameters

- base – USART peripheral base address.
- baudRate\_Bps – USART baudrate to be set..
- enableMode32k – true is 32k mode, false is normal mode.
- srcClock\_Hz – USART clock source frequency in HZ.

#### Return values

- kStatus\_USART\_BaudrateNotSupport – Baudrate is not support in current clock source.
- kStatus\_Success – Set baudrate succeed.
- kStatus\_InvalidArgument – One or more arguments are invalid.

```
void USART_Enable9bitMode(USART_Type *base, bool enable)
```

Enable 9-bit data mode for USART.

This function set the 9-bit mode for USART module. The 9th bit is not used for parity thus can be modified by user.

#### Parameters

- base – USART peripheral base address.
- enable – true to enable, false to disable.

---

static inline void USART\_SetMatchAddress(USART\_Type \*base, uint8\_t address)

Set the USART slave address.

This function configures the address for USART module that works as slave in 9-bit data mode. When the address detection is enabled, the frame it receives with MSB being 1 is considered as an address frame, otherwise it is considered as data frame. Once the address frame matches slave's own addresses, this slave is addressed. This address frame and its following data frames are stored in the receive buffer, otherwise the frames will be discarded. To un-address a slave, just send an address frame with unmatched address.

---

**Note:** Any USART instance joined in the multi-slave system can work as slave. The position of the address mark is the same as the parity bit when parity is enabled for 8 bit and 9 bit data formats.

---

#### Parameters

- base – USART peripheral base address.
- address – USART slave address.

static inline void USART\_EnableMatchAddress(USART\_Type \*base, bool match)

Enable the USART match address feature.

#### Parameters

- base – USART peripheral base address.
- match – true to enable match address, false to disable.

static inline void USART\_EnableTxDMA(USART\_Type \*base, bool enable)

Enable DMA for Tx.

static inline void USART\_EnableRxDMA(USART\_Type \*base, bool enable)

Enable DMA for Rx.

static inline void USART\_SetRxFifoWatermark(USART\_Type \*base, uint8\_t water)

Sets the rx FIFO watermark.

#### Parameters

- base – USART peripheral base address.
- water – Rx FIFO watermark.

static inline void USART\_SetTxFifoWatermark(USART\_Type \*base, uint8\_t water)

Sets the tx FIFO watermark.

#### Parameters

- base – USART peripheral base address.
- water – Tx FIFO watermark.

static inline uint8\_t USART\_GetRxFifoCount(USART\_Type \*base)

Gets the rx FIFO data count.

#### Parameters

- base – USART peripheral base address.

#### Returns

rx FIFO data count.

static inline uint8\_t USART\_GetTxFifoCount(USART\_Type \*base)

Gets the tx FIFO data count.

**Parameters**

- base – USART peripheral base address.

**Returns**

tx FIFO data count.

void USART\_SendAddress(USART\_Type \*base, uint8\_t address)

Transmit an address frame in 9-bit data mode.

**Parameters**

- base – USART peripheral base address.
- address – USART slave address.

FSL\_USART\_DRIVER\_VERSION

USART driver version.

FSL\_USART\_DRIVER\_VERSION

USART driver version.

Error codes for the USART driver.

*Values:*

enumerator kStatus\_USART\_TxBusy  
Transmitter is busy.

enumerator kStatus\_USART\_RxBusy  
Receiver is busy.

enumerator kStatus\_USART\_TxIdle  
USART transmitter is idle.

enumerator kStatus\_USART\_RxIdle  
USART receiver is idle.

enumerator kStatus\_USART\_TxError  
Error happens on tx.

enumerator kStatus\_USART\_RxError  
Error happens on rx.

enumerator kStatus\_USART\_RxRingBufferOverrun  
Error happens on rx ring buffer

enumerator kStatus\_USART\_NoiseError  
USART noise error.

enumerator kStatus\_USART\_FramingError  
USART framing error.

enumerator kStatus\_USART\_ParityError  
USART parity error.

enumerator kStatus\_USART\_HardwareOverrun  
USART hardware over flow.

enumerator kStatus\_USART\_BaudrateNotSupport  
Baudrate is not support in current clock source

enumerator kStatus\_USART\_Timeout  
    USART times out.

enum \_uart\_parity\_mode  
    USART parity mode.

*Values:*

enumerator kUSART\_ParityDisabled  
    Parity disabled

enumerator kUSART\_ParityEven  
    Parity enabled, type even, bit setting: PARITYSEL = 10

enumerator kUSART\_ParityOdd  
    Parity enabled, type odd, bit setting: PARITYSEL = 11

enum \_uart\_sync\_mode  
    USART synchronous mode.

*Values:*

enumerator kUSART\_SyncModeDisabled  
    Asynchronous mode.

enumerator kUSART\_SyncModeSlave  
    Synchronous slave mode.

enumerator kUSART\_SyncModeMaster  
    Synchronous master mode.

enum \_uart\_stop\_bit\_count  
    USART stop bit count.

*Values:*

enumerator kUSART\_OneStopBit  
    One stop bit

enumerator kUSART\_TwoStopBit  
    Two stop bits

enum \_uart\_data\_len  
    USART data size.

*Values:*

enumerator kUSART\_7BitsPerChar  
    Seven bit mode

enumerator kUSART\_8BitsPerChar  
    Eight bit mode

enum \_uart\_clock\_polarity  
    USART clock polarity configuration, used in sync mode.

*Values:*

enumerator kUSART\_RxSampleOnFallingEdge  
    Un\_RXD is sampled on the falling edge of SCLK.

enumerator kUSART\_RxSampleOnRisingEdge  
    Un\_RXD is sampled on the rising edge of SCLK.

`enum _uart_interrupt_enable`

USART interrupt configuration structure, default settings all disabled.

*Values:*

`enumerator kUSART_RxReadyInterruptEnable`

Receive ready interrupt.

`enumerator kUSART_TxReadyInterruptEnable`

Transmit ready interrupt.

`enumerator kUSART_TxIdleInterruptEnable`

Transmit idle interrupt.

`enumerator kUSART_DeltaCtsInterruptEnable`

Cts pin change interrupt.

`enumerator kUSART_TxDisableInterruptEnable`

Transmit disable interrupt.

`enumerator kUSART_HardwareOverRunInterruptEnable`

hardware ove run interrupt.

`enumerator kUSART_RxBreakInterruptEnable`

Receive break interrupt.

`enumerator kUSART_RxStartInterruptEnable`

Receive ready interrupt.

`enumerator kUSART_FramErrorInterruptEnable`

Receive start interrupt.

`enumerator kUSART_ParityErrorInterruptEnable`

Receive frame error interrupt.

`enumerator kUSART_RxNoiseInterruptEnable`

Receive noise error interrupt.

`enumerator kUSART_AutoBaudErrorInterruptEnable`

Receive auto baud error interrupt.

`enumerator kUSART_AllInterruptEnable`

All interrupt.

`enum _uart_flags`

USART status flags.

This provides constants for the USART status flags for use in the USART functions.

*Values:*

`enumerator kUSART_RxReady`

Receive ready flag.

`enumerator kUSART_RxIdleFlag`

Receive IDLE flag.

`enumerator kUSART_TxReady`

Transmit ready flag.

`enumerator kUSART_TxIdleFlag`

Transmit idle flag.

enumerator kUSART\_CtsState  
    Cts pin status.

enumerator kUSART\_DeltaCtsFlag  
    Cts pin change flag.

enumerator kUSART\_TxDisableFlag  
    Transmit disable flag.

enumerator kUSART\_HardwareOverrunFlag  
    Hardware over run flag.

enumerator kUSART\_RxBreakFlag  
    Receive break flag.

enumerator kUSART\_RxStartFlag  
    receive start flag.

enumerator kUSART\_FramErrorFlag  
    Frame error flag.

enumerator kUSART\_ParityErrorFlag  
    Parity error flag.

enumerator kUSART\_RxNoiseFlag  
    Receive noise flag.

enumerator kUSART\_AutoBaudErrorFlag  
    Auto baud error flag.

Error codes for the USART driver.

*Values:*

enumerator kStatus\_USART\_TxBusy  
    Transmitter is busy.

enumerator kStatus\_USART\_RxBusy  
    Receiver is busy.

enumerator kStatus\_USART\_TxIdle  
    USART transmitter is idle.

enumerator kStatus\_USART\_RxIdle  
    USART receiver is idle.

enumerator kStatus\_USART\_TxError  
    Error happens on txFIFO.

enumerator kStatus\_USART\_RxError  
    Error happens on rxFIFO.

enumerator kStatus\_USART\_RxRingBufferOverrun  
    Error happens on rx ring buffer

enumerator kStatus\_USART\_NoiseError  
    USART noise error.

enumerator kStatus\_USART\_FramingError  
    USART framing error.

enumerator kStatus\_USART\_ParityError  
    USART parity error.

enumerator kStatus\_USART\_BaudrateNotSupport  
    Baudrate is not support in current clock source

enum \_usart\_sync\_mode  
    USART synchronous mode.

*Values:*

enumerator kUSART\_SyncModeDisabled  
    Asynchronous mode.

enumerator kUSART\_SyncModeSlave  
    Synchronous slave mode.

enumerator kUSART\_SyncModeMaster  
    Synchronous master mode.

enum \_usart\_parity\_mode  
    USART parity mode.

*Values:*

enumerator kUSART\_ParityDisabled  
    Parity disabled

enumerator kUSART\_ParityEven  
    Parity enabled, type even, bit setting: PE|PT = 10

enumerator kUSART\_ParityOdd  
    Parity enabled, type odd, bit setting: PE|PT = 11

enum \_usart\_stop\_bit\_count  
    USART stop bit count.

*Values:*

enumerator kUSART\_OneStopBit  
    One stop bit

enumerator kUSART\_TwoStopBit  
    Two stop bits

enum \_usart\_data\_len  
    USART data size.

*Values:*

enumerator kUSART\_7BitsPerChar  
    Seven bit mode

enumerator kUSART\_8BitsPerChar  
    Eight bit mode

enum \_usart\_clock\_polarity  
    USART clock polarity configuration, used in sync mode.

*Values:*

enumerator kUSART\_RxSampleOnFallingEdge  
    Un\_RXD is sampled on the falling edge of SCLK.

enumerator kUSART\_RxSampleOnRisingEdge  
Un\_RXD is sampled on the rising edge of SCLK.

enum \_\_uart\_txfifo\_watermark  
txFIFO watermark values

*Values:*

enumerator kUSART\_TxFifo0  
USART tx watermark is empty

enumerator kUSART\_TxFifo1  
USART tx watermark at 1 item

enumerator kUSART\_TxFifo2  
USART tx watermark at 2 items

enumerator kUSART\_TxFifo3  
USART tx watermark at 3 items

enumerator kUSART\_TxFifo4  
USART tx watermark at 4 items

enumerator kUSART\_TxFifo5  
USART tx watermark at 5 items

enumerator kUSART\_TxFifo6  
USART tx watermark at 6 items

enumerator kUSART\_TxFifo7  
USART tx watermark at 7 items

enum \_\_uart\_rxfifo\_watermark  
rxFIFO watermark values

*Values:*

enumerator kUSART\_RxFifo1  
USART rx watermark at 1 item

enumerator kUSART\_RxFifo2  
USART rx watermark at 2 items

enumerator kUSART\_RxFifo3  
USART rx watermark at 3 items

enumerator kUSART\_RxFifo4  
USART rx watermark at 4 items

enumerator kUSART\_RxFifo5  
USART rx watermark at 5 items

enumerator kUSART\_RxFifo6  
USART rx watermark at 6 items

enumerator kUSART\_RxFifo7  
USART rx watermark at 7 items

enumerator kUSART\_RxFifo8  
USART rx watermark at 8 items

enum \_\_uart\_interrupt\_enable  
USART interrupt configuration structure, default settings all disabled.

*Values:*

```
enumerator kUSART_TxErrorInterruptEnable
enumerator kUSART_RxErrorInterruptEnable
enumerator kUSART_TxLevelInterruptEnable
enumerator kUSART_RxLevelInterruptEnable
enumerator kUSART_TxIdleInterruptEnable
    Transmitter idle.

enumerator kUSART_CtsChangeInterruptEnable
    Change in the state of the CTS input.

enumerator kUSART_RxBreakChangeInterruptEnable
    Break condition asserted or deasserted.

enumerator kUSART_RxStartInterruptEnable
    Rx start bit detected.

enumerator kUSART_FramingErrorInterruptEnable
    Framing error detected.

enumerator kUSART_ParityErrorInterruptEnable
    Parity error detected.

enumerator kUSART_NoiseErrorInterruptEnable
    Noise error detected.

enumerator kUSART_AutoBaudErrorInterruptEnable
    Auto baudrate error detected.

enumerator kUSART_AllInterruptEnables

enum __usart__flags
    USART status flags.

This provides constants for the USART status flags for use in the USART functions.

Values:

enumerator kUSART_TxError
    TXERR bit, sets if TX buffer is error

enumerator kUSART_RxError
    RXERR bit, sets if RX buffer is error

enumerator kUSART_TxFifoEmptyFlag
    TXEMPTY bit, sets if TX buffer is empty

enumerator kUSART_TxFifoNotFullFlag
    TXNOTFULL bit, sets if TX buffer is not full

enumerator kUSART_RxFifoNotEmptyFlag
    RXNOEMPTY bit, sets if RX buffer is not empty

enumerator kUSART_RxFifoFullFlag
    RXFULL bit, sets if RX buffer is full

enumerator kUSART_RxIdleFlag
    Receiver idle.

enumerator kUSART_TxIdleFlag
    Transmitter idle.
```

enumerator kUSART\_CtsAssertFlag  
 CTS signal high.

enumerator kUSART\_CtsChangeFlag  
 CTS signal changed interrupt status.

enumerator kUSART\_BreakDetectFlag  
 Break detected. Self cleared when rx pin goes high again.

enumerator kUSART\_BreakDetectChangeFlag  
 Break detect change interrupt flag. A change in the state of receiver break detection.

enumerator kUSART\_RxStartFlag  
 Rx start bit detected interrupt flag.

enumerator kUSART\_FramingErrorFlag  
 Framing error interrupt flag.

enumerator kUSART\_ParityErrorFlag  
 parity error interrupt flag.

enumerator kUSART\_NoiseErrorFlag  
 Noise error interrupt flag.

enumerator kUSART\_AutobaudErrorFlag  
 Auto baudrate error interrupt flag, caused by the baudrate counter timeout before the end of start bit.

enumerator kUSART\_AllClearFlags

typedef enum *\_usart\_parity\_mode* usart\_parity\_mode\_t  
 USART parity mode.

typedef enum *\_usart\_sync\_mode* usart\_sync\_mode\_t  
 USART synchronous mode.

typedef enum *\_usart\_stop\_bit\_count* usart\_stop\_bit\_count\_t  
 USART stop bit count.

typedef enum *\_usart\_data\_len* usart\_data\_len\_t  
 USART data size.

typedef enum *\_usart\_clock\_polarity* usart\_clock\_polarity\_t  
 USART clock polarity configuration, used in sync mode.

typedef struct *\_usart\_config* usart\_config\_t  
 USART configuration structure.

typedef struct *\_usart\_transfer* usart\_transfer\_t  
 USART transfer structure.

typedef struct *\_usart\_handle* usart\_handle\_t

typedef void (\*usart\_transfer\_callback\_t)(USART\_Type \*base, usart\_handle\_t \*handle, status\_t status, void \*userData)  
 USART transfer callback function.

typedef enum *\_usart\_sync\_mode* usart\_sync\_mode\_t  
 USART synchronous mode.

typedef enum *\_usart\_parity\_mode* usart\_parity\_mode\_t  
 USART parity mode.

```
typedef enum _uart_stop_bit_count usart_stop_bit_count_t
    USART stop bit count.

typedef enum _uart_data_len usart_data_len_t
    USART data size.

typedef enum _uart_clock_polarity usart_clock_polarity_t
    USART clock polarity configuration, used in sync mode.

typedef enum _uart_txfifo_watermark usart_txfifo_watermark_t
    txFIFO watermark values

typedef enum _uart_rxfifo_watermark usart_rxfifo_watermark_t
    rxFIFO watermark values

typedef struct _uart_config usart_config_t
    USART configuration structure.

typedef struct _uart_transfer usart_transfer_t
    USART transfer structure.

typedef struct _uart_handle usart_handle_t

typedef void (*uart_transfer_callback_t)(USART_Type *base, usart_handle_t *handle, status_t
status, void *userData)
    USART transfer callback function.

typedef void (*flexcomm_usart_irq_handler_t)(USART_Type *base, usart_handle_t *handle)
    TypeDef for usart interrupt handler.

FSL_SDK_ENABLE_USART_DRIVER_TRANSACTIONAL_APIS
    Macro gate for enable transaction API. 1 for enable, 0 for disable.

FSL_SDK_USART_DRIVER_ENABLE_BAUDRATE_AUTO_GENERATE
    USART baud rate auto generate switch gate. 1 for enable, 0 for disable.

UART_RETRY_TIMES
    Retry times for waiting flag.

    Defining to zero means to keep waiting for the flag until it is assert/deassert.

    Defining to zero means to keep waiting for the flag until it is assert/deassert in blocking
transfer, otherwise the program will wait until the UART_RETRY_TIMES counts down to 0,
if the flag still remains unchanged then program will return kStatus_USART_Timeout. It is
not advised to use this macro in formal application to prevent any hardware error because
the actual wait period is affected by the compiler and optimization.

USART_FIFOTRIG_TXLVL_GET(base)
USART_FIFOTRIG_RXLVL_GET(base)

UART_RETRY_TIMES
    Retry times for waiting flag.

    Defining to zero means to keep waiting for the flag until it is assert/deassert in blocking
transfer, otherwise the program will wait until the UART_RETRY_TIMES counts down to 0,
if the flag still remains unchanged then program will return kStatus_USART_Timeout. It is
not advised to use this macro in formal application to prevent any hardware error because
the actual wait period is affected by the compiler and optimization.

struct _uart_config
    #include <fsl_usart.h> USART configuration structure.
```

**Public Members**

```

uint32_t baudRate_Bps
    USART baud rate

bool enableRx
    USART receive enable.
    Enable RX

bool enableTx
    USART transmit enable.
    Enable TX

bool loopback
    Enable peripheral loopback

bool enableContinuousSCLK
    USART continuous Clock generation enable in synchronous master mode.

bool enableHardwareFlowControl
    Enable hardware control RTS/CTS

usart_parity_mode_t parityMode
    Parity mode, disabled (default), even, odd

usart_stop_bit_count_t stopBitCount
    Number of stop bits, 1 stop bit (default) or 2 stop bits

usart_data_len_t bitCountPerChar
    Data length - 7 bit, 8 bit

usart_sync_mode_t syncMode
    Transfer mode - asynchronous, synchronous master, synchronous slave.
    Transfer mode select - asynchronous, synchronous master, synchronous slave.

usart_clock_polarity_t clockPolarity
    Selects the clock polarity and sampling edge in sync mode.
    Selects the clock polarity and sampling edge in synchronous mode.

bool enableMode32k
    USART uses 32 kHz clock from the RTC oscillator as the clock source.

usart_txfifo_watermark_t txWatermark
    txFIFO watermark

usart_rxfifo_watermark_t rxWatermark
    rxFIFO watermark

struct _usart_transfer
#include <fsl_usart.h> USART transfer structure.

```

**Public Members**

```

size_t dataSize
    The byte count to be transfer.

struct _usart_handle
#include <fsl_usart.h> USART handle structure.

```

**Public Members**

```
const uint8_t *volatile txData
    Address of remaining data to send.

volatile size_t txDataSize
    Size of the remaining data to send.

size_t txDataSizeAll
    Size of the data to send out.

uint8_t *volatile rxData
    Address of remaining data to receive.

volatile size_t rxDataSize
    Size of the remaining data to receive.

size_t rxDataSizeAll
    Size of the data to receive.

uint8_t *rxRingBuffer
    Start address of the receiver ring buffer.

size_t rxRingBufferSize
    Size of the ring buffer.

volatile uint16_t rxRingBufferHead
    Index for the driver to store received data into ring buffer.

volatile uint16_t rxRingBufferTail
    Index for the user to get data from the ring buffer.

usart_transfer_callback_t callback
    Callback function.

void *userData
    USART callback function parameter.

volatile uint8_t txState
    TX transfer state.

volatile uint8_t rxState
    RX transfer state.

uint8_t txWatermark
    txFIFO watermark.

uint8_t rxWatermark
    rxFIFO watermark.

union __unnamed10__
```

**Public Members**

```
uint8_t *data
    The buffer of data to be transfer.

uint8_t *rxData
    The buffer to receive data.

const uint8_t *txData
    The buffer of data to be sent.

union __unnamed14__
```

**Public Members**

`uint8_t *data`  
The buffer of data to be transfer.

`uint8_t *rxData`  
The buffer to receive data.

`const uint8_t *txData`  
The buffer of data to be sent.

## 2.30 WKT: Self-wake-up Timer

`void WKT_Init(WKT_Type *base, const wkt_config_t *config)`  
Ungates the WKT clock and configures the peripheral for basic operation.

---

**Note:** This API should be called at the beginning of the application using the WKT driver.

---

**Parameters**

- `base` – WKT peripheral base address
- `config` – Pointer to user's WKT config structure.

`void WKT_Deinit(WKT_Type *base)`  
Gate the WKT clock.

**Parameters**

- `base` – WKT peripheral base address

`static inline void WKT_GetDefaultConfig(wkt_config_t *config)`  
Initializes the WKT configuration structure.

This function initializes the WKT configuration structure to default values. The default values are as follows.

`config->clockSource = kWKT_DividedFROClockSource;`

**See also:**

`wkt_config_t`

**Parameters**

- `config` – Pointer to the WKT configuration structure.

`static inline uint32_t WKT_GetCounterValue(WKT_Type *base)`  
Read actual WKT counter value.

**Parameters**

- `base` – WKT peripheral base address

`static inline uint32_t WKT_GetStatusFlags(WKT_Type *base)`  
Gets the WKT status flags.

**Parameters**

- `base` – WKT peripheral base address

**Returns**

The status flags. This is the logical OR of members of the enumeration `wkt_status_flags_t`

static inline void WKT\_ClearStatusFlags(WKT\_Type \*base, uint32\_t mask)

Clears the WKT status flags.

**Parameters**

- `base` – WKT peripheral base address
- `mask` – The status flags to clear. This is a logical OR of members of the enumeration `wkt_status_flags_t`

static inline void WKT\_StartTimer(WKT\_Type \*base, uint32\_t count)

Starts the timer counting.

After calling this function, timer loads a count value, counts down to 0, then stops.

---

**Note:** User can call the utility macros provided in `fsl_common.h` to convert to ticks Do not write to Counter register while the counting is in progress

---

**Parameters**

- `base` – WKT peripheral base address.
- `count` – The value to be loaded into the WKT Count register

static inline void WKT\_StopTimer(WKT\_Type \*base)

Stops the timer counting.

This function Clears the counter and stops the timer from counting.

**Parameters**

- `base` – WKT peripheral base address

FSL\_WKT\_DRIVER\_VERSION

Version 2.0.2

enum `_wkt_clock_source`

Describes WKT clock source.

*Values:*

enumerator `kWKT_DividedFROClockSource`

WKT clock sourced from the divided FRO clock

enumerator `kWKT_LowPowerClockSource`

WKT clock sourced from the Low power clock Use this clock, LPOSCE bit of DPDCTRL register must be enabled

enumerator `kWKT_ExternalClockSource`

WKT clock sourced from the Low power clock Use this clock, WAKECLKPAD\_DISABLE bit of DPDCTRL register must be enabled

enum `_wkt_status_flags`

List of WKT flags.

*Values:*

enumerator `kWKT_AlarmFlag`

Alarm flag

```
typedef enum _wkt_clock_source wkt_clock_source_t
```

Describes WKT clock source.

```
typedef struct _wkt_config wkt_config_t
```

Describes WKT configuration structure.

```
typedef enum _wkt_status_flags wkt_status_flags_t
```

List of WKT flags.

```
struct _wkt_config
```

#include <fsl\_wkt.h> Describes WKT configuration structure.

### Public Members

*wkt\_clock\_source\_t* clockSource

External or internal clock source select

## 2.31 WWDT: Windowed Watchdog Timer Driver

```
void WWDT_GetDefaultConfig(wwdt_config_t *config)
```

Initializes WWDT configure structure.

This function initializes the WWDT configure structure to default value. The default value are:

```
config->enableWwdt = true;
config->enableWatchdogReset = false;
config->enableWatchdogProtect = false;
config->enableLockOscillator = false;
config->windowValue = 0xFFFFFFFU;
config->timeoutValue = 0xFFFFFFFU;
config->warningValue = 0;
```

### See also:

[wwdt\\_config\\_t](#)

### Parameters

- config – Pointer to WWDT config structure.

```
void WWDT_Init(WWDT_Type *base, const wwdt_config_t *config)
```

Initializes the WWDT.

This function initializes the WWDT. When called, the WWDT runs according to the configuration.

Example:

```
wwdt_config_t config;
WWDT_GetDefaultConfig(&config);
config.timeoutValue = 0x7fU;
WWDT_Init(wwdt_base,&config);
```

### Parameters

- base – WWDT peripheral base address
- config – The configuration of WWDT

```
void WWDT_Deinit(WWDT_Type *base)
```

Shuts down the WWDT.

This function shuts down the WWDT.

#### Parameters

- base – WWDT peripheral base address

```
static inline void WWDT_Enable(WWDT_Type *base)
```

Enables the WWDT module.

This function write value into WWDT\_MOD register to enable the WWDT, it is a write-once bit; once this bit is set to one and a watchdog feed is performed, the watchdog timer will run permanently.

#### Parameters

- base – WWDT peripheral base address

```
static inline void WWDT_Disable(WWDT_Type *base)
```

Disables the WWDT module.

#### *Deprecated:*

Do not use this function. It will be deleted in next release version, for once the bit field of WDEN written with a 1, it can not be re-written with a 0.

This function write value into WWDT\_MOD register to disable the WWDT.

#### Parameters

- base – WWDT peripheral base address

```
static inline uint32_t WWDT_GetStatusFlags(WWDT_Type *base)
```

Gets all WWDT status flags.

This function gets all status flags.

Example for getting Timeout Flag:

```
uint32_t status;  
status = WWDT_GetStatusFlags(wwdt_base) & kWWDT_TimeoutFlag;
```

#### Parameters

- base – WWDT peripheral base address

#### Returns

The status flags. This is the logical OR of members of the enumeration \_wwdt\_status\_flags\_t

```
void WWDT_ClearStatusFlags(WWDT_Type *base, uint32_t mask)
```

Clear WWDT flag.

This function clears WWDT status flag.

Example for clearing warning flag:

```
WWDT_ClearStatusFlags(wwdt_base, kWWDT_WarningFlag);
```

#### Parameters

- base – WWDT peripheral base address
- mask – The status flags to clear. This is a logical OR of members of the enumeration \_wwdt\_status\_flags\_t

static inline void WWDT\_SetWarningValue(WWDT\_Type \*base, uint32\_t warningValue)

Set the WWDT warning value.

The WDWARNINT register determines the watchdog timer counter value that will generate a watchdog interrupt. When the watchdog timer counter is no longer greater than the value defined by WARNINT, an interrupt will be generated after the subsequent WDCLK.

#### Parameters

- base – WWDT peripheral base address
- warningValue – WWDT warning value.

static inline void WWDT\_SetTimeoutValue(WWDT\_Type \*base, uint32\_t timeoutCount)

Set the WWDT timeout value.

This function sets the timeout value. Every time a feed sequence occurs the value in the TC register is loaded into the Watchdog timer. Writing a value below 0xFF will cause 0xFF to be loaded into the TC register. Thus the minimum time-out interval is TWCLK\*256\*4. If enableWatchdogProtect flag is true in `wwdt_config_t` config structure, any attempt to change the timeout value before the watchdog counter is below the warning and window values will cause a watchdog reset and set the WDTOF flag.

#### Parameters

- base – WWDT peripheral base address
- timeoutCount – WWDT timeout value, count of WWDT clock tick.

static inline void WWDT\_SetWindowValue(WWDT\_Type \*base, uint32\_t windowValue)

Sets the WWDT window value.

The WINDOW register determines the highest TV value allowed when a watchdog feed is performed. If a feed sequence occurs when timer value is greater than the value in WINDOW, a watchdog event will occur. To disable windowing, set windowValue to 0xFFFFFFF (maximum possible timer value) so windowing is not in effect.

#### Parameters

- base – WWDT peripheral base address
- windowValue – WWDT window value.

void WWDT\_Refresh(WWDT\_Type \*base)

Refreshes the WWDT timer.

This function feeds the WWDT. This function should be called before WWDT timer is in timeout. Otherwise, a reset is asserted.

#### Parameters

- base – WWDT peripheral base address

FSL\_WWDT\_DRIVER\_VERSION

Defines WWDT driver version.

WWDT\_FIRST\_WORD\_OF\_REFRESH

First word of refresh sequence

WWDT\_SECOND\_WORD\_OF\_REFRESH

Second word of refresh sequence

enum \_wwdt\_status\_flags\_t

WWDT status flags.

This structure contains the WWDT status flags for use in the WWDT functions.

*Values:*

enumerator kWWDT\_TimeoutFlag  
Time-out flag, set when the timer times out

enumerator kWWDT\_WarningFlag  
Warning interrupt flag, set when timer is below the value WDWARNINT

typedef struct \_wwdt\_config wwdt\_config\_t  
Describes WWDT configuration structure.

struct \_wwdt\_config  
*#include <fsl\_wwdt.h>* Describes WWDT configuration structure.

### Public Members

bool enableWwdt  
Enables or disables WWDT

bool enableWatchdogReset  
true: Watchdog timeout will cause a chip reset false: Watchdog timeout will not cause a chip reset

bool enableWatchdogProtect  
true: Enable watchdog protect i.e timeout value can only be changed after counter is below warning & window values false: Disable watchdog protect; timeout value can be changed at any time

bool enableLockOscillator  
true: Disabling or powering down the watchdog oscillator is prevented Once set, this bit can only be cleared by a reset false: Do not lock oscillator

uint32\_t windowValue  
Window value, set this to 0xFFFFFFF if windowing is not in effect

uint32\_t timeoutValue  
Timeout value

uint32\_t warningValue  
Watchdog time counter value that will generate a warning interrupt. Set this to 0 for no warning

uint32\_t clockFreq\_Hz  
Watchdog clock source frequency.

# Chapter 3

## Middleware

### 3.1 Motor Control

#### 3.1.1 FreeMASTER

*Communication Driver User Guide*

##### Introduction

**What is FreeMASTER?** FreeMASTER is a PC-based application developed by NXP for NXP customers. It is a versatile tool usable as a real-time monitor, visualization tool, and a graphical control panel of embedded applications based on the NXP processing units.

This document describes the embedded-side software driver which implements an interface between the application and the host PC. The interface covers the following communication:

- **Serial** UART communication either over plain RS232 interface or more typically over a USB-to-Serial either external or built in a debugger probe.
- **USB** direct connection to target microcontroller
- **CAN bus**
- **TCP/IP network** wired or WiFi
- **Segger J-Link RTT**
- **JTAG** debug port communication
- ...and all of the above also using a **Zephyr** generic drivers.

The driver also supports so-called “packet-driven BDM” interface which enables a protocol-based communication over a debugging port. The BDM stands for Background Debugging Module and its physical implementation is different on each platform. Some platforms leverage a semi-standard JTAG interface, other platforms provide a custom implementation called BDM. Regardless of the name, this debugging interface enables non-intrusive access to the memory space while the target CPU is running. For basic memory read and write operations, there is no communication driver required on the target when communicating with the host PC. Use this driver to get more advanced FreeMASTER protocol features over the BDM interface. The driver must be configured for the packet-driven BDM mode, in which the host PC uses the debugging interface to write serial command frames directly to the target memory buffer. The same method is then used to read response frames from that memory buffer.

Similar to “packet-driven BDM”, the FreeMASTER also supports a communication over [J-Link RTT]((<https://www.segger.com/products/debug-probes/j-link/technology/about-real-time-transfer/>)) interface defined by SEGGER Microcontroller GmbH for ARM CortexM-based microcontrollers. This method also uses JTAG physical interface and enables high-speed real time communication to run over the same channel as used for application debugging.

**Driver version 3** This document describes version 3 of the FreeMASTER Communication Driver. This version features the implementation of the new Serial Protocol, which significantly extends the features and security of its predecessor. The new protocol internal number is v4 and its specification is available in the documentation accompanying the driver code.

Driver V3 is deployed to modern 32-bit MCU platforms first, so the portfolio of supported platforms is smaller than for the previous V2 versions. It is recommended to keep using the V2 driver for legacy platforms, such as S08, S12, ColdFire, or Power Architecture. Reach out to [FreeMASTER community](#) or to the local NXP representative with requests for more information or to port the V3 driver to legacy MCU devices.

Thanks to a layered approach, the new driver simplifies the porting of the driver to new UART, CAN or networking communication interfaces significantly. Users are encouraged to port the driver to more NXP MCU platforms and contribute the code back to NXP for integration into future releases. Existing code and low-level driver layers may be used as an example when porting to new targets.

**Note:** Using the FreeMASTER tool and FreeMASTER Communication Driver is only allowed in systems based on NXP microcontroller or microprocessor unit. Use with non-NXP MCU platforms is **not permitted** by the license terms.

**Target platforms** The driver implementation uses the following abstraction mechanisms which simplify driver porting and supporting new communication modules:

- **General CPU Platform** (see source code in the `src/platforms` directory). The code in this layer is only specific to native data type sizes and CPU architectures (for example; alignment-aware memory copy routines). This driver version brings two generic implementations of 32-bit platforms supporting both little-endian and big-endian architectures. There are also implementations customized for the 56F800E family of digital signal controllers and S12Z MCUs. **Zephyr** is treated as a specific CPU platform as it brings unified user configuration (Kconfig) and generic hardware device drivers. With Zephyr, the transport layer and low-level communication layers described below are configured automatically using Kconfig and Device Tree technologies.
- **Transport Communication Layer** - The Serial, CAN, Networking, PD-BDM, and other methods of transport logic are implemented as a driver layer called `FMSTR_TRANSPORT` with a uniform API. A support of the Network transport also extends single-client modes of operation which are native for Serial, USB and CAN by a concept of multiple client sessions.
- **Low-level Communication Driver** - Each type of transport further defines a low-level API used to access the physical communication module. For example, the Serial transport defines a character-oriented API implemented by different serial communication modules like UART, LPUART, USART, and also USB-CDC. Similarly, the CAN transport defines a message-oriented API implemented by the FlexCAN or MCAN modules. Moreover, there are multiple different implementations for the same kind of communication peripherals. The difference between the implementation is in the way the low-level hardware registers are accessed. The `mcuxsdk` folder contains implementations which use MCUXpresso SDK drivers. These drivers should be used in applications based on the NXP MCUXpresso SDK. The “ampsdk” drivers target automotive-specific MCUs and their respective SDKs. The “dreg” implementations use a plain C-language access to hardware register addresses which makes it a universal and the most portable solution. In this case, users are encouraged to add more drivers for other communication modules or other respective SDKs and contribute the code back to NXP for integration.

The low-level drivers defined for the Networking transport enable datagram-oriented UDP and stream TCP communication. This implementation is demonstrated using the lwIP software stack but shall be portable to other TCP/IP stacks. It may sound surprisingly, but also the Segger J-Link RTT communication driver is linked to the Networking transport (RTT is stream oriented communication handled similarly to TCP).

**Replacing existing drivers** For all supported platforms, the driver described in this document replaces the V2 implementation and also older driver implementations that were available separately for individual platforms (PC Master SCI drivers).

**Clocks, pins, and peripheral initialization** The FreeMASTER communication driver is only responsible for runtime processing of the communication and must be integrated with an user application code to function properly. The user application code is responsible for general initialization of clock sources, pin multiplexers, and peripheral registers related to the communication speed. Such initialization should be done before calling the FMSTR\_Init function.

It is recommended to develop the user application using one of the Software Development Kits (SDKs) available from third parties or directly from NXP, such as MCUXpresso SDK, MCUXpresso IDE, and related tools. This approach simplifies the general configuration process significantly.

**MCUXpresso SDK** The MCUXpresso SDK is a software package provided by NXP which contains the device initialization code, linker files, and software drivers with example applications for the NXP family of MCUs. The MCUXpresso Config Tools may be used to generate the clock-setup and pin-multiplexer setup code suitable for the selected processor.

The MCUXpresso SDK also contains this FreeMASTER communication driver as a “middleware” component which may be downloaded along with the example applications from <https://mcuxpresso.nxp.com/en/welcome>.

**MCUXpresso SDK on GitHub** The FreeMASTER communication driver is also released as one of the middleware components of the MCUXpresso SDK on the GitHub. This release enables direct integration of the FreeMASTER source code Git repository into a target applications including Zephyr applications.

Related links:

- [The official FreeMASTER middleware repository](#).
- [Online version of this document](#)

**FreeMASTER in Zephyr** The FreeMASTER middleware repository can be used with MCUXpresso SDK as well as a Zephyr module. Zephyr-specific samples which include examples of Kconfig and Device Tree configurations for Serial, USB and Network communications are available in separate repository. West manifest in this sample repository fetches the full Zephyr package including the FreeMASTER middleware repository used as a Zephyr module.

## Example applications

**MCUX SDK Example applications** There are several example applications available for each supported MCU platform.

- **fmstr\_uart** demonstrates a plain serial transmission, typically connecting to a computer’s physical or virtual COM port. The typical transmission speed is 115200 bps.

- **fmstr\_can** demonstrates CAN bus communication. This requires a suitable CAN interface connected to the computer and interconnected with the target MCU using a properly terminated CAN bus. The typical transmission speed is 500 kbps. A FreeMASTER-over-CAN communication plug-in must be used.
- **fmstr\_usb\_cdc** uses an on-chip USB controller to implement a CDC communication class. It is connected directly to a computer's USB port and creates a virtual COM port device. The typical transmission speed is above 1 Mbps.
- **fmstr\_net** demonstrates the Network communication over UDP or TCP protocol. Existing examples use lwIP stack to implement the communication, but in general, it shall be possible to use any other TCP/IP stack to achieve the same functionality.
- **fmstr\_wifi** is the fmstr\_net application modified to use a WiFi network interface instead of a wired Ethernet connection.
- **fmstr\_rtt** demonstrates the communication over SEGGER J-Link RTT interface. Both fmstr\_net and fmstr\_rtt examples require the FreeMASTER TCP/UDP communication plug-in to be used on the PC host side.
- **fmstr\_eonce** uses the real-time data unit on the JTAG EOnCE module of the 56F800E family to implement pseudo-serial communication over the JTAG port. The typical transmission speed is around 10 kbps. This communication requires FreeMASTER JTAG/EOnCE communication plug-in.
- **fmstr\_pdbdm** uses JTAG or BDM debugging interface to access the target RAM directly while the CPU is running. Note that such approach can be used with any MCU application, even without any special driver code. The computer reads from and writes into the RAM directly without CPU intervention. The Packet-Driven BDM (PD-BDM) communication uses the same memory access to exchange command and response frames. With PD-BDM, the FreeMASTER tool is able to go beyond basic memory read/write operations and accesses also advanced features like Recorder, TSA, or Pipes. The typical transmission speed is around 10 kbps. A PD-BDM communication plug-in must be used in FreeMASTER and configured properly for the selected debugging interface. Note that this communication cannot be used while a debugging interface is used by a debugger session.
- **fmstr\_any** is a special example application which demonstrates how the NXP MCUXpresso Config Tools can be used to configure pins, clocks, peripherals, interrupts, and even the FreeMASTER “middleware” driver features in a graphical and user friendly way. The user can switch between the Serial, CAN, and other ways of communication and generate the required initialization code automatically.

**Zephyr sample applications** Zephyr sample applications demonstrate Kconfig and Device Tree configuration which configure the FreeMASTER middleware module for a selected communication option (Serial, CAN, Network or RTT).

Refer to *readme.md* files in each sample directory for description of configuration options required to implement FreeMASTER connectivity.

## Description

This section shows how to add the FreeMASTER Communication Driver into application and how to configure the connection to the FreeMASTER visualization tool.

**Features** The FreeMASTER driver implements the FreeMASTER protocol V4 and provides the following features which may be accessed using the FreeMASTER visualization tool:

- Read/write access to any memory location on the target.
- Optional password protection of the read, read/write, and read/write/flash access levels.

- Atomic bit manipulation on the target memory (bit-wise write access).
- Optimal size-aligned access to memory which is also suitable to access the peripheral register space.
- Oscilloscope access—real-time access to target variables. The sample rate may be limited by the communication speed.
- Recorder— access to the fast transient recorder running on the board as a part of the FreeMASTER driver. The sample rate is only limited by the MCU CPU speed. The length of the data recorded depends on the amount of available memory.
- Multiple instances of Oscilloscopes and Recorders without the limitation of maximum number of variables.
- Application commands—high-level message delivery from the PC to the application.
- TSA tables—describing the data types, variables, files, or hyperlinks exported by the target application. The TSA newly supports also non-memory mapped resources like external EEPROM or SD Card files.
- Pipes—enabling the buffered stream-oriented data exchange for a general-purpose terminal-like communication, diagnostic data streaming, or other data exchange.

The FreeMASTER driver features:

- Full FreeMASTER protocol V4 implementation with a new V4 style of CRC used.
- Layered approach supporting Serial, CAN, Network, PD-BDM, and other transports.
- Layered low-level Serial transport driver architecture enabling to select UART, LPUART, USART, and other physical implementations of serial interfaces, including USB-CDC.
- Layered low-level CAN transport driver architecture enabling to select FlexCAN, msCAN, MCAN, and other physical implementations of the CAN interface.
- Layered low-level Networking transport enabling to select TCP, UDP or J-Link RTT communication.
- TSA support to write-protect memory regions or individual variables and to deny the access to the unsafe memory.
- The pipe callback handlers are invoked whenever new data is available for reading from the pipe.
- Two Serial Single-Wire modes of operation are enabled. The “external” mode has the RX and TX shorted on-board. The “true” single-wire mode interconnects internally when the MCU or UART modules support it.

The following sections briefly describe all FreeMASTER features implemented by the driver. See the PC-based FreeMASTER User Manual for more details on how to use the features to monitor, tune, or control an embedded application.

**Board Detection** The FreeMASTER protocol V4 defines the standard set of configuration values which the host PC tool reads to identify the target and to access other target resources properly. The configuration includes the following parameters:

- Version of the driver and the version of the protocol implemented.
- MTU as the Maximum size of the Transmission Unit (for example; communication buffer size).
- Application name, description, and version strings.
- Application build date and time as a string.
- Target processor byte ordering (little/big endian).
- Protection level that requires password authentication.

- Number of the Recorder and Oscilloscope instances.
- RAM Base Address for optimized memory access commands.

**Memory Read** This basic feature enables the host PC to read any data memory location by specifying the address and size of the required memory area. The device response frame must be shorter than the MTU to fit into the outgoing communication buffer. To read a device memory of any size, the host uses the information retrieved during the Board Detection and splits the large-block request to multiple partial requests.

The driver uses size-aligned operations to read the target memory (for example; uses proper read-word instruction when an address is aligned to 4 bytes).

**Memory Write** Similarly to the Memory Read operation, the Memory Write feature enables to write to any RAM memory location on the target device. A single write command frame must be shorter than the MTU to fit into the target communication buffer. Larger requests must be split into smaller ones.

The driver uses size-aligned operations to write to the target memory (for example; uses proper write-word instruction when an address is aligned to 4 bytes).

**Masked Memory Write** To implement the write access to a single bit or a group of bits of target variables, the Masked Memory Write feature is available in the FreeMASTER protocol and it is supported by the driver using the Read-Modify-Write approach.

Be careful when writing to bit fields of volatile variables that are also modified in an application interrupt. The interrupt may be serviced in the middle of a read-modify-write operation and it may cause data corruption.

**Oscilloscope** The protocol and driver enables any number of variables to be read at once with a single request from the host. This feature is called Oscilloscope and the FreeMASTER tool uses it to display a real-time graph of variable values.

The driver can be configured to support any number of Oscilloscope instances and enable simultaneously running graphs to be displayed on the host computer screen.

**Recorder** The protocol enables the host to select target variables whose values are then periodically recorded into a dedicated on-board memory buffer. After such data sampling stops (either on a host request or by evaluating a threshold-crossing condition), the data buffer is downloaded to the host and displayed as a graph. The data sampling rate is not limited by the speed of the communication line, so it enables displaying the variable transitions in a very high resolution.

The driver can be configured to support multiple Recorder instances and enable multiple recorder graphs to be displayed on the host screen. Having multiple recorders also enables setting the recording point differently for each instance. For example; one instance may be recording data in a general timer interrupt while another instance may record at a specific control algorithm time in the PWM interrupt.

**TSA** With the TSA feature, data types and variables can be described directly in the application source code. Such information is later provided to the FreeMASTER tool which may use it instead of reading symbol data from the application ELF executable file.

The information is encoded as so-called TSA tables which become direct part of the application code. The TSA tables contain descriptors of variables that shall be visible to the host tool. The descriptors can describe the memory areas by specifying the address and size of the memory

block or more conveniently using the C variable names directly. Different set of TSA descriptors can be used to encode information about the structure types, unions, enumerations, or arrays.

The driver also supports special types of TSA table entries to describe user resources like external EEPROM and SD Card files, memory-mapped files, virtual directories, web URL hyperlinks, and constant enumerations.

**TSA Safety** When the TSA is enabled in the application, the TSA Safety can be enabled and validate the memory accesses directly by the embedded-side driver. When the TSA Safety is turned on, any memory request received from the host is validated and accepted only if it belongs to a TSA-described object. The TSA entries can be declared as Read-Write or Read-Only so that the driver can actively deny the write access to the Read-Only objects.

**Application commands** The Application Commands are high-level messages that can be delivered from the PC Host to the embedded application for further processing. The embedded application can either poll the status, or be called back when a new Application Command arrives to be processed. After the embedded application acknowledges that the command is handled, the host receives the Result Code and reads the other return data from memory. Both the Application Commands and the Result Codes are specific to a given application and it is user's responsibility to define them. The FreeMASTER protocol and the FreeMASTER driver only implement the delivery channel and a set of API calls to enable the Application Command processing in general.

**Pipes** The Pipes enable buffered and stream-oriented data exchange between the PC Host and the target application. Any pipe can be written to and read from at both ends (either on the PC or the MCU). The data transmission is acknowledged using the special FreeMASTER protocol commands. It is guaranteed that the data bytes are delivered from the writer to the reader in a proper order and without losses.

**Serial single-wire operation** The MCU Serial Communication Driver natively supports normal dual-wire operation. Because the protocol is half-duplex only, the driver can also operate in two single-wire modes:

- “External” single-wire operation where the Receiver and Transmitter pins are shorted on the board. This mode is supported by default in the MCU driver because the Receiver and Transmitter units are enabled or disabled whenever needed. It is also easy to extend this operation for the RS485 communication.
- “True” single-wire mode which uses only a single pin and the direction switching is made by the UART module. This mode of operation must be enabled by defining the FM-STR\_SERIAL\_SINGLEWIRE configuration option.

**Multi-session support** With networking interface it is possible for multiple clients to access the target MCU simultaneously. Reading and writing of target memory is processed atomically so there is no risk of data corruption. The state-full resources such as Recorders or Oscilloscopes are locked to a client session upon first use and access is denied to other clients until lock is released..

## Zephyr-specific

**Dedicated communication task** FreeMASTER communication may run isolated in a dedicated task. The task automates the FMSTR\_Init and FMSTR\_Poll calls together with periodic activities enabling the FreeMASTER UI to fetch information about tasks and CPU utilization. The task can be started automatically or manually, and it must be assigned a priority to be able to react on interrupts and other communication events. Refer to Zephyr FreeMASTER sample applications which all use this communication task.

**Zephyr shell and logging over FreeMASTER pipe** FreeMASTER implements a shell backend which may use FreeMASTER pipe as a I/O terminal and logging output. Refer to Zephyr FreeMASTER sample applications which all use this feature.

**Automatic TSA tables** TSA tables can be declared as “automatic” in Zephyr which make them automatically registered in the table list. This may be very useful when there are many TSA tables or when the tables are defined in different (often unrelated) libraries linked together. In this case user does not need to build a list of all tables manually.

**Driver files** The driver source files can be found in a top-level src folder, further divided into the sub-folders:

- **src/platforms** platform-specific folder—one folder exists for each supported processor platform (for example; 32-bit Little Endian platform). Each such folder contains a platform header file with data types and a code which implements the potentially platform-specific operations, such as aligned memory access.
- **src/common** folder—contains the common driver source files shared by the driver for all supported platforms. All the .c files must be added to the project, compiled, and linked together with the application.
  - *freemaster.h* - master driver header file, which declares the common data types, macros, and prototypes of the FreeMASTER driver API functions.
  - *freemaster\_cfg.h.example* - this file can serve as an example of the FreeMASTER driver configuration file. Save this file into a project source code folder and rename it to *freemaster\_cfg.h*. The FreeMASTER driver code includes this file to get the project-specific configuration options and to optimize the compilation of the driver.
  - *freemaster\_defcfg.h* - defines the default values for each FreeMASTER configuration option if the option is not set in the *freemaster\_cfg.h* file.
  - *freemaster\_protocol.h* - defines the FreeMASTER protocol constants used internally by the driver.
  - *freemaster\_protocol.c* - implements the FreeMASTER protocol decoder and handles the basic Get Configuration Value, Memory Read, and Memory Write commands.
  - *freemaster\_rec.c* - handles the Recorder-specific commands and implements the Recorder sampling and triggering routines. When the Recorder is disabled by the FreeMASTER driver configuration file, this file only compiles to empty API functions.
  - *freemaster\_scope.c* - handles the Oscilloscope-specific commands. If the Oscilloscope is disabled by the FreeMASTER driver configuration file, this file compiles as void.
  - *freemaster\_pipes.c* - implements the Pipes functionality when the Pipes feature is enabled.
  - *freemaster\_appcmd.c* - handles the communication commands used to deliver and execute the Application Commands within the context of the embedded application. When the Application Commands are disabled by the FreeMASTER driver configuration file, this file only compiles to empty API functions.

- *freemaster\_tsa.c* - handles the commands specific to the TSA feature. This feature enables the FreeMASTER host tool to obtain the TSA memory descriptors declared in the embedded application. If the TSA is disabled by the FreeMASTER driver configuration file, this file compiles as void.
- *freemaster\_tsa.h* - contains the declaration of the macros used to define the TSA memory descriptors. This file is indirectly included into the user application code (via *freemaster.h*).
- *freemaster\_sha.c* - implements the SHA-1 hash code used in the password authentication algorithm.
- *freemaster\_private.h* - contains the declarations of functions and data types used internally in the driver. It also contains the C pre-processor statements to perform the compile-time verification of the user configuration provided in the *freemaster\_cfg.h* file.
- *freemaster\_serial.c* - implements the serial protocol logic including the CRC, FIFO queuing, and other communication-related operations. This code calls the functions of the low-level communication driver indirectly via a character-oriented API exported by the specific low-level driver.
- *freemaster\_serial.h* - defines the low-level character-oriented Serial API.
- *freemaster\_can.c* - implements the CAN protocol logic including the CAN message preparation, signalling using the first data byte in the CAN frame, and other communication-related operations. This code calls the functions of the low-level communication driver indirectly via a message-oriented API exported by the specific low-level driver.
- *freemaster\_can.h* - defines the low-level message-oriented CAN API.
- *freemaster\_net.c* - implements the Network protocol transport logic including multiple session management code.
- *freemaster\_net.h* - definitions related to the Network transport.
- *freemaster\_pdbdm.c* - implements the packet-driven BDM communication buffer and other communication-related operations.
- *freemaster\_utils.c* - aligned memory copy routines, circular buffer management and other utility functions
- *freemaster\_utils.h* - definitions related to utility code.
- ***src/drivers/[sdk]/serial*** - contains the code related to the serial communication implemented using one of the supported SDK frameworks.
  - *freemaster\_serial\_XXX.c* and *.h* - implement low-level access to the communication peripheral registers. Different files exist for the UART, LPUART, USART, and other kinds of Serial communication modules.
- ***src/drivers/[sdk]/can*** - contains the code related to the serial communication implemented using one of the supported SDK frameworks.
  - *freemaster\_XXX.c* and *.h* - implement low-level access to the communication peripheral registers. Different files exist for the FlexCAN, msCAN, MCAN, and other kinds of CAN communication modules.
- ***src/drivers/[sdk]/network*** - contains low-level code adapting the FreeMASTER Network transport to an underlying TCP/IP or RTT stack.
  - *freemaster\_net\_lwip\_tcp.c* and *\_udp.c* - default networking implementation of TCP and UDP transports using lwIP stack.
  - *freemaster\_net\_segger\_rtt.c* - implementation of network transport using Segger J-Link RTT interface

**Driver configuration** The driver is configured using a single header file (*freemaster\_cfg.h*). Create this file and save it together with other project source files before compiling the driver code. All FreeMASTER driver source files include the *freemaster\_cfg.h* file and use the macros defined here for the conditional and parameterized compilation. The C compiler must locate the configuration file when compiling the driver files. Typically, it can be achieved by putting this file into a folder where the other project-specific included files are stored.

As a starting point to create the configuration file, get the *freemaster\_cfg.h.example* file, rename it to *freemaster\_cfg.h*, and save it into the project area.

**Note:** It is NOT recommended to leave the *freemaster\_cfg.h* file in the FreeMASTER driver source code folder. The configuration file must be placed at a project-specific location, so that it does not affect the other applications that use the same driver.

**Configurable items** This section describes the configuration options which can be defined in *freemaster\_cfg.h*.

### Interrupt modes

```
#define FMSTR_LONG_INTR [0|1]
#define FMSTR_SHORT_INTR [0|1]
#define FMSTR_POLL_DRIVEN [0|1]
```

**Value Type** boolean (0 or 1)

**Description** Exactly one of the three macros must be defined to non-zero. The others must be defined to zero or left undefined. The non-zero-defined constant selects the interrupt mode of the driver. See [Driver interrupt modes](#).

- FMSTR\_LONG\_INTR — long interrupt mode
- FMSTR\_SHORT\_INTR — short interrupt mode
- FMSTR\_POLL\_DRIVEN — poll-driven mode

**Note:** Some options may not be supported by all communication interfaces. For example, the FMSTR\_SHORT\_INTR option is not supported by the USB\_CDC interface.

### Protocol transport

```
#define FMSTR_TRANSPORT [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER source code. Specify one of existing instances to make use of the protocol transport.

**Description** Use one of the pre-defined constants, as implemented by the FreeMASTER code. The current driver supports the following transports:

- FMSTR\_SERIAL - serial communication protocol
- FMSTR\_CAN - using CAN communication
- FMSTR\_PDBDM - using packet-driven BDM communication
- FMSTR\_NET - network communication using TCP or UDP protocol

**Serial transport** This section describes configuration parameters used when serial transport is used:

```
#define FMSTR_TRANSPORT FMSTR_SERIAL
```

**FMSTR\_SERIAL\_DRV** Select what low-level driver interface will be used when implementing the Serial communication.

```
#define FMSTR_SERIAL_DRV [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing serial driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/serial* implementation):

- **FMSTR\_SERIAL\_MCUX\_UART** - UART driver
- **FMSTR\_SERIAL\_MCUX\_LPUART** - LPUART driver
- **FMSTR\_SERIAL\_MCUX\_USART** - USART driver
- **FMSTR\_SERIAL\_MCUX\_MINIUSART** - miniUSART driver
- **FMSTR\_SERIAL\_MCUX\_QSCI** - DSC QSCI driver
- **FMSTR\_SERIAL\_MCUX\_USB** - USB/CDC class driver (also see code in the */support/mcuxsdk\_usb* folder)
- **FMSTR\_SERIAL\_56F800E\_EONCE** - DSC JTAG EOnCE driver

Other SDKs or BSPs may define custom low-level driver interface structure which may be used as FMSTR\_SERIAL\_DRV. For example:

- **FMSTR\_SERIAL\_DREG\_UART** - demonstrates the low-level interface implemented without the MCUXpresso SDK and using direct access to peripheral registers.

### FMSTR\_SERIAL\_BASE

```
#define FMSTR_SERIAL_BASE [address|symbol]
```

**Value Type** Optional address value (numeric or symbolic)

**Description** Specify the base address of the UART, LPUART, USART, or other serial peripheral module to be used for the communication. This value is not defined by default. User application should call FMSTR\_SetSerialBaseAddress() to select the peripheral module.

### FMSTR\_COMM\_BUFFER\_SIZE

```
#define FMSTR_COMM_BUFFER_SIZE [number]
```

**Value Type** 0 or a value in range 32...255

**Description** Specify the size of the communication buffer to be allocated by the driver. Default value, which suits all driver features, is used when this option is defined as 0.

**FMSTR\_COMM\_RQUEUE\_SIZE**

```
#define FMSTR_COMM_RQUEUE_SIZE [number]
```

**Value Type** Value in range 0...255

**Description** Specify the size of the FIFO receiver queue used to quickly receive and store characters in the FMSTR\_SHORT\_INTR interrupt mode.  
The default value is 32 B.

**FMSTR\_SERIAL\_SINGLEWIRE**

```
#define FMSTR_SERIAL_SINGLEWIRE [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Set to non-zero to enable the “True” single-wire mode which uses a single MCU pin to communicate. The low-level driver enables the pin direction switching when the MCU peripheral supports it.

**CAN Bus transport** This section describes configuration parameters used when CAN transport is used:

```
#define FMSTR_TRANSPORT FMSTR_CAN
```

**FMSTR\_CAN\_DRV** Select what low-level driver interface will be used when implementing the CAN communication.

```
#define FMSTR_CAN_DRV [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing CAN driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/can implementation*):

- **FMSTR\_CAN\_MCUX\_FLEXCAN** - FlexCAN driver
- **FMSTR\_CAN\_MCUX\_MCAN** - MCAN driver
- **FMSTR\_CAN\_MCUX\_MSCAN** - msCAN driver
- **FMSTR\_CAN\_MCUX\_DSCFLEXCAN** - DSC FlexCAN driver
- **FMSTR\_CAN\_MCUX\_DSCMSCAN** - DSC msCAN driver

Other SDKs or BSPs may define the custom low-level driver interface structure which may be used as FMSTR\_CAN\_DRV.

**FMSTR\_CAN\_BASE**

```
#define FMSTR_CAN_BASE [address|symbol]
```

**Value Type** Optional address value (numeric or symbolic)

**Description** Specify the base address of the FlexCAN, msCAN, or other CAN peripheral module to be used for the communication. This value is not defined by default. User application should call FMSTR\_SetCanBaseAddress() to select the peripheral module.

#### FMSTR\_CAN\_CMDID

```
#define FMSTR_CAN_CMDID [number]
```

**Value Type** CAN identifier (11-bit or 29-bit number)

**Description** CAN message identifier used for FreeMASTER commands (direction from PC Host tool to target application). When declaring 29-bit identifier, combine the numeric value with FMSTR\_CAN\_EXTID bit. Default value is 0x7AA.

#### FMSTR\_CAN\_RSPID

```
#define FMSTR_CAN_RSPID [number]
```

**Value Type** CAN identifier (11-bit or 29-bit number)

**Description** CAN message identifier used for responding messages (direction from target application to PC Host tool). When declaring 29-bit identifier, combine the numeric value with FMSTR\_CAN\_EXTID bit. Note that both *CMDID* and *RSPID* values may be the same. Default value is 0x7AA.

#### FMSTR\_FLEXCAN\_TXMB

```
#define FMSTR_FLEXCAN_TXMB [number]
```

**Value Type** Number in range of 0..N where N is number of CAN message-buffers supported by HW module.

**Description** Only used when the FlexCAN low-level driver is used. Define the FlexCAN message buffer for CAN frame transmission. Default value is 0.

#### FMSTR\_FLEXCAN\_RXMB

```
#define FMSTR_FLEXCAN_RXMB [number]
```

**Value Type** Number in range of 0..N where N is number of CAN message-buffers supported by HW module.

**Description** Only used when the FlexCAN low-level driver is used. Define the FlexCAN message buffer for CAN frame reception. Note that the FreeMASTER driver may also operate with a common message buffer used by both TX and RX directions. Default value is 1.

**Network transport** This section describes configuration parameters used when Network transport is used:

```
#define FMSTR_TRANSPORT FMSTR_NET
```

**FMSTR\_NET\_DRV** Select network interface implementation.

```
#define FMSTR_NET_DRV [identifier]
```

**Value Type** Identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing NET driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/network implementation*):

- **FMSTR\_NET\_LWIP\_TCP** - TCP communication using lwIP stack
- **FMSTR\_NET\_LWIP\_UDP** - UDP communication using lwIP stack
- **FMSTR\_NET\_SEGGER\_RTT** - Communication using SEGGER J-Link RTT interface

Other SDKs or BSPs may define the custom networking interface which may be used as FMSTR\_CAN\_DRV.

Add another row below:

**FMSTR\_NET\_PORT**

```
#define FMSTR_NET_PORT [number]
```

**Value Type** TCP or UDP port number (short integer)

**Description** Specifies the server port number used by TCP or UDP protocols.

**FMSTR\_NET\_BLOCKING\_TIMEOUT**

```
#define FMSTR_NET_BLOCKING_TIMEOUT [number]
```

**Value Type** Timeout as number of milliseconds

**Description** This value specifies a timeout in milliseconds for which the network socket operations may block the execution inside *FMSTR\_Poll*. This may be set high (e.g. 250) when a dedicated RTOS task is used to handle FreeMASTER protocol polling. Set to a lower value when the polling task is also responsible for other operations. Set to 0 to attempt to use non-blocking socket operations.

**FMSTR\_NET\_AUTODISCOVERY**

```
#define FMSTR_NET_AUTODISCOVERY [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** This option enables the FreeMASTER driver to use a separate UDP socket to broadcast auto-discovery messages to network. This helps the FreeMASTER tool to discover the target device address, port and protocol options.

**Debugging options****FMSTR\_DISABLE**

```
#define FMSTR_DISABLE [0|1]
```

**Value Type** boolean (0 or 1)

**Description** Define as non-zero to disable all FreeMASTER features, exclude the driver code from build, and compile all its API functions empty. This may be useful to remove FreeMASTER without modifying any application source code. Default value is 0 (false).

**FMSTR\_DEBUG\_TX**

```
#define FMSTR_DEBUG_TX [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to enable the driver to periodically transmit test frames out on the selected communication interface (SCI or CAN). With the debug transmission enabled, it is simpler to detect problems in the baudrate or other communication configuration settings.

The test frames are transmitted until the first valid command frame is received from the PC Host tool. The test frame is a valid error status frame, as defined by the protocol format. On the serial line, the test frame consists of three printable characters (+©W) which are easy to capture using the serial terminal tools.

This feature requires the FMSTR\_Poll() function to be called periodically. Default value is 0 (false).

**FMSTR\_APPLICATION\_STR**

```
#define FMSTR_APPLICATION_STR
```

**Value Type** String.

**Description** Name of the application visible in FreeMASTER host application.

**Memory access**

### FMSTR\_USE\_READMEM

```
#define FMSTR_USE_READMEM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Memory Read command and enable FreeMASTER to have read access to memory and variables. The access can be further restricted by using a TSA feature.  
Default value is 1 (true).

### FMSTR\_USE\_WRITEMEM

```
#define FMSTR_USE_WRITEMEM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Memory Write command.  
The default value is 1 (true).

## Oscilloscope options

### FMSTR\_USE\_SCOPE

```
#define FMSTR_USE_SCOPE [number]
```

**Value Type** Integer number.

**Description** Number of Oscilloscope instances to be supported. Set to 0 to disable the Oscilloscope feature.  
Default value is 0.

### FMSTR\_MAX\_SCOPE\_VARS

```
#define FMSTR_MAX_SCOPE_VARS [number]
```

**Value Type** Integer number larger than 2.

**Description** Number of variables to be supported by each Oscilloscope instance.  
Default value is 8.

## Recorder options

### FMSTR\_USE\_RECORDER

```
#define FMSTR_USE_RECORDER [number]
```

**Value Type** Integer number.

**Description** Number of Recorder instances to be supported. Set to 0 to disable the Recorder feature.

Default value is 0.

#### FMSTR\_REC\_BUFF\_SIZE

```
#define FMSTR_REC_BUFF_SIZE [number]
```

**Value Type** Integer number larger than 2.

**Description** Defines the size of the memory buffer used by the Recorder instance #0. Default: not defined, user shall call 'FMSTRRecorderCreate()' API function to specify this parameter in run time.

#### FMSTR\_REC\_TIMEBASE

```
#define FMSTR_REC_TIMEBASE [time specification]
```

**Value Type** Number (nanoseconds time).

**Description** Defines the base sampling rate in nanoseconds (sampling speed) Recorder instance #0.

Use one of the following macros:

- FMSTR\_REC\_BASE\_SECONDS(x)
- FMSTR\_REC\_BASE\_MILLISEC(x)
- FMSTR\_REC\_BASE\_MICROSEC(x)
- FMSTR\_REC\_BASE\_NANOSEC(x)

Default: not defined, user shall call 'FMSTRRecorderCreate()' API function to specify this parameter in run time.

#### FMSTR\_REC\_FLOAT\_TRIG

```
#define FMSTR_REC_FLOAT_TRIG [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the floating-point triggering. Be aware that floating-point triggering may grow the code size by linking the floating-point standard library.

Default value is 0 (false).

### Application Commands options

**FMSTR\_USE\_APPCMD**

```
#define FMSTR_USE_APPCMD [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Application Commands feature. Default value is 0 (false).

**FMSTR\_APPCMD\_BUFF\_SIZE**

```
#define FMSTR_APPCMD_BUFF_SIZE [size]
```

**Value Type** Numeric buffer size in range 1..255

**Description** The size of the Application Command data buffer allocated by the driver. The buffer stores the (optional) parameters of the Application Command which waits to be processed.

**FMSTR\_MAX\_APPCMD\_CALLS**

```
#define FMSTR_MAX_APPCMD_CALLS [number]
```

**Value Type** Number in range 0..255

**Description** The number of different Application Commands that can be assigned a callback handler function using FMSTR\_RegisterAppCmdCall(). Default value is 0.

**TSA options****FMSTR\_USE\_TSA**

```
#define FMSTR_USE_TSA [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the FreeMASTER TSA feature to be used. With this option enabled, the TSA tables defined in the applications are made available to the FreeMASTER host tool. Default value is 0 (false).

**FMSTR\_USE\_TSA\_SAFETY**

```
#define FMSTR_USE_TSA_SAFETY [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the memory access validation in the FreeMASTER driver. With this option, the host tool is not able to access the memory which is not described by at least one TSA descriptor. Also a write access is denied for objects defined as read-only in TSA tables. Default value is 0 (false).

#### FMSTR\_USE\_TSA\_INROM

```
#define FMSTR_USE_TSA_INROM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Declare all TSA descriptors as *const*, which enables the linker to put the data into the flash memory. The actual result depends on linker settings or the linker commands used in the project.

Default value is 0 (false).

#### FMSTR\_USE\_TSA\_DYNAMIC

```
#define FMSTR_USE_TSA_DYNAMIC [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable runtime-defined TSA entries to be added to the TSA table by the FMSTR\_SetUpTsaBuff() and FMSTR\_TsaAddVar() functions.

Default value is 0 (false).

### Pipes options

#### FMSTR\_USE\_PIPES

```
#define FMSTR_USE_PIPES [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the FreeMASTER Pipes feature to be used.

Default value is 0 (false).

#### FMSTR\_MAX\_PIPES\_COUNT

```
#define FMSTR_MAX_PIPES_COUNT [number]
```

**Value Type** Number in range 1..63.

**Description** The number of simultaneous pipe connections to support. The default value is 1.

**Driver interrupt modes** To implement the communication, the FreeMASTER driver handles the Serial or CAN module's receive and transmit requests. Use the *freemaster\_cfg.h* configuration file to select whether the driver processes the communication automatically in the interrupt service routine handler or if it only polls the status of the module (typically during the application idle time).

This section describes each of the interrupt mode in more details.

### Completely Interrupt-Driven operation Activated using:

```
#define FMSTR_LONG_INTR 1
```

In this mode, both the communication and the FreeMASTER protocol decoding is done in the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, or other interrupt service routine. Because the protocol execution may be a lengthy task (especially with the TSA-Safety enabled) it is recommended to use this mode only if the interrupt prioritization scheme is possible in the application and the FreeMASTER interrupt is assigned to a lower (the lowest) priority.

In this mode, the application code must register its own interrupt handler for all interrupt vectors related to the selected communication interface and call the *FMSTR\_SerialIsr* or *FMSTR\_CanIsr* functions from that handler.

### Mixed Interrupt and Polling Modes Activated using:

```
#define FMSTR_SHORT_INTR 1
```

In this mode, the communication processing time is split between the interrupt routine and the main application loop or task. The raw communication is handled by the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, or other interrupt service routine, while the protocol decoding and execution is handled by the *FMSTR\_Poll* routine. Call *FMSTR\_Poll* during the idle time in the application main loop.

The interrupt processing in this mode is relatively fast and deterministic. Upon a serial-receive event, the received character is only placed into a FIFO-like queue and it is not further processed. Upon a CAN receive event, the received frame is stored into a receive buffer. When transmitting, the characters are fetched from the prepared transmit buffer.

In this mode, the application code must register its own interrupt handler for all interrupt vectors related to the selected communication interface and call the *FMSTR\_SerialIsr* or *FMSTR\_CanIsr* functions from that handler.

When the serial interface is used as the serial communication interface, ensure that the *FMSTR\_Poll* function is called at least once per *N* character time periods. *N* is the length of the FreeMASTER FIFO queue (*FMSTR\_COMM\_RQUEUE\_SIZE*) and the character time is the time needed to transmit or receive a single byte over the SCI line.

### Completely Poll-driven

```
#define FMSTR_POLL_DRIVEN 1
```

In this mode, both the communication and the FreeMASTER protocol decoding are done in the *FMSTR\_Poll* routine. No interrupts are needed and the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, and similar handlers compile to an empty code.

When using this mode, ensure that the *FMSTR\_Poll* function is called by the application at least once per the serial “character time” which is the time needed to transmit or receive a single character.

In the latter two modes (*FMSTR\_SHORT\_INTR* and *FMSTR\_POLL\_DRIVEN*), the protocol handling takes place in the *FMSTR\_Poll* routine. An application interrupt can occur in the middle of the

Read Memory or Write Memory commands' execution and corrupt the variable being accessed by the FreeMASTER driver. In these two modes, some issues or glitches may occur when using FreeMASTER to visualize or monitor volatile variables modified in interrupt servicing code.

The same issue may appear even in the full interrupt mode (FMSTR\_LONG\_INTR), if volatile variables are modified in the interrupt code with a priority higher than the priority of the communication interrupt.

**Data types** Simple portability was one of the main requirements when writing the FreeMASTER driver. This is why the driver code uses the privately-declared data types and the vast majority of the platform-dependent code is separated in the platform-dependent source files. The data types used in the driver API are all defined in the platform-specific header file.

To prevent name conflicts with the symbols used in the application, all data types, macros, and functions have the FMSTR\_ prefix. The only global variables used in the driver are the transport and low-level API structures exported from the driver-implementation layer to upper layers. Other than that, all private variables are declared as static and named using the fmstr\_ prefix.

**Communication interface initialization** The FreeMASTER driver does not perform neither the initialization nor the configuration of the peripheral module that it uses to communicate. It is the application startup code responsibility to configure the communication module before the FreeMASTER driver is initialized by the FMSTR\_Init call.

When the Serial communication module is used as the FreeMASTER communication interface, configure the UART receive and transmit pins, the serial communication baud rate, parity (no-parity), the character length (eight bits), and the number of stop bits (one) before initializing the FreeMASTER driver. For either the long or the short interrupt modes of the driver (see [Driver interrupt modes](#)), configure the interrupt controller and register an application-specific interrupt handler for all interrupt sources related to the selected serial peripheral module. Call the FMSTR\_SerialIsr function from the application handler.

When a CAN module is used as the FreeMASTER communication interface, configure the CAN receive and transmit pins and the CAN module bit rate before initializing the FreeMASTER driver. For either the long or the short interrupt modes of the driver (see [Driver interrupt modes](#)), configure the interrupt controller and register an application-specific interrupt handler for all interrupt sources related to the selected CAN peripheral module. Call the FMSTR\_CanIsr function from the application handler.

**Note:** It is not necessary to enable or unmask the serial nor the CAN interrupts before initializing the FreeMASTER driver. The driver enables or disables the interrupts and communication lines, as required during runtime.

**FreeMASTER Recorder calls** When using the FreeMASTER Recorder in the application (FMSTR\_USE\_RECORDER > 0), call the FMSTR\_RecorderCreate function early after FMSTR\_Init to set up each recorder instance to be used in the application. Then call the FMSTR\_Recorder function periodically in the code where the data recording should occur. A typical place to call the Recorder routine is at the timer or PWM interrupts, but it can be anywhere else. The example applications provided together with the driver code call the FMSTR\_Recorder in the main application loop.

In applications where FMSTR\_Recorder is called periodically with a constant period, specify the period in the Recorder configuration structure before calling FMSTR\_RecorderCreate. This setting enables the PC Host FreeMASTER tool to display the X-axis of the Recorder graph properly scaled for the time domain.

**Driver usage** Start using or evaluating FreeMASTER by opening some of the example applications available in the driver setup package.

Follow these steps to enable the basic FreeMASTER connectivity in the application:

- Make sure that all `*.c` files of the FreeMASTER driver from the `src/common/platforms/[your_platform]` folder are a part of the project. See [Driver files](#) for more details.
- Configure the FreeMASTER driver by creating or editing the `freemaster_cfg.h` file and by saving it into the application project directory. See [Driver configuration](#) for more details.
- Include the `freemaster.h` file into any application source file that makes the FreeMASTER API calls.
- Initialize the Serial or CAN modules. Set the baud rate, parity, and other parameters of the communication. Do not enable the communication interrupts in the interrupt mask registers.
- For the `FMSTR_LONG_INTR` and `FMSTR_SHORT_INTR` modes, install the application-specific interrupt routine and call the `FMSTR_SerialIsr` or `FMSTR_CanIsr` functions from this handler.
- Call the `FMSTR_Init` function early on in the application initialization code.
- Call the `FMSTRRecorderCreate` functions for each Recorder instance to enable the Recorder feature.
- In the main application loop, call the `FMSTR_Poll` API function periodically when the application is idle.
- For the `FMSTR_SHORT_INTR` and `FMSTR_LONG_INTR` modes, enable the interrupts globally so that the interrupts can be handled by the CPU.

**Communication troubleshooting** The most common problem that causes communication issues is a wrong baud rate setting or a wrong pin multiplexer setting of the target MCU. When a communication between the PC Host running FreeMASTER and the target MCU cannot be established, try enabling the `FMSTR_DEBUG_TX` option in the `freemaster_cfg.h` file and call the `FMSTR_Poll` function periodically in the main application task loop.

With this feature enabled, the FreeMASTER driver periodically transmits a test frame through the Serial or CAN lines. Use a logic analyzer or an oscilloscope to monitor the signals at the communication pins of the CPU device to examine whether the bit rate and signal polarity are configured properly.

## Driver API

This section describes the driver Application Programmers' Interface (API) needed to initialize and use the FreeMASTER serial communication driver.

**Control API** There are three key functions to initialize and use the driver.

### `FMSTR_Init`

#### Prototype

```
FMSTR_BOOL FMSTR_Init(void);
```

- Declaration: `freemaster.h`
- Implementation: `freemaster_protocol.c`

**Description** This function initializes the internal variables of the FreeMASTER driver and enables the communication interface. This function does not change the configuration of the selected communication module. The hardware module must be initialized before the [FMSTR\\_Init](#) function is called.

A call to this function must occur before calling any other FreeMASTER driver API functions.

## FMSTR\_Poll

### Prototype

```
void FMSTR_Poll(void);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_protocol.c*

**Description** In the poll-driven or short interrupt modes, this function handles the protocol decoding and execution (see [Driver interrupt modes](#)). In the poll-driven mode, this function also handles the communication interface with the PC. Typically, the [FMSTR\\_Poll](#) function is called during the “idle” time in the main application task loop.

To prevent the receive data overflow (loss) on a serial interface, make sure that the [FMSTR\\_Poll](#) function is called at least once per the time calculated as:

$N * Tchar$

where:

- $N$  is equal to the length of the receive FIFO queue (configured by the `FMSTR_COMM_RQUEUE_SIZE` macro).  $N$  is 1 for the poll-driven mode.
- $Tchar$  is the character time, which is the time needed to transmit or receive a single byte over the SCI line.

**Note:** In the long interrupt mode, this function typically compiles as an empty function and can still be called. It is worthwhile to call this function regardless of the interrupt mode used in the application. This approach enables a convenient switching between the different interrupt modes only by changing the configuration macros in the *freemaster\_cfg.h* file.

## FMSTR\_SerialIsr / FMSTR\_CanIsr

### Prototype

```
void FMSTR_SerialIsr(void);
void FMSTR_CanIsr(void);
```

- Declaration: *freemaster.h*
- Implementation: *hw-specific low-level driver C file*

**Description** This function contains the interrupt-processing code of the FreeMASTER driver. In long or short interrupt modes (see [Driver interrupt modes](#)), this function must be called from the application interrupt service routine registered for the communication interrupt vector. On platforms where the communication module uses multiple interrupt vectors, the application should register a handler for all vectors and call this function at each interrupt.

**Note:** In a poll-driven mode, this function is compiled as an empty function and does not have to be used.

## Recorder API

### FMSTRRecorderCreate

#### Prototype

```
FMSTR_BOOL FMSTRRecorderCreate(FMSTR_INDEX recIndex, FMSTR_REC_BUFF* buffCfg);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function registers a recorder instance and enables it to be used by the PC Host tool. Call this function for all recorder instances from 0 to the maximum number defined by the FMSTR\_USE\_RECORDER configuration option (minus one). An exception to this requirement is the recorder of instance 0 which may be automatically configured by FMSTR\_Init when the *freemaster\_cfg.h* configuration file defines the *FMSTR\_REC\_BUFF\_SIZE* and *FMSTR\_REC\_TIMEBASE* options.

For more information, see [Configurable items](#).

### FMSTRRecorder

#### Prototype

```
void FMSTRRecorder(FMSTR_INDEX recIndex);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function takes a sample of the variables being recorded using the FreeMASTER Recorder instance *recIndex*. If the selected Recorder is not active when the *FMSTRRecorder* function is being called, the function returns immediately. When the Recorder is active, the values of the variables being recorded are copied into the recorder buffer and the trigger conditions are evaluated.

If a trigger condition is satisfied, the Recorder enters the post-trigger mode, where it counts down the follow-up samples (number of *FMSTRRecorder* function calls) and de-activates the Recorder when the required post-trigger samples are finished.

The *FMSTRRecorder* function is typically called in the timer or PWM interrupt service routines. This function can also be called in the application main loop (for testing purposes).

### FMSTRRecorderTrigger

#### Prototype

```
void FMSTRRecorderTrigger(FMSTR_INDEX recIndex);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function forces the Recorder trigger condition to happen, which causes the Recorder to be automatically deactivated after the post-trigger samples are sampled. Use this function in the application code for programmatic control over the Recorder triggering. This can be useful when a more complex triggering conditions need to be used.

**Fast Recorder API** The Fast Recorder feature is not available in the FreeMASTER driver version 3. This feature was heavily dependent on the target platform and it was only available for the 56F8xxxx DSCs.

**TSA Tables** When the TSA is enabled in the FreeMASTER driver configuration file (by setting the FMSTR\_USE\_TSA macro to a non-zero value), it defines the so-called TSA tables in the application. This section describes the macros that must be used to define the TSA tables.

There can be any number of TSA tables spread across the application source files. There must be always exactly one TSA Table List defined, which informs the FreeMASTER driver about the active TSA tables.

When there is at least one TSA table and one TSA Table List defined in the application, the TSA information automatically appears in the FreeMASTER symbols list. The symbols can then be used to create FreeMASTER variables for visualization or control.

**TSA table definition** The TSA table describes the static or global variables together with their address, size, type, and access-protection information. If the TSA-described variables are of a structure type, the TSA table may also describe this type and provide an access to the individual structure members of the variable.

The TSA table definition begins with the FMSTR\_TSA\_TABLE\_BEGIN macro with a *table\_id* identifying the table. The *table\_id* shall be a valid C-language symbol.

```
FMSTR_TSA_TABLE_BEGIN(table_id)
```

After this opening macro, the TSA descriptors are placed using these macros:

```
/* Adding variable descriptors */
FMSTR_TSA_RW_VAR(name, type) /* read/write variable entry */
FMSTR_TSA_RO_VAR(name, type) /* read-only variable entry */

/* Description of complex data types */
FMSTR_TSA_STRUCT(struct_name) /* structure or union type entry */
FMSTR_TSA_MEMBER(struct_name, member_name, type) /* structure member entry */

/* Memory blocks */
FMSTR_TSA_RW_MEM(name, type, address, size) /* read/write memory block */
FMSTR_TSA_RO_MEM(name, type, address, size) /* read-only memory block */
```

The table is closed using the FMSTR\_TSA\_TABLE\_END macro:

```
FMSTR_TSA_TABLE_END()
```

**TSA descriptor parameters** The TSA descriptor macros accept these parameters:

- *name* — variable name. The variable must be defined before the TSA descriptor references it.
- *type* — variable or member type. Only one of the pre-defined type constants may be used (see below).
- *struct\_name* — structure type name. The type must be defined (typedef) before the TSA descriptor references it.

- *member\_name* — structure member name.

**Note:** The structure member descriptors (FMSTR\_TSA\_MEMBER) must immediately follow the parent structure descriptor (FMSTR\_TSA\_STRUCT) in the table.

**Note:** To write-protect the variables in the FreeMASTER driver (FMSTR\_TSA\_RO\_VAR), enable the TSA-Safety feature in the configuration file.

**TSA variable types** The table lists *type* identifiers which can be used in TSA descriptors:

Constant	Description
FMSTR_TSA_UINTn	Unsigned integer type of size <i>n</i> bits (n=8,16,32,64)
FMSTR_TSA_SINTn	Signed integer type of size <i>n</i> bits (n=8,16,32,64)
FMSTR_TSA_FRACn	Fractional number of size <i>n</i> bits (n=16,32,64).
FMSTR_TSA_FRAC_Q(m,n)	Signed fractional number in general Q form (m+n+1 total bits)
FMSTR_TSA_FRAC_UQ(m,n)	Unsigned fractional number in general UQ form (m+n total bits)
FMSTR_TSA_FLOAT	4-byte standard IEEE floating-point type
FMSTR_TSA_DOUBLE	8-byte standard IEEE floating-point type
FMSTR_TSA_POINTER	Generic pointer type defined (platform-specific 16 or 32 bit)
FMSTR_TSA_USERTYPE( <i>name</i> )	Structure or union type declared with FMSTR_TSA_STRUCT record

**TSA table list** There shall be exactly one TSA Table List in the application. The list contains one entry for each TSA table defined anywhere in the application.

The TSA Table List begins with the FMSTR\_TSA\_TABLE\_LIST\_BEGIN macro and continues with the TSA table entries for each table.

```
FMSTR_TSA_TABLE_LIST_BEGIN()

FMSTR_TSA_TABLE(table_id)
FMSTR_TSA_TABLE(table_id2)
FMSTR_TSA_TABLE(table_id3)
...
```

The list is closed with the FMSTR\_TSA\_TABLE\_LIST\_END macro:

```
FMSTR_TSA_TABLE_LIST_END()
```

**TSA Active Content entries** FreeMASTER v2.0 and higher supports TSA Active Content, enabling the TSA tables to describe the memory-mapped files, virtual directories, and URL hyperlinks. FreeMASTER can access such objects similarly to accessing the files and folders on the local hard drive.

With this set of TSA entries, the FreeMASTER pages can be embedded directly into the target MCU flash and accessed by FreeMASTER directly over the communication line. The HTML-coded pages rendered inside the FreeMASTER window can access the TSA Active Content resources using a special URL referencing the *fmstr:* protocol.

This example provides an overview of the supported TSA Active Content entries:

```
FMSTR_TSA_TABLE_BEGIN(files_and_links)

/* Directory entry applies to all subsequent MEMFILE entries */
FMSTR_TSA_DIRECTORY("/text_files") /* entering a new virtual directory */
```

(continues on next page)

(continued from previous page)

```

/* The readme.txt file will be accessible at the fmstr://text_files/readme.txt URL */
FMSTR_TSA_MEMFILE("readme.txt", readme_txt, sizeof(readme_txt)) /* memory-mapped file */

/* Files can also be specified with a full path so the DIRECTORY entry does not apply */
FMSTR_TSA_MEMFILE("/index.htm", index, sizeof(index)) /* memory-mapped file */
FMSTR_TSA_MEMFILE("/prj/demo.pmp", demo_pmp, sizeof(demo_pmp)) /* memory-mapped file */

/* Hyperlinks can point to a local MEMFILE object or to the Internet */
FMSTR_TSA_HREF("Board's Built-in Welcome Page", "/index.htm")
FMSTR_TSA_HREF("FreeMASTER Home Page", "http://www.nxp.com/freemaster")

/* Project file links simplify opening the projects from any URLs */
FMSTR_TSA_PROJECT("Demonstration Project (embedded)", "/prj/demo.pmp")
FMSTR_TSA_PROJECT("Full Project (online)", "http://mycompany.com/prj/demo.pmp")

FMSTR_TSA_TABLE_END()

```

## TS API

### FMSTR\_SetUpTsaBuff

#### Prototype

```
FMSTR_BOOL FMSTR_SetUpTsaBuff(FMSTR_ADDR buffAddr, FMSTR_SIZE buffSize);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_tsa.c*

#### Arguments

- *buffAddr* [in] - address of the memory buffer for the dynamic TSA table
- *buffSize* [in] - size of the memory buffer which determines the maximum number of TSA entries to be added in the runtime

**Description** This function must be used to assign the RAM memory buffer to the TSA subsystem when FMSTR\_USE\_TSA\_DYNAMIC is enabled. The memory buffer is then used to store the TSA entries added dynamically to the runtime TSA table using the FMSTR\_TsaAddVar function call. The runtime TSA table is processed by the FreeMASTER PC Host tool along with all static tables as soon as the communication port is open.

The size of the memory buffer determines the number of TSA entries that can be added dynamically. Depending on the MCU platform, one TSA entry takes either 8 or 16 bytes.

### FMSTR\_TsaAddVar

#### Prototype

```
FMSTR_BOOL FMSTR_TsaAddVar(FMSTR_TSATBL_STRPTR tsaName, FMSTR_TSATBL_STRPTR
    ↳tsaType,
    FMSTR_TSATBL_VOIDPTR varAddr, FMSTR_SIZE32 varSize,
    FMSTR_SIZE flags);
```

- Declaration: *freemaster.h*

- Implementation: *freemaster\_tsa.c*

### Arguments

- *tsaName* [in] - name of the object
- *tsaType* [in] - name of the object type
- *varAddr* [in] - address of the object
- *varSize* [in] - size of the object
- *flags* [in] - access flags; a combination of these values:
  - *FMSTR\_TSA\_INFO\_RO\_VAR* — read-only memory-mapped object (typically a variable)
  - *FMSTR\_TSA\_INFO\_RW\_VAR* — read/write memory-mapped object
  - *FMSTR\_TSA\_INFO\_NON\_VAR* — other entry, describing structure types, structure members, enumerations, and other types

**Description** This function can be called only when the dynamic TSA table is enabled by the *FMSTR\_USE\_TSA\_DYNAMIC* configuration option and when the *FMSTR\_SetUpTsaBuff* function call is made to assign the dynamic TSA table memory. This function adds an entry into the dynamic TSA table. It can be used to register a read-only or read/write memory object or describe an item of the user-defined type.

See [TSA table definition](#) for more details about the TSA table entries.

### Application Commands API

#### **FMSTR\_GetAppCmd**

##### Prototype

```
FMSTR_APPCMD_CODE FMSTR_GetAppCmd(void);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

**Description** This function can be used to detect if there is an Application Command waiting to be processed by the application. If no command is pending, this function returns the *FMSTR\_APPCMDRESULT\_NOCMD* constant. Otherwise, this function returns the code of the Application Command that must be processed. Use the *FMSTR\_AppCmdAck* call to acknowledge the Application Command after it is processed and to return the appropriate result code to the host.

The *FMSTR\_GetAppCmd* function does not report the commands for which a callback handler function exists. If the *FMSTR\_GetAppCmd* function is called when a callback-registered command is pending (and before it is actually processed by the callback function), this function returns *FMSTR\_APPCMDRESULT\_NOCMD*.

#### **FMSTR\_GetAppCmdData**

## Prototype

```
FMSTR_APPCMD_PDATA FMSTR_GetAppCmdData(FMSTR_SIZE* dataLen);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *dataLen* [out] - pointer to the variable that receives the length of the data available in the buffer. It can be NULL when this information is not needed.

**Description** This function can be used to retrieve the Application Command data when the application determines that an Application Command is pending (see [FMSTR\\_GetAppCmd](#)).

There is just a single buffer to hold the Application Command data (the buffer length is FMSTR\_APPCMD\_BUFF\_SIZE bytes). If the data are to be used in the application after the command is processed by the FMSTR\_AppCmdAck call, copy the data out to a private buffer.

## FMSTR\_AppCmdAck

### Prototype

```
void FMSTR_AppCmdAck(FMSTR_APPCMD_RESULT resultCode);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *resultCode* [in] - the result code which is to be returned to FreeMASTER

**Description** This function is used when the Application Command processing finishes in the application. The resultCode passed to this function is returned back to the host and the driver is re-initialized to expect the next Application Command.

After this function is called and before the next Application Command arrives, the return value of the FMSTR\_GetAppCmd function is FMSTR\_APPCMDRESULT\_NOCMD.

## FMSTR\_AppCmdSetresponseData

### Prototype

```
void FMSTR_AppCmdSetresponseData(FMSTR_ADDR resultDataAddr, FMSTR_SIZE resultDataLen);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *resultDataAddr* [in] - pointer to the data buffer that is to be copied to the Application Command data buffer
- *resultDataLen* [in] - length of the data to be copied. It must not exceed the FMSTR\_APPCMD\_BUFF\_SIZE value.

**Description** This function can be used before the Application Command processing finishes, when there are data to be returned back to the PC.

The response data buffer is copied into the Application Command data buffer, from where it is accessed when the host requires it. Do not use FMSTR\_GetAppCmdData and the data buffer after FMSTR\_AppCmdSetResponseData is called.

**Note:** The current version of FreeMASTER does not support the Application Command response data.

## FMSTR\_RegisterAppCmdCall

### Prototype

```
FMSTR_BOOL FMSTR_RegisterAppCmdCall(FMSTR_APPCMD_CODE appCmdCode, FMSTR_
→PAPPCMDFUNC callbackFunc);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *appCmdCode* [in] - the Application Command code for which the callback is to be registered
- *callbackFunc* [in] - pointer to the callback function that is to be registered. Use NULL to unregister a callback registered previously with this Application Command.

**Return value** This function returns a non-zero value when the callback function was successfully registered or unregistered. It can return zero when trying to register a callback function for more than FMSTR\_MAX\_APPCMD\_CALLS different Application Commands.

**Description** This function can be used to register the given function as a callback handler for the Application Command. The Application Command is identified using single-byte code. The callback function is invoked automatically by the FreeMASTER driver when the protocol decoder obtains a request to get the application command result code.

The prototype of the callback function is

```
FMSTR_APPCMD_RESULT HandlerFunction(FMSTR_APPCMD_CODE nAppcmd,
FMSTR_APPCMD_PDATA pData, FMSTR_SIZE nDataLen);
```

Where:

- *nAppcmd* -Application Command code
- *pData* —points to the Application Command data received (if any)
- *nDataLen* —information about the Application Command data length

The return value of the callback function is used as the Application Command Result Code and returned to FreeMASTER.

**Note:** The FMSTR\_MAX\_APPCMD\_CALLS configuration macro defines how many different Application Commands may be handled by a callback function. When FMSTR\_MAX\_APPCMD\_CALLS is undefined or defined as zero, the FMSTR\_RegisterAppCmdCall function always fails.

## Pipes API

### FMSTR\_PipeOpen

#### Prototype

```
FMSTR_HPIPE FMSTR_PipeOpen(FMSTR_PIPE_PORT pipePort, FMSTR_PPIEFUNC pipeCallback,
    →
    FMSTR_ADDR pipeRxBuff, FMSTR_PIPE_SIZE pipeRxSize,
    FMSTR_ADDR pipeTxBuff, FMSTR_PIPE_SIZE pipeTxSize,
    FMSTR_U8 type, const FMSTR_CHAR *name);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

#### Arguments

- *pipePort* [in] - port number that identifies the pipe for the client
- *pipeCallback* [in] - pointer to the callback function that is called whenever a pipe data status changes
- *pipeRxBuff* [in] - address of the receive memory buffer
- *pipeRxSize* [in] - size of the receive memory buffer
- *pipeTxBuff* [in] - address of the transmit memory buffer
- *pipeTxSize* [in] - size of the transmit memory buffer
- *type* [in] - a combination of FMSTR\_PIPE\_MODE\_xxx and FMSTR\_PIPE\_SIZE\_xxx constants describing primary pipe data format and usage. This type helps FreeMASTER decide how to access the pipe by default. Optional, use 0 when undetermined.
- *name* [in] - user name of the pipe port. This name is visible to the FreeMASTER user when creating the graphical pipe interface.

**Description** This function initializes a new pipe and makes it ready to accept or send the data to the PC Host client. The receive memory buffer is used to store the received data before they are read out by the FMSTR\_PipeRead call. When this buffer gets full, the PC Host client denies the data transmission into this pipe until there is enough free space again. The transmit memory buffer is used to store the data transmitted by the application to the PC Host client using the FMSTR\_PipeWrite call. The transmit buffer can get full when the PC Host is disconnected or when it is slow in receiving and reading out the pipe data.

The function returns the pipe handle which must be stored and used in the subsequent calls to manage the pipe object.

The callback function (if specified) is called whenever new data are received through the pipe and available for reading. This callback is also called when the data waiting in the transmit buffer are successfully pushed to the PC Host and the transmit buffer free space increases. The prototype of the callback function provided by the user application must be as follows. The *PipeHandler* name is only a placeholder and must be defined by the application.

```
void PipeHandler(FMSTR_HPIPE pipeHandle);
```

## FMSTR\_PipeClose

### Prototype

```
void FMSTR_PipeClose(FMSTR_HPIPE pipeHandle);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

### Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call

**Description** This function de-initializes the pipe object. No data can be received or sent on the pipe after this call.

## FMSTR\_PipeWrite

### Prototype

```
FMSTR_PIPE_SIZE FMSTR_PipeWrite(FMSTR_HPIPE pipeHandle, FMSTR_ADDR pipeData,  
FMSTR_PIPE_SIZE pipeDataLen, FMSTR_PIPE_SIZE writeGranularity);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

### Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call
- *pipeData* [in] - address of the data to be written
- *pipeDataLen* [in] - length of the data to be written
- *writeGranularity* [in] - size of the minimum unit of data which is to be written

**Description** This function puts the user-specified data into the pipe's transmit memory buffer and schedules it for transmission. This function returns the number of bytes that were successfully written into the buffer. This number may be smaller than the number of the requested bytes if there is not enough free space in the transmit buffer.

The *writeGranularity* argument can be used to split the data into smaller chunks, each of the size given by the *writeGranularity* value. The FMSTR\_PipeWrite function writes as many data chunks as possible into the transmit buffer and does not attempt to write an incomplete chunk. This feature can prove to be useful to avoid the intermediate caching when writing an array of integer values or other multi-byte data items. When making the *nGranularity* value equal to the *nLength* value, all data are considered as one chunk which is either written successfully as a whole or not at all. The *nGranularity* value of 0 or 1 disables the data-chunk approach.

## FMSTR\_PipeRead

## Prototype

```
FMSTR_PIPE_SIZE FMSTR_PipeRead(FMSTR_HPIPE pipeHandle, FMSTR_ADDR pipeData,
                                FMSTR_PIPE_SIZE pipeDataLen, FMSTR_PIPE_SIZE readGranularity);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

## Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call
- *pipeData* [in] - address of the data buffer to be filled with the received data
- *pipeDataLen* [in] - length of the data to be read
- *readGranularity* [in] - size of the minimum unit of data which is to be read

**Description** This function copies the data received from the pipe from its receive buffer to the user buffer for further processing. The function returns the number of bytes that were successfully copied to the buffer. This number may be smaller than the number of the requested bytes if there is not enough data bytes available in the receive buffer.

The readGranularity argument can be used to copy the data in larger chunks in the same way as described in the FMSTR\_PipeWrite function.

**API data types** This section describes the data types used in the FreeMASTER driver. The information provided here can be useful when modifying or porting the FreeMASTER Communication Driver to new NXP platforms.

**Note:** The licensing conditions prohibit use of FreeMASTER and the FreeMASTER Communication Driver with non-NXP MPU or MCU products.

**Public common types** The table below describes the public data types used in the FreeMASTER driver API calls. The data types are declared in the *freemaster.h* header file.

Type name	Description
<i>FM-STR_ADDR</i>	Data type used to hold the memory address. On most platforms, this is normally a C-pointer, but it may also be a pure integer type. For example, this type is defined as long integer on the 56F8xxx platform where the 24-bit addresses must be supported, but the C-pointer may be only 16 bits wide in some compiler configurations.
<i>FM-STR_SIZE</i>	Data type used to hold the memory block size. It is required that this type is unsigned and at least 16 bits wide integer.
<i>FM-STR_BOOL</i>	Data type used as a general boolean type. This type is used only in zero/non-zero conditions in the driver code.
<i>FM-STR_APPCM</i>	Data type used to hold the Application Command code. Generally, this is an unsigned 8-bit value.
<i>FM-STR_APPCM</i>	Data type used to create the Application Command data buffer. Generally, this is an unsigned 8-bit value.
<i>FM-STR_APPCM</i>	Data type used to hold the Application Command result code. Generally, this is an unsigned 8-bit value.

**Public TSA types** The table describes the TSA-specific public data types. These types are declared in the *freemaster\_tsa.h* header file, which is included in the user application indirectly by the *freemaster.h* file.

<i>FM-STR_TSA_TII</i>	Data type used to hold a descriptor index in the TSA table or a table index in the list of TSA tables.
By default, this is defined as <i>FM-STR_SIZE</i> .	
<i>FM-STR_TSA_TS</i>	Data type used to hold a memory block size, as used in the TSA descriptors.
By default, this is defined as <i>FM-STR_SIZE</i> .	

**Public Pipes types** The table describes the data types used by the FreeMASTER Pipes API:

<i>FM-STR_HPIPE</i>	Pipe handle that identifies the open-pipe object.
Generally, this is a pointer to a void type.	
<i>FM-STR_PIPE_P</i>	Integer type required to hold at least 7 bits of data.
Generally, this is an unsigned 8-bit or 16-bit type.	
<i>FM-STR_PIPE_SI</i>	Integer type required to hold at least 16 bits of data.
This is used to store the data buffer sizes.	
<i>FM-STR_PPIPEF</i>	Pointer to the pipe handler function.
See <a href="#">FM-STR_PipeOpen</a> for more details.	

**Internal types** The table describes the data types used internally by the FreeMASTER driver. The data types are declared in the platform-specific header file and they are not available in the application code.

<i>FMSTR_U8</i>	The smallest memory entity. On the vast majority of platforms, this is an unsigned 8-bit integer. On the 56F8xx DSP platform, this is defined as an unsigned 16-bit integer.
<i>FM-STR_U16</i>	Unsigned 16-bit integer.
<i>FM-STR_U32</i>	Unsigned 32-bit integer.
<i>FMSTR_S8</i>	Signed 8-bit integer.
<i>FM-STR_S16</i>	Signed 16-bit integer.
<i>FM-STR_S32</i>	Signed 32-bit integer.
<i>FM-STR_FLOAT</i>	4-byte standard IEEE floating-point type.
<i>FM-STR_FLAGS</i>	Data type forming a union with a structure of flag bit-fields.
<i>FM-STR_SIZE8</i>	Data type holding a general size value, at least 8 bits wide.
<i>FM-STR_INDEX</i>	General for-loop index. Must be signed, at least 16 bits wide.
<i>FM-STR_BCHR</i>	A single character in the communication buffer. Typically, this is an 8-bit unsigned integer, except for the DSP platforms where it is a 16-bit integer.
<i>FM-STR_BPTR</i>	A pointer to the communication buffer (an array of <i>FMSTR_BCHR</i> ).

## Document references

### Links

- This document online: <https://mcuxpresso.nxp.com/mcuxsdk/latest/html/middleware/freemaster/doc/index.html>

- FreeMASTER tool home: [www.nxp.com/freemaster](http://www.nxp.com/freemaster)
- FreeMASTER community area: [community.nxp.com/community/freemaster](http://community.nxp.com/community/freemaster)
- FreeMASTER GitHub code repo: <https://github.com/nxp-mcuxpresso/mcux-freemaster>
- MCUXpresso SDK home: [www.nxp.com/mcuxpresso](http://www.nxp.com/mcuxpresso)
- MCUXpresso SDK builder: [mcuxpresso.nxp.com/en](http://mcuxpresso.nxp.com/en)

## Documents

- *FreeMASTER Usage Serial Driver Implementation* (document [AN4752](#))
- *Integrating FreeMASTER Time Debugging Tool With CodeWarrior For Microcontrollers v10.X Project* (document [AN4771](#))
- *Flash Driver Library For MC56F847xx And MC56F827xx DSC Family* (document [AN4860](#))

**Revision history** This Table summarizes the changes done to this document since the initial release.

Revision	Date	Description
1.0	03/2006	Limited initial release
2.0	09/2007	Updated for FreeMASTER version. New Freescale document template used.
2.1	12/2007	Added description of the new Fast Recorder feature and its API.
2.2	04/2010	Added support for MPC56xx platform, Added new API for use CAN interface.
2.3	04/2011	Added support for Kxx Kinetis platform and MQX operating system.
2.4	06/2011	Serial driver update, adds support for USB CDC interface.
2.5	08/2011	Added Packet Driven BDM interface.
2.7	12/2013	Added FLEXCAN32 interface, byte access and isr callback configuration option.
2.8	06/2014	Removed obsolete license text, see the software package content for up-to-date license.
2.9	03/2015	Update for driver version 1.8.2 and 1.9: FreeMASTER Pipes, TSA Active Content, LIN Transport Layer support, DEBUG-TX communication troubleshooting, Kinetis SDK support.
3.0	08/2016	Update for driver version 2.0: Added support for MPC56xx, MPC57xx, KEAxx and S32Kxx platforms. New NXP document template as well as new license agreement used. added MCAN interface. Folders structure at the installation destination was rearranged.
4.0	04/2019	Update for driver released as part of FreeMASTER v3.0 and MCUXpresso SDK 2.6. Updated to match new V4 serial communication protocol and new configuration options. This version of the document removes substantial portion of outdated information related to S08, S12, ColdFire, Power and other legacy platforms.
4.1	04/2020	Minor update for FreeMASTER driver included in MCUXpresso SDK 2.8.
4.2	09/2020	Added example applications description and information about the MCUXpresso Config Tools. Fixed the pipe-related API description.
4.3	10/2024	Added description of Network and Segger J-Link RTT interface configuration. Accompanying the MCUXpresso SDK version 24.12.00.
4.4	04/2025	Added Zephyr-specific information. Accompanying the MCUXpresso SDK version 25.06.00.

# Chapter 4

## RTOS

### 4.1 FreeRTOS

#### 4.1.1 FreeRTOS kernel

Open source RTOS kernel for small devices.

[FreeRTOS kernel for MCUXpresso SDK Readme](#)

[FreeRTOS kernel for MCUXpresso SDK ChangeLog](#)

[FreeRTOS kernel Readme](#)

#### 4.1.2 FreeRTOS drivers

This is set of NXP provided FreeRTOS reentrant bus drivers.

#### 4.1.3 backoffalgorithm

Algorithm for calculating exponential backoff with jitter for network retry attempts.

[Readme](#)

#### 4.1.4 corehttp

C language HTTP client library designed for embedded platforms.

#### 4.1.5 corejson

JSON parser.

**Readme**

**4.1.6 coremqtt**

MQTT publish/subscribe messaging library.

**4.1.7 coremqtt-agent**

The coreMQTT Agent library is a high level API that adds thread safety to the coreMQTT library.

**Readme**

**4.1.8 corepkcs11**

PKCS #11 key management library.

**Readme**

**4.1.9 freertos-plus-tcp**

Open source RTOS FreeRTOS Plus TCP.

**Readme**