



# MCUXpresso SDK Documentation

Release 26.03.00-pvw1



NXP  
Jan 19, 2026



# Table of contents

|          |                                                      |            |
|----------|------------------------------------------------------|------------|
| <b>1</b> | <b>TWR-KM34Z50MV3</b>                                | <b>3</b>   |
| 1.1      | Overview                                             | 3          |
| 1.2      | Getting Started with MCUXpresso SDK Package          | 3          |
| 1.2.1    | Getting Started with MCUXpresso SDK Package          | 3          |
| 1.3      | Getting Started with MCUXpresso SDK GitHub           | 58         |
| 1.3.1    | Getting Started with MCUXpresso SDK Repository       | 58         |
| 1.4      | Release Notes                                        | 65         |
| 1.4.1    | MCUXpresso SDK Release Notes                         | 65         |
| 1.5      | ChangeLog                                            | 68         |
| 1.5.1    | MCUXpresso SDK Changelog                             | 68         |
| 1.6      | Driver API Reference Manual                          | 105        |
| 1.7      | Middleware Documentation                             | 105        |
| 1.7.1    | FreeMASTER                                           | 105        |
| 1.7.2    | FreeRTOS                                             | 105        |
| <b>2</b> | <b>MKM34ZA5</b>                                      | <b>107</b> |
| 2.1      | ADC16: 16-bit SAR Analog-to-Digital Converter Driver | 107        |
| 2.2      | AFE: Analog Front End Driver                         | 116        |
| 2.3      | Clock Driver                                         | 124        |
| 2.4      | CMP: Analog Comparator Driver                        | 147        |
| 2.5      | CRC: Cyclic Redundancy Check Driver                  | 152        |
| 2.6      | DMA: Direct Memory Access Controller Driver          | 155        |
| 2.7      | DMAMUX: Direct Memory Access Multiplexer Driver      | 165        |
| 2.8      | EWM: External Watchdog Monitor Driver                | 166        |
| 2.9      | FGPIO Driver                                         | 169        |
| 2.10     | C90TFS Flash Driver                                  | 169        |
| 2.11     | ftfx adapter                                         | 169        |
| 2.12     | Ftftx CACHE Driver                                   | 169        |
| 2.13     | ftfx controller                                      | 171        |
| 2.14     | ftfx feature                                         | 188        |
| 2.15     | Ftftx FLASH Driver                                   | 188        |
| 2.16     | Ftftx FLEXNVM Driver                                 | 202        |
| 2.17     | ftfx utilities                                       | 213        |
| 2.18     | GPIO: General-Purpose Input/Output Driver            | 213        |
| 2.19     | GPIO Driver                                          | 215        |
| 2.20     | I2C: Inter-Integrated Circuit Driver                 | 217        |
| 2.21     | I2C DMA Driver                                       | 217        |
| 2.22     | I2C Driver                                           | 218        |
| 2.23     | IRTC: IRTC Driver                                    | 233        |
| 2.24     | Common Driver                                        | 244        |
| 2.25     | LLWU: Low-Leakage Wakeup Unit Driver                 | 257        |
| 2.26     | LPTMR: Low-Power Timer                               | 261        |
| 2.27     | MCM: Miscellaneous Control Module                    | 267        |
| 2.28     | PIT: Periodic Interrupt Timer                        | 272        |
| 2.29     | PMC: Power Management Controller                     | 276        |
| 2.30     | PORT: Port Control and Interrupts                    | 281        |

|          |                                                          |            |
|----------|----------------------------------------------------------|------------|
| 2.31     | QTM: Quad Timer Driver                                   | 289        |
| 2.32     | RCM: Reset Control Module Driver                         | 296        |
| 2.33     | RNGA: Random Number Generator Accelerator Driver         | 302        |
| 2.34     | SIM: System Integration Module Driver                    | 303        |
| 2.35     | SLCD: Segment LCD Driver                                 | 305        |
| 2.36     | Smart Card                                               | 317        |
| 2.37     | Smart Card UART Driver                                   | 324        |
| 2.38     | SMC: System Mode Controller Driver                       | 327        |
| 2.39     | SPI: Serial Peripheral Interface Driver                  | 333        |
| 2.40     | SPI DMA Driver                                           | 333        |
| 2.41     | SPI Driver                                               | 337        |
| 2.42     | SYSPMU: System Memory Protection Unit                    | 350        |
| 2.43     | UART: Universal Asynchronous Receiver/Transmitter Driver | 357        |
| 2.44     | UART DMA Driver                                          | 357        |
| 2.45     | UART Driver                                              | 360        |
| 2.46     | VREF: Voltage Reference Driver                           | 375        |
| 2.47     | WDOG: Watchdog Timer Driver                              | 378        |
| 2.48     | XBAR: Inter-Peripheral Crossbar Switch                   | 385        |
| <b>3</b> | <b>Middleware</b>                                        | <b>389</b> |
| 3.1      | Motor Control                                            | 389        |
| 3.1.1    | FreeMASTER                                               | 389        |
| <b>4</b> | <b>RTOS</b>                                              | <b>427</b> |
| 4.1      | FreeRTOS                                                 | 427        |
| 4.1.1    | FreeRTOS kernel                                          | 427        |
| 4.1.2    | FreeRTOS drivers                                         | 427        |
| 4.1.3    | backoffalgorithm                                         | 427        |
| 4.1.4    | corehttp                                                 | 427        |
| 4.1.5    | corejson                                                 | 427        |
| 4.1.6    | coremqtt                                                 | 428        |
| 4.1.7    | corepkcs11                                               | 428        |
| 4.1.8    | freertos-plus-tcp                                        | 428        |


This documentation contains information specific to the twrk34z50mv3 board.



# Chapter 1

## TWR-KM34Z50MV3

### 1.1 Overview



MCU device and part on board is shown below:

- Device: MKM34ZA5
- PartNumber: MKM34Z128ACLL5

### 1.2 Getting Started with MCUXpresso SDK Package

#### 1.2.1 Getting Started with MCUXpresso SDK Package

Starting with version 25.09.00, MCUXpresso SDK introduced two package versions for offline development:

- **Classic SDK Package:** Traditional board-specific packages with pre-configured IDE projects for MCUXpresso IDE, IAR, Keil, and other toolchains.
- **Repository-Layout SDK Package:** Board-specific packages that maintain the same structure and build system as the GitHub Repository SDK, providing offline access to the repository SDK development experience. Available when selecting the ARMGCC toolchain.

**From version 25.12.00 onward:**

- When you select ARMGCC, the SDK download will use the Repository-Layout version.
- For all other toolchains, the SDK download will remain in the Classic version.


Note: The Repository-Layout SDK package was first introduced in version 25.09.00, but initially only for MCXW23x platforms.

## Classic SDK Package

**Overview** The NXP MCUXpresso software and tools offer comprehensive development solutions designed to optimize, ease, and help accelerate embedded system development of applications based on general purpose, crossover, and Bluetooth-enabled MCUs from NXP. The MCUXpresso SDK includes a flexible set of peripheral drivers designed to speed up and simplify development of embedded applications. Along with the peripheral drivers, the MCUXpresso SDK provides an extensive and rich set of example applications covering everything from basic peripheral use case examples to full demo applications. The MCUXpresso SDK contains optional RTOS integrations such as FreeRTOS and Azure RTOS, and various other middleware to support rapid development.

For supported toolchain versions, see *MCUXpresso SDK Release Notes* (document MCUXSDKRN).

For more details about MCUXpresso SDK, see [MCUXpresso Software Development Kit \(SDK\)](#).



**MCUXpresso SDK board support package folders** MCUXpresso SDK board support package provides example applications for NXP development and evaluation boards for Arm Cortex-M cores including Freedom, Tower System, and LPCXpresso boards. Board support packages are found inside the top-level boards folder and each supported board has its own folder (an MCUXpresso SDK package can support multiple boards). Within each `<board_name>` folder, there are various subfolders to classify the type of examples it contains. These include (but are not limited to):


- `cmsis_driver_examples`: Simple applications intended to show how to use CMSIS drivers.
- `demo_apps`: Full-featured applications that highlight key functionality and use cases of the target MCU. These applications typically use multiple MCU peripherals and may leverage stacks and middleware.
- `driver_examples`: Simple applications that show how to use the MCUXpresso SDK's peripheral drivers for a single use case. These applications typically only use a single peripheral but there are cases where multiple peripherals are used (for example, SPI conversion using DMA).
- `emwin_examples`: Applications that use the emWin GUI widgets.

- `rtos_examples`: Basic FreeRTOS OS examples that show the use of various RTOS objects (semaphores, queues, and so on) and interfaces with the MCUXpresso SDK's RTOS drivers
- `usb_examples`: Applications that use the USB host/device/OTG stack.

**Example application structure** This section describes how the various types of example applications interact with the other components in the MCUXpresso SDK. To get a comprehensive understanding of all MCUXpresso SDK components and folder structure, see *MCUXpresso SDK API Reference Manual*.

Each `<board_name>` folder in the boards directory contains a comprehensive set of examples that are relevant to that specific piece of hardware. Although we use the `hello_world` example (part of the `demo_apps` folder), the same general rules apply to any type of example in the `<board_name>` folder.

In the `hello_world` application folder you see the following contents:



All files in the application folder are specific to that example, so it is easy to copy and paste an existing example to start developing a custom application based on a project provided in the MCUXpresso SDK.

**Locating example application source files** When opening an example application in any of the supported IDEs, various source files are referenced. The MCUXpresso SDK devices folder is the central component to all example applications. It means that the examples reference the same source files and, if one of these files is modified, it could potentially impact the behavior of other examples.

The main areas of the MCUXpresso SDK tree used in all example applications are:

- `devices/<device_name>`: The device's CMSIS header file, MCUXpresso SDK feature file, and a few other files
- `devices/<device_name>/cmsis_drivers`: All the CMSIS drivers for your specific MCU
- `devices/<device_name>/drivers`: All of the peripheral drivers for your specific MCU
- `devices/<device_name>/<tool_name>`: Toolchain-specific startup code, including vector table definitions
- `devices/<device_name>/utilities`: Items such as the debug console that are used by many of the example applications

- devices/<devices\_name>/project: Project template used in CMSIS PACK new project creation

For examples containing middleware/stacks or an RTOS, there are references to the appropriate source code. Middleware source files are located in the `middleware` folder and RTOSes are in the `rtos` folder. The core files of each of these are shared, so modifying one could have potential impacts on other projects that depend on that file.


**Run a demo using MCUXpresso IDE** **Note:** Ensure that the MCUXpresso IDE toolchain is included when generating the MCUXpresso SDK package.

This section describes the steps required to configure MCUXpresso IDE to build, run, and debug example applications. The `hello_world` demo application targeted for the hardware platform is used as an example, though these steps can be applied to any example application in the MCUXpresso SDK.


**Select the workspace location** Every time MCUXpresso IDE launches, it prompts the user to select a workspace location. MCUXpresso IDE is built on top of Eclipse which uses workspace to store information about its current configuration, and in some use cases, source files for the projects are in the workspace. The location of the workspace can be anywhere, but it is recommended that the workspace be located outside the MCUXpresso SDK tree.

**Build an example application** To build an example application, follow these steps.


1. Drag and drop the SDK zip file into the **Installed SDKs** view to install an SDK. In the window that appears, click **OK** and wait until the import has finished.



2. On the **Quickstart Panel**, click **Import SDK example(s)...**



3. Expand the demo\_apps folder and select hello\_world.
4. Click **Next**.




5. Ensure **Redlib: Use floating-point version of printf** is selected if the example prints floating-point numbers on the terminal for demo applications such as `adc_basic`, `adc_burst`, `adc_dma`, and `adc_interrupt`. Otherwise, it is not necessary to select this option. Then, click **Finish**.

**Run an example application** For more information on debug probe support in the MCUXpresso IDE, see [community.nxp.com](http://community.nxp.com).


To download and run the application, perform the following steps:

1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via a USB cable.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug serial port number (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:

1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in board.h file)
2. No parity
3. 8 data bits



4. 1 stop bit
4. On the **Quickstart Panel**, click **Debug** to launch the debug session.
5. The first time you debug a project, the **Debug Emulator Selection** dialog is displayed, showing all supported probes that are attached to your computer. Select the probe through which you want to debug and click **OK**. (For any future debug sessions, the stored probe selection is automatically used, unless the probe cannot be found.)



- The application is downloaded to the target and automatically runs to `main()`.
- Start the application by clicking **Resume**.




The `hello_world` application is now running and a banner is displayed on the terminal. If not, check your terminal settings and connections.




**Build a multicore example application** This section describes the steps required to configure MCUXpresso IDE to build, run, and debug multicore example applications. The following steps can be applied to any multicore example application in the MCUXpresso SDK. Here, the dual-core version of hello\_world example application targeted for the LPCXpresso54114 hardware platform is used as an example.

1. Multicore examples are imported into the workspace in a similar way as single core applications, explained in **Build an example application**. When the SDK zip package for LPCXpresso54114 is installed and available in the **Installed SDKs** view, click **Import SDK example(s)...** on the Quickstart Panel. In the window that appears, expand the **LPCxx** folder and select **LPC54114J256**. Then, select **lpcxpresso54114** and click **Next**.
2. Expand the multicore\_examples/hello\_world folder and select **cm4**. The cm0plus counterpart project is automatically imported with the cm4 project, because the multicore examples are linked together and there is no need to select it explicitly. Click **Finish**.




3. Now, two projects should be imported into the workspace. To start building the multicore application, highlight the `lpcxpresso54114_multicore_examples_hello_world_cm4` project (multicore master project) in the Project Explorer. Then choose the appropriate build target, **Debug** or **Release**, by clicking the downward facing arrow next to the hammer icon, as shown in the figure. For this example, select **Debug**.






The project starts building after the build target is selected. Because of the project reference settings in multicore projects, triggering the build of the primary core application (cm4) also causes the referenced auxiliary core application (cm0plus) to build.


**Note:** When the **Release** build is requested, it is necessary to change the build configuration of both the primary and auxiliary core application projects first. To do this, select both projects in the Project Explorer view and then right click which displays the context-sensitive menu. Select **Build Configurations -> Set Active -> Release**. This alternate navigation using the menu item is **Project -> Build Configuration -> Set Active -> Release**. After switching to the **Release** build configuration, the build of the multicore example can be started by triggering the primary core application (cm4) build.




**Run a multicore example application** The primary core debugger handles flashing of both the primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform all steps as described in **Run an example application**. These steps are common for both single-core applications and the primary side of dual-core applications, ensuring both sides of the multicore application are properly loaded and started. However, there is one additional dialogue that is specific to multicore examples which requires selecting the target core. See the following figures as reference.









After clicking the “Resume All Debug sessions” button, the hello\_world multicore application runs and a banner is displayed on the terminal. If this is not the case, check your terminal settings and connections.




An LED controlled by the auxiliary core starts flashing, indicating that the auxiliary core has been released from the reset and running correctly. It is also possible to debug both sides of the multicore application in parallel. After creating the debug session for the primary core, perform same steps also for the auxiliary core application. Highlight the lpcxpresso54114\_multicore\_examples\_hello\_world\_cm0plus project (multicore slave project) in the Project Explorer. On the Quickstart Panel, click “Debug ‘lpcxpresso54114\_multicore\_examples\_hello\_world\_cm0plus’ [Debug]” to launch the second debug

session.







Now, the two debug sessions should be opened, and the debug controls can be used for both debug sessions depending on the debug session selection. Keep the primary core debug session selected by clicking the “Resume” button. The hello\_world multicore application then starts running. The primary core application starts the auxiliary core application during runtime, and the auxiliary core application stops at the beginning of the main() function. The debug session of the auxiliary core application is highlighted. After clicking the “Resume” button, it is applied to the auxiliary core debug session. Therefore, the auxiliary core application continues its execution.




At this point, it is possible to suspend and resume individual cores independently. It is also possible to make synchronous suspension and resumption of both the cores. This is done either by selecting both opened debug sessions (multiple selections) and clicking the “Suspend” / “Resume” control button, or just using the “Suspend All Debug sessions” and the “Resume All Debug sessions” buttons.






**Build a TrustZone example application** This section describes the steps required to configure MCUXpresso IDE to build, run, and debug TrustZone example applications. The TrustZone version of the hello\_world example application targeted for the MIMXRT595-EVK hardware platform is used as an example, though these steps can be applied to any TrustZone example application in the MCUXpresso SDK.

1. TrustZone examples are imported into the workspace in a similar way as single core applications. When the SDK zip package for MIMXRT595-EVK is installed and available in the **Installed SDKs** view, click **Import SDK example(s)...** on the Quickstart Panel. In the window that appears, expand the **MIMXRT500** folder and select **MIMXRT595S**. Then, select **evkmimxrt595** and click **Next**.
2. Expand the `trustzone_examples/` folder and select `hello_world_s`. Because TrustZone examples are linked together, the non-secure project is automatically imported with the secure project, and there is no need to select it explicitly. Then, click **Finish**.




- Now, two projects should be imported into the workspace. To start building the TrustZone application, highlight the `evkmimxrt595_hello_world_s` project (TrustZone master project) in the Project Explorer. Then, choose the appropriate build target, **Debug** or **Release**, by clicking the downward facing arrow next to the hammer icon, as shown in following figure. For this example, select the **Debug** target.




The project starts building after the build target is selected. It is requested to build the application for the secure project first, because the non-secure project must know the secure project since CMSE library when running the linker. It is not possible to finish the non-secure project linker when the secure project since CMSE library is not ready.

**Note:** When the **Release** build is requested, it is necessary to change the build configuration of both the secure and non-secure application projects first. To do this, select both projects in the Project Explorer view by clicking to select the first project, then using shift-click or control-click to select the second project. Right click in the Project Explorer view to display the context-sensitive menu and select **Build Configurations > Set Active > Release**. This is also possible by using the menu item of **Project > Build Configuration > Set Active > Release**. After switching to the **Release** build configuration. Build the application for the secure project first.



**Run a TrustZone example application** To download and run the application, perform all steps as described in **Run an example application**. These steps are common for single core, and TrustZone applications, ensuring <board\_name>\_hello\_world\_s is selected for debugging.

In the Quickstart Panel, click **Debug** to launch the second debug session.



Now, the TrustZone sessions should be opened. Click **Resume**. The `hello_world` TrustZone application then starts running, and the secure application starts the non-secure application during runtime.

**Run a demo application using IAR** This section describes the steps required to build, run, and debug example applications provided in the MCUXpresso SDK.

**Note:** IAR Embedded Workbench for Arm version 8.32.3 is used in the following example, and the IAR toolchain should correspond to the latest supported version, as described in the *MCUXpresso SDK Release Notes*.

**Build an example application** Do the following steps to build the `hello_world` example application.


1. Open the desired demo application workspace. Most example application workspace files can be located using the following path:

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/iar
```


Other example applications may have additional folders in their path.

2. Select the desired build target from the drop-down menu.

For this example, select **hello\_world – debug**.




3. To build the demo application, click **Make**, highlighted in red in following figure.



4. The build completes without errors.

**Run an example application** To download and run the application, perform these steps:

1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via USB cable.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug COM port (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in the board.h file)
  2. No parity
  3. 8 data bits




4. 1 stop bit

4. In IAR, click the **Download and Debug** button to download the application to the target.



5. The application is then downloaded to the target and automatically runs to the `main()` function.



6. Run the code by clicking the **Go** button.

7. The `hello_world` application is now running and a banner is displayed on the terminal. If it does not appear, check your terminal settings and connections.



**Build a multicore example application** This section describes the steps to build and run a dual-core application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/multicore_examples/<application_name>/<core_type>/iar
```

Begin with a simple dual-core version of the Hello World application. The multicore Hello World IAR workspaces are located in this folder:

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm0plus/iar/hello_world_cm0plus.  
↪ eww
```


```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm4/iar/hello_world_cm4.eww
```

Build both applications separately by clicking the **Make** button. Build the application for the auxiliary core (cm0plus) first, because the primary core application project (cm4) must know the auxiliary core application binary when running the linker. It is not possible to finish the primary core linker when the auxiliary core application binary is not ready.


**Run a multicore example application** The primary core debugger handles flashing both primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform steps 1 – 4 as described in **Run an example application**. These steps are common for both single core and dual-core applications in IAR.

After clicking the “Download and Debug” button, the auxiliary core project is opened in the separate EWARM instance. Both the primary and auxiliary images are loaded into the device flash memory and the primary core application is executed. It stops at the default C language entry point in the `*main()*function`.

Run both cores by clicking the “Start all cores” button to start the multicore application.



During the primary core code execution, the auxiliary core is released from the reset. The `hello_world` multicore application is now running and a banner is displayed on the terminal. If this does not appear, check the terminal settings and connections.



An LED controlled by the auxiliary core starts flashing, indicating that the auxiliary core has been released from the reset and is running correctly. When both cores are running, use the “Stop all cores”, and “Start all cores” control buttons to stop or run both cores simultaneously.

**Build a TrustZone example application** This section describes the particular steps that must be done in order to build and run a TrustZone application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/iar/  
↪<application_name>_ns/iar
```

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/[<core_type>]/iar/  
↪<application_name>_s/iar
```

Begin with a simple TrustZone version of the Hello World application. The TrustZone Hello World IAR workspaces are located in this folder:


```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_ns/iar/hello_world_  
↪ns.eww
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/iar/hello_world_s.  
↪eww
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/iar/hello_world.eww
```


This project `hello_world.eww` contains both secure and non-secure projects in one workspace and it allows the user to easily transition from one project to another. Build both applications separately by clicking **Make**. It is requested to build the application for the secure project first, because the non-secure project must know the secure project, since the CMSE library is running the linker. It is not possible to finish the non-secure project linker with the secure project since CMSE library is not ready.

**Run a TrustZone example application** The secure project is configured to download both secure and non-secure output files, so debugging can be fully managed from the secure project. To download and run the TrustZone application, switch to the secure application project and perform steps 1 – 4 as described in **Run an example application**. These steps are common for both single core, and TrustZone applications in IAR. After clicking **Download and Debug**, both the secure and non-secure images are loaded into the device memory, and the secure application is executed. It stops at the `Reset_Handler` function.




Run the code by clicking **Go** to start the application.

The TrustZone hello\_world application is now running and a banner is displayed on the terminal. If this is not true, check your terminal settings and connections.




**Note:** If the application is running in RAM (debug/release build target), in **Options\*\*>\*\*Debugger > Download** tab, disable **Use flash loader(s)**. This can avoid the `_ns` download issue on i.MXRT500.



**Run a demo using Keil MDK/µVision** This section describes the steps required to build, run, and debug example applications provided in the MCUXpresso SDK.

**Install CMSIS device pack** After the MDK tools are installed, Cortex Microcontroller Software Interface Standard (CMSIS) device packs must be installed to fully support the device from a debug perspective. These packs include things such as memory map information, register definitions, and flash programming algorithms. Follow these steps to install the appropriate CMSIS pack.

1. Open the MDK IDE, which is called µVision. In the IDE, select the **Pack Installer** icon.



2. After the installation finishes, close the Pack Installer window and return to the µVision IDE.

### Build an example application

1. Open the desired example application workspace in:

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/mdk
```

The workspace file is named as <demo\_name>.uvmpw. For this specific example, the actual path is:


2. To build the demo project, select **Rebuild**, highlighted in red.



3. The build completes without errors.


**Run an example application** To download and run the application, perform these steps:

1. Ensure the host driver for the debugger firmware has been installed. See [On-board debugger](#).
2. Connect the development platform to your PC via USB cable using USB connector.
3. Open the terminal application on the PC, such as PuTTY or TeraTerm and connect to the debug serial port number (to determine the COM port number, see [How to determine COM port](#)). Configure the terminal with these settings:
  1. 115200 or 9600 baud rate, depending on your board (reference BOARD\_DEBUG\_UART\_BAUDRATE variable in the board.h file)
  2. No parity
  3. 8 data bits




4. 1 stop bit


4. In  $\mu$ Vision, after the application is built, click the **Download** button to download the application to the target.



5. After clicking the **Download** button, the application downloads to the target and is running. To debug the application, click the **Start/Stop Debug Session** button, highlighted in red.



6. Run the code by clicking the **Run** button to start the application.



The hello\_world application is now running and a banner is displayed on the terminal. If this does not appear, check your terminal settings and connections.



**Build a multicore example application** This section describes the steps to build and run a dual-core application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/multicore_examples/<application_name>/<core_type>/mdk
```

Begin with a simple dual-core version of the Hello World application. The multicore Hello World Keil MSDK/μVision workspaces are located in this folder:


```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm0plus/mdk/hello_world_
→cm0plus.uvmpw
```

```
<install_dir>/boards/lpcxpresso54114/multicore_examples/hello_world/cm4/mdk/hello_world_cm4.uvmpw
```

Build both applications separately by clicking the **Rebuild** button. Build the application for the auxiliary core (cm0plus) first because the primary core application project (cm4) must know the auxiliary core application binary when running the linker. It is not possible to finish the primary core linker when the auxiliary core application binary is not ready.


**Run a multicore example application** The primary core debugger flashes both the primary and the auxiliary core applications into the SoC flash memory. To download and run the multicore application, switch to the primary core application project and perform steps 1 – 5 as described in **Run an example application**. These steps are common for both single-core and dual-core applications in μVision.

Both the primary and the auxiliary image is loaded into the device flash memory. After clicking the “Run” button, the primary core application is executed. During the primary core code execution, the auxiliary core is released from the reset. The hello\_world multicore application is now running and a banner is displayed on the terminal. If this does not appear, check your terminal settings and connections.



An LED controlled by the auxiliary core starts flashing indicating that the auxiliary core has been released from the reset and is running correctly.

Attach the running application of the auxiliary core by opening the auxiliary core project in the second  $\mu$ Vision instance and clicking the “Start/Stop Debug Session” button. After this, the second debug session is opened and the auxiliary core application can be debugged.



Arm describes multicore debugging using the NXP LPC54114 Cortex-M4/M0+ dual-core processor and Keil uVision IDE in Application Note 318 at [www.keil.com/appnotes/docs/apnt\\_318.asp](http://www.keil.com/appnotes/docs/apnt_318.asp). The associated video can be found [here](#).

**Build a TrustZone example application** This section describes the particular steps that must be done in order to build and run a TrustZone application. The demo applications workspace files are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/<application_name>_ns/
↪ mdk
```

```
<install_dir>/boards/<board_name>/trustzone_examples/<application_name>/<application_name>_s/
↪ mdk
```

Begin with a simple TrustZone version of the Hello World application. The TrustZone Hello World Keil MSDK/ $\mu$ Vision workspaces are located in this folder:

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_ns/mdk/hello_world_
↪ ns.uvmpw
```

```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/mdk/hello_world_s.
↪ uvmpw
```


```
<install_dir>/boards/<board_name>/trustzone_examples/hello_world/hello_world_s/mdk/hello_world.  
→ uvmpw
```

This project `hello_world.uvmpw` contains both secure and non-secure projects in one workspace and it allows the user to easily transition from one project to another.

Build both applications separately by clicking **Rebuild**. It is requested to build the application for the secure project first, because the non-secure project must know the secure project since CMSE library is running the linker. It is not possible to finish the non-secure project linker with the secure project because CMSE library is not ready.


**Run a TrustZone example application** The secure project is configured to download both secure and non-secure output files so debugging can be fully managed from the secure project.

To download and run the TrustZone application, switch to the secure application project and perform steps as described in **Run an example application**. These steps are common for single core, dual-core, and TrustZone applications in  $\mu$ Vision. After clicking **Download and Debug**, both the secure and non-secure images are loaded into the device flash memory, and the secure application is executed. It stops at the `main()` function.



Run the code by clicking **Run** to start the application.

The `hello_world` application is now running and a banner is displayed on the terminal. If not, check your terminal settings and connections.



**Run a demo using ARMGCC / VSCODE** This section describes the steps to run an example application from the SDK archive using the ARMGCC / VSCODE toolchain.

Refer to the [running a demo using MCUXpresso VSC](#) section for detailed instructions on setting up and configuring your project in Visual Studio Code.

Refer to the [CLI](#) section for detailed instructions on building and running your project from the command line.

**MCUXpresso Config Tools** MCUXpresso Config Tools can help configure the processor and generate initialization code for the on chip peripherals. The tools are able to modify any existing example project, or create a new configuration for the selected board or processor. The generated code is designed to be used with MCUXpresso SDK version 24.12.00 or later.

Following table describes the tools included in the MCUXpresso Config Tools.

| Config Tool                      | Description                                                                                                                                                                    | Image                                                                                 |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| <b>Pins tool</b>                 | For configuration of pin routing and pin electrical properties.                                                                                                                |    |
| <b>Clock tool</b>                | For system clock configuration                                                                                                                                                 |    |
| <b>Peripherals tools</b>         | For configuration of other peripherals                                                                                                                                         |   |
| <b>TEE tool</b>                  | Configures access policies for memory area and peripherals helping to protect and isolate sensitive parts of the application.                                                  |  |
| <b>Device Configuration tool</b> | Configures Device Configuration Data (DCD) contained in the program image that the Boot ROM code interprets to set up various on-chip peripherals prior to the program launch. |  |

MCUXpresso Config Tools can be accessed in the following products:

- **Integrated** in the MCUXpresso IDE. Config tools are integrated with both compiler and debugger which makes it the easiest way to begin the development.
- **Standalone version** available for download from [www.nxp.com/mcuxpresso](http://www.nxp.com/mcuxpresso). Recommended for customers using IAR Embedded Workbench, Keil MDK µVision, or Arm GCC.
- **Online version** available on [mcuxpresso.nxp.com](http://mcuxpresso.nxp.com). Recommended doing a quick evaluation of the processor or use the tool without installation.

Each version of the product contains a specific *Quick Start Guide* document MCUXpresso IDE Config Tools installation folder that can help start your work.

**How to determine COM port** This section describes the steps necessary to determine the debug COM port number of your NXP hardware development platform. All NXP boards ship with a factory programmed, onboard debug interface, whether it is based on MCU-Link or the legacy OpenSDA, LPC-Link2, P&E Micro OSJTAG interface. To determine what your specific board ships with, see [Default debug interfaces](#).

1. **Linux:** The serial port can be determined by running the following command after the USB Serial is connected to the host:

```
$ dmesg | grep "ttyUSB"
[503175.307873] usb 3-12: cp210x converter now attached to ttyUSB0
[503175.309372] usb 3-12: cp210x converter now attached to ttyUSB1
```

There are two ports, one is for core0 debug console and the other is for core1.


2. **Windows:** To determine the COM port open Device Manager in the Windows operating system. Click the **Start** menu and type **Device Manager** in the search bar.

In the Device Manager, expand the **Ports (COM & LPT)** section to view the available ports. The COM port names are different for all the NXP boards.


1. **CMSIS-DAP/mbed/DAPLink** interface:




2. **P&E Micro:**




3. **J-Link:**



4. **P&E Micro OSJTAG:**



5. **MRB-KW01:**



**On-board Debugger** This section describes the on-board debuggers used on NXP development boards.

**On-board debugger MCU-Link** MCU-Link is a powerful and cost effective debug probe that can be used seamlessly with MCUXpresso IDE, and is also compatible with 3rd party IDEs that support CMSIS-DAP protocol. MCU-Link also includes a USB to UART bridge feature (VCOM) that can be used to provide a serial connection between the target MCU and a host computer. MCU-Link features a high-speed USB interface for high performance debug. MCU-Link is compatible with Windows, MacOS and Linux. A free utility from NXP provides an easy way to install firmware updates.

On-board MCU-Link debugger supports CMSIS-DAP and J-Link firmware. See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**

- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](https://developer.mbed.org/handbook/Windows-serial-configuration) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.

- If using J-Link with either a standalone debug pod or MCU-Link, install the J-Link software (drivers and utilities) from [www.segger.com/jlink-software.html](http://www.segger.com/jlink-software.html).

**Updating MCU-Link firmware** This firmware in this debug interface may be updated using the host computer utility called MCU-Link. This typically used when switching between the default debugger protocol (CMSIS-DAP) to SEGGER J-Link, or for updating this firmware with new releases of these. This section contains the steps to reprogram the debug probe firmware.

**Note:** If MCUXpresso IDE is used and the jumper making DFULink is installed on the board (JP5 on some boards, but consult the board user manual or schematic for specific jumper number), MCU-Link debug probe boots to DFU mode, and MCUXpresso IDE automatically downloads the CMSIS-DAP firmware to the probe before flash memory programming (after clicking **Debug**). Using DFU mode ensures that most up-to-date/compatible firmware is used with MCUXpresso IDE.

NXP provides the MCU-Link utility, which is the recommended tool for programming the latest versions of CMSIS-DAP and J-Link firmware onto MCU-Link or NXP boards. The utility can be downloaded from [MCU-Link](#).

These steps show how to update the debugger firmware on your board for Windows operating system.

1. Install the MCU-Link utility.
2. Unplug the board's USB cable.
3. Make the DFU link (install the jumper labeled DFULink).
4. Connect the probe to the host via USB (use Link USB connector).
5. Open a command shell and call the appropriate script located in the MCU-Link installation directory (<MCU-Link install dir>).
  1. To program CMSIS-DAP debug firmware: <MCU-Link install dir>/scripts/program\_CMSIS
  2. To program J-Link debug firmware: <MCU-Link install dir>/scripts/program\_JLINK
6. Remove DFU link (remove the jumper installed in Step 3).
7. Repower the board by removing the USB cable and plugging it in again.

**On-board debugger LPC-Link** LPC-Link 2 is an extensible debug probe that can be used seamlessly with MCUXpresso IDE, and is also compatible with 3rd party IDEs that support CMSIS-DAP protocol. MCU-Link also includes a USB to UART bridge feature (VCOM) that can be used to provide a serial connection between the target MCU and a host computer. LPC-Link 2 is compatible with Windows, MacOS and Linux. A free utility from NXP provides an easy way to install firmware updates.

On-board LPC-Link 2 debugger supports CMSIS-DAP and J-Link firmware. See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**

- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](http://developer.mbed.org/handbook/Windows-serial-configuration) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.
- If using J-Link with either a standalone debug pod or MCU-Link, install the J-Link software (drivers and utilities) from [www.segger.com/jlink-software.html](http://www.segger.com/jlink-software.html).

**Updating LPC-Link firmware** The LPCXpresso hardware platform comes with a CMSIS-DAP-compatible debug interface (known as LPC-Link2). This firmware in this debug interface may be updated using the host computer utility called LPCScript. This typically used when switching between the default debugger protocol (CMSIS-DAP) to SEGGER J-Link, or for updating this firmware with new releases of these. This section contains the steps to reprogram the debug probe firmware.

**Note:** If MCUXpresso IDE is used and the jumper making DFULink is installed on the board (JP5 on some boards, but consult the board user manual or schematic for specific jumper number), LPC-Link2 debug probe boots to DFU mode, and MCUXpresso IDE automatically downloads the CMSIS-DAP firmware to the probe before flash memory programming (after clicking **Debug**). Using DFU mode ensures that most up-to-date/compatible firmware is used with MCUXpresso IDE.

NXP provides the LPCScript utility, which is the recommended tool for programming the latest versions of CMSIS-DAP and J-Link firmware onto LPC-Link2 or LPCXpresso boards. The utility can be downloaded from [LPCScript](#).

These steps show how to update the debugger firmware on your board for Windows operating system. For Linux OS, follow the instructions described in LPCScript user guide ([LPCScript](#), select **LPCScript**, and then the documentation tab).

1. Install the LPCScript utility.
2. Unplug the board's USB cable.
3. Make the DFU link (install the jumper labeled DFULink).
4. Connect the probe to the host via USB (use Link USB connector).
5. Open a command shell and call the appropriate script located in the LPCScript installation directory (<LPCScript install dir>).
  1. To program CMSIS-DAP debug firmware: <LPCScript install dir>/scripts/program\_CMSIS
  2. To program J-Link debug firmware: <LPCScript install dir>/scripts/program\_JLINK
6. Remove DFU link (remove the jumper installed in Step 3).
7. Repower the board by removing the USB cable and plugging it in again.

**On-board debugger OpenSDA** OpenSDA/OpenSDAv2 is a serial and debug adapter that is built into several NXP evaluation boards. It provides a bridge between your computer (or other USB host) and the embedded target processor, which can be used for debugging, flash programming, and serial communication, all over a simple USB cable.

The difference is the firmware implementation: OpenSDA: Programmed with the proprietary P&E Micro developed bootloader. P&E Micro is the default debug interface app. OpenSDAv2: Programmed with the open-sourced CMSIS-DAP/mbed bootloader. CMSIS-DAP is the default debug interface app.

See the table in [Default debug interfaces](#) to determine the default debug interface that comes loaded on your specific hardware platform.

**The corresponding host driver must be installed before debugging.**


- For boards with CMSIS-DAP firmware, visit [developer.mbed.org/handbook/Windows-serial-configuration](https://developer.mbed.org/handbook/Windows-serial-configuration) and follow the instructions to install the Windows operating system serial driver. If running on Linux OS, this step is not required.
- For boards with a P&E Micro interface, see [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.

**Updating OpenSDA firmware** Any NXP hardware platform that comes with an OpenSDA-compatible debug interface has the ability to update the OpenSDA firmware. This typically means to switch from the default application (either CMSIS-DAP or P&E Micro) to a SEGGER J-Link. This section contains the steps to switch the OpenSDA firmware to a J-Link interface. However, the steps can be applied to restoring the original image also. For reference, OpenSDA firmware files can be found at the links below:

- J-Link: Download appropriate image from [www.segger.com/opensda.html](http://www.segger.com/opensda.html). Choose the appropriate J-Link binary based on the table in [Default debug interfaces](#). Any OpenSDA v1.0 interface should use the standard OpenSDA download (in other words, the one with no version). For OpenSDA 2.0 or 2.1, select the corresponding binary.
- CMSIS-DAP: CMSIS-DAP OpenSDA firmware is available at [www.nxp.com/opensda](http://www.nxp.com/opensda).
- P&E Micro: Downloading P&E Micro OpenSDA firmware images requires registration with P&E Micro ([www.pemicro.com](http://www.pemicro.com)).

Perform the following steps to update the OpenSDA firmware on your board for Windows and Linux OS users:

1. Unplug the board's USB cable.
2. Press the **Reset** button on the board. While still holding the button, plug the USB cable back into the board.
3. When the board re-enumerates, it shows up as a disk drive called **MAINTENANCE**.



4. Drag and drop the new firmware image onto the MAINTENANCE drive.

**Note:** If for any reason the firmware update fails, the board can always reenter maintenance mode by holding down **Reset** button and power cycling.

These steps show how to update the OpenSDA firmware on your board for Mac OS users.

1. Unplug the board's USB cable.
2. Press the **Reset** button of the board. While still holding the button, plug the USB cable back into the board.
3. For boards with OpenSDA v2.0 or v2.1, it shows up as a disk drive called **BOOTLOADER** in **Finder**. Boards with OpenSDA v1.0 may or may not show up depending on the bootloader version. If you see the drive in **Finder**, proceed to the next step. If you do not see the drive in **Finder**, use a PC with Windows OS 7 or an earlier version to either update the OpenSDA firmware, or update the OpenSDA bootloader to version 1.11 or later. The bootloader update instructions and image can be obtained from P&E Microcomputer website.
4. For OpenSDA v2.1 and OpenSDA v1.0 (with bootloader 1.11 or later) users, drag the new firmware image onto the BOOTLOADER drive in **Finder**.
5. For OpenSDA v2.0 users, type these commands in a Terminal window:

```
> sudo mount -u -w -o sync /Volumes/BOOTLOADER  
> cp -X <path to update file> /Volumes/BOOTLOADER
```

**Note:** If for any reason the firmware update fails, the board can always reenter bootloader mode by holding down the **Reset** button and power cycling.

**On-board debugger Multilink** An on-board Multilink debug circuit provides a JTAG interface and a power supply input through a single micro-USB connector. It is a hardware interface that allows PC software to debug and program a target processor through its debug port.

**The host driver must be installed before debugging.**

- See [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.

**On-board debugger OSJTAG** An on-board OSJTAG debug circuit provides a JTAG interface and a power supply input through a single micro-USB connector. It is a hardware interface that allows PC software to debug and program a target processor through its debug port.

**The host driver must be installed before debugging.**

- See [PE micro](#) to download and install the P&E Micro Hardware Interface Drivers package.

**Default debug interfaces** The MCUXpresso SDK supports various hardware platforms that come loaded with various factory programmed debug interface configurations. The following table lists the hardware platforms supported by the MCUXpresso SDK, their default debug firmware, and any version information that helps differentiate a specific interface configuration.

| Hardware platform | Default debugger firmware | On-board debugger probe |
|-------------------|---------------------------|-------------------------|
| EVK-MCIMX7ULP     | N/A                       | N/A                     |
| EVK-MIMX8MM       | N/A                       | N/A                     |
| EVK-MIMX8MN       | N/A                       | N/A                     |
| EVK-MIMX8MNDDR3L  | N/A                       | N/A                     |
| EVK-MIMX8MP       | N/A                       | N/A                     |
| EVK-MIMX8MQ       | N/A                       | N/A                     |
| EVK-MIMX8ULP      | N/A                       | N/A                     |
| EVK-MIMXRT1010    | CMSIS-DAP                 | LPC-Link2               |
| EVK-MIMXRT1015    | CMSIS-DAP                 | LPC-Link2               |
| EVK-MIMXRT1020    | CMSIS-DAP                 | LPC-Link2               |
| EVK-MIMXRT1064    | CMSIS-DAP                 | LPC-Link2               |
| EVK-MIMXRT595     | CMSIS-DAP                 | LPC-Link2               |
| EVK-MIMXRT685     | CMSIS-DAP                 | LPC-Link2               |
| EVK9-MIMX8ULP     | N/A                       | N/A                     |
| EVKB-IMXRT1050    | CMSIS-DAP                 | LPC-Link2               |
| FRDM-K22F         | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-K32L2A4S     | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-K32L2B       | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-K32L3A6      | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-KE02Z40M     | P&E Micro                 | OpenSDA v1              |
| FRDM-KE15Z        | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-KE16Z        | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-KE17Z        | CMSIS-DAP                 | OpenSDA v2              |
| FRDM-KE17Z512     | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA153      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA156      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA174      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA266      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA344      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA346      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXA366      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXC041      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXC242      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXC444      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXE247      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXE31B      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXN236      | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXN947      | CMSIS-DAP                 | MCU-Link                |

continues on next page

Table 1 – continued from previous page

| Hardware platform | Default debugger firmware | On-board debugger probe |
|-------------------|---------------------------|-------------------------|
| FRDM-MCXW23       | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXW71       | CMSIS-DAP                 | MCU-Link                |
| FRDM-MCXW72       | CMSIS-DAP                 | MCU-Link                |
| FRDM-RW612        | CMSIS-DAP                 | MCU-Link                |
| IMX943-EVK        | N/A                       | N/A                     |
| IMX95LP4XEVK-15   | N/A                       | N/A                     |
| IMX95LPD5EVK-19   | N/A                       | N/A                     |
| IMX95VERDINEVK    | N/A                       | N/A                     |
| KW45B41Z-EVK      | CMSIS-DAP                 | MCU-Link                |
| KW45B41Z-LOC      | CMSIS-DAP                 | MCU-Link                |
| KW47-EVK          | CMSIS-DAP                 | MCU-Link                |
| KW47-LOC          | CMSIS-DAP                 | MCU-Link                |
| LPC845BREAKOUT    | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso51U68   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso54628   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso54S018  | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso54S018M | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso55S06   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso55S16   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso55S28   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso55S36   | CMSIS-DAP                 | MCU-Link                |
| LPCXpresso55S69   | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso802     | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso804     | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso824MAX  | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso845MAX  | CMSIS-DAP                 | LPC-Link2               |
| LPCXpresso860MAX  | CMSIS-DAP                 | LPC-Link2               |
| MC56F80000-EVK    | P&E Micro                 | Multilink               |
| MC56F81000-EVK    | P&E Micro                 | Multilink               |
| MC56F83000-EVK    | P&E Micro                 | OSJTAG                  |
| MCIMX93-EVK       | N/A                       | N/A                     |
| MCIMX93-QSB       | N/A                       | N/A                     |
| MCIMX93AUTO-EVK   | N/A                       | N/A                     |
| MCX-N5XX-EVK      | CMSIS-DAP                 | MCU-Link                |
| MCX-N9XX-EVK      | CMSIS-DAP                 | MCU-Link                |
| MCX-W71-EVK       | CMSIS-DAP                 | MCU-Link                |
| MCX-W72-EVK       | CMSIS-DAP                 | MCU-Link                |
| MIMXRT1024-EVK    | CMSIS-DAP                 | LPC-Link2               |
| MIMXRT1040-EVK    | CMSIS-DAP                 | LPC-Link2               |
| MIMXRT1060-EVKB   | CMSIS-DAP                 | LPC-Link2               |
| MIMXRT1060-EVKC   | CMSIS-DAP                 | MCU-Link                |
| MIMXRT1160-EVK    | CMSIS-DAP                 | LPC-Link2               |
| MIMXRT1170-EVKB   | CMSIS-DAP                 | MCU-Link                |
| MIMXRT1180-EVK    | CMSIS-DAP                 | MCU-Link                |
| MIMXRT685-AUD-EVK | CMSIS-DAP                 | LPC-Link2               |
| MIMXRT700-EVK     | CMSIS-DAP                 | MCU-Link                |
| RD-RW612-BGA      | CMSIS-DAP                 | MCU-Link                |
| TWR-KM34Z50MV3    | P&E Micro                 | OpenSDA v1              |
| TWR-KM34Z75M      | P&E Micro                 | OpenSDA v1              |
| TWR-KM35Z75M      | CMSIS-DAP                 | OpenSDA v2              |
| TWR-MC56F8200     | P&E Micro                 | OSJTAG                  |
| TWR-MC56F8400     | P&E Micro                 | OSJTAG                  |

**How to define IRQ handler in CPP files** With MCUXpresso SDK, users could define their own IRQ handler in application level to override the default IRQ handler. For example, to override the default PIT\_IRQHandler define in startup\_DEVICE.s, application code like app.c can be implement like:

```
// c
void PIT_IRQHandler(void)
{
    // Your code
}
```

When application file is CPP file, like app.cpp, then `extern "C"` should be used to ensure the function prototype alignment.

```
// cpp
extern "C" {
    void PIT_IRQHandler(void);
}
void PIT_IRQHandler(void)
{
    // Your code
}
```

## Repository-Layout SDK Package

**Development Tools Installation** This guide explains how to install the essential tools for development with the MCUXpresso SDK.

**Quick Start: Automated Installation (Recommended)** The **MCUXpresso Installer** is the fastest way to get started. It automatically installs all the basic tools you need.

1. **Download the MCUXpresso Installer** from: [Dependency-Installation](#)
2. **Run the installer** and select “**MCUXpresso SDK Developer**” from the menu
3. **Click Install** and let it handle everything automatically

**Manual Installation** If you prefer to install tools manually or need specific versions, follow these steps:

## Essential Tools

**Git - Version Control** **What it does:** Manages code versions and downloads SDK repositories from GitHub.

### Installation:

- Visit [git-scm.com](https://git-scm.com)
- Download for your operating system
- Run installer with default settings
- **Important:** Make sure “Add Git to PATH” is selected during installation

### Setup:

```
git config --global user.name "Your Name"
git config --global user.email "youremail@example.com"
```

**Python - Scripting Environment** **What it does:** Runs build scripts and SDK tools.

**Installation:**

- Install Python **3.10 or newer** from [python.org](https://python.org)
- **Important:** Check “Add Python to PATH” during installation

**West - SDK Management Tool** **What it does:** Manages SDK repositories and provides build commands. The west tool is developed by the Zephyr project for managing multiple repositories.

**Installation:**

```
pip install -U west
```

**Minimum version:** 1.2.0 or newer

## Build System Tools

**CMake - Build Configuration** **What it does:** Configures how your projects are built.

**Recommended version:** 3.30.0 or newer

**Installation:**

- **Windows:** Download .msi installer from [cmake.org/download](https://cmake.org/download)
- **Linux:** Use package manager or download from [cmake.org](https://cmake.org)
- **macOS:** Use Homebrew (brew install cmake) or download from [cmake.org](https://cmake.org)

**Ninja - Fast Build System** **What it does:** Compiles your code quickly.

**Minimum version:** 1.12.1 or newer

**Installation:**

- **Windows:** Usually included, or download from [ninja-build.org](https://ninja-build.org)
- **Linux:** sudo apt install ninja-build or download binary
- **macOS:** brew install ninja or download binary

**Ruby - IDE Project Generation (Optional)** **What it does:** Generates project files for IDEs like IAR and Keil.

**When needed:** Only if you want to use traditional IDEs instead of VS Code.

**Installation:** Follow the Ruby environment setup guide

**Compiler Toolchains** Choose and install the compiler toolchain you want to use:

| Toolchain                       |                  |  | Best For                 | Download Link                 |                     | Environment Variable |
|---------------------------------|------------------|--|--------------------------|-------------------------------|---------------------|----------------------|
| <b>ARM GCC</b><br>(Recommended) |                  |  | Most users, free         | <a href="#">ARM Toolchain</a> | <a href="#">GNU</a> | ARMGCC_DIR           |
|                                 | <b>IAR EWARM</b> |  | Professional development | <a href="#">IAR Systems</a>   |                     | IAR_DIR              |
| <b>Keil MDK</b>                 |                  |  | ARM ecosystem            | <a href="#">ARM Developer</a> |                     | MDK_DIR              |
| <b>ARM Compiler</b>             |                  |  | Advanced optimization    | <a href="#">ARM Developer</a> |                     | ARMCLANG_DIR         |

**Setting Up Environment Variables** After toolchain installation, set an environment variable so the build system locates it:

**Windows:**

```
# Example for ARM GCC installed in C:\armgcc
setx ARMGCC_DIR "C:\armgcc"
```

**Linux/macOS:**

```
# Add to ~/.bashrc or ~/.zshrc
export ARMGCC_DIR="/usr" # or your installation path
```

**Verify Your Installation** After installation, verify everything works by opening a terminal/command prompt and running these commands:

```
# Check each tool - you should see version numbers
git --version
python --version
west --version
cmake --version
ninja --version
arm-none-eabi-gcc --version # (if using ARM GCC)
```

**Troubleshooting Installation Issues** “Command not found” errors:

- The tool isn’t in your system PATH
- **Solution:** Add the installation directory to your PATH environment variable

**Python/pip issues:**

- Try using python3 and pip3 instead of python and pip
- On Windows, run the Command Prompt as an Administrator

**Slow downloads:**

- Add timeout option: `pip install -U west --default-timeout=1000`
- Use alternative mirror: `pip install -U west -i https://pypi.tuna.tsinghua.edu.cn/simple`

**Building Your First Project** This guide explains how to build and run your first SDK example project using the west build system. This applies to both GitHub Repository SDK and Repository-Layout SDK Package.

**Prerequisites**

- GitHub Repository SDK workspace initialized OR Repository-Layout SDK Package extracted
- Development board connected via USB
- Build tools installed per [Installation Guide](#)

**Understanding Board Support** Use the west extension to discover available examples for your board:

```
west list _project -p examples/demo_apps/hello_world
```

This shows all supported build configurations. You can filter by toolchain:

```
west list _project -p examples/demo_apps/hello_world -t armgcc
```

## Basic Build Process

**Simple Build** Build the hello\_world example with default settings:

```
west build -b your_board examples/demo_apps/hello_world
```

The default toolchain is armgcc, and the build system will select the first debug target as default if no config is specified.

## Specifying Configuration

```
# Release build
west build -b your_board examples/demo_apps/hello_world --config release
```

```
# Debug build (default)
west build -b your_board examples/demo_apps/hello_world --config debug
```

## Alternative Toolchains

```
# IAR toolchain
west build -b your_board examples/demo_apps/hello_world --toolchain iar
```

```
# Other toolchains as supported by the example
```

**Multicore Applications** For multicore devices, specify the core ID:

```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config ↵
↵ flexspi_nor_debug
```

For multicore projects using sysbuild:

```
west build -b evkbmimxrt1170 --sysbuild ./examples/multicore_examples/hello_world/primary -Dcore_ ↵
↵ id=cm7 --config flexspi_nor_debug --toolchain=armgcc -p always
```

**Flash an Application** Flash the built application to your board:

```
west flash -r linkserver
```

**Debug** Start a debug session:

```
west debug -r linkserver
```

## Common Build Options

**Clean Build** Force a complete rebuild:

```
west build -b your_board examples/demo_apps/hello_world -p always
```

**Dry Run** See the commands that get executed without running them:

```
west build -b your_board examples/demo_apps/hello_world --dry-run
```

**Device Variants** For boards supporting multiple device variants:

```
west build -b your_board examples/demo_apps/hello_world --device DEVICE_PART_NUMBER --config ↵  
↵release
```

## Project Configuration

**CMake Configuration Only** Run configuration without building:

```
west build -b your_board examples/demo_apps/hello_world -Dcore_id=cm7 --cmake-only -p
```

**Interactive Configuration** Launch the configuration GUI:

```
west build -t guiconfig
```

## Troubleshooting

**Build Failures** Use pristine builds to resolve dependency issues:

```
west build -b your_board examples/demo_apps/hello_world -p always
```

**Getting Help** View the help information for west build:

```
west build -h
```

**Check Supported Configurations** To see available configuration options and board targets for an example, refer to the below command:

```
west list_project -p examples/demo_apps/hello_world
```

## Next Steps

- Explore other examples in the SDK
- Learn about [Command Line Development](#) for advanced options
- Try [VS Code Development](#) for integrated development
- Refer [Workspace Structure](#) to understand the SDK layout

**MCUXpresso for VS Code Development** This guide covers using MCUXpresso for VS Code extension to build, debug, and develop SDK applications with an integrated development environment.

## Prerequisites

- SDK workspace initialized (GitHub Repository SDK or Repository-Layout SDK Package)
- Development tools installed per [Installation Guide](#)
- Visual Studio Code installed
- MCUXpresso for VS Code extension installed


## Extension Installation

**Install MCUXpresso for VS Code** The MCUXpresso for VS Code extension provides integrated development capabilities for MCUXpresso SDK projects. Refer to the [MCUXpresso for VS Code Wiki](#) for detailed installation and setup instructions.

## SDK Import and Setup


**Import Methods** The SDK can be imported in several ways. The MCUXpresso for VS Code extension supports both GitHub Repository SDK and Repository-Layout SDK Package distributions.

**Import GitHub Repository SDK** Click **Import Repository** from the **QUICKSTART PANEL**




**Note:** You can import the SDK in several ways. Refer to [MCUXpresso for VS Code Wiki](#) for details.

Select **Local** if you've already obtained the SDK according to [setting up the repo](#). Select your location and click **Import**.




**Import Repository-Layout SDK Package** Click **Import Repository** from the **QUICKSTART**




**PANEL**

Select **Local** if you've already unzipped the Repository-Layout SDK Package. Select your location and click **Import**.




Else if the SDK is ZIP archive, select **Local Archive**, browse to the downloaded SDK ZIP file, fill the link of expect location, then click **Import**.



## Building Example Applications

### Import Example Project


1. Click **Import Example from Repository** from the **QUICKSTART PANEL**



2. Configure project settings:

- **MCUXpresso SDK:** Select your imported SDK
- **Arm GNU Toolchain:** Choose toolchain
- **Board:** Select your target development board
- **Template:** Choose example category
- **Application:** Select specific example (e.g., hello\_world)
- **App type:** Choose between Repository applications or Freestanding applications

3. Click **Import**



**Application Types**   **Repository Applications:**

- Located inside the MCUXpresso SDK
- Integrated with SDK workspace

#### Freestanding Applications:


- Imported to user-defined location
- Independent of SDK location

**Trust Confirmation** VS Code will prompt you to confirm if the imported files are trusted. Click **Yes** to proceed.

## Building Projects

### Build Process

1. Navigate to **PROJECTS** view
2. Find your project
3. Click the **Build Project** icon




The integrated terminal will display build output at the bottom of the VS Code window.

## Running and Debugging

### Serial Monitor Setup


1. Open **Serial Monitor** from VS Code's integrated terminal



2. Configure serial settings:
  - **VCom Port:** Select port for your device
  - **Baud Rate:** Set to 115200

## Debug Session


1. Navigate to **PROJECTS** view
2. Click the play button to initiate a debug session



The debug session will begin with debug controls initially at the top of the interface.


**Debug Controls** Use the debug controls to manage execution:

- **Continue:** Resume code execution
- **Step controls:** Navigate through code



- **Stop:** Terminate debug session

**Monitor Output** Observe application output in the **Serial Monitor** to verify correct operation.



**Debug Probe Support** For comprehensive information on debug probe support and configuration, refer to the [MCUXpresso for VS Code Wiki DebugK section](#).

## Project Configuration

**Workspace Management** The extension integrates with the MCUXpresso SDK workspace structure, providing access to:

- Example applications
- Board configurations
- Middleware components
- Build system integration

**Multi-Project Support** The PROJECTS view allows management of multiple imported projects within the same workspace.

## Troubleshooting

### Import Issues SDK not detected:

- Verify SDK workspace is properly initialized
- Ensure all required repositories are updated
- Check SDK manifest files are present

### Project import failures:

- Confirm board support exists for selected example
- Verify toolchain installation
- Check example compatibility with selected board

### Build Problems Build failures:

- Check integrated terminal for error messages
- Verify all dependencies are installed
- Ensure toolchain is properly configured

### Debug Issues    Debug session fails:

- Verify board connection via USB
- Check debug probe drivers are installed
- Confirm build completed successfully

### Serial monitor problems:

- Verify correct VCom port selection
- Check baud rate configuration (115200)
- Ensure board drivers are installed

**Integration with Command Line**    MCUXpresso for VS Code integrates with the underlying west build system, allowing seamless integration with command line workflows described in [Command Line Development](#).

## Advanced Features

**Project Types**    The extension supports both repository-based and freestanding project types, providing flexibility in project organization and SDK integration.

**Build System Integration**    The extension leverages the MCUXpresso SDK build system, providing access to all build configurations and options available through command line tools.

### Next Steps

- Explore additional examples in the SDK
- Review [Command Line Development](#) for advanced build options
- Refer [MCUXpresso for VS Code Wiki](#) for detailed documentation
- Learn about [SDK Architecture](#) for better understanding of the development environment

**Command Line Development**    This guide covers developing with the MCUXpresso SDK using command line tools and the west build system. This workflow applies to both GitHub Repository SDK and Repository-Layout SDK Package distributions.

### Prerequisites

- GitHub Repository SDK workspace initialized OR Repository-Layout SDK Package extracted
- Development tools installed per [Installation Guide](#)
- Target board connected via USB

**Understanding Board Support**    Use the west extension to discover available examples for your board:

```
west list _project -p examples/demo_apps/hello_world
```

This shows all supported build configurations. You can filter by toolchain:

```
west list _project -p examples/demo_apps/hello_world -t armgcc
```

## Basic Build Commands

**Standard Build Process** Build with default settings (armgcc toolchain, first debug config):

```
west build -b your_board examples/demo_apps/hello_world
```

## Specifying Build Configuration

# Release build

```
west build -b your_board examples/demo_apps/hello_world --config release
```

# Debug build with specific toolchain

```
west build -b your_board examples/demo_apps/hello_world --toolchain iar --config debug
```

**Multicore Applications** For multicore devices, specify the core ID:

```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config ↵
↪ flexspi_nor_debug
```

For multicore projects using sysbuild:

```
west build -b evkbmimxrt1170 --sysbuild ./examples/multicore_examples/hello_world/primary -Dcore_
↪ id=cm7 --config flexspi_nor_debug --toolchain=armgcc -p always
```

**Shield Support** For boards with shields:

```
west build -b mimxrt700evk --shield a8974 examples/issdk_examples/sensors/fxls8974cf/fxls8974cf_poll -
↪ Dcore_id=cm33_core0
```

## Advanced Build Options

**Clean Builds** Force a complete rebuild:

```
west build -b your_board examples/demo_apps/hello_world -p always
```

**Dry Run** See what commands would be executed:

```
west build -b your_board examples/demo_apps/hello_world --dry-run
```

**Device Variants** For boards supporting multiple device variants:

```
west build -b your_board examples/demo_apps/hello_world --device MK22F12810 --config release
```

## Project Configuration

**CMake Configuration Only** Run configuration without building:

```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world -Dcore_id=cm7 --cmake-only -p
```

**Interactive Configuration** Launch the configuration GUI:

```
west build -t guiconfig
```

## Flashing and Debugging

**Flash Application** Flash the built application to your board:

```
west flash -r linkserver
```

**Debug Session** Start a debugging session:

```
west debug -r linkserver
```

**IDE Project Generation** Generate IDE project files for traditional IDEs:

```
# Generate IAR project
west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config_
↪ flexspi_nor_debug -p always -t guiproject
```

IDE project files are generated in mcuxsdk/build/<toolchain> folder.

**Note:** Ruby installation is required for IDE project generation. See [Installation Guide](#) for setup instructions.

## Troubleshooting

**Build Failures** Use pristine builds to resolve dependency issues:

```
west build -b your_board examples/demo_apps/hello_world -p always
```

**Toolchain Issues** Verify environment variables are set correctly:

```
# Check ARM GCC
echo $ARMGCC_DIR
arm-none-eabi-gcc --version

# Check IAR (if using)
echo $IAR_DIR
```

**Getting Help** Display help information:

```
west build -h
west flash -h
west debug -h
```

**Check Supported Configurations** If unsure about supported options for an example:

```
west list_project -p examples/demo_apps/hello_world
```

## Best Practices

### Project Organization

- Keep custom projects outside the SDK tree
- Use version control for your application code
- Document any SDK modifications

### Build Efficiency

- Use `-p` always for clean builds when troubleshooting
- Leverage `--dry-run` to understand build processes
- Use specific configs and toolchains to reduce build time

### Development Workflow

1. Start with existing examples closest to your requirements
2. Copy and modify rather than building from scratch
3. Test with `hello_world` before moving to complex examples
4. Use configuration tools for pin muxing and clock setup

### Next Steps

- Explore [VS Code Development](#) for integrated development experience
- Review [Workspace Structure](#) to understand SDK organization
- Refer build system documentation for advanced configurations

**Workspace Structure** After you initialize your SDK workspace, it creates a specific directory structure that organizes all SDK components. This structure is identical for both GitHub Repository SDK and Repository-Layout SDK Package.

### Top-Level Organization

```
your-sdk-workspace/  
  manifests/      # West manifest repository  
  mcuxsdk/        # Main SDK content
```

The `mcuxsdk/` directory serves as your primary working directory and contains all the SDK components.

**SDK Component Layout** Based on the actual SDK structure, the main directories include:

| Di-<br>rec-<br>tory | Contents                                                                                                                                                                                            | Purpose                                             |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| arch/               | Architecture-specific files                                                                                                                                                                         | ARM CMSIS, build configurations                     |
| cmake/              | Build system modules                                                                                                                                                                                | CMake configuration and build rules                 |
| compo               | Software components                                                                                                                                                                                 | Reusable software libraries and utilities           |
| devices             | Device support packages                                                                                                                                                                             | MCU-specific headers, startup code, linker scripts  |
| drivers             | Peripheral drivers                                                                                                                                                                                  | Hardware abstraction layer for MCU peripherals      |
| examp               | Sample applications                                                                                                                                                                                 | Demonstration code and reference implementations    |
| middle              | Optional software stacks                                                                                                                                                                            | Networking, graphics, security, and other libraries |
| rtos/               | Operating system support                                                                                                                                                                            | FreeRTOS integration                                |
| scripts             | Build and utility scripts                                                                                                                                                                           | West extensions and development tools               |
| svd                 | Svd files for devices, this is optional because of large size. Customers run <code>west manifest config group.filter +optional</code> and <code>west update mcux-soc-svd</code> to get this folder. |                                                     |

**Example Organization** Examples follow a two-tier structure separating common code from board-specific implementations:

### Common Example Files

```
examples/demo_apps/hello_world/
  CMakeLists.txt      # Build configuration
  example.yml         # Example metadata
  hello_world.c       # Application source code
  Kconfig             # Configuration options
  readme.md           # General documentation
```

### Board-Specific Files

```
examples/_boards/your_board/demo_apps/hello_world/
  app.h               # Board specific application header
  example_board_readme.md # Board specific documentation
  hardware_init.c     # Board specific hardware initialization
  pin_mux.c           # Pin multiplexing configuration
  pin_mux.h           # Pin multiplexing header definitions
  hello_world.bin     # Pre-built binary for quick testing
  hello_world.mex     # MCUXpresso Config Tools project file
  prj.conf            # Board specific Kconfig configuration
  reconfig.cmake      # Board specific cmake configuration overrides
```

**Device Support Structure** Device support is organized hierarchically by MCU family:

```
devices/
  MCX/          # MCU portfolio
    MCXW/       # MCU family
      MCXW235/  # Specific device
        MCXW235.h # Device register definitions
      drivers/   # Device-specific drivers
      gcc/       # GNU toolchain files
      iar/       # IAR toolchain files
      mcuxpresso/ # MCUXpresso IDE files
      startup_MCXW235.c # Startup and vector table
      system_MCXW235.c # System initialization
```

**Middleware Organization** Middleware components are categorized by functionality and maintained in separate repositories. Based on the manifest files, common middleware categories include:

- **Connectivity:** USB, TCP/IP, industrial protocols
- **Security:** Cryptographic libraries, secure boot
- **Wireless:** Bluetooth, IEEE 802.15.4, Wi-Fi
- **Graphics:** Display drivers, UI frameworks
- **Audio:** Processing libraries, voice recognition
- **Machine Learning:** Inference engines, neural networks
- **Safety:** IEC60730B safety libraries
- **Motor Control:** Motor control and real-time control libraries

**Documentation Structure** SDK documentation is distributed across multiple locations:

- docs/ - Core SDK documentation and build infrastructure
- Component repositories - API documentation and integration guides
- Board directories - Hardware-specific setup instructions

For complete documentation, refer to the [online documentation](#).

**Understanding Example Structure** Each example has **two README files**:

**1. General README:** examples/demo\_apps/hello\_world/readme.md

- What the example does
- General functionality description
- Common usage information

**2. Board-Specific README:** examples/\_boards/{board\_name}/demo\_apps/hello\_world/example\_board\_readme.md

- Board-specific setup instructions
- Hardware connections required
- Board-specific behavior notes

**Tip:** Always check both readme files - start with the general one, then read the board-specific one for detailed setup.

## 1.3 Getting Started with MCUXpresso SDK GitHub

### 1.3.1 Getting Started with MCUXpresso SDK Repository

Welcome to the **GitHub Repository SDK Guide**. This documentation provides instructions for setting up and working with the MCUXpresso SDK distributed in a **multi-repository model**. The SDK is distributed across multiple GitHub repositories and managed using the **Zephyr West** tool, enabling modular development and streamlined workflows.

#### Overview

The GitHub Repository SDK approach offers:

- **Modular Structure:** Multiple repositories for flexibility and scalability.
- **Zephyr West Integration:** Simplified repository management and synchronization.
- **Cross-Platform Support:** Designed for MCUXpresso SDK development environments.

#### Benefits of the Multi-Repository Approach

- **Scalability:** Easily add or update components without impacting the entire SDK.
- **Collaboration:** Enables distributed development across teams and repositories.
- **Version Control:** Independent versioning for components ensures better stability.
- **Automation:** Zephyr West simplifies dependency handling and repository synchronization.

#### Setup and Configuration

Follow these steps to prepare your development environment:

**GitHub Repository Setup** This guide explains how to initialize your MCUXpresso SDK workspace from GitHub repositories using the west tool. The GitHub Repository SDK uses multiple repositories hosted on GitHub to provide modular, flexible development.

**Prerequisites** Verify the requirements:

#### System Requirements:

- Python 3.8 or later
- Git 2.25 or later
- CMake 3.20 or later
- Build tools for your target platform

#### Verification Commands:

```
python --version  # Should show 3.8+
git --version     # Should show 2.25+
cmake --version   # Should show 3.20+
west --version    # Should show west tool installation
```

**Workspace Initialization** The GitHub Repository SDK uses the Zephyr west tool to manage multiple repositories containing different SDK components.

**Step 1: Initialize Workspace** Create and initialize your SDK workspace from GitHub:

**Get the latest SDK from main branch:**

```
west init -m https://github.com/nxp-mcuxpresso/mcuxsdk-manifests.git mcuxpresso-sdk
```

**Get SDK at specific revision:**

```
west init -m https://github.com/nxp-mcuxpresso/mcuxsdk-manifests.git mcuxpresso-sdk --mr {revision}
```

*Note: Replace {revision} with the desired release tag, such as v25.09.00*

**Step 2: Choose Your Repository Update Strategy** Navigate to the SDK workspace:

```
cd mcuxpresso-sdk
```

The west tool manages multiple GitHub repositories containing different SDK components. You have two options for downloading:

**Option A: Download All Repositories (Complete SDK)** Download all SDK repositories for comprehensive development:

```
west update
```

This command downloads all the repositories defined in the manifest from GitHub. Initial download takes several minutes and requires ~7 GB of disk space.

**Best for:**

- Exploring the complete SDK
- Multi-board development projects
- Comprehensive middleware evaluation

**Option B: Targeted Repository Download (Recommended)** Download only repositories needed for your specific board or device to save time and disk space:

```
# For specific board development
west update_board --set board your_board_name

# For specific device family development
west update_board --set device your_device_name

# List available repositories before downloading
west update_board --set board your_board_name --list-repo
```

**Best for:**

- Single board development

- Faster setup and reduced disk usage
- Focused development workflows

### Examples:

```
# Update only repositories for FRDM-MCXW23 board
west update_board --set board frdm-mcxw23

# Update only repositories for MCXW23 device family
west update_board --set device mcxw23
```

### Step 3: Verify Installation Confirm successful setup:

```
# Verify workspace structure
ls -la
# Should show: manifests/ and mcuxsdk/ directories

# Test build system
west list_project -p examples/demo_apps/hello_world
# Should display available build configurations
```

**Advanced Repository Management** The west extension command `update_board` provides advanced repository management capabilities for optimized workspace setup with GitHub repositories.

### Board-Specific Setup Update only repositories required for a specific board:

```
# Update only repositories for specific board, e.g., frdm-mcxw23
west update_board --set board frdm-mcxw23

# List available repositories for the board before updating
west update_board --set board frdm-mcxw23 --list-repo
```

### Device-Specific Setup Update only repositories required for a specific device family:

```
# Update only repositories for specific device, e.g., MCXW235
west update_board --set device mcxw23

# List available repositories for the device family
west update_board --set device mcxw23 --list-repo
```

**Custom Configuration** For advanced users who want to create custom repository combinations:

```
# Use custom configuration file
west update_board --set custom path/to/custom-config.yml

# Generate custom configuration template
cp manifests/boards/custom.yml.template my-custom-config.yml
```

### Benefits of Targeted Setup Reduced Download Size

- Download only components needed for your target board or device
- Significantly faster initial setup for focused development

- Typical reduction from 7 GB to 2GB

### Optimized Workspace

- Cleaner workspace with relevant components only
- Reduced disk space usage
- Faster repository operations

### Flexible Development

- Switch between different board configurations easily
- Maintain separate workspaces for different projects
- Include optional components as needed

**Repository Information** Before setting up your workspace, you can explore what repositories are available:

```
# Display repository information in console
west update_board --set board frdm-mcxw23 --list-repo

# Export repository information to YAML file for reference
west update_board --set board frdm-mcxw23 --list-repo -o board-repos.yml
```

This command lists all the available repositories with descriptions and outlines the included components in the workspace.

**Package Generation (Optional)** The `update_board` command can also generate ZIP packages for offline distribution:

```
# Generate board-specific SDK package
west update_board --set board frdm-mcxw23 -o frdm-mcxw23-sdk.zip
```

**Note:** Package generation is primarily intended for creating custom SDK distributions. For regular development, use the workspace update commands without the `-o` option.

## Workspace Management

**Updating Your Workspace** Keep your SDK current with latest updates from GitHub:

### For Complete SDK Workspace:

```
# Update manifest repository
cd manifests
git pull

# Update all component repositories
cd ..
west update
```

### For Targeted Workspace:

```
# Update manifest repository
cd manifests
git pull

# Update board-specific repositories
cd ..
west update_board --set board your_board_name
```

**Workspace Status** Check workspace synchronization status:

```
# Show status of all repositories
west status
```

```
# Show detailed information about repositories
west list
```

### Troubleshooting Network Issues:

- Use `west update --keep-descendants` for partial failures
- Configure Git credentials for private repositories
- Check firewall settings for Git protocol access

### Permission Issues:

- Ensure write permissions in workspace directory
- Run commands without `sudo`/administrator privileges
- Verify Git SSH key configuration for authenticated access

### Disk Space:

- Full SDK workspace requires approximately 7-8 GB
- Targeted workspace typically requires 1-2 GB
- Use board-specific setup to reduce workspace size

### Repository Management Issues:

- Verify board/device names match available configurations
- Check that custom YAML files follow the correct template format
- Use `--list-repo` to verify available repositories before setup

**Next Steps** With your workspace initialized:

1. Review [Workspace Structure](#) to understand the layout
2. Build your first project with [First Build Guide](#)
3. Explore [Development Workflows MCUXpresso VSCode](#) or [Development Workflows Command Line](#) for the details on project setup and execution

For advanced repository management, see the [west tool documentation](#).

## Explore SDK Structure and Content

Learn about the organization of the SDK and its components:

**SDK Architecture Overview** The MCUXpresso SDK uses a modular architecture where software components are distributed across multiple repositories hosted on GitHub and managed through the west tool. This approach provides flexibility, maintainability, and enables selective component inclusion.

**Repository Organization** Based on the manifest structure, the SDK consists of four main repository categories:

**Manifest Repository** The manifest repo (mcuxsdk-manifests) contains the west.yml manifest file that tracks all other repositories in the SDK.

**Base Repositories** Recorded in submanifests/base.yml and loaded in the root west.yml manifest file. These are the foundational repositories that build the SDK:

- **Devices:** MCU-specific support packages
- **Examples:** Demonstration applications and code samples
- **Boards:** Board support packages

**Middleware Repositories** Recorded in the submanifests/middleware subdirectory, categorized according to functionality:

- **Connectivity:** Networking stacks, USB, and communication protocols
- **Security:** Cryptographic libraries and secure boot components
- **Wireless:** Bluetooth, IEEE 802.15.4, and other wireless protocols
- **Graphics:** Display drivers and UI frameworks
- **Audio:** Audio processing and voice recognition libraries
- **Machine Learning:** AI inference engines and neural network libraries
- **Safety:** IEC60730B safety libraries
- **Motor Control:** Motor control and real-time control libraries

**Internal Repositories** Recorded in submanifests/internal.yml and grouped into the “bifrost” group. These are only visible to NXP internal developers and hosted on NXP internal git servers.

**Repository Hosting** Public repositories are hosted on GitHub under these organizations:

- [nxp-mcuxpresso](#)
- [NXP](#)
- [nxp-zephyr](#)

Internal repositories are hosted on NXP's private Git infrastructure.

**Benefits of This Architecture** **Selective Integration:** Projects include only required components, reducing memory footprint and build complexity.

**Independent Versioning:** Each component maintains its own release cycle and version control.

**Community Collaboration:** Public repositories accept community contributions through standard Git workflows.

**Scalable Maintenance:** Component owners can update their repositories without affecting the entire SDK.

**Workspace Management** The west tool manages repository synchronization, version tracking, and workspace updates. All repositories are checked out under the mcuxsdk/ directory with their designated paths defined in the manifest files.

## Development Workflows

Get started with building and running projects:

**Using MCUXpresso Config Tools** MCUXpresso Config tools provide a user-friendly way to configure hardware initialization of your projects. This guide explains the basic workflow with the MCUXpresso SDK west build system and the Config Tools.

### Prerequisites

- GitHub Repository SDK workspace initialized OR Repository-Layout SDK Package extracted
- MCUXpresso Config Tools standalone installed (version 25.09 or above)
- MCUXpresso SDK Project that can be successfully built

**Board Files** MCUXpresso Config Tools generate source files for the board. These files include `pin_mux.c/h` and `clock_config.c/h`. The files contain initialization code functions that reflect the hardware configuration in the Config Tools. Within the SDK codebase, these files are specific for the board and either shared by multiple example projects or specific for one example. Open or import the configuration from the SDK project in the Config Tools and customize the settings to match the custom board or specific project use case and regenerate the code. See *User Guide for MCUXpresso Config Tools (Desktop)* (document [GSMCUXCTUG](#)) for details.

**Note:** When opening the configuration for SDK example projects, the board files may be shared across multiple examples. To ensure a separate copy of the board configuration files exists, create a freestanding project with copied board files.

**Visual Studio Code** To open the configuration in Visual Studio Code, use the context menu for the project to access Config Tools. See [MCUXpresso Extension Documentation](#) for details. Otherwise, use the manual workflow described in detail in the following section.

**Manual Workflow** Use the following steps:

1. Before using Config Tools, run the west command to get the project information for Config Tools from the SDK project files, for example:

```
west cfg_project_info -b lpcxpresso55s69 ...mcuxsdk/examples/demo_apps/hello_world/ -Dcore_
↪id=cm33_core0
```

This results in the creation of the project information json file that is searched by the config tools when the configuration is created. The parameters of the command should match the build parameters that will be used for the project.

2. Launch the MCUXpresso Config Tools and in the **Start development** wizard, select **Create a new configuration based on the existing IDE/Toolchain project**. Select the created “cfg\_tools” subfolder as a project folder (for example: `...mcuxsdk/examples/demo_apps/hello_world/cfg_tools/`).

**Updating the SDK West project** **Note:** Updating project is supported with Config Tools V25.12 or newer only.

Changes in the Config tools generated source code modules may require adjustments to the toolchain project to ensure a successful build. These changes may mean, for example, adding the newly generated files, adding include paths, required drivers, or other SDK components.

This section describes how to manually resolve the changes needed in the project within the toolchain projects based on the SDK project managed by the West tool.

After the configuration in the Config Tools is finished, write updated files to the disk using the 'Update Code' command. The written files include a json file with the required changes for the toolchain project.

To resolve the changes in the project in the terminal, launch the west command that updates the project. For example:

```
west cfg_resolve -b lpcxpresso55s69 ...mcuxsdk/examples/demo_apps/hello_world/ -Dcore_id=cm33_core0
```

This command updates the appropriate cmake and kconfig files to address the changes. After this, the application can be built.

**Note:** The `cfg_resolve` command supports additional arguments. Launch the `west cfg_resolve -h` command to get the list and description.

## 1.4 Release Notes

### 1.4.1 MCUXpresso SDK Release Notes

#### Overview

The MCUXpresso SDK is a comprehensive software enablement package designed to simplify and accelerate application development with Arm Cortex-M-based devices from NXP, including its general purpose, crossover and Bluetooth-enabled MCUs. MCUXpresso SW and Tools for DSC further extends the SDK support to current 32-bit Digital Signal Controllers. The MCUXpresso SDK includes production-grade software with integrated RTOS (optional), integrated enabling software technologies (stacks and middleware), reference software, and more.

In addition to working seamlessly with the MCUXpresso IDE, the MCUXpresso SDK also supports and provides example projects for various toolchains. The Development tools chapter in the associated Release Notes provides details about toolchain support for your board. Support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

Underscoring our commitment to high quality, the MCUXpresso SDK is MISRA compliant and checked with Coverity static analysis tools. For details on MCUXpresso SDK, see [MCUXpresso-SDK: Software Development Kit for MCUXpresso](#).

#### MCUXpresso SDK

As part of the MCUXpresso software and tools, MCUXpresso SDK is the evolution of Kinetis SDK, includes support for LPC, DSC, PN76, and i.MX System-on-Chip (SoC). The same drivers, APIs, and middleware are still available with support for Kinetis, LPC, DSC, and i.MX silicon. The MCUXpresso SDK adds support for the MCUXpresso IDE, an Eclipse-based toolchain that works with all MCUXpresso SDKs. Easily import your SDK into the new toolchain to access to all of the available components, examples, and demos for your target silicon. In addition to the MCUXpresso IDE, support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

In order to maintain compatibility with legacy Freescale code, the filenames and source code in MCUXpresso SDK containing the legacy Freescale prefix FSL has been left as is. The FSL prefix has been redefined as the NXP Foundation Software Library.

## Development tools

The MCUXpresso SDK was tested with following development tools. Same versions or above are recommended.

- MCUXpresso IDE, Rev. 25.06.xx
- IAR Embedded Workbench for Arm, version is 9.60.4
- Keil MDK, version is 5.42
- MCUXpresso for VS Code v25.12
- GCC Arm Embedded Toolchain 14.2.x

## Supported development systems

This release supports board and devices listed in following table. The board and devices in bold were tested in this release.

| Devel-<br>opment<br>boards | MCU devices                       |                                 |                                           |
|----------------------------|-----------------------------------|---------------------------------|-------------------------------------------|
| <b>TWR-<br/>KM34Z50MV</b>  | MKM14Z128ACHH5,<br>MKM33Z128ACLL5 | MKM14Z64ACHH5,<br>MKM33Z64ACLL5 | MKM33Z128ACLLH5,<br><b>MKM34Z128ACLL5</b> |

## MCUXpresso SDK release package

The MCUXpresso SDK release package content is aligned with the silicon subfamily it supports. This includes the boards, CMSIS, devices, middleware, and RTOS support.

**Device support** The device folder contains the whole software enablement available for the specific System-on-Chip (SoC) subfamily. This folder includes clock-specific implementation, device register header files, device register feature header files, and the system configuration source files. Included with the standard SoC support are folders containing peripheral drivers, toolchain support, and a standard debug console. The device-specific header files provide a direct access to the microcontroller peripheral registers. The device header file provides an overall SoC memory mapped register definition. The folder also includes the feature header file for each peripheral on the microcontroller. The toolchain folder contains the startup code and linker files for each supported toolchain. The startup code efficiently transfers the code execution to the main() function.

**Board support** The boards folder provides the board-specific demo applications, driver examples, and middleware examples.

**Demo application and other examples** The demo applications demonstrate the usage of the peripheral drivers to achieve a system level solution. Each demo application contains a readme file that describes the operation of the demo and required setup steps. The driver examples demonstrate the capabilities of the peripheral drivers. Each example implements a common use case to help demonstrate the driver functionality.

## RTOS

**FreeRTOS** Real-time operating system for microcontrollers from Amazon

## Middleware

**CMSIS DSP Library** The MCUXpresso SDK is shipped with the standard CMSIS development pack, including the prebuilt libraries.

**TinyCBOR** Concise Binary Object Representation (CBOR) Library

**PKCS#11** The PKCS#11 standard specifies an application programming interface (API), called “Cryptoki,” for devices that hold cryptographic information and perform cryptographic functions. Cryptoki follows a simple object based approach, addressing the goals of technology independence (any kind of device) and resource sharing (multiple applications accessing multiple devices), presenting to applications a common, logical view of the device called a “cryptographic token”.

**llhttp** HTTP parser llhttp

**FreeMASTER** FreeMASTER communication driver for 32-bit platforms.

## Release contents

Provides an overview of the MCUXpresso SDK release package contents and locations.

| Deliverable                                                                          | Location                                           |
|--------------------------------------------------------------------------------------|----------------------------------------------------|
| Boards                                                                               | INSTALL_DIR/boards                                 |
| Demo Applications                                                                    | INSTALL_DIR/boards/<board_name>/demo_apps          |
| Driver Examples                                                                      | INSTALL_DIR/boards/<board_name>/driver_examples    |
| eIQ examples                                                                         | INSTALL_DIR/boards/<board_name>/eiq_examples       |
| Board Project Template for MCUXpresso IDE NPW                                        | INSTALL_DIR/boards/<board_name>/project_template   |
| Driver, SoC header files, extension header files and feature header files, utilities | INSTALL_DIR/devices/<device_name>                  |
| CMSIS drivers                                                                        | INSTALL_DIR/devices/<device_name>/cmsis_drivers    |
| Peripheral drivers                                                                   | INSTALL_DIR/devices/<device_name>/drivers          |
| Toolchain linker files and startup code                                              | INSTALL_DIR/devices/<device_name>/<toolchain_name> |
| Utilities such as debug console                                                      | INSTALL_DIR/devices/<device_name>/utilities        |
| Device Project Template for MCUXpresso IDE NPW                                       | INSTALL_DIR/devices/<device_name>/project_template |
| CMSIS Arm Cortex-M header files, DSP library source                                  | INSTALL_DIR/CMSIS                                  |
| Components and board device drivers                                                  | INSTALL_DIR/components                             |
| RTOS                                                                                 | INSTALL_DIR/rtos                                   |
| Release Notes, Getting Started Document and other documents                          | INSTALL_DIR/docs                                   |
| Tools such as shared cmake files                                                     | INSTALL_DIR/tools                                  |
| Middleware                                                                           | INSTALL_DIR/middleware                             |

## Known issues

This section lists the known issues, limitations, and/or workarounds.

## Cannot add SDK components into FreeRTOS projects

It is not possible to add any SDK components into FreeRTOS project using the MCUXpresso IDE New Project wizard.

## 1.5 ChangeLog

### 1.5.1 MCUXpresso SDK Changelog

#### Board Support Files

##### board

###### [25.06.00]

- Initial version

##### clock\_config

###### [25.06.00]

- Initial version

##### pin\_mux

###### [25.06.00]

- Initial version
- 

#### ADC16

###### [2.3.0]

- Improvements
  - Added new API `ADC16_EnableAsynchronousClockOutput()` to enable/disable ADACK output.
  - In `ADC16_GetDefaultConfig()`, set `enableAsynchronousClock` to false.

###### [2.2.0]

- Improvements
  - Added hardware average mode in `adc_config_t` structure, then the hardware average mode can be set by invoking `ADC16_Init()` function.

###### [2.1.0]

- New Features:
  - Supported KM series' new ADC reference voltage source, bandgap from PMC.

**[2.0.3]**

- Bug Fixes
  - Fixed IAR warning Pa082: the order of volatile access should be defined.

**[2.0.2]**

- Improvements
  - Used conversion control feature macro instead of that in IO map.

**[2.0.1]**

- Bug Fixes
  - Fixed MISRA-2012 rules.
    - \* Rule 16.4, 10.1, 13.2, 14.4 and 17.7.

**[2.0.0]**

- Initial version
- 

**AFE****[2.0.3]**

- Improvements
  - Fixed CERT-C issues

**[2.0.2]**

- Bug Fixes
  - Fixed MISRA C-2012 rule 10.1, rule 10.4 and so on.

**[2.0.1]**

- Improvements
  - Changed type modifiers from `const xx_Type * s_xxBases` to `xx_Type *const s_xxBases`.
  - Added static modifier for `s_xxx` variables defined in drivers.

**[2.0.0]**

- Initial version.
- 

**CLOCK****[2.0.1]**

- Bug Fixes
  - Fixed an issue that in `CLOCK_SetFbeMode()` C4 register not updated.

#### [2.0.0]

- Initial version.
- 

### CMP

#### [2.0.3]

- Improvements
  - Updated to clear CMP settings in DeInit function.

#### [2.0.2]

- Bug Fixes
  - Fixed the violations of MISRA 2012 rules:
    - \* Rule 10.3

#### [2.0.1]

- Bug Fixes
  - Fixed MISRA-2012 rules.
    - \* Rule 14.4, rule 10.3, rule 10.1, rule 10.4 and rule 17.7.

#### [2.0.0]

- Initial version.
- 

### COMMON

#### [2.6.3]

- New Features
  - Added bit mask inversion macros to avoid type promotion.
  - Added register operation macros.
- Improvements
  - Make function `MSDK_EnableCpuCycleCounter` compatible with CMSIS-5 and CMSIS-6.
- Bug Fixes
  - Fixed build issue of CMSIS PACK BSP example caused by CMSIS 6.1 issue.

#### [2.6.2]

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule for implicit conversions in boolean contexts

**[2.6.1]**

- Improvements
  - Support Cortex M23.

**[2.6.0]**

- Bug Fixes
  - Fix CERT-C violations.

**[2.5.0]**

- New Features
  - Added new APIs `InitCriticalSectionMeasurementContext`, `DisableGlobalIRQEx` and `EnableGlobalIRQEx` so that user can measure the execution time of the protected sections.

**[2.4.3]**

- Improvements
  - Enable irqs that mount under `irqsteer` interrupt extender.

**[2.4.2]**

- Improvements
  - Add the macros to convert peripheral address to secure address or non-secure address.

**[2.4.1]**

- Improvements
  - Improve for the macro redefinition error when integrated with `zephyr`.

**[2.4.0]**

- New Features
  - Added `EnableIRQWithPriority`, `IRQ_SetPriority`, and `IRQ_ClearPendingIRQ` for ARM.
  - Added `MSDK_EnableCpuCycleCounter`, `MSDK_GetCpuCycleCount` for ARM.

**[2.3.3]**

- New Features
  - Added `NETC` into status group.

**[2.3.2]**

- Improvements
  - Make driver `aarch64` compatible

### [2.3.1]

- Bug Fixes
  - Fixed MAKE\_VERSION overflow on 16-bit platforms.

### [2.3.0]

- Improvements
  - Split the driver to common part and CPU architecture related part.

### [2.2.10]

- Bug Fixes
  - Fixed the ATOMIC macros build error in cpp files.

### [2.2.9]

- Bug Fixes
  - Fixed MISRA C-2012 issue, 5.6, 5.8, 8.4, 8.5, 8.6, 10.1, 10.4, 17.7, 21.3.
  - Fixed SDK\_Malloc issue that not allocate memory with required size.

### [2.2.8]

- Improvements
  - Included stddef.h header file for MDK tool chain.
- New Features:
  - Added atomic modification macros.

### [2.2.7]

- Other Change
  - Added MECC status group definition.

### [2.2.6]

- Other Change
  - Added more status group definition.
- Bug Fixes
  - Undef \_\_VECTOR\_TABLE to avoid duplicate definition in cmsis\_clang.h

### [2.2.5]

- Bug Fixes
  - Fixed MISRA C-2012 rule-15.5.

**[2.2.4]**

- Bug Fixes
  - Fixed MISRA C-2012 rule-10.4.

**[2.2.3]**

- New Features
  - Provided better accuracy of SDK\_DelayAtLeastUs with DWT, use macro SDK\_DELAY\_USE\_DWT to enable this feature.
  - Modified the Cortex-M7 delay count divisor based on latest tests on RT series boards, this setting lets result be closer to actual delay time.

**[2.2.2]**

- New Features
  - Added include RTE\_Components.h for CMSIS pack RTE.

**[2.2.1]**

- Bug Fixes
  - Fixed violation of MISRA C-2012 Rule 3.1, 10.1, 10.3, 10.4, 11.6, 11.9.

**[2.2.0]**

- New Features
  - Moved SDK\_DelayAtLeastUs function from clock driver to common driver.

**[2.1.4]**

- New Features
  - Added OTFAD into status group.

**[2.1.3]**

- Bug Fixes
  - MISRA C-2012 issue fixed.
    - \* Fixed the rule: rule-10.3.

**[2.1.2]**

- Improvements
  - Add SUPPRESS\_FALL\_THROUGH\_WARNING() macro for the usage of suppressing fallthrough warning.

**[2.1.1]**

- Bug Fixes
  - Deleted and optimized repeated macro.

### [2.1.0]

- New Features
  - Added IRQ operation for XCC toolchain.
  - Added group IDs for newly supported drivers.

### [2.0.2]

- Bug Fixes
  - MISRA C-2012 issue fixed.
    - \* Fixed the rule: rule-10.4.

### [2.0.1]

- Improvements
  - Removed the implementation of LPC8XX Enable/DisableDeepSleepIRQ() function.
  - Added new feature macro switch “FSL\_FEATURE\_HAS\_NO\_NONCACHEABLE\_SECTION” for specific SoCs which have no noncacheable sections, that helps avoid an unnecessary complex in link file and the startup file.
  - Updated the align(x) to **attribute**(aligned(x)) to support MDK v6 armclang compiler.

### [2.0.0]

- Initial version.
- 

## CRC

### [2.1.0]

- Bug fix:
  - Choosing CRC clocks from CRC clock array according to instance instead of hardcoded value.

### [2.0.5]

- Bug fix:
  - Fix CERT-C issue with boolean-to-unsigned integer conversion.

### [2.0.4]

- Improvements
  - Release peripheral from reset if necessary in init function.

### [2.0.3]

- Bug fix:
  - Fix MISRA issues.

**[2.0.2]**

- Bug fix:
  - Fix MISRA issues.

**[2.0.1]**

- Bug fix:
  - DATA and DATALL macro definition moved from header file to source file.

**[2.0.0]**

- Initial version.
- 

**DMA****[2.1.3]**

- Bug Fixes
  - Fixed coverity issues with CERT INT30-C, CERT INT31-C compliance.

**[2.1.2]**

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 10.3.

**[2.1.1]**

- Improvements
  - Corrected the dma channel feature macro from FSL\_FEATURE\_DMAMUX\_MODULE\_CHANNEL to FSL\_FEATURE\_DMA\_MODULE\_CHANNEL.

**[2.1.0]**

- Improvements
  - Added api DMA\_PrepareTransferConfig to expose option address increment.
  - Added api DMA\_EnableAutoStopRequest to support auto stop request feature.

**[2.0.2]**

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 10.4, 10.3, 14.4, 16.4, 11.6, 10.1.

**[2.0.1]**

- Bug Fixes
  - By adding parenthesis, fixed the build fail of DMA driver due to rule 12.5, MISRA C 2004.

## [2.0.0]

- Initial version.
- 

## DMAMUX

### [2.1.3]

- Improvements
  - Wrap `DMAMUX_GetInstance` into `FSL_SDK_DISABLE_DRIVER_CLOCK_CONTROL` to avoid build issues.

### [2.1.2]

- Bug Fixes
  - Add macro `FSL_DMAMUX_CHANNEL_NUM` to calculate correct DMAMUX channel number when input EDAM channel number.

### [2.1.1]

- Improvements
  - Add macro `FSL_FEATURE_DMAMUX_CHANNEL_NEEDS_ENDIAN_CONVERT` and `DMAMUX_CHANNEL_ENDIAN_CONVERTn` to do channel endian convert.

### [2.1.0]

- Improvements
  - Modify the type of parameter source from `uint32_t` to `int32_t` in the `DMA-MUX_SetSource`.

### [2.0.5]

- Improvements
  - Added feature `FSL_FEATURE_DMAMUX_CHCFG_REGISTER_WIDTH` for the difference of CHCFG register width.

### [2.0.4]

- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 10.4.

### [2.0.3]

- Bug Fixes
  - Fixed the issue for MISRA-2012 check.
    - \* Fixed rule 10.4 and rule 10.3.

#### [2.0.2]

- New Features
  - Added an always-on enable feature to a DMA channel for ULP1 DMAMUX support.

#### [2.0.1]

- Bug Fixes
  - Fixed the build warning issue by changing the type of parameter source from uint8\_t to uint32\_t when setting DMA request source in DMAMUX\_SetSourceChange.

#### [2.0.0]

- Initial version.
- 

### EWM

#### [2.0.4]

- Bug Fixes
  - Fixed CERT INT31-C violations.

#### [2.0.3]

- Bug Fixes
  - Fixed violation of MISRA C-2012 rules: 10.1, 10.3.

#### [2.0.2]

- Bug Fixes
  - Fixed violation of MISRA C-2012 rules: 10.3, 10.4.

#### [2.0.1]

- Bug Fixes
  - Fixed the hard fault in EWM\_Deinit.

#### [2.0.0]

- Initial version.
- 

### FLASH

#### [3.3.0]

- New Feature
  - Support for EEPROM Quick Write on devices with FTFC

### [3.2.0]

- New Feature
  - Basic support for FTFC

### [3.1.3]

- New Feature
  - Support 512KB flash for Kinetis E serials.

### [3.1.2]

- Bug Fixes — Remove redundant comments.

### [3.1.1]

- Bug Fixes — MISRA C-2012 issue fixed: rule 10.3

### [3.1.0]

- New Feature
  - Support erase flash asynchronously.

### [3.0.2]

- Bug Fixes — MISRA C-2012 issue fixed: rule 8.4, 17.7, 10.4, 16.1, 21.15, 11.3, 10.7 — building warning -Wnull-dereference on arm compiler v6

### [3.0.1]

- New Features
  - Added support FlexNVM alias for (kw37/38/39).

### [3.0.0]

- Improvements
  - Reorganized FTFx flash driver source file.
  - Extracted flash cache driver from FTFx driver.
  - Extracted flexnvm flash driver from FTFx driver.

### [2.3.1]

- Bug Fixes
  - Unified Flash IFR design from K3.
  - New encoding rule for K3 flash size.

**[2.3.0]**

- New Features
  - Added support for device with LP flash (K3S/G).
  - Added flash prefetch speculation APIs.
- Improvements
  - Refined flash\_cache\_clear function.
  - Reorganized the member of flash\_config\_t struct.

**[2.2.0]**

- New Features
  - Supported FTFL device in FLASH\_Swap API.
  - Supported various pflash start addresses.
  - Added support for KV58 in cache clear function.
  - Added support for device with secondary flash (KW40).
- Bug Fixes
  - Compiled execute-in-ram functions as PIC binary code for driver use.
  - Added missed flexram properties.
  - Fixed unaligned variable issue for execute-in-ram function code array.

**[2.1.0]**

- Improvements
  - Updated coding style to align with KSDK 2.0.
  - Different-alignment-size support for pflash and flexnvm.
  - Improved the implementation of execute-in-ram functions.

**[2.0.0]**

- Initial version
- 

**GPIO****[2.8.4]**

- Improvements
  - Make function GPIO\_PortGetInterruptFlags and GPIO\_PortClearInterruptFlags available for all variants, they are used for all pins flags in one GPIO port.

**[2.8.3]**

- Bug Fixes
  - Fixed violations of the MISRA C-2012 Rule 10.1, 5.7.

#### [2.8.2]

- Bug Fixes
  - Fixed COVERITY issue that GPIO\_GetInstance could return clock array overflow values due to GPIO base and clock being out of sync.

#### [2.8.1]

- Bug Fixes
  - Fixed CERT INT31-C issues.

#### [2.8.0]

- Improvements
  - Add API GPIO\_PortInit/GPIO\_PortDeinit to set GPIO clock enable and releasing GPIO reset.

#### [2.8.0]

- Improvements
  - Add API GPIO\_PortInit/GPIO\_PortDeinit to set GPIO clock enable and releasing GPIO reset.
  - Remove support for API GPIO\_GetPinsDMARequestFlags with GPIO\_ISFR\_COUNT <= 1.

#### [2.7.3]

- Improvements
  - Release peripheral from reset if necessary in init function.

#### [2.7.2]

- New Features
  - Support devices without PORT module.

#### [2.7.1]

- Bug Fixes
  - Fixed MISRA C-2012 rule 10.4 issues in GPIO\_GpioGetInterruptChannelFlags() function and GPIO\_GpioClearInterruptChannelFlags() function.

#### [2.7.0]

- New Features
  - Added API to support Interrupt select (IRQS) bitfield.

**[2.6.0]**

- New Features
  - Added API to get GPIO version information.
  - Added API to control a pin for general purpose input.
  - Added some APIs to control pin in secure and privilege status.

**[2.5.3]**

- Bug Fixes
  - Correct the feature macro typo: FSL\_FEATURE\_GPIO\_HAS\_NO\_INDEP\_OUTPUT\_CONTORL.

**[2.5.2]**

- Improvements
  - Improved GPIO\_PortSet/GPIO\_PortClear/GPIO\_PortToggle functions to support devices without Set/Clear/Toggle registers.

**[2.5.1]**

- Bug Fixes
  - Fixed wrong macro definition.
  - Fixed MISRA C-2012 rule issues in the FGPIO\_CheckAttributeBytes() function.
  - Defined the new macro to separate the scene when the width of registers is different.
  - Removed some redundant macros.
- New Features
  - Added some APIs to get/clear the interrupt status flag when the port doesn't control pins' interrupt.

**[2.4.1]**

- Improvements
  - Improved GPIO\_CheckAttributeBytes() function to support 8 bits width GACR register.

**[2.4.0]**

- Improvements
  - API interface added:
    - \* New APIs were added to configure the GPIO interrupt clear settings.

**[2.3.2]**

- Bug Fixes
  - Fixed the issue for MISRA-2012 check.
    - \* Fixed rule 3.1, 10.1, 8.6, 10.6, and 10.3.

### [2.3.1]

- Improvements
  - Removed deprecated APIs.

### [2.3.0]

- New Features
  - Updated the driver code to adapt the case of interrupt configurations in GPIO module. New APIs were added to configure the GPIO interrupt settings if the module has this feature on it.

### [2.2.1]

- Improvements
  - API interface changes:
    - \* Refined naming of APIs while keeping all original APIs by marking them as deprecated. The original APIs will be removed in next release. The main change is updating APIs with prefix of `_PinXXX()` and `_PortXXX`.

### [2.1.1]

- Improvements
  - API interface changes:
    - \* Added an API for the check attribute bytes.

### [2.1.0]

- Improvements
    - API interface changes:
      - \* Added “pins” or “pin” to some APIs’ names.
      - \* Renamed “`_PinConfigure`” to “`GPIO_PinInit`”.
- 

## I2C

### [2.0.10]

- Bug Fixes
  - Fixed coverity issues.

### [2.0.9]

- Bug Fixes
  - Fixed the MISRA-2012 violations.
    - \* Fixed rule 8.4, 10.1, 10.4, 13.5, 20.8.

**[2.0.8]**

- Bug Fixes
  - Fixed the bug that DFEN bit of I2C Status register 2 could not be set in I2C\_MasterInit.
  - MISRA C-2012 issue fixed: rule 14.2, 15.7, and 16.4.
  - Eliminated IAR Pa082 warnings from I2C\_MasterTransferDMA and I2C\_MasterTransferCallbackDMA by assigning volatile variables to local variables and using local variables instead.
  - Fixed MISRA issues.
    - \* Fixed rules 10.1, 10.3, 10.4, 11.9, 14.4, 15.7, 17.7.
- Improvements
  - Improved timeout mechanism when waiting certain state in transfer API.
  - Updated the I2C\_WAIT\_TIMEOUT macro to unified name I2C\_RETRY\_TIMES.
  - Moved the master manually acknowledge byte operation into static function I2C\_MasterAckByte.
  - Fixed control/status clean flow issue inside I2C\_MasterReadBlocking to avoid potential issue that pending status is cleaned before it's proceeded.

**[2.0.7]**

- Bug Fixes
  - Fixed the issue for MISRA-2012 check.
    - \* Fixed rule 11.9 ,15.7 ,14.4 ,10.4 ,10.8 ,10.3, 10.1, 10.6, 13.5, 11.3, 13.2, 17.7, 5.7, 8.3, 8.5, 11.1, 16.1.
  - Fixed Coverity issue of unchecked return value in I2C\_RTOS\_Transfer.
  - Fixed variable redefine issue by moving i2cBases from fsl\_i2c.h to fsl\_i2c.c.
- Improvements
  - Added I2C\_MASTER\_FACK\_CONTROL macro to enable FACK control for master transfer receive flow with IP supporting double buffer, then master could hold the SCL by manually setting TX AK/NAK during data transfer.

**[2.0.6]**

- Bug Fixes
  - Fixed the issue that I2C Master transfer APIs(blocking/non-blocking) did not support the situation of master transfer with subaddress and transfer data size being zero, which means no data followed by the subaddress.

**[2.0.5]**

- Improvements
  - Added I2C\_WATI\_TIMEOUT macro to allow the user to specify the timeout times for waiting flags in functional API and blocking transfer API.

#### [2.0.4]

- Bug Fixes
  - Added a proper handle for transfer config flag `kI2C_TransferNoStartFlag` to support transmit with `kI2C_TransferNoStartFlag` flag. Support write only or write+read with no start flag; does not support read only with no start flag.

#### [2.0.3]

- Bug Fixes
  - Removed `enableHighDrive` member in the master/slave configuration structure because the operation to `HDRS` bit is useless, the user need to use `DSE` bit in port register to configure the high drive capability.
  - Added register reset operation in `I2C_MasterInit` and `I2C_SlaveInit` APIs. Fixed issue where I2C could not switch between master and slave mode.
  - Improved slave IRQ handler to handle the corner case that stop flag and address match flag come synchronously.

#### [2.0.2]

- Bug Fixes
  - Fixed issue in master receive and slave transmit mode with no stop flag. The master could not succeed to start next transfer because the master could not send out re-start signal.
  - Fixed the out-of-order issue of data transfer due to memory barrier.
  - Added hold time configuration for slave. By leaving the SCL divider and `MULT` reset values when configured to slave mode, the setup and hold time of the slave is then reduced outside of spec for lower baudrates. This can cause intermittent arbitration loss on the master side.
- New Features
  - Added address nak event for master.
  - Added general call event for slave.

#### [2.0.1]

- New Features
  - Added double buffer enable configuration for SoCs which have the `DFEN` bit in `S2` register.
  - Added flexible transmit/receive buffer size support in `I2C_SlaveHandleIRQ`.
  - Added start flag clear, address match, and release bus operation in `I2C_SlaveWrite/ReadBlocking` API.
- Bug Fixes
  - Changed the `kI2C_SlaveRepeatedStartEvent` to `kI2C_SlaveStartEvent`.

#### [2.0.0]

- Initial version.

## IRTC

### [2.3.3]

- Bug Fixes
  - Fix CERT INT31-C issue.

### [2.3.2]

- Bug Fixes
  - Fixed API IRTC\_GetDatetime read YEARMON, DAYS, HOURMIN, SECONDS registers issue.

### [2.3.1]

- Bug Fixes
  - Fixed MISRA C-2012 issue 10.4.

### [2.3.0]

- New Feature
  - Supported platforms with multiple IRTC instances.

### [2.2.4]

- Bug Fixes
  - Fixed MISRA C-2012 issue 10.1, 10.3, 10.4, 10.7, 12.2.

### [2.2.3]

- Bug Fixes
  - Updated undefined macro names by available ones.

### [2.2.2]

- Bug Fixes
  - Fixed MISRA C-2012 issue 10.3.

### [2.2.1]

- Bug Fixes
  - Fixed MISRA issues.

### [2.2.0]

- New Feature
  - Add new APIs for CLK\_SEL and CLKO to select RTC clock and enable/disable output to peripherals.
  - Supported platforms without tamper feature.

### [2.1.3]

- Bug Fixes
  - Fixed MISRA C-2012 issue 10.1 and 10.4.

### [2.1.2]

- Bug Fixes
  - Fixed kIRTC\_TamperFlag flag can't be cleared issue.

### [2.1.1]

- Bug Fixes
  - MISRA C-2012 issue check.
    - \* Fixed rules, containing: rule-10.1, rule-10.3, rule-10.4.

### [2.1.0]

- Bug Fixes
  - Fixed incorrect leap year check in IRTC\_CheckDatetimeFormat.
- New Feature
  - Added new APIs for new feature FSL\_FEATURE\_RTC\_HAS\_SUBSYSTEM.
  - Added new APIs for TAMPER, TAMPER\_QUEUE status get and clear.
  - Added new API to enable/disable 32 kHz RTC OSC clock during RTC register write.
  - Updated IRTC\_SetTamperParams to support new feature FSL\_FEATURE\_RTC\_HAS\_FILTER23\_CFG
  - Updated irtc\_config\_t to exclude member wakeupSelect for new feature FSL\_FEATURE\_RTC\_HAS\_NO\_CTRL2\_WAKEUP\_MODE.

### [2.0.2]

- Bug Fixes
  - MISRA C-2012 issue check.
    - \* Fixed rules, containing: rule-10.1, rule-10.3, rule-10.4, rule-10.6, rule-10.8, rule-11.9, rule-12.2, rule-15.5, rule-16.4, rule-17.7.

### [2.0.1]

- Bug Fixes
  - Fixed the issue of hard code in IRTC\_Init.

### [2.0.0]

- Initial version.
-

## LLWU

### [2.0.5]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.3.
  - Fixed the issue that function LLWU\_SetExternalWakeupPinMode() does not work on 32-bit width platforms.

### [2.0.4]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.3, 10.4, 10.6, 10.7, 11.3.
  - Fixed issue that LLWU\_ClearExternalWakeupPinFlag may clear other filter flags by mistake on platforms with 32-bit LLWU registers.

### [2.0.3]

- Bug Fixes
  - Fixed MISRA-2012 rules.
    - \* Rule 16.4.

### [2.0.2]

- Improvements
  - Corrected driver function LLWU\_SetResetPinMode parameter name.
- Bug Fixes
  - Fixed MISRA-2012 rules.
    - \* Rule 14.4, 10.8, 10.4, 10.3.

### [2.0.1]

- Other Changes
  - Updates for KL8x.

### [2.0.0]

- Initial version.
- 

## LPTMR

### [2.2.1]

- Bug Fixes
  - Fix CERT INT31-C issues.

#### [2.2.0]

- Improvements
  - Updated `lptmr_prescaler_clock_select_t`, only define the valid options.

#### [2.1.1]

- Improvements
  - Updated the characters from “PTMR” to “LPTMR” in “FSL\_FEATURE\_PTMR\_HAS\_NO\_PRESCALER\_CLOCK\_SOURCE\_1\_SUPPORT” feature definition.

#### [2.1.0]

- Improvements
  - Implement for some special devices’ not supporting for all clock sources.
- Bug Fixes
  - Fixed issue when accessing CMR register.

#### [2.0.2]

- Bug Fixes
  - Fixed MISRA-2012 issues.
    - \* Rule 10.1.

#### [2.0.1]

- Improvements
  - Updated the LPTMR driver to support 32-bit CNR and CMR registers in some devices.

#### [2.0.0]

- Initial version.
- 

## MCM

#### [2.2.0]

- Improvements
  - Support platforms with less features.

#### [2.1.0]

- Others
  - Remove `byteID` from `mcm_lmem_fault_attribute_t` for document update.

**[2.0.0]**

- Initial version.
- 

**PIT****[2.2.0]**

- Bug Fixes
  - According to ERR050763, PIT\_LDVAL\_STAT register is not reliable in dynamic load mode, so remove the status check in PIT\_SetRtiTimerPeriod which added since 2.1.1.
  - Removed not used bit PIT\_RTI\_TCTRL\_CHN\_MASK.
- Improvements
  - Added more guide about get RTI load status in PIT\_SetRtiTimerPeriod's API comment.
  - Change PIT\_RTI\_Deinit to inline API.
  - Ensure PIT peripheral clock enabled in PIT\_RTI\_Init.
- New Features
  - Added PIT\_ClearRtiSyncStatus API to clear the RTI\_LDVAL\_STAT register.

**[2.1.1]**

- Bug Fixes
  - Enable PIT when using RTI to ensure RTI can work properly in debug mode.
- Improvements
  - Added status check in PIT\_SetRtiTimerPeriod to ensure the load value is synchronized into the RTI clock domain.
  - Added note for PIT\_RTI\_Init to remind users wait RTI sync.

**[2.1.0]**

- New Features
  - Support RTI (Real Time Interrupt) timer.

**[2.0.5]**

- Improvements
  - Support workaround for ERR007914. This workaround guarantee the write to MCR register is not ignored.

**[2.0.4]**

- Bug Fixes
  - Fixed PIT\_SetTimerPeriod implementation, the load value trigger should be PIT clock cycles minus 1.

### [2.0.3]

- Bug Fixes
  - Clear all status bits for all channels to make sure the status of all TCTRL registers is clean.

### [2.0.2]

- Bug Fixes
  - Fixed MISRA-2012 issues.
    - \* Rule 10.1.

### [2.0.1]

- Bug Fixes
  - Cleared timer enable bit for all channels in function PIT\_Init() to make sure all channels stay in disable status before setting other configurations.
  - Fixed MISRA-2012 rules.
    - \* Rule 14.4, rule 10.4.

### [2.0.0]

- Initial version.
- 

## PMC

### [2.0.4]

- Bug Fixes
  - Add validation before narrowing uint32\_t to uint8\_t conversions using assert
  - Replace direct boolean to integer casts with explicit ternary operators
  - Add INT31-C compliance comments for safe narrowing conversions
  - Apply fixes to PMC\_ConfigureLowVoltDetect, PMC\_ConfigureLowVoltWarning, and PMC\_ConfigureBandgapBuffer functions

### [2.0.3]

- Bug Fixes
  - Fixed the violation of MISRA C-2012 rule 11.3.

### [2.0.2]

- Bug Fixes
  - Fixed the violations of MISRA 2012 rules:
    - \* Rule 10.3.

**[2.0.1]**

- Bug Fixes
  - Fixed MISRA issues.
    - \* Rule 10.8, Rule 10.3.

**[2.0.0]**

- Initial version.
- 

**PORT****[2.5.1]**

- Bug Fixes
  - Fix CERT INT31-C issues.
  - Fixed the violations of MISRA C-2012 rules: 10.1.

**[2.5.0]**

- Bug Fixes
  - Correct the kPORT\_MuxAsGpio for some platforms.

**[2.4.1]**

- Bug Fixes
  - Fixed the violations of MISRA C-2012 rules: 10.1, 10.8 and 14.4.

**[2.4.0]**

- New Features
  - Updated port\_pin\_config\_t to support input buffer and input invert.

**[2.3.0]**

- New Features
  - Added new APIs for Electrical Fast Transient(EFT) detect.
  - Added new API to configure port voltage range.

**[2.2.0]**

- New Features
  - Added new api PORT\_EnablePinDoubleDriveStrength.

**[2.1.1]**

- Bug Fixes
  - Fixed the violations of MISRA C-2012 rules: 10.1, 10.4–11.3–11.8, 14.4.

#### [2.1.0]

- New Features
  - Updated the driver code to adapt the case of the interrupt configurations in GPIO module. Will move the pin configuration APIs to GPIO module.

#### [2.0.2]

- Other Changes
  - Added feature guard macros in the driver.

#### [2.0.1]

- Other Changes
    - Added “const” in function parameter.
    - Updated some enumeration variables’ names.
- 

### QTMR

#### [2.0.2]

- Bug Fixes
  - Fix CERT INT30-C and CERT INT31-C violations.

#### [2.0.1]

- Bug Fixes
  - MISRA C-2012 issue check.
    - \* Fixed rules, containing: rule-10.1, rule-10.3, rule-10.4, rule-11.9, rule-14.4, rule-15.5, rule-17.7.
  - Changed FSL\_COMPONENT\_ID as platform.drivers.qtmr\_2.

#### [2.0.0]

- Initial version.
- 

### RCM

#### [2.0.5]

- Bug Fixes
  - Replace direct boolean to integer casts with explicit ternary operators for INT31-C compliance.
  - Add validation before narrowing uint32\_t to uint8\_t conversion using assert.
  - Add INT31-C compliance comments for safe type handling.
  - Apply fixes to RCM\_ConfigureResetPinFilter and RCM\_SetForceBootRomSource functions.

#### [2.0.4]

- Bug Fixes
  - Fixed violation of MISRA C-2012 rule 10.3

#### [2.0.3]

- Bug Fixes
  - Fixed violation of MISRA C-2012 rules.

#### [2.0.2]

- Bug Fixes
  - Fixed MISRA issue.
    - \* Rule 10.8, rule 10.1, rule 13.2, rule 3.1.

#### [2.0.1]

- Bug Fixes
  - Fixed kRCM\_SourceSw bit shift issue.

#### [2.0.0]

- Initial version.
- 

### RNGA

#### [2.0.2]

- Bug fix:
  - Fix MISRA issue.

#### [2.0.1]

- Bug fix:
  - Fixed C++ build warning in RNGA driver.

#### [2.0.0]

- Initial version.
- 

### SIM

#### [2.2.0]

- Improvements
  - Added API to trigger TRGMUX.

#### [2.1.3]

- Improvements
  - Updated function SIM\_GetUniqueId to support different register names.

#### [2.1.2]

- Bug Fixes
  - Fixed SIM\_GetUniqueId bug that could not get UIDH.

#### [2.1.1]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.1, 10.4

#### [2.1.0]

- Improvements
  - Added new APIs: SIM\_GetRfAddr() and SIM\_EnableSystickClock().

#### [2.0.0]

- Initial version.
- 

### SLCD

#### [2.1.0]

- New Features
  - Added new enumerations, updated SLCD\_Init and SLCD\_GetDefaultConfig to support new low power IP on new SoCs.

#### [2.0.4]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.4.

#### [2.0.3]

- Bug Fixes
  - Fixed SLCD\_Init bug that some bit-fields are cleared by mistake.

#### [2.0.2]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 3.1, 10.1, 10.3, 10.3, 10.4 11.4, 17.7

**[2.0.1]**

- Bug Fixes
  - Changed the Blink mode start setting flow.
- Other Changes
  - Added static to SLCD global variables.

**[2.0.0]**

- Initial version.
- 

**SMC****[2.0.8]**

- Bug Fixes
  - Replace direct boolean to integer casts with explicit ternary operators for INT31-C compliance
  - Add validation before narrowing uint32\_t to uint8\_t conversion using assert
  - Add INT31-C compliance comments for safe type handling
  - Apply fixes to RCM\_ConfigureResetPinFilter and RCM\_SetForceBootRomSource functions

**[2.0.7]**

- Bug Fixes
  - Fixed MISRA-2012 issue 10.3.

**[2.0.6]**

- Bug Fixes
  - Fixed issue for MISRA-2012 check.
    - \* Fixed rule 10.3, rule 11.3.

**[2.0.5]**

- Bug Fixes
  - Fixed issue for MISRA-2012 check.
    - \* Fixed rule 15.7, rule 14.4, rule 10.3, rule 10.1, rule 10.4.

**[2.0.4]**

- Bug Fixes
  - When entering stop modes, used RAM function for the flash synchronization issue. Application should make sure that, the RW data of fsl\_smc.c is located in memory region which is not powered off in stop modes.

### [2.0.3]

- Improvements
  - Added APIs SMC\_PreEnterStopModes, SMC\_PreEnterWaitModes, SMC\_PostExitWaitModes, and SMC\_PostExitStopModes.

### [2.0.2]

- Bug Fixes
  - Added DSB before WFI while ISB after WFI.
- Other Changes
  - Updated SMC\_SetPowerModeVlpw implementation.

### [2.0.1]

- Other Changes
  - Updated for KL8x.

### [2.0.0]

- Initial version.
- 

## SPI

### [2.1.4]

- Bug Fixes
  - Fixed coverity issues.

### [2.1.3]

- Bug Fixes
  - Fixed the txData from void \* to const void \* in transmit API.

### [2.1.2]

- Improvements
  - Changed SPI\_DUMMYDATA to 0x00.

### [2.1.1]

- Bug Fixes
  - Fixed MISRA 10.3 violation.

**[2.1.0]**

- Improvements
  - Added timeout mechanism when waiting certain states in transfer driver.
- Bug Fixes
  - Fixed the bug that, when working as a slave, instance that does not have FIFO may miss some rx data.
  - Fixed master RX data overflow issue by synchronizing transmit and receive process.
  - Fixed issue that slave should not share the same non-blocking initialization API and IRQ handler with master to prevent dead lock issue.
  - Fixed issue that callback should be invoked after all data is sent out to bus.
  - Added code in SPI\_SlaveTransferNonBlocking to empty rx buffer before initializing transfer.

**[2.0.5]**

- Bug Fixes
  - Eliminated Pa082 warnings from SPI\_WriteNonBlocking and SPI\_GetStatusFlags.
  - Fixed MISRA issues.
    - \* Fixed issues 10.1, 10.3, 10.4, 10.7, 10.8, 11.9, 14.4, 17.7.

**[2.0.4]**

- New Features
  - Supported 3-wire mode for SPI driver. Added new API SPI\_SetPinMode() to control the transfer direction of the single wire. For master instance, MOSI is selected as I/O pin. For slave instance, MISO is selected as I/O pin.
  - Added dummy data setup API to allow users to configure the dummy data to be transferred.

**[2.0.3]**

- Bug Fixes
  - Fixed the potential interrupt race condition at high baudrate when calling API SPI\_MasterTransferNonBlocking.

**[2.0.2]**

- New Features
  - Allowed users to set the transfer size for SPI\_TransferNoBlocking non-integer times of watermark.
  - Allowed users to define the dummy data. Users only need to define the macro SPI\_DUMMYDATA in applications.

### [2.0.1]

- Bug Fixes
  - Fixed SPI\_Enable function parameter error.
  - Set the s\_dummy variable as static variable in fsl\_spi\_dma.c.
- Improvements
  - Optimized the code size while not using transactional API.
  - Improved performance in polling method.
  - Added #ifndef/#endif to allow users to change the default tx value at compile time.

### [2.0.0]

- Initial version.
- 

## SPI DMA Driver

### [2.1.1]

- Bug Fixes
  - Fixed the bug that TX data not sent to bus when transfer finish callback is called.

### [2.1.0]

- Improvements
  - Added timeout mechanism when waiting certain states in transfer driver.
- Bug Fixes
  - Fixed the bug that, when working as a slave, instance that does not have FIFO may miss some rx data.
  - Fixed master RX data overflow issue by synchronizing transmit and receive process.
  - Fixed issue that slave should not share the same non-blocking initialization API and IRQ handler with master to prevent dead lock issue.
  - Fixed issue that callback should be invoked after all data is sent out to bus.
  - Added code in SPI\_SlaveTransferNonBlocking to empty rx buffer before initializing transfer.

### [2.0.5]

- Bug Fixes
  - Eliminated Pa082 warnings from SPI\_WriteNonBlocking and SPI\_GetStatusFlags.
  - Fixed MISRA issues.
    - \* Fixed issues 10.1, 10.3, 10.4, 10.7, 10.8, 11.9, 14.4, 17.7.

**[2.0.4]**

- New Features
  - Supported 3-wire mode for SPI driver. Added new API SPI\_SetPinMode() to control the transfer direction of the single wire. For master instance, MOSI is selected as I/O pin. For slave instance, MISO is selected as I/O pin.
  - Added dummy data setup API to allow users to configure the dummy data to be transferred.

**[2.0.3]**

- Bug Fixes
  - Fixed the potential interrupt race condition at high baudrate when calling API SPI\_MasterTransferNonBlocking.

**[2.0.2]**

- New Features
  - Allowed users to set the transfer size for SPI\_TransferNonBlocking non-integer times of watermark.
  - Allowed users to define the dummy data. Users only need to define the macro SPI\_DUMMYDATA in applications.

**[2.0.1]**

- Bug Fixes
  - Fixed SPI\_Enable function parameter error.
  - Set the s\_dummy variable as static variable in fsl\_spi\_dma.c.
- Improvements
  - Optimized the code size while not using transactional API.
  - Improved performance in polling method.
  - Added #ifndef/#endif to allow users to change the default tx value at compile time.

**[2.0.0]**

- Initial version.
- 

**SYSMPU****[2.2.3]**

- Bug Fixes
  - Fixed violation of MISRA C-2012 Rule 10.4, a part of issues is ignored before.

**[2.2.2]**

- Bug Fixes
  - Fixed violation of MISRA C-2012 Rule 10.1, 10.3, 10.4, 10.7, 10.6, 10.8, 12.2.

### [2.2.1]

- Bug Fixes
  - Fixed MISRA issue.

### [2.2.0]

- Improvements
  - Renamed MPU to SYSMPU.
  - Changed macro definition for slave number and fixed the get error status calculation.

### [2.1.1]

- Improvements
  - Added the feature file macro definition limitation for the MPU\_SetRegionRwMasterAccessRights().

### [2.1.0]

- Other Changes
  - API changes:
    - \* Changed the mpu\_region\_num\_t and mpu\_master\_t to uint32\_t.
    - \* Changed the mpu\_low\_masters\_access\_rights\_t, mpu\_high\_masters\_access\_rights\_t to mpu\_rwxrights\_master\_access\_control\_t, mpu\_rwrights\_master\_access\_control\_t.
    - \* Changed the MPU\_SetRegionLowMasterAccessRights(), MPU\_SetRegionHighMasterAccessRights() to MPU\_SetRegionRwxMasterAccessRights(), MPU\_SetRegionRwMasterAccessRights().

### [2.0.0]

- Initial version.
- 

## UART

### [2.5.1]

- Improvements
  - Use separate data for TX and RX in uart\_transfer\_t.
- Bug Fixes
  - Fixed bug that when ring buffer is used, if some data is received in ring buffer first before calling UART\_TransferReceiveNonBlocking, the received data count returned by UART\_TransferGetReceiveCount is wrong.

**[2.5.0]**

- New Features
  - Added APIs UART\_GetRxFifoCount/UART\_GetTxFifoCount to get rx/tx FIFO data count.
  - Added APIs UART\_SetRxFifoWatermark/UART\_SetTxFifoWatermark to set rx/tx FIFO water mark.
- Bug Fixes
  - Fixed bug of race condition during UART transfer using transactional APIs, by disabling and re-enabling the global interrupt before and after critical operations on interrupt enable registers.
  - Fixed DMA/eDMA transfer blocking issue by enabling tx idle interrupt after DMA/eDMA transmission finishes.

**[2.4.0]**

- New Features
  - Added APIs to configure 9-bit data mode, set slave address and send address.

**[2.3.0]**

- Bug Fixes
  - Fixed the bug that, when framing/parity/noise/overflow flag or idle line detect flag is set, receive FIFO should be flushed to avoid FIFO pointer being in unknown state, since FIFO has no valid data.
- Improvements
  - Modified UART\_TransferHandleIRQ so that txState will be set to idle only when all data has been sent out to bus.
  - Modified UART\_TransferGetSendCount so that this API returns the real byte count that UART has sent out rather than the software buffer status.
  - Added timeout mechanism when waiting for certain states in transfer driver.

**[2.2.0]**

- New Features
  - Added UART hardware FIFO enable/disable API.
- Improvements
  - Added check for kUART\_TransmissionCompleteFlag in UART\_TransferHandleIRQ, UART\_SentEDMACallback and UART\_TransferSendDMACallback to ensure all the data would be sent out to bus.
- Bug Fixes
  - Eliminated IAR Pa082 warnings from UART\_TransferGetRxRingBufferLength, UART\_GetEnabledInterrupts, UART\_GetStatusFlags and UART\_TransferHandleIRQ.
  - Added code in UART\_ReadBlocking so that if more than one receiver errors occur, all status flags will be cleared and the most severe error status will be returned.
  - Fixed MISRA issues.
    - \* Fixed rules 10.1, 10.3, 10.4, 14.4, 11.6, 17.7.

#### [2.1.6]

- Bug Fixes
  - Fixed the issue of register's being in repeatedly reading status while performing the IRQ routine.

#### [2.1.5]

- Improvements
  - Added hardware flow control function support.
  - Added idle-line-detecting feature in UART\_TransferNonBlocking function. If an idle line is detected, a callback will be triggered with status `kStatus_UART_IdleLineDetected` returned. This feature may be useful when the number of received bytes is less than the expected receive data size. Before triggering the callback, data in the FIFO is read out (if it has FIFO), and no interrupt will be disabled except for the case that the receive data size reaches 0.
  - Enabled the RX FIFO watermark function. With the idle-line-detecting feature enabled, you can set the watermark value to whatever you want (should not be bigger than the RX FIFO size). Data is then received and a callback will be triggered when data receive ends.

#### [2.1.4]

- Improvements
  - Changed parameter type in `UART_RTOS_Init()` struct `rtos_uart_config` → `uart_rtos_config_t`.
- Bug Fixes
  - Disabled UART receive interrupt instead of global interrupt when reading data from ring buffer. With ring buffer used, receive nonblocking will disable global interrupt to protect the ring buffer. This has a negative effect on other IPs using interrupt.

#### [2.1.3]

- New Features
  - Added RX framing error and parity error status check when using interrupt transfer.

#### [2.1.2]

- Bug Fixes
  - Fixed baud rate fine adjust bug to make the computed baud rate more accurate.

#### [2.1.1]

- Bug Fixes
  - Removed needless check of event flags and assert in `UART_RTOS_Receive`.
  - Always waited for RX event flag in `UART_RTOS_Receive`.

#### [2.1.0]

- Improvements
  - Added transactional API.

#### [2.0.0]

- Initial version.
- 

### UART\_DMA

#### [2.5.0]

- Refer UART driver change log 2.1.0 to 2.5.0
- 

### VREF

#### [2.1.3]

- Improvements
  - Add timeout for APIs with dfmea issues.

#### [2.1.2]

- Bug Fixes
  - Fixed the violation of MISRA-2012 rule 10.3.
  - Fixed MISRA C-2012 rule 10.3, rule 10.4 violation.

#### [2.1.1]

- Bug Fixes
  - MISRA-2012 issue fixed.
    - \* Fixed rules containing: rule-10.4, rule-10.3, rule-10.1.

#### [2.1.0]

- Improvements
  - Added new functions to support L5K board: added VREF\_SetTrim2V1Val() and VREF\_GetTrim2V1Val() functions to supply 2V1 output mode.

#### [2.0.0]

- Initial version.
-

## WDOG

### [2.0.2]

- Improvements
  - WDG\_Init() adds a 256 bus clock delay for WCT window finish.

### [2.0.1]

- Bug Fixes
  - MISRA C-2012 issue fixed: rule 10.3, 10.4, 10.6, 10.7 11.9 and 17.7.

### [2.0.0]

- Initial version.
- 

## XBAR

### [2.1.1]

- Bug Fixes
  - Fixed CERT-C issues.

### [2.1.0]

- Improvements
  - Improved to support XBAR which has less than 4 interrupt output.
- Bug Fixes
  - Fixed violations of MISRA C-2012 rule 12.2.

### [2.0.5]

- Bug Fixes
  - Fixed violations of the MISRA C-2012 rules 10.1, 10.3, 10.4, 10.6, 10.7, 10.8, 12.2, 18.1, 20.7.

### [2.0.4]

- Bug Fixes
  - Fixed IAR build warning Pa082.

### [2.0.3]

- Improvements
  - Optimized XBAR\_SetOutputSignalConfig.

**[2.0.2]**

- Bug Fixes
  - Corrected configuration for function XBAR\_SetOutputSignalConfig.

**[2.0.1]**

- Bug Fixes
  - Fixed w1c bits for XBAR\_SetOutputSignalConfig function.

**[2.0.0]**

- Initial version.
- 

## 1.6 Driver API Reference Manual

This section provides a link to the Driver API RM, detailing available drivers and their usage to help you integrate hardware efficiently.

[MKM34ZA5](#)

## 1.7 Middleware Documentation

Find links to detailed middleware documentation for key components. While not all onboard middleware is covered, this serves as a useful reference for configuration and development.

### 1.7.1 FreeMASTER

[freemaster](#)

### 1.7.2 FreeRTOS

[FreeRTOS](#)



# Chapter 2

## MKM34ZA5

### 2.1 ADC16: 16-bit SAR Analog-to-Digital Converter Driver

`void ADC16_Init(ADC_Type *base, const adc16_config_t *config)`

Initializes the ADC16 module.

#### Parameters

- `base` – ADC16 peripheral base address.
- `config` – Pointer to configuration structure. See “*adc16\_config\_t*”.

`void ADC16_Deinit(ADC_Type *base)`

De-initializes the ADC16 module.

#### Parameters

- `base` – ADC16 peripheral base address.

`void ADC16_GetDefaultConfig(adc16_config_t *config)`

Gets an available pre-defined settings for the converter’s configuration.

This function initializes the converter configuration structure with available settings. The default values are as follows.

```
config->referenceVoltageSource = kADC16_ReferenceVoltageSourceVref;
config->clockSource            = kADC16_ClockSourceAsynchronousClock;
config->enableAsynchronousClock = false;
config->clockDivider            = kADC16_ClockDivider8;
config->resolution              = kADC16_ResolutionSE12Bit;
config->longSampleMode          = kADC16_LongSampleDisabled;
config->enableHighSpeed         = false;
config->enableLowPower          = false;
config->enableContinuousConversion = false;
```

#### Parameters

- `config` – Pointer to the configuration structure.

`status_t ADC16_DoAutoCalibration(ADC_Type *base)`

Automates the hardware calibration.

This auto calibration helps to adjust the plus/minus side gain automatically. Execute the calibration before using the converter. Note that the hardware trigger should be used during the calibration.

#### Parameters

- `base` – ADC16 peripheral base address.

**Return values**

- `kStatus_Success` – Calibration is done successfully.
- `kStatus_Fail` – Calibration has failed.

**Returns**

Execution status.

`static inline void ADC16_SetOffsetValue(ADC_Type *base, int16_t value)`

Sets the offset value for the conversion result.

This offset value takes effect on the conversion result. If the offset value is not zero, the reading result is subtracted by it. Note, the hardware calibration fills the offset value automatically.

**Parameters**

- `base` – ADC16 peripheral base address.
- `value` – Setting offset value.

`static inline void ADC16_EnableDMA(ADC_Type *base, bool enable)`

Enables generating the DMA trigger when the conversion is complete.

**Parameters**

- `base` – ADC16 peripheral base address.
- `enable` – Switcher of the DMA feature. “true” means enabled, “false” means not enabled.

`static inline void ADC16_EnableHardwareTrigger(ADC_Type *base, bool enable)`

Enables the hardware trigger mode.

**Parameters**

- `base` – ADC16 peripheral base address.
- `enable` – Switcher of the hardware trigger feature. “true” means enabled, “false” means not enabled.

`void ADC16_SetChannelMuxMode(ADC_Type *base, adc16_channel_mux_mode_t mode)`

Sets the channel mux mode.

Some sample pins share the same channel index. The channel mux mode decides which pin is used for an indicated channel.

**Parameters**

- `base` – ADC16 peripheral base address.
- `mode` – Setting channel mux mode. See “`adc16_channel_mux_mode_t`”.

`void ADC16_SetHardwareCompareConfig(ADC_Type *base, const  
adc16_hardware_compare_config_t *config)`

Configures the hardware compare mode.

The hardware compare mode provides a way to process the conversion result automatically by using hardware. Only the result in the compare range is available. To compare the range, see “`adc16_hardware_compare_mode_t`” or the appropriate reference manual for more information.

**Parameters**

- `base` – ADC16 peripheral base address.

- `config` – Pointer to the “`adc16_hardware_compare_config_t`” structure. Passing “NULL” disables the feature.

`void ADC16_SetHardwareAverage(ADC_Type *base, adc16_hardware_average_mode_t mode)`

Sets the hardware average mode.

The hardware average mode provides a way to process the conversion result automatically by using hardware. The multiple conversion results are accumulated and averaged internally making them easier to read.

#### Parameters

- `base` – ADC16 peripheral base address.
- `mode` – Setting the hardware average mode. See “`adc16_hardware_average_mode_t`”.

`void ADC16_SetPGAConfig(ADC_Type *base, const adc16_pga_config_t *config)`

Configures the PGA for the converter’s front end.

#### Parameters

- `base` – ADC16 peripheral base address.
- `config` – Pointer to the “`adc16_pga_config_t`” structure. Passing “NULL” disables the feature.

`uint32_t ADC16_GetStatusFlags(ADC_Type *base)`

Gets the status flags of the converter.

#### Parameters

- `base` – ADC16 peripheral base address.

#### Returns

Flags’ mask if indicated flags are asserted. See “`_adc16_status_flags`”.

`void ADC16_ClearStatusFlags(ADC_Type *base, uint32_t mask)`

Clears the status flags of the converter.

#### Parameters

- `base` – ADC16 peripheral base address.
- `mask` – Mask value for the cleared flags. See “`_adc16_status_flags`”.

`static inline void ADC16_EnableAsynchronousClockOutput(ADC_Type *base, bool enable)`

Enable/disable ADC Asynchronous clock output to other modules.

#### Parameters

- `base` – ADC16 peripheral base address.
- `enable` – Used to enable/disable ADC ADACK output.
  - **true** Asynchronous clock and clock output is enabled regardless of the state of the ADC.
  - **false** Asynchronous clock output disabled, asynchronous clock is enabled only if it is selected as input clock and a conversion is active.

`void ADC16_SetChannelConfig(ADC_Type *base, uint32_t channelGroup, const adc16_channel_config_t *config)`

Configures the conversion channel.

This operation triggers the conversion when in software trigger mode. When in hardware trigger mode, this API configures the channel while the external trigger source helps to trigger the conversion.

Note that the “Channel Group” has a detailed description. To allow sequential conversions of the ADC to be triggered by internal peripherals, the ADC has more than one group of status and control registers, one for each conversion. The channel group parameter indicates which group of registers are used, for example, channel group 0 is for Group A registers and channel group 1 is for Group B registers. The channel groups are used in a “ping-pong” approach to control the ADC operation. At any point, only one of the channel groups is actively controlling ADC conversions. The channel group 0 is used for both software and hardware trigger modes. Channel group 1 and greater indicates multiple channel group registers for use only in hardware trigger mode. See the chip configuration information in the appropriate MCU reference manual for the number of SC1n registers (channel groups) specific to this device. Channel group 1 or greater are not used for software trigger operation. Therefore, writing to these channel groups does not initiate a new conversion. Updating the channel group 0 while a different channel group is actively controlling a conversion is allowed and vice versa. Writing any of the channel group registers while that specific channel group is actively controlling a conversion aborts the current conversion.

#### Parameters

- base – ADC16 peripheral base address.
- channelGroup – Channel group index.
- config – Pointer to the “adc16\_channel\_config\_t” structure for the conversion channel.

```
static inline uint32_t ADC16_GetChannelConversionValue(ADC_Type *base, uint32_t
                                                    channelGroup)
```

Gets the conversion value.

#### Parameters

- base – ADC16 peripheral base address.
- channelGroup – Channel group index.

#### Returns

Conversion value.

```
uint32_t ADC16_GetChannelStatusFlags(ADC_Type *base, uint32_t channelGroup)
```

Gets the status flags of channel.

#### Parameters

- base – ADC16 peripheral base address.
- channelGroup – Channel group index.

#### Returns

Flags’ mask if indicated flags are asserted. See “\_adc16\_channel\_status\_flags”.

```
FSL_ADC16_DRIVER_VERSION
```

ADC16 driver version 2.3.0.

```
enum _adc16_channel_status_flags
```

Channel status flags.

*Values:*

```
enumerator kADC16_ChannelConversionDoneFlag
```

Conversion done.

```
enum _adc16_status_flags
```

Converter status flags.

*Values:*

enumerator kADC16\_ActiveFlag

Converter is active.

enumerator kADC16\_CalibrationFailedFlag

Calibration is failed.

enum \_adc\_channel\_mux\_mode

Channel multiplexer mode for each channel.

For some ADC16 channels, there are two pin selections in channel multiplexer. For example, ADC0\_SE4a and ADC0\_SE4b are the different channels that share the same channel number.

*Values:*

enumerator kADC16\_ChannelMuxA

For channel with channel mux a.

enumerator kADC16\_ChannelMuxB

For channel with channel mux b.

enum \_adc16\_clock\_divider

Clock divider for the converter.

*Values:*

enumerator kADC16\_ClockDivider1

For divider 1 from the input clock to the module.

enumerator kADC16\_ClockDivider2

For divider 2 from the input clock to the module.

enumerator kADC16\_ClockDivider4

For divider 4 from the input clock to the module.

enumerator kADC16\_ClockDivider8

For divider 8 from the input clock to the module.

enum \_adc16\_resolution

Converter's resolution.

*Values:*

enumerator kADC16\_Resolution8or9Bit

Single End 8-bit or Differential Sample 9-bit.

enumerator kADC16\_Resolution12or13Bit

Single End 12-bit or Differential Sample 13-bit.

enumerator kADC16\_Resolution10or11Bit

Single End 10-bit or Differential Sample 11-bit.

enumerator kADC16\_ResolutionSE8Bit

Single End 8-bit.

enumerator kADC16\_ResolutionSE12Bit

Single End 12-bit.

enumerator kADC16\_ResolutionSE10Bit

Single End 10-bit.

enumerator kADC16\_ResolutionDF9Bit

Differential Sample 9-bit.

enumerator kADC16\_\_ResolutionDF13Bit  
Differential Sample 13-bit.

enumerator kADC16\_\_ResolutionDF11Bit  
Differential Sample 11-bit.

enum \_\_adc16\_\_clock\_\_source  
Clock source.

*Values:*

enumerator kADC16\_\_ClockSourceAlt0  
Selection 0 of the clock source.

enumerator kADC16\_\_ClockSourceAlt1  
Selection 1 of the clock source.

enumerator kADC16\_\_ClockSourceAlt2  
Selection 2 of the clock source.

enumerator kADC16\_\_ClockSourceAlt3  
Selection 3 of the clock source.

enumerator kADC16\_\_ClockSourceAsynchronousClock  
Using internal asynchronous clock.

enum \_\_adc16\_\_long\_\_sample\_\_mode  
Long sample mode.

*Values:*

enumerator kADC16\_\_LongSampleCycle24  
20 extra ADCK cycles, 24 ADCK cycles total.

enumerator kADC16\_\_LongSampleCycle16  
12 extra ADCK cycles, 16 ADCK cycles total.

enumerator kADC16\_\_LongSampleCycle10  
6 extra ADCK cycles, 10 ADCK cycles total.

enumerator kADC16\_\_LongSampleCycle6  
2 extra ADCK cycles, 6 ADCK cycles total.

enumerator kADC16\_\_LongSampleDisabled  
Disable the long sample feature.

enum \_\_adc16\_\_reference\_\_voltage\_\_source  
Reference voltage source.

*Values:*

enumerator kADC16\_\_ReferenceVoltageSourceVref  
For external pins pair of VrefH and VrefL.

enumerator kADC16\_\_ReferenceVoltageSourceValt  
For alternate reference pair of ValtH and ValtL.

enum \_\_adc16\_\_hardware\_\_average\_\_mode  
Hardware average mode.

*Values:*

enumerator kADC16\_\_HardwareAverageCount4  
For hardware average with 4 samples.

enumerator kADC16\_\_HardwareAverageCount8

For hardware average with 8 samples.

enumerator kADC16\_\_HardwareAverageCount16

For hardware average with 16 samples.

enumerator kADC16\_\_HardwareAverageCount32

For hardware average with 32 samples.

enumerator kADC16\_\_HardwareAverageDisabled

Disable the hardware average feature.

enum \_adc16\_\_hardware\_\_compare\_\_mode

Hardware compare mode.

*Values:*

enumerator kADC16\_\_HardwareCompareMode0

$x < \text{value1}$ .

enumerator kADC16\_\_HardwareCompareMode1

$x > \text{value1}$ .

enumerator kADC16\_\_HardwareCompareMode2

if  $\text{value1} \leq \text{value2}$ , then  $x < \text{value1} \mid \mid x > \text{value2}$ ; else,  $\text{value1} > x > \text{value2}$ .

enumerator kADC16\_\_HardwareCompareMode3

if  $\text{value1} \leq \text{value2}$ , then  $\text{value1} \leq x \leq \text{value2}$ ; else  $x \geq \text{value1} \mid \mid x \leq \text{value2}$ .

enum \_adc16\_\_pga\_\_gain

PGA's Gain mode.

*Values:*

enumerator kADC16\_\_PGAGainValueOf1

For amplifier gain of 1.

enumerator kADC16\_\_PGAGainValueOf2

For amplifier gain of 2.

enumerator kADC16\_\_PGAGainValueOf4

For amplifier gain of 4.

enumerator kADC16\_\_PGAGainValueOf8

For amplifier gain of 8.

enumerator kADC16\_\_PGAGainValueOf16

For amplifier gain of 16.

enumerator kADC16\_\_PGAGainValueOf32

For amplifier gain of 32.

enumerator kADC16\_\_PGAGainValueOf64

For amplifier gain of 64.

typedef enum \_adc\_channel\_mux\_mode adc16\_channel\_mux\_mode\_t

Channel multiplexer mode for each channel.

For some ADC16 channels, there are two pin selections in channel multiplexer. For example, ADC0\_SE4a and ADC0\_SE4b are the different channels that share the same channel number.

typedef enum \_adc16\_clock\_divider adc16\_clock\_divider\_t

Clock divider for the converter.

```
typedef enum _adc16_resolution adc16_resolution_t
    Converter's resolution.

typedef enum _adc16_clock_source adc16_clock_source_t
    Clock source.

typedef enum _adc16_long_sample_mode adc16_long_sample_mode_t
    Long sample mode.

typedef enum _adc16_reference_voltage_source adc16_reference_voltage_source_t
    Reference voltage source.

typedef enum _adc16_hardware_average_mode adc16_hardware_average_mode_t
    Hardware average mode.

typedef enum _adc16_hardware_compare_mode adc16_hardware_compare_mode_t
    Hardware compare mode.

typedef enum _adc16_pga_gain adc16_pga_gain_t
    PGA's Gain mode.

typedef struct _adc16_config adc16_config_t
    ADC16 converter configuration.

typedef struct _adc16_hardware_compare_config adc16_hardware_compare_config_t
    ADC16 Hardware comparison configuration.

typedef struct _adc16_channel_config adc16_channel_config_t
    ADC16 channel conversion configuration.

typedef struct _adc16_pga_config adc16_pga_config_t
    ADC16 programmable gain amplifier configuration.

struct _adc16_config
    #include <fsl_adc16.h> ADC16 converter configuration.
```

### Public Members

```
adc16_reference_voltage_source_t referenceVoltageSource
    Select the reference voltage source.

adc16_clock_source_t clockSource
    Select the input clock source to converter.

bool enableAsynchronousClock
    Enable the asynchronous clock output.

adc16_clock_divider_t clockDivider
    Select the divider of input clock source.

adc16_resolution_t resolution
    Select the sample resolution mode.

adc16_long_sample_mode_t longSampleMode
    Select the long sample mode.

bool enableHighSpeed
    Enable the high-speed mode.

bool enableLowPower
    Enable low power.
```

bool enableContinuousConversion

Enable continuous conversion mode.

adc16\_hardware\_average\_mode\_t hardwareAverageMode

Set hardware average mode.

struct \_\_adc16\_hardware\_compare\_config

#include <fsl\_adc16.h> ADC16 Hardware comparison configuration.

### Public Members

adc16\_hardware\_compare\_mode\_t hardwareCompareMode

Select the hardware compare mode. See “adc16\_hardware\_compare\_mode\_t”.

int16\_t value1

Setting value1 for hardware compare mode.

int16\_t value2

Setting value2 for hardware compare mode.

struct \_\_adc16\_channel\_config

#include <fsl\_adc16.h> ADC16 channel conversion configuration.

### Public Members

uint32\_t channelNumber

Setting the conversion channel number. The available range is 0-31. See channel connection information for each chip in Reference Manual document.

bool enableInterruptOnConversionCompleted

Generate an interrupt request once the conversion is completed.

bool enableDifferentialConversion

Using Differential sample mode.

struct \_\_adc16\_pga\_config

#include <fsl\_adc16.h> ADC16 programmable gain amplifier configuration.

### Public Members

adc16\_pga\_gain\_t pgaGain

Setting PGA gain.

bool enableRunInNormalMode

Enable PGA working in normal mode, or low power mode by default.

bool disablePgaChopping

Disable the PGA chopping function. The PGA employs chopping to remove/reduce offset and 1/f noise and offers an offset measurement configuration that aids the offset calibration.

bool enableRunInOffsetMeasurement

Enable the PGA working in offset measurement mode. When this feature is enabled, the PGA disconnects itself from the external inputs and auto-configures into offset measurement mode. With this field set, run the ADC in the recommended settings and enable the maximum hardware averaging to get the PGA offset number. The output is the (PGA offset \* (64+1)) for the given PGA setting.

## 2.2 AFE: Analog Front End Driver

`void AFE_Init(AFE_Type *base, const afe_config_t *config)`

Initialization for the AFE module.

This function configures the AFE module for the configuration which are shared by all channels.

### Parameters

- `base` – AFE peripheral base address.
- `config` – Pointer to structure of “*afe\_config\_t*”.

`void AFE_Deinit(AFE_Type *base)`

De-Initialization for the AFE module.

This function disables clock.

### Parameters

- `base` – AFE peripheral base address.

`void AFE_GetDefaultConfig(afe_config_t *config)`

Fills the user configure structure.

This function fills the *afe\_config\_t* structure with default settings. Default value are:

```
config->enableLowPower = false;
config->resultFormat    = kAFE_ResultFormatRight;
config->clockDivider    = kAFE_ClockDivider2;
config->clockSource     = kAFE_ClockSource1;
config->startupCount    = 2U;
```

### Parameters

- `config` – Pointer to structure of “*afe\_config\_t*”.

`static inline void AFE_SoftwareReset(AFE_Type *base, bool enable)`

Software reset the AFE module.

This function is to reset all the ADCs, PGAs, decimation filters and clock configuration bits. When asserted as “false”, all ADCs, PGAs and decimation filters are disabled. Clock Configuration bits are reset. When asserted as “true”, all ADCs, PGAs and decimation filters are enabled.

### Parameters

- `base` – AFE peripheral base address.
- `enable` – Assert the reset command.

`static inline void AFE_Enable(AFE_Type *base, bool enable)`

Enables all configured AFE channels.

This function enables AFE and filter.

### Parameters

- `base` – AFE peripheral base address.
- `enable` – Enable the AFE module or not.

`void AFE_SetChannelConfig(AFE_Type *base, uint32_t channel, const afe_channel_config_t *config)`

Configure the selected AFE channel.

This function configures the selected AFE channel.

### Parameters

- base – AFE peripheral base address.
- channel – AFE channel index.
- config – Pointer to structure of “afe\_channel\_config\_t”.

void AFE\_GetDefaultChannelConfig(*afe\_channel\_config\_t* \*config)

Fills the channel configuration structure.

This function fills the afe\_channel\_config\_t structure with default settings. Default value are:

```
config->enableHardwareTrigger    = false;
config->enableContinuousConversion = false;
config->channelMode              = kAFE_Normal;
config->decimatorOversampleRatio = kAFE_DecimatorOversampleRatio64;
config->pgaGainSelect            = kAFE_PgaGain1;
```

### Parameters

- config – Pointer to structure of “afe\_channel\_config\_t”.

uint32\_t AFE\_GetChannelConversionValue(AFE\_Type \*base, uint32\_t channel)

Reads the raw conversion value.

This function returns the raw conversion value of the selected channel.

---

**Note:** The returned value could be left or right adjusted according to the AFE module configuration.

---

### Parameters

- base – AFE peripheral base address.
- channel – AFE channel index.

### Returns

Conversion value.

static inline void AFE\_DoSoftwareTriggerChannel(AFE\_Type \*base, uint32\_t mask)

Triggers the AFE conversion by software.

This function triggers the AFE conversion by executing a software command. It starts the conversion on selected channels if the software trigger option is selected for the channels.

### Parameters

- base – AFE peripheral base address.
- mask – AFE channel mask software trigger. The parameter can be combination of the following source if defined:
  - kAFE\_Channel0Trigger
  - kAFE\_Channel1Trigger
  - kAFE\_Channel2Trigger
  - kAFE\_Channel3Trigger

static inline uint32\_t AFE\_GetChannelStatusFlags(AFE\_Type \*base)

Gets the AFE status flag state.

This function gets all AFE status.

**Parameters**

- base – AFE peripheral base address.

**Returns**

the mask of these status flag bits.

void AFE\_SetChannelPhaseDelayValue(AFE\_Type \*base, uint32\_t channel, uint32\_t value)

Sets phase delays value.

This function sets the phase delays for channels. This delay is inserted before the trigger response of the decimation filters. The delay is used to provide a phase compensation between AFE channels in step of prescaled modulator clock periods.

**Parameters**

- base – AFE peripheral base address.
- channel – AFE channel index.
- value – delay time value.

static inline void AFE\_SetChannelPhasetDelayOk(AFE\_Type \*base)

Asserts the phase delay setting.

This function should be called after all desired channel's delay registers are loaded. Values in channel's delay registers are active after calling this function and after the conversation starts.

**Parameters**

- base – AFE peripheral base address.

static inline void AFE\_EnableChannelInterrupts(AFE\_Type \*base, uint32\_t mask)

Enables AFE interrupt.

This function enables one channel interrupt.

**Parameters**

- base – AFE peripheral base address.
- mask – AFE channel interrupt mask. The parameter can be combination of the following source if defined:
  - kAFE\_Channel0InterruptEnable
  - kAFE\_Channel1InterruptEnable
  - kAFE\_Channel2InterruptEnable
  - kAFE\_Channel3InterruptEnable

static inline void AFE\_DisableChannelInterrupts(AFE\_Type \*base, uint32\_t mask)

Disables AFE interrupt.

This function disables one channel interrupt.

**Parameters**

- base – AFE peripheral base address.
- mask – AFE channel interrupt mask. The parameter can be combination of the following source if defined:
  - kAFE\_Channel0InterruptEnable
  - kAFE\_Channel1InterruptEnable
  - kAFE\_Channel2InterruptEnable
  - kAFE\_Channel3InterruptEnable

static inline uint32\_t AFE\_GetEnabledChannelInterrupts(AFE\_Type \*base)

Returns mask of all enabled AFE interrupts.

**Parameters**

- base – AFE peripheral base address.

**Returns**

Return the mask of these interrupt enable/disable bits.

void AFE\_EnableChannelDMA(AFE\_Type \*base, uint32\_t mask, bool enable)

Enables/Disables AFE DMA.

This function enables/disables one channel DMA request.

**Parameters**

- base – AFE peripheral base address.
- mask – AFE channel dma mask.
- enable – Pass true to enable interrupt, false to disable. The parameter can be combination of the following source if defined:
  - kAFE\_Channel0DMAEnable
  - kAFE\_Channel1DMAEnable
  - kAFE\_Channel2DMAEnable
  - kAFE\_Channel3DMAEnable

FSL\_AFE\_DRIVER\_VERSION

Version 2.0.3.

enum \_afe\_channel\_status\_flag

Defines the type of status flags.

*Values:*

enumerator kAFE\_Channel0OverflowFlag

Channel 0 previous conversion result has not been read and new data has already arrived.

enumerator kAFE\_Channel1OverflowFlag

Channel 1 previous conversion result has not been read and new data has already arrived.

enumerator kAFE\_Channel2OverflowFlag

Channel 2 previous conversion result has not been read and new data has already arrived.

enumerator kAFE\_Channel0ReadyFlag

Channel 0 is ready to conversion.

enumerator kAFE\_Channel1ReadyFlag

Channel 1 is ready to conversion.

enumerator kAFE\_Channel2ReadyFlag

Channel 2 is ready to conversion.

enumerator kAFE\_Channel0ConversionCompleteFlag

Channel 0 conversion is complete.

enumerator kAFE\_Channel1ConversionCompleteFlag

Channel 1 conversion is complete.

enumerator kAFE\_Channel2ConversionCompleteFlag

Channel 2 conversion is complete.

enumerator kAFE\_Channel3OverflowFlag

Channel 3 previous conversion result has not been read and new data has already arrived.

enumerator kAFE\_Channel3ReadyFlag

Channel 3 is ready to conversion.

enumerator kAFE\_Channel3ConversionCompleteFlag

Channel 3 conversion is complete.

Defines AFE interrupt enable.

*Values:*

enumerator kAFE\_Channel0InterruptEnable

Channel 0 Interrupt.

enumerator kAFE\_Channel1InterruptEnable

Channel 1 Interrupt.

enumerator kAFE\_Channel2InterruptEnable

Channel 2 Interrupt.

enumerator kAFE\_Channel3InterruptEnable

Channel 3 Interrupt.

Defines AFE DMA enable.

*Values:*

enumerator kAFE\_Channel0DMAEnable

Channel 0 DMA.

enumerator kAFE\_Channel1DMAEnable

Channel 1 DMA.

enumerator kAFE\_Channel2DMAEnable

Channel 2 DMA.

enumerator kAFE\_Channel3DMAEnable

Channel 3 DMA

Defines AFE channel trigger flag.

*Values:*

enumerator kAFE\_Channel0Trigger

Channel 0 software trigger.

enumerator kAFE\_Channel1Trigger

Channel 1 software trigger.

enumerator kAFE\_Channel2Trigger

Channel 2 software trigger.

enumerator kAFE\_Channel3Trigger

Channel 3 software trigger.

enum \_afe\_decimator\_oversampling\_ratio

AFE OSR modes.

*Values:*

enumerator kAFE\_DecimatorOversampleRatio64

Decimator over sample ratio is 64.

enumerator kAFE\_DecimatorOversampleRatio128

Decimator over sample ratio is 128.

enumerator kAFE\_DecimatorOversampleRatio256

Decimator over sample ratio is 256.

enumerator kAFE\_DecimatorOversampleRatio512

Decimator over sample ratio is 512.

enumerator kAFE\_DecimatorOversampleRatio1024

Decimator over sample ratio is 1024.

enumerator kAFE\_DecimatorOversampleRatio2048

Decimator over sample ratio is 2048.

enum \_afe\_result\_format

Defines the AFE result format modes.

*Values:*

enumerator kAFE\_ResultFormatLeft

Left justified result format.

enumerator kAFE\_ResultFormatRight

Right justified result format.

enum \_afe\_clock\_divider

Defines the AFE clock divider modes.

*Values:*

enumerator kAFE\_ClockDivider1

Clock divided by 1.

enumerator kAFE\_ClockDivider2

Clock divided by 2.

enumerator kAFE\_ClockDivider4

Clock divided by 4.

enumerator kAFE\_ClockDivider8

Clock divided by 8.

enumerator kAFE\_ClockDivider16

Clock divided by 16.

enumerator kAFE\_ClockDivider32

Clock divided by 32.

enumerator kAFE\_ClockDivider64

Clock divided by 64.

enumerator kAFE\_ClockDivider128

Clock divided by 128.

enumerator kAFE\_ClockDivider256

Clock divided by 256.

enum \_\_afe\_clock\_source

Defines the AFE clock source modes.

*Values:*

enumerator kAFE\_ClockSource0

Modulator clock source 0.

enumerator kAFE\_ClockSource1

Modulator clock source 1.

enumerator kAFE\_ClockSource2

Modulator clock source 2.

enumerator kAFE\_ClockSource3

Modulator clock source 3.

enum \_\_afe\_pga\_gain

Defines the PGA's values.

*Values:*

enumerator kAFE\_PgaDisable

PGA disabled.

enumerator kAFE\_PgaGain1

Input gained by 1.

enumerator kAFE\_PgaGain2

Input gained by 2.

enumerator kAFE\_PgaGain4

Input gained by 4.

enumerator kAFE\_PgaGain8

Input gained by 8.

enumerator kAFE\_PgaGain16

Input gained by 16.

enumerator kAFE\_PgaGain32

Input gained by 32.

enum \_\_afe\_bypass\_mode

Defines the bypass modes.

*Values:*

enumerator kAFE\_BypassInternalClockPositiveEdge

Bypassed channel mode - internal clock selected, positive edge for registering data by the decimation filter

enumerator kAFE\_BypassExternalClockPositiveEdge

Bypassed channel mode - external clock selected, positive edge for registering data by the decimation filter

enumerator kAFE\_BypassInternalClockNegativeEdge

Bypassed channel mode - internal clock selected, negative edge for registering data by the decimation filter

enumerator kAFE\_\_BypassExternalClockNegativeEdge

Bypassed channel mode - external clock selected, negative edge for registering data by the decimation filter

enumerator kAFE\_\_BypassDisable

Normal channel mode.

typedef enum *\_afe\_decimator\_oversampling\_ratio* afe\_decimator\_oversample\_ratio\_t

AFE OSR modes.

typedef enum *\_afe\_result\_format* afe\_result\_format\_t

Defines the AFE result format modes.

typedef enum *\_afe\_clock\_divider* afe\_clock\_divider\_t

Defines the AFE clock divider modes.

typedef enum *\_afe\_clock\_source* afe\_clock\_source\_t

Defines the AFE clock source modes.

typedef enum *\_afe\_pga\_gain* afe\_pga\_gain\_t

Defines the PGA's values.

typedef enum *\_afe\_bypass\_mode* afe\_bypass\_mode\_t

Defines the bypass modes.

typedef struct *\_afe\_channel\_config* afe\_channel\_config\_t

Defines the structure to initialize the AFE channel.

This structure keeps the configuration for the AFE channel.

typedef struct *\_afe\_config* afe\_config\_t

Defines the structure to initialize the AFE module.

This structure keeps the configuration for the AFE module.

struct *\_afe\_channel\_config*

*#include <fsl\_afe.h>* Defines the structure to initialize the AFE channel.

This structure keeps the configuration for the AFE channel.

## Public Members

bool enableHardwareTrigger

Enable triggering by hardware.

bool enableContinuousConversion

Enable continuous conversion mode.

*afe\_bypass\_mode\_t* channelMode

Select if channel is in bypassed mode.

*afe\_pga\_gain\_t* pgaGainSelect

Select the analog gain applied to the input signal.

*afe\_decimator\_oversample\_ratio\_t* decimatorOversampleRatio

Select the over sampling ration.

struct *\_afe\_config*

*#include <fsl\_afe.h>* Defines the structure to initialize the AFE module.

This structure keeps the configuration for the AFE module.

### Public Members

bool enableLowPower

Enable low power mode.

*afe\_result\_format\_t* resultFormat

Select the result format.

*afe\_clock\_divider\_t* clockDivider

Select the clock divider ration for the modulator clock.

*afe\_clock\_source\_t* clockSource

Select clock source for modulator clock.

uint8\_t startupCount

Select the start up delay of modulators.

## 2.3 Clock Driver

enum \_\_clock\_name

Clock name used to get clock frequency.

*Values:*

enumerator kCLOCK\_CoreSysClk

Core/system clock

enumerator kCLOCK\_PlatClk

Platform clock

enumerator kCLOCK\_BusClk

Bus clock

enumerator kCLOCK\_FlashClk

Flash clock

enumerator kCLOCK\_Er32kClk

External reference 32K clock (ERCLK32K)

enumerator kCLOCK\_Osc0ErClk

OSC0 external reference clock (OSC0ERCLK)

enumerator kCLOCK\_McgFixedFreqClk

MCG fixed frequency clock (MCGFFCLK)

enumerator kCLOCK\_McgInternalRefClk

MCG internal reference clock (MCGIRCLK)

enumerator kCLOCK\_McgFllClk

MCGFLLCLK

enumerator kCLOCK\_McgPll0Clk

MCGPLL0CLK

enumerator kCLOCK\_McgExtPllClk

EXT\_PLLCLK

enumerator kCLOCK\_McgPeriphClk

MCG peripheral clock (MCGPCLK)

enumerator kCLOCK\_LpoClk

LPO clock

enum \_clock\_ip\_name

Clock gate name used for CLOCK\_EnableClock/CLOCK\_DisableClock.

*Values:*

enumerator kCLOCK\_IpInvalid

enumerator kCLOCK\_Ewm0

enumerator kCLOCK\_Mcg

enumerator kCLOCK\_Osc

enumerator kCLOCK\_I2c0

enumerator kCLOCK\_I2c1

enumerator kCLOCK\_Uart0

enumerator kCLOCK\_Uart1

enumerator kCLOCK\_Uart2

enumerator kCLOCK\_Uart3

enumerator kCLOCK\_Vref0

enumerator kCLOCK\_Cmp0

enumerator kCLOCK\_Cmp1

enumerator kCLOCK\_Spi0

enumerator kCLOCK\_Spi1

enumerator kCLOCK\_Slcd0

enumerator kCLOCK\_PortA

enumerator kCLOCK\_PortB

enumerator kCLOCK\_PortC

enumerator kCLOCK\_PortD

enumerator kCLOCK\_PortE

enumerator kCLOCK\_PortF

enumerator kCLOCK\_PortG

enumerator kCLOCK\_PortH

enumerator kCLOCK\_PortI

enumerator kCLOCK\_Rtc0

enumerator kCLOCK\_Rtcreg

enumerator kCLOCK\_Wdog

enumerator kCLOCK\_Xbar

enumerator kCLOCK\_\_Tmr0  
enumerator kCLOCK\_\_Tmr1  
enumerator kCLOCK\_\_Tmr2  
enumerator kCLOCK\_\_Tmr3  
enumerator kCLOCK\_\_Ftf0  
enumerator kCLOCK\_\_Dmamux0  
enumerator kCLOCK\_\_Dmamux1  
enumerator kCLOCK\_\_Dmamux2  
enumerator kCLOCK\_\_Dmamux3  
enumerator kCLOCK\_\_Rnga0  
enumerator kCLOCK\_\_Adc0  
enumerator kCLOCK\_\_Pit0  
enumerator kCLOCK\_\_Pit1  
enumerator kCLOCK\_\_Afe0  
enumerator kCLOCK\_\_Crc0  
enumerator kCLOCK\_\_Lptmr0  
enumerator kCLOCK\_\_SimLp  
enumerator kCLOCK\_\_SimHp  
enumerator kCLOCK\_\_Sysmpu0  
enumerator kCLOCK\_\_Dma0

enum \_\_osc\_\_mode

OSC work mode.

*Values:*

enumerator kOSC\_\_ModeExt

Use an external clock.

enumerator kOSC\_\_ModeOscLowPower

Oscillator low power.

enumerator kOSC\_\_ModeOscHighGain

Oscillator high gain.

enum \_\_osc\_\_cap\_\_load

Oscillator capacitor load setting.

*Values:*

enumerator kOSC\_\_Cap2P

2 pF capacitor load

enumerator kOSC\_\_Cap4P

4 pF capacitor load

enumerator kOSC\_Cap8P  
8 pF capacitor load

enumerator kOSC\_Cap16P  
16 pF capacitor load

enum \_\_oscer\_enable\_mode  
OSCERCLK enable mode.

*Values:*

enumerator kOSC\_ErClkEnable  
Enable.

enumerator kOSC\_ErClkEnableInStop  
Enable in stop mode.

enum \_\_mcg\_fl\_src  
MCG FLL reference clock source select.

*Values:*

enumerator kMCG\_FllSrcExternal  
External reference clock is selected

enumerator kMCG\_FllSrcInternal  
The slow internal reference clock is selected

enum \_\_mcg\_irc\_mode  
MCG internal reference clock select.

*Values:*

enumerator kMCG\_IrcSlow  
Slow internal reference clock selected

enumerator kMCG\_IrcFast  
Fast internal reference clock selected

enum \_\_mcg\_dmx32  
MCG DCO Maximum Frequency with 32.768 kHz Reference.

*Values:*

enumerator kMCG\_Dmx32Default  
DCO has a default range of 25%

enumerator kMCG\_Dmx32Fine  
DCO is fine-tuned for maximum frequency with 32.768 kHz reference

enum \_\_mcg\_drs  
MCG DCO range select.

*Values:*

enumerator kMCG\_DrsLow  
Low frequency range

enumerator kMCG\_DrsMid  
Mid frequency range

enumerator kMCG\_DrsMidHigh  
Mid-High frequency range

enumerator kMCG\_DrsHigh

High frequency range

enum \_\_mcg\_pll\_ref\_src

MCG PLL reference clock select.

*Values:*

enumerator kMCG\_PllRefRtc

Selects 32k RTC oscillator.

enumerator kMCG\_PllRefIrc

Selects 32k IRC.

enumerator kMCG\_PllRefFllRef

Selects FLL reference clock, the clock after FRDIV.

enum \_\_mcg\_clkout\_src

MCGOUT clock source.

*Values:*

enumerator kMCG\_ClkOutSrcOut

Output of the FLL is selected (reset default)

enumerator kMCG\_ClkOutSrcInternal

Internal reference clock is selected

enumerator kMCG\_ClkOutSrcExternal

External reference clock is selected

enum \_\_mcg\_atm\_select

MCG Automatic Trim Machine Select.

*Values:*

enumerator kMCG\_AtmSel32k

32 kHz Internal Reference Clock selected

enumerator kMCG\_AtmSel4m

4 MHz Internal Reference Clock selected

enum \_\_mcg\_oscsel

MCG OSC Clock Select.

*Values:*

enumerator kMCG\_OscselOsc

Selects System Oscillator (OSCCLK)

enumerator kMCG\_OscselRtc

Selects 32 kHz RTC Oscillator

enum \_\_mcg\_pll\_clk\_select

MCG PLLCS select.

*Values:*

enumerator kMCG\_PllClkSelPll0

PLL0 output clock is selected

enumerator kMCG\_PllClkSelPll1

enum \_mcg\_monitor\_mode

MCG clock monitor mode.

*Values:*

enumerator kMCG\_MonitorNone

Clock monitor is disabled.

enumerator kMCG\_MonitorInt

Trigger interrupt when clock lost.

enumerator kMCG\_MonitorReset

System reset when clock lost.

MCG status. Enumeration \_mcg\_status.

*Values:*

enumerator kStatus\_MCG\_ModeUnreachable

Can't switch to target mode.

enumerator kStatus\_MCG\_ModeInvalid

Current mode invalid for the specific function.

enumerator kStatus\_MCG\_AtmBusClockInvalid

Invalid bus clock for ATM.

enumerator kStatus\_MCG\_AtmDesiredFreqInvalid

Invalid desired frequency for ATM.

enumerator kStatus\_MCG\_AtmIrcUsed

IRC is used when using ATM.

enumerator kStatus\_MCG\_AtmHardwareFail

Hardware fail occurs during ATM.

enumerator kStatus\_MCG\_SourceUsed

Can't change the clock source because it is in use.

MCG status flags. Enumeration \_mcg\_status\_flags\_t.

*Values:*

enumerator kMCG\_Osc0LostFlag

OSC0 lost.

enumerator kMCG\_Osc0InitFlag

OSC0 crystal initialized.

enumerator kMCG\_RtcOscLostFlag

RTC OSC lost.

enumerator kMCG\_Pll0LostFlag

PLL0 lost.

enumerator kMCG\_Pll0LockFlag

PLL0 locked.

MCG internal reference clock (MCGIRCLK) enable mode definition. Enumeration \_mcg\_ircclk\_enable\_mode.

*Values:*

enumerator kMCG\_IrcIkEnable  
MCGIRCLK enable.

enumerator kMCG\_IrcIkEnableInStop  
MCGIRCLK enable in stop mode.

MCG PLL clock enable mode definition. Enumeration `_mcg_pll_enable_mode`.

*Values:*

enumerator kMCG\_PllEnableIndependent  
MCGPLLCLK enable independent of the MCG clock mode. Generally, the PLL is disabled in FLL modes (FEI/FBI/FEE/FBE). Setting the PLL clock enable independent, enables the PLL in the FLL modes.

enumerator kMCG\_PllEnableInStop  
MCGPLLCLK enable in STOP mode.

enum `_mcg_mode`

MCG mode definitions.

*Values:*

enumerator kMCG\_ModeFEI  
FEI - FLL Engaged Internal

enumerator kMCG\_ModeFBI  
FBI - FLL Bypassed Internal

enumerator kMCG\_ModeBLPI  
BLPI - Bypassed Low Power Internal

enumerator kMCG\_ModeFEE  
FEE - FLL Engaged External

enumerator kMCG\_ModeFBE  
FBE - FLL Bypassed External

enumerator kMCG\_ModeBLPE  
BLPE - Bypassed Low Power External

enumerator kMCG\_ModePBE  
PBE - PLL Bypassed External

enumerator kMCG\_ModePEE  
PEE - PLL Engaged External

enumerator kMCG\_ModePEI  
PEI - PLL Engaged Internal

enumerator kMCG\_ModePBI  
PBI - PLL Bypassed Internal

enumerator kMCG\_ModeError  
Unknown mode

typedef enum `_clock_name` clock\_name\_t

Clock name used to get clock frequency.

typedef enum `_clock_ip_name` clock\_ip\_name\_t

Clock gate name used for `CLOCK_EnableClock/CLOCK_DisableClock`.

typedef struct *\_sim\_clock\_config* sim\_clock\_config\_t

SIM configuration structure for clock setting.

typedef enum *\_osc\_mode* osc\_mode\_t

OSC work mode.

typedef struct *\_oscer\_config* oscer\_config\_t

OSC configuration for OSCERCLK.

typedef struct *\_osc\_config* osc\_config\_t

OSC Initialization Configuration Structure.

Defines the configuration data structure to initialize the OSC. When porting to a new board, set the following members according to the board setting:

- a. freq: The external frequency.
- b. workMode: The OSC module mode.

typedef enum *\_mcg\_fll\_src* mcg\_fll\_src\_t

MCG FLL reference clock source select.

typedef enum *\_mcg\_irc\_mode* mcg\_irc\_mode\_t

MCG internal reference clock select.

typedef enum *\_mcg\_dmx32* mcg\_dmx32\_t

MCG DCO Maximum Frequency with 32.768 kHz Reference.

typedef enum *\_mcg\_drs* mcg\_drs\_t

MCG DCO range select.

typedef enum *\_mcg\_pll\_ref\_src* mcg\_pll\_ref\_src\_t

MCG PLL reference clock select.

typedef enum *\_mcg\_clkout\_src* mcg\_clkout\_src\_t

MCGOUT clock source.

typedef enum *\_mcg\_atm\_select* mcg\_atm\_select\_t

MCG Automatic Trim Machine Select.

typedef enum *\_mcg\_oscsel* mcg\_oscsel\_t

MCG OSC Clock Select.

typedef enum *\_mcg\_pll\_clk\_select* mcg\_pll\_clk\_select\_t

MCG PLLCS select.

typedef enum *\_mcg\_monitor\_mode* mcg\_monitor\_mode\_t

MCG clock monitor mode.

typedef enum *\_mcg\_mode* mcg\_mode\_t

MCG mode definitions.

typedef struct *\_mcg\_pll\_config* mcg\_pll\_config\_t

MCG PLL configuration.

typedef struct *\_mcg\_config* mcg\_config\_t

MCG mode change configuration structure.

When porting to a new board, set the following members according to the board setting:

- a. frdiv: If the FLL uses the external reference clock, set this value to ensure that the external reference clock divided by frdiv is in the 31.25 kHz to 39.0625 kHz range.
- b. The PLL reference clock divider PRDIV: PLL reference clock frequency after PRDIV should be in the FSL\_FEATURE\_MCG\_PLL\_REF\_MIN to FSL\_FEATURE\_MCG\_PLL\_REF\_MAX range.

`volatile uint32_t g_xtal0Freq`

External XTAL0 (OSC0) clock frequency.

The XTAL0/EXTAL0 (OSC0) clock frequency in Hz. When the clock is set up, use the function `CLOCK_SetXtal0Freq` to set the value in the clock driver. For example, if XTAL0 is 8 MHz:

```
Set up the OSC0
CLOCK_InitOsc0(...);
Set the XTAL0 value to the clock driver.
CLOCK_SetXtal0Freq(8000000);
```

This is important for the multicore platforms where only one core needs to set up the OSC0 using the `CLOCK_InitOsc0`. All other cores need to call the `CLOCK_SetXtal0Freq` to get a valid clock frequency.

`volatile uint32_t g_xtal32Freq`

External XTAL32/EXTAL32/RTC\_CLKIN clock frequency.

The XTAL32/EXTAL32/RTC\_CLKIN clock frequency in Hz. When the clock is set up, use the function `CLOCK_SetXtal32Freq` to set the value in the clock driver.

This is important for the multicore platforms where only one core needs to set up the clock. All other cores need to call the `CLOCK_SetXtal32Freq` to get a valid clock frequency.

`static inline void CLOCK_EnableClock(clock_ip_name_t name)`

Enable the clock for specific IP.

#### Parameters

- `name` – Which clock to enable, see `clock_ip_name_t`.

`static inline void CLOCK_DisableClock(clock_ip_name_t name)`

Disable the clock for specific IP.

#### Parameters

- `name` – Which clock to disable, see `clock_ip_name_t`.

`static inline void CLOCK_SetEr32kClock(uint32_t src)`

Set ERCLK32K source.

#### Parameters

- `src` – The value to set ERCLK32K clock source.

`static inline void CLOCK_SetAfeClkSrc(uint32_t src)`

Set the clock selection of AFECLKSEL.

#### Parameters

- `src` – The value to set AFECLKSEL clock source.

`static inline void CLOCK_SetClkOutClock(uint32_t src)`

Set CLKOUT source.

#### Parameters

- `src` – The value to set CLKOUT source.

`static inline void CLOCK_SetAdcTriggerClock(uint32_t src)`

Set ADC trigger clock source.

#### Parameters

- `src` – The value to set ADC trigger clock source.

uint32\_t CLOCK\_GetAfeFreq(void)

Gets the clock frequency for AFE module.

This function checks the current mode configurations in MISC\_CTL register.

**Returns**

Clock frequency value in Hertz

uint32\_t CLOCK\_GetFreq(*clock\_name\_t* clockName)

Gets the clock frequency for a specific clock name.

This function checks the current clock configurations and then calculates the clock frequency for a specific clock name defined in *clock\_name\_t*. The MCG must be properly configured before using this function.

**Parameters**

- clockName – Clock names defined in *clock\_name\_t*

**Returns**

Clock frequency value in Hertz

uint32\_t CLOCK\_GetCoreSysClkFreq(void)

Get the core clock or system clock frequency.

**Returns**

Clock frequency in Hz.

uint32\_t CLOCK\_GetPlatClkFreq(void)

Get the platform clock frequency.

**Returns**

Clock frequency in Hz.

uint32\_t CLOCK\_GetBusClkFreq(void)

Get the bus clock frequency.

**Returns**

Clock frequency in Hz.

uint32\_t CLOCK\_GetFlashClkFreq(void)

Get the flash clock frequency.

**Returns**

Clock frequency in Hz.

uint32\_t CLOCK\_GetEr32kClkFreq(void)

Get the external reference 32K clock frequency (ERCLK32K).

**Returns**

Clock frequency in Hz.

uint32\_t CLOCK\_GetOsc0ErClkFreq(void)

Get the OSC0 external reference clock frequency (OSC0ERCLK).

**Returns**

Clock frequency in Hz.

void CLOCK\_SetSimConfig(*sim\_clock\_config\_t* const \*config)

Set the clock configure in SIM module.

This function sets system layer clock settings in SIM module.

**Parameters**

- config – Pointer to the configure structure.

`static inline void CLOCK_SetSimSafeDivs(void)`

Set the system clock dividers in SIM to safe value.

The system level clocks (core clock, bus clock, flexbus clock and flash clock) must be in allowed ranges. During MCG clock mode switch, the MCG output clock changes then the system level clocks may be out of range. This function could be used before MCG mode change, to make sure system level clocks are in allowed range.

`FSL_CLOCK_DRIVER_VERSION`

CLOCK driver version 2.0.1.

`SDK_DEVICE_MAXIMUM_CPU_CLOCK_FREQUENCY`

`DMAMUX_CLOCKS`

Clock ip name array for DMAMUX.

`RTC_CLOCKS`

Clock ip name array for RTC.

`SPI_CLOCKS`

Clock ip name array for SPI.

`SLCD_CLOCKS`

Clock ip name array for SLCD.

`EWM_CLOCKS`

Clock ip name array for EWM.

`AFE_CLOCKS`

Clock ip name array for AFE.

`ADC16_CLOCKS`

Clock ip name array for ADC16.

`XBAR_CLOCKS`

Clock ip name array for XBAR.

`SYSMPU_CLOCKS`

Clock ip name array for MPU.

`VREF_CLOCKS`

Clock ip name array for VREF.

`DMA_CLOCKS`

Clock ip name array for DMA.

`PORT_CLOCKS`

Clock ip name array for PORT.

`UART_CLOCKS`

Clock ip name array for UART.

`PIT_CLOCKS`

Clock ip name array for PIT.

`RNGA_CLOCKS`

Clock ip name array for RNGA.

`CRC_CLOCKS`

Clock ip name array for CRC.

`I2C_CLOCKS`

Clock ip name array for I2C.

LPTMR\_CLOCKS

Clock ip name array for LPTMR.

TMR\_CLOCKS

Clock ip name array for TMR.

PDB\_CLOCKS

Clock ip name array for PDB.

FTF\_CLOCKS

Clock ip name array for FTF.

CMP\_CLOCKS

Clock ip name array for CMP.

LPO\_CLK\_FREQ

LPO clock frequency.

SYS\_CLK

Peripherals clock source definition.

BUS\_CLK

I2C0\_CLK\_SRC

I2C1\_CLK\_SRC

SPI0\_CLK\_SRC

SPI1\_CLK\_SRC

UART0\_CLK\_SRC

UART1\_CLK\_SRC

UART2\_CLK\_SRC

UART3\_CLK\_SRC

CLK\_GATE\_REG\_OFFSET\_SHIFT

CLK\_GATE\_REG\_OFFSET\_MASK

CLK\_GATE\_BIT\_SHIFT\_SHIFT

CLK\_GATE\_BIT\_SHIFT\_MASK

CLK\_GATE\_DEFINE(reg\_offset, bit\_shift)

CLK\_GATE\_ABSTRACT\_REG\_OFFSET(x)

CLK\_GATE\_ABSTRACT\_BITS\_SHIFT(x)

uint32\_t CLOCK\_GetOutClkFreq(void)

Gets the MCG output clock (MCGOUTCLK) frequency.

This function gets the MCG output clock frequency in Hz based on the current MCG register value.

**Returns**

The frequency of MCGOUTCLK.

uint32\_t CLOCK\_GetFllFreq(void)

Gets the MCG FLL clock (MCGFLLCLK) frequency.

This function gets the MCG FLL clock frequency in Hz based on the current MCG register value. The FLL is enabled in FEI/FBI/FEE/FBE mode and disabled in low power state in other modes.

**Returns**

The frequency of MCGFLLCLK.

uint32\_t CLOCK\_GetInternalRefClkFreq(void)

Gets the MCG internal reference clock (MCGIRCLK) frequency.

This function gets the MCG internal reference clock frequency in Hz based on the current MCG register value.

**Returns**

The frequency of MCGIRCLK.

uint32\_t CLOCK\_GetFixedFreqClkFreq(void)

Gets the MCG fixed frequency clock (MCGFFCLK) frequency.

This function gets the MCG fixed frequency clock frequency in Hz based on the current MCG register value.

**Returns**

The frequency of MCGFFCLK.

uint32\_t CLOCK\_GetPll0Freq(void)

Gets the MCG PLL0 clock (MCGPLL0CLK) frequency.

This function gets the MCG PLL0 clock frequency in Hz based on the current MCG register value.

**Returns**

The frequency of MCGPLL0CLK.

static inline void CLOCK\_SetLowPowerEnable(bool enable)

Enables or disables the MCG low power.

Enabling the MCG low power disables the PLL and FLL in bypass modes. In other words, in FBE and PBE modes, enabling low power sets the MCG to BLPE mode. In FBI and PBI modes, enabling low power sets the MCG to BLPI mode. When disabling the MCG low power, the PLL or FLL are enabled based on MCG settings.

**Parameters**

- enable – True to enable MCG low power, false to disable MCG low power.

status\_t CLOCK\_SetInternalRefClkConfig(uint8\_t enableMode, mcg\_irc\_mode\_t ircs, uint8\_t fcrdiv)

Configures the Internal Reference clock (MCGIRCLK).

This function sets the MCGIRCLK base on parameters. It also selects the IRC source. If the fast IRC is used, this function sets the fast IRC divider. This function also sets whether the MCGIRCLK is enabled in stop mode. Calling this function in FBI/PBI/BLPI modes may change the system clock. As a result, using the function in these modes it is not allowed.

**Parameters**

- enableMode – MCGIRCLK enable mode, OR'ed value of the enumeration `_mcg_ircclk_enable_mode`.
- ircs – MCGIRCLK clock source, choose fast or slow.
- fcrdiv – Fast IRC divider setting (FCRDIV).

**Return values**

- `kStatus_MCG_SourceUsed` – Because the internal reference clock is used as a clock source, the configuration should not be changed. Otherwise, a glitch occurs.
- `kStatus_Success` – MCGIRCLK configuration finished successfully.

`status_t` `CLOCK_SetExternalRefClkConfig(mcg_oscsele_t oscsel)`

Selects the MCG external reference clock.

Selects the MCG external reference clock source, changes the `MCG_C7[OSCSEL]`, and waits for the clock source to be stable. Because the external reference clock should not be changed in FEE/FBE/BLPE/PBE/PEE modes, do not call this function in these modes.

#### Parameters

- `oscsel` – MCG external reference clock source, `MCG_C7[OSCSEL]`.

#### Return values

- `kStatus_MCG_SourceUsed` – Because the external reference clock is used as a clock source, the configuration should not be changed. Otherwise, a glitch occurs.
- `kStatus_Success` – External reference clock set successfully.

`static inline void` `CLOCK_SetFllExtRefDiv(uint8_t frdiv)`

Set the FLL external reference clock divider value.

Sets the FLL external reference clock divider value, the register `MCG_C1[FRDIV]`.

#### Parameters

- `frdiv` – The FLL external reference clock divider value, `MCG_C1[FRDIV]`.

`void` `CLOCK_EnablePll0(mcg_pll_config_t const *config)`

Enables the PLL0 in FLL mode.

This function sets up the PLL0 in FLL mode and reconfigures the PLL0. Ensure that the PLL reference clock is enabled before calling this function and that the PLL0 is not used as a clock source. The function `CLOCK_CalcPllDiv` gets the correct PLL divider values.

#### Parameters

- `config` – Pointer to the configuration structure.

`static inline void` `CLOCK_DisablePll0(void)`

Disables the PLL0 in FLL mode.

This function disables the PLL0 in FLL mode. It should be used together with the `CLOCK_EnablePll0`.

`void` `CLOCK_SetOsc0MonitorMode(mcg_monitor_mode_t mode)`

Sets the OSC0 clock monitor mode.

This function sets the OSC0 clock monitor mode. See `mcg_monitor_mode_t` for details.

#### Parameters

- `mode` – Monitor mode to set.

`void` `CLOCK_SetRtcOscMonitorMode(mcg_monitor_mode_t mode)`

Sets the RTC OSC clock monitor mode.

This function sets the RTC OSC clock monitor mode. See `mcg_monitor_mode_t` for details.

#### Parameters

- `mode` – Monitor mode to set.

void CLOCK\_SetPll0MonitorMode(*mcg\_monitor\_mode\_t* mode)

Sets the PLL0 clock monitor mode.

This function sets the PLL0 clock monitor mode. See *mcg\_monitor\_mode\_t* for details.

#### Parameters

- mode – Monitor mode to set.

uint32\_t CLOCK\_GetStatusFlags(void)

Gets the MCG status flags.

This function gets the MCG clock status flags. All status flags are returned as a logical OR of the enumeration refer to *\_mcg\_status\_flags\_t*. To check a specific flag, compare the return value with the flag.

Example:

To check the clock lost lock status of OSC0 and PLL0.

```
uint32_t mcgFlags;

mcgFlags = CLOCK_GetStatusFlags();

if (mcgFlags & kMCG_Osc0LostFlag)
{
    OSC0 clock lock lost. Do something.
}
if (mcgFlags & kMCG_Pll0LostFlag)
{
    PLL0 clock lock lost. Do something.
}
```

#### Returns

Logical OR value of the enumeration *\_mcg\_status\_flags\_t*.

void CLOCK\_ClearStatusFlags(uint32\_t mask)

Clears the MCG status flags.

This function clears the MCG clock lock lost status. The parameter is a logical OR value of the flags to clear. See the enumeration *\_mcg\_status\_flags\_t*.

Example:

To clear the clock lost lock status flags of OSC0 and PLL0.

```
CLOCK_ClearStatusFlags(kMCG_Osc0LostFlag | kMCG_Pll0LostFlag);
```

#### Parameters

- mask – The status flags to clear. This is a logical OR of members of the enumeration *\_mcg\_status\_flags\_t*.

static inline void OSC\_SetExtRefClkConfig(OSC\_Type \*base, *oscer\_config\_t* const \*config)

Configures the OSC external reference clock (OSCERCLK).

This function configures the OSC external reference clock (OSCERCLK). This is an example to enable the OSCERCLK in normal and stop modes and also set the output divider to 1:

```
oscer_config_t config =
{
    .enableMode = kOSC_ErClkEnable | kOSC_ErClkEnableInStop,
    .erclkDiv   = 1U,
};

OSC_SetExtRefClkConfig(OSC, &config);
```

**Parameters**

- base – OSC peripheral address.
- config – Pointer to the configuration structure.

static inline void OSC\_SetCapLoad(OSC\_Type \*base, uint8\_t capLoad)

Sets the capacitor load configuration for the oscillator.

This function sets the specified capacitors configuration for the oscillator. This should be done in the early system level initialization function call based on the system configuration.

Example:

```
To enable only 2 pF and 8 pF capacitor load, please use like this.  
OSC_SetCapLoad(OSC, kOSC_Cap2P | kOSC_Cap8P);
```

**Parameters**

- base – OSC peripheral address.
- capLoad – OR'ed value for the capacitor load option, see \_osc\_cap\_load.

void CLOCK\_InitOsc0(osc\_config\_t const \*config)

Initializes the OSC0.

This function initializes the OSC0 according to the board configuration.

**Parameters**

- config – Pointer to the OSC0 configuration structure.

void CLOCK\_DeinitOsc0(void)

Deinitializes the OSC0.

This function deinitializes the OSC0.

static inline void CLOCK\_SetXtal0Freq(uint32\_t freq)

Sets the XTAL0 frequency based on board settings.

**Parameters**

- freq – The XTAL0/EXTAL0 input clock frequency in Hz.

static inline void CLOCK\_SetXtal32Freq(uint32\_t freq)

Sets the XTAL32/RTC\_CLKIN frequency based on board settings.

**Parameters**

- freq – The XTAL32/EXTAL32/RTC\_CLKIN input clock frequency in Hz.

void CLOCK\_SetSlowIrcFreq(uint32\_t freq)

Set the Slow IRC frequency based on the trimmed value.

**Parameters**

- freq – The Slow IRC frequency input clock frequency in Hz.

void CLOCK\_SetFastIrcFreq(uint32\_t freq)

Set the Fast IRC frequency based on the trimmed value.

**Parameters**

- freq – The Fast IRC frequency input clock frequency in Hz.

*status\_t* CLOCK\_TrimInternalRefClk(uint32\_t extFreq, uint32\_t desireFreq, uint32\_t \*actualFreq, *mcg\_atm\_select\_t* atms)

Auto trims the internal reference clock.

This function trims the internal reference clock by using the external clock. If successful, it returns the kStatus\_Success and the frequency after trimming is received in the parameter actualFreq. If an error occurs, the error code is returned.

#### Parameters

- extFreq – External clock frequency, which should be a bus clock.
- desireFreq – Frequency to trim to.
- actualFreq – Actual frequency after trimming.
- atms – Trim fast or slow internal reference clock.

#### Return values

- kStatus\_Success – ATM success.
- kStatus\_MCG\_AtmBusClockInvalid – The bus clock is not in allowed range for the ATM.
- kStatus\_MCG\_AtmDesiredFreqInvalid – MCGIRCLK could not be trimmed to the desired frequency.
- kStatus\_MCG\_AtmIrcUsed – Could not trim because MCGIRCLK is used as a bus clock source.
- kStatus\_MCG\_AtmHardwareFail – Hardware fails while trimming.

*mcg\_mode\_t* CLOCK\_GetMode(void)

Gets the current MCG mode.

This function checks the MCG registers and determines the current MCG mode.

#### Returns

Current MCG mode or error code; See *mcg\_mode\_t*.

*status\_t* CLOCK\_SetFeiMode(*mcg\_dmx32\_t* dmx32, *mcg\_drs\_t* drs, void (\*flStableDelay)(void))

Sets the MCG to FEI mode.

This function sets the MCG to FEI mode. If setting to FEI mode fails from the current mode, this function returns an error.

---

**Note:** If dmx32 is set to kMCG\_Dmx32Fine, the slow IRC must not be trimmed to a frequency above 32768 Hz.

---

#### Parameters

- dmx32 – DMX32 in FEI mode.
- drs – The DCO range selection.
- flStableDelay – Delay function to ensure that the FLL is stable. Passing NULL does not cause a delay.

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

```
status_t CLOCK_SetFeeMode(uint8_t frdiv, mcg_dmx32_t dmx32, mcg_drs_t drs, void (*flStableDelay)(void))
```

Sets the MCG to FEE mode.

This function sets the MCG to FEE mode. If setting to FEE mode fails from the current mode, this function returns an error.

#### Parameters

- frdiv – FLL reference clock divider setting, FRDIV.
- dmx32 – DMX32 in FEE mode.
- drs – The DCO range selection.
- flStableDelay – Delay function to make sure FLL is stable. Passing NULL does not cause a delay.

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

```
status_t CLOCK_SetFbiMode(mcg_dmx32_t dmx32, mcg_drs_t drs, void (*flStableDelay)(void))
```

Sets the MCG to FBI mode.

This function sets the MCG to FBI mode. If setting to FBI mode fails from the current mode, this function returns an error.

---

**Note:** If dmx32 is set to kMCG\_Dmx32Fine, the slow IRC must not be trimmed to frequency above 32768 Hz.

---

#### Parameters

- dmx32 – DMX32 in FBI mode.
- drs – The DCO range selection.
- flStableDelay – Delay function to make sure FLL is stable. If the FLL is not used in FBI mode, this parameter can be NULL. Passing NULL does not cause a delay.

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

```
status_t CLOCK_SetFbeMode(uint8_t frdiv, mcg_dmx32_t dmx32, mcg_drs_t drs, void (*flStableDelay)(void))
```

Sets the MCG to FBE mode.

This function sets the MCG to FBE mode. If setting to FBE mode fails from the current mode, this function returns an error.

#### Parameters

- frdiv – FLL reference clock divider setting, FRDIV.
- dmx32 – DMX32 in FBE mode.
- drs – The DCO range selection.
- flStableDelay – Delay function to make sure FLL is stable. If the FLL is not used in FBE mode, this parameter can be NULL. Passing NULL does not cause a delay.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* CLOCK\_SetBlpiMode(void)

Sets the MCG to BLPI mode.

This function sets the MCG to BLPI mode. If setting to BLPI mode fails from the current mode, this function returns an error.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* CLOCK\_SetBlpeMode(void)

Sets the MCG to BLPE mode.

This function sets the MCG to BLPE mode. If setting to BLPE mode fails from the current mode, this function returns an error.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* CLOCK\_SetPbeMode(*mcg\_pll\_clk\_select\_t* pllcs, *mcg\_pll\_config\_t* const \*config)

Sets the MCG to PBE mode.

This function sets the MCG to PBE mode. If setting to PBE mode fails from the current mode, this function returns an error.

---

**Note:**

- a. The parameter `pllcs` selects the PLL. For platforms with only one PLL, the parameter `pllcs` is kept for interface compatibility.
  - b. The parameter `config` is the PLL configuration structure. On some platforms, it is possible to choose the external PLL directly, which renders the configuration structure not necessary. In this case, pass in `NULL`. For example: `CLOCK_SetPbeMode(kMCG_OscselOsc, kMCG_PllClkSelExtPll, NULL);`
- 

**Parameters**

- `pllcs` – The PLL selection, `PLLCS`.
- `config` – Pointer to the PLL configuration.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* CLOCK\_SetPeeMode(void)

Sets the MCG to PEE mode.

This function sets the MCG to PEE mode.

---

**Note:** This function only changes the CLKS to use the PLL/FLL output. If the PRDIV/VDIV are different than in the PBE mode, set them up in PBE mode and wait. When the clock is stable, switch to PEE mode.

---

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* `CLOCK_SetPbiMode(void)`

Sets the MCG to PBI mode.

This function sets the MCG to PBI mode.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* `CLOCK_SetPeiMode(void)`

Sets the MCG to PEI mode.

This function sets the MCG to PEI mode.

**Return values**

- `kStatus_MCG_ModeUnreachable` – Could not switch to the target mode.
- `kStatus_Success` – Switched to the target mode successfully.

*status\_t* `CLOCK_ExternalModeToFbeModeQuick(void)`

Switches the MCG to FBE mode from the external mode.

This function switches the MCG from external modes (PEE/PBE/BLPE/FEE) to the FBE mode quickly. The external clock is used as the system clock source and PLL is disabled. However, the FLL settings are not configured. This is a lite function with a small code size, which is useful during the mode switch. For example, to switch from PEE mode to FEI mode:

```
CLOCK_ExternalModeToFbeModeQuick();
CLOCK_SetFeiMode(...);
```

**Return values**

- `kStatus_Success` – Switched successfully.
- `kStatus_MCG_ModeInvalid` – If the current mode is not an external mode, do not call this function.

*status\_t* `CLOCK_InternalModeToFbiModeQuick(void)`

Switches the MCG to FBI mode from internal modes.

This function switches the MCG from internal modes (PEI/PBI/BLPI/FEI) to the FBI mode quickly. The MCGIRCLK is used as the system clock source and PLL is disabled. However, FLL settings are not configured. This is a lite function with a small code size, which is useful during the mode switch. For example, to switch from PEI mode to FEE mode:

```
CLOCK_InternalModeToFbiModeQuick();
CLOCK_SetFeeMode(...);
```

**Return values**

- `kStatus_Success` – Switched successfully.
- `kStatus_MCG_ModeInvalid` – If the current mode is not an internal mode, do not call this function.

*status\_t* CLOCK\_BootToFeiMode(*mcg\_dmx32\_t* dmx32, *mcg\_drs\_t* drs, void (\*fllStableDelay)(void))

Sets the MCG to FEI mode during system boot up.

This function sets the MCG to FEI mode from the reset mode. It can also be used to set up MCG during system boot up.

---

**Note:** If *dmx32* is set to *kMCG\_Dmx32Fine*, the slow IRC must not be trimmed to frequency above 32768 Hz.

---

#### Parameters

- *dmx32* – DMX32 in FEI mode.
- *drs* – The DCO range selection.
- *fllStableDelay* – Delay function to ensure that the FLL is stable.

#### Return values

- *kStatus\_MCG\_ModeUnreachable* – Could not switch to the target mode.
- *kStatus\_Success* – Switched to the target mode successfully.

*status\_t* CLOCK\_BootToFeeMode(*mcg\_oscsel\_t* oscsel, *uint8\_t* frdiv, *mcg\_dmx32\_t* dmx32, *mcg\_drs\_t* drs, void (\*fllStableDelay)(void))

Sets the MCG to FEE mode during system bootup.

This function sets MCG to FEE mode from the reset mode. It can also be used to set up the MCG during system boot up.

#### Parameters

- *oscsel* – OSC clock select, OSCSEL.
- *frdiv* – FLL reference clock divider setting, FRDIV.
- *dmx32* – DMX32 in FEE mode.
- *drs* – The DCO range selection.
- *fllStableDelay* – Delay function to ensure that the FLL is stable.

#### Return values

- *kStatus\_MCG\_ModeUnreachable* – Could not switch to the target mode.
- *kStatus\_Success* – Switched to the target mode successfully.

*status\_t* CLOCK\_BootToBlpiMode(*uint8\_t* fcrdiv, *mcg\_irc\_mode\_t* ircs, *uint8\_t* ircEnableMode)

Sets the MCG to BLPI mode during system boot up.

This function sets the MCG to BLPI mode from the reset mode. It can also be used to set up the MCG during system boot up.

#### Parameters

- *fcrdiv* – Fast IRC divider, FCRDIV.
- *ircs* – The internal reference clock to select, IRCS.
- *ircEnableMode* – The MCGIRCLK enable mode, OR'ed value of the enumeration *\_mcg\_ircclk\_enable\_mode*.

#### Return values

- *kStatus\_MCG\_SourceUsed* – Could not change MCGIRCLK setting.
- *kStatus\_Success* – Switched to the target mode successfully.

*status\_t* CLOCK\_BootToBlpeMode(*mcg\_oscsel\_t* oscsel)

Sets the MCG to BLPE mode during system boot up.

This function sets the MCG to BLPE mode from the reset mode. It can also be used to set up the MCG during system boot up.

#### Parameters

- oscsel – OSC clock select, MCG\_C7[OSCSEL].

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

*status\_t* CLOCK\_BootToPeeMode(*mcg\_oscsel\_t* oscsel, *mcg\_pll\_clk\_select\_t* pllcs, *mcg\_pll\_config\_t* const \*config)

Sets the MCG to PEE mode during system boot up.

This function sets the MCG to PEE mode from reset mode. It can also be used to set up the MCG during system boot up.

#### Parameters

- oscsel – OSC clock select, MCG\_C7[OSCSEL].
- pllcs – The PLL selection, PLLCS.
- config – Pointer to the PLL configuration.

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

*status\_t* CLOCK\_BootToPeiMode(void)

Sets the MCG to PEI mode during system boot up.

This function sets the MCG to PEI mode from the reset mode. It can be used to set up the MCG during system boot up.

#### Return values

- kStatus\_MCG\_ModeUnreachable – Could not switch to the target mode.
- kStatus\_Success – Switched to the target mode successfully.

*status\_t* CLOCK\_SetMcgConfig(*mcg\_config\_t* const \*config)

Sets the MCG to a target mode.

This function sets MCG to a target mode defined by the configuration structure. If switching to the target mode fails, this function chooses the correct path.

---

**Note:** If the external clock is used in the target mode, ensure that it is enabled. For example, if the OSC0 is used, set up OSC0 correctly before calling this function.

---

#### Parameters

- config – Pointer to the target MCG mode configuration structure.

#### Returns

Return kStatus\_Success if switched successfully; Otherwise, it returns an error code \_mcg\_status.

`uint8_t er32kSrc`

ERCLK32K source selection.

`uint32_t clkdiv1`

SIM\_CLKDIV1.

`uint8_t enableMode`

OSCERCLK enable mode. OR'ed value of `_oscer_enable_mode`.

`uint32_t freq`

External clock frequency.

`uint8_t capLoad`

Capacitor load setting.

`osc_mode_t workMode`

OSC work mode setting.

`oscer_config_t oscerConfig`

Configuration for OSCERCLK.

`uint8_t enableMode`

Enable mode. OR'ed value of enumeration `_mcg_pll_enable_mode`.

`mcg_pll_ref_src_t refSrc`

PLL reference clock source.

`uint8_t frdiv`

FLL reference clock divider.

`mcg_mode_t mcgMode`

MCG mode.

`uint8_t irclkEnableMode`

MCGIRCLK enable mode.

`mcg_irc_mode_t ircs`

Source, MCG\_C2[IRCS].

`uint8_t ferdiv`

Divider, MCG\_SC[FCRDIV].

`uint8_t frdiv`

Divider MCG\_C1[FRDIV].

`mcg_drs_t drs`

DCO range MCG\_C4[DRST\_DRS].

`mcg_dmx32_t dmx32`

MCG\_C4[DMX32].

`mcg_oscsel_t oscsel`

OSC select MCG\_C7[OSCSSEL].

`mcg_pll_config_t pll0Config`

MCGPLL0CLK configuration.

`MCG_CONFIG_CHECK_PARAM`

Configures whether to check a parameter in a function.

Some MCG settings must be changed with conditions, for example:

- a. MCGIRCLK settings, such as the source, divider, and the trim value should not change when MCGIRCLK is used as a system clock source.

- b. MCG\_C7[OSCSEL] should not be changed when the external reference clock is used as a system clock source. For example, in FBE/BLPE/PBE modes.
- c. The users should only switch between the supported clock modes.

MCG functions check the parameter and MCG status before setting, if not allowed to change, the functions return error. The parameter checking increases code size, if code size is a critical requirement, change MCG\_CONFIG\_CHECK\_PARAM to 0 to disable parameter checking.

FSL\_SDK\_DISABLE\_DRIVER\_CLOCK\_CONTROL

Configure whether driver controls clock.

When set to 0, peripheral drivers will enable clock in initialize function and disable clock in de-initialize function. When set to 1, peripheral driver will not control the clock, application could control the clock out of the driver.

---

**Note:** All drivers share this feature switcher. If it is set to 1, application should handle clock enable and disable for all drivers.

---

struct \_\_sim\_clock\_config

#include <fsl\_clock.h> SIM configuration structure for clock setting.

struct \_\_oscer\_config

#include <fsl\_clock.h> OSC configuration for OSCERCLK.

struct \_\_osc\_config

#include <fsl\_clock.h> OSC Initialization Configuration Structure.

Defines the configuration data structure to initialize the OSC. When porting to a new board, set the following members according to the board setting:

- a. freq: The external frequency.
- b. workMode: The OSC module mode.

struct \_\_mcg\_pll\_config

#include <fsl\_clock.h> MCG PLL configuration.

struct \_\_mcg\_config

#include <fsl\_clock.h> MCG mode change configuration structure.

When porting to a new board, set the following members according to the board setting:

- a. frdiv: If the FLL uses the external reference clock, set this value to ensure that the external reference clock divided by frdiv is in the 31.25 kHz to 39.0625 kHz range.
- b. The PLL reference clock divider PRDIV: PLL reference clock frequency after PRDIV should be in the FSL\_FEATURE\_MCG\_PLL\_REF\_MIN to FSL\_FEATURE\_MCG\_PLL\_REF\_MAX range.

## 2.4 CMP: Analog Comparator Driver

void CMP\_Init(CMP\_Type \*base, const *cmp\_config\_t* \*config)

Initializes the CMP.

This function initializes the CMP module. The operations included are as follows.

- Enabling the clock for CMP module.
- Configuring the comparator.

- Enabling the CMP module. Note that for some devices, multiple CMP instances share the same clock gate. In this case, to enable the clock for any instance enables all CMPs. See the appropriate MCU reference manual for the clock assignment of the CMP.

#### Parameters

- base – CMP peripheral base address.
- config – Pointer to the configuration structure.

void CMP\_Deinit(CMP\_Type \*base)

De-initializes the CMP module.

This function de-initializes the CMP module. The operations included are as follows.

- Disabling the CMP module.
- Disabling the clock for CMP module.

This function disables the clock for the CMP. Note that for some devices, multiple CMP instances share the same clock gate. In this case, before disabling the clock for the CMP, ensure that all the CMP instances are not used.

#### Parameters

- base – CMP peripheral base address.

static inline void CMP\_Enable(CMP\_Type \*base, bool enable)

Enables/disables the CMP module.

#### Parameters

- base – CMP peripheral base address.
- enable – Enables or disables the module.

void CMP\_GetDefaultConfig(*cmp\_config\_t* \*config)

Initializes the CMP user configuration structure.

This function initializes the user configuration structure to these default values.

```
config->enableCmp      = true;
config->hysteresisMode  = kCMP_HysteresisLevel0;
config->enableHighSpeed = false;
config->enableInvertOutput = false;
config->useUnfilteredOutput = false;
config->enablePinOut     = false;
config->enableTriggerMode = false;
```

#### Parameters

- config – Pointer to the configuration structure.

void CMP\_SetInputChannels(CMP\_Type \*base, uint8\_t positiveChannel, uint8\_t negativeChannel)

Sets the input channels for the comparator.

This function sets the input channels for the comparator. Note that two input channels cannot be set the same way in the application. When the user selects the same input from the analog mux to the positive and negative port, the comparator is disabled automatically.

#### Parameters

- base – CMP peripheral base address.
- positiveChannel – Positive side input channel number. Available range is 0-7.

- `negativeChannel` – Negative side input channel number. Available range is 0-7.

`void CMP_EnableDMA(CMP_Type *base, bool enable)`

Enables/disables the DMA request for rising/falling events.

This function enables/disables the DMA request for rising/falling events. Either event triggers the generation of the DMA request from CMP if the DMA feature is enabled. Both events are ignored for generating the DMA request from the CMP if the DMA is disabled.

**Parameters**

- `base` – CMP peripheral base address.
- `enable` – Enables or disables the feature.

`static inline void CMP_EnableWindowMode(CMP_Type *base, bool enable)`

Enables/disables the window mode.

**Parameters**

- `base` – CMP peripheral base address.
- `enable` – Enables or disables the feature.

`static inline void CMP_EnablePassThroughMode(CMP_Type *base, bool enable)`

Enables/disables the pass through mode.

**Parameters**

- `base` – CMP peripheral base address.
- `enable` – Enables or disables the feature.

`void CMP_SetFilterConfig(CMP_Type *base, const cmp_filter_config_t *config)`

Configures the filter.

**Parameters**

- `base` – CMP peripheral base address.
- `config` – Pointer to the configuration structure.

`void CMP_SetDACConfig(CMP_Type *base, const cmp_dac_config_t *config)`

Configures the internal DAC.

**Parameters**

- `base` – CMP peripheral base address.
- `config` – Pointer to the configuration structure. “NULL” disables the feature.

`void CMP_EnableInterrupts(CMP_Type *base, uint32_t mask)`

Enables the interrupts.

**Parameters**

- `base` – CMP peripheral base address.
- `mask` – Mask value for interrupts. See “`_cmp_interrupt_enable`”.

`void CMP_DisableInterrupts(CMP_Type *base, uint32_t mask)`

Disables the interrupts.

**Parameters**

- `base` – CMP peripheral base address.
- `mask` – Mask value for interrupts. See “`_cmp_interrupt_enable`”.

uint32\_t CMP\_GetStatusFlags(CMP\_Type \*base)

Gets the status flags.

**Parameters**

- base – CMP peripheral base address.

**Returns**

Mask value for the asserted flags. See “\_cmp\_status\_flags”.

void CMP\_ClearStatusFlags(CMP\_Type \*base, uint32\_t mask)

Clears the status flags.

**Parameters**

- base – CMP peripheral base address.
- mask – Mask value for the flags. See “\_cmp\_status\_flags”.

FSL\_CMP\_DRIVER\_VERSION

CMP driver version 2.0.3.

enum \_cmp\_interrupt\_enable

Interrupt enable/disable mask.

*Values:*

enumerator kCMP\_OutputRisingInterruptEnable

Comparator interrupt enable rising.

enumerator kCMP\_OutputFallingInterruptEnable

Comparator interrupt enable falling.

enum \_cmp\_status\_flags

Status flags' mask.

*Values:*

enumerator kCMP\_OutputRisingEventFlag

Rising-edge on the comparison output has occurred.

enumerator kCMP\_OutputFallingEventFlag

Falling-edge on the comparison output has occurred.

enumerator kCMP\_OutputAssertEventFlag

Return the current value of the analog comparator output.

enum \_cmp\_hysteresis\_mode

CMP Hysteresis mode.

*Values:*

enumerator kCMP\_HysteresisLevel0

Hysteresis level 0.

enumerator kCMP\_HysteresisLevel1

Hysteresis level 1.

enumerator kCMP\_HysteresisLevel2

Hysteresis level 2.

enumerator kCMP\_HysteresisLevel3

Hysteresis level 3.

enum *\_cmp\_reference\_voltage\_source*

CMP Voltage Reference source.

*Values:*

enumerator *kCMP\_VrefSourceVin1*

Vin1 is selected as a resistor ladder network supply reference Vin.

enumerator *kCMP\_VrefSourceVin2*

Vin2 is selected as a resistor ladder network supply reference Vin.

typedef enum *\_cmp\_hysteresis\_mode* *cmp\_hysteresis\_mode\_t*

CMP Hysteresis mode.

typedef enum *\_cmp\_reference\_voltage\_source* *cmp\_reference\_voltage\_source\_t*

CMP Voltage Reference source.

typedef struct *\_cmp\_config* *cmp\_config\_t*

Configures the comparator.

typedef struct *\_cmp\_filter\_config* *cmp\_filter\_config\_t*

Configures the filter.

typedef struct *\_cmp\_dac\_config* *cmp\_dac\_config\_t*

Configures the internal DAC.

struct *\_cmp\_config*

*#include <fsl\_cmp.h>* Configures the comparator.

### Public Members

bool *enableCmp*

Enable the CMP module.

*cmp\_hysteresis\_mode\_t* *hysteresisMode*

CMP Hysteresis mode.

bool *enableHighSpeed*

Enable High-speed (HS) comparison mode.

bool *enableInvertOutput*

Enable the inverted comparator output.

bool *useUnfilteredOutput*

Set the compare output(COUT) to equal COUTA(true) or COUT(false).

bool *enablePinOut*

The comparator output is available on the associated pin.

bool *enableTriggerMode*

Enable the trigger mode.

struct *\_cmp\_filter\_config*

*#include <fsl\_cmp.h>* Configures the filter.

### Public Members

bool *enableSample*

Using the external SAMPLE as a sampling clock input or using a divided bus clock.

uint8\_t filterCount

Filter Sample Count. Available range is 1-7; 0 disables the filter.

uint8\_t filterPeriod

Filter Sample Period. The divider to the bus clock. Available range is 0-255.

struct \_\_cmp\_dac\_config

*#include <fsl\_cmp.h>* Configures the internal DAC.

### Public Members

*cmp\_reference\_voltage\_source\_t* referenceVoltageSource

Supply voltage reference source.

uint8\_t DACValue

Value for the DAC Output Voltage. Available range is 0-63.

## 2.5 CRC: Cyclic Redundancy Check Driver

FSL\_CRC\_DRIVER\_VERSION

CRC driver version. Version 2.1.0.

Current version: 2.1.0

Change log:

- Version 2.1.0
  - Choosing CRC clocks from CRC clock array according to instance instead of hard-coded value.
- Version 2.0.5
  - Fix CERT-C issue with boolean-to-unsigned integer conversion.
- Version 2.0.4
  - Release peripheral from reset if necessary in init function.
- Version 2.0.3
  - Fix MISRA issues
- Version 2.0.2
  - Fix MISRA issues
- Version 2.0.1
  - move DATA and DATALL macro definition from header file to source file

enum \_\_crc\_bits

CRC bit width.

*Values:*

enumerator kCrcBits16

Generate 16-bit CRC code

enumerator kCrcBits32

Generate 32-bit CRC code

enum `_crc_result`

CRC result type.

*Values:*

enumerator `kCrcFinalChecksum`

CRC data register read value is the final checksum. Reflect out and final xor protocol features are applied.

enumerator `kCrcIntermediateChecksum`

CRC data register read value is intermediate checksum (raw value). Reflect out and final xor protocol feature are not applied. Intermediate checksum can be used as a seed for `CRC_Init()` to continue adding data to this checksum.

typedef enum `_crc_bits` `crc_bits_t`

CRC bit width.

typedef enum `_crc_result` `crc_result_t`

CRC result type.

typedef struct `_crc_config` `crc_config_t`

CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

void `CRC_Init(CRC_Type *base, const crc_config_t *config)`

Enables and configures the CRC peripheral module.

This function enables the clock gate in the SIM module for the CRC peripheral. It also configures the CRC module and starts a checksum computation by writing the seed.

#### Parameters

- `base` – CRC peripheral address.
- `config` – CRC module configuration structure.

void `CRC_Deinit(CRC_Type *base)`

Disables the CRC peripheral module.

This function disables the clock gate in the SIM module for the CRC peripheral.

#### Parameters

- `base` – CRC peripheral address.

void `CRC_GetDefaultConfig(crc_config_t *config)`

Loads default values to the CRC protocol configuration structure.

Loads default values to the CRC protocol configuration structure. The default values are as follows.

```
config->polynomial = 0x1021;
config->seed = 0xFFFF;
config->reflectIn = false;
config->reflectOut = false;
config->complementChecksum = false;
config->crcBits = kCrcBits16;
config->crcResult = kCrcFinalChecksum;
```

#### Parameters

- `config` – CRC protocol configuration structure.

`void CRC_WriteData(CRC_Type *base, const uint8_t *data, size_t dataSize)`

Writes data to the CRC module.

Writes input data buffer bytes to the CRC data register. The configured type of transpose is applied.

#### Parameters

- `base` – CRC peripheral address.
- `data` – Input data stream, MSByte in `data[0]`.
- `dataSize` – Size in bytes of the input data buffer.

`uint32_t CRC_Get32bitResult(CRC_Type *base)`

Reads the 32-bit checksum from the CRC module.

Reads the CRC data register (either an intermediate or the final checksum). The configured type of transpose and complement is applied.

#### Parameters

- `base` – CRC peripheral address.

#### Returns

An intermediate or the final 32-bit checksum, after configured transpose and complement operations.

`uint16_t CRC_Get16bitResult(CRC_Type *base)`

Reads a 16-bit checksum from the CRC module.

Reads the CRC data register (either an intermediate or the final checksum). The configured type of transpose and complement is applied.

#### Parameters

- `base` – CRC peripheral address.

#### Returns

An intermediate or the final 16-bit checksum, after configured transpose and complement operations.

`CRC_DRIVER_USE_CRC16_CCIT_FALSE_AS_DEFAULT`

Default configuration structure filled by `CRC_GetDefaultConfig()`. Use CRC16-CCIT-FALSE as default.

`struct _crc_config`

*#include <fsl\_crc.h>* CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

#### Public Members

`uint32_t polynomial`

CRC Polynomial, MSBit first. Example polynomial:  $0x1021 = 1\_0000\_0010\_0001 = x^{12} + x^5 + 1$

`uint32_t seed`

Starting checksum value

`bool reflectIn`

Reflect bits on input.

`bool reflectOut`

Reflect bits on output.

`bool complementChecksum`

True if the result shall be complement of the actual checksum.

`crc_bits_t crcBits`

Selects 16- or 32- bit CRC protocol.

`crc_result_t crcResult`

Selects final or intermediate checksum return from `CRC_Get16bitResult()` or `CRC_Get32bitResult()`

## 2.6 DMA: Direct Memory Access Controller Driver

`void DMA_Init(DMA_Type *base)`

Initializes the DMA peripheral.

This function ungates the DMA clock.

### Parameters

- `base` – DMA peripheral base address.

`void DMA_Deinit(DMA_Type *base)`

Deinitializes the DMA peripheral.

This function gates the DMA clock.

### Parameters

- `base` – DMA peripheral base address.

`void DMA_ResetChannel(DMA_Type *base, uint32_t channel)`

Resets the DMA channel.

Sets all register values to reset values and enables the cycle steal and auto stop channel request features.

### Parameters

- `base` – DMA peripheral base address.
- `channel` – DMA channel number.

`void DMA_SetTransferConfig(DMA_Type *base, uint32_t channel, const dma_transfer_config_t *config)`

Configures the DMA transfer attribute.

This function configures the transfer attribute including the source address, destination address, transfer size, and so on. This example shows how to set up the `dma_transfer_config_t` parameters and how to call the `DMA_ConfigBasicTransfer` function.

```
dma_transfer_config_t transferConfig;
memset(&transferConfig, 0, sizeof(transferConfig));
transferConfig.srcAddr = (uint32_t)srcAddr;
transferConfig.destAddr = (uint32_t)destAddr;
transferConfig.enableSrcIncrement = true;
transferConfig.enableDestIncrement = true;
transferConfig.srcSize = kDMA_TransferSize32bits;
transferConfig.destSize = kDMA_TransferSize32bits;
transferConfig.transferSize = sizeof(uint32_t) * BUFF_LENGTH;
DMA_SetTransferConfig(DMA0, 0, &transferConfig);
```

### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- config – Pointer to the DMA transfer configuration structure.

```
void DMA_SetChannelLinkConfig(DMA_Type *base, uint32_t channel, const  
                             dma_channel_link_config_t *config)
```

Configures the DMA channel link feature.

This function allows DMA channels to have their transfers linked. The current DMA channel triggers a DMA request to the linked channels (LCH1 or LCH2) depending on the channel link type. Perform a link to channel LCH1 after each cycle-steal transfer followed by a link to LCH2 after the BCR decrements to 0 if the type is kDMA\_ChannelLinkChannel1AndChannel2. Perform a link to LCH1 after each cycle-steal transfer if the type is kDMA\_ChannelLinkChannel1. Perform a link to LCH1 after the BCR decrements to 0 if the type is kDMA\_ChannelLinkChannel1AfterBCR0.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- config – Pointer to the channel link configuration structure.

```
static inline void DMA_SetSourceAddress(DMA_Type *base, uint32_t channel, uint32_t srcAddr)
```

Sets the DMA source address for the DMA transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- srcAddr – DMA source address.

```
static inline void DMA_SetDestinationAddress(DMA_Type *base, uint32_t channel, uint32_t  
                                             destAddr)
```

Sets the DMA destination address for the DMA transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- destAddr – DMA destination address.

```
static inline void DMA_SetTransferSize(DMA_Type *base, uint32_t channel, uint32_t size)
```

Sets the DMA transfer size for the DMA transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- size – The number of bytes to be transferred.

```
void DMA_SetModulo(DMA_Type *base, uint32_t channel, dma_modulo_t srcModulo,  
                  dma_modulo_t destModulo)
```

Sets the DMA modulo for the DMA transfer.

This function defines a specific address range specified to be the value after (SAR + SSIZE)/(DAR + DSIZE) calculation is performed or the original register value. It provides the ability to implement a circular data queue easily.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- srcModulo – source address modulo.
- destModulo – destination address modulo.

static inline void DMA\_EnableCycleSteal(DMA\_Type \*base, uint32\_t channel, bool enable)

Enables the DMA cycle steal for the DMA transfer.

If the cycle steal feature is enabled (true), the DMA controller forces a single read/write transfer per request, or it continuously makes read/write transfers until the BCR decrements to 0.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- enable – The command for enable (true) or disable (false).

static inline void DMA\_EnableAutoAlign(DMA\_Type \*base, uint32\_t channel, bool enable)

Enables the DMA auto align for the DMA transfer.

If the auto align feature is enabled (true), the appropriate address register increments regardless of DINC or SINC.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- enable – The command for enable (true) or disable (false).

static inline void DMA\_EnableAsyncRequest(DMA\_Type \*base, uint32\_t channel, bool enable)

Enables the DMA async request for the DMA transfer.

If the async request feature is enabled (true), the DMA supports asynchronous DREQs while the MCU is in stop mode.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.
- enable – The command for enable (true) or disable (false).

static inline void DMA\_EnableInterrupts(DMA\_Type \*base, uint32\_t channel)

Enables an interrupt for the DMA transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_DisableInterrupts(DMA\_Type \*base, uint32\_t channel)

Disables an interrupt for the DMA transfer.

#### Parameters

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_EnableChannelRequest(DMA\_Type \*base, uint32\_t channel)

Enables the DMA hardware channel request.

**Parameters**

- base – DMA peripheral base address.
- channel – The DMA channel number.

static inline void DMA\_DisableChannelRequest(DMA\_Type \*base, uint32\_t channel)

Disables the DMA hardware channel request.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

static inline void DMA\_TriggerChannelStart(DMA\_Type \*base, uint32\_t channel)

Starts the DMA transfer with a software trigger.

This function starts only one read/write iteration.

**Parameters**

- base – DMA peripheral base address.
- channel – The DMA channel number.

static inline void DMA\_EnableAutoStopRequest(DMA\_Type \*base, uint32\_t channel, bool enable)

Starts the DMA enable/disable auto disable request.

**Parameters**

- base – DMA peripheral base address.
- channel – The DMA channel number.
- enable – true is enable, false is disable.

static inline uint32\_t DMA\_GetRemainingBytes(DMA\_Type \*base, uint32\_t channel)

Gets the remaining bytes of the current DMA transfer.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

**Returns**

The number of bytes which have not been transferred yet.

static inline uint32\_t DMA\_GetChannelStatusFlags(DMA\_Type \*base, uint32\_t channel)

Gets the DMA channel status flags.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.

**Returns**

The mask of the channel status. Use the `_dma_channel_status_flags` type to decode the return 32 bit variables.

static inline void DMA\_ClearChannelStatusFlags(DMA\_Type \*base, uint32\_t channel, uint32\_t mask)

Clears the DMA channel status flags.

**Parameters**

- base – DMA peripheral base address.
- channel – DMA channel number.
- mask – The mask of the channel status to be cleared. Use the defined `_dma_channel_status_flags` type.

void DMA\_CreateHandle(*dma\_handle\_t* \*handle, DMA\_Type \*base, uint32\_t channel)

Creates the DMA handle.

This function is called first if using the transactional API for the DMA. This function initializes the internal state of the DMA handle.

#### Parameters

- handle – DMA handle pointer. The DMA handle stores callback function and parameters.
- base – DMA peripheral base address.
- channel – DMA channel number.

void DMA\_SetCallback(*dma\_handle\_t* \*handle, *dma\_callback* callback, void \*userData)

Sets the DMA callback function.

This callback is called in the DMA IRQ handler. Use the callback to do something after the current transfer complete.

#### Parameters

- handle – DMA handle pointer.
- callback – DMA callback function pointer.
- userData – Parameter for callback function. If it is not needed, just set to NULL.

void DMA\_PrepareTransferConfig(*dma\_transfer\_config\_t* \*config, void \*srcAddr, uint32\_t srcWidth, void \*destAddr, uint32\_t destWidth, uint32\_t transferBytes, *dma\_addr\_increment\_t* srcIncrement, *dma\_addr\_increment\_t* destIncrement)

Prepares the DMA transfer configuration structure.

This function prepares the transfer configuration structure according to the user input. The difference between this function and `DMA_PrepareTransfer` is that this function expose the address increment parameter to application, but in `DMA_PrepareTransfer`, only parts of the address increment option can be selected by `dma_transfer_type_t`.

#### Parameters

- config – Pointer to the user configuration structure of type `dma_transfer_config_t`.
- srcAddr – DMA transfer source address.
- srcWidth – DMA transfer source address width (byte).
- destAddr – DMA transfer destination address.
- destWidth – DMA transfer destination address width (byte).
- transferBytes – DMA transfer bytes to be transferred.
- srcIncrement – source address increment type.
- destIncrement – dest address increment type.

```
void DMA__PrepareTransfer(dma_transfer_config_t *config, void *srcAddr, uint32_t srcWidth,  
                        void *destAddr, uint32_t destWidth, uint32_t transferBytes,  
                        dma_transfer_type_t type)
```

Prepares the DMA transfer configuration structure.

This function prepares the transfer configuration structure according to the user input.

#### Parameters

- config – Pointer to the user configuration structure of type *dma\_transfer\_config\_t*.
- srcAddr – DMA transfer source address.
- srcWidth – DMA transfer source address width (byte).
- destAddr – DMA transfer destination address.
- destWidth – DMA transfer destination address width (byte).
- transferBytes – DMA transfer bytes to be transferred.
- type – DMA transfer type.

```
status_t DMA__SubmitTransfer(dma_handle_t *handle, const dma_transfer_config_t *config,  
                           uint32_t options)
```

Submits the DMA transfer request.

This function submits the DMA transfer request according to the transfer configuration structure.

---

**Note:** This function can't process multi transfer request.

---

#### Parameters

- handle – DMA handle pointer.
- config – Pointer to DMA transfer configuration structure.
- options – Additional configurations for transfer. Use the defined *dma\_transfer\_options\_t* type.

#### Return values

- kStatus\_DMA\_Success – It indicates that the DMA submit transfer request succeeded.
- kStatus\_DMA\_Busy – It indicates that the DMA is busy. Submit transfer request is not allowed.

```
static inline void DMA__StartTransfer(dma_handle_t *handle)
```

DMA starts a transfer.

This function enables the channel request. Call this function after submitting a transfer request.

#### Parameters

- handle – DMA handle pointer.

#### Return values

- kStatus\_DMA\_Success – It indicates that the DMA start transfer succeed.
- kStatus\_DMA\_Busy – It indicates that the DMA has started a transfer.

static inline void DMA\_StopTransfer(*dma\_handle\_t* \*handle)

DMA stops a transfer.

This function disables the channel request to stop a DMA transfer. The transfer can be resumed by calling the DMA\_StartTransfer.

**Parameters**

- handle – DMA handle pointer.

void DMA\_AbortTransfer(*dma\_handle\_t* \*handle)

DMA aborts a transfer.

This function disables the channel request and clears all status bits. Submit another transfer after calling this API.

**Parameters**

- handle – DMA handle pointer.

void DMA\_HandleIRQ(*dma\_handle\_t* \*handle)

DMA IRQ handler for current transfer complete.

This function clears the channel interrupt flag and calls the callback function if it is not NULL.

**Parameters**

- handle – DMA handle pointer.

FSL\_DMA\_DRIVER\_VERSION

DMA driver version 2.1.3.

\_dma\_channel\_status\_flags status flag for the DMA driver.

*Values:*

enumerator kDMA\_TransactionsBCRFlag

Contains the number of bytes yet to be transferred for a given block

enumerator kDMA\_TransactionsDoneFlag

Transactions Done

enumerator kDMA\_TransactionsBusyFlag

Transactions Busy

enumerator kDMA\_TransactionsRequestFlag

Transactions Request

enumerator kDMA\_BusErrorOnDestinationFlag

Bus Error on Destination

enumerator kDMA\_BusErrorOnSourceFlag

Bus Error on Source

enumerator kDMA\_ConfigurationErrorFlag

Configuration Error

enum \_dma\_transfer\_size

DMA transfer size type.

*Values:*

enumerator kDMA\_Transfersize32bits

32 bits are transferred for every read/write

enumerator kDMA\_\_Transfersize8bits

8 bits are transferred for every read/write

enumerator kDMA\_\_Transfersize16bits

16b its are transferred for every read/write

enum \_\_dma\_\_modulo

Configuration type for the DMA modulo.

*Values:*

enumerator kDMA\_\_ModuloDisable

Buffer disabled

enumerator kDMA\_\_Modulo16Bytes

Circular buffer size is 16 bytes.

enumerator kDMA\_\_Modulo32Bytes

Circular buffer size is 32 bytes.

enumerator kDMA\_\_Modulo64Bytes

Circular buffer size is 64 bytes.

enumerator kDMA\_\_Modulo128Bytes

Circular buffer size is 128 bytes.

enumerator kDMA\_\_Modulo256Bytes

Circular buffer size is 256 bytes.

enumerator kDMA\_\_Modulo512Bytes

Circular buffer size is 512 bytes.

enumerator kDMA\_\_Modulo1KBytes

Circular buffer size is 1 KB.

enumerator kDMA\_\_Modulo2KBytes

Circular buffer size is 2 KB.

enumerator kDMA\_\_Modulo4KBytes

Circular buffer size is 4 KB.

enumerator kDMA\_\_Modulo8KBytes

Circular buffer size is 8 KB.

enumerator kDMA\_\_Modulo16KBytes

Circular buffer size is 16 KB.

enumerator kDMA\_\_Modulo32KBytes

Circular buffer size is 32 KB.

enumerator kDMA\_\_Modulo64KBytes

Circular buffer size is 64 KB.

enumerator kDMA\_\_Modulo128KBytes

Circular buffer size is 128 KB.

enumerator kDMA\_\_Modulo256KBytes

Circular buffer size is 256 KB.

enum \_\_dma\_\_channel\_\_link\_\_type

DMA channel link type.

*Values:*

enumerator kDMA\_ChannelLinkDisable

No channel link.

enumerator kDMA\_ChannelLinkChannel1AndChannel2

Perform a link to channel LCH1 after each cycle-steal transfer. followed by a link to LCH2 after the BCR decrements to 0.

enumerator kDMA\_ChannelLinkChannel1

Perform a link to LCH1 after each cycle-steal transfer.

enumerator kDMA\_ChannelLinkChannel1AfterBCR0

Perform a link to LCH1 after the BCR decrements.

enum \_dma\_transfer\_type

DMA transfer type.

*Values:*

enumerator kDMA\_MemoryToMemory

Memory to Memory transfer.

enumerator kDMA\_PeripheralToMemory

Peripheral to Memory transfer.

enumerator kDMA\_MemoryToPeripheral

Memory to Peripheral transfer.

enum \_dma\_transfer\_options

DMA transfer options.

*Values:*

enumerator kDMA\_NoOptions

Transfer without options.

enumerator kDMA\_EnableInterrupt

Enable interrupt while transfer complete.

enum \_dma\_addr\_increment

dma addre increment type

*Values:*

enumerator kDMA\_AddrNoIncrement

Transfer address not increment.

enumerator kDMA\_AddrIncrementPerTransferWidth

Transfer address increment per transfer width

\_dma\_transfer\_status DMA transfer status

*Values:*

enumerator kStatus\_DMA\_Busy

DMA is busy.

typedef enum \_dma\_transfer\_size dma\_transfer\_size\_t

DMA transfer size type.

typedef enum \_dma\_modulo dma\_modulo\_t

Configuration type for the DMA modulo.

typedef enum *\_dma\_channel\_link\_type* dma\_channel\_link\_type\_t  
DMA channel link type.

typedef enum *\_dma\_transfer\_type* dma\_transfer\_type\_t  
DMA transfer type.

typedef enum *\_dma\_transfer\_options* dma\_transfer\_options\_t  
DMA transfer options.

typedef enum *\_dma\_addr\_increment* dma\_addr\_increment\_t  
dma addre increment type

typedef struct *\_dma\_transfer\_config* dma\_transfer\_config\_t  
DMA transfer configuration structure.

typedef struct *\_dma\_channel\_link\_config* dma\_channel\_link\_config\_t  
DMA transfer configuration structure.

typedef void (\*dma\_callback)(struct *\_dma\_handle* \*handle, void \*userData)  
Callback function prototype for the DMA driver.

typedef struct *\_dma\_handle* dma\_handle\_t  
DMA DMA handle structure.

struct *\_dma\_transfer\_config*  
*#include <fsl\_dma.h>* DMA transfer configuration structure.

### Public Members

uint32\_t srcAddr  
DMA transfer source address.

uint32\_t destAddr  
DMA destination address.

bool enableSrcIncrement  
Source address increase after each transfer.

*dma\_transfer\_size\_t* srcSize  
Source transfer size unit.

bool enableDestIncrement  
Destination address increase after each transfer.

*dma\_transfer\_size\_t* destSize  
Destination transfer unit.

uint32\_t transferSize  
The number of bytes to be transferred.

struct *\_dma\_channel\_link\_config*  
*#include <fsl\_dma.h>* DMA transfer configuration structure.

### Public Members

*dma\_channel\_link\_type\_t* linkType  
Channel link type.

uint32\_t channel1  
The index of channel 1.

uint32\_t channel2

The index of channel 2.

struct \_\_dma\_handle

*#include <fsl\_dma.h>* DMA DMA handle structure.

### Public Members

DMA\_Type \*base

DMA peripheral address.

uint8\_t channel

DMA channel used.

*dma\_callback* callback

DMA callback function.

void \*userData

Callback parameter.

## 2.7 DMAMUX: Direct Memory Access Multiplexer Driver

void DMAMUX\_Init(DMAMUX\_Type \*base)

Initializes the DMAMUX peripheral.

This function ungates the DMAMUX clock.

### Parameters

- base – DMAMUX peripheral base address.

void DMAMUX\_Deinit(DMAMUX\_Type \*base)

Deinitializes the DMAMUX peripheral.

This function gates the DMAMUX clock.

### Parameters

- base – DMAMUX peripheral base address.

static inline void DMAMUX\_EnableChannel(DMAMUX\_Type \*base, uint32\_t channel)

Enables the DMAMUX channel.

This function enables the DMAMUX channel.

### Parameters

- base – DMAMUX peripheral base address.
- channel – DMAMUX channel number.

static inline void DMAMUX\_DisableChannel(DMAMUX\_Type \*base, uint32\_t channel)

Disables the DMAMUX channel.

This function disables the DMAMUX channel.

---

**Note:** The user must disable the DMAMUX channel before configuring it.

---

### Parameters

- base – DMAMUX peripheral base address.

- channel – DMAMUX channel number.

static inline void DMAMUX\_SetSource(DMAMUX\_Type \*base, uint32\_t channel, int32\_t source)

Configures the DMAMUX channel source.

#### Parameters

- base – DMAMUX peripheral base address.
- channel – DMAMUX channel number.
- source – Channel source, which is used to trigger the DMA transfer. User need to use the `dma_request_source_t` type as the input parameter.

static inline void DMAMUX\_EnablePeriodTrigger(DMAMUX\_Type \*base, uint32\_t channel)

Enables the DMAMUX period trigger.

This function enables the DMAMUX period trigger feature.

#### Parameters

- base – DMAMUX peripheral base address.
- channel – DMAMUX channel number.

static inline void DMAMUX\_DisablePeriodTrigger(DMAMUX\_Type \*base, uint32\_t channel)

Disables the DMAMUX period trigger.

This function disables the DMAMUX period trigger.

#### Parameters

- base – DMAMUX peripheral base address.
- channel – DMAMUX channel number.

FSL\_DMAMUX\_DRIVER\_VERSION

DMAMUX driver version 2.1.1.

## 2.8 EWM: External Watchdog Monitor Driver

void EWM\_Init(EWM\_Type \*base, const *ewm\_config\_t* \*config)

Initializes the EWM peripheral.

This function is used to initialize the EWM. After calling, the EWM runs immediately according to the configuration. Note that, except for the interrupt enable control bit, other control bits and registers are write once after a CPU reset. Modifying them more than once generates a bus transfer error.

This is an example.

```
ewm_config_t config;
EWM_GetDefaultConfig(&config);
config.compareHighValue = 0xAAU;
EWM_Init(ewm_base, &config);
```

#### Parameters

- base – EWM peripheral base address
- config – The configuration of the EWM

`void EWM_Deinit(EWM_Type *base)`

Deinitializes the EWM peripheral.

This function is used to shut down the EWM.

#### Parameters

- `base` – EWM peripheral base address

`void EWM_GetDefaultConfig(ewm_config_t *config)`

Initializes the EWM configuration structure.

This function initializes the EWM configuration structure to default values. The default values are as follows.

```
ewmConfig->enableEwm = true;
ewmConfig->enableEwmInput = false;
ewmConfig->setInputAssertLogic = false;
ewmConfig->enableInterrupt = false;
ewmConfig->ewm_lpo_clock_source_t = kEWM_LpoClockSource0;
ewmConfig->prescaler = 0;
ewmConfig->compareLowValue = 0;
ewmConfig->compareHighValue = 0xFEU;
```

#### See also:

`ewm_config_t`

#### Parameters

- `config` – Pointer to the EWM configuration structure.

`static inline void EWM_EnableInterrupts(EWM_Type *base, uint32_t mask)`

Enables the EWM interrupt.

This function enables the EWM interrupt.

#### Parameters

- `base` – EWM peripheral base address
- `mask` – The interrupts to enable The parameter can be combination of the following source if defined
  - `kEWM_InterruptEnable`

`static inline void EWM_DisableInterrupts(EWM_Type *base, uint32_t mask)`

Disables the EWM interrupt.

This function enables the EWM interrupt.

#### Parameters

- `base` – EWM peripheral base address
- `mask` – The interrupts to disable The parameter can be combination of the following source if defined
  - `kEWM_InterruptEnable`

`static inline uint32_t EWM_GetStatusFlags(EWM_Type *base)`

Gets all status flags.

This function gets all status flags.

This is an example for getting the running flag.

```
uint32_t status;  
status = EWM_GetStatusFlags(ewm_base) & kEWM_RunningFlag;
```

**See also:**

`_ewm_status_flags_t`

- True: a related status flag has been set.
- False: a related status flag is not set.

**Parameters**

- base – EWM peripheral base address

**Returns**

State of the status flag: asserted (true) or not-asserted (false).

`void EWM_Refresh(EWM_Type *base)`

Services the EWM.

This function resets the EWM counter to zero.

**Parameters**

- base – EWM peripheral base address

`FSL_EWM_DRIVER_VERSION`

EWM driver version 2.0.4.

`enum _ewm_lpo_clock_source`

Describes EWM clock source.

*Values:*

enumerator `kEWM_LpoClockSource0`

EWM clock sourced from `lpo_clk[0]`

enumerator `kEWM_LpoClockSource1`

EWM clock sourced from `lpo_clk[1]`

enumerator `kEWM_LpoClockSource2`

EWM clock sourced from `lpo_clk[2]`

enumerator `kEWM_LpoClockSource3`

EWM clock sourced from `lpo_clk[3]`

`enum _ewm_interrupt_enable_t`

EWM interrupt configuration structure with default settings all disabled.

This structure contains the settings for all of EWM interrupt configurations.

*Values:*

enumerator `kEWM_InterruptEnable`

Enable the EWM to generate an interrupt

`enum _ewm_status_flags_t`

EWM status flags.

This structure contains the constants for the EWM status flags for use in the EWM functions.

*Values:*

enumerator `kEWM_RunningFlag`

Running flag, set when EWM is enabled

```
typedef enum _ewm_lpo_clock_source ewm_lpo_clock_source_t
```

Describes EWM clock source.

```
typedef struct _ewm_config ewm_config_t
```

Data structure for EWM configuration.

This structure is used to configure the EWM.

```
struct _ewm_config
```

*#include <fsl\_ewm.h>* Data structure for EWM configuration.

This structure is used to configure the EWM.

### Public Members

```
bool enableEwm
```

Enable EWM module

```
bool enableEwmInput
```

Enable EWM\_in input

```
bool setInputAssertLogic
```

EWM\_in signal assertion state

```
bool enableInterrupt
```

Enable EWM interrupt

```
ewm_lpo_clock_source_t clockSource
```

Clock source select

```
uint8_t prescaler
```

Clock prescaler value

```
uint8_t compareLowValue
```

Compare low-register value

```
uint8_t compareHighValue
```

Compare high-register value

## 2.9 FGPIO Driver

### 2.10 C90TFS Flash Driver

### 2.11 ftfx adapter

### 2.12 Ftftx CACHE Driver

```
enum _ftfx_cache_ram_func_constants
```

Constants for execute-in-RAM flash function.

*Values:*

```
enumerator kFTFx_CACHE_RamFuncMaxSizeInWords
```

The maximum size of execute-in-RAM function.

typedef struct *\_flash\_prefetch\_speculation\_status* ftfx\_prefetch\_speculation\_status\_t  
FTFx prefetch speculation status.

typedef struct *\_ftfx\_cache\_config* ftfx\_cache\_config\_t  
FTFx cache driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

*status\_t* FTFx\_CACHE\_Init(*ftfx\_cache\_config\_t* \*config)  
Initializes the global FTFx cache structure members.

This function checks and initializes the Flash module for the other FTFx cache APIs.

#### Parameters

- config – Pointer to the storage for the driver runtime state.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.

*status\_t* FTFx\_CACHE\_ClearCachePrefetchSpeculation(*ftfx\_cache\_config\_t* \*config, bool  
isPreProcess)

Process the cache/prefetch/speculation to the flash.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- isPreProcess – The possible option used to control flash cache/prefetch/speculation

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – Invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.

*status\_t* FTFx\_CACHE\_PflashSetPrefetchSpeculation(*ftfx\_prefetch\_speculation\_status\_t*  
\*speculationStatus)

Sets the PFlash prefetch speculation to the intended speculation status.

#### Parameters

- speculationStatus – The expected protect status to set to the PFlash protection register. Each bit is

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidSpeculationOption – An invalid speculation option argument is provided.

*status\_t* FTFx\_CACHE\_PflashGetPrefetchSpeculation(*ftfx\_prefetch\_speculation\_status\_t*  
\*speculationStatus)

Gets the PFlash prefetch speculation status.

#### Parameters

- speculationStatus – Speculation status returned by the PFlash IP.

**Return values**

kStatus\_FTFx\_Success – API was executed successfully.

struct \_flash\_prefetch\_speculation\_status

#include <fsl\_ftfx\_cache.h> FTFx prefetch speculation status.

**Public Members**

bool instructionOff

Instruction speculation.

bool dataOff

Data speculation.

union function\_bit\_operation\_ptr\_t

#include <fsl\_ftfx\_cache.h>

**Public Members**

uint32\_t commadAddr

void (\*callFlashCommand)(volatile uint32\_t \*base, uint32\_t bitMask, uint32\_t bitShift, uint32\_t bitValue)

struct \_ftfx\_cache\_config

#include <fsl\_ftfx\_cache.h> FTFx cache driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

**Public Members**

uint8\_t flashMemoryIndex

0 - primary flash; 1 - secondary flash

function\_bit\_operation\_ptr\_t bitOperFuncAddr

An buffer point to the flash execute-in-RAM function.

## 2.13 ftfx controller

FTFx driver status codes.

*Values:*

enumerator kStatus\_FTFx\_Success

API is executed successfully

enumerator kStatus\_FTFx\_InvalidArgument

Invalid argument

enumerator kStatus\_FTFx\_SizeError

Error size

enumerator kStatus\_FTFx\_AlignmentError

Parameter is not aligned with the specified baseline

- enumerator kStatus\_FTFx\_AddressError  
Address is out of range
- enumerator kStatus\_FTFx\_AccessError  
Invalid instruction codes and out-of bound addresses
- enumerator kStatus\_FTFx\_ProtectionViolation  
The program/erase operation is requested to execute on protected areas
- enumerator kStatus\_FTFx\_CommandFailure  
Run-time error during command execution.
- enumerator kStatus\_FTFx\_UnknownProperty  
Unknown property.
- enumerator kStatus\_FTFx\_EraseKeyError  
API erase key is invalid.
- enumerator kStatus\_FTFx\_RegionExecuteOnly  
The current region is execute-only.
- enumerator kStatus\_FTFx\_ExecuteInRamFunctionNotReady  
Execute-in-RAM function is not available.
- enumerator kStatus\_FTFx\_PartitionStatusUpdateFailure  
Failed to update partition status.
- enumerator kStatus\_FTFx\_SetFlexramAsEepromError  
Failed to set FlexRAM as EEPROM.
- enumerator kStatus\_FTFx\_RecoverFlexramAsRamError  
Failed to recover FlexRAM as RAM.
- enumerator kStatus\_FTFx\_SetFlexramAsRamError  
Failed to set FlexRAM as RAM.
- enumerator kStatus\_FTFx\_RecoverFlexramAsEepromError  
Failed to recover FlexRAM as EEPROM.
- enumerator kStatus\_FTFx\_CommandNotSupported  
Flash API is not supported.
- enumerator kStatus\_FTFx\_SwapSystemNotInUninitialized  
Swap system is not in an uninitialized state.
- enumerator kStatus\_FTFx\_SwapIndicatorAddressError  
The swap indicator address is invalid.
- enumerator kStatus\_FTFx\_ReadOnlyProperty  
The flash property is read-only.
- enumerator kStatus\_FTFx\_InvalidPropertyValue  
The flash property value is out of range.
- enumerator kStatus\_FTFx\_InvalidSpeculationOption  
The option of flash prefetch speculation is invalid.
- enumerator kStatus\_FTFx\_CommandOperationInProgress  
The option of flash command is processing.

enum \_ftfx\_driver\_api\_keys

Enumeration for FTFx driver API keys.

---

**Note:** The resulting value is built with a byte order such that the string being readable in expected order when viewed in a hex editor, if the value is treated as a 32-bit little endian value.

---

*Values:*

enumerator kFTFx\_ApiEraseKey

Key value used to validate all FTFx erase APIs.

void FTFx\_API\_Init(*ftfx\_config\_t* \*config)

Initializes the global flash properties structure members.

This function checks and initializes the Flash module for the other Flash APIs.

**Parameters**

- config – Pointer to the storage for the driver runtime state.

status\_t FTFx\_API\_UpdateFlexnvmPartitionStatus(*ftfx\_config\_t* \*config)

Updates FlexNVM memory partition status according to data flash 0 IFR.

This function updates FlexNVM memory partition status.

**Parameters**

- config – Pointer to the storage for the driver runtime state.

**Return values**

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_PartitionStatusUpdateFailure – Failed to update the partition status.

status\_t FTFx\_CMD\_Erase(*ftfx\_config\_t* \*config, uint32\_t start, uint32\_t lengthInBytes, uint32\_t key)

Erases the flash sectors encompassed by parameters passed into function.

This function erases the appropriate number of flash sectors based on the desired start address and length.

**Parameters**

- config – The pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words) to be erased. Must be word-aligned.
- key – The value used to validate all flash erase APIs.

**Return values**

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_AlignmentError – The parameter is not aligned with the specified baseline.
- kStatus\_FTFx\_AddressError – The address is out of range.

- `kStatus_FTFx_EraseKeyError` – The API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_EraseSectorNonBlocking(ftfx_config_t *config, uint32_t start, uint32_t key)`

Erases the flash sectors encompassed by parameters passed into function.

This function erases one flash sector size based on the start address.

#### Parameters

- `config` – The pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- `key` – The value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – The parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – The address is out of range.
- `kStatus_FTFx_EraseKeyError` – The API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.

`status_t FTFx_CMD_EraseAll(ftfx_config_t *config, uint32_t key)`

Erases entire flash.

#### Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FTFx_CMD_EraseAllUnsecure(ftfx_config_t *config, uint32_t key)`

Erases the entire flash, including protected sectors.

#### Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FTFx_CMD_EraseAllExecuteOnlySegments(ftfx_config_t *config, uint32_t key)`

Erases all program flash execute-only segments defined by the FXACC registers.

#### Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_Program(ftfx_config_t *config, uint32_t start, const uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and the length.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_ProgramOnce(ftfx_config_t *config, uint32_t index, const uint8_t *src, uint32_t lengthInBytes)`

Programs Program Once Field through parameters.

This function programs the Program Once Field with the desired data for a given flash area as determined by the index and length.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating which area of the Program Once Field to be programmed.
- `src` – A pointer to the source buffer of data that is to be programmed into the Program Once Field.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.

- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_ProgramSection(ftfx_config_t *config, uint32_t start, const uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters via the Program Section command.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_SetFlexramAsRamError` – Failed to set flexram as RAM.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_RecoverFlexramAsEepromError` – Failed to recover FlexRAM as EEPROM.

`status_t FTFx_CMD_ProgramPartition(ftfx_config_t *config, ftfx_partition_flexram_load_opt_t option, uint32_t eepromDataSizeCode, uint32_t flexnvmPartitionCode, uint8_t CSEcKeySize, uint8_t CFE)`

Prepares the FlexNVM block for use as data flash, EEPROM backup, or a combination of both and initializes the FlexRAM.

#### Parameters

- `config` – Pointer to storage for the driver runtime state.
- `option` – The option used to set FlexRAM load behavior during reset.
- `eepromDataSizeCode` – Determines the amount of FlexRAM used in each of the available EEPROM subsystems.
- `flexnvmPartitionCode` – Specifies how to split the FlexNVM block between data flash memory and EEPROM backup memory supporting EEPROM functions.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – Invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FTFx_CMD_ReadOnce(ftfx_config_t *config, uint32_t index, uint8_t *dst, uint32_t lengthInBytes)`

Reads the Program Once Field through parameters.

This function reads the read once field with given index and length.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating the area of program once field to be read.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_ReadResource(ftfx_config_t *config, uint32_t start, uint8_t *dst, uint32_t lengthInBytes, ftfx_read_resource_opt_t option)`

Reads the resource with data at locations passed in through parameters.

This function reads the flash memory with the desired location for a given flash area as determined by the start address and length.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.

- `lengthInBytes` – The length, given in bytes (not words or long-words), to be read. Must be word-aligned.
- `option` – The resource option which indicates which area should be read back.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_VerifyErase(ftfx_config_t *config, uint32_t start, uint32_t lengthInBytes, ftfx_margin_value_t margin)`

Verifies an erasure of the desired flash area at a specified margin level.

This function checks the appropriate number of flash sectors based on the desired start address and length to check whether the flash is erased to the specified read margin level.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `margin` – Read margin choice.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

*status\_t* FTFx\_CMD\_VerifyEraseAll(*ftfx\_config\_t* \*config, *ftfx\_margin\_value\_t* margin)

Verifies erasure of the entire flash at a specified margin level.

This function checks whether the flash is erased to the specified read margin level.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- margin – Read margin choice.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during the command execution.

*status\_t* FTFx\_CMD\_VerifyEraseAllExecuteOnlySegments(*ftfx\_config\_t* \*config,  
*ftfx\_margin\_value\_t* margin)

Verifies whether the program flash execute-only segments have been erased to the specified read margin level.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- margin – Read margin choice.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during the command execution.

*status\_t* FTFx\_CMD\_VerifyProgram(*ftfx\_config\_t* \*config, uint32\_t start, uint32\_t lengthInBytes,  
const uint8\_t \*expectedData, *ftfx\_margin\_value\_t* margin,  
uint32\_t \*failedAddress, uint32\_t \*failedData)

Verifies programming of the desired flash area at a specified margin level.

This function verifies the data programed in the flash memory using the Flash Program Check Command and compares it to the expected data for a given flash area as determined by the start address and length.

#### Parameters

- config – A pointer to the storage for the driver runtime state.

- `start` – The start address of the desired flash memory to be verified. Must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `expectedData` – A pointer to the expected data that is to be verified against.
- `margin` – Read margin choice.
- `failedAddress` – A pointer to the returned failing address.
- `failedData` – A pointer to the returned failing data. Some derivatives do not include failed data as part of the FCCOBx registers. In this case, zeros are returned upon failure.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_REG_GetSecurityState(ftfx_config_t *config, ftfx_security_state_t *state)`

Returns the security state via the pointer passed into the function.

This function retrieves the current flash security status, including the security enabling state and the backdoor key enabling state.

#### Parameters

- `config` – A pointer to storage for the driver runtime state.
- `state` – A pointer to the value returned for the current security status code:

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

`status_t FTFx_CMD_SecurityBypass(ftfx_config_t *config, const uint8_t *backdoorKey)`

Allows users to bypass security with a backdoor key.

If the MCU is in secured state, this function unsecures the MCU by comparing the provided backdoor key with ones in the flash configuration field.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `backdoorKey` – A pointer to the user buffer containing the backdoor key.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.

- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_SetFlexramFunction(ftfx_config_t *config, ftfx_flexram_func_opt_t option)`

Sets the FlexRAM function command.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `option` – The option used to set the work mode of FlexRAM.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_SwapControl(ftfx_config_t *config, uint32_t address, ftfx_swap_control_opt_t option, ftfx_swap_state_config_t *returnInfo)`

Configures the Swap function or checks the swap state of the Flash module.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `address` – Address used to configure the flash Swap function.
- `option` – The possible option used to configure Flash Swap function or check the flash Swap status
- `returnInfo` – A pointer to the data which is used to return the information of flash Swap.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_SwapIndicatorAddressError` – Swap indicator address is invalid.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`enum _ftfx_partition_flexram_load_option`

Enumeration for the FlexRAM load during reset option.

*Values:*

`enumerator kFTFx_PartitionFlexramLoadOptLoadedWithValidEepromData`

FlexRAM is loaded with valid EEPROM data during reset sequence.

`enumerator kFTFx_PartitionFlexramLoadOptNotLoaded`

FlexRAM is not loaded during reset sequence.

`enum _ftfx_read_resource_opt`

Enumeration for the two possible options of flash read resource command.

*Values:*

`enumerator kFTFx_ResourceOptionFlashIfR`

Select code for Program flash 0 IFR, Program flash swap 0 IFR, Data flash 0 IFR

`enumerator kFTFx_ResourceOptionVersionId`

Select code for the version ID

`enum _ftfx_margin_value`

Enumeration for supported FTFx margin levels.

*Values:*

`enumerator kFTFx_MarginValueNormal`

Use the ‘normal’ read level for 1s.

`enumerator kFTFx_MarginValueUser`

Apply the ‘User’ margin to the normal read-1 level.

`enumerator kFTFx_MarginValueFactory`

Apply the ‘Factory’ margin to the normal read-1 level.

`enumerator kFTFx_MarginValueInvalid`

Not real margin level, Used to determine the range of valid margin level.

`enum _ftfx_security_state`

Enumeration for the three possible FTFx security states.

*Values:*

`enumerator kFTFx_SecurityStateNotSecure`

Flash is not secure.

`enumerator kFTFx_SecurityStateBackdoorEnabled`

Flash backdoor is enabled.

`enumerator kFTFx_SecurityStateBackdoorDisabled`

Flash backdoor is disabled.

enum \_ftfx\_flexram\_function\_option

Enumeration for the two possilbe options of set FlexRAM function command.

*Values:*

enumerator kFTFx\_FlexramFuncOptAvailableAsRam

An option used to make FlexRAM available as RAM

enumerator kFTFx\_FlexramFuncOptEepromQuickWriteRecovery

An option used to complete interrupted EEPROM quick write process

enumerator kFTFx\_FlexramFuncOptEepromQuickWriteStatus

An option used to make EEPROM quick write status query

enumerator kFTFx\_FlexramFuncOptAvailableForEepromQuickWrite

An option used to make FlexRAM available for EEPROM in Quick Write mode

enumerator kFTFx\_FlexramFuncOptAvailableForEeprom

An option used to make FlexRAM available for EEPROM

enum \_flash\_acceleration\_ram\_property

Enumeration for acceleration ram property.

*Values:*

enumerator kFLASH\_AccelerationRamSize

enum \_ftfx\_swap\_control\_option

Enumeration for the possible options of Swap control commands.

*Values:*

enumerator kFTFx\_SwapControlOptionIntializeSystem

An option used to initialize the Swap system

enumerator kFTFx\_SwapControlOptionSetInUpdateState

An option used to set the Swap in an update state

enumerator kFTFx\_SwapControlOptionSetInCompleteState

An option used to set the Swap in a complete state

enumerator kFTFx\_SwapControlOptionReportStatus

An option used to report the Swap status

enumerator kFTFx\_SwapControlOptionDisableSystem

An option used to disable the Swap status

enum \_ftfx\_swap\_state

Enumeration for the possible flash Swap status.

*Values:*

enumerator kFTFx\_SwapStateUninitialized

Flash Swap system is in an uninitialized state.

enumerator kFTFx\_SwapStateReady

Flash Swap system is in a ready state.

enumerator kFTFx\_SwapStateUpdate

Flash Swap system is in an update state.

enumerator kFTFx\_SwapStateUpdateErased

Flash Swap system is in an updateErased state.

enumerator kFTFx\_SwapStateComplete

Flash Swap system is in a complete state.

enumerator kFTFx\_SwapStateDisabled

Flash Swap system is in a disabled state.

enum \_ftfx\_swap\_block\_status

Enumeration for the possible flash Swap block status.

*Values:*

enumerator kFTFx\_SwapBlockStatusLowerHalfProgramBlocksAtZero

Swap block status is that lower half program block at zero.

enumerator kFTFx\_SwapBlockStatusUpperHalfProgramBlocksAtZero

Swap block status is that upper half program block at zero.

enum \_ftfx\_memory\_type

Enumeration for FTFx memory type.

*Values:*

enumerator kFTFx\_MemTypePflash

enumerator kFTFx\_MemTypeFlexnvm

typedef enum \_ftfx\_partition\_flexram\_load\_option ftfx\_partition\_flexram\_load\_opt\_t

Enumeration for the FlexRAM load during reset option.

typedef enum \_ftfx\_read\_resource\_opt ftfx\_read\_resource\_opt\_t

Enumeration for the two possible options of flash read resource command.

typedef enum \_ftfx\_margin\_value ftfx\_margin\_value\_t

Enumeration for supported FTFx margin levels.

typedef enum \_ftfx\_security\_state ftfx\_security\_state\_t

Enumeration for the three possible FTFx security states.

typedef enum \_ftfx\_flexram\_function\_option ftfx\_flexram\_func\_opt\_t

Enumeration for the two possible options of set FlexRAM function command.

typedef enum \_ftfx\_swap\_control\_option ftfx\_swap\_control\_opt\_t

Enumeration for the possible options of Swap control commands.

typedef enum \_ftfx\_swap\_state ftfx\_swap\_state\_t

Enumeration for the possible flash Swap status.

typedef enum \_ftfx\_swap\_block\_status ftfx\_swap\_block\_status\_t

Enumeration for the possible flash Swap block status.

typedef struct \_ftfx\_swap\_state\_config ftfx\_swap\_state\_config\_t

Flash Swap information.

typedef struct \_ftfx\_special\_mem ftfx\_spec\_mem\_t

ftfx special memory access information.

typedef struct \_ftfx\_mem\_descriptor ftfx\_mem\_desc\_t

Flash memory descriptor.

typedef struct \_ftfx\_ops\_config ftfx\_ops\_config\_t

Active FTFx information for the current operation.

typedef struct \_ftfx\_ifr\_descriptor ftfx\_ifr\_desc\_t

Flash IFR memory descriptor.

```
typedef struct _ftfx_config ftfx_config_t
```

Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

```
struct _ftfx_swap_state_config
```

*#include <fsl\_ftfx\_controller.h>* Flash Swap information.

### Public Members

*ftfx\_swap\_state\_t* flashSwapState

The current Swap system status.

*ftfx\_swap\_block\_status\_t* currentSwapBlockStatus

The current Swap block status.

*ftfx\_swap\_block\_status\_t* nextSwapBlockStatus

The next Swap block status.

```
struct _ftfx_special_mem
```

*#include <fsl\_ftfx\_controller.h>* ftfx special memory access information.

### Public Members

uint32\_t base

Base address of flash special memory.

uint32\_t size

size of flash special memory.

uint32\_t count

flash special memory count.

```
struct _ftfx_mem_descriptor
```

*#include <fsl\_ftfx\_controller.h>* Flash memory descriptor.

### Public Members

uint32\_t blockBase

A base address of the flash block

uint32\_t aliasBlockBase

A base address of the alias flash block

uint32\_t totalSize

The size of the flash block.

uint32\_t sectorSize

The size in bytes of a sector of flash.

uint32\_t blockCount

A number of flash blocks.

```
struct _ftfx_ops_config
```

*#include <fsl\_ftfx\_controller.h>* Active FTFx information for the current operation.

### Public Members

uint32\_t convertedAddress

A converted address for the current flash type.

struct \_\_ftfx\_ifr\_descriptor

*#include <fsl\_ftfx\_controller.h>* Flash IFR memory descriptor.

union function\_ptr\_t

*#include <fsl\_ftfx\_controller.h>*

### Public Members

uint32\_t commadAddr

void (\*callFlashCommand)(volatile uint8\_t \*FTMRx\_fstat)

struct \_\_ftfx\_config

*#include <fsl\_ftfx\_controller.h>* Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

### Public Members

uint32\_t flexramBlockBase

The base address of the FlexRAM/acceleration RAM

uint32\_t flexramTotalSize

The size of the FlexRAM/acceleration RAM

uint16\_t eepromTotalSize

The size of EEPROM area which was partitioned from FlexRAM

*function\_ptr\_t* runCmdFuncAddr

An buffer point to the flash execute-in-RAM function.

struct \_\_unnamed12\_\_

### Public Members

uint8\_t type

Type of flash block.

uint8\_t index

Index of flash block.

struct feature

struct addrAligment

struct feature

struct resRange

### Public Members

uint8\_t versionIdStart

Version ID start address

uint32\_t pflashIfrStart

Program Flash 0 IFR start address

uint32\_t dflashIfrStart

Data Flash 0 IFR start address

uint32\_t pflashSwapIfrStart

Program Flash Swap IFR start address

struct idxInfo

## 2.14 ftfx feature

FTFx\_DRIVER\_IS\_FLASH\_RESIDENT

Flash driver location.

Used for the flash resident application.

FTFx\_DRIVER\_IS\_EXPORTED

Flash Driver Export option.

Used for the MCUXpresso SDK application.

FTFx\_FLASH1\_HAS\_PROT\_CONTROL

Indicates whether the secondary flash has its own protection register in flash module.

FTFx\_FLASH1\_HAS\_XACC\_CONTROL

Indicates whether the secondary flash has its own Execute-Only access register in flash module.

FTFx\_DRIVER\_HAS\_FLASH1\_SUPPORT

Indicates whether the secondary flash is supported in the Flash driver.

FTFx\_FLASH\_COUNT

FTFx\_FLASH1\_IS\_INDEPENDENT\_BLOCK

## 2.15 Ftftx FLASH Driver

*status\_t* FLASH\_Init(*flash\_config\_t* \*config)

Initializes the global flash properties structure members.

This function checks and initializes the Flash module for the other Flash APIs.

### Parameters

- config – Pointer to the storage for the driver runtime state.

### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.

- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FLASH_Erase(flash_config_t *config, uint32_t start, uint32_t lengthInBytes, uint32_t key)`

Erases the Dflash sectors encompassed by parameters passed into function.

This function erases the appropriate number of flash sectors based on the desired start address and length.

#### Parameters

- `config` – The pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words) to be erased. Must be word-aligned.
- `key` – The value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the appropriate number of flash sectors based on the desired start address and length were erased successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – The parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – The address is out of range.
- `kStatus_FTFx_EraseKeyError` – The API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_EraseSectorNonBlocking(flash_config_t *config, uint32_t start, uint32_t key)`

Erases the Dflash sectors encompassed by parameters passed into function.

This function erases one flash sector size based on the start address, and it is executed asynchronously.

NOTE: This function can only erase one flash sector at a time, and the other commands can be executed after the previous command has been completed.

#### Parameters

- `config` – The pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- `key` – The value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.

- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – The parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – The address is out of range.
- `kStatus_FTFx_EraseKeyError` – The API erase key is invalid.

`status_t FLASH_EraseAll(flash_config_t *config, uint32_t key)`

Erases entire flexnvm.

#### Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the all pflash and flexnvm were erased successfully, the swap and eeprom have been reset to unconfigured state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FLASH_EraseAllUnsecure(flash_config_t *config, uint32_t key)`

Erases the entire flexnvm, including protected sectors.

#### Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the protected sectors of flash were reset to unprotected status.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FLASH_Program(flash_config_t *config, uint32_t start, uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and the length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data were programed successfully into flash based on desired start address and length.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_ProgramOnce(flash_config_t *config, uint32_t index, uint8_t *src, uint32_t lengthInBytes)`

Program the Program-Once-Field through parameters.

This function Program the Program-once-feild with given index and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating the area of program once field to be read.
- `src` – A pointer to the source buffer of data that is used to store data to be write.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; The index indicating the area of program once field was programed successfully.

- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t` FLASH\_ProgramSection(*flash\_config\_t* \*config, uint32\_t start, uint8\_t \*src, uint32\_t lengthInBytes)

Programs flash with data at locations passed in through parameters via the Program Section command.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data have been programed successfully into flash based on start address and length.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_SetFlexramAsRamError` – Failed to set flexram as RAM.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_RecoverFlexramAsEepromError` – Failed to recover FlexRAM as EEPROM.

`status_t` FLASH\_ReadResource(*flash\_config\_t* \*config, uint32\_t start, uint8\_t \*dst, uint32\_t lengthInBytes, *ftfx\_read\_resource\_opt\_t* option)

Reads the resource with data at locations passed in through parameters.

This function reads the flash memory with the desired location for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be read. Must be word-aligned.
- `option` – The resource option which indicates which area should be read back.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the data have been read successfully from program flash IFR, data flash IFR space, and the Version ID field.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_ReadOnce(flash_config_t *config, uint32_t index, uint8_t *dst, uint32_t lengthInBytes)`

Reads the Program Once Field through parameters.

This function reads the read once feild with given index and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating the area of program once field to be read.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the data have been successfully read form Program flash0 IFR map and Program Once field based on index and length.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.

- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_VerifyErase(flash_config_t *config, uint32_t start, uint32_t lengthInBytes, ftfx_margin_value_t margin)`

Verifies an erasure of the desired flash area at a specified margin level.

This function checks the appropriate number of flash sectors based on the desired start address and length to check whether the flash is erased to the specified read margin level.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `margin` – Read margin choice.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the specified FLASH region has been erased.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_VerifyEraseAll(flash_config_t *config, ftfx_margin_value_t margin)`

Verifies erasure of the entire flash at a specified margin level.

This function checks whether the flash is erased to the specified read margin level.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `margin` – Read margin choice.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; all program flash and flexnvm were in erased state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_VerifyProgram(flash_config_t *config, uint32_t start, uint32_t lengthInBytes, const uint8_t *expectedData, ftfx_margin_value_t margin, uint32_t *failedAddress, uint32_t *failedData)`

Verifies programming of the desired flash area at a specified margin level.

This function verifies the data programmed in the flash memory using the Flash Program Check Command and compares it to the expected data for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. Must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `expectedData` – A pointer to the expected data that is to be verified against.
- `margin` – Read margin choice.
- `failedAddress` – A pointer to the returned failing address.
- `failedData` – A pointer to the returned failing data. Some derivatives do not include failed data as part of the FCCOBx registers. In this case, zeros are returned upon failure.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data have been successfully programed into specified FLASH region.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_GetSecurityState(flash_config_t *config, ftfx_security_state_t *state)`

Returns the security state via the pointer passed into the function.

This function retrieves the current flash security status, including the security enabling state and the backdoor key enabling state.

**Parameters**

- `config` – A pointer to storage for the driver runtime state.
- `state` – A pointer to the value returned for the current security status code:

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully; the security state of flash was stored to state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

`status_t FLASH_SecurityBypass(flash_config_t *config, const uint8_t *backdoorKey)`

Allows users to bypass security with a backdoor key.

If the MCU is in secured state, this function unsecures the MCU by comparing the provided backdoor key with ones in the flash configuration field.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `backdoorKey` – A pointer to the user buffer containing the backdoor key.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_SetFlexramFunction(flash_config_t *config, ftfx_flexram_func_opt_t option)`

Sets the FlexRAM function command.

**Parameters**

- `config` – A pointer to the storage for the driver runtime state.
- `option` – The option used to set the work mode of FlexRAM.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully; the FlexRAM has been successfully configured as RAM or EEPROM.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

*status\_t* FLASH\_Swap(*flash\_config\_t* \*config, uint32\_t address, bool isSetEnable)

Swaps the lower half flash with the higher half flash.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- address – Address used to configure the flash swap function
- isSetEnable – The possible option used to configure the Flash Swap function or check the flash Swap status.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the lower half flash and higher half flash have been swapped.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_AlignmentError – Parameter is not aligned with specified baseline.
- kStatus\_FTFx\_SwapIndicatorAddressError – Swap indicator address is invalid.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during command execution.
- kStatus\_FTFx\_SwapSystemNotInUninitialized – Swap system is not in an uninitialized state.

*status\_t* FLASH\_IsProtected(*flash\_config\_t* \*config, uint32\_t start, uint32\_t lengthInBytes, *flash\_prot\_state\_t* \*protection\_state)

Returns the protection state of the desired flash area via the pointer passed into the function.

This function retrieves the current flash protect status for a given flash area as determined by the start address and length.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be checked. Must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words) to be checked. Must be word-aligned.
- protection\_state – A pointer to the value returned for the current protection status code for the desired flash area.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the protection state of specified FLASH region was stored to protection\_state.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_AlignmentError – Parameter is not aligned with specified baseline.

- `kStatus_FTFx_AddressError` – The address is out of range.

`status_t FLASH_IsExecuteOnly(flash_config_t *config, uint32_t start, uint32_t lengthInBytes, flash_xacc_state_t *access_state)`

Returns the access state of the desired flash area via the pointer passed into the function.

This function retrieves the current flash access status for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be checked. Must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be checked. Must be word-aligned.
- `access_state` – A pointer to the value returned for the current access status code for the desired flash area.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the `executeOnly` state of specified FLASH region was stored to `access_state`.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – The parameter is not aligned to the specified baseline.
- `kStatus_FTFx_AddressError` – The address is out of range.

`status_t FLASH_PflashSetProtection(flash_config_t *config, pflash_prot_status_t *protectStatus)`

Sets the PFlash Protection to the intended protection status.

#### Parameters

- `config` – A pointer to storage for the driver runtime state.
- `protectStatus` – The expected protect status to set to the PFlash protection register. Each bit is corresponding to protection of 1/32(64) of the total PFlash. The least significant bit is corresponding to the lowest address area of PFlash. The most significant bit is corresponding to the highest address area of PFlash. There are two possible cases as shown below: 0: this area is protected. 1: this area is unprotected.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the specified FLASH region is protected.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FLASH_PflashGetProtection(flash_config_t *config, pflash_prot_status_t *protectStatus)`

Gets the PFlash protection status.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `protectStatus` – Protect status returned by the PFlash IP. Each bit is corresponding to the protection of 1/32(64) of the total PFlash. The least significant bit corresponds to the lowest address area of the PFlash. The most significant bit corresponds to the highest address area of PFlash. There

are two possible cases as shown below: 0: this area is protected. 1: this area is unprotected.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully; the Protection state was stored to `protectStatus`;
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

`status_t` FLASH\_GetProperty(*flash\_config\_t* \*config, *flash\_property\_tag\_t* whichProperty, *uint32\_t* \*value)

Returns the desired flash property.

**Parameters**

- config – A pointer to the storage for the driver runtime state.
- whichProperty – The desired property from the list of properties in enum `flash_property_tag_t`
- value – A pointer to the value returned for the desired flash property.

**Return values**

- `kStatus_FTFx_Success` – API was executed successfully; the flash property was stored to value.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_UnknownProperty` – An unknown property tag.

`status_t` FLASH\_GetCommandState(void)

Get previous command status.

This function is used to obtain the execution status of the previous command.

**Return values**

- `kStatus_FTFx_Success` – The previous command is executed successfully.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`FSL_FLASH_DRIVER_VERSION`

Flash driver version for SDK.

Version 3.3.0.

`FSL_FLASH_DRIVER_VERSION_ROM`

Flash driver version for ROM.

Version 3.0.0.

`enum _flash_protection_state`

Enumeration for the three possible flash protection levels.

*Values:*

enumerator `kFLASH_ProtectionStateUnprotected`

Flash region is not protected.

enumerator kFLASH\_ProtectionStateProtected

Flash region is protected.

enumerator kFLASH\_ProtectionStateMixed

Flash is mixed with protected and unprotected region.

enum \_flash\_execute\_only\_access\_state

Enumeration for the three possible flash execute access levels.

*Values:*

enumerator kFLASH\_AccessStateUnLimited

Flash region is unlimited.

enumerator kFLASH\_AccessStateExecuteOnly

Flash region is execute only.

enumerator kFLASH\_AccessStateMixed

Flash is mixed with unlimited and execute only region.

enum \_flash\_property\_tag

Enumeration for various flash properties.

*Values:*

enumerator kFLASH\_PropertyPflash0SectorSize

Pflash sector size property.

enumerator kFLASH\_PropertyPflash0TotalSize

Pflash total size property.

enumerator kFLASH\_PropertyPflash0BlockSize

Pflash block size property.

enumerator kFLASH\_PropertyPflash0BlockCount

Pflash block count property.

enumerator kFLASH\_PropertyPflash0BlockBaseAddr

Pflash block base address property.

enumerator kFLASH\_PropertyPflash0FacSupport

Pflash fac support property.

enumerator kFLASH\_PropertyPflash0AccessSegmentSize

Pflash access segment size property.

enumerator kFLASH\_PropertyPflash0AccessSegmentCount

Pflash access segment count property.

enumerator kFLASH\_PropertyPflash1SectorSize

Pflash sector size property.

enumerator kFLASH\_PropertyPflash1TotalSize

Pflash total size property.

enumerator kFLASH\_PropertyPflash1BlockSize

Pflash block size property.

enumerator kFLASH\_PropertyPflash1BlockCount

Pflash block count property.

enumerator kFLASH\_PropertyPflash1BlockBaseAddr

Pflash block base address property.

enumerator kFLASH\_PropertyPflash1FacSupport

Pflash fac support property.

enumerator kFLASH\_PropertyPflash1AccessSegmentSize

Pflash access segment size property.

enumerator kFLASH\_PropertyPflash1AccessSegmentCount

Pflash access segment count property.

enumerator kFLASH\_PropertyFlexRamBlockBaseAddr

FlexRam block base address property.

enumerator kFLASH\_PropertyFlexRamTotalSize

FlexRam total size property.

typedef enum *\_flash\_protection\_state* flash\_prot\_state\_t

Enumeration for the three possible flash protection levels.

typedef union *\_pflash\_protection\_status* pflash\_prot\_status\_t

PFlash protection status.

typedef enum *\_flash\_execute\_only\_access\_state* flash\_xacc\_state\_t

Enumeration for the three possible flash execute access levels.

typedef enum *\_flash\_property\_tag* flash\_property\_tag\_t

Enumeration for various flash properties.

typedef struct *\_flash\_config* flash\_config\_t

Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

kStatus\_FLASH\_Success

kFLASH\_ApiEraseKey

union *\_pflash\_protection\_status*

*#include <fsl\_ftfx\_flash.h>* PFlash protection status.

## Public Members

uint32\_t protl

PROT[31:0] .

uint32\_t proth

PROT[63:32].

uint8\_t protsl

PROTS[7:0] .

uint8\_t protsh

PROTS[15:8] .

uint8\_t reserved[2]

struct *\_flash\_config*

*#include <fsl\_ftfx\_flash.h>* Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

## 2.16 Ftftx FLEXNVM Driver

*status\_t* FLEXNVM\_Init(*flexnvm\_config\_t* \*config)

Initializes the global flash properties structure members.

This function checks and initializes the Flash module for the other Flash APIs.

### Parameters

- config – Pointer to the storage for the driver runtime state.

### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_PartitionStatusUpdateFailure – Failed to update the partition status.

*status\_t* FLEXNVM\_DflashErase(*flexnvm\_config\_t* \*config, uint32\_t start, uint32\_t lengthInBytes, uint32\_t key)

Erases the Dflash sectors encompassed by parameters passed into function.

This function erases the appropriate number of flash sectors based on the desired start address and length.

### Parameters

- config – The pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words) to be erased. Must be word-aligned.
- key – The value used to validate all flash erase APIs.

### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the appropriate number of date flash sectors based on the desired start address and length were erased successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_AlignmentError – The parameter is not aligned with the specified baseline.
- kStatus\_FTFx\_AddressError – The address is out of range.
- kStatus\_FTFx\_EraseKeyError – The API erase key is invalid.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during the command execution.

*status\_t* FLEXNVM\_EraseAll(*flexnvm\_config\_t* \*config, uint32\_t key)

Erases entire flexnvm.

#### Parameters

- config – Pointer to the storage for the driver runtime state.
- key – A value used to validate all flash erase APIs.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the entire flexnvm has been erased successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_EraseKeyError – API erase key is invalid.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during command execution.
- kStatus\_FTFx\_PartitionStatusUpdateFailure – Failed to update the partition status.

*status\_t* FLEXNVM\_EraseAllUnsecure(*flexnvm\_config\_t* \*config, uint32\_t key)

Erases the entire flexnvm, including protected sectors.

#### Parameters

- config – Pointer to the storage for the driver runtime state.
- key – A value used to validate all flash erase APIs.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the flexnvm is not in security state.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_EraseKeyError – API erase key is invalid.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during command execution.
- kStatus\_FTFx\_PartitionStatusUpdateFailure – Failed to update the partition status.

*status\_t* FLEXNVM\_DflashProgram(*flexnvm\_config\_t* \*config, uint32\_t start, uint8\_t \*src, uint32\_t lengthInBytes)

Programs flash with data at locations passed in through parameters.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and the length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data have been successfully programmed into specified data flash region.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLEXNVM_DflashProgramSection(flexnvm_config_t *config, uint32_t start, uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters via the Program Section command.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data have been successfully programmed into specified data flash area.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.

- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_SetFlexramAsRamError` – Failed to set flexram as RAM.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_RecoverFlexramAsEepromError` – Failed to recover FlexRAM as EEPROM.

`status_t FLEXNVM_ProgramPartition(flexnvm_config_t *config,  
ftfx_partition_flexram_load_opt_t option, uint32_t  
eepromDataSizeCode, uint32_t flexnvmPartitionCode)`

Prepares the FlexNVM block for use as data flash, EEPROM backup, or a combination of both and initializes the FlexRAM.

#### Parameters

- `config` – Pointer to storage for the driver runtime state.
- `option` – The option used to set FlexRAM load behavior during reset.
- `eepromDataSizeCode` – Determines the amount of FlexRAM used in each of the available EEPROM subsystems.
- `flexnvmPartitionCode` – Specifies how to split the FlexNVM block between data flash memory and EEPROM backup memory supporting EEPROM functions.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the FlexNVM block for use as data flash, EEPROM backup, or a combination of both have been Prepared.
- `kStatus_FTFx_InvalidArgument` – Invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FLEXNVM_ProgramPartition_CSE(flexnvm_config_t *config,  
ftfx_partition_flexram_load_opt_t option, uint32_t  
eepromDataSizeCode, uint32_t  
flexnvmPartitionCode, uint8_t CSEcKeySize, uint8_t  
SFE)`

Prepares the FlexNVM block for use as data flash, EEPROM backup, or a combination of both and initializes the FlexRAM. This is the CSE enabled version for IP's like FTFC.

#### Parameters

- `config` – Pointer to storage for the driver runtime state.
- `option` – The option used to set FlexRAM load behavior during reset.
- `eeepromDataSizeCode` – Determines the amount of FlexRAM used in each of the available EEPROM subsystems.
- `flexnvmPartitionCode` – Specifies how to split the FlexNVM block between data flash memory and EEPROM backup memory supporting EEPROM functions.
- `CSEcKeySize` – CSEc/SHE key size, see RM for details and possible values
- `SFE` – Security Flag Extension (SFE), see RM for details and possible values

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the FlexNVM block for use as data flash, EEPROM backup, or a combination of both have been Prepared.
- `kStatus_FTFx_InvalidArgument` – Invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FLEXNVM_ReadResource(flexnvm_config_t *config, uint32_t start, uint8_t *dst, uint32_t lengthInBytes, ftfx_read_resource_opt_t option)`

Reads the resource with data at locations passed in through parameters.

This function reads the flash memory with the desired location for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be read. Must be word-aligned.
- `option` – The resource option which indicates which area should be read back.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the data have been read successfully from program flash IFR, data flash IFR space, and the Version ID field
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLEXNVM_DflashVerifyErase(flexnvm_config_t *config, uint32_t start, uint32_t lengthInBytes, ftfx_margin_value_t margin)`

Verifies an erasure of the desired flash area at a specified margin level.

This function checks the appropriate number of flash sectors based on the desired start address and length to check whether the flash is erased to the specified read margin level.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `margin` – Read margin choice.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the specified data flash region is in erased state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLEXNVM_VerifyEraseAll(flexnvm_config_t *config, ftfx_margin_value_t margin)`

Verifies erasure of the entire flash at a specified margin level.

This function checks whether the flash is erased to the specified read margin level.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `margin` – Read margin choice.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the entire flexnvm region is in erased state.

- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLEXNVM_DflashVerifyProgram(flexnvm_config_t *config, uint32_t start, uint32_t lengthInBytes, const uint8_t *expectedData, ftfx_margin_value_t margin, uint32_t *failedAddress, uint32_t *failedData)`

Verifies programming of the desired flash area at a specified margin level.

This function verifies the data programmed in the flash memory using the Flash Program Check Command and compares it to the expected data for a given flash area as determined by the start address and length.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. Must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `expectedData` – A pointer to the expected data that is to be verified against.
- `margin` – Read margin choice.
- `failedAddress` – A pointer to the returned failing address.
- `failedData` – A pointer to the returned failing data. Some derivatives do not include failed data as part of the FCCOBx registers. In this case, zeros are returned upon failure.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data have been programmed successfully into specified data flash region.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

*status\_t* FLEXNVM\_GetSecurityState(*flexnvm\_config\_t* \*config, *ftfx\_security\_state\_t* \*state)

Returns the security state via the pointer passed into the function.

This function retrieves the current flash security status, including the security enabling state and the backdoor key enabling state.

#### Parameters

- config – A pointer to storage for the driver runtime state.
- state – A pointer to the value returned for the current security status code:

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the security state of flexnvm was stored to state.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.

*status\_t* FLEXNVM\_SecurityBypass(*flexnvm\_config\_t* \*config, const uint8\_t \*backdoorKey)

Allows users to bypass security with a backdoor key.

If the MCU is in secured state, this function unsecures the MCU by comparing the provided backdoor key with ones in the flash configuration field.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- backdoorKey – A pointer to the user buffer containing the backdoor key.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_CommandFailure – Run-time error during the command execution.

*status\_t* FLEXNVM\_SetFlexramFunction(*flexnvm\_config\_t* \*config, *ftfx\_flexram\_func\_opt\_t* option)

Sets the FlexRAM function command.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- option – The option used to set the work mode of FlexRAM.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the FlexRAM has been successfully configured as RAM or EEPROM
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus\_FTFx\_AccessError – Invalid instruction codes and out-of bounds addresses.

- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLEXNVM_DflashSetProtection(flexnvm_config_t *config, uint8_t protectStatus)`

Sets the DFlash protection to the intended protection status.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `protectStatus` – The expected protect status to set to the DFlash protection register. Each bit corresponds to the protection of the 1/8 of the total DFlash. The least significant bit corresponds to the lowest address area of the DFlash. The most significant bit corresponds to the highest address area of the DFlash. There are two possible cases as shown below: 0: this area is protected. 1: this area is unprotected.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully; the specified DFlash region is protected.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_CommandNotSupported` – Flash API is not supported.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FLEXNVM_DflashGetProtection(flexnvm_config_t *config, uint8_t *protectStatus)`

Gets the DFlash protection status.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `protectStatus` – DFlash Protect status returned by the PFlash IP. Each bit corresponds to the protection of the 1/8 of the total DFlash. The least significant bit corresponds to the lowest address area of the DFlash. The most significant bit corresponds to the highest address area of the DFlash, and so on. There are two possible cases as below: 0: this area is protected. 1: this area is unprotected.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_CommandNotSupported` – Flash API is not supported.

`status_t FLEXNVM_EepromSetProtection(flexnvm_config_t *config, uint8_t protectStatus)`

Sets the EEPROM protection to the intended protection status.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `protectStatus` – The expected protect status to set to the EEPROM protection register. Each bit corresponds to the protection of the 1/8 of the total EEPROM. The least significant bit corresponds to the lowest address area of the EEPROM. The most significant bit corresponds to the highest address area of EEPROM, and so on. There are two possible cases as shown below: 0: this area is protected. 1: this area is unprotected.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_CommandNotSupported` – Flash API is not supported.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.

`status_t FLEXNVM_EepromGetProtection(flexnvm_config_t *config, uint8_t *protectStatus)`

Gets the EEPROM protection status.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `protectStatus` – DFlash Protect status returned by the PFlash IP. Each bit corresponds to the protection of the 1/8 of the total EEPROM. The least significant bit corresponds to the lowest address area of the EEPROM. The most significant bit corresponds to the highest address area of the EEPROM. There are two possible cases as below: 0: this area is protected. 1: this area is unprotected.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_CommandNotSupported` – Flash API is not supported.

`status_t FLEXNVM_GetProperty(flexnvm_config_t *config, flexnvm_property_tag_t whichProperty, uint32_t *value)`

Returns the desired flexnvm property.

#### Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `whichProperty` – The desired property from the list of properties in enum `flexnvm_property_tag_t`
- `value` – A pointer to the value returned for the desired flexnvm property.

#### Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_UnknownProperty` – An unknown property tag.

`enum_flexnvm_property_tag`

Enumeration for various flexnvm properties.

*Values:*

enumerator `kFLEXNVM_PropertyDflashSectorSize`  
Dflash sector size property.

enumerator `kFLEXNVM_PropertyDflashTotalSize`  
Dflash total size property.

enumerator `kFLEXNVM_PropertyDflashBlockSize`  
Dflash block size property.

enumerator `kFLEXNVM_PropertyDflashBlockCount`  
Dflash block count property.

enumerator kFLEXNVM\_PropertyDflashBlockBaseAddr

Dflash block base address property.

enumerator kFLEXNVM\_PropertyAliasDflashBlockBaseAddr

Dflash block base address Alias property.

enumerator kFLEXNVM\_PropertyFlexRamBlockBaseAddr

FlexRam block base address property.

enumerator kFLEXNVM\_PropertyFlexRamTotalSize

FlexRam total size property.

enumerator kFLEXNVM\_PropertyEepromTotalSize

EEPROM total size property.

typedef enum *flexnvm\_property\_tag* flexnvm\_property\_tag\_t

Enumeration for various flexnvm properties.

typedef struct *flexnvm\_config* flexnvm\_config\_t

Flexnvm driver state information.

An instance of this structure is allocated by the user of the Flexnvm driver and passed into each of the driver APIs.

*status\_t* FLEXNVM\_EepromWrite(*flexnvm\_config\_t* \*config, uint32\_t start, uint8\_t \*src, uint32\_t lengthInBytes)

Programs the EEPROM with data at locations passed in through parameters.

This function programs the emulated EEPROM with the desired data for a given flash area as determined by the start address and length.

#### Parameters

- config – A pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be programmed. Must be word-aligned.
- src – A pointer to the source buffer of data that is to be programmed into the flash.
- lengthInBytes – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

#### Return values

- kStatus\_FTFx\_Success – API was executed successfully; the desired data have been successfully programmed into specified eeprom region.
- kStatus\_FTFx\_InvalidArgument – An invalid argument is provided.
- kStatus\_FTFx\_AddressError – Address is out of range.
- kStatus\_FTFx\_SetFlexramAsEepromError – Failed to set flexram as eeprom.
- kStatus\_FTFx\_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus\_FTFx\_RecoverFlexramAsRamError – Failed to recover the FlexRAM as RAM.

struct *flexnvm\_config*

*#include <fsl\_ftfx\_flexnvm.h>* Flexnvm driver state information.

An instance of this structure is allocated by the user of the Flexnvm driver and passed into each of the driver APIs.

## 2.17 ftfx utilities

ALIGN\_DOWN(x, a)

Alignment(down) utility.

ALIGN\_UP(x, a)

Alignment(up) utility.

MAKE\_VERSION(major, minor, bugfix)

Constructs the version number for drivers.

MAKE\_STATUS(group, code)

Constructs a status code value from a group and a code number.

FOUR\_CHAR\_CODE(a, b, c, d)

Constructs the four character code for the Flash driver API key.

B1P4(b)

bytes2word utility.

B1P3(b)

B1P2(b)

B1P1(b)

B2P3(b)

B2P2(b)

B2P1(b)

B3P2(b)

B3P1(b)

BYTE2WORD\_1\_3(x, y)

BYTE2WORD\_2\_2(x, y)

BYTE2WORD\_3\_1(x, y)

BYTE2WORD\_1\_1\_2(x, y, z)

BYTE2WORD\_1\_2\_1(x, y, z)

BYTE2WORD\_2\_1\_1(x, y, z)

BYTE2WORD\_1\_1\_1\_1(x, y, z, w)

## 2.18 GPIO: General-Purpose Input/Output Driver

FSL\_GPIO\_DRIVER\_VERSION

GPIO driver version.

enum \_gpio\_pin\_direction

GPIO direction definition.

*Values:*

enumerator kGPIO\_\_DigitalInput  
Set current pin as digital input

enumerator kGPIO\_\_DigitalOutput  
Set current pin as digital output

enum \_\_gpio\_checker\_attribute  
GPIO checker attribute.

*Values:*

enumerator kGPIO\_\_UsernonsecureRWUsersecureRWPrivilegedsecureRW  
User nonsecure:Read+Write; User Secure:Read+Write; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureRUsersecureRWPrivilegedsecureRW  
User nonsecure:Read; User Secure:Read+Write; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureNUsersecureRWPrivilegedsecureRW  
User nonsecure:None; User Secure:Read+Write; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureRUsersecureRPrivilegedsecureRW  
User nonsecure:Read; User Secure:Read; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureNUsersecureRPrivilegedsecureRW  
User nonsecure:None; User Secure:Read; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureNUsersecureNPrivilegedsecureRW  
User nonsecure:None; User Secure:None; Privileged Secure:Read+Write

enumerator kGPIO\_\_UsernonsecureNUsersecureNPrivilegedsecureR  
User nonsecure:None; User Secure:None; Privileged Secure:Read

enumerator kGPIO\_\_UsernonsecureNUsersecureNPrivilegedsecureN  
User nonsecure:None; User Secure:None; Privileged Secure:None

enumerator kGPIO\_\_IgnoreAttributeCheck  
Ignores the attribute check

typedef enum \_\_gpio\_pin\_direction gpio\_pin\_direction\_t  
GPIO direction definition.

typedef enum \_\_gpio\_checker\_attribute gpio\_checker\_attribute\_t  
GPIO checker attribute.

typedef struct \_\_gpio\_pin\_config gpio\_pin\_config\_t  
The GPIO pin configuration structure.

Each pin can only be configured as either an output pin or an input pin at a time. If configured as an input pin, leave the outputConfig unused. Note that in some use cases, the corresponding port property should be configured in advance with the PORT\_SetPinConfig().

GPIO\_\_FIT\_REG(value)

struct \_\_gpio\_pin\_config  
*#include <fsl\_gpio.h>* The GPIO pin configuration structure.

Each pin can only be configured as either an output pin or an input pin at a time. If configured as an input pin, leave the outputConfig unused. Note that in some use cases, the corresponding port property should be configured in advance with the PORT\_SetPinConfig().

## Public Members

*gpio\_pin\_direction\_t* pinDirection

GPIO direction, input or output

uint8\_t outputLogic

Set a default output logic, which has no use in input

## 2.19 GPIO Driver

void GPIO\_PortInit(GPIO\_Type \*base)

Initializes the GPIO peripheral.

This function ungates the GPIO clock.

### Parameters

- base – GPIO peripheral base pointer.

void GPIO\_PortDeinit(GPIO\_Type \*base)

Deinitializes the GPIO peripheral.

### Parameters

- base – GPIO peripheral base pointer.

void GPIO\_PinInit(GPIO\_Type \*base, uint32\_t pin, const *gpio\_pin\_config\_t* \*config)

Initializes a GPIO pin used by the board.

To initialize the GPIO, define a pin configuration, as either input or output, in the user file. Then, call the GPIO\_PinInit() function.

This is an example to define an input pin or an output pin configuration.

```

Define a digital input pin configuration,
gpio_pin_config_t config =
{
    kGPIO_DigitalInput,
    0,
}
Define a digital output pin configuration,
gpio_pin_config_t config =
{
    kGPIO_DigitalOutput,
    0,
}

```

### Parameters

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- pin – GPIO port pin number
- config – GPIO pin configuration pointer

static inline void GPIO\_PinWrite(GPIO\_Type \*base, uint32\_t pin, uint8\_t output)

Sets the output level of the multiple GPIO pins to the logic 1 or 0.

### Parameters

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- pin – GPIO pin number
- output – GPIO pin output logic level.

- 0: corresponding pin output low-logic level.
- 1: corresponding pin output high-logic level.

static inline void GPIO\_PortSet(GPIO\_Type \*base, uint32\_t mask)

Sets the output level of the multiple GPIO pins to the logic 1.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- mask – GPIO pin number macro

static inline void GPIO\_PortClear(GPIO\_Type \*base, uint32\_t mask)

Sets the output level of the multiple GPIO pins to the logic 0.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- mask – GPIO pin number macro

static inline void GPIO\_PortToggle(GPIO\_Type \*base, uint32\_t mask)

Reverses the current output logic of the multiple GPIO pins.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- mask – GPIO pin number macro

static inline uint32\_t GPIO\_PinRead(GPIO\_Type \*base, uint32\_t pin)

Reads the current input value of the GPIO port.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- pin – GPIO pin number

**Return values**

GPIO – port input value

- 0: corresponding pin input low-logic level.
- 1: corresponding pin input high-logic level.

uint32\_t GPIO\_PortGetInterruptFlags(GPIO\_Type \*base)

Reads the GPIO port interrupt status flag.

If a pin is configured to generate the DMA request, the corresponding flag is cleared automatically at the completion of the requested DMA transfer. Otherwise, the flag remains set until a logic one is written to that flag. If configured for a level sensitive interrupt that remains asserted, the flag is set again immediately.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)

**Return values**

The – current GPIO port interrupt status flag, for example, 0x00010001 means the pin 0 and 17 have the interrupt.

void GPIO\_PortClearInterruptFlags(GPIO\_Type \*base, uint32\_t mask)

Clears multiple GPIO pin interrupt status flags.

**Parameters**

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- mask – GPIO pin number macro

void GPIO\_CheckAttributeBytes(GPIO\_Type \*base, *gpio\_checker\_attribute\_t* attribute)

brief The GPIO module supports a device-specific number of data ports, organized as 32-bit words/8-bit Bytes. Each 32-bit/8-bit data port includes a GACR register, which defines the byte-level attributes required for a successful access to the GPIO programming model. If the GPIO module's GACR register organized as 32-bit words, the attribute controls for the 4 data bytes in the GACR follow a standard little endian data convention.

#### Parameters

- base – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- attribute – GPIO checker attribute

## 2.20 I2C: Inter-Integrated Circuit Driver

### 2.21 I2C DMA Driver

void I2C\_MasterTransferCreateHandleDMA(I2C\_Type \*base, *i2c\_master\_dma\_handle\_t* \*handle, *i2c\_master\_transfer\_callback\_t* callback, void \*userData, *dma\_handle\_t* \*dmaHandle)

Initializes the I2C handle which is used in transactional functions.

#### Parameters

- base – I2C peripheral base address
- handle – Pointer to the *i2c\_master\_dma\_handle\_t* structure
- callback – Pointer to the user callback function
- userData – A user parameter passed to the callback function
- dmaHandle – DMA handle pointer

*status\_t* I2C\_MasterTransferDMA(I2C\_Type \*base, *i2c\_master\_dma\_handle\_t* \*handle, *i2c\_master\_transfer\_t* \*xfer)

Performs a master DMA non-blocking transfer on the I2C bus.

#### Parameters

- base – I2C peripheral base address
- handle – A pointer to the *i2c\_master\_dma\_handle\_t* structure
- xfer – A pointer to the transfer structure of the *i2c\_master\_transfer\_t*

#### Return values

- kStatus\_Success – Successfully completes the data transmission.
- kStatus\_I2C\_Busy – A previous transmission is still not finished.
- kStatus\_I2C\_Timeout – A transfer error, waits for the signal timeout.
- kStatus\_I2C\_ArbitrationLost – A transfer error, arbitration lost.
- kStatus\_I2C\_Nak – A transfer error, receives NAK during transfer.

*status\_t* I2C\_MasterTransferGetCountDMA(I2C\_Type \*base, *i2c\_master\_dma\_handle\_t* \*handle, *size\_t* \*count)

Gets a master transfer status during a DMA non-blocking transfer.

#### Parameters

- base – I2C peripheral base address

- `handle` – A pointer to the `i2c_master_dma_handle_t` structure
- `count` – A number of bytes transferred so far by the non-blocking transaction.

`void I2C_MasterTransferAbortDMA(I2C_Type *base, i2c_master_dma_handle_t *handle)`  
Aborts a master DMA non-blocking transfer early.

#### Parameters

- `base` – I2C peripheral base address
- `handle` – A pointer to the `i2c_master_dma_handle_t` structure.

`FSL_I2C_DMA_DRIVER_VERSION`  
I2C DMA driver version.

`typedef struct _i2c_master_dma_handle i2c_master_dma_handle_t`  
Retry times for waiting flag.  
I2C master DMA handle typedef.

`typedef void (*i2c_master_dma_transfer_callback_t)(I2C_Type *base, i2c_master_dma_handle_t *handle, status_t status, void *userData)`  
I2C master DMA transfer callback typedef.

`struct _i2c_master_dma_handle`  
`#include <fsl_i2c_dma.h>` I2C master DMA transfer structure.

#### Public Members

`i2c_master_transfer_t` transfer  
I2C master transfer struct.

`size_t` transferSize  
Total bytes to be transferred.

`uint8_t` state  
I2C master transfer status.

`dma_handle_t *dmaHandle`  
The DMA handler used.

`i2c_master_dma_transfer_callback_t` completionCallback  
A callback function called after the DMA transfer finished.

`void *userData`  
A callback parameter passed to the callback function.

## 2.22 I2C Driver

`void I2C_MasterInit(I2C_Type *base, const i2c_master_config_t *masterConfig, uint32_t srcClock_Hz)`

Initializes the I2C peripheral. Call this API to ungate the I2C clock and configure the I2C with master configuration.

---

**Note:** This API should be called at the beginning of the application. Otherwise, any operation to the I2C module can cause a hard fault because the clock is not enabled. The configuration structure can be custom filled or it can be set with default values by using

the `I2C_MasterGetDefaultConfig()`. After calling this API, the master is ready to transfer. This is an example.

```
i2c_master_config_t config = {  
    .enableMaster = true,  
    .enableStopHold = false,  
    .highDrive = false,  
    .baudRate_Bps = 100000,  
    .glitchFilterWidth = 0  
};  
I2C_MasterInit(I2C0, &config, 12000000U);
```

---

### Parameters

- `base` – I2C base pointer
- `masterConfig` – A pointer to the master configuration structure
- `srcClock_Hz` – I2C peripheral clock frequency in Hz

`void I2C_SlaveInit(I2C_Type *base, const i2c_slave_config_t *slaveConfig, uint32_t srcClock_Hz)`  
Initializes the I2C peripheral. Call this API to ungate the I2C clock and initialize the I2C with the slave configuration.

---

**Note:** This API should be called at the beginning of the application. Otherwise, any operation to the I2C module can cause a hard fault because the clock is not enabled. The configuration structure can partly be set with default values by `I2C_SlaveGetDefaultConfig()` or it can be custom filled by the user. This is an example.

```
i2c_slave_config_t config = {  
    .enableSlave = true,  
    .enableGeneralCall = false,  
    .addressingMode = kI2C_Address7bit,  
    .slaveAddress = 0x1DU,  
    .enableWakeUp = false,  
    .enablehighDrive = false,  
    .enableBaudRateCtl = false,  
    .sclStopHoldTime_ns = 4000  
};  
I2C_SlaveInit(I2C0, &config, 12000000U);
```

---

### Parameters

- `base` – I2C base pointer
- `slaveConfig` – A pointer to the slave configuration structure
- `srcClock_Hz` – I2C peripheral clock frequency in Hz

`void I2C_MasterDeinit(I2C_Type *base)`  
De-initializes the I2C master peripheral. Call this API to gate the I2C clock. The I2C master module can't work unless the `I2C_MasterInit` is called.

### Parameters

- `base` – I2C base pointer

`void I2C_SlaveDeinit(I2C_Type *base)`  
De-initializes the I2C slave peripheral. Calling this API gates the I2C clock. The I2C slave module can't work unless the `I2C_SlaveInit` is called to enable the clock.

### Parameters

- base – I2C base pointer

uint32\_t I2C\_GetInstance(I2C\_Type \*base)

Get instance number for I2C module.

#### Parameters

- base – I2C peripheral base address.

void I2C\_MasterGetDefaultConfig(*i2c\_master\_config\_t* \*masterConfig)

Sets the I2C master configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in the I2C\_MasterConfigure(). Use the initialized structure unchanged in the I2C\_MasterConfigure() or modify the structure before calling the I2C\_MasterConfigure(). This is an example.

```
i2c_master_config_t config;  
I2C_MasterGetDefaultConfig(&config);
```

#### Parameters

- masterConfig – A pointer to the master configuration structure.

void I2C\_SlaveGetDefaultConfig(*i2c\_slave\_config\_t* \*slaveConfig)

Sets the I2C slave configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in the I2C\_SlaveConfigure(). Modify fields of the structure before calling the I2C\_SlaveConfigure(). This is an example.

```
i2c_slave_config_t config;  
I2C_SlaveGetDefaultConfig(&config);
```

#### Parameters

- slaveConfig – A pointer to the slave configuration structure.

static inline void I2C\_Enable(I2C\_Type \*base, bool enable)

Enables or disables the I2C peripheral operation.

#### Parameters

- base – I2C base pointer
- enable – Pass true to enable and false to disable the module.

uint32\_t I2C\_MasterGetStatusFlags(I2C\_Type \*base)

Gets the I2C status flags.

#### Parameters

- base – I2C base pointer

#### Returns

status flag, use status flag to AND `_i2c_flags` to get the related status.

static inline uint32\_t I2C\_SlaveGetStatusFlags(I2C\_Type \*base)

Gets the I2C status flags.

#### Parameters

- base – I2C base pointer

#### Returns

status flag, use status flag to AND `_i2c_flags` to get the related status.

`static inline void I2C_MasterClearStatusFlags(I2C_Type *base, uint32_t statusMask)`

Clears the I2C status flag state.

The following status register flags can be cleared `kI2C_ArbitrationLostFlag` and `kI2C_IntPendingFlag`.

#### Parameters

- `base` – I2C base pointer
- `statusMask` – The status flag mask, defined in type `i2c_status_flag_t`. The parameter can be any combination of the following values:
  - `kI2C_StartDetectFlag` (if available)
  - `kI2C_StopDetectFlag` (if available)
  - `kI2C_ArbitrationLostFlag`
  - `kI2C_IntPendingFlagFlag`

`static inline void I2C_SlaveClearStatusFlags(I2C_Type *base, uint32_t statusMask)`

Clears the I2C status flag state.

The following status register flags can be cleared `kI2C_ArbitrationLostFlag` and `kI2C_IntPendingFlag`

#### Parameters

- `base` – I2C base pointer
- `statusMask` – The status flag mask, defined in type `i2c_status_flag_t`. The parameter can be any combination of the following values:
  - `kI2C_StartDetectFlag` (if available)
  - `kI2C_StopDetectFlag` (if available)
  - `kI2C_ArbitrationLostFlag`
  - `kI2C_IntPendingFlagFlag`

`void I2C_EnableInterrupts(I2C_Type *base, uint32_t mask)`

Enables I2C interrupt requests.

#### Parameters

- `base` – I2C base pointer
- `mask` – interrupt source The parameter can be combination of the following source if defined:
  - `kI2C_GlobalInterruptEnable`
  - `kI2C_StopDetectInterruptEnable/kI2C_StartDetectInterruptEnable`
  - `kI2C_SdaTimeoutInterruptEnable`

`void I2C_DisableInterrupts(I2C_Type *base, uint32_t mask)`

Disables I2C interrupt requests.

#### Parameters

- `base` – I2C base pointer
- `mask` – interrupt source The parameter can be combination of the following source if defined:
  - `kI2C_GlobalInterruptEnable`
  - `kI2C_StopDetectInterruptEnable/kI2C_StartDetectInterruptEnable`
  - `kI2C_SdaTimeoutInterruptEnable`

static inline void I2C\_\_EnableDMA(I2C\_Type \*base, bool enable)

Enables/disables the I2C DMA interrupt.

**Parameters**

- base – I2C base pointer
- enable – true to enable, false to disable

static inline uint32\_t I2C\_\_GetDataRegAddr(I2C\_Type \*base)

Gets the I2C tx/rx data register address. This API is used to provide a transfer address for I2C DMA transfer configuration.

**Parameters**

- base – I2C base pointer

**Returns**

data register address

void I2C\_\_MasterSetBaudRate(I2C\_Type \*base, uint32\_t baudRate\_Bps, uint32\_t srcClock\_Hz)

Sets the I2C master transfer baud rate.

**Parameters**

- base – I2C base pointer
- baudRate\_Bps – the baud rate value in bps
- srcClock\_Hz – Source clock

status\_t I2C\_\_MasterStart(I2C\_Type \*base, uint8\_t address, i2c\_direction\_t direction)

Sends a START on the I2C bus.

This function is used to initiate a new master mode transfer by sending the START signal. The slave address is sent following the I2C START signal.

**Parameters**

- base – I2C peripheral base pointer
- address – 7-bit slave device address.
- direction – Master transfer directions(transmit/receive).

**Return values**

- kStatus\_\_Success – Successfully send the start signal.
- kStatus\_I2C\_Busy – Current bus is busy.

status\_t I2C\_\_MasterStop(I2C\_Type \*base)

Sends a STOP signal on the I2C bus.

**Return values**

- kStatus\_\_Success – Successfully send the stop signal.
- kStatus\_I2C\_Timeout – Send stop signal failed, timeout.

status\_t I2C\_\_MasterRepeatedStart(I2C\_Type \*base, uint8\_t address, i2c\_direction\_t direction)

Sends a REPEATED START on the I2C bus.

**Parameters**

- base – I2C peripheral base pointer
- address – 7-bit slave device address.
- direction – Master transfer directions(transmit/receive).

**Return values**

- `kStatus_Success` – Successfully send the start signal.
- `kStatus_I2C_Busy` – Current bus is busy but not occupied by current I2C master.

*status\_t* I2C\_MasterWriteBlocking(I2C\_Type \*base, const uint8\_t \*txBuff, size\_t txSize, uint32\_t flags)

Performs a polling send transaction on the I2C bus.

#### Parameters

- `base` – The I2C peripheral base pointer.
- `txBuff` – The pointer to the data to be transferred.
- `txSize` – The length in bytes of the data to be transferred.
- `flags` – Transfer control flag to decide whether need to send a stop, use `kI2C_TransferDefaultFlag` to issue a stop and `kI2C_TransferNoStop` to not send a stop.

#### Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.

*status\_t* I2C\_MasterReadBlocking(I2C\_Type \*base, uint8\_t \*rxBuff, size\_t rxSize, uint32\_t flags)

Performs a polling receive transaction on the I2C bus.

---

**Note:** The `I2C_MasterReadBlocking` function stops the bus before reading the final byte. Without stopping the bus prior for the final read, the bus issues another read, resulting in garbage data being read into the data register.

---

#### Parameters

- `base` – I2C peripheral base pointer.
- `rxBuff` – The pointer to the data to store the received data.
- `rxSize` – The length in bytes of the data to be received.
- `flags` – Transfer control flag to decide whether need to send a stop, use `kI2C_TransferDefaultFlag` to issue a stop and `kI2C_TransferNoStop` to not send a stop.

#### Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_Timeout` – Send stop signal failed, timeout.

*status\_t* I2C\_SlaveWriteBlocking(I2C\_Type \*base, const uint8\_t \*txBuff, size\_t txSize)

Performs a polling send transaction on the I2C bus.

#### Parameters

- `base` – The I2C peripheral base pointer.
- `txBuff` – The pointer to the data to be transferred.
- `txSize` – The length in bytes of the data to be transferred.

#### Return values

- `kStatus_Success` – Successfully complete the data transmission.

- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.

`status_t I2C_SlaveReadBlocking(I2C_Type *base, uint8_t *rxBuff, size_t rxSize)`

Performs a polling receive transaction on the I2C bus.

#### Parameters

- `base` – I2C peripheral base pointer.
- `rxBuff` – The pointer to the data to store the received data.
- `rxSize` – The length in bytes of the data to be received.

#### Return values

- `kStatus_Success` – Successfully complete data receive.
- `kStatus_I2C_Timeout` – Wait status flag timeout.

`status_t I2C_MasterTransferBlocking(I2C_Type *base, i2c_master_transfer_t *xfer)`

Performs a master polling transfer on the I2C bus.

---

**Note:** The API does not return until the transfer succeeds or fails due to arbitration lost or receiving a NAK.

---

#### Parameters

- `base` – I2C peripheral base address.
- `xfer` – Pointer to the transfer structure.

#### Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_Busy` – Previous transmission still not finished.
- `kStatus_I2C_Timeout` – Transfer error, wait signal timeout.
- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.

`void I2C_MasterTransferCreateHandle(I2C_Type *base, i2c_master_handle_t *handle, i2c_master_transfer_callback_t callback, void *userData)`

Initializes the I2C handle which is used in transactional functions.

#### Parameters

- `base` – I2C base pointer.
- `handle` – pointer to `i2c_master_handle_t` structure to store the transfer state.
- `callback` – pointer to user callback function.
- `userData` – user parameter passed to the callback function.

`status_t I2C_MasterTransferNonBlocking(I2C_Type *base, i2c_master_handle_t *handle, i2c_master_transfer_t *xfer)`

Performs a master interrupt non-blocking transfer on the I2C bus.

---

**Note:** Calling the API returns immediately after transfer initiates. The user needs to call `I2C_MasterGetTransferCount` to poll the transfer status to check whether the transfer is finished. If the return status is not `kStatus_I2C_Busy`, the transfer is finished.

---

**Parameters**

- base – I2C base pointer.
- handle – pointer to `i2c_master_handle_t` structure which stores the transfer state.
- xfer – pointer to `i2c_master_transfer_t` structure.

**Return values**

- `kStatus_Success` – Successfully start the data transmission.
- `kStatus_I2C_Busy` – Previous transmission still not finished.
- `kStatus_I2C_Timeout` – Transfer error, wait signal timeout.

`status_t I2C_MasterTransferGetCount(I2C_Type *base, i2c_master_handle_t *handle, size_t *count)`

Gets the master transfer status during a interrupt non-blocking transfer.

**Parameters**

- base – I2C base pointer.
- handle – pointer to `i2c_master_handle_t` structure which stores the transfer state.
- count – Number of bytes transferred so far by the non-blocking transaction.

**Return values**

- `kStatus_InvalidArgument` – count is Invalid.
- `kStatus_Success` – Successfully return the count.

`status_t I2C_MasterTransferAbort(I2C_Type *base, i2c_master_handle_t *handle)`

Aborts an interrupt non-blocking transfer early.

---

**Note:** This API can be called at any time when an interrupt non-blocking transfer initiates to abort the transfer early.

---

**Parameters**

- base – I2C base pointer.
- handle – pointer to `i2c_master_handle_t` structure which stores the transfer state

**Return values**

- `kStatus_I2C_Timeout` – Timeout during polling flag.
- `kStatus_Success` – Successfully abort the transfer.

`void I2C_MasterTransferHandleIRQ(I2C_Type *base, void *i2cHandle)`

Master interrupt handler.

**Parameters**

- base – I2C base pointer.
- i2cHandle – pointer to `i2c_master_handle_t` structure.

`void I2C_SlaveTransferCreateHandle(I2C_Type *base, i2c_slave_handle_t *handle, i2c_slave_transfer_callback_t callback, void *userData)`

Initializes the I2C handle which is used in transactional functions.

**Parameters**

- `base` – I2C base pointer.
- `handle` – pointer to `i2c_slave_handle_t` structure to store the transfer state.
- `callback` – pointer to user callback function.
- `userData` – user parameter passed to the callback function.

`status_t I2C_SlaveTransferNonBlocking(I2C_Type *base, i2c_slave_handle_t *handle, uint32_t eventMask)`

Starts accepting slave transfers.

Call this API after calling the `I2C_SlaveInit()` and `I2C_SlaveTransferCreateHandle()` to start processing transactions driven by an I2C master. The slave monitors the I2C bus and passes events to the callback that was passed into the call to `I2C_SlaveTransferCreateHandle()`. The callback is always invoked from the interrupt context.

The set of events received by the callback is customizable. To do so, set the `eventMask` parameter to the OR'd combination of `i2c_slave_transfer_event_t` enumerators for the events you wish to receive. The `kI2C_SlaveTransmitEvent` and `kLPI2C_SlaveReceiveEvent` events are always enabled and do not need to be included in the mask. Alternatively, pass 0 to get a default set of only the transmit and receive events that are always enabled. In addition, the `kI2C_SlaveAllEvents` constant is provided as a convenient way to enable all events.

#### Parameters

- `base` – The I2C peripheral base address.
- `handle` – Pointer to `i2c_slave_handle_t` structure which stores the transfer state.
- `eventMask` – Bit mask formed by OR'ing together `i2c_slave_transfer_event_t` enumerators to specify which events to send to the callback. Other accepted values are 0 to get a default set of only the transmit and receive events, and `kI2C_SlaveAllEvents` to enable all events.

#### Return values

- `kStatus_Success` – Slave transfers were successfully started.
- `kStatus_I2C_Busy` – Slave transfers have already been started on this handle.

`void I2C_SlaveTransferAbort(I2C_Type *base, i2c_slave_handle_t *handle)`

Aborts the slave transfer.

---

**Note:** This API can be called at any time to stop slave for handling the bus events.

---

#### Parameters

- `base` – I2C base pointer.
- `handle` – pointer to `i2c_slave_handle_t` structure which stores the transfer state.

`status_t I2C_SlaveTransferGetCount(I2C_Type *base, i2c_slave_handle_t *handle, size_t *count)`

Gets the slave transfer remaining bytes during a interrupt non-blocking transfer.

#### Parameters

- `base` – I2C base pointer.
- `handle` – pointer to `i2c_slave_handle_t` structure.
- `count` – Number of bytes transferred so far by the non-blocking transaction.

#### Return values

- kStatus\_InvalidArgument – count is Invalid.
- kStatus\_Success – Successfully return the count.

void I2C\_SlaveTransferHandleIRQ(I2C\_Type \*base, void \*i2cHandle)

Slave interrupt handler.

#### Parameters

- base – I2C base pointer.
- i2cHandle – pointer to i2c\_slave\_handle\_t structure which stores the transfer state

FSL\_I2C\_DRIVER\_VERSION

I2C driver version.

I2C status return codes.

*Values:*

enumerator kStatus\_I2C\_Busy

I2C is busy with current transfer.

enumerator kStatus\_I2C\_Idle

Bus is Idle.

enumerator kStatus\_I2C\_Nak

NAK received during transfer.

enumerator kStatus\_I2C\_ArbitrationLost

Arbitration lost during transfer.

enumerator kStatus\_I2C\_Timeout

Timeout polling status flags.

enumerator kStatus\_I2C\_Addr\_Nak

NAK received during the address probe.

enum \_i2c\_flags

I2C peripheral flags.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask.

---

*Values:*

enumerator kI2C\_ReceiveNakFlag

I2C receive NAK flag.

enumerator kI2C\_IntPendingFlag

I2C interrupt pending flag. This flag can be cleared.

enumerator kI2C\_TransferDirectionFlag

I2C transfer direction flag.

enumerator kI2C\_RangeAddressMatchFlag

I2C range address match flag.

enumerator kI2C\_ArbitrationLostFlag

I2C arbitration lost flag. This flag can be cleared.

enumerator kI2C\_BusBusyFlag

I2C bus busy flag.

enumerator kI2C\_AddressMatchFlag

I2C address match flag.

enumerator kI2C\_TransferCompleteFlag

I2C transfer complete flag.

enumerator kI2C\_StopDetectFlag

I2C stop detect flag. This flag can be cleared.

enumerator kI2C\_StartDetectFlag

I2C start detect flag. This flag can be cleared.

enum \_i2c\_interrupt\_enable

I2C feature interrupt source.

*Values:*

enumerator kI2C\_GlobalInterruptEnable

I2C global interrupt.

enumerator kI2C\_StopDetectInterruptEnable

I2C stop detect interrupt.

enumerator kI2C\_StartStopDetectInterruptEnable

I2C start&stop detect interrupt.

enum \_i2c\_direction

The direction of master and slave transfers.

*Values:*

enumerator kI2C\_Write

Master transmits to the slave.

enumerator kI2C\_Read

Master receives from the slave.

enum \_i2c\_slave\_address\_mode

Addressing mode.

*Values:*

enumerator kI2C\_Address7bit

7-bit addressing mode.

enumerator kI2C\_RangeMatch

Range address match addressing mode.

enum \_i2c\_master\_transfer\_flags

I2C transfer control flag.

*Values:*

enumerator kI2C\_TransferDefaultFlag

A transfer starts with a start signal, stops with a stop signal.

enumerator kI2C\_TransferNoStartFlag

A transfer starts without a start signal, only support write only or write+read with no start flag, do not support read only with no start flag.

enumerator kI2C\_TransferRepeatedStartFlag

A transfer starts with a repeated start signal.

enumerator kI2C\_TransferNoStopFlag

A transfer ends without a stop signal.

enum \_i2c\_slave\_transfer\_event

Set of events sent to the callback for nonblocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to I2C\_SlaveTransferNonBlocking() to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its *transfer* parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

*Values:*

enumerator kI2C\_SlaveAddressMatchEvent

Received the slave address after a start or repeated start.

enumerator kI2C\_SlaveTransmitEvent

A callback is requested to provide data to transmit (slave-transmitter role).

enumerator kI2C\_SlaveReceiveEvent

A callback is requested to provide a buffer in which to place received data (slave-receiver role).

enumerator kI2C\_SlaveTransmitAckEvent

A callback needs to either transmit an ACK or NACK.

enumerator kI2C\_SlaveStartEvent

A start/repeated start was detected.

enumerator kI2C\_SlaveCompletionEvent

A stop was detected or finished transfer, completing the transfer.

enumerator kI2C\_SlaveGeneralCallEvent

Received the general call address after a start or repeated start.

enumerator kI2C\_SlaveAllEvents

A bit mask of all available events.

Common sets of flags used by the driver.

*Values:*

enumerator kClearFlags

All flags which are cleared by the driver upon starting a transfer.

enumerator kIrqFlags

typedef enum \_i2c\_direction i2c\_direction\_t

The direction of master and slave transfers.

typedef enum \_i2c\_slave\_address\_mode i2c\_slave\_address\_mode\_t

Addressing mode.

```
typedef enum _i2c_slave_transfer_event i2c_slave_transfer_event_t
```

Set of events sent to the callback for nonblocking slave transfers.

These event enumerations are used for two related purposes. First, a bit mask created by OR'ing together events is passed to I2C\_SlaveTransferNonBlocking() to specify which events to enable. Then, when the slave callback is invoked, it is passed the current event through its *transfer* parameter.

---

**Note:** These enumerations are meant to be OR'd together to form a bit mask of events.

---

```
typedef struct _i2c_master_config i2c_master_config_t
```

I2C master user configuration.

```
typedef struct _i2c_slave_config i2c_slave_config_t
```

I2C slave user configuration.

```
typedef struct _i2c_master_handle i2c_master_handle_t
```

I2C master handle typedef.

```
typedef void (*i2c_master_transfer_callback_t)(I2C_Type *base, i2c_master_handle_t *handle,
status_t status, void *userData)
```

I2C master transfer callback typedef.

```
typedef struct _i2c_slave_handle i2c_slave_handle_t
```

I2C slave handle typedef.

```
typedef struct _i2c_master_transfer i2c_master_transfer_t
```

I2C master transfer structure.

```
typedef struct _i2c_slave_transfer i2c_slave_transfer_t
```

I2C slave transfer structure.

```
typedef void (*i2c_slave_transfer_callback_t)(I2C_Type *base, i2c_slave_transfer_t *xfer, void
*userData)
```

I2C slave transfer callback typedef.

I2C\_RETRY\_TIMES

Retry times for waiting flag.

I2C\_MASTER\_FACK\_CONTROL

Master Fast ack control, control if master needs to manually write ack, this is used to low the speed of transfer for SoCs with feature FSL\_FEATURE\_I2C\_HAS\_DOUBLE\_BUFFERING.

I2C\_HAS\_STOP\_DETECT

```
struct _i2c_master_config
```

```
#include <fsl_i2c.h> I2C master user configuration.
```

## Public Members

bool enableMaster

Enables the I2C peripheral at initialization time.

bool enableStopHold

Controls the stop hold enable.

bool enableDoubleBuffering

Controls double buffer enable; notice that enabling the double buffer disables the clock stretch.

uint32\_t baudRate\_Bps

Baud rate configuration of I2C peripheral.

uint8\_t glitchFilterWidth

Controls the width of the glitch.

struct \_\_i2c\_slave\_config

*#include <fsl\_i2c.h>* I2C slave user configuration.

### Public Members

bool enableSlave

Enables the I2C peripheral at initialization time.

bool enableGeneralCall

Enables the general call addressing mode.

bool enableWakeUp

Enables/disables waking up MCU from low-power mode.

bool enableDoubleBuffering

Controls a double buffer enable; notice that enabling the double buffer disables the clock stretch.

bool enableBaudRateCtl

Enables/disables independent slave baud rate on SCL in very fast I2C modes.

uint16\_t slaveAddress

A slave address configuration.

uint16\_t upperAddress

A maximum boundary slave address used in a range matching mode.

*i2c\_slave\_address\_mode\_t* addressingMode

An addressing mode configuration of *i2c\_slave\_address\_mode\_config\_t*.

uint32\_t sclStopHoldTime\_ns

the delay from the rising edge of SCL (I2C clock) to the rising edge of SDA (I2C data) while SCL is high (stop condition), SDA hold time and SCL start hold time are also configured according to the SCL stop hold time.

struct \_\_i2c\_master\_transfer

*#include <fsl\_i2c.h>* I2C master transfer structure.

### Public Members

uint32\_t flags

A transfer flag which controls the transfer.

uint8\_t slaveAddress

7-bit slave address.

*i2c\_direction\_t* direction

A transfer direction, read or write.

uint32\_t subaddress

A sub address. Transferred MSB first.

uint8\_t subaddressSize

A size of the command buffer.

uint8\_t \*volatile data  
A transfer buffer.

volatile size\_t dataSize  
A transfer size.

struct \_\_i2c\_master\_handle  
*#include <fsl\_i2c.h>* I2C master handle structure.

### Public Members

*i2c\_master\_transfer\_t* transfer  
I2C master transfer copy.

size\_t transferSize  
Total bytes to be transferred.

uint8\_t state  
A transfer state maintained during transfer.

*i2c\_master\_transfer\_callback\_t* completionCallback  
A callback function called when the transfer is finished.

void \*userData  
A callback parameter passed to the callback function.

struct \_\_i2c\_slave\_transfer  
*#include <fsl\_i2c.h>* I2C slave transfer structure.

### Public Members

*i2c\_slave\_transfer\_event\_t* event  
A reason that the callback is invoked.

uint8\_t \*volatile data  
A transfer buffer.

volatile size\_t dataSize  
A transfer size.

*status\_t* completionStatus  
Success or error code describing how the transfer completed. Only applies for kI2C\_SlaveCompletionEvent.

size\_t transferredCount  
A number of bytes actually transferred since the start or since the last repeated start.

struct \_\_i2c\_slave\_handle  
*#include <fsl\_i2c.h>* I2C slave handle structure.

### Public Members

volatile bool isBusy  
Indicates whether a transfer is busy.

*i2c\_slave\_transfer\_t* transfer  
I2C slave transfer copy.

uint32\_t eventMask

A mask of enabled events.

i2c\_slave\_transfer\_callback\_t callback

A callback function called at the transfer event.

void \*userData

A callback parameter passed to the callback.

## 2.23 IRTC: IRTC Driver

status\_t IRTC\_Init(RTC\_Type \*base, const irtc\_config\_t \*config)

Ungates the IRTC clock and configures the peripheral for basic operation.

This function initiates a soft-reset of the IRTC module, this has not effect on DST, calendaring, standby time and tamper detect registers.

---

**Note:** This API should be called at the beginning of the application using the IRTC driver.

---

### Parameters

- base – IRTC peripheral base address
- config – Pointer to user's IRTC config structure.

### Returns

kStatus\_Success If the driver is initialized successfully.

### Returns

kStatus\_Fail if we cannot disable register write protection

### Returns

kStatus\_InvalidArgument If the input parameters are wrong.

status\_t IRTC\_Deinit(RTC\_Type \*base)

Gate the IRTC clock.

### Parameters

- base – IRTC peripheral base address

### Returns

kStatus\_Success If the driver is initialized successfully.

### Returns

kStatus\_InvalidArgument If the input parameters are wrong.

void IRTC\_GetDefaultConfig(irtc\_config\_t \*config)

Fill in the IRTC config struct with the default settings.

The default values are:

```
config->wakeupSelect = true;
config->timerStdMask = false;
config->alrmMatch = kRTC__MatchSecMinHr;
```

### Parameters

- config – Pointer to user's IRTC config structure.

*status\_t* IRTC\_SetDatetime(RTC\_Type \*base, const *irtc\_datetime\_t* \*datetime)

Sets the IRTC date and time according to the given time structure.

The IRTC counter is started after the time is set.

#### Parameters

- base – IRTC peripheral base address
- datetime – Pointer to structure where the date and time details to set are stored

#### Returns

kStatus\_Success: success in setting the time and starting the IRTC  
kStatus\_InvalidArgument: failure. An error occurs because the datetime format is incorrect.

void IRTC\_GetDatetime(RTC\_Type \*base, *irtc\_datetime\_t* \*datetime)

Gets the IRTC time and stores it in the given time structure.

#### Parameters

- base – IRTC peripheral base address
- datetime – Pointer to structure where the date and time details are stored.

*status\_t* IRTC\_SetAlarm(RTC\_Type \*base, const *irtc\_datetime\_t* \*alarmTime)

Sets the IRTC alarm time.

---

**Note:** weekDay field of alarmTime is not used during alarm match and should be set to 0

---

#### Parameters

- base – RTC peripheral base address
- alarmTime – Pointer to structure where the alarm time is stored.

#### Returns

kStatus\_Success: success in setting the alarm  
kStatus\_InvalidArgument: error in setting the alarm. Error occurs because the alarm datetime format is incorrect.

void IRTC\_GetAlarm(RTC\_Type \*base, *irtc\_datetime\_t* \*datetime)

Returns the IRTC alarm time.

#### Parameters

- base – RTC peripheral base address
- datetime – Pointer to structure where the alarm date and time details are stored.

static inline void IRTC\_EnableInterrupts(RTC\_Type \*base, uint32\_t mask)

Enables the selected IRTC interrupts.

#### Parameters

- base – IRTC peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration *irtc\_interrupt\_enable\_t*

static inline void IRTC\_DisableInterrupts(RTC\_Type \*base, uint32\_t mask)

Disables the selected IRTC interrupts.

#### Parameters

- `base` – IRTC peripheral base address
- `mask` – The interrupts to enable. This is a logical OR of members of the enumeration `irtc_interrupt_enable_t`

static inline uint32\_t IRTC\_GetEnabledInterrupts(RTC\_Type \*base)

Gets the enabled IRTC interrupts.

#### Parameters

- `base` – IRTC peripheral base address

#### Returns

The enabled interrupts. This is the logical OR of members of the enumeration `irtc_interrupt_enable_t`

static inline uint32\_t IRTC\_GetStatusFlags(RTC\_Type \*base)

Gets the IRTC status flags.

#### Parameters

- `base` – IRTC peripheral base address

#### Returns

The status flags. This is the logical OR of members of the enumeration `irtc_status_flags_t`

static inline void IRTC\_ClearStatusFlags(RTC\_Type \*base, uint32\_t mask)

Clears the IRTC status flags.

#### Parameters

- `base` – IRTC peripheral base address
- `mask` – The status flags to clear. This is a logical OR of members of the enumeration `irtc_status_flags_t`

void IRTC\_SetDaylightTime(RTC\_Type \*base, const *irtc\_daylight\_time\_t* \*datetime)

Sets the IRTC daylight savings start and stop date and time.

It also enables the daylight saving bit in the IRTC control register

#### Parameters

- `base` – IRTC peripheral base address
- `datetime` – Pointer to a structure where the date and time details are stored.

void IRTC\_GetDaylightTime(RTC\_Type \*base, *irtc\_daylight\_time\_t* \*datetime)

Gets the IRTC daylight savings time and stores it in the given time structure.

#### Parameters

- `base` – IRTC peripheral base address
- `datetime` – Pointer to a structure where the date and time details are stored.

void IRTC\_SetCoarseCompensation(RTC\_Type \*base, uint8\_t compensationValue, uint8\_t compensationInterval)

Enables the coarse compensation and sets the value in the IRTC compensation register.

#### Parameters

- `base` – IRTC peripheral base address
- `compensationValue` – Compensation value is a 2's complement value.
- `compensationInterval` – Compensation interval.

```
void IRTC_SetFineCompensation(RTC_Type *base, uint8_t integralValue, uint8_t fractionValue,
                             bool accumulateFractional)
```

Enables the fine compensation and sets the value in the IRTC compensation register.

#### Parameters

- `base` – The IRTC peripheral base address
- `integralValue` – Compensation integral value; twos complement value of the integer part
- `fractionValue` – Compensation fraction value expressed as number of clock cycles of a fixed 4.194304Mhz clock that have to be added.
- `accumulateFractional` – Flag indicating if we want to add to previous fractional part; true: Add to previously accumulated fractional part, false: Start afresh and overwrite current value

```
void IRTC_SetTamperParams(RTC_Type *base, irtc_tamper_pins_t tamperNumber, const
                          irtc_tamper_config_t *tamperConfig)
```

This function allows configuring the four tamper inputs.

The function configures the filter properties for the three external tampers. It also sets up active/passive and direction of the tamper bits, which are not available on all platforms.

---

**Note:** This function programs the tamper filter parameters. The user must gate the 32K clock to the RTC before calling this function. It is assumed that the time and date are set after this and the tamper parameters do not require to be changed again later.

---

#### Parameters

- `base` – The IRTC peripheral base address
- `tamperNumber` – The IRTC tamper input to configure
- `tamperConfig` – The IRTC tamper properties

```
uint8_t IRTC_ReadTamperQueue(RTC_Type *base, irtc_datetime_t *tamperTimestamp)
```

This function reads the tamper timestamp and returns the associated tamper pin.

The tamper timestamp has month, day, hour, minutes, and seconds. Ignore the year field as this information is not available in the tamper queue. The user should look at the RTC\_YEARMON register for this because the expectation is that the queue is read at least once a year. Return the tamper pin number associated with the timestamp.

#### Parameters

- `base` – The IRTC peripheral base address
- `tamperTimestamp` – The tamper timestamp

#### Returns

The tamper pin number

```
static inline bool IRTC_GetTamperQueueFullStatus(RTC_Type *base)
```

Gets the IRTC Tamper queue full status.

#### Parameters

- `base` – IRTC peripheral base address

#### Return values

- `true` – Tamper queue is full.
- `false` – Tamper queue is not full.

static inline void IRTC\_ClearTamperQueueFullStatus(RTC\_Type \*base)

Clear the IRTC Tamper queue full status.

**Parameters**

- base – IRTC peripheral base address

FSL\_IRTC\_DRIVER\_VERSION

enum \_irtc\_filter\_clock\_source

IRTC filter clock source options.

*Values:*

enumerator kIRTC\_32K

Use 32 kHz clock source for the tamper filter.

enumerator kIRTC\_512

Use 512 Hz clock source for the tamper filter.

enumerator kIRTC\_128

Use 128 Hz clock source for the tamper filter.

enumerator kIRTC\_64

Use 64 Hz clock source for the tamper filter.

enumerator kIRTC\_16

Use 16 Hz clock source for the tamper filter.

enumerator kIRTC\_8

Use 8 Hz clock source for the tamper filter.

enumerator kIRTC\_4

Use 4 Hz clock source for the tamper filter.

enumerator kIRTC\_2

Use 2 Hz clock source for the tamper filter.

enum \_irtc\_tamper\_pins

IRTC Tamper pins.

*Values:*

enumerator kIRTC\_Tamper\_0

External Tamper 0

enumerator kIRTC\_Tamper\_1

External Tamper 1

enumerator kIRTC\_Tamper\_2

External Tamper 2

enumerator kIRTC\_Tamper\_3

Internal tamper, does not have filter configuration

enum \_irtc\_interrupt\_enable

List of IRTC interrupts.

*Values:*

enumerator kIRTC\_TamperInterruptEnable

Tamper Interrupt Enable

enumerator kIRTC\_AlarmInterruptEnable

Alarm Interrupt Enable

enumerator kIRTC\_DayInterruptEnable  
Days Interrupt Enable

enumerator kIRTC\_HourInterruptEnable  
Hours Interrupt Enable

enumerator kIRTC\_MinInterruptEnable  
Minutes Interrupt Enable

enumerator kIRTC\_1hzInterruptEnable  
1 Hz interval Interrupt Enable

enumerator kIRTC\_2hzInterruptEnable  
2 Hz interval Interrupt Enable

enumerator kIRTC\_4hzInterruptEnable  
4 Hz interval Interrupt Enable

enumerator kIRTC\_8hzInterruptEnable  
8 Hz interval Interrupt Enable

enumerator kIRTC\_16hzInterruptEnable  
16 Hz interval Interrupt Enable

enumerator kIRTC\_32hzInterruptEnable  
32 Hz interval Interrupt Enable

enumerator kIRTC\_64hzInterruptEnable  
64 Hz interval Interrupt Enable

enumerator kIRTC\_128hzInterruptEnable  
128 Hz interval Interrupt Enable

enumerator kIRTC\_256hzInterruptEnable  
256 Hz interval Interrupt Enable

enumerator kIRTC\_512hzInterruptEnable  
512 Hz interval Interrupt Enable

enumerator kIRTC\_TamperQueueFullInterruptEnable  
Tamper queue full Interrupt Enable

enum \_irtc\_status\_flags

List of IRTC flags.

*Values:*

enumerator kIRTC\_TamperFlag  
Tamper Status flag

enumerator kIRTC\_AlarmFlag  
Alarm Status flag

enumerator kIRTC\_DayFlag  
Days Status flag

enumerator kIRTC\_HourFlag  
Hour Status flag

enumerator kIRTC\_MinFlag  
Minutes Status flag

enumerator kIRTC\_1hzFlag  
1 Hz interval status flag

enumerator kIRTC\_2hzFlag  
2 Hz interval status flag

enumerator kIRTC\_4hzFlag  
4 Hz interval status flag

enumerator kIRTC\_8hzFlag  
8 Hz interval status flag

enumerator kIRTC\_16hzFlag  
16 Hz interval status flag

enumerator kIRTC\_32hzFlag  
32 Hz interval status flag

enumerator kIRTC\_64hzFlag  
64 Hz interval status flag

enumerator kIRTC\_128hzFlag  
128 Hz interval status flag

enumerator kIRTC\_256hzFlag  
256 Hz interval status flag

enumerator kIRTC\_512hzFlag  
512 Hz interval status flag

enumerator kIRTC\_InvalidFlag  
Indicates if time/date counters are invalid

enumerator kIRTC\_WriteProtFlag  
Write protect enable status flag

enumerator kIRTC\_CpuLowVoltFlag  
CPU low voltage warning flag

enumerator kIRTC\_ResetSrcFlag  
Reset source flag

enumerator kIRTC\_CmpIntFlag  
Compensation interval status flag

enumerator kIRTC\_CmpDoneFlag  
Compensation done flag

enumerator kIRTC\_BusErrFlag  
Bus error flag

enum \_irtc\_alarm\_match  
IRTC alarm match options.

*Values:*

enumerator kRTC\_MatchSecMinHr  
Only match second, minute and hour

enumerator kRTC\_MatchSecMinHrDay  
Only match second, minute, hour and day

enumerator kRTC\_MatchSecMinHrDayMnth

Only match second, minute, hour, day and month

enumerator kRTC\_MatchSecMinHrDayMnthYr

Only match second, minute, hour, day, month and year

enum \_irtc\_osc\_cap\_load

List of RTC Oscillator capacitor load settings.

*Values:*

enumerator kRTC\_Capacitor2p

2pF capacitor load

enumerator kRTC\_Capacitor4p

4pF capacitor load

enumerator kRTC\_Capacitor8p

8pF capacitor load

enumerator kRTC\_Capacitor16p

16pF capacitor load

enum \_irtc\_clockout\_sel

IRTC clockout select.

*Values:*

enumerator kRTC\_ClkoutNo

No clock out

enumerator kRTC\_ClkoutFine1Hz

clock out fine 1Hz

enumerator kRTC\_Clkout32kHz

clock out 32.768kHz

enumerator kRTC\_ClkoutCoarse1Hz

clock out coarse 1Hz

typedef enum \_irtc\_filter\_clock\_source irtc\_filter\_clock\_source\_t

IRTC filter clock source options.

typedef enum \_irtc\_tamper\_pins irtc\_tamper\_pins\_t

IRTC Tamper pins.

typedef enum \_irtc\_interrupt\_enable irtc\_interrupt\_enable\_t

List of IRTC interrupts.

typedef enum \_irtc\_status\_flags irtc\_status\_flags\_t

List of IRTC flags.

typedef enum \_irtc\_alarm\_match irtc\_alarm\_match\_t

IRTC alarm match options.

typedef enum \_irtc\_osc\_cap\_load irtc\_osc\_cap\_load\_t

List of RTC Oscillator capacitor load settings.

typedef enum \_irtc\_clockout\_sel irtc\_clockout\_sel\_t

IRTC clockout select.

typedef struct \_irtc\_datetime irtc\_datetime\_t

Structure is used to hold the date and time.

```
typedef struct _irtc_daylight_time irtc_daylight_time_t
```

Structure is used to hold the daylight saving time.

```
typedef struct _irtc_tamper_config irtc_tamper_config_t
```

Structure is used to define the parameters to configure a RTC tamper event.

```
typedef struct _irtc_config irtc_config_t
```

RTC config structure.

This structure holds the configuration settings for the RTC peripheral. To initialize this structure to reasonable defaults, call the `IRTC_GetDefaultConfig()` function and pass a pointer to your config structure instance.

The config struct can be made const so it resides in flash

```
static inline void IRTC_SetOscCapLoad(RTC_Type *base, uint16_t capLoad)
```

This function sets the specified capacitor configuration for the RTC oscillator.

#### Parameters

- base – IRTC peripheral base address
- capLoad – Oscillator loads to enable. This is a logical OR of members of the enumeration `irtc_osc_cap_load_t`

```
status_t IRTC_SetWriteProtection(RTC_Type *base, bool lock)
```

Locks or unlocks IRTC registers for write access.

---

**Note:** When the registers are unlocked, they remain in unlocked state for 2 seconds, after which they are locked automatically. After power-on-reset, the registers come out unlocked and they are locked automatically 15 seconds after power on.

---

#### Parameters

- base – IRTC peripheral base address
- lock – true: Lock IRTC registers; false: Unlock IRTC registers.

#### Returns

`kStatus_Success`: if lock or unlock operation is successful  
`kStatus_Fail`: if lock or unlock operation fails even after multiple retry attempts

```
static inline void IRTC_Reset(RTC_Type *base)
```

Performs a software reset on the IRTC module.

Clears contents of alarm, interrupt (status and enable except tamper interrupt enable bit) registers, `STATUS[COMP_DONE]` and `STATUS[BUS_ERR]`. This has no effect on DST, calendar-ing, standby time and tamper detect registers.

#### Parameters

- base – IRTC peripheral base address

```
static inline void IRTC_Enable32kClkDuringRegisterWrite(RTC_Type *base, bool enable)
```

Enable/disable 32 kHz RTC OSC clock during RTC register write.

#### Parameters

- base – IRTC peripheral base address
- enable – Enable/disable 32 kHz RTC OSC clock.
  - true: Enables the oscillator.
  - false: Disables the oscillator.

`void IRTC_ConfigClockOut(RTC_Type *base, irtc_clockout_sel_t clkOut)`

Select which clock to output from RTC.

Select which clock to output from RTC for other modules to use inside SoC, for example, RTC subsystem needs RTC to output 1HZ clock for sub-second counter.

#### Parameters

- base – IRTC peripheral base address
- clkOut – select clock to use for output,

`static inline uint8_t IRTC_GetTamperStatusFlag(RTC_Type *base)`

Gets the IRTC Tamper status flags.

#### Parameters

- base – IRTC peripheral base address

#### Returns

The Tamper status value.

`static inline void IRTC_ClearTamperStatusFlag(RTC_Type *base)`

Gets the IRTC Tamper status flags.

#### Parameters

- base – IRTC peripheral base address

`static inline void IRTC_SetTamperConfigurationOver(RTC_Type *base)`

Set tamper configuration over.

Note that this API is needed after call IRTC\_SetTamperParams to configure tamper events to notify IRTC module that tamper configuration process is over.

#### Parameters

- base – IRTC peripheral base address

`IRTC_STATUS_W1C_BITS`

`struct _irtc_datetime`

*#include <fsl\_irtc.h>* Structure is used to hold the date and time.

#### Public Members

`uint16_t year`

Range from 1984 to 2239.

`uint8_t month`

Range from 1 to 12.

`uint8_t day`

Range from 1 to 31 (depending on month).

`uint8_t weekDay`

Range from 0(Sunday) to 6(Saturday).

`uint8_t hour`

Range from 0 to 23.

`uint8_t minute`

Range from 0 to 59.

uint8\_t second

Range from 0 to 59.

struct \_\_irtc\_daylight\_time

*#include <fsl\_irtc.h>* Structure is used to hold the daylight saving time.

### Public Members

uint8\_t startMonth

Range from 1 to 12

uint8\_t endMonth

Range from 1 to 12

uint8\_t startDay

Range from 1 to 31 (depending on month)

uint8\_t endDay

Range from 1 to 31 (depending on month)

uint8\_t startHour

Range from 0 to 23

uint8\_t endHour

Range from 0 to 23

struct \_\_irtc\_tamper\_config

*#include <fsl\_irtc.h>* Structure is used to define the parameters to configure a RTC tamper event.

### Public Members

bool activePassive

true: configure tamper as active; false: passive tamper

bool direction

true: configure tamper direction as output; false: configure as input; this is only used if a tamper pin is defined as active

bool pinPolarity

true: tamper has active low polarity; false: active high polarity

irtc\_filter\_clock\_source\_t filterClk

Clock source for the tamper filter

uint8\_t filterDuration

Tamper filter duration.

struct \_\_irtc\_config

*#include <fsl\_irtc.h>* RTC config structure.

This structure holds the configuration settings for the RTC peripheral. To initialize this structure to reasonable defaults, call the IRTC\_GetDefaultConfig() function and pass a pointer to your config structure instance.

The config struct can be made const so it resides in flash

### Public Members

`bool` wakeupSelect  
true: Tamper pin 0 is used to wakeup the chip; false: Tamper pin 0 is used as the tamper pin

`bool` timerStdMask  
true: Sampling clocks gated in standby mode; false: Sampling clocks not gated

`irtc_alarm_match_t` alarmMatch  
Pick one option from enumeration :: `irtc_alarm_match_t`

## 2.24 Common Driver

`FSL_COMMON_DRIVER_VERSION`  
common driver version.

`DEBUG_CONSOLE_DEVICE_TYPE_NONE`  
No debug console.

`DEBUG_CONSOLE_DEVICE_TYPE_UART`  
Debug console based on UART.

`DEBUG_CONSOLE_DEVICE_TYPE_LPUART`  
Debug console based on LPUART.

`DEBUG_CONSOLE_DEVICE_TYPE_LPSCI`  
Debug console based on LPSCI.

`DEBUG_CONSOLE_DEVICE_TYPE_USBCDC`  
Debug console based on USB CDC.

`DEBUG_CONSOLE_DEVICE_TYPE_FLEXCOMM`  
Debug console based on FLEXCOMM.

`DEBUG_CONSOLE_DEVICE_TYPE_IUART`  
Debug console based on i.MX UART.

`DEBUG_CONSOLE_DEVICE_TYPE_VUSART`  
Debug console based on LPC\_VUSART.

`DEBUG_CONSOLE_DEVICE_TYPE_MINI_USART`  
Debug console based on LPC\_USART.

`DEBUG_CONSOLE_DEVICE_TYPE_SWO`  
Debug console based on SWO.

`DEBUG_CONSOLE_DEVICE_TYPE_QSCI`  
Debug console based on QSCI.

`MIN(a, b)`  
Computes the minimum of *a* and *b*.

`MAX(a, b)`  
Computes the maximum of *a* and *b*.

`UINT16_MAX`  
Max value of `uint16_t` type.

UINT32\_MAX

Max value of uint32\_t type.

MCUX\_MASK\_INVERT\_8(mask)

8-bit mask inversion.

MCUX\_MASK\_INVERT\_16(mask)

16-bit mask inversion.

MCUX\_MASK\_INVERT\_32(mask)

32-bit mask inversion for completeness.

MCUX\_REG\_WRITE8(reg, value)

8-bit register write macro

MCUX\_REG\_WRITE16(reg, value)

16-bit register write macro

MCUX\_REG\_WRITE32(reg, value)

32-bit register write macro

MCUX\_REG\_READ8(reg)

8-bit register read macro

MCUX\_REG\_READ16(reg)

16-bit register read macro

MCUX\_REG\_READ32(reg)

32-bit register read macro

MCUX\_REG\_BIT\_SET8(reg, mask)

8-bit register bit set macro

MCUX\_REG\_BIT\_SET16(reg, mask)

16-bit register bit set macro

MCUX\_REG\_BIT\_SET32(reg, mask)

32-bit register bit set macro

MCUX\_REG\_BIT\_CLEAR8(reg, mask)

8-bit register bit clear macro

MCUX\_REG\_BIT\_CLEAR16(reg, mask)

16-bit register bit clear macro

MCUX\_REG\_BIT\_CLEAR32(reg, mask)

32-bit register bit clear macro

MCUX\_REG\_BIT\_GET8(reg, mask)

8-bit register bit get macro

MCUX\_REG\_BIT\_GET16(reg, mask)

16-bit register bit get macro

MCUX\_REG\_BIT\_GET32(reg, mask)

32-bit register bit get macro

MCUX\_REG\_MODIFY8(reg, mask, value)

32-bit register read-modify-write macro

MCUX\_REG\_MODIFY16(reg, mask, value)

16-bit register read-modify-write macro

MCUX\_REG\_MODIFY32(reg, mask, value)

32-bit register read-modify-write macro

SDK\_ATOMIC\_LOCAL\_ADD(addr, val)

Add value *val* from the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_SUB(addr, val)

Subtract value *val* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_SET(addr, bits)

Set the bits specifiled by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_CLEAR(addr, bits)

Clear the bits specifiled by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_TOGGLE(addr, bits)

Toggle the bits specifiled by *bits* to the variable at address *address*.

SDK\_ATOMIC\_LOCAL\_CLEAR\_AND\_SET(addr, clearBits, setBits)

For the variable at address *address*, clear the bits specifiled by *clearBits* and set the bits specifiled by *setBits*.

SDK\_ATOMIC\_LOCAL\_COMPARE\_AND\_SET(addr, expected, newValue)

For the variable at address *address*, check whether the value equal to *expected*. If value same as *expected* then update *newValue* to address and return **true** , else return **false** .

SDK\_ATOMIC\_LOCAL\_TEST\_AND\_SET(addr, newValue)

For the variable at address *address*, set as *newValue* value and return old value.

USEC\_TO\_COUNT(us, clockFreqInHz)

Macro to convert a microsecond period to raw count value

COUNT\_TO\_USEC(count, clockFreqInHz)

Macro to convert a raw count value to microsecond

MSEC\_TO\_COUNT(ms, clockFreqInHz)

Macro to convert a millisecond period to raw count value

COUNT\_TO\_MSEC(count, clockFreqInHz)

Macro to convert a raw count value to millisecond

SDK\_ISR\_EXIT\_BARRIER

SDK\_ALIGN(var, alignbytes)

Macro to define a variable with alignbytes alignment

SDK\_SIZEALIGN(var, alignbytes)

Macro to define a variable with L1 d-cache line size alignment

Macro to define a variable with L2 cache line size alignment

Macro to change a value to a given size aligned value (rounded up)

SDK\_SIZEALIGN\_UP(var, alignbytes)

Macro to change a value to a given size aligned value (rounded up), the wrapper of SDK\_SIZEALIGN

SDK\_SIZEALIGN\_DOWN(var, alignbytes)

Macro to change a value to a given size aligned value (rounded down)

SDK\_IS\_ALIGNED(var, alignbytes)

Macro to check if a value is aligned to a given size

AT\_NONCACHEABLE\_SECTION(*var*)

Define a variable *var*, and place it in non-cacheable section.

AT\_NONCACHEABLE\_SECTION\_ALIGN(*var*, *alignbytes*)

Define a variable *var*, and place it in non-cacheable section, the start address of the variable is aligned to *alignbytes*.

AT\_NONCACHEABLE\_SECTION\_INIT(*var*)

Define a variable *var* with initial value, and place it in non-cacheable section.

AT\_NONCACHEABLE\_SECTION\_ALIGN\_INIT(*var*, *alignbytes*)

Define a variable *var* with initial value, and place it in non-cacheable section, the start address of the variable is aligned to *alignbytes*.

AT\_CACHE\_LINE\_SECTION(*var*)

Define a variable *var*, which is cache line size aligned and be placed in CacheLineData section.

AT\_CACHE\_LINE\_SECTION\_INIT(*var*)

Define a variable *var* with initial value, which is cache line size aligned and be placed in CacheLineData.init section.

AT\_QUICKACCESS\_SECTION\_CODE(*func*)

Place function in a section which can be accessed quickly by core.

AT\_QUICKACCESS\_SECTION\_DATA(*var*)

Place data in a section which can be accessed quickly by core.

AT\_QUICKACCESS\_SECTION\_DATA\_ALIGN(*var*, *alignbytes*)

Place data in a section which can be accessed quickly by core, and the variable address is set to align with *alignbytes*.

MCUX\_RAMFUNC

Function attribute to place function in RAM. For example, to place function *my\_func* in ram, use like:

```
MCUX_RAMFUNC my_func
```

RAMFUNCTION\_SECTION\_CODE(*func*)

Place function in ram.

enum \_\_status\_groups

Status group numbers.

*Values:*

enumerator kStatusGroup\_Generic

Group number for generic status codes.

enumerator kStatusGroup\_FLASH

Group number for FLASH status codes.

enumerator kStatusGroup\_LPSPI

Group number for LPSPI status codes.

enumerator kStatusGroup\_FLEXIO\_SPI

Group number for FLEXIO SPI status codes.

enumerator kStatusGroup\_DSPI

Group number for DSPI status codes.

enumerator kStatusGroup\_FLEXIO\_UART  
Group number for FLEXIO UART status codes.

enumerator kStatusGroup\_FLEXIO\_I2C  
Group number for FLEXIO I2C status codes.

enumerator kStatusGroup\_LPI2C  
Group number for LPI2C status codes.

enumerator kStatusGroup\_UART  
Group number for UART status codes.

enumerator kStatusGroup\_I2C  
Group number for UART status codes.

enumerator kStatusGroup\_LPSCI  
Group number for LPSCI status codes.

enumerator kStatusGroup\_LPUART  
Group number for LPUART status codes.

enumerator kStatusGroup\_SPI  
Group number for SPI status code.

enumerator kStatusGroup\_XRDC  
Group number for XRDC status code.

enumerator kStatusGroup\_SEMA42  
Group number for SEMA42 status code.

enumerator kStatusGroup\_SDHC  
Group number for SDHC status code

enumerator kStatusGroup\_SDMMC  
Group number for SDMMC status code

enumerator kStatusGroup\_SAI  
Group number for SAI status code

enumerator kStatusGroup\_MCG  
Group number for MCG status codes.

enumerator kStatusGroup\_SCG  
Group number for SCG status codes.

enumerator kStatusGroup\_SDSPI  
Group number for SDSPI status codes.

enumerator kStatusGroup\_FLEXIO\_I2S  
Group number for FLEXIO I2S status codes

enumerator kStatusGroup\_FLEXIO\_MCULCD  
Group number for FLEXIO LCD status codes

enumerator kStatusGroup\_FLASHIAP  
Group number for FLASHIAP status codes

enumerator kStatusGroup\_FLEXCOMM\_I2C  
Group number for FLEXCOMM I2C status codes

enumerator kStatusGroup\_I2S  
Group number for I2S status codes

enumerator kStatusGroup\_IUART  
Group number for IUART status codes

enumerator kStatusGroup\_CSI  
Group number for CSI status codes

enumerator kStatusGroup\_MIPIDSI  
Group number for MIPI DSI status codes

enumerator kStatusGroup\_SDRAMC  
Group number for SDRAMC status codes.

enumerator kStatusGroup\_POWER  
Group number for POWER status codes.

enumerator kStatusGroup\_ENET  
Group number for ENET status codes.

enumerator kStatusGroup\_PHY  
Group number for PHY status codes.

enumerator kStatusGroup\_TRGMUX  
Group number for TRGMUX status codes.

enumerator kStatusGroup\_SMARTCARD  
Group number for SMARTCARD status codes.

enumerator kStatusGroup\_LMEM  
Group number for LMEM status codes.

enumerator kStatusGroup\_QSPI  
Group number for QSPI status codes.

enumerator kStatusGroup\_DMA  
Group number for DMA status codes.

enumerator kStatusGroup\_EDMA  
Group number for EDMA status codes.

enumerator kStatusGroup\_DMAMGR  
Group number for DMAMGR status codes.

enumerator kStatusGroup\_FLEXCAN  
Group number for FlexCAN status codes.

enumerator kStatusGroup\_LTC  
Group number for LTC status codes.

enumerator kStatusGroup\_FLEXIO\_CAMERA  
Group number for FLEXIO CAMERA status codes.

enumerator kStatusGroup\_LPC\_SPI  
Group number for LPC\_SPI status codes.

enumerator kStatusGroup\_LPC\_USART  
Group number for LPC\_USART status codes.

enumerator kStatusGroup\_DMIC  
Group number for DMIC status codes.

enumerator kStatusGroup\_SDIF  
Group number for SDIF status codes.

enumerator kStatusGroup\_SPIFI  
Group number for SPIFI status codes.

enumerator kStatusGroup\_OTP  
Group number for OTP status codes.

enumerator kStatusGroup\_MCAN  
Group number for MCAN status codes.

enumerator kStatusGroup\_CAAM  
Group number for CAAM status codes.

enumerator kStatusGroup\_ECSPi  
Group number for ECSPi status codes.

enumerator kStatusGroup\_USDHC  
Group number for USDHC status codes.

enumerator kStatusGroup\_LPC\_I2C  
Group number for LPC\_I2C status codes.

enumerator kStatusGroup\_DCP  
Group number for DCP status codes.

enumerator kStatusGroup\_MSCAN  
Group number for MSCAN status codes.

enumerator kStatusGroup\_ESAI  
Group number for ESAI status codes.

enumerator kStatusGroup\_FLEXSPI  
Group number for FLEXSPI status codes.

enumerator kStatusGroup\_MMDC  
Group number for MMDC status codes.

enumerator kStatusGroup\_PDM  
Group number for MIC status codes.

enumerator kStatusGroup\_SDMA  
Group number for SDMA status codes.

enumerator kStatusGroup\_ICS  
Group number for ICS status codes.

enumerator kStatusGroup\_SPDIF  
Group number for SPDIF status codes.

enumerator kStatusGroup\_LPC\_MINISPI  
Group number for LPC\_MINISPI status codes.

enumerator kStatusGroup\_HASHCRYPT  
Group number for Hashcrypt status codes

enumerator kStatusGroup\_LPC\_SPI\_SSP  
Group number for LPC\_SPI\_SSP status codes.

enumerator kStatusGroup\_I3C  
Group number for I3C status codes

enumerator kStatusGroup\_LPC\_I2C\_1  
Group number for LPC\_I2C\_1 status codes.

enumerator kStatusGroup\_NOTIFIER  
Group number for NOTIFIER status codes.

enumerator kStatusGroup\_DebugConsole  
Group number for debug console status codes.

enumerator kStatusGroup\_SEMC  
Group number for SEMC status codes.

enumerator kStatusGroup\_ApplicationRangeStart  
Starting number for application groups.

enumerator kStatusGroup\_IAP  
Group number for IAP status codes

enumerator kStatusGroup\_SFA  
Group number for SFA status codes

enumerator kStatusGroup\_SPC  
Group number for SPC status codes.

enumerator kStatusGroup\_PUF  
Group number for PUF status codes.

enumerator kStatusGroup\_TOUCH\_PANEL  
Group number for touch panel status codes

enumerator kStatusGroup\_VBAT  
Group number for VBAT status codes

enumerator kStatusGroup\_XSPI  
Group number for XSPI status codes

enumerator kStatusGroup\_PNGDEC  
Group number for PNGDEC status codes

enumerator kStatusGroup\_JPEGDEC  
Group number for JPEGDEC status codes

enumerator kStatusGroup\_AUDMIX  
Group number for AUDMIX status codes

enumerator kStatusGroup\_HAL\_GPIO  
Group number for HAL GPIO status codes.

enumerator kStatusGroup\_HAL\_UART  
Group number for HAL UART status codes.

enumerator kStatusGroup\_HAL\_TIMER  
Group number for HAL TIMER status codes.

enumerator kStatusGroup\_HAL\_SPI  
Group number for HAL SPI status codes.

enumerator kStatusGroup\_HAL\_I2C  
Group number for HAL I2C status codes.

enumerator kStatusGroup\_HAL\_FLASH  
Group number for HAL FLASH status codes.

enumerator kStatusGroup\_HAL\_PWM  
Group number for HAL PWM status codes.

enumerator `kStatusGroup_HAL_RNG`  
Group number for HAL RNG status codes.

enumerator `kStatusGroup_HAL_I2S`  
Group number for HAL I2S status codes.

enumerator `kStatusGroup_HAL_ADC_SENSOR`  
Group number for HAL ADC SENSOR status codes.

enumerator `kStatusGroup_TIMERMANAGER`  
Group number for TiMER MANAGER status codes.

enumerator `kStatusGroup_SERIALMANAGER`  
Group number for SERIAL MANAGER status codes.

enumerator `kStatusGroup_LED`  
Group number for LED status codes.

enumerator `kStatusGroup_BUTTON`  
Group number for BUTTON status codes.

enumerator `kStatusGroup_EXTERN_EEPROM`  
Group number for EXTERN EEPROM status codes.

enumerator `kStatusGroup_SHELL`  
Group number for SHELL status codes.

enumerator `kStatusGroup_MEM_MANAGER`  
Group number for MEM MANAGER status codes.

enumerator `kStatusGroup_LIST`  
Group number for List status codes.

enumerator `kStatusGroup_OSA`  
Group number for OSA status codes.

enumerator `kStatusGroup_COMMON_TASK`  
Group number for Common task status codes.

enumerator `kStatusGroup_MSG`  
Group number for messaging status codes.

enumerator `kStatusGroup_SDK_OCOTP`  
Group number for OCOTP status codes.

enumerator `kStatusGroup_SDK_FLEXSPINOR`  
Group number for FLEXSPINOR status codes.

enumerator `kStatusGroup_CODEC`  
Group number for codec status codes.

enumerator `kStatusGroup_ASRC`  
Group number for codec status ASRC.

enumerator `kStatusGroup_OTFAD`  
Group number for codec status codes.

enumerator `kStatusGroup_SDIOSLV`  
Group number for SDIOSLV status codes.

enumerator `kStatusGroup_MECC`  
Group number for MECC status codes.

enumerator kStatusGroup\_ENET\_QOS  
Group number for ENET\_QOS status codes.

enumerator kStatusGroup\_LOG  
Group number for LOG status codes.

enumerator kStatusGroup\_I3CBUS  
Group number for I3CBUS status codes.

enumerator kStatusGroup\_QSCI  
Group number for QSCI status codes.

enumerator kStatusGroup\_ELEMU  
Group number for ELEMU status codes.

enumerator kStatusGroup\_QUEUEDSPI  
Group number for QSPI status codes.

enumerator kStatusGroup\_POWER\_MANAGER  
Group number for POWER\_MANAGER status codes.

enumerator kStatusGroup\_IPED  
Group number for IPED status codes.

enumerator kStatusGroup\_ELS\_PKC  
Group number for ELS PKC status codes.

enumerator kStatusGroup\_CSS\_PKC  
Group number for CSS PKC status codes.

enumerator kStatusGroup\_HOSTIF  
Group number for HOSTIF status codes.

enumerator kStatusGroup\_CLIF  
Group number for CLIF status codes.

enumerator kStatusGroup\_BMA  
Group number for BMA status codes.

enumerator kStatusGroup\_NETC  
Group number for NETC status codes.

enumerator kStatusGroup\_ELE  
Group number for ELE status codes.

enumerator kStatusGroup\_GLIKEY  
Group number for GLIKEY status codes.

enumerator kStatusGroup\_AON\_POWER  
Group number for AON\_POWER status codes.

enumerator kStatusGroup\_AON\_COMMON  
Group number for AON\_COMMON status codes.

enumerator kStatusGroup\_ENDAT3  
Group number for ENDAT3 status codes.

enumerator kStatusGroup\_HIPERFACE  
Group number for HIPERFACE status codes.

enumerator kStatusGroup\_NPX  
Group number for NPX status codes.

enumerator kStatusGroup\_ELA\_CSEC

Group number for ELA\_CSEC status codes.

enumerator kStatusGroup\_FLEXIO\_T\_FORMAT

Group number for T-format status codes.

enumerator kStatusGroup\_FLEXIO\_A\_FORMAT

Group number for A-format status codes.

enumerator kStatusGroup\_LPC\_QSPI

Group number for LPC QSPI status codes.

Generic status return codes.

*Values:*

enumerator kStatus\_Success

Generic status for Success.

enumerator kStatus\_Fail

Generic status for Fail.

enumerator kStatus\_ReadOnly

Generic status for read only failure.

enumerator kStatus\_OutOfRange

Generic status for out of range access.

enumerator kStatus\_InvalidArgument

Generic status for invalid argument check.

enumerator kStatus\_Timeout

Generic status for timeout.

enumerator kStatus\_NoTransferInProgress

Generic status for no transfer in progress.

enumerator kStatus\_Busy

Generic status for module is busy.

enumerator kStatus\_NoData

Generic status for no data is found for the operation.

typedef int32\_t status\_t

Type used for all status and error return values.

void \*SDK\_Malloc(size\_t size, size\_t alignbytes)

Allocate memory with given alignment and aligned size.

This is provided to support the dynamically allocated memory used in cache-able region.

#### **Parameters**

- size – The length required to malloc.
- alignbytes – The alignment size.

#### **Return values**

The – allocated memory.

void SDK\_Free(void \*ptr)

Free memory.

#### **Parameters**

- ptr – The memory to be release.

void SDK\_DelayAtLeastUs(uint32\_t delayTime\_us, uint32\_t coreClock\_Hz)

Delay at least for some time. Please note that, this API uses while loop for delay, different run-time environments make the time not precise, if precise delay count was needed, please implement a new delay function with hardware timer.

#### Parameters

- delayTime\_us – Delay time in unit of microsecond.
- coreClock\_Hz – Core clock frequency with Hz.

static inline status\_t EnableIRQ(IRQn\_Type interrupt)

Enable specific interrupt.

Enable LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only enables the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

#### Parameters

- interrupt – The IRQ number.

#### Return values

- kStatus\_Success – Interrupt enabled successfully
- kStatus\_Fail – Failed to enable the interrupt

static inline status\_t DisableIRQ(IRQn\_Type interrupt)

Disable specific interrupt.

Disable LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only disables the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

#### Parameters

- interrupt – The IRQ number.

#### Return values

- kStatus\_Success – Interrupt disabled successfully
- kStatus\_Fail – Failed to disable the interrupt

static inline status\_t EnableIRQWithPriority(IRQn\_Type interrupt, uint8\_t priNum)

Enable the IRQ, and also set the interrupt priority.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

#### Parameters

- interrupt – The IRQ to Enable.

- priNum – Priority number set to interrupt controller register.

**Return values**

- kStatus\_Success – Interrupt priority set successfully
- kStatus\_Fail – Failed to set the interrupt priority.

static inline *status\_t* IRQ\_SetPriority(IRQn\_Type interrupt, uint8\_t priNum)

Set the IRQ priority.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

**Parameters**

- interrupt – The IRQ to set.
- priNum – Priority number set to interrupt controller register.

**Return values**

- kStatus\_Success – Interrupt priority set successfully
- kStatus\_Fail – Failed to set the interrupt priority.

static inline *status\_t* IRQ\_ClearPendingIRQ(IRQn\_Type interrupt)

Clear the pending IRQ flag.

Only handle LEVEL1 interrupt. For some devices, there might be multiple interrupt levels. For example, there are NVIC and intmux. Here the interrupts connected to NVIC are the LEVEL1 interrupts, because they are routed to the core directly. The interrupts connected to intmux are the LEVEL2 interrupts, they are routed to NVIC first then routed to core.

This function only handles the LEVEL1 interrupts. The number of LEVEL1 interrupts is indicated by the feature macro FSL\_FEATURE\_NUMBER\_OF\_LEVEL1\_INT\_VECTORS.

**Parameters**

- interrupt – The flag which IRQ to clear.

**Return values**

- kStatus\_Success – Interrupt priority set successfully
- kStatus\_Fail – Failed to set the interrupt priority.

static inline uint32\_t DisableGlobalIRQ(void)

Disable the global IRQ.

Disable the global interrupt and return the current primask register. User is required to provided the primask register for the EnableGlobalIRQ().

**Returns**

Current primask value.

static inline void EnableGlobalIRQ(uint32\_t primask)

Enable the global IRQ.

Set the primask register with the provided primask value but not just enable the primask. The idea is for the convenience of integration of RTOS. some RTOS get its own management mechanism of primask. User is required to use the EnableGlobalIRQ() and DisableGlobalIRQ() in pair.

**Parameters**

- `primask` – value of primask register to be restored. The primask value is supposed to be provided by the `DisableGlobalIRQ()`.

```
static inline bool __SDK_AtomicLocalCompareAndSet(uint32_t *addr, uint32_t expected, uint32_t
                                                    newValue)
```

```
static inline uint32_t __SDK_AtomicTestAndSet(uint32_t *addr, uint32_t newValue)
```

`FSL_DRIVER_TRANSFER_DOUBLE_WEAK_IRQ`

Macro to use the default weak IRQ handler in drivers.

`MAKE_STATUS(group, code)`

Construct a status code value from a group and code number.

`MAKE_VERSION(major, minor, bugfix)`

Construct the version number for drivers.

The driver version is a 32-bit number, for both 32-bit platforms(such as Cortex M) and 16-bit platforms(such as DSC).

|        |               |    |               |    |         |   |   |
|--------|---------------|----|---------------|----|---------|---|---|
| Unused | Major Version |    | Minor Version |    | Bug Fix |   |   |
| 31     | 25            | 24 | 17            | 16 | 9       | 8 | 0 |

`ARRAY_SIZE(x)`

Computes the number of elements in an array.

`UINT64_H(X)`

Macro to get upper 32 bits of a 64-bit value

`UINT64_L(X)`

Macro to get lower 32 bits of a 64-bit value

`SUPPRESS_FALL_THROUGH_WARNING()`

For switch case code block, if case section ends without “break;” statement, there will be fallthrough warning with compiler flag `-Wextra` or `-Wimplicit-fallthrough=n` when using `armgcc`. To suppress this warning, “`SUPPRESS_FALL_THROUGH_WARNING()`,” need to be added at the end of each case section which misses “break;”statement.

`MSDK_REG_SECURE_ADDR(x)`

Convert the register address to the one used in secure mode.

`MSDK_REG_NONSECURE_ADDR(x)`

Convert the register address to the one used in non-secure mode.

`MSDK_HAS_DWT_CYCCNT`

The chip supports DWT CYCCNT or not.

`MSDK_INVALID_IRQ_HANDLER`

Invalid IRQ handler address.

## 2.25 LLWU: Low-Leakage Wakeup Unit Driver

```
static inline void LLWU_GetVersionId(LLWU_Type *base, llwu_version_id_t *versionId)
```

Gets the LLWU version ID.

This function gets the LLWU version ID, including the major version number, the minor version number, and the feature specification number.

### Parameters

- `base` – LLWU peripheral base address.

- `versionId` – A pointer to the version ID structure.

`static inline void LLWU_GetParam(LLWU_Type *base, llwu_param_t *param)`

Gets the LLWU parameter.

This function gets the LLWU parameter, including a wakeup pin number, a module number, a DMA number, and a pin filter number.

#### Parameters

- `base` – LLWU peripheral base address.
- `param` – A pointer to the LLWU parameter structure.

`void LLWU_SetExternalWakeupPinMode(LLWU_Type *base, uint32_t pinIndex, llwu_external_pin_mode_t pinMode)`

Sets the external input pin source mode.

This function sets the external input pin source mode that is used as a wake up source.

#### Parameters

- `base` – LLWU peripheral base address.
- `pinIndex` – A pin index to be enabled as an external wakeup source starting from 1.
- `pinMode` – A pin configuration mode defined in the `llwu_external_pin_modes_t`.

`bool LLWU_GetExternalWakeupPinFlag(LLWU_Type *base, uint32_t pinIndex)`

Gets the external wakeup source flag.

This function checks the external pin flag to detect whether the MCU is woken up by the specific pin.

#### Parameters

- `base` – LLWU peripheral base address.
- `pinIndex` – A pin index, which starts from 1.

#### Returns

True if the specific pin is a wakeup source.

`void LLWU_ClearExternalWakeupPinFlag(LLWU_Type *base, uint32_t pinIndex)`

Clears the external wakeup source flag.

This function clears the external wakeup source flag for a specific pin.

#### Parameters

- `base` – LLWU peripheral base address.
- `pinIndex` – A pin index, which starts from 1.

`static inline void LLWU_EnableInternalModuleInterruptWakup(LLWU_Type *base, uint32_t moduleIndex, bool enable)`

Enables/disables the internal module source.

This function enables/disables the internal module source mode that is used as a wake up source.

#### Parameters

- `base` – LLWU peripheral base address.
- `moduleIndex` – A module index to be enabled as an internal wakeup source starting from 1.
- `enable` – An enable or a disable setting

```
static inline void LLWU_EnableInternalModuleDmaRequestWakeup(LLWU_Type *base, uint32_t  
                                                           moduleIndex, bool enable)
```

Enables/disables the internal module DMA wakeup source.

This function enables/disables the internal DMA that is used as a wake up source.

#### Parameters

- base – LLWU peripheral base address.
- moduleIndex – An internal module index which is used as a DMA request source, starting from 1.
- enable – Enable or disable the DMA request source

```
void LLWU_SetPinFilterMode(LLWU_Type *base, uint32_t filterIndex,  
                          llwu_external_pin_filter_mode_t filterMode)
```

Sets the pin filter configuration.

This function sets the pin filter configuration.

#### Parameters

- base – LLWU peripheral base address.
- filterIndex – A pin filter index used to enable/disable the digital filter, starting from 1.
- filterMode – A filter mode configuration

```
bool LLWU_GetPinFilterFlag(LLWU_Type *base, uint32_t filterIndex)
```

Gets the pin filter configuration.

This function gets the pin filter flag.

#### Parameters

- base – LLWU peripheral base address.
- filterIndex – A pin filter index, which starts from 1.

#### Returns

True if the flag is a source of the existing low-leakage power mode.

```
void LLWU_ClearPinFilterFlag(LLWU_Type *base, uint32_t filterIndex)
```

Clears the pin filter configuration.

This function clears the pin filter flag.

#### Parameters

- base – LLWU peripheral base address.
- filterIndex – A pin filter index to clear the flag, starting from 1.

```
void LLWU_SetResetPinMode(LLWU_Type *base, bool pinEnable, bool pinFilterEnable)
```

Sets the reset pin mode.

This function determines how the reset pin is used as a low leakage mode exit source.

#### Parameters

- base – LLWU peripheral base address.
- pinEnable – Enable reset the pin filter
- pinFilterEnable – Specify whether the pin filter is enabled in Low-Leakage power mode.

```
FSL_LLWU_DRIVER_VERSION
```

LLWU driver version.

enum `_llwu_external_pin_mode`

External input pin control modes.

*Values:*

enumerator `kLLWU_ExternalPinDisable`

Pin disabled as a wakeup input.

enumerator `kLLWU_ExternalPinRisingEdge`

Pin enabled with the rising edge detection.

enumerator `kLLWU_ExternalPinFallingEdge`

Pin enabled with the falling edge detection.

enumerator `kLLWU_ExternalPinAnyEdge`

Pin enabled with any change detection.

enum `_llwu_pin_filter_mode`

Digital filter control modes.

*Values:*

enumerator `kLLWU_PinFilterDisable`

Filter disabled.

enumerator `kLLWU_PinFilterRisingEdge`

Filter positive edge detection.

enumerator `kLLWU_PinFilterFallingEdge`

Filter negative edge detection.

enumerator `kLLWU_PinFilterAnyEdge`

Filter any edge detection.

typedef enum `_llwu_external_pin_mode` `llwu_external_pin_mode_t`

External input pin control modes.

typedef enum `_llwu_pin_filter_mode` `llwu_pin_filter_mode_t`

Digital filter control modes.

typedef struct `_llwu_version_id` `llwu_version_id_t`

IP version ID definition.

typedef struct `_llwu_param` `llwu_param_t`

IP parameter definition.

typedef struct `_llwu_external_pin_filter_mode` `llwu_external_pin_filter_mode_t`

An external input pin filter control structure.

`LLWU_REG_VAL(x)`

struct `_llwu_version_id`

*#include <fsl\_llwu.h>* IP version ID definition.

### Public Members

uint16\_t feature

A feature specification number.

uint8\_t minor

The minor version number.

uint8\_t major

The major version number.

struct \_llwu\_param

#include <fsl\_llwu.h> IP parameter definition.

### Public Members

uint8\_t filters

A number of the pin filter.

uint8\_t dmas

A number of the wakeup DMA.

uint8\_t modules

A number of the wakeup module.

uint8\_t pins

A number of the wake up pin.

struct \_llwu\_external\_pin\_filter\_mode

#include <fsl\_llwu.h> An external input pin filter control structure.

### Public Members

uint32\_t pinIndex

A pin number

llwu\_pin\_filter\_mode\_t filterMode

Filter mode

## 2.26 LPTMR: Low-Power Timer

void LPTMR\_Init(LPTMR\_Type \*base, const *lptmr\_config\_t* \*config)

Un gates the LPTMR clock and configures the peripheral for a basic operation.

---

**Note:** This API should be called at the beginning of the application using the LPTMR driver.

---

### Parameters

- base – LPTMR peripheral base address
- config – A pointer to the LPTMR configuration structure.

void LPTMR\_Deinit(LPTMR\_Type \*base)

Gates the LPTMR clock.

### Parameters

- base – LPTMR peripheral base address

void LPTMR\_GetDefaultConfig(*lptmr\_config\_t* \*config)

Fills in the LPTMR configuration structure with default settings.

The default values are as follows.

```
config->timerMode = kLPTMR_TimerModeTimeCounter;
config->pinSelect = kLPTMR_PinSelectInput_0;
config->pinPolarity = kLPTMR_PinPolarityActiveHigh;
config->enableFreeRunning = false;
config->bypassPrescaler = true;
config->prescalerClockSource = kLPTMR_PrescalerClock_1;
config->value = kLPTMR_Prescale_Glitch_0;
```

### Parameters

- config – A pointer to the LPTMR configuration structure.

static inline void LPTMR\_EnableInterrupts(LPTMR\_Type \*base, uint32\_t mask)

Enables the selected LPTMR interrupts.

### Parameters

- base – LPTMR peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration `lptmr_interrupt_enable_t`

static inline void LPTMR\_DisableInterrupts(LPTMR\_Type \*base, uint32\_t mask)

Disables the selected LPTMR interrupts.

### Parameters

- base – LPTMR peripheral base address
- mask – The interrupts to disable. This is a logical OR of members of the enumeration `lptmr_interrupt_enable_t`.

static inline uint32\_t LPTMR\_GetEnabledInterrupts(LPTMR\_Type \*base)

Gets the enabled LPTMR interrupts.

### Parameters

- base – LPTMR peripheral base address

### Returns

The enabled interrupts. This is the logical OR of members of the enumeration `lptmr_interrupt_enable_t`

static inline uint32\_t LPTMR\_GetStatusFlags(LPTMR\_Type \*base)

Gets the LPTMR status flags.

### Parameters

- base – LPTMR peripheral base address

### Returns

The status flags. This is the logical OR of members of the enumeration `lptmr_status_flags_t`

static inline void LPTMR\_ClearStatusFlags(LPTMR\_Type \*base, uint32\_t mask)

Clears the LPTMR status flags.

### Parameters

- base – LPTMR peripheral base address
- mask – The status flags to clear. This is a logical OR of members of the enumeration `lptmr_status_flags_t`.

```
static inline void LPTMR_SetTimerPeriod(LPTMR_Type *base, uint32_t ticks)
```

Sets the timer period in units of count.

Timers counts from 0 until it equals the count value set here. The count value is written to the CMR register.

---

**Note:**

- a. The TCF flag is set with the CNR equals the count provided here and then increments.
  - b. Call the utility macros provided in the fsl\_common.h to convert to ticks.
- 

**Parameters**

- base – LPTMR peripheral base address
- ticks – A timer period in units of ticks

```
static inline uint32_t LPTMR_GetCurrentTimerCount(LPTMR_Type *base)
```

Reads the current timer counting value.

This function returns the real-time timer counting value in a range from 0 to a timer period.

---

**Note:** Call the utility macros provided in the fsl\_common.h to convert ticks to usec or msec.

---

**Parameters**

- base – LPTMR peripheral base address

**Returns**

The current counter value in ticks

```
static inline void LPTMR_StartTimer(LPTMR_Type *base)
```

Starts the timer.

After calling this function, the timer counts up to the CMR register value. Each time the timer reaches the CMR value and then increments, it generates a trigger pulse and sets the timeout interrupt flag. An interrupt is also triggered if the timer interrupt is enabled.

**Parameters**

- base – LPTMR peripheral base address

```
static inline void LPTMR_StopTimer(LPTMR_Type *base)
```

Stops the timer.

This function stops the timer and resets the timer's counter register.

**Parameters**

- base – LPTMR peripheral base address

```
FSL_LPTMR_DRIVER_VERSION
```

Driver Version

```
enum __lptmr_pin_select
```

LPTMR pin selection used in pulse counter mode.

*Values:*

```
enumerator kLPTMR_PinSelectInput_0
```

Pulse counter input 0 is selected

enumerator kLPTMR\_PinSelectInput\_1

Pulse counter input 1 is selected

enumerator kLPTMR\_PinSelectInput\_2

Pulse counter input 2 is selected

enumerator kLPTMR\_PinSelectInput\_3

Pulse counter input 3 is selected

enum \_\_lptmr\_pin\_polarity

LPTMR pin polarity used in pulse counter mode.

*Values:*

enumerator kLPTMR\_PinPolarityActiveHigh

Pulse Counter input source is active-high

enumerator kLPTMR\_PinPolarityActiveLow

Pulse Counter input source is active-low

enum \_\_lptmr\_timer\_mode

LPTMR timer mode selection.

*Values:*

enumerator kLPTMR\_TimerModeTimeCounter

Time Counter mode

enumerator kLPTMR\_TimerModePulseCounter

Pulse Counter mode

enum \_\_lptmr\_prescaler\_glitch\_value

LPTMR prescaler/glitch filter values.

*Values:*

enumerator kLPTMR\_Prescale\_Glitch\_0

Prescaler divide 2, glitch filter does not support this setting

enumerator kLPTMR\_Prescale\_Glitch\_1

Prescaler divide 4, glitch filter 2

enumerator kLPTMR\_Prescale\_Glitch\_2

Prescaler divide 8, glitch filter 4

enumerator kLPTMR\_Prescale\_Glitch\_3

Prescaler divide 16, glitch filter 8

enumerator kLPTMR\_Prescale\_Glitch\_4

Prescaler divide 32, glitch filter 16

enumerator kLPTMR\_Prescale\_Glitch\_5

Prescaler divide 64, glitch filter 32

enumerator kLPTMR\_Prescale\_Glitch\_6

Prescaler divide 128, glitch filter 64

enumerator kLPTMR\_Prescale\_Glitch\_7

Prescaler divide 256, glitch filter 128

enumerator kLPTMR\_Prescale\_Glitch\_8

Prescaler divide 512, glitch filter 256

enumerator kLPTMR\_Prescale\_Glitch\_9  
Prescaler divide 1024, glitch filter 512

enumerator kLPTMR\_Prescale\_Glitch\_10  
Prescaler divide 2048 glitch filter 1024

enumerator kLPTMR\_Prescale\_Glitch\_11  
Prescaler divide 4096, glitch filter 2048

enumerator kLPTMR\_Prescale\_Glitch\_12  
Prescaler divide 8192, glitch filter 4096

enumerator kLPTMR\_Prescale\_Glitch\_13  
Prescaler divide 16384, glitch filter 8192

enumerator kLPTMR\_Prescale\_Glitch\_14  
Prescaler divide 32768, glitch filter 16384

enumerator kLPTMR\_Prescale\_Glitch\_15  
Prescaler divide 65536, glitch filter 32768

enum \_lptmr\_prescaler\_clock\_select  
LPTMR prescaler/glitch filter clock select.

---

**Note:** Clock connections are SoC-specific

---

*Values:*

enumerator kLPTMR\_PrescalerClock\_0  
Prescaler/glitch filter clock 0 selected.

enumerator kLPTMR\_PrescalerClock\_1  
Prescaler/glitch filter clock 1 selected.

enumerator kLPTMR\_PrescalerClock\_2  
Prescaler/glitch filter clock 2 selected.

enumerator kLPTMR\_PrescalerClock\_3  
Prescaler/glitch filter clock 3 selected.

enum \_lptmr\_interrupt\_enable  
List of the LPTMR interrupts.

*Values:*

enumerator kLPTMR\_TimerInterruptEnable  
Timer interrupt enable

enum \_lptmr\_status\_flags  
List of the LPTMR status flags.

*Values:*

enumerator kLPTMR\_TimerCompareFlag  
Timer compare flag

typedef enum \_lptmr\_pin\_select lptmr\_pin\_select\_t  
LPTMR pin selection used in pulse counter mode.

typedef enum \_lptmr\_pin\_polarity lptmr\_pin\_polarity\_t  
LPTMR pin polarity used in pulse counter mode.

typedef enum *\_lptmr\_timer\_mode* lptmr\_timer\_mode\_t  
LPTMR timer mode selection.

typedef enum *\_lptmr\_prescaler\_glitch\_value* lptmr\_prescaler\_glitch\_value\_t  
LPTMR prescaler/glitch filter values.

typedef enum *\_lptmr\_prescaler\_clock\_select* lptmr\_prescaler\_clock\_select\_t  
LPTMR prescaler/glitch filter clock select.

---

**Note:** Clock connections are SoC-specific

---

typedef enum *\_lptmr\_interrupt\_enable* lptmr\_interrupt\_enable\_t  
List of the LPTMR interrupts.

typedef enum *\_lptmr\_status\_flags* lptmr\_status\_flags\_t  
List of the LPTMR status flags.

typedef struct *\_lptmr\_config* lptmr\_config\_t  
LPTMR config structure.

This structure holds the configuration settings for the LPTMR peripheral. To initialize this structure to reasonable defaults, call the LPTMR\_GetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration struct can be made constant so it resides in flash.

static inline void LPTMR\_EnableTimerDMA(LPTMR\_Type \*base, bool enable)  
Enable or disable timer DMA request.

#### Parameters

- base – base LPTMR peripheral base address
- enable – Switcher of timer DMA feature. “true” means to enable, “false” means to disable.

struct *\_lptmr\_config*  
*#include <fsl\_lptmr.h>* LPTMR config structure.

This structure holds the configuration settings for the LPTMR peripheral. To initialize this structure to reasonable defaults, call the LPTMR\_GetDefaultConfig() function and pass a pointer to your configuration structure instance.

The configuration struct can be made constant so it resides in flash.

#### Public Members

*lptmr\_timer\_mode\_t* timerMode  
Time counter mode or pulse counter mode

*lptmr\_pin\_select\_t* pinSelect  
LPTMR pulse input pin select; used only in pulse counter mode

*lptmr\_pin\_polarity\_t* pinPolarity  
LPTMR pulse input pin polarity; used only in pulse counter mode

bool enableFreeRunning  
True: enable free running, counter is reset on overflow False: counter is reset when the compare flag is set

bool bypassPrescaler  
True: bypass prescaler; false: use clock from prescaler

*lptmr\_prescaler\_clock\_select\_t* prescalerClockSource

LPTMR clock source

*lptmr\_prescaler\_glitch\_value\_t* value

Prescaler or glitch filter value

## 2.27 MCM: Miscellaneous Control Module

FSL\_MCM\_DRIVER\_VERSION

MCM driver version.

Enum *\_mcm\_interrupt\_flag*. Interrupt status flag mask. .

Values:

enumerator *kMCM\_CacheWriteBuffer*

Cache Write Buffer Error Enable.

enumerator *kMCM\_ParityError*

Cache Parity Error Enable.

enumerator *kMCM\_FPUInvalidOperation*

FPU Invalid Operation Interrupt Enable.

enumerator *kMCM\_FPUDivideByZero*

FPU Divide-by-zero Interrupt Enable.

enumerator *kMCM\_FPUOverflow*

FPU Overflow Interrupt Enable.

enumerator *kMCM\_FPUUnderflow*

FPU Underflow Interrupt Enable.

enumerator *kMCM\_FPUInexact*

FPU Inexact Interrupt Enable.

enumerator *kMCM\_FPUInputDenormalInterrupt*

FPU Input Denormal Interrupt Enable.

typedef union *\_mcm\_buffer\_fault\_attribute* *mcm\_buffer\_fault\_attribute\_t*

The union of buffer fault attribute.

typedef union *\_mcm\_lmem\_fault\_attribute* *mcm\_lmem\_fault\_attribute\_t*

The union of LMEM fault attribute.

static inline void *MCM\_EnableCrossbarRoundRobin*(*MCM\_Type* \*base, bool enable)

Enables/Disables crossbar round robin.

### Parameters

- base – MCM peripheral base address.
- enable – Used to enable/disable crossbar round robin.
  - **true** Enable crossbar round robin.
  - **false** disable crossbar round robin.

static inline void MCM\_EnableInterruptStatus(MCM\_Type \*base, uint32\_t mask)

Enables the interrupt.

**Parameters**

- base – MCM peripheral base address.
- mask – Interrupt status flags mask(`mcm_interrupt_flag`).

static inline void MCM\_DisableInterruptStatus(MCM\_Type \*base, uint32\_t mask)

Disables the interrupt.

**Parameters**

- base – MCM peripheral base address.
- mask – Interrupt status flags mask(`mcm_interrupt_flag`).

static inline uint16\_t MCM\_GetInterruptStatus(MCM\_Type \*base)

Gets the Interrupt status .

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_ClearCacheWriteBufferErrorStatus(MCM\_Type \*base)

Clears the Interrupt status .

**Parameters**

- base – MCM peripheral base address.

static inline uint32\_t MCM\_GetBufferFaultAddress(MCM\_Type \*base)

Gets buffer fault address.

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_GetBufferFaultAttribute(MCM\_Type \*base, *mcm\_buffer\_fault\_attribute\_t* \*bufferfault)

Gets buffer fault attributes.

**Parameters**

- base – MCM peripheral base address.
- bufferfault – Structure to store the result.

static inline uint32\_t MCM\_GetBufferFaultData(MCM\_Type \*base)

Gets buffer fault data.

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_LimitCodeCachePeripheralWriteBuffering(MCM\_Type \*base, bool enable)

Limit code cache peripheral write buffering.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable limit code cache peripheral write buffering.
  - **true** Enable limit code cache peripheral write buffering.
  - **false** disable limit code cache peripheral write buffering.

static inline void MCM\_BypassFixedCodeCacheMap(MCM\_Type \*base, bool enable)  
Bypass fixed code cache map.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable bypass fixed code cache map.
  - **true** Enable bypass fixed code cache map.
  - **false** disable bypass fixed code cache map.

static inline void MCM\_EnableCodeBusCache(MCM\_Type \*base, bool enable)  
Enables/Disables code bus cache.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to disable/enable code bus cache.
  - **true** Enable code bus cache.
  - **false** disable code bus cache.

static inline void MCM\_ForceCodeCacheToNoAllocation(MCM\_Type \*base, bool enable)  
Force code cache to no allocation.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to force code cache to allocation or no allocation.
  - **true** Force code cache to no allocation.
  - **false** Force code cache to allocation.

static inline void MCM\_EnableCodeCacheWriteBuffer(MCM\_Type \*base, bool enable)  
Enables/Disables code cache write buffer.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable code cache write buffer.
  - **true** Enable code cache write buffer.
  - **false** Disable code cache write buffer.

static inline void MCM\_ClearCodeBusCache(MCM\_Type \*base)  
Clear code bus cache.

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_EnablePcParityFaultReport(MCM\_Type \*base, bool enable)  
Enables/Disables PC Parity Fault Report.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable PC Parity Fault Report.
  - **true** Enable PC Parity Fault Report.
  - **false** disable PC Parity Fault Report.

static inline void MCM\_EnablePcParity(MCM\_Type \*base, bool enable)  
Enables/Disables PC Parity.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable PC Parity.
  - **true** Enable PC Parity.
  - **false** disable PC Parity.

static inline void MCM\_LockConfigState(MCM\_Type \*base)  
Lock the configuration state.

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_EnableCacheParityReporting(MCM\_Type \*base, bool enable)  
Enables/Disables cache parity reporting.

**Parameters**

- base – MCM peripheral base address.
- enable – Used to enable/disable cache parity reporting.
  - **true** Enable cache parity reporting.
  - **false** disable cache parity reporting.

static inline uint32\_t MCM\_GetLmemFaultAddress(MCM\_Type \*base)  
Gets LMEM fault address.

**Parameters**

- base – MCM peripheral base address.

static inline void MCM\_GetLmemFaultAttribute(MCM\_Type \*base, *mcm\_lmem\_fault\_attribute\_t*  
\*lmemFault)

Get LMEM fault attributes.

**Parameters**

- base – MCM peripheral base address.
- lmemFault – Structure to store the result.

static inline uint64\_t MCM\_GetLmemFaultData(MCM\_Type \*base)  
Gets LMEM fault data.

**Parameters**

- base – MCM peripheral base address.

MCM\_LMFATR\_TYPE\_MASK

MCM\_LMFATR\_MODE\_MASK

MCM\_LMFATR\_BUFF\_MASK

MCM\_LMFATR\_CACH\_MASK

MCM\_ISCR\_STAT\_MASK

FSL\_COMPONENT\_ID

union \_mcm\_buffer\_fault\_attribute

*#include <fsl\_mcm.h>* The union of buffer fault attribute.

### Public Members

uint32\_t attribute

Indicates the faulting attributes, when a properly-enabled cache write buffer error interrupt event is detected.

struct *\_mcm\_buffer\_fault\_attribute.\_mcm\_buffer\_fault\_attrib* attribute\_memory

struct *\_mcm\_buffer\_fault\_attrib*

*#include <fsl\_mcm.h>*

### Public Members

uint32\_t busErrorDataAccessType

Indicates the type of cache write buffer access.

uint32\_t busErrorPrivilegeLevel

Indicates the privilege level of the cache write buffer access.

uint32\_t busErrorSize

Indicates the size of the cache write buffer access.

uint32\_t busErrorAccess

Indicates the type of system bus access.

uint32\_t busErrorMasterID

Indicates the crossbar switch bus master number of the captured cache write buffer bus error.

uint32\_t busErrorOverrun

Indicates if another cache write buffer bus error is detected.

union *\_mcm\_lmem\_fault\_attribute*

*#include <fsl\_mcm.h>* The union of LMEM fault attribute.

### Public Members

uint32\_t attribute

Indicates the attributes of the LMEM fault detected.

struct *\_mcm\_lmem\_fault\_attribute.\_mcm\_lmem\_fault\_attrib* attribute\_memory

struct *\_mcm\_lmem\_fault\_attrib*

*#include <fsl\_mcm.h>*

### Public Members

uint32\_t parityFaultProtectionSignal

Indicates the features of parity fault protection signal.

uint32\_t parityFaultMasterSize

Indicates the parity fault master size.

uint32\_t parityFaultWrite

Indicates the parity fault is caused by read or write.

uint32\_t backdoorAccess

Indicates the LMEM access fault is initiated by core access or backdoor access.

`uint32_t parityFaultSyndrome`  
Indicates the parity fault syndrome.

`uint32_t overrun`  
Indicates the number of faultss.

## 2.28 PIT: Periodic Interrupt Timer

`void PIT_Init(PIT_Type *base, const pit_config_t *config)`

Ungates the PIT clock, enables the PIT module, and configures the peripheral for basic operations.

---

**Note:** This API should be called at the beginning of the application using the PIT driver.

---

### Parameters

- `base` – PIT peripheral base address
- `config` – Pointer to the user's PIT config structure

`void PIT_Deinit(PIT_Type *base)`

Gates the PIT clock and disables the PIT module.

### Parameters

- `base` – PIT peripheral base address

`static inline void PIT_GetDefaultConfig(pit_config_t *config)`

Fills in the PIT configuration structure with the default settings.

The default values are as follows.

```
config->enableRunInDebug = false;
```

### Parameters

- `config` – Pointer to the configuration structure.

`static inline void PIT_SetTimerChainMode(PIT_Type *base, pit_chnl_t channel, bool enable)`

Enables or disables chaining a timer with the previous timer.

When a timer has a chain mode enabled, it only counts after the previous timer has expired. If the timer n-1 has counted down to 0, counter n decrements the value by one. Each timer is 32-bits, which allows the developers to chain timers together and form a longer timer (64-bits and larger). The first timer (timer 0) can't be chained to any other timer.

### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number which is chained with the previous timer
- `enable` – Enable or disable chain. true: Current timer is chained with the previous timer. false: Timer doesn't chain with other timers.

`static inline void PIT_EnableInterrupts(PIT_Type *base, pit_chnl_t channel, uint32_t mask)`

Enables the selected PIT interrupts.

### Parameters

- `base` – PIT peripheral base address

- `channel` – Timer channel number
- `mask` – The interrupts to enable. This is a logical OR of members of the enumeration `pit_interrupt_enable_t`

`static inline void PIT_DisableInterrupts(PIT_Type *base, pit_chnl_t channel, uint32_t mask)`  
Disables the selected PIT interrupts.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number
- `mask` – The interrupts to disable. This is a logical OR of members of the enumeration `pit_interrupt_enable_t`

`static inline uint32_t PIT_GetEnabledInterrupts(PIT_Type *base, pit_chnl_t channel)`  
Gets the enabled PIT interrupts.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number

#### Returns

The enabled interrupts. This is the logical OR of members of the enumeration `pit_interrupt_enable_t`

`static inline uint32_t PIT_GetStatusFlags(PIT_Type *base, pit_chnl_t channel)`  
Gets the PIT status flags.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number

#### Returns

The status flags. This is the logical OR of members of the enumeration `pit_status_flags_t`

`static inline void PIT_ClearStatusFlags(PIT_Type *base, pit_chnl_t channel, uint32_t mask)`  
Clears the PIT status flags.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number
- `mask` – The status flags to clear. This is a logical OR of members of the enumeration `pit_status_flags_t`

`static inline void PIT_SetTimerPeriod(PIT_Type *base, pit_chnl_t channel, uint32_t count)`  
Sets the timer period in units of count.

Timers begin counting from the value set by this function until it reaches 0, then it generates an interrupt and load this register value again. Writing a new value to this register does not restart the timer. Instead, the value is loaded after the timer expires.

---

**Note:** Users can call the utility macros provided in `fsl_common.h` to convert to ticks.

---

#### Parameters

- `base` – PIT peripheral base address

- `channel` – Timer channel number
- `count` – Timer period in units of ticks

static inline uint32\_t PIT\_GetCurrentTimerCount(PIT\_Type \*base, *pit\_chnl\_t* channel)

Reads the current timer counting value.

This function returns the real-time timer counting value, in a range from 0 to a timer period.

---

**Note:** Users can call the utility macros provided in `fsl_common.h` to convert ticks to usec or msec.

---

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number

#### Returns

Current timer counting value in ticks

static inline void PIT\_StartTimer(PIT\_Type \*base, *pit\_chnl\_t* channel)

Starts the timer counting.

After calling this function, timers load period value, count down to 0 and then load the respective start value again. Each time a timer reaches 0, it generates a trigger pulse and sets the timeout interrupt flag.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number.

static inline void PIT\_StopTimer(PIT\_Type \*base, *pit\_chnl\_t* channel)

Stops the timer counting.

This function stops every timer counting. Timers reload their periods respectively after the next time they call the `PIT_DRV_StartTimer`.

#### Parameters

- `base` – PIT peripheral base address
- `channel` – Timer channel number.

FSL\_PIT\_DRIVER\_VERSION

PIT Driver Version 2.2.0.

enum `_pit_chnl`

List of PIT channels.

---

**Note:** Actual number of available channels is SoC dependent

---

*Values:*

enumerator `kPIT_Chnl_0`

PIT channel number 0

enumerator `kPIT_Chnl_1`

PIT channel number 1

enumerator `kPIT_Chnl_2`

PIT channel number 2

enumerator kPIT\_Chnl\_3  
PIT channel number 3

enum \_\_pit\_interrupt\_enable  
List of PIT interrupts.

*Values:*

enumerator kPIT\_TimerInterruptEnable  
Timer interrupt enable

enum \_\_pit\_status\_flags  
List of PIT status flags.

*Values:*

enumerator kPIT\_TimerFlag  
Timer flag

typedef enum \_\_pit\_chnl pit\_chnl\_t  
List of PIT channels.

---

**Note:** Actual number of available channels is SoC dependent

---

typedef enum \_\_pit\_interrupt\_enable pit\_interrupt\_enable\_t  
List of PIT interrupts.

typedef enum \_\_pit\_status\_flags pit\_status\_flags\_t  
List of PIT status flags.

typedef struct \_\_pit\_config pit\_config\_t  
PIT configuration structure.

This structure holds the configuration settings for the PIT peripheral. To initialize this structure to reasonable defaults, call the PIT\_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

uint64\_t PIT\_GetLifetimeTimerCount(PIT\_Type \*base)  
Reads the current lifetime counter value.

The lifetime timer is a 64-bit timer which chains timer 0 and timer 1 together. Timer 0 and 1 are chained by calling the PIT\_SetTimerChainMode before using this timer. The period of lifetime timer is equal to the “period of timer 0 \* period of timer 1”. For the 64-bit value, the higher 32-bit has the value of timer 1, and the lower 32-bit has the value of timer 0.

#### Parameters

- base – PIT peripheral base address

#### Returns

Current lifetime timer value

struct \_\_pit\_config  
*#include <fsl\_pit.h>* PIT configuration structure.

This structure holds the configuration settings for the PIT peripheral. To initialize this structure to reasonable defaults, call the PIT\_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

### Public Members

bool enableRunInDebug

true: Timers run in debug mode; false: Timers stop in debug mode

## 2.29 PMC: Power Management Controller

static inline void PMC\_GetVersionId(PMC\_Type \*base, *pmc\_version\_id\_t* \*versionId)

Gets the PMC version ID.

This function gets the PMC version ID, including major version number, minor version number, and a feature specification number.

### Parameters

- base – PMC peripheral base address.
- versionId – Pointer to version ID structure.

void PMC\_GetParam(PMC\_Type \*base, *pmc\_param\_t* \*param)

Gets the PMC parameter.

This function gets the PMC parameter including the VLPO enable and the HVD enable.

### Parameters

- base – PMC peripheral base address.
- param – Pointer to PMC param structure.

void PMC\_ConfigureLowVoltDetect(PMC\_Type \*base, const *pmc\_low\_volt\_detect\_config\_t* \*config)

Configures the low-voltage detect setting.

This function configures the low-voltage detect setting, including the trip point voltage setting, enables or disables the interrupt, enables or disables the system reset.

### Parameters

- base – PMC peripheral base address.
- config – Low-voltage detect configuration structure.

static inline bool PMC\_GetLowVoltDetectFlag(PMC\_Type \*base)

Gets the Low-voltage Detect Flag status.

This function reads the current LVDF status. If it returns 1, a low-voltage event is detected.

### Parameters

- base – PMC peripheral base address.

### Returns

Current low-voltage detect flag

- true: Low-voltage detected
- false: Low-voltage not detected

static inline void PMC\_ClearLowVoltDetectFlag(PMC\_Type \*base)

Acknowledges clearing the Low-voltage Detect flag.

This function acknowledges the low-voltage detection errors (write 1 to clear LVDF).

### Parameters

- base – PMC peripheral base address.

```
void PMC_ConfigureLowVoltWarning(PMC_Type *base, const pmc_low_volt_warning_config_t *config)
```

Configures the low-voltage warning setting.

This function configures the low-voltage warning setting, including the trip point voltage setting and enabling or disabling the interrupt.

#### Parameters

- base – PMC peripheral base address.
- config – Low-voltage warning configuration structure.

```
static inline bool PMC_GetLowVoltWarningFlag(PMC_Type *base)
```

Gets the Low-voltage Warning Flag status.

This function polls the current LVWF status. When 1 is returned, it indicates a low-voltage warning event. LVWF is set when V Supply transitions below the trip point or after reset and V Supply is already below the V LVW.

#### Parameters

- base – PMC peripheral base address.

#### Returns

Current LVWF status

- true: Low-voltage Warning Flag is set.
- false: the Low-voltage Warning does not happen.

```
static inline void PMC_ClearLowVoltWarningFlag(PMC_Type *base)
```

Acknowledges the Low-voltage Warning flag.

This function acknowledges the low voltage warning errors (write 1 to clear LVWF).

#### Parameters

- base – PMC peripheral base address.

```
void PMC_ConfigureHighVoltDetect(PMC_Type *base, const pmc_high_volt_detect_config_t *config)
```

Configures the high-voltage detect setting.

This function configures the high-voltage detect setting, including the trip point voltage setting, enabling or disabling the interrupt, enabling or disabling the system reset.

#### Parameters

- base – PMC peripheral base address.
- config – High-voltage detect configuration structure.

```
static inline bool PMC_GetHighVoltDetectFlag(PMC_Type *base)
```

Gets the High-voltage Detect Flag status.

This function reads the current HVDF status. If it returns 1, a low voltage event is detected.

#### Parameters

- base – PMC peripheral base address.

#### Returns

Current high-voltage detect flag

- true: High-voltage detected
- false: High-voltage not detected

```
static inline void PMC_ClearHighVoltDetectFlag(PMC_Type *base)
```

Acknowledges clearing the High-voltage Detect flag.

This function acknowledges the high-voltage detection errors (write 1 to clear HVDF).

#### Parameters

- base – PMC peripheral base address.

```
void PMC_ConfigureBandgapBuffer(PMC_Type *base, const pmc_bandgap_buffer_config_t  
                                *config)
```

Configures the PMC bandgap.

This function configures the PMC bandgap, including the drive select and behavior in low-power mode.

#### Parameters

- base – PMC peripheral base address.
- config – Pointer to the configuration structure

```
static inline bool PMC_GetPeriphIOIsolationFlag(PMC_Type *base)
```

Gets the acknowledge Peripherals and I/O pads isolation flag.

This function reads the Acknowledge Isolation setting that indicates whether certain peripherals and the I/O pads are in a latched state as a result of having been in the VLLS mode.

#### Parameters

- base – PMC peripheral base address.
- base – Base address for current PMC instance.

#### Returns

ACK isolation 0 - Peripherals and I/O pads are in a normal run state. 1 - Certain peripherals and I/O pads are in an isolated and latched state.

```
static inline void PMC_ClearPeriphIOIsolationFlag(PMC_Type *base)
```

Acknowledges the isolation flag to Peripherals and I/O pads.

This function clears the ACK Isolation flag. Writing one to this setting when it is set releases the I/O pads and certain peripherals to their normal run mode state.

#### Parameters

- base – PMC peripheral base address.

```
static inline bool PMC_IsRegulatorInRunRegulation(PMC_Type *base)
```

Gets the regulator regulation status.

This function returns the regulator to run a regulation status. It provides the current status of the internal voltage regulator.

#### Parameters

- base – PMC peripheral base address.
- base – Base address for current PMC instance.

#### Returns

Regulation status 0 - Regulator is in a stop regulation or in transition to/from the regulation. 1 - Regulator is in a run regulation.

```
FSL_PMC_DRIVER_VERSION
```

PMC driver version.

Version 2.0.4.

enum \_pmc\_low\_volt\_detect\_volt\_select

Low-voltage Detect Voltage Select.

*Values:*

enumerator kPMC\_LowVoltDetectLowTrip

Low-trip point selected (VLVD = VLVDL )

enumerator kPMC\_LowVoltDetectHighTrip

High-trip point selected (VLVD = VLVDH )

enum \_pmc\_low\_volt\_warning\_volt\_select

Low-voltage Warning Voltage Select.

*Values:*

enumerator kPMC\_LowVoltWarningLowTrip

Low-trip point selected (VLVW = VLVW1)

enumerator kPMC\_LowVoltWarningMid1Trip

Mid 1 trip point selected (VLVW = VLVW2)

enumerator kPMC\_LowVoltWarningMid2Trip

Mid 2 trip point selected (VLVW = VLVW3)

enumerator kPMC\_LowVoltWarningHighTrip

High-trip point selected (VLVW = VLVW4)

enum \_pmc\_high\_volt\_detect\_volt\_select

High-voltage Detect Voltage Select.

*Values:*

enumerator kPMC\_HighVoltDetectLowTrip

Low-trip point selected (VHVD = VHVDL )

enumerator kPMC\_HighVoltDetectHighTrip

High-trip point selected (VHVD = VHVDH )

enum \_pmc\_bandgap\_buffer\_drive\_select

Bandgap Buffer Drive Select.

*Values:*

enumerator kPMC\_BandgapBufferDriveLow

Low-drive.

enumerator kPMC\_BandgapBufferDriveHigh

High-drive.

enum \_pmc\_vlp\_freq\_option

VLPx Option.

*Values:*

enumerator kPMC\_FreqRestrict

Frequency is restricted in VLPx mode.

enumerator kPMC\_FreqUnrestrict

Frequency is unrestricted in VLPx mode.

typedef enum \_pmc\_low\_volt\_detect\_volt\_select pmc\_low\_volt\_detect\_volt\_select\_t

Low-voltage Detect Voltage Select.

typedef enum *\_pmc\_low\_volt\_warning\_volt\_select* pmc\_low\_volt\_warning\_volt\_select\_t  
Low-voltage Warning Voltage Select.

typedef enum *\_pmc\_high\_volt\_detect\_volt\_select* pmc\_high\_volt\_detect\_volt\_select\_t  
High-voltage Detect Voltage Select.

typedef enum *\_pmc\_bandgap\_buffer\_drive\_select* pmc\_bandgap\_buffer\_drive\_select\_t  
Bandgap Buffer Drive Select.

typedef enum *\_pmc\_vlp\_freq\_option* pmc\_vlp\_freq\_mode\_t  
VLPx Option.

typedef struct *\_pmc\_version\_id* pmc\_version\_id\_t  
IP version ID definition.

typedef struct *\_pmc\_param* pmc\_param\_t  
IP parameter definition.

typedef struct *\_pmc\_low\_volt\_detect\_config* pmc\_low\_volt\_detect\_config\_t  
Low-voltage Detect Configuration Structure.

typedef struct *\_pmc\_low\_volt\_warning\_config* pmc\_low\_volt\_warning\_config\_t  
Low-voltage Warning Configuration Structure.

typedef struct *\_pmc\_high\_volt\_detect\_config* pmc\_high\_volt\_detect\_config\_t  
High-voltage Detect Configuration Structure.

typedef struct *\_pmc\_bandgap\_buffer\_config* pmc\_bandgap\_buffer\_config\_t  
Bandgap Buffer configuration.

struct *\_pmc\_version\_id*  
*#include <fsl\_pmc.h>* IP version ID definition.

### Public Members

uint16\_t feature  
Feature Specification Number.

uint8\_t minor  
Minor version number.

uint8\_t major  
Major version number.

struct *\_pmc\_param*  
*#include <fsl\_pmc.h>* IP parameter definition.

### Public Members

bool vlpoEnable  
VLPO enable.

bool hvdEnable  
HVD enable.

struct *\_pmc\_low\_volt\_detect\_config*  
*#include <fsl\_pmc.h>* Low-voltage Detect Configuration Structure.

**Public Members**

bool enableInt  
    Enable interrupt when Low-voltage detect

bool enableReset  
    Enable system reset when Low-voltage detect

*pmc\_low\_volt\_detect\_volt\_select\_t* voltSelect  
    Low-voltage detect trip point voltage selection

struct \_\_pmc\_low\_volt\_warning\_config  
    #include <fsl\_pmc.h> Low-voltage Warning Configuration Structure.

**Public Members**

bool enableInt  
    Enable interrupt when low-voltage warning

*pmc\_low\_volt\_warning\_volt\_select\_t* voltSelect  
    Low-voltage warning trip point voltage selection

struct \_\_pmc\_high\_volt\_detect\_config  
    #include <fsl\_pmc.h> High-voltage Detect Configuration Structure.

**Public Members**

bool enableInt  
    Enable interrupt when high-voltage detect

bool enableReset  
    Enable system reset when high-voltage detect

*pmc\_high\_volt\_detect\_volt\_select\_t* voltSelect  
    High-voltage detect trip point voltage selection

struct \_\_pmc\_bandgap\_buffer\_config  
    #include <fsl\_pmc.h> Bandgap Buffer configuration.

**Public Members**

bool enable  
    Enable bandgap buffer.

bool enableInLowPowerMode  
    Enable bandgap buffer in low-power mode.

*pmc\_bandgap\_buffer\_drive\_select\_t* drive  
    Bandgap buffer drive select.

## 2.30 PORT: Port Control and Interrupts

```
static inline void PORT_SetPinConfig(PORT_Type *base, uint32_t pin, const port_pin_config_t
                                     *config)
```

Sets the port PCR register.

This is an example to define an input pin or output pin PCR configuration.

```
// Define a digital input pin PCR configuration
port_pin_config_t config = {
    kPORT_PullUp,
    kPORT_FastSlewRate,
    kPORT_PassiveFilterDisable,
    kPORT_OpenDrainDisable,
    kPORT_LowDriveStrength,
    kPORT_MuxAsGpio,
    kPORT_UnLockRegister,
};
```

### Parameters

- base – PORT peripheral base pointer.
- pin – PORT pin number.
- config – PORT PCR register configuration structure.

```
static inline void PORT_SetMultiplePinsConfig(PORT_Type *base, uint32_t mask, const
                                              port_pin_config_t *config)
```

Sets the port PCR register for multiple pins.

This is an example to define input pins or output pins PCR configuration.

```
Define a digital input pin PCR configuration
port_pin_config_t config = {
    kPORT_PullUp ,
    kPORT_PullEnable,
    kPORT_FastSlewRate,
    kPORT_PassiveFilterDisable,
    kPORT_OpenDrainDisable,
    kPORT_LowDriveStrength,
    kPORT_MuxAsGpio,
    kPORT_UnlockRegister,
};
```

### Parameters

- base – PORT peripheral base pointer.
- mask – PORT pin number macro.
- config – PORT PCR register configuration structure.

```
static inline void PORT_SetMultipleInterruptPinsConfig(PORT_Type *base, uint32_t mask,
                                                       port_interrupt_t config)
```

Sets the port interrupt configuration in PCR register for multiple pins.

### Parameters

- base – PORT peripheral base pointer.
- mask – PORT pin number macro.
- config – PORT pin interrupt configuration.
  - kPORT\_InterruptOrDMADisabled: Interrupt/DMA request disabled.
  - kPORT\_DMARisingEdge : DMA request on rising edge(if the DMA requests exit).

- kPORT\_DMAFallingEdge: DMA request on falling edge(if the DMA requests exit).
- kPORT\_DMAEitherEdge : DMA request on either edge(if the DMA requests exit).
- kPORT\_FlagRisingEdge : Flag sets on rising edge(if the Flag states exit).
- kPORT\_FlagFallingEdge : Flag sets on falling edge(if the Flag states exit).
- kPORT\_FlagEitherEdge : Flag sets on either edge(if the Flag states exit).
- kPORT\_InterruptLogicZero : Interrupt when logic zero.
- kPORT\_InterruptRisingEdge : Interrupt on rising edge.
- kPORT\_InterruptFallingEdge: Interrupt on falling edge.
- kPORT\_InterruptEitherEdge : Interrupt on either edge.
- kPORT\_InterruptLogicOne : Interrupt when logic one.
- kPORT\_ActiveHighTriggerOutputEnable : Enable active high-trigger output (if the trigger states exit).
- kPORT\_ActiveLowTriggerOutputEnable : Enable active low-trigger output (if the trigger states exit).

static inline void PORT\_SetPinMux(PORT\_Type \*base, uint32\_t pin, *port\_mux\_t* mux)

Configures the pin muxing.

---

**Note:** : This function is NOT recommended to use together with the PORT\_SetPinsConfig, because the PORT\_SetPinsConfig need to configure the pin mux anyway (Otherwise the pin mux is reset to zero : kPORT\_PinDisabledOrAnalog). This function is recommended to use to reset the pin mux

---

#### Parameters

- base – PORT peripheral base pointer.
- pin – PORT pin number.
- mux – pin muxing slot selection.
  - kPORT\_PinDisabledOrAnalog: Pin disabled or work in analog function.
  - kPORT\_MuxAsGpio : Set as GPIO.
  - kPORT\_MuxAlt2 : chip-specific.
  - kPORT\_MuxAlt3 : chip-specific.
  - kPORT\_MuxAlt4 : chip-specific.
  - kPORT\_MuxAlt5 : chip-specific.
  - kPORT\_MuxAlt6 : chip-specific.
  - kPORT\_MuxAlt7 : chip-specific.

static inline void PORT\_EnablePinsDigitalFilter(PORT\_Type \*base, uint32\_t mask, bool enable)

Enables the digital filter in one port, each bit of the 32-bit register represents one pin.

#### Parameters

- base – PORT peripheral base pointer.
- mask – PORT pin number macro.
- enable – PORT digital filter configuration.

```
static inline void PORT_SetDigitalFilterConfig(PORT_Type *base, const
                                             port_digital_filter_config_t *config)
```

Sets the digital filter in one port, each bit of the 32-bit register represents one pin.

#### Parameters

- base – PORT peripheral base pointer.
- config – PORT digital filter configuration structure.

```
static inline void PORT_SetPinInterruptConfig(PORT_Type *base, uint32_t pin, port_interrupt_t
                                             config)
```

Configures the port pin interrupt/DMA request.

#### Parameters

- base – PORT peripheral base pointer.
- pin – PORT pin number.
- config – PORT pin interrupt configuration.
  - kPORT\_InterruptOrDMADisabled: Interrupt/DMA request disabled.
  - kPORT\_DMARisingEdge : DMA request on rising edge(if the DMA requests exit).
  - kPORT\_DMAFallingEdge: DMA request on falling edge(if the DMA requests exit).
  - kPORT\_DMAEitherEdge : DMA request on either edge(if the DMA requests exit).
  - kPORT\_FlagRisingEdge : Flag sets on rising edge(if the Flag states exit).
  - kPORT\_FlagFallingEdge : Flag sets on falling edge(if the Flag states exit).
  - kPORT\_FlagEitherEdge : Flag sets on either edge(if the Flag states exit).
  - kPORT\_InterruptLogicZero : Interrupt when logic zero.
  - kPORT\_InterruptRisingEdge : Interrupt on rising edge.
  - kPORT\_InterruptFallingEdge: Interrupt on falling edge.
  - kPORT\_InterruptEitherEdge : Interrupt on either edge.
  - kPORT\_InterruptLogicOne : Interrupt when logic one.
  - kPORT\_ActiveHighTriggerOutputEnable : Enable active high-trigger output (if the trigger states exit).
  - kPORT\_ActiveLowTriggerOutputEnable : Enable active low-trigger output (if the trigger states exit).

```
static inline void PORT_SetPinDriveStrength(PORT_Type *base, uint32_t pin, uint8_t strength)
```

Configures the port pin drive strength.

#### Parameters

- base – PORT peripheral base pointer.
- pin – PORT pin number.
- strength – PORT pin drive strength
  - kPORT\_LowDriveStrength = 0U - Low-drive strength is configured.
  - kPORT\_HighDriveStrength = 1U - High-drive strength is configured.

static inline uint32\_t PORT\_GetPinsInterruptFlags(PORT\_Type \*base)

Reads the whole port status flag.

If a pin is configured to generate the DMA request, the corresponding flag is cleared automatically at the completion of the requested DMA transfer. Otherwise, the flag remains set until a logic one is written to that flag. If configured for a level sensitive interrupt that remains asserted, the flag is set again immediately.

**Parameters**

- base – PORT peripheral base pointer.

**Returns**

Current port interrupt status flags, for example, 0x00010001 means the pin 0 and 16 have the interrupt.

static inline void PORT\_ClearPinsInterruptFlags(PORT\_Type \*base, uint32\_t mask)

Clears the multiple pin interrupt status flag.

**Parameters**

- base – PORT peripheral base pointer.
- mask – PORT pin number macro.

FSL\_PORT\_DRIVER\_VERSION

PORT driver version.

enum \_port\_pull

Internal resistor pull feature selection.

*Values:*

enumerator kPORT\_PullDisable

Internal pull-up/down resistor is disabled.

enumerator kPORT\_PullDown

Internal pull-down resistor is enabled.

enumerator kPORT\_PullUp

Internal pull-up resistor is enabled.

enum \_port\_slew\_rate

Slew rate selection.

*Values:*

enumerator kPORT\_FastSlewRate

Fast slew rate is configured.

enumerator kPORT\_SlowSlewRate

Slow slew rate is configured.

enum \_port\_open\_drain\_enable

Open Drain feature enable/disable.

*Values:*

enumerator kPORT\_OpenDrainDisable

Open drain output is disabled.

enumerator kPORT\_OpenDrainEnable

Open drain output is enabled.

enum `_port_passive_filter_enable`

Passive filter feature enable/disable.

*Values:*

enumerator `kPORT_PassiveFilterDisable`

Passive input filter is disabled.

enumerator `kPORT_PassiveFilterEnable`

Passive input filter is enabled.

enum `_port_drive_strength`

Configures the drive strength.

*Values:*

enumerator `kPORT_LowDriveStrength`

Low-drive strength is configured.

enumerator `kPORT_HighDriveStrength`

High-drive strength is configured.

enum `_port_lock_register`

Unlock/lock the pin control register field[15:0].

*Values:*

enumerator `kPORT_UnlockRegister`

Pin Control Register fields [15:0] are not locked.

enumerator `kPORT_LockRegister`

Pin Control Register fields [15:0] are locked.

enum `_port_mux`

Pin mux selection.

*Values:*

enumerator `kPORT_PinDisabledOrAnalog`

Corresponding pin is disabled, but is used as an analog pin.

enumerator `kPORT_MuxAsGpio`

Corresponding pin is configured as GPIO.

enumerator `kPORT_MuxAlt0`

Chip-specific

enumerator `kPORT_MuxAlt1`

Chip-specific

enumerator `kPORT_MuxAlt2`

Chip-specific

enumerator `kPORT_MuxAlt3`

Chip-specific

enumerator `kPORT_MuxAlt4`

Chip-specific

enumerator `kPORT_MuxAlt5`

Chip-specific

enumerator `kPORT_MuxAlt6`

Chip-specific

enumerator kPORT\_MuxAlt7

Chip-specific

enumerator kPORT\_MuxAlt8

Chip-specific

enumerator kPORT\_MuxAlt9

Chip-specific

enumerator kPORT\_MuxAlt10

Chip-specific

enumerator kPORT\_MuxAlt11

Chip-specific

enumerator kPORT\_MuxAlt12

Chip-specific

enumerator kPORT\_MuxAlt13

Chip-specific

enumerator kPORT\_MuxAlt14

Chip-specific

enumerator kPORT\_MuxAlt15

Chip-specific

enum \_port\_interrupt

Configures the interrupt generation condition.

*Values:*

enumerator kPORT\_InterruptOrDMADisabled

Interrupt/DMA request is disabled.

enumerator kPORT\_DMARisingEdge

DMA request on rising edge.

enumerator kPORT\_DMAFallingEdge

DMA request on falling edge.

enumerator kPORT\_DMAEitherEdge

DMA request on either edge.

enumerator kPORT\_FlagRisingEdge

Flag sets on rising edge.

enumerator kPORT\_FlagFallingEdge

Flag sets on falling edge.

enumerator kPORT\_FlagEitherEdge

Flag sets on either edge.

enumerator kPORT\_InterruptLogicZero

Interrupt when logic zero.

enumerator kPORT\_InterruptRisingEdge

Interrupt on rising edge.

enumerator kPORT\_InterruptFallingEdge

Interrupt on falling edge.

enumerator kPORT\_InterruptEitherEdge  
Interrupt on either edge.

enumerator kPORT\_InterruptLogicOne  
Interrupt when logic one.

enumerator kPORT\_ActiveHighTriggerOutputEnable  
Enable active high-trigger output.

enumerator kPORT\_ActiveLowTriggerOutputEnable  
Enable active low-trigger output.

enum \_port\_digital\_filter\_clock\_source  
Digital filter clock source selection.

*Values:*

enumerator kPORT\_BusClock  
Digital filters are clocked by the bus clock.

enumerator kPORT\_LpoClock  
Digital filters are clocked by the 1 kHz LPO clock.

typedef enum \_port\_mux port\_mux\_t  
Pin mux selection.

typedef enum \_port\_interrupt port\_interrupt\_t  
Configures the interrupt generation condition.

typedef enum \_port\_digital\_filter\_clock\_source port\_digital\_filter\_clock\_source\_t  
Digital filter clock source selection.

typedef struct \_port\_digital\_filter\_config port\_digital\_filter\_config\_t  
PORT digital filter feature configuration definition.

typedef struct \_port\_pin\_config port\_pin\_config\_t  
PORT pin configuration structure.

FSL\_COMPONENT\_ID

struct \_port\_digital\_filter\_config  
*#include <fsl\_port.h>* PORT digital filter feature configuration definition.

### Public Members

uint32\_t digitalFilterWidth  
Set digital filter width  
*port\_digital\_filter\_clock\_source\_t* clockSource  
Set digital filter clockSource

struct \_port\_pin\_config  
*#include <fsl\_port.h>* PORT pin configuration structure.

### Public Members

uint16\_t pullSelect  
No-pull/pull-down/pull-up select  
uint16\_t slewRate  
Fast/slow slew rate Configure

uint16\_t passiveFilterEnable  
Passive filter enable/disable

uint16\_t openDrainEnable  
Open drain enable/disable

uint16\_t driveStrength  
Fast/slow drive strength configure

uint16\_t lockRegister  
Lock/unlock the PCR field[15:0]

## 2.31 QTMR: Quad Timer Driver

void QTMR\_Init(TMR\_Type \*base, const *qtmr\_config\_t* \*config)

Un-gates the Quad Timer clock and configures the peripheral for basic operation.

---

**Note:** This API should be called at the beginning of the application using the Quad Timer driver.

---

### Parameters

- base – Quad Timer peripheral base address
- config – Pointer to user's Quad Timer config structure

void QTMR\_Deinit(TMR\_Type \*base)

Stops the counter and gates the Quad Timer clock.

### Parameters

- base – Quad Timer peripheral base address

void QTMR\_GetDefaultConfig(*qtmr\_config\_t* \*config)

Fill in the Quad Timer config struct with the default settings.

The default values are:

```
config->debugMode = kQTMR_RunNormalInDebug;
config->enableExternalForce = false;
config->enableMasterMode = false;
config->faultFilterCount = 0;
config->faultFilterPeriod = 0;
config->primarySource = kQTMR_ClockDivide_2;
config->secondarySource = kQTMR_Counter0InputPin;
```

### Parameters

- config – Pointer to user's Quad Timer config structure.

void QTMR\_EnableInterrupts(TMR\_Type \*base, uint32\_t mask)

Enables the selected Quad Timer interrupts.

### Parameters

- base – Quad Timer peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration *qtmr\_interrupt\_enable\_t*

void QTMR\_DisableInterrupts(TMR\_Type \*base, uint32\_t mask)

Disables the selected Quad Timer interrupts.

**Parameters**

- base – Quad Timer peripheral base address
- mask – The interrupts to enable. This is a logical OR of members of the enumeration qtmr\_interrupt\_enable\_t

uint32\_t QTMR\_GetEnabledInterrupts(TMR\_Type \*base)

Gets the enabled Quad Timer interrupts.

**Parameters**

- base – Quad Timer peripheral base address

**Returns**

The enabled interrupts. This is the logical OR of members of the enumeration qtmr\_interrupt\_enable\_t

uint32\_t QTMR\_GetStatus(TMR\_Type \*base)

Gets the Quad Timer status flags.

**Parameters**

- base – Quad Timer peripheral base address

**Returns**

The status flags. This is the logical OR of members of the enumeration qtmr\_status\_flags\_t

void QTMR\_ClearStatusFlags(TMR\_Type \*base, uint32\_t mask)

Clears the Quad Timer status flags.

**Parameters**

- base – Quad Timer peripheral base address
- mask – The status flags to clear. This is a logical OR of members of the enumeration qtmr\_status\_flags\_t

void QTMR\_SetTimerPeriod(TMR\_Type \*base, uint16\_t ticks)

Sets the timer period in ticks.

Timers counts from initial value till it equals the count value set here. The counter will then reinitialize to the value specified in the Load register.

---

**Note:**

- a. This function will write the time period in ticks to COMP1 or COMP2 register depending on the count direction
  - b. User can call the utility macros provided in fsl\_common.h to convert to ticks
  - c. This function supports cases, providing only primary source clock without secondary source clock.
- 

**Parameters**

- base – Quad Timer peripheral base address
- ticks – Timer period in units of ticks

```
static inline uint16_t QTMR_GetCurrentTimerCount(TMR_Type *base)
```

Reads the current timer counting value.

This function returns the real-time timer counting value, in a range from 0 to a timer period.

---

**Note:** User can call the utility macros provided in `fsl_common.h` to convert ticks to usec or msec

---

#### Parameters

- `base` – Quad Timer peripheral base address

#### Returns

Current counter value in ticks

```
static inline void QTMR_StartTimer(TMR_Type *base, qtmr_counting_mode_t clockSource)
```

Starts the Quad Timer counter.

#### Parameters

- `base` – Quad Timer peripheral base address
- `clockSource` – Quad Timer clock source

```
static inline void QTMR_StopTimer(TMR_Type *base)
```

Stops the Quad Timer counter.

#### Parameters

- `base` – Quad Timer peripheral base address

```
FSL_QTMR_DRIVER_VERSION
```

Version.

```
enum _qtmr_primary_count_source
```

Quad Timer primary clock source selection.

*Values:*

```
enumerator kQTMR_ClockCounter0InputPin
```

Use counter 0 input pin

```
enumerator kQTMR_ClockCounter1InputPin
```

Use counter 1 input pin

```
enumerator kQTMR_ClockCounter2InputPin
```

Use counter 2 input pin

```
enumerator kQTMR_ClockCounter3InputPin
```

Use counter 3 input pin

```
enumerator kQTMR_ClockCounter0Output
```

Use counter 0 output

```
enumerator kQTMR_ClockCounter1Output
```

Use counter 1 output

```
enumerator kQTMR_ClockCounter2Output
```

Use counter 2 output

```
enumerator kQTMR_ClockCounter3Output
```

Use counter 3 output

enumerator kQTMR\_ClockDivide\_1  
IP bus clock divide by 1 prescaler

enumerator kQTMR\_ClockDivide\_2  
IP bus clock divide by 2 prescaler

enumerator kQTMR\_ClockDivide\_4  
IP bus clock divide by 4 prescaler

enumerator kQTMR\_ClockDivide\_8  
IP bus clock divide by 8 prescaler

enumerator kQTMR\_ClockDivide\_16  
IP bus clock divide by 16 prescaler

enumerator kQTMR\_ClockDivide\_32  
IP bus clock divide by 32 prescaler

enumerator kQTMR\_ClockDivide\_64  
IP bus clock divide by 64 prescaler

enumerator kQTMR\_ClockDivide\_128  
IP bus clock divide by 128 prescaler

enum \_qtmr\_input\_source  
Quad Timer input sources selection.

*Values:*

enumerator kQTMR\_Counter0InputPin  
Use counter 0 input pin

enumerator kQTMR\_Counter1InputPin  
Use counter 1 input pin

enumerator kQTMR\_Counter2InputPin  
Use counter 2 input pin

enumerator kQTMR\_Counter3InputPin  
Use counter 3 input pin

enum \_qtmr\_counting\_mode  
Quad Timer counting mode selection.

*Values:*

enumerator kQTMR\_NoOperation  
No operation

enumerator kQTMR\_PriSrcRiseEdge  
Count rising edges of primary source

enumerator kQTMR\_PriSrcRiseAndFallEdge  
Count rising and falling edges of primary source

enumerator kQTMR\_PriSrcRiseEdgeSecInpHigh  
Count rise edges of pri SRC while sec inp high active

enumerator kQTMR\_QuadCountMode  
Quadrature count mode, uses pri and sec sources

enumerator kQTMR\_PriSrcRiseEdgeSecDir  
Count rising edges of pri SRC; sec SRC specifies dir

enumerator kQTMR\_SecSrcTrigPriCnt  
Edge of sec SRC trigger primary count until compare

enumerator kQTMR\_CascadeCount  
Cascaded count mode (up/down)

enum \_\_qtmr\_output\_mode  
Quad Timer output mode selection.

*Values:*

enumerator kQTMR\_AssertWhenCountActive  
Assert OFLAG while counter is active

enumerator kQTMR\_ClearOnCompare  
Clear OFLAG on successful compare

enumerator kQTMR\_SetOnCompare  
Set OFLAG on successful compare

enumerator kQTMR\_ToggleOnCompare  
Toggle OFLAG on successful compare

enumerator kQTMR\_ToggleOnAltCompareReg  
Toggle OFLAG using alternating compare registers

enumerator kQTMR\_SetOnCompareClearOnSecSrcInp  
Set OFLAG on compare, clear on sec SRC input edge

enumerator kQTMR\_SetOnCompareClearOnCountRoll  
Set OFLAG on compare, clear on counter rollover

enumerator kQTMR\_EnableGateClock  
Enable gated clock output while count is active

enum \_\_qtmr\_input\_capture\_edge  
Quad Timer input capture edge mode, rising edge, or falling edge.

*Values:*

enumerator kQTMR\_NoCapture  
Capture is disabled

enumerator kQTMR\_RisingEdge  
Capture on rising edge (IPS=0) or falling edge (IPS=1)

enumerator kQTMR\_FallingEdge  
Capture on falling edge (IPS=0) or rising edge (IPS=1)

enumerator kQTMR\_RisingAndFallingEdge  
Capture on both edges

enum \_\_qtmr\_preload\_control  
Quad Timer input capture edge mode, rising edge, or falling edge.

*Values:*

enumerator kQTMR\_NoPreload  
Never preload

enumerator kQTMR\_LoadOnComp1  
Load upon successful compare with value in COMP1

enumerator kQTMR\_LoadOnComp2

Load upon successful compare with value in COMP2

enum \_\_qtmr\_debug\_action

List of Quad Timer run options when in Debug mode.

*Values:*

enumerator kQTMR\_RunNormalInDebug

Continue with normal operation

enumerator kQTMR\_HaltCounter

Halt counter

enumerator kQTMR\_ForceOutToZero

Force output to logic 0

enumerator kQTMR\_HaltCountForceOutZero

Halt counter and force output to logic 0

enum \_\_qtmr\_interrupt\_enable

List of Quad Timer interrupts.

*Values:*

enumerator kQTMR\_CompareInterruptEnable

Compare interrupt.

enumerator kQTMR\_Compare1InterruptEnable

Compare 1 interrupt.

enumerator kQTMR\_Compare2InterruptEnable

Compare 2 interrupt.

enumerator kQTMR\_OverflowInterruptEnable

Timer overflow interrupt.

enumerator kQTMR\_EdgeInterruptEnable

Input edge interrupt.

enum \_\_qtmr\_status\_flags

List of Quad Timer flags.

*Values:*

enumerator kQTMR\_CompareFlag

Compare flag

enumerator kQTMR\_Compare1Flag

Compare 1 flag

enumerator kQTMR\_Compare2Flag

Compare 2 flag

enumerator kQTMR\_OverflowFlag

Timer overflow flag

enumerator kQTMR\_EdgeFlag

Input edge flag

typedef enum \_\_qtmr\_primary\_count\_source qtmr\_primary\_count\_source\_t

Quad Timer primary clock source selection.

typedef enum *\_qtmr\_input\_source* qtmr\_input\_source\_t

Quad Timer input sources selection.

typedef enum *\_qtmr\_counting\_mode* qtmr\_counting\_mode\_t

Quad Timer counting mode selection.

typedef enum *\_qtmr\_output\_mode* qtmr\_output\_mode\_t

Quad Timer output mode selection.

typedef enum *\_qtmr\_input\_capture\_edge* qtmr\_input\_capture\_edge\_t

Quad Timer input capture edge mode, rising edge, or falling edge.

typedef enum *\_qtmr\_preload\_control* qtmr\_preload\_control\_t

Quad Timer input capture edge mode, rising edge, or falling edge.

typedef enum *\_qtmr\_debug\_action* qtmr\_debug\_action\_t

List of Quad Timer run options when in Debug mode.

typedef enum *\_qtmr\_interrupt\_enable* qtmr\_interrupt\_enable\_t

List of Quad Timer interrupts.

typedef enum *\_qtmr\_status\_flags* qtmr\_status\_flags\_t

List of Quad Timer flags.

typedef struct *\_qtmr\_config* qtmr\_config\_t

Quad Timer config structure.

This structure holds the configuration settings for the Quad Timer peripheral. To initialize this structure to reasonable defaults, call the QTMR\_GetDefaultConfig() function and pass a pointer to your config structure instance.

The config struct can be made const so it resides in flash

*status\_t* QTMR\_SetupPwm(TMR\_Type \*base, uint32\_t pwmFreqHz, uint8\_t dutyCyclePercent, bool outputPolarity, uint32\_t srcClock\_Hz)

Sets up Quad timer module for PWM signal output.

The function initializes the timer module according to the parameters passed in by the user. The function also sets up the value compare registers to match the PWM signal requirements.

#### Parameters

- base – Quad Timer peripheral base address
- pwmFreqHz – PWM signal frequency in Hz
- dutyCyclePercent – PWM pulse width, value should be between 0 to 100  
0=inactive signal(0% duty cycle)... 100=active signal (100% duty cycle)
- outputPolarity – true: invert polarity of the output signal, false: no inversion
- srcClock\_Hz – Main counter clock in Hz.

#### Returns

Returns an error if there was error setting up the signal.

void QTMR\_SetupInputCapture(TMR\_Type \*base, *qtmr\_input\_source\_t* capturePin, bool inputPolarity, bool reloadOnCapture, *qtmr\_input\_capture\_edge\_t* captureMode)

Allows the user to count the source clock cycles until a capture event arrives.

The count is stored in the capture register.

#### Parameters

- `base` – Quad Timer peripheral base address
- `capturePin` – Pin through which we receive the input signal to trigger the capture
- `inputPolarity` – `true`: invert polarity of the input signal, `false`: no inversion
- `reloadOnCapture` – `true`: reload the counter when an input capture occurs, `false`: no reload
- `captureMode` – Specifies which edge of the input signal triggers a capture

`struct __qtmr_config`

`#include <fsl_qtmr.h>` Quad Timer config structure.

This structure holds the configuration settings for the Quad Timer peripheral. To initialize this structure to reasonable defaults, call the `QTMR_GetDefaultConfig()` function and pass a pointer to your config structure instance.

The config struct can be made `const` so it resides in flash

### Public Members

`qtmr_primary_count_source_t` primarySource

Specify the primary count source

`qtmr_input_source_t` secondarySource

Specify the secondary count source

`bool` enableMasterMode

`true`: Broadcast compare function output to other counters; `false` no broadcast

`bool` enableExternalForce

`true`: Compare from another counter force state of OFLAG signal `false`: OFLAG controlled by local counter

`uint8_t` faultFilterCount

Fault filter count

`uint8_t` faultFilterPeriod

Fault filter period; value of 0 will bypass the filter

`qtmr_debug_action_t` debugMode

Operation in Debug mode

## 2.32 RCM: Reset Control Module Driver

`static inline void RCM_GetVersionId(RCM_Type *base, rcm_version_id_t *versionId)`

Gets the RCM version ID.

This function gets the RCM version ID including the major version number, the minor version number, and the feature specification number.

### Parameters

- `base` – RCM peripheral base address.
- `versionId` – Pointer to the version ID structure.

```
static inline uint32_t RCM_GetResetSourceImplementedStatus(RCM_Type *base)
```

Gets the reset source implemented status.

This function gets the RCM parameter that indicates whether the corresponding reset source is implemented. Use source masks defined in the `rcm_reset_source_t` to get the desired source status.

This is an example.

```
uint32_t status;
```

To test whether the MCU is reset using Watchdog.

```
status = RCM_GetResetSourceImplementedStatus(RCM) & (kRCM_SourceWdog | kRCM_SourcePin);
```

### Parameters

- base – RCM peripheral base address.

### Returns

All reset source implemented status bit map.

```
static inline uint32_t RCM_GetPreviousResetSources(RCM_Type *base)
```

Gets the reset source status which caused a previous reset.

This function gets the current reset source status. Use source masks defined in the `rcm_reset_source_t` to get the desired source status.

This is an example.

```
uint32_t resetStatus;
```

To get all reset source statuses.

```
resetStatus = RCM_GetPreviousResetSources(RCM) & kRCM_SourceAll;
```

To test whether the MCU is reset using Watchdog.

```
resetStatus = RCM_GetPreviousResetSources(RCM) & kRCM_SourceWdog;
```

To test multiple reset sources.

```
resetStatus = RCM_GetPreviousResetSources(RCM) & (kRCM_SourceWdog | kRCM_SourcePin);
```

### Parameters

- base – RCM peripheral base address.

### Returns

All reset source status bit map.

```
static inline uint32_t RCM_GetStickyResetSources(RCM_Type *base)
```

Gets the sticky reset source status.

This function gets the current reset source status that has not been cleared by software for a specific source.

This is an example.

```
uint32_t resetStatus;
```

To get all reset source statuses.

```
resetStatus = RCM_GetStickyResetSources(RCM) & kRCM_SourceAll;
```

To test whether the MCU is reset using Watchdog.

```
resetStatus = RCM_GetStickyResetSources(RCM) & kRCM_SourceWdog;
```

To test multiple reset sources.

```
resetStatus = RCM_GetStickyResetSources(RCM) & (kRCM_SourceWdog | kRCM_SourcePin);
```

**Parameters**

- base – RCM peripheral base address.

**Returns**

All reset source status bit map.

```
static inline void RCM_ClearStickyResetSources(RCM_Type *base, uint32_t sourceMasks)
```

Clears the sticky reset source status.

This function clears the sticky system reset flags indicated by source masks.

This is an example.

Clears multiple reset sources.

```
RCM_ClearStickyResetSources(kRCM_SourceWdog | kRCM_SourcePin);
```

**Parameters**

- base – RCM peripheral base address.
- sourceMasks – reset source status bit map

```
void RCM_ConfigureResetPinFilter(RCM_Type *base, const rcm_reset_pin_filter_config_t *config)
```

Configures the reset pin filter.

This function sets the reset pin filter including the filter source, filter width, and so on.

**Parameters**

- base – RCM peripheral base address.
- config – Pointer to the configuration structure.

```
static inline bool RCM_GetEasyPortModePinStatus(RCM_Type *base)
```

Gets the EZP\_MS\_B pin assert status.

This function gets the easy port mode status (EZP\_MS\_B) pin assert status.

**Parameters**

- base – RCM peripheral base address.

**Returns**

status true - asserted, false - reasserted

```
static inline rcm_boot_rom_config_t RCM_GetBootRomSource(RCM_Type *base)
```

Gets the ROM boot source.

This function gets the ROM boot source during the last chip reset.

**Parameters**

- base – RCM peripheral base address.

**Returns**

The ROM boot source.

```
static inline void RCM_ClearBootRomSource(RCM_Type *base)
```

Clears the ROM boot source flag.

This function clears the ROM boot source flag.

**Parameters**

- base – Register base address of RCM

```
void RCM_SetForceBootRomSource(RCM_Type *base, rcm_boot_rom_config_t config)
```

Forces the boot from ROM.

This function forces booting from ROM during all subsequent system resets.

#### Parameters

- base – RCM peripheral base address.
- config – Boot configuration.

```
static inline void RCM_SetSystemResetInterruptConfig(RCM_Type *base, uint32_t intMask,  
                                                    rcm_reset_delay_t delay)
```

Sets the system reset interrupt configuration.

For a graceful shut down, the RCM supports delaying the assertion of the system reset for a period of time when the reset interrupt is generated. This function can be used to enable the interrupt and the delay period. The interrupts are passed in as bit mask. See `rcm_int_t` for details. For example, to delay a reset for 512 LPO cycles after the WDOG timeout or loss-of-clock occurs, configure as follows: `RCM_SetSystemResetInterruptConfig(kRCM_IntWatchDog | kRCM_IntLossOfClk, kRCM_ResetDelay512Lpo);`

#### Parameters

- base – RCM peripheral base address.
- intMask – Bit mask of the system reset interrupts to enable. See `rcm_interrupt_enable_t` for details.
- delay – Bit mask of the system reset interrupts to enable.

```
FSL_RCM_DRIVER_VERSION
```

RCM driver version 2.0.5.

```
enum _rcm_reset_source
```

System Reset Source Name definitions.

*Values:*

```
enumerator kRCM_SourceWakeup
```

Low-leakage wakeup reset

```
enumerator kRCM_SourceLvd
```

Low-voltage detect reset

```
enumerator kRCM_SourceLoc
```

Loss of clock reset

```
enumerator kRCM_SourceLol
```

Loss of lock reset

```
enumerator kRCM_SourceWdog
```

Watchdog reset

```
enumerator kRCM_SourcePin
```

External pin reset

```
enumerator kRCM_SourcePor
```

Power on reset

```
enumerator kRCM_SourceJtag
```

JTAG generated reset

```
enumerator kRCM_SourceLockup
```

Core lock up reset

enumerator kRCM\_SourceSw  
Software reset

enumerator kRCM\_SourceMdmmap  
MDM-AP system reset

enumerator kRCM\_SourceEzpt  
EzPort reset

enumerator kRCM\_SourceSackerr  
Parameter could get all reset flags

enumerator kRCM\_SourceAll

enum \_rcm\_run\_wait\_filter\_mode  
Reset pin filter select in Run and Wait modes.

*Values:*

enumerator kRCM\_FilterDisable  
All filtering disabled

enumerator kRCM\_FilterBusClock  
Bus clock filter enabled

enumerator kRCM\_FilterLpoClock  
LPO clock filter enabled

enum \_rcm\_boot\_rom\_config  
Boot from ROM configuration.

*Values:*

enumerator kRCM\_BootFlash  
Boot from flash

enumerator kRCM\_BootRomCfg0  
Boot from boot ROM due to BOOTCFG0

enumerator kRCM\_BootRomFopt  
Boot from boot ROM due to FOPT[7]

enumerator kRCM\_BootRomBoth  
Boot from boot ROM due to both BOOTCFG0 and FOPT[7]

enum \_rcm\_reset\_delay  
Maximum delay time from interrupt asserts to system reset.

*Values:*

enumerator kRCM\_ResetDelay8Lpo  
Delay 8 LPO cycles.

enumerator kRCM\_ResetDelay32Lpo  
Delay 32 LPO cycles.

enumerator kRCM\_ResetDelay128Lpo  
Delay 128 LPO cycles.

enumerator kRCM\_ResetDelay512Lpo  
Delay 512 LPO cycles.

enum `_rcm_interrupt_enable`

System reset interrupt enable bit definitions.

*Values:*

enumerator `kRCM_IntNone`

No interrupt enabled.

enumerator `kRCM_IntLossOfClk`

Loss of clock interrupt.

enumerator `kRCM_IntLossOfLock`

Loss of lock interrupt.

enumerator `kRCM_IntWatchDog`

Watch dog interrupt.

enumerator `kRCM_IntExternalPin`

External pin interrupt.

enumerator `kRCM_IntGlobal`

Global interrupts.

enumerator `kRCM_IntCoreLockup`

Core lock up interrupt

enumerator `kRCM_IntSoftware`

software interrupt

enumerator `kRCM_IntStopModeAckErr`

Stop mode ACK error interrupt.

enumerator `kRCM_IntCore1`

Core 1 interrupt.

enumerator `kRCM_IntAll`

Enable all interrupts.

typedef enum `_rcm_reset_source` `rcm_reset_source_t`

System Reset Source Name definitions.

typedef enum `_rcm_run_wait_filter_mode` `rcm_run_wait_filter_mode_t`

Reset pin filter select in Run and Wait modes.

typedef enum `_rcm_boot_rom_config` `rcm_boot_rom_config_t`

Boot from ROM configuration.

typedef enum `_rcm_reset_delay` `rcm_reset_delay_t`

Maximum delay time from interrupt asserts to system reset.

typedef enum `_rcm_interrupt_enable` `rcm_interrupt_enable_t`

System reset interrupt enable bit definitions.

typedef struct `_rcm_version_id` `rcm_version_id_t`

IP version ID definition.

typedef struct `_rcm_reset_pin_filter_config` `rcm_reset_pin_filter_config_t`

Reset pin filter configuration.

struct `_rcm_version_id`

`#include <fsl_rcm.h>` IP version ID definition.

**Public Members**

uint16\_t feature  
Feature Specification Number.

uint8\_t minor  
Minor version number.

uint8\_t major  
Major version number.

struct \_rcm\_reset\_pin\_filter\_config  
*#include <fsl\_rcm.h>* Reset pin filter configuration.

**Public Members**

bool enableFilterInStop  
Reset pin filter select in stop mode.

rcm\_run\_wait\_filter\_mode\_t filterInRunWait  
Reset pin filter in run/wait mode.

uint8\_t busClockFilterCount  
Reset pin bus clock filter width.

## 2.33 RNGA: Random Number Generator Accelerator Driver

FSL\_RNGA\_DRIVER\_VERSION  
RNGA driver version 2.0.2.

enum \_rnga\_mode  
RNGA working mode.

*Values:*

enumerator kRNGA\_ModeNormal  
Normal Mode. The ring-oscillator clocks are active; RNGA generates entropy (randomness) from the clocks and stores it in shift registers.

enumerator kRNGA\_ModeSleep  
Sleep Mode. The ring-oscillator clocks are inactive; RNGA does not generate entropy.

typedef enum \_rnga\_mode rnga\_mode\_t  
RNGA working mode.

void RNGA\_Init(RNG\_Type \*base)  
Initializes the RNGA.

This function initializes the RNGA. When called, the RNGA entropy generation starts immediately.

**Parameters**

- base – RNGA base address

void RNGA\_Deinit(RNG\_Type \*base)  
Shuts down the RNGA.

This function shuts down the RNGA.

**Parameters**

- base – RNGA base address

*status\_t* RNGA\_GetRandomData(RNG\_Type \*base, void \*data, size\_t data\_size)

Gets random data.

This function gets random data from the RNGA.

#### Parameters

- base – RNGA base address
- data – pointer to user buffer to be filled by random data
- data\_size – size of data in bytes

#### Returns

RNGA status

void RNGA\_Seed(RNG\_Type \*base, uint32\_t seed)

Feeds the RNGA module.

This function inputs an entropy value that the RNGA uses to seed its pseudo-random algorithm.

#### Parameters

- base – RNGA base address
- seed – input seed value

void RNGA\_SetMode(RNG\_Type \*base, *rnga\_mode\_t* mode)

Sets the RNGA in normal mode or sleep mode.

This function sets the RNGA in sleep mode or normal mode.

#### Parameters

- base – RNGA base address
- mode – normal mode or sleep mode

*rnga\_mode\_t* RNGA\_GetMode(RNG\_Type \*base)

Gets the RNGA working mode.

This function gets the RNGA working mode.

#### Parameters

- base – RNGA base address

#### Returns

normal mode or sleep mode

## 2.34 SIM: System Integration Module Driver

FSL\_SIM\_DRIVER\_VERSION

Driver version.

enum \_sim\_usb\_volt\_reg\_enable\_mode

USB voltage regulator enable setting.

*Values:*

enumerator kSIM\_UsbVoltRegEnable

Enable voltage regulator.

enumerator kSIM\_UsbVoltRegEnableInLowPower

Enable voltage regulator in VLPR/VLPW modes.

enumerator kSIM\_UsbVoltRegEnableInStop

Enable voltage regulator in STOP/VLPS/LLS/VLLS modes.

enumerator kSIM\_UsbVoltRegEnableInAllModes

Enable voltage regulator in all power modes.

enum \_sim\_flash\_mode

Flash enable mode.

*Values:*

enumerator kSIM\_FlashDisableInWait

Disable flash in wait mode.

enumerator kSIM\_FlashDisable

Disable flash in normal mode.

typedef struct \_sim\_uid sim\_uid\_t

Unique ID.

void SIM\_SetUsbVoltRegulatorEnableMode(uint32\_t mask)

Sets the USB voltage regulator setting.

This function configures whether the USB voltage regulator is enabled in normal RUN mode, STOP/VLPS/LLS/VLLS modes, and VLPR/VLPW modes. The configurations are passed in as mask value of \_sim\_usb\_volt\_reg\_enable\_mode. For example, to enable USB voltage regulator in RUN/VLPR/VLPW modes and disable in STOP/VLPS/LLS/VLLS mode, use:

```
SIM_SetUsbVoltRegulatorEnableMode(kSIM_UsbVoltRegEnable  
kSIM_UsbVoltRegEnableInLowPower);
```

#### Parameters

- mask – USB voltage regulator enable setting.

void SIM\_GetUniqueId(sim\_uid\_t \*uid)

Gets the unique identification register value.

#### Parameters

- uid – Pointer to the structure to save the UID value.

static inline void SIM\_SetFlashMode(uint8\_t mode)

Sets the flash enable mode.

#### Parameters

- mode – The mode to set; see \_sim\_flash\_mode for mode details.

struct \_sim\_uid

#include <fsl\_sim.h> Unique ID.

### Public Members

uint32\_t H

UIDH.

uint32\_t M

SIM\_UIDM.

uint32\_t L

UIDL.

## 2.35 SLCD: Segment LCD Driver

**void SLCD\_Init(LCD\_Type \*base, *slcd\_config\_t* \*configure)**

Initializes the SLCD, ungates the module clock, initializes the power setting, enables all used plane pins, and sets with interrupt and work mode with the configuration.

### Parameters

- *base* – SLCD peripheral base address.
- *configure* – SLCD configuration pointer. For the configuration structure, many parameters have the default setting and the `SLCD_Getdefaultconfig()` is provided to get them. Use it verified for their applications. The others have no default settings, such as “clk-Config”, and must be provided by the application before calling the `SLCD_Init()` API.

**void SLCD\_Deinit(LCD\_Type \*base)**

Deinitializes the SLCD module, gates the module clock, disables an interrupt, and displays the SLCD.

### Parameters

- *base* – SLCD peripheral base address.

**void SLCD\_GetDefaultConfig(*slcd\_config\_t* \*configure)**

Gets the SLCD default configuration structure. The purpose of this API is to get default parameters of the configuration structure for the `SLCD_Init()`. Use these initialized parameters unchanged in `SLCD_Init()` or modify fields of the structure before the calling `SLCD_Init()`. All default parameters of the configure structuration are listed.

```
config.displayMode      = kSLCD_NormalMode;
config.powerSupply      = kSLCD_InternalV13UseChargePump;
config.voltageTrim      = kSLCD_RegulatedVoltageTrim00;
config.lowPowerBehavior = kSLCD_EnabledInWaitStop;
config.interruptSrc      = 0;
config.faultConfig      = NULL;
config.frameFreqIntEnable = false;
```

### Parameters

- *configure* – The SLCD configuration structure pointer.

**static inline void SLCD\_StartDisplay(LCD\_Type \*base)**

Enables the SLCD controller, starts generation, and displays the front plane and back plane waveform.

### Parameters

- *base* – SLCD peripheral base address.

**static inline void SLCD\_StopDisplay(LCD\_Type \*base)**

Stops the SLCD controller. There is no waveform generator and all enabled pins only output a low value.

### Parameters

- *base* – SLCD peripheral base address.

**void SLCD\_StartBlinkMode(LCD\_Type \*base, *slcd\_blink\_mode\_t* mode, *slcd\_blink\_rate\_t* rate)**

Starts the SLCD blink mode.

### Parameters

- base – SLCD peripheral base address.
- mode – SLCD blink mode.
- rate – SLCD blink rate.

static inline void SLCD\_StopBlinkMode(LCD\_Type \*base)

Stops the SLCD blink mode.

#### Parameters

- base – SLCD peripheral base address.

static inline void SLCD\_SetBackPlanePhase(LCD\_Type \*base, uint32\_t pinIndx,  
slcd\_phase\_type\_t phase)

Sets the SLCD back plane pin phase.

This function sets the SLCD back plane pin phase. “kSLCD\_PhaseXActivate” setting means the phase X is active for the back plane pin. “kSLCD\_NoPhaseActivate” setting means there is no phase active for the back plane pin. For example, set the back plane pin 20 for phase A.

```
SLCD_SetBackPlanePhase(LCD, 20, kSLCD_PhaseAActivate);
```

#### Parameters

- base – SLCD peripheral base address.
- pinIndx – SLCD back plane pin index. Range from 0 to 63.
- phase – The phase activates for the back plane pin.

static inline void SLCD\_SetFrontPlaneSegments(LCD\_Type \*base, uint32\_t pinIndx, uint8\_t  
operation)

Sets the SLCD front plane segment operation for a front plane pin.

This function sets the SLCD front plane segment on or off operation. Each bit turns on or off the segments associated with the front plane pin in the following pattern: HGFEDCBA (most significant bit controls segment H and least significant bit controls segment A). For example, turn on the front plane pin 20 for phase B and phase C.

```
SLCD_SetFrontPlaneSegments(LCD, 20, (kSLCD_PhaseBActivate | kSLCD_PhaseCActivate));
```

#### Parameters

- base – SLCD peripheral base address.
- pinIndx – SLCD back plane pin index. Range from 0 to 63.
- operation – The operation for the segment on the front plane pin. This is a logical OR of the enumeration :: slcd\_phase\_type\_t.

static inline void SLCD\_SetFrontPlaneOnePhase(LCD\_Type \*base, uint32\_t pinIndx,  
slcd\_phase\_index\_t phaseIndx, bool enable)

Sets one SLCD front plane pin for one phase.

This function can be used to set one phase on or off for the front plane pin. It can be call many times to set the plane pin for different phase indexes. For example, turn on the front plane pin 20 for phase B and phase C.

```
SLCD_SetFrontPlaneOnePhase(LCD, 20, kSLCD_PhaseBIndex, true);  
SLCD_SetFrontPlaneOnePhase(LCD, 20, kSLCD_PhaseCIndex, true);
```

#### Parameters

- base – SLCD peripheral base address.

- pinIndx – SLCD back plane pin index. Range from 0 to 63.
- phaseIndx – The phase bit index slcd\_phase\_index\_t.
- enable – True to turn on the segment for phaseIndx phase false to turn off the segment for phaseIndx phase.

static inline void SLCD\_EnablePadSafeState(LCD\_Type \*base, bool enable)

Enables/disables the SLCD pad safe state.

Forces the safe state on the LCD pad controls. All LCD front plane and backplane functions are disabled.

#### Parameters

- base – SLCD peripheral base address.
- enable – True enable, false disable.

static inline uint32\_t SLCD\_GetFaultDetectCounter(LCD\_Type \*base)

Gets the SLCD fault detect counter.

This function gets the number of samples inside the fault detection sample window.

#### Parameters

- base – SLCD peripheral base address.

#### Returns

The fault detect counter. The maximum return value is 255. If the maximum 255 returns, the overflow may happen. Reconfigure the fault detect sample window and fault detect clock prescaler for proper sampling.

void SLCD\_EnableInterrupts(LCD\_Type \*base, uint32\_t mask)

Enables the SLCD interrupt. For example, to enable fault detect complete interrupt and frame frequency interrupt, for FSL\_FEATURE\_SLCD\_HAS\_FRAME\_FREQUENCY\_INTERRUPT enabled case, do the following.

```
SLCD_EnableInterrupts(LCD, kSLCD_FaultDetectCompleteInterrupt | kSLCD_FrameFreqInterrupt);
```

#### Parameters

- base – SLCD peripheral base address.
- mask – SLCD interrupts to enable. This is a logical OR of the enumeration :: slcd\_interrupt\_enable\_t.

void SLCD\_DisableInterrupts(LCD\_Type \*base, uint32\_t mask)

Disables the SLCD interrupt. For example, to disable fault detect complete interrupt and frame frequency interrupt, for FSL\_FEATURE\_SLCD\_HAS\_FRAME\_FREQUENCY\_INTERRUPT enabled case, do the following.

```
SLCD_DisableInterrupts(LCD, kSLCD_FaultDetectCompleteInterrupt | kSLCD_FrameFreqInterrupt);
```

#### Parameters

- base – SLCD peripheral base address.
- mask – SLCD interrupts to disable. This is a logical OR of the enumeration :: slcd\_interrupt\_enable\_t.

uint32\_t SLCD\_GetInterruptStatus(LCD\_Type \*base)

Gets the SLCD interrupt status flag.

#### Parameters

- base – SLCD peripheral base address.

**Returns**

The event status of the interrupt source. This is the logical OR of members of the enumeration :: slcd\_interrupt\_enable\_t.

void SLCD\_ClearInterruptStatus(LCD\_Type \*base, uint32\_t mask)

Clears the SLCD interrupt events status flag.

**Parameters**

- base – SLCD peripheral base address.
- mask – SLCD interrupt source to be cleared. This is the logical OR of members of the enumeration :: slcd\_interrupt\_enable\_t.

FSL\_SLCD\_DRIVER\_VERSION

SLCD driver version.

enum \_slcd\_clock\_prescaler

SLCD clock prescaler to generate frame frequency.

*Values:*

enumerator kSLCD\_ClkPrescaler00  
Prescaler 0.

enumerator kSLCD\_ClkPrescaler01  
Prescaler 1.

enumerator kSLCD\_ClkPrescaler02  
Prescaler 2.

enumerator kSLCD\_ClkPrescaler03  
Prescaler 3.

enumerator kSLCD\_ClkPrescaler04  
Prescaler 4.

enumerator kSLCD\_ClkPrescaler05  
Prescaler 5.

enumerator kSLCD\_ClkPrescaler06  
Prescaler 6.

enumerator kSLCD\_ClkPrescaler07  
Prescaler 7.

enum \_slcd\_blink\_rate

SLCD blink rate.

*Values:*

enumerator kSLCD\_BlinkRate00  
SLCD blink rate is LCD clock/((2<sup>12</sup>)).

enumerator kSLCD\_BlinkRate01  
SLCD blink rate is LCD clock/((2<sup>13</sup>)).

enumerator kSLCD\_BlinkRate02  
SLCD blink rate is LCD clock/((2<sup>14</sup>)).

enumerator kSLCD\_BlinkRate03  
SLCD blink rate is LCD clock/((2<sup>15</sup>)).

enumerator kSLCD\_BlinkRate04  
SLCD blink rate is LCD clock/((2<sup>16</sup>)).

enumerator kSLCD\_BlinkRate05  
SLCD blink rate is LCD clock/((2<sup>17</sup>)).

enumerator kSLCD\_BlinkRate06  
SLCD blink rate is LCD clock/((2<sup>18</sup>)).

enumerator kSLCD\_BlinkRate07  
SLCD blink rate is LCD clock/((2<sup>19</sup>)).

enum \_slcd\_power\_supply\_option  
SLCD power supply option.

*Values:*

enumerator kSLCD\_InternalVll3UseChargePump  
VLL3 connected to VDD internally, charge pump is used to generate VLL1 and VLL2.

enumerator kSLCD\_ExternalVll3UseResistorBiasNetwork  
VLL3 is driven externally and resistor bias network is used to generate VLL1 and VLL2.

enumerator kSLCD\_ExteranlVll3UseChargePump  
VLL3 is driven externally and charge pump is used to generate VLL1 and VLL2.

enumerator kSLCD\_InternalVll1UseChargePump  
VIREG is connected to VLL1 internally and charge pump is used to generate VLL2 and VLL3.

enum \_slcd\_regulated\_voltage\_trim  
SLCD regulated voltage trim parameter, be used to meet the desired contrast.

*Values:*

enumerator kSLCD\_RegulatedVolatgeTrim00  
Increase the voltage to 0.91 V.

enumerator kSLCD\_RegulatedVolatgeTrim01  
Increase the voltage to 1.01 V.

enumerator kSLCD\_RegulatedVolatgeTrim02  
Increase the voltage to 0.96 V.

enumerator kSLCD\_RegulatedVolatgeTrim03  
Increase the voltage to 1.06 V.

enumerator kSLCD\_RegulatedVolatgeTrim04  
Increase the voltage to 0.93 V.

enumerator kSLCD\_RegulatedVolatgeTrim05  
Increase the voltage to 1.03 V.

enumerator kSLCD\_RegulatedVolatgeTrim06  
Increase the voltage to 0.98 V.

enumerator kSLCD\_RegulatedVolatgeTrim07  
Increase the voltage to 1.07 V.

enumerator kSLCD\_RegulatedVolatgeTrim08  
Increase the voltage to 0.92 V.

enumerator kSLCD\_RegulatedVolatgeTrim09  
Increase the voltage to 1.02 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim10

Increase the voltage to 0.97 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim11

Increase the voltage to 1.08 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim12

Increase the voltage to 0.94 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim13

Increase the voltage to 1.05 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim14

Increase the voltage to 0.99 V.

enumerator kSLCD\_\_RegulatedVolatgeTrim15

Increase the voltage to 1.09 V.

enum \_slcd\_load\_adjust

SLCD load adjust to handle different LCD glass capacitance or configure the LCD charge pump clock source. Adjust the LCD glass capacitance if resistor bias network is enabled: kSLCD\_LowLoadOrFastestClkSrc - Low load (LCD glass capacitance 2000pF or lower. LCD or GPIO function can be used on VLL1,VLL2,Vcap1 and Vcap2 pins) kSLCD\_LowLoadOrIntermediateClkSrc - low load (LCD glass capacitance 2000pF or lower. LCD or GPIO function can be used on VLL1,VLL2,Vcap1 and Vcap2 pins) kSLCD\_HighLoadOrIntermediateClkSrc - high load (LCD glass capacitance 8000pF or lower. LCD or GPIO function can be used on Vcap1 and Vcap2 pins) kSLCD\_HighLoadOrSlowestClkSrc - high load (LCD glass capacitance 8000pF or lower LCD or GPIO function can be used on Vcap1 and Vcap2 pins) Adjust clock for charge pump if charge pump is enabled: kSLCD\_LowLoadOrFastestClkSrc - Fasten clock source (LCD glass capacitance 8000pF or 4000pF or lower if Fast Frame Rate is set) kSLCD\_LowLoadOrIntermediateClkSrc - Intermediate clock source (LCD glass capacitance 4000pF or 2000pF or lower if Fast Frame Rate is set) kSLCD\_HighLoadOrIntermediateClkSrc - Intermediate clock source (LCD glass capacitance 2000pF or 1000pF or lower if Fast Frame Rate is set) kSLCD\_HighLoadOrSlowestClkSrc - slowest clock source (LCD glass capacitance 1000pF or 500pF or lower if Fast Frame Rate is set)

*Values:*

enumerator kSLCD\_\_LowLoadOrFastestClkSrc

Adjust in low load or selects fastest clock.

enumerator kSLCD\_\_LowLoadOrIntermediateClkSrc

Adjust in low load or selects intermediate clock.

enumerator kSLCD\_\_HighLoadOrIntermediateClkSrc

Adjust in high load or selects intermediate clock.

enumerator kSLCD\_\_HighLoadOrSlowestClkSrc

Adjust in high load or selects slowest clock.

enum \_slcd\_clock\_src

SLCD clock source.

*Values:*

enumerator kSLCD\_\_DefaultClk

Select default clock ERCLK32K.

enumerator kSLCD\_\_AlternateClk1

Select alternate clock source 1 : MCGIRCLK.

enumerator kSLCD\_AlternateClk2

Select alternate clock source 2 : OSCERCLK.

enum \_slcd\_alt\_clock\_div

SLCD alternate clock divider.

*Values:*

enumerator kSLCD\_AltClkDivFactor1

No divide for alternate clock.

enumerator kSLCD\_AltClkDivFactor64

Divide alternate clock with factor 64.

enumerator kSLCD\_AltClkDivFactor256

Divide alternate clock with factor 256.

enumerator kSLCD\_AltClkDivFactor512

Divide alternate clock with factor 512.

enum \_slcd\_duty\_cycle

SLCD duty cycle.

*Values:*

enumerator kSLCD\_1Div1DutyCycle

LCD use 1 BP 1/1 duty cycle.

enumerator kSLCD\_1Div2DutyCycle

LCD use 2 BP 1/2 duty cycle.

enumerator kSLCD\_1Div3DutyCycle

LCD use 3 BP 1/3 duty cycle.

enumerator kSLCD\_1Div4DutyCycle

LCD use 4 BP 1/4 duty cycle.

enumerator kSLCD\_1Div5DutyCycle

LCD use 5 BP 1/5 duty cycle.

enumerator kSLCD\_1Div6DutyCycle

LCD use 6 BP 1/6 duty cycle.

enumerator kSLCD\_1Div7DutyCycle

LCD use 7 BP 1/7 duty cycle.

enumerator kSLCD\_1Div8DutyCycle

LCD use 8 BP 1/8 duty cycle.

enum \_slcd\_phase\_type

SLCD segment phase type.

*Values:*

enumerator kSLCD\_NoPhaseActivate

LCD waveform no phase activates.

enumerator kSLCD\_PhaseAActivate

LCD waveform phase A activates.

enumerator kSLCD\_PhaseBActivate

LCD waveform phase B activates.

enumerator kSLCD\_PhaseCActivate  
LCD waveform phase C activates.

enumerator kSLCD\_PhaseDActivate  
LCD waveform phase D activates.

enumerator kSLCD\_PhaseEActivate  
LCD waveform phase E activates.

enumerator kSLCD\_PhaseFActivate  
LCD waveform phase F activates.

enumerator kSLCD\_PhaseGActivate  
LCD waveform phase G activates.

enumerator kSLCD\_PhaseHActivate  
LCD waveform phase H activates.

enum \_slcd\_phase\_index  
SLCD segment phase bit index.

*Values:*

enumerator kSLCD\_PhaseAIndex  
LCD phase A bit index.

enumerator kSLCD\_PhaseBIndex  
LCD phase B bit index.

enumerator kSLCD\_PhaseCIndex  
LCD phase C bit index.

enumerator kSLCD\_PhaseDIndex  
LCD phase D bit index.

enumerator kSLCD\_PhaseEIndex  
LCD phase E bit index.

enumerator kSLCD\_PhaseFIndex  
LCD phase F bit index.

enumerator kSLCD\_PhaseGIndex  
LCD phase G bit index.

enumerator kSLCD\_PhaseHIndex  
LCD phase H bit index.

enum \_slcd\_display\_mode  
SLCD display mode.

*Values:*

enumerator kSLCD\_NormalMode  
LCD Normal display mode.

enumerator kSLCD\_AlternateMode  
LCD Alternate display mode. For four back planes or less.

enumerator kSLCD\_BlankMode  
LCD Blank display mode.

enum \_slcd\_blink\_mode  
SLCD blink mode.

*Values:*

enumerator kSLCD\_BlankDisplayBlink

Display blank during the blink period.

enumerator kSLCD\_AltDisplayBlink

Display alternate display during the blink period if duty cycle is lower than 5.

enum \_slcd\_fault\_detect\_clock\_prescaler

SLCD fault detect clock prescaler.

*Values:*

enumerator kSLCD\_FaultSampleFreqDivider1

Fault detect sample clock frequency is 1/1 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider2

Fault detect sample clock frequency is 1/2 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider4

Fault detect sample clock frequency is 1/4 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider8

Fault detect sample clock frequency is 1/8 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider16

Fault detect sample clock frequency is 1/16 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider32

Fault detect sample clock frequency is 1/32 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider64

Fault detect sample clock frequency is 1/64 bus clock.

enumerator kSLCD\_FaultSampleFreqDivider128

Fault detect sample clock frequency is 1/128 bus clock.

enum \_slcd\_fault\_detect\_sample\_window\_width

SLCD fault detect sample window width.

*Values:*

enumerator kSLCD\_FaultDetectWindowWidth4SampleClk

Sample window width is 4 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth8SampleClk

Sample window width is 8 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth16SampleClk

Sample window width is 16 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth32SampleClk

Sample window width is 32 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth64SampleClk

Sample window width is 64 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth128SampleClk

Sample window width is 128 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth256SampleClk

Sample window width is 256 sample clock cycles.

enumerator kSLCD\_FaultDetectWindowWidth512SampleClk

Sample window width is 512 sample clock cycles.

enum `_slcd_interrupt_enable`

SLCD interrupt source.

*Values:*

enumerator `kSLCD_FaultDetectCompleteInterrupt`

SLCD fault detection complete interrupt source.

enumerator `kSLCD_FrameFreqInterrupt`

SLCD frame frequency interrupt source. Not available in all low-power modes.

enum `_slcd_lowpower_behavior`

SLCD behavior in low power mode.

*Values:*

enumerator `kSLCD_EnabledInWaitStop`

SLCD works in wait and stop mode.

enumerator `kSLCD_EnabledInWaitOnly`

SLCD works in wait mode and is disabled in stop mode.

enumerator `kSLCD_EnabledInStopOnly`

SLCD works in stop mode and is disabled in wait mode.

enumerator `kSLCD_DisabledInWaitStop`

SLCD is disabled in stop mode and wait mode.

typedef enum `_slcd_clock_prescaler` `slcd_clock_prescaler_t`

SLCD clock prescaler to generate frame frequency.

typedef enum `_slcd_blink_rate` `slcd_blink_rate_t`

SLCD blink rate.

typedef enum `_slcd_power_supply_option` `slcd_power_supply_option_t`

SLCD power supply option.

typedef enum `_slcd_regulated_voltage_trim` `slcd_regulated_voltage_trim_t`

SLCD regulated voltage trim parameter, be used to meet the desired contrast.

typedef enum `_slcd_load_adjust` `slcd_load_adjust_t`

SLCD load adjust to handle different LCD glass capacitance or configure the LCD charge pump clock source. Adjust the LCD glass capacitance if resistor bias network is enabled: `kSLCD_LowLoadOrFastestClkSrc` - Low load (LCD glass capacitance 2000pF or lower. LCD or GPIO function can be used on VLL1,VLL2,Vcap1 and Vcap2 pins) `kSLCD_LowLoadOrIntermediateClkSrc` - low load (LCD glass capacitance 2000pF or lower. LCD or GPIO function can be used on VLL1,VLL2,Vcap1 and Vcap2 pins) `kSLCD_HighLoadOrIntermediateClkSrc` - high load (LCD glass capacitance 8000pF or lower. LCD or GPIO function can be used on Vcap1 and Vcap2 pins) `kSLCD_HighLoadOrSlowestClkSrc` - high load (LCD glass capacitance 8000pF or lower LCD or GPIO function can be used on Vcap1 and Vcap2 pins) Adjust clock for charge pump if charge pump is enabled: `kSLCD_LowLoadOrFastestClkSrc` - Fasten clock source (LCD glass capacitance 8000pF or 4000pF or lower if Fast Frame Rate is set) `kSLCD_LowLoadOrIntermediateClkSrc` - Intermediate clock source (LCD glass capacitance 4000pF or 2000pF or lower if Fast Frame Rate is set) `kSLCD_HighLoadOrIntermediateClkSrc` - Intermediate clock source (LCD glass capacitance 2000pF or 1000pF or lower if Fast Frame Rate is set) `kSLCD_HighLoadOrSlowestClkSrc` - slowest clock source (LCD glass capacitance 1000pF or 500pF or lower if Fast Frame Rate is set)

typedef enum `_slcd_clock_src` `slcd_clock_src_t`

SLCD clock source.

`typedef enum _slcd_alt_clock_div` `slcd_alt_clock_div_t`  
SLCD alternate clock divider.

`typedef struct _slcd_clock_config` `slcd_clock_config_t`  
SLCD clock configuration structure.

`typedef enum _slcd_duty_cycle` `slcd_duty_cycle_t`  
SLCD duty cycle.

`typedef enum _slcd_phase_type` `slcd_phase_type_t`  
SLCD segment phase type.

`typedef enum _slcd_phase_index` `slcd_phase_index_t`  
SLCD segment phase bit index.

`typedef enum _slcd_display_mode` `slcd_display_mode_t`  
SLCD display mode.

`typedef enum _slcd_blink_mode` `slcd_blink_mode_t`  
SLCD blink mode.

`typedef enum _slcd_fault_detect_clock_prescaler` `slcd_fault_detect_clock_prescaler_t`  
SLCD fault detect clock prescaler.

`typedef enum _slcd_fault_detect_sample_window_width`  
`slcd_fault_detect_sample_window_width_t`  
SLCD fault detect sample window width.

`typedef enum _slcd_interrupt_enable` `slcd_interrupt_enable_t`  
SLCD interrupt source.

`typedef enum _slcd_lowpower_behavior` `slcd_lowpower_behavior`  
SLCD behavior in low power mode.

`typedef struct _slcd_fault_detect_config` `slcd_fault_detect_config_t`  
SLCD fault frame detection configuration structure.

`typedef struct _slcd_config` `slcd_config_t`  
SLCD configuration structure.

`struct _slcd_clock_config`  
`#include <fsl_slcd.h>` SLCD clock configuration structure.

### Public Members

`slcd_clock_src_t` `clkSource`  
Clock source. “`slcd_clock_src_t`” is recommended to be used. The SLCD is optimized to operate using a 32.768kHz clock input.

`slcd_alt_clock_div_t` `altClkDivider`  
The divider to divide the alternate clock used for alternate clock source.

`slcd_clock_prescaler_t` `clkPrescaler`  
Clock prescaler.

`bool` `fastFrameRateEnable`  
Fast frame rate enable flag.

`struct _slcd_fault_detect_config`  
`#include <fsl_slcd.h>` SLCD fault frame detection configuration structure.

### Public Members

bool faultDetectIntEnable

Fault frame detection interrupt enable flag.

bool faultDetectBackPlaneEnable

True means the pin id fault detected is back plane otherwise front plane.

uint8\_t faultDetectPinIndex

Fault detected pin id from 0 to 63.

*slcd\_fault\_detect\_clock\_prescaler\_t* faultPrescaler

Fault detect clock prescaler.

*slcd\_fault\_detect\_sample\_window\_width\_t* width

Fault detect sample window width.

struct *\_slcd\_config*

*#include <fsl\_slcd.h>* SLCD configuration structure.

### Public Members

*slcd\_power\_supply\_option\_t* powerSupply

Power supply option.

*slcd\_regulated\_voltage\_trim\_t* voltageTrim

Regulated voltage trim used for the internal regulator VIREG to adjust to facilitate contrast control.

*slcd\_clock\_config\_t* \*clkConfig

Clock configure.

*slcd\_load\_adjust\_t* loadAdjust

Load adjust to handle glass capacitance.

*slcd\_display\_mode\_t* displayMode

SLCD display mode.

*slcd\_duty\_cycle\_t* dutyCycle

Duty cycle.

*slcd\_lowpower\_behavior* lowPowerBehavior

SLCD behavior in low power mode.

bool frameFreqIntEnable

Frame frequency interrupt enable flag.

uint32\_t slcdLowPinEnabled

Setting enabled SLCD pin 0 ~ pin 31. Setting bit n to 1 means enable pin n.

uint32\_t slcdHighPinEnabled

Setting enabled SLCD pin 32 ~ pin 63. Setting bit n to 1 means enable pin (n + 32).

uint32\_t backPlaneLowPin

Setting back plane pin 0 ~ pin 31. Setting bit n to 1 means setting pin n as back plane. It should never have the same bit setting as the frontPlane Pin.

uint32\_t backPlaneHighPin

Setting back plane pin 32 ~ pin 63. Setting bit n to 1 means setting pin (n + 32) as back plane. It should never have the same bit setting as the frontPlane Pin.

*slcd\_fault\_detect\_config\_t* \*faultConfig

Fault frame detection configure. If not requirement, set to NULL.

## 2.36 Smart Card

FSL\_SMARTCARD\_DRIVER\_VERSION

Smart card driver version 2.3.0.

Smart card Error codes.

*Values:*

enumerator kStatus\_SMARTCARD\_Success

Transfer ends successfully

enumerator kStatus\_SMARTCARD\_TxBusy

Transmit in progress

enumerator kStatus\_SMARTCARD\_RxBusy

Receiving in progress

enumerator kStatus\_SMARTCARD\_NoTransferInProgress

No transfer in progress

enumerator kStatus\_SMARTCARD\_Timeout

Transfer ends with time-out

enumerator kStatus\_SMARTCARD\_Initialized

Smart card driver is already initialized

enumerator kStatus\_SMARTCARD\_PhyInitialized

Smart card PHY drive is already initialized

enumerator kStatus\_SMARTCARD\_CardNotActivated

Smart card is not activated

enumerator kStatus\_SMARTCARD\_InvalidInput

Function called with invalid input arguments

enumerator kStatus\_SMARTCARD\_OtherError

Some other error occur

enum \_smartcard\_control

Control codes for the Smart card protocol timers and misc.

*Values:*

enumerator kSMARTCARD\_EnableADT

enumerator kSMARTCARD\_DisableADT

enumerator kSMARTCARD\_EnableGTV

enumerator kSMARTCARD\_DisableGTV

enumerator kSMARTCARD\_ResetWWT

enumerator kSMARTCARD\_EnableWWT

enumerator kSMARTCARD\_DisableWWT

enumerator kSMARTCARD\_ResetCWT

enumerator kSMARTCARD\_EnableCWT

enumerator kSMARTCARD\_DisableCWT  
enumerator kSMARTCARD\_ResetBWT  
enumerator kSMARTCARD\_EnableBWT  
enumerator kSMARTCARD\_DisableBWT  
enumerator kSMARTCARD\_EnableInitDetect  
enumerator kSMARTCARD\_EnableAnack  
enumerator kSMARTCARD\_DisableAnack  
enumerator kSMARTCARD\_ConfigureBaudrate  
enumerator kSMARTCARD\_SetupATRMMode  
enumerator kSMARTCARD\_SetupT0Mode  
enumerator kSMARTCARD\_SetupT1Mode  
enumerator kSMARTCARD\_EnableReceiverMode  
enumerator kSMARTCARD\_DisableReceiverMode  
enumerator kSMARTCARD\_EnableTransmitterMode  
enumerator kSMARTCARD\_DisableTransmitterMode  
enumerator kSMARTCARD\_ResetWaitTimeMultiplier

enum \_\_smartcard\_card\_voltage\_class  
Defines Smart card interface voltage class values.

*Values:*

enumerator kSMARTCARD\_VoltageClassUnknown  
enumerator kSMARTCARD\_VoltageClassA5\_0V  
enumerator kSMARTCARD\_VoltageClassB3\_3V  
enumerator kSMARTCARD\_VoltageClassC1\_8V

enum \_\_smartcard\_transfer\_state  
Defines Smart card I/O transfer states.

*Values:*

enumerator kSMARTCARD\_IdleState  
enumerator kSMARTCARD\_WaitingForTSSState  
enumerator kSMARTCARD\_InvalidTSDetectedState  
enumerator kSMARTCARD\_ReceivingState  
enumerator kSMARTCARD\_TransmittingState

enum \_\_smartcard\_reset\_type  
Defines Smart card reset types.

*Values:*

enumerator kSMARTCARD\_ColdReset

enumerator kSMARTCARD\_WarmReset

enumerator kSMARTCARD\_NoColdReset

enumerator kSMARTCARD\_NoWarmReset

enum *\_smartcard\_transport\_type*

Defines Smart card transport protocol types.

*Values:*

enumerator kSMARTCARD\_T0Transport

enumerator kSMARTCARD\_T1Transport

enum *\_smartcard\_parity\_type*

Defines Smart card data parity types.

*Values:*

enumerator kSMARTCARD\_EvenParity

enumerator kSMARTCARD\_OddParity

enum *\_smartcard\_card\_convention*

Defines data Convention format.

*Values:*

enumerator kSMARTCARD\_DirectConvention

enumerator kSMARTCARD\_InverseConvention

enum *\_smartcard\_interface\_control*

Defines Smart card interface IC control types.

*Values:*

enumerator kSMARTCARD\_InterfaceSetVcc

enumerator kSMARTCARD\_InterfaceSetClockToResetDelay

enumerator kSMARTCARD\_InterfaceReadStatus

enum *\_smartcard\_direction*

Defines transfer direction.

*Values:*

enumerator kSMARTCARD\_Receive

enumerator kSMARTCARD\_Transmit

typedef enum *\_smartcard\_control* smartcard\_control\_t

Control codes for the Smart card protocol timers and misc.

typedef enum *\_smartcard\_card\_voltage\_class* smartcard\_card\_voltage\_class\_t

Defines Smart card interface voltage class values.

typedef enum *\_smartcard\_transfer\_state* smartcard\_transfer\_state\_t

Defines Smart card I/O transfer states.

typedef enum *\_smartcard\_reset\_type* smartcard\_reset\_type\_t

Defines Smart card reset types.

```
typedef enum _smartcard_transport_type smartcard__transport__type__t
```

Defines Smart card transport protocol types.

```
typedef enum _smartcard_parity_type smartcard__parity__type__t
```

Defines Smart card data parity types.

```
typedef enum _smartcard_card_convention smartcard__card__convention__t
```

Defines data Convention format.

```
typedef enum _smartcard_interface_control smartcard__interface__control__t
```

Defines Smart card interface IC control types.

```
typedef enum _smartcard_direction smartcard__direction__t
```

Defines transfer direction.

```
typedef void (*smartcard__interface__callback__t)(void *smartcardContext, void *param)
```

Smart card interface interrupt callback function type.

```
typedef void (*smartcard__transfer__callback__t)(void *smartcardContext, void *param)
```

Smart card transfer interrupt callback function type.

```
typedef void (*smartcard__time__delay__t)(uint32_t us)
```

Time Delay function used to passive waiting using RTOS [us].

```
typedef struct _smartcard_card_params smartcard__card__params__t
```

Defines card-specific parameters for Smart card driver.

```
typedef struct _smartcard_timers_state smartcard__timers__state__t
```

Smart card defines the state of the EMV timers in the Smart card driver.

```
typedef struct _smartcard_interface_config smartcard__interface__config__t
```

Defines user specified configuration of Smart card interface.

```
typedef struct _smartcard_xfer smartcard__xfer__t
```

Defines user transfer structure used to initialize transfer.

```
typedef struct _smartcard_context smartcard__context__t
```

Runtime state of the Smart card driver.

```
SMARTCARD_INIT_DELAY_CLOCK_CYCLES
```

Smart card global define which specify number of clock cycles until initial 'TS' character has to be received.

```
SMARTCARD_EMV_ATR_DURATION_ETU
```

Smart card global define which specify number of clock cycles during which ATR string has to be received.

```
SMARTCARD_TS_DIRECT_CONVENTION
```

Smart card specification initial TS character definition of direct convention.

```
SMARTCARD_TS_INVERSE_CONVENTION
```

Smart card specification initial TS character definition of inverse convention.

```
struct _smartcard_card_params
```

*#include <fsl\_smartcard.h>* Defines card-specific parameters for Smart card driver.

## Public Members

```
uint16_t Fi
```

4 bits Fi - clock rate conversion integer

`uint8_t fMax`  
Maximum Smart card frequency in MHz

`uint8_t WI`  
8 bits WI - work wait time integer

`uint8_t Di`  
4 bits DI - baud rate divisor

`uint8_t BWI`  
4 bits BWI - block wait time integer

`uint8_t CWI`  
4 bits CWI - character wait time integer

`uint8_t BGI`  
4 bits BGI - block guard time integer

`uint8_t GTN`  
8 bits GTN - extended guard time integer

`uint8_t IFSC`  
Indicates IFSC value of the card

`uint8_t modeNegotiable`  
Indicates if the card acts in negotiable or a specific mode.

`uint8_t currentD`  
4 bits DI - current baud rate divisor

`uint8_t status`  
Indicates smart card status

`bool t0Indicated`  
Indicates if T=0 indicated in TD1 byte

`bool t1Indicated`  
Indicates if T=1 indicated in TD2 byte

`bool atrComplete`  
Indicates whether the ATR received from the card was complete or not

`bool atrValid`  
Indicates whether the ATR received from the card was valid or not

`bool present`  
Indicates if a smart card is present

`bool active`  
Indicates if the smart card is activated

`bool faulty`  
Indicates whether smart card/interface is faulty

`smartcard_card_convention_t convention`  
Card convention, `kSMARTCARD_DirectConvention` for direct convention, `kSMARTCARD_InverseConvention` for inverse convention

`struct __smartcard_timers_state`  
*#include <fsl\_smartcard.h>* Smart card defines the state of the EMV timers in the Smart card driver.

### Public Members

volatile bool adtExpired

Indicates whether ADT timer expired

volatile bool wwtExpired

Indicates whether WWT timer expired

volatile bool cwtExpired

Indicates whether CWT timer expired

volatile bool bwtExpired

Indicates whether BWT timer expired

volatile bool initCharTimerExpired

Indicates whether reception timer for initialization character (TS) after the RST has expired

struct \_smartcard\_interface\_config

*#include <fsl\_smartcard.h>* Defines user specified configuration of Smart card interface.

### Public Members

uint32\_t smartCardClock

Smart card interface clock [Hz]

uint32\_t clockToResetDelay

Indicates clock to RST apply delay [smart card clock cycles]

uint8\_t clockModule

Smart card clock module number

uint8\_t clockModuleChannel

Smart card clock module channel number

uint8\_t clockModuleSourceClock

Smart card clock module source clock [e.g., BusClk]

*smartcard\_card\_voltage\_class\_t* vcc

Smart card voltage class

uint8\_t controlPort

Smart card PHY control port instance

uint8\_t controlPin

Smart card PHY control pin instance

uint8\_t irqPort

Smart card PHY Interrupt port instance

uint8\_t irqPin

Smart card PHY Interrupt pin instance

uint8\_t resetPort

Smart card reset port instance

uint8\_t resetPin

Smart card reset pin instance

uint8\_t vsel0Port

Smart card PHY Vsel0 control port instance

`uint8_t vsel0Pin`  
Smart card PHY Vsel0 control pin instance

`uint8_t vsel1Port`  
Smart card PHY Vsel1 control port instance

`uint8_t vsel1Pin`  
Smart card PHY Vsel1 control pin instance

`uint8_t dataPort`  
Smart card PHY data port instance

`uint8_t dataPin`  
Smart card PHY data pin instance

`uint8_t dataPinMux`  
Smart card PHY data pin mux option

`uint8_t tsTimerId`  
Numerical identifier of the External HW timer for Initial character detection

`struct __smartcard_xfer`  
*#include <fsl\_smartcard.h>* Defines user transfer structure used to initialize transfer.

### Public Members

`smartcard_direction_t direction`  
Direction of communication. (RX/TX)

`uint8_t *buff`  
The buffer of data.

`size_t size`  
The number of transferred units.

`struct __smartcard_context`  
*#include <fsl\_smartcard.h>* Runtime state of the Smart card driver.

### Public Members

`void *base`  
Smart card module base address

`smartcard_direction_t direction`  
Direction of communication. (RX/TX)

`uint8_t *xBuff`  
The buffer of data being transferred.

`volatile size_t xSize`  
The number of bytes to be transferred.

`volatile bool xIsBusy`  
True if there is an active transfer.

`uint8_t txFifoEntryCount`  
Number of data word entries in transmit FIFO.

`uint8_t rxFifoThreshold`  
The max value of the receiver FIFO threshold.

*smartcard\_interface\_callback\_t* interfaceCallback

Callback to invoke after interface IC raised interrupt.

*smartcard\_transfer\_callback\_t* transferCallback

Callback to invoke after transfer event occur.

void \*interfaceCallbackParam

Interface callback parameter pointer.

void \*transferCallbackParam

Transfer callback parameter pointer.

*smartcard\_time\_delay\_t* timeDelay

Function which handles time delay defined by user or RTOS.

*smartcard\_reset\_type\_t* resetType

Indicates whether a Cold reset or Warm reset was requested.

*smartcard\_transport\_type\_t* tType

Indicates current transfer protocol (T0 or T1)

volatile *smartcard\_transfer\_state\_t* transferState

Indicates the current transfer state

*smartcard\_timers\_state\_t* timersState

Indicates the state of different protocol timers used in driver

*smartcard\_card\_params\_t* cardParams

Smart card parameters(ATR and current) and interface slots states(ATR and current)

uint8\_t IFSD

Indicates the terminal IFSD

*smartcard\_parity\_type\_t* parity

Indicates current parity even/odd

volatile bool rxtCrossed

Indicates whether RXT thresholds has been crossed

volatile bool txtCrossed

Indicates whether TXT thresholds has been crossed

volatile bool wtxRequested

Indicates whether WTX has been requested or not

volatile bool parityError

Indicates whether a parity error has been detected

uint8\_t statusBytes[2]

Used to store Status bytes SW1, SW2 of the last executed card command response

*smartcard\_interface\_config\_t* interfaceConfig

Smart card interface configuration structure

bool abortTransfer

Used to abort transfer.

## 2.37 Smart Card UART Driver

`void SMARTCARD_UART_GetDefaultConfig(smartcard_card_params_t *cardParams)`

Fills in the `smartcard_card_params` structure with default values according to the EMV 4.3 specification.

**Parameters**

- `cardParams` – The configuration structure of type `smartcard_interface_config_t`. Function fill in members: `Fi = 372`; `Di = 1`; `currentD = 1`; `WI = 0x0A`; `GTN = 0x00`; with default values.

`status_t SMARTCARD_UART_Init(UART_Type *base, smartcard_context_t *context, uint32_t srcClock_Hz)`

Initializes a UART peripheral for the Smart card/ISO-7816 operation.

This function un-gates the UART clock, initializes the module to EMV default settings, configures the IRQ, enables the module-level interrupt to the core, and initializes the driver context.

**Parameters**

- `base` – The UART peripheral base address.
- `context` – A pointer to a smart card driver context structure.
- `srcClock_Hz` – Smart card clock generation module source clock.

**Returns**

An error code or `kStatus_SMARTCARD_Success`.

`void SMARTCARD_UART_Deinit(UART_Type *base)`

This function disables the UART interrupts, disables the transmitter and receiver, and flushes the FIFOs (for modules that support FIFOs) and gates UART clock in SIM.

**Parameters**

- `base` – The UART peripheral base address.

`int32_t SMARTCARD_UART_GetTransferRemainingBytes(UART_Type *base, smartcard_context_t *context)`

Returns whether the previous UART transfer has finished.

When performing an async transfer, call this function to ascertain the context of the current transfer: in progress (or busy) or complete (success). If the transfer is still in progress, the user can obtain the number of words that have not been transferred by reading `xSize` of smart card context structure.

**Parameters**

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.

**Returns**

The number of bytes not transferred.

`status_t SMARTCARD_UART_AbortTransfer(UART_Type *base, smartcard_context_t *context)`

Terminates an asynchronous UART transfer early.

During an async UART transfer, the user can terminate the transfer early if the transfer is still in progress.

**Parameters**

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.

**Return values**

- `kStatus_SMARTCARD_Success` – The transfer abort was successful.
- `kStatus_SMARTCARD_NoTransmitInProgress` – No transmission is currently in progress.

`status_t SMARTCARD_UART_TransferNonBlocking(UART_Type *base, smartcard_context_t *context, smartcard_xfer_t *xfer)`

Transfers data using interrupts.

A non-blocking (also known as asynchronous) function means that the function returns immediately after initiating the transfer function. The application has to get the transfer status to see when the transfer is complete. In other words, after calling non-blocking (asynchronous) transfer function, the application must get the transfer status to check if transmit is completed or not.

#### Parameters

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.
- `xfer` – A pointer to Smart card transfer structure where the linked buffers and sizes are stored.

#### Returns

An error code or `kStatus_SMARTCARD_Success`.

`status_t SMARTCARD_UART_Control(UART_Type *base, smartcard_context_t *context, smartcard_control_t control, uint32_t param)`

Controls the UART module per different user requests.

return An `kStatus_SMARTCARD_OtherError` in case of error return `kStatus_SMARTCARD_Success` in success

#### Parameters

- `base` – The UART peripheral base address.
- `context` – A pointer to a smart card driver context structure.
- `control` – Smart card command type.
- `param` – Integer value specific to a control command.

`void SMARTCARD_UART_IRQHandler(UART_Type *base, smartcard_context_t *context)`

Interrupt handler for UART.

This handler uses the buffers stored in the `smartcard_context_t` structures to transfer data. The Smart card driver requires this function to call when the UART interrupt occurs.

#### Parameters

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.

`void SMARTCARD_UART_ErrIRQHandler(UART_Type *base, smartcard_context_t *context)`

Error interrupt handler for UART.

This function handles error conditions during a transfer.

#### Parameters

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.

`void SMARTCARD_UART_TSExpiryCallback(UART_Type *base, smartcard_context_t *context)`  
Handles initial TS character timer time-out event.

**Parameters**

- `base` – The UART peripheral base address.
- `context` – A pointer to a Smart card driver context structure.

`void smartcard_uart_TimerStart(uint8_t channel, uint32_t time)`  
Initializes timer specific channel with input period, enable channel interrupt and start counter.

**Parameters**

- `channel` – The timer channel.
- `time` – The time period.

`SMARTCARD_EMV_RX_NACK_THRESHOLD`  
EMV RX NACK interrupt generation threshold.

`SMARTCARD_EMV_TX_NACK_THRESHOLD`  
EMV TX NACK interrupt generation threshold.

`SMARTCARD_EMV_RX_TO_TX_GUARD_TIME_T0`  
EMV TX & RX GUART TIME default value.

`SBR_CAL_ADJUST_D1_T0`

`BRFA_CAL_ADJUST_D1_T0`

`SBR_CAL_ADJUST_D2_T0`

`BRFA_CAL_ADJUST_D2_T0`

`SBR_CAL_ADJUST_D4_T0`

`BRFA_CAL_ADJUST_D4_T0`

`SBR_CAL_ADJUST_D1_T1`

`BRFA_CAL_ADJUST_D1_T1`

`SBR_CAL_ADJUST_D2_T1`

`BRFA_CAL_ADJUST_D2_T1`

`SBR_CAL_ADJUST_D4_T1`

`BRFA_CAL_ADJUST_D4_T1`

## 2.38 SMC: System Mode Controller Driver

`static inline void SMC_GetVersionId(SMC_Type *base, smc_version_id_t *versionId)`  
Gets the SMC version ID.

This function gets the SMC version ID, including major version number, minor version number, and feature specification number.

**Parameters**

- `base` – SMC peripheral base address.
- `versionId` – Pointer to the version ID structure.

```
void SMC_GetParam(SMC_Type *base, smc_param_t *param)
```

Gets the SMC parameter.

This function gets the SMC parameter including the enabled power modes.

#### Parameters

- base – SMC peripheral base address.
- param – Pointer to the SMC param structure.

```
static inline void SMC_SetPowerModeProtection(SMC_Type *base, uint8_t allowedModes)
```

Configures all power mode protection settings.

This function configures the power mode protection settings for supported power modes in the specified chip family. The available power modes are defined in the `smc_power_mode_protection_t`. This should be done at an early system level initialization stage. See the reference manual for details. This register can only write once after the power reset.

The allowed modes are passed as bit map. For example, to allow LLS and VLLS, use `SMC_SetPowerModeProtection(kSMC_AllowPowerModeVlls | kSMC_AllowPowerModeVlps)`. To allow all modes, use `SMC_SetPowerModeProtection(kSMC_AllowPowerModeAll)`.

#### Parameters

- base – SMC peripheral base address.
- allowedModes – Bitmap of the allowed power modes.

```
static inline smc_power_state_t SMC_GetPowerModeState(SMC_Type *base)
```

Gets the current power mode status.

This function returns the current power mode status. After the application switches the power mode, it should always check the status to check whether it runs into the specified mode or not. The application should check this mode before switching to a different mode. The system requires that only certain modes can switch to other specific modes. See the reference manual for details and the `smc_power_state_t` for information about the power status.

#### Parameters

- base – SMC peripheral base address.

#### Returns

Current power mode status.

```
void SMC_PreEnterStopModes(void)
```

Prepares to enter stop modes.

This function should be called before entering STOP/VLPS/LLS/VLLS modes.

```
void SMC_PostExitStopModes(void)
```

Recovers after wake up from stop modes.

This function should be called after wake up from STOP/VLPS/LLS/VLLS modes. It is used with `SMC_PreEnterStopModes`.

```
void SMC_PreEnterWaitModes(void)
```

Prepares to enter wait modes.

This function should be called before entering WAIT/VLPW modes.

`void SMC_PostExitWaitModes(void)`

Recovers after wake up from stop modes.

This function should be called after wake up from WAIT/VLPW modes. It is used with SMC\_PreEnterWaitModes.

`status_t SMC_SetPowerModeRun(SMC_Type *base)`

Configures the system to RUN power mode.

**Parameters**

- `base` – SMC peripheral base address.

**Returns**

SMC configuration error code.

`status_t SMC_SetPowerModeHsrn(SMC_Type *base)`

Configures the system to HSRUN power mode.

**Parameters**

- `base` – SMC peripheral base address.

**Returns**

SMC configuration error code.

`status_t SMC_SetPowerModeWait(SMC_Type *base)`

Configures the system to WAIT power mode.

**Parameters**

- `base` – SMC peripheral base address.

**Returns**

SMC configuration error code.

`status_t SMC_SetPowerModeStop(SMC_Type *base, smc_partial_stop_option_t option)`

Configures the system to Stop power mode.

**Parameters**

- `base` – SMC peripheral base address.
- `option` – Partial Stop mode option.

**Returns**

SMC configuration error code.

`status_t SMC_SetPowerModeVlpr(SMC_Type *base, bool wakeupMode)`

Configures the system to VLPR power mode.

**Parameters**

- `base` – SMC peripheral base address.
- `wakeupMode` – Enter Normal Run mode if true, else stay in VLPR mode.

**Returns**

SMC configuration error code.

`status_t SMC_SetPowerModeVlpw(SMC_Type *base)`

Configures the system to VLPW power mode.

**Parameters**

- `base` – SMC peripheral base address.

**Returns**

SMC configuration error code.

*status\_t* SMC\_SetPowerModeVlps(SMC\_Type \*base)

Configures the system to VLPS power mode.

**Parameters**

- base – SMC peripheral base address.

**Returns**

SMC configuration error code.

*status\_t* SMC\_SetPowerModeLls(SMC\_Type \*base, const *smc\_power\_mode\_lls\_config\_t* \*config)

Configures the system to LLS power mode.

**Parameters**

- base – SMC peripheral base address.
- config – The LLS power mode configuration structure

**Returns**

SMC configuration error code.

*status\_t* SMC\_SetPowerModeVlls(SMC\_Type \*base, const *smc\_power\_mode\_vlls\_config\_t* \*config)

Configures the system to VLLS power mode.

**Parameters**

- base – SMC peripheral base address.
- config – The VLLS power mode configuration structure.

**Returns**

SMC configuration error code.

FSL\_SMC\_DRIVER\_VERSION

SMC driver version.

enum \_smc\_power\_mode\_protection

Power Modes Protection.

*Values:*

enumerator kSMC\_AllowPowerModeVlls

Allow Very-low-leakage Stop Mode.

enumerator kSMC\_AllowPowerModeLls

Allow Low-leakage Stop Mode.

enumerator kSMC\_AllowPowerModeVlp

Allow Very-Low-power Mode.

enumerator kSMC\_AllowPowerModeHsrn

Allow High-speed Run mode.

enumerator kSMC\_AllowPowerModeAll

Allow all power mode.

enum \_smc\_power\_state

Power Modes in PMSTAT.

*Values:*

enumerator kSMC\_PowerStateRun

0000\_0001 - Current power mode is RUN

enumerator kSMC\_PowerStateStop

0000\_0010 - Current power mode is STOP

enumerator kSMC\_PowerStateVlpr  
0000\_0100 - Current power mode is VLPR

enumerator kSMC\_PowerStateVlpw  
0000\_1000 - Current power mode is VLPW

enumerator kSMC\_PowerStateVlps  
0001\_0000 - Current power mode is VLPS

enumerator kSMC\_PowerStateLls  
0010\_0000 - Current power mode is LLS

enumerator kSMC\_PowerStateVlls  
0100\_0000 - Current power mode is VLLS

enumerator kSMC\_PowerStateHsrunk  
1000\_0000 - Current power mode is HSRUN

enum \_smc\_run\_mode

Run mode definition.

*Values:*

enumerator kSMC\_RunNormal  
Normal RUN mode.

enumerator kSMC\_RunVlpr  
Very-low-power RUN mode.

enumerator kSMC\_Hsrunk  
High-speed Run mode (HSRUN).

enum \_smc\_stop\_mode

Stop mode definition.

*Values:*

enumerator kSMC\_StopNormal  
Normal STOP mode.

enumerator kSMC\_StopVlps  
Very-low-power STOP mode.

enumerator kSMC\_StopLls  
Low-leakage Stop mode.

enumerator kSMC\_StopVlls  
Very-low-leakage Stop mode.

enum \_smc\_stop\_submode

VLLS/LLS stop sub mode definition.

*Values:*

enumerator kSMC\_StopSub0  
Stop submode 0, for VLLS0/LLS0.

enumerator kSMC\_StopSub1  
Stop submode 1, for VLLS1/LLS1.

enumerator kSMC\_StopSub2  
Stop submode 2, for VLLS2/LLS2.

enumerator kSMC\_StopSub3  
Stop submode 3, for VLLS3/LLS3.

enum \_smc\_partial\_stop\_mode  
Partial STOP option.

*Values:*

enumerator kSMC\_PartialStop  
STOP - Normal Stop mode

enumerator kSMC\_PartialStop1  
Partial Stop with both system and bus clocks disabled

enumerator kSMC\_PartialStop2  
Partial Stop with system clock disabled and bus clock enabled

\_smc\_status, SMC configuration status.

*Values:*

enumerator kStatus\_SMC\_StopAbort  
Entering Stop mode is abort

typedef enum \_smc\_power\_mode\_protection smc\_power\_mode\_protection\_t  
Power Modes Protection.

typedef enum \_smc\_power\_state smc\_power\_state\_t  
Power Modes in PMSTAT.

typedef enum \_smc\_run\_mode smc\_run\_mode\_t  
Run mode definition.

typedef enum \_smc\_stop\_mode smc\_stop\_mode\_t  
Stop mode definition.

typedef enum \_smc\_stop\_submode smc\_stop\_submode\_t  
VLLS/LLS stop sub mode definition.

typedef enum \_smc\_partial\_stop\_mode smc\_partial\_stop\_option\_t  
Partial STOP option.

typedef struct \_smc\_version\_id smc\_version\_id\_t  
IP version ID definition.

typedef struct \_smc\_param smc\_param\_t  
IP parameter definition.

typedef struct \_smc\_power\_mode\_lls\_config smc\_power\_mode\_lls\_config\_t  
SMC Low-Leakage Stop power mode configuration.

typedef struct \_smc\_power\_mode\_vlls\_config smc\_power\_mode\_vlls\_config\_t  
SMC Very Low-Leakage Stop power mode configuration.

struct \_smc\_version\_id  
*#include <fsl\_smc.h>* IP version ID definition.

## Public Members

uint16\_t feature  
Feature Specification Number.

uint8\_t minor

Minor version number.

uint8\_t major

Major version number.

struct \_\_smc\_param

*#include <fsl\_smc.h>* IP parameter definition.

#### Public Members

bool hsruntimeEnable

HSRUN mode enable.

bool llsEnable

LLS mode enable.

bool lls2Enable

LLS2 mode enable.

bool vlls0Enable

VLLS0 mode enable.

struct \_\_smc\_power\_mode\_lls\_config

*#include <fsl\_smc.h>* SMC Low-Leakage Stop power mode configuration.

#### Public Members

smc\_stop\_submode\_t subMode

Low-leakage Stop sub-mode

bool enableLpoClock

Enable LPO clock in LLS mode

struct \_\_smc\_power\_mode\_vlls\_config

*#include <fsl\_smc.h>* SMC Very Low-Leakage Stop power mode configuration.

#### Public Members

smc\_stop\_submode\_t subMode

Very Low-leakage Stop sub-mode

bool enablePorDetectInVlls0

Enable Power on reset detect in VLLS mode

bool enableRam2InVlls2

Enable RAM2 power in VLLS2

bool enableLpoClock

Enable LPO clock in VLLS mode

## 2.39 SPI: Serial Peripheral Interface Driver

## 2.40 SPI DMA Driver

```
void SPI_MasterTransferCreateHandleDMA(SPI_Type *base, spi_dma_handle_t *handle,  
                                       spi_dma_callback_t callback, void *userData,  
                                       dma_handle_t *txHandle, dma_handle_t *rxHandle)
```

Initialize the SPI master DMA handle.

This function initializes the SPI master DMA handle which can be used for other SPI master transactional APIs. Usually, for a specified SPI instance, user need only call this API once to get the initialized handle.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI handle pointer.
- callback – User callback function called at the end of a transfer.
- userData – User data for callback.
- txHandle – DMA handle pointer for SPI Tx, the handle shall be static allocated by users.
- rxHandle – DMA handle pointer for SPI Rx, the handle shall be static allocated by users.

```
status_t SPI_MasterTransferDMA(SPI_Type *base, spi_dma_handle_t *handle, spi_transfer_t  
                               *xfer)
```

Perform a non-blocking SPI transfer using DMA.

---

**Note:** This interface returned immediately after transfer initiates, users should call SPI\_GetTransferStatus to poll the transfer status to check whether SPI transfer finished.

---

#### Parameters

- base – SPI peripheral base address.
- handle – SPI DMA handle pointer.
- xfer – Pointer to dma transfer structure.

#### Return values

- kStatus\_Success – Successfully start a transfer.
- kStatus\_InvalidArgument – Input argument is invalid.
- kStatus\_SPI\_Busy – SPI is not idle, is running another transfer.

```
void SPI_MasterTransferAbortDMA(SPI_Type *base, spi_dma_handle_t *handle)
```

Abort a SPI transfer using DMA.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI DMA handle pointer.

```
status_t SPI_MasterTransferGetCountDMA(SPI_Type *base, spi_dma_handle_t *handle, size_t  
                                       *count)
```

Get the transferred bytes for SPI slave DMA.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI DMA handle pointer.
- count – Transferred bytes.

**Return values**

- `kStatus_SPI_Success` – Succeed get the transfer count.
- `kStatus_NoTransferInProgress` – There is not a non-blocking transaction currently in progress.

```
static inline void SPI_SlaveTransferCreateHandleDMA(SPI_Type *base, spi_dma_handle_t
                                                    *handle, spi_dma_callback_t callback, void
                                                    *userData, dma_handle_t *txHandle,
                                                    dma_handle_t *rxHandle)
```

Initialize the SPI slave DMA handle.

This function initializes the SPI slave DMA handle which can be used for other SPI master transactional APIs. Usually, for a specified SPI instance, user need only call this API once to get the initialized handle.

**Parameters**

- `base` – SPI peripheral base address.
- `handle` – SPI handle pointer.
- `callback` – User callback function called at the end of a transfer.
- `userData` – User data for callback.
- `txHandle` – DMA handle pointer for SPI Tx, the handle shall be static allocated by users.
- `rxHandle` – DMA handle pointer for SPI Rx, the handle shall be static allocated by users.

```
static inline status_t SPI_SlaveTransferDMA(SPI_Type *base, spi_dma_handle_t *handle,
                                            spi_transfer_t *xfer)
```

Perform a non-blocking SPI transfer using DMA.

---

**Note:** This interface returned immediately after transfer initiates, users should call `SPI_GetTransferStatus` to poll the transfer status to check whether SPI transfer finished.

---

**Parameters**

- `base` – SPI peripheral base address.
- `handle` – SPI DMA handle pointer.
- `xfer` – Pointer to dma transfer structure.

**Return values**

- `kStatus_Success` – Successfully start a transfer.
- `kStatus_InvalidArgument` – Input argument is invalid.
- `kStatus_SPI_Busy` – SPI is not idle, is running another transfer.

```
static inline void SPI_SlaveTransferAbortDMA(SPI_Type *base, spi_dma_handle_t *handle)
```

Abort a SPI transfer using DMA.

**Parameters**

- `base` – SPI peripheral base address.
- `handle` – SPI DMA handle pointer.

```
static inline status_t SPI_SlaveTransferGetCountDMA(SPI_Type *base, spi_dma_handle_t
                                                    *handle, size_t *count)
```

Get the transferred bytes for SPI slave DMA.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI DMA handle pointer.
- count – Transferred bytes.

#### Return values

- `kStatus_SPI_Success` – Succeed get the transfer count.
- `kStatus_NoTransferInProgress` – There is not a non-blocking transaction currently in progress.

```
FSL_SPI_DMA_DRIVER_VERSION
```

SPI DMA driver version.

```
typedef struct _spi_dma_handle spi_dma_handle_t
```

```
typedef void (*spi_dma_callback_t)(SPI_Type *base, spi_dma_handle_t *handle, status_t status,
void *userData)
```

SPI DMA callback called at the end of transfer.

```
struct _spi_dma_handle
```

*#include <fsl\_spi\_dma.h>* SPI DMA transfer handle, users should not touch the content of the handle.

#### Public Members

```
bool txInProgress
```

Send transfer finished

```
bool rxInProgress
```

Receive transfer finished

```
dma_handle_t *txHandle
```

DMA handler for SPI send

```
dma_handle_t *rxHandle
```

DMA handler for SPI receive

```
uint8_t bytesPerFrame
```

Bytes in a frame for SPI transfer

```
spi_dma_callback_t callback
```

Callback for SPI DMA transfer

```
void *userData
```

User Data for SPI DMA callback

```
uint32_t state
```

Internal state of SPI DMA transfer

```
size_t transferSize
```

Bytes need to be transfer

## 2.41 SPI Driver

**void SPI\_MasterGetDefaultConfig(*spi\_master\_config\_t* \*config)**

Sets the SPI master configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in SPI\_MasterInit(). User may use the initialized structure unchanged in SPI\_MasterInit(), or modify some fields of the structure before calling SPI\_MasterInit(). After calling this API, the master is ready to transfer. Example:

```
spi_master_config_t config;
SPI_MasterGetDefaultConfig(&config);
```

### Parameters

- config – pointer to master config structure

**void SPI\_MasterInit(SPI\_Type \*base, const *spi\_master\_config\_t* \*config, uint32\_t srcClock\_Hz)**

Initializes the SPI with master configuration.

The configuration structure can be filled by user from scratch, or be set with default values by SPI\_MasterGetDefaultConfig(). After calling this API, the slave is ready to transfer. Example

```
spi_master_config_t config = {
    .baudRate_Bps = 400000,
    ...
};
SPI_MasterInit(SPI0, &config);
```

### Parameters

- base – SPI base pointer
- config – pointer to master configuration structure
- srcClock\_Hz – Source clock frequency.

**void SPI\_SlaveGetDefaultConfig(*spi\_slave\_config\_t* \*config)**

Sets the SPI slave configuration structure to default values.

The purpose of this API is to get the configuration structure initialized for use in SPI\_SlaveInit(). Modify some fields of the structure before calling SPI\_SlaveInit(). Example:

```
spi_slave_config_t config;
SPI_SlaveGetDefaultConfig(&config);
```

### Parameters

- config – pointer to slave configuration structure

**void SPI\_SlaveInit(SPI\_Type \*base, const *spi\_slave\_config\_t* \*config)**

Initializes the SPI with slave configuration.

The configuration structure can be filled by user from scratch or be set with default values by SPI\_SlaveGetDefaultConfig(). After calling this API, the slave is ready to transfer. Example

```
spi_slave_config_t config = {
    .polarity = kSPIClockPolarity_ActiveHigh;
    .phase = kSPIClockPhase_FirstEdge;
```

(continues on next page)

(continued from previous page)

```
.direction = kSPIMsbFirst;
...
};
SPI_MasterInit(SPI0, &config);
```

**Parameters**

- base – SPI base pointer
- config – pointer to master configuration structure

void SPI\_Deinit(SPI\_Type \*base)

De-initializes the SPI.

Calling this API resets the SPI module, gates the SPI clock. The SPI module can't work unless calling the SPI\_MasterInit/SPI\_SlaveInit to initialize module.

**Parameters**

- base – SPI base pointer

static inline void SPI\_Enable(SPI\_Type \*base, bool enable)

Enables or disables the SPI.

**Parameters**

- base – SPI base pointer
- enable – pass true to enable module, false to disable module

uint32\_t SPI\_GetStatusFlags(SPI\_Type \*base)

Gets the status flag.

**Parameters**

- base – SPI base pointer

**Returns**

SPI Status, use status flag to AND \_spi\_flags could get the related status.

static inline void SPI\_ClearInterrupt(SPI\_Type \*base, uint8\_t mask)

Clear the interrupt if enable INCTLR.

**Parameters**

- base – SPI base pointer
- mask – Interrupt need to be cleared The parameter could be any combination of the following values:
  - kSPI\_RxFullAndModfInterruptEnable
  - kSPI\_TxEmptyInterruptEnable
  - kSPI\_MatchInterruptEnable
  - kSPI\_RxFifoNearFullInterruptEnable
  - kSPI\_TxFifoNearEmptyInterruptEnable

void SPI\_EnableInterrupts(SPI\_Type \*base, uint32\_t mask)

Enables the interrupt for the SPI.

**Parameters**

- base – SPI base pointer
- mask – SPI interrupt source. The parameter can be any combination of the following values:

- kSPI\_RxFullAndModfInterruptEnable
- kSPI\_TxEmptyInterruptEnable
- kSPI\_MatchInterruptEnable
- kSPI\_RxFifoNearFullInterruptEnable
- kSPI\_TxFifoNearEmptyInterruptEnable

void SPI\_DisableInterrupts(SPI\_Type \*base, uint32\_t mask)

Disables the interrupt for the SPI.

#### Parameters

- base – SPI base pointer
- mask – SPI interrupt source. The parameter can be any combination of the following values:
  - kSPI\_RxFullAndModfInterruptEnable
  - kSPI\_TxEmptyInterruptEnable
  - kSPI\_MatchInterruptEnable
  - kSPI\_RxFifoNearFullInterruptEnable
  - kSPI\_TxFifoNearEmptyInterruptEnable

static inline void SPI\_EnableDMA(SPI\_Type \*base, uint8\_t mask, bool enable)

Enables the DMA source for SPI.

#### Parameters

- base – SPI base pointer
- mask – SPI DMA source.
- enable – True means enable DMA, false means disable DMA

static inline uint32\_t SPI\_GetDataRegisterAddress(SPI\_Type \*base)

Gets the SPI tx/rx data register address.

This API is used to provide a transfer address for the SPI DMA transfer configuration.

#### Parameters

- base – SPI base pointer

#### Returns

data register address

uint32\_t SPI\_GetInstance(SPI\_Type \*base)

Get the instance for SPI module.

#### Parameters

- base – SPI base address

static inline void SPI\_SetPinMode(SPI\_Type \*base, spi\_pin\_mode\_t pinMode)

Sets the pin mode for transfer.

#### Parameters

- base – SPI base pointer
- pinMode – pin mode for transfer AND `_spi_pin_mode` could get the related configuration.

void SPI\_MasterSetBaudRate(SPI\_Type \*base, uint32\_t baudRate\_Bps, uint32\_t srcClock\_Hz)

Sets the baud rate for SPI transfer. This is only used in master.

**Parameters**

- base – SPI base pointer
- baudRate\_Bps – baud rate needed in Hz.
- srcClock\_Hz – SPI source clock frequency in Hz.

static inline void SPI\_SetMatchData(SPI\_Type \*base, uint32\_t matchData)

Sets the match data for SPI.

The match data is a hardware comparison value. When the value received in the SPI receive data buffer equals the hardware comparison value, the SPI Match Flag in the S register (S[SPMF]) sets. This can also generate an interrupt if the enable bit sets.

**Parameters**

- base – SPI base pointer
- matchData – Match data.

void SPI\_EnableFIFO(SPI\_Type \*base, bool enable)

Enables or disables the FIFO if there is a FIFO.

**Parameters**

- base – SPI base pointer
- enable – True means enable FIFO, false means disable FIFO.

status\_t SPI\_WriteBlocking(SPI\_Type \*base, uint8\_t \*buffer, size\_t size)

Sends a buffer of data bytes using a blocking method.

---

**Note:** This function blocks via polling until all bytes have been sent.

---

**Parameters**

- base – SPI base pointer
- buffer – The data bytes to send
- size – The number of data bytes to send

**Returns**

kStatus\_SPI\_Timeout The transfer timed out and was aborted.

void SPI\_WriteData(SPI\_Type \*base, uint16\_t data)

Writes a data into the SPI data register.

**Parameters**

- base – SPI base pointer
- data – needs to be write.

uint16\_t SPI\_ReadData(SPI\_Type \*base)

Gets a data from the SPI data register.

**Parameters**

- base – SPI base pointer

**Returns**

Data in the register.

```
void SPI_SetDummyData(SPI_Type *base, uint8_t dummyData)
```

Set up the dummy data.

#### Parameters

- base – SPI peripheral address.
- dummyData – Data to be transferred when tx buffer is NULL.

```
void SPI_MasterTransferCreateHandle(SPI_Type *base, spi_master_handle_t *handle,  
                                   spi_master_callback_t callback, void *userData)
```

Initializes the SPI master handle.

This function initializes the SPI master handle which can be used for other SPI master transactional APIs. Usually, for a specified SPI instance, call this API once to get the initialized handle.

#### Parameters

- base – SPI peripheral base address.
- handle – SPI handle pointer.
- callback – Callback function.
- userData – User data.

```
status_t SPI_MasterTransferBlocking(SPI_Type *base, spi_transfer_t *xfer)
```

Transfers a block of data using a polling method.

#### Parameters

- base – SPI base pointer
- xfer – pointer to spi\_xfer\_config\_t structure

#### Return values

- kStatus\_Success – Successfully start a transfer.
- kStatus\_InvalidArgument – Input argument is invalid.

```
status_t SPI_MasterTransferNonBlocking(SPI_Type *base, spi_master_handle_t *handle,  
                                       spi_transfer_t *xfer)
```

Performs a non-blocking SPI interrupt transfer.

---

**Note:** The API immediately returns after transfer initialization is finished. Call SPI\_GetStatusIRQ() to get the transfer status.

---

---

**Note:** If SPI transfer data frame size is 16 bits, the transfer size cannot be an odd number.

---

#### Parameters

- base – SPI peripheral base address.
- handle – pointer to spi\_master\_handle\_t structure which stores the transfer state
- xfer – pointer to spi\_xfer\_config\_t structure

#### Return values

- kStatus\_Success – Successfully start a transfer.
- kStatus\_InvalidArgument – Input argument is invalid.

- `kStatus_SPI_Busy` – SPI is not idle, is running another transfer.

`status_t SPI_MasterTransferGetCount(SPI_Type *base, spi_master_handle_t *handle, size_t *count)`

Gets the bytes of the SPI interrupt transferred.

#### Parameters

- `base` – SPI peripheral base address.
- `handle` – Pointer to SPI transfer handle, this should be a static variable.
- `count` – Transferred bytes of SPI master.

#### Return values

- `kStatus_SPI_Success` – Succeed get the transfer count.
- `kStatus_NoTransferInProgress` – There is not a non-blocking transaction currently in progress.

`void SPI_MasterTransferAbort(SPI_Type *base, spi_master_handle_t *handle)`

Aborts an SPI transfer using interrupt.

#### Parameters

- `base` – SPI peripheral base address.
- `handle` – Pointer to SPI transfer handle, this should be a static variable.

`void SPI_MasterTransferHandleIRQ(SPI_Type *base, spi_master_handle_t *handle)`

Interrupts the handler for the SPI.

#### Parameters

- `base` – SPI peripheral base address.
- `handle` – pointer to `spi_master_handle_t` structure which stores the transfer state.

`void SPI_SlaveTransferCreateHandle(SPI_Type *base, spi_slave_handle_t *handle, spi_slave_callback_t callback, void *userData)`

Initializes the SPI slave handle.

This function initializes the SPI slave handle which can be used for other SPI slave transactional APIs. Usually, for a specified SPI instance, call this API once to get the initialized handle.

#### Parameters

- `base` – SPI peripheral base address.
- `handle` – SPI handle pointer.
- `callback` – Callback function.
- `userData` – User data.

`status_t SPI_SlaveTransferNonBlocking(SPI_Type *base, spi_slave_handle_t *handle, spi_transfer_t *xfer)`

Performs a non-blocking SPI slave interrupt transfer.

---

**Note:** The API returns immediately after the transfer initialization is finished. Call `SPI_GetStatusIRQ()` to get the transfer status.

---

---

**Note:** If SPI transfer data frame size is 16 bits, the transfer size cannot be an odd number.

---

**Parameters**

- base – SPI peripheral base address.
- handle – pointer to `spi_slave_handle_t` structure which stores the transfer state
- xfer – pointer to `spi_xfer_config_t` structure

**Return values**

- `kStatus_Success` – Successfully start a transfer.
- `kStatus_InvalidArgument` – Input argument is invalid.
- `kStatus_SPI_Busy` – SPI is not idle, is running another transfer.

```
static inline status_t SPI_SlaveTransferGetCount(SPI_Type *base, spi_slave_handle_t *handle,
                                                size_t *count)
```

Gets the bytes of the SPI interrupt transferred.

**Parameters**

- base – SPI peripheral base address.
- handle – Pointer to SPI transfer handle, this should be a static variable.
- count – Transferred bytes of SPI slave.

**Return values**

- `kStatus_SPI_Success` – Succeed get the transfer count.
- `kStatus_NoTransferInProgress` – There is not a non-blocking transaction currently in progress.

```
static inline void SPI_SlaveTransferAbort(SPI_Type *base, spi_slave_handle_t *handle)
```

Aborts an SPI slave transfer using interrupt.

**Parameters**

- base – SPI peripheral base address.
- handle – Pointer to SPI transfer handle, this should be a static variable.

```
void SPI_SlaveTransferHandleIRQ(SPI_Type *base, spi_slave_handle_t *handle)
```

Interrupts a handler for the SPI slave.

**Parameters**

- base – SPI peripheral base address.
- handle – pointer to `spi_slave_handle_t` structure which stores the transfer state

```
FSL_SPI_DRIVER_VERSION
```

SPI driver version.

Return status for the SPI driver.

*Values:*

enumerator `kStatus_SPI_Busy`  
SPI bus is busy

enumerator `kStatus_SPI_Idle`  
SPI is idle

enumerator kStatus\_SPI\_Error  
SPI error

enumerator kStatus\_SPI\_Timeout  
SPI timeout polling status flags.

enum \_spi\_clock\_polarity  
SPI clock polarity configuration.

*Values:*

enumerator kSPI\_ClockPolarityActiveHigh  
Active-high SPI clock (idles low).

enumerator kSPI\_ClockPolarityActiveLow  
Active-low SPI clock (idles high).

enum \_spi\_clock\_phase  
SPI clock phase configuration.

*Values:*

enumerator kSPI\_ClockPhaseFirstEdge  
First edge on SPCK occurs at the middle of the first cycle of a data transfer.

enumerator kSPI\_ClockPhaseSecondEdge  
First edge on SPCK occurs at the start of the first cycle of a data transfer.

enum \_spi\_shift\_direction  
SPI data shifter direction options.

*Values:*

enumerator kSPI\_MsbFirst  
Data transfers start with most significant bit.

enumerator kSPI\_LsbFirst  
Data transfers start with least significant bit.

enum \_spi\_ss\_output\_mode  
SPI slave select output mode options.

*Values:*

enumerator kSPI\_SlaveSelectAsGpio  
Slave select pin configured as GPIO.

enumerator kSPI\_SlaveSelectFaultInput  
Slave select pin configured for fault detection.

enumerator kSPI\_SlaveSelectAutomaticOutput  
Slave select pin configured for automatic SPI output.

enum \_spi\_pin\_mode  
SPI pin mode options.

*Values:*

enumerator kSPI\_PinModeNormal  
Pins operate in normal, single-direction mode.

enumerator kSPI\_PinModeInput  
Bidirectional mode. Master: MOSI pin is input; Slave: MISO pin is input.

enumerator kSPI\_PinModeOutput

Bidirectional mode. Master: MOSI pin is output; Slave: MISO pin is output.

enum \_spi\_data\_bitcount\_mode

SPI data length mode options.

*Values:*

enumerator kSPI\_8BitMode

8-bit data transmission mode

enumerator kSPI\_16BitMode

16-bit data transmission mode

enum \_spi\_interrupt\_enable

SPI interrupt sources.

*Values:*

enumerator kSPI\_RxFullAndModfInterruptEnable

Receive buffer full (SPRF) and mode fault (MODF) interrupt

enumerator kSPI\_TxEmptyInterruptEnable

Transmit buffer empty interrupt

enumerator kSPI\_MatchInterruptEnable

Match interrupt

enumerator kSPI\_RxFifoNearFullInterruptEnable

Receive FIFO nearly full interrupt

enumerator kSPI\_TxFifoNearEmptyInterruptEnable

Transmit FIFO nearly empty interrupt

enum \_spi\_flags

SPI status flags.

*Values:*

enumerator kSPI\_RxBufferFullFlag

Read buffer full flag

enumerator kSPI\_MatchFlag

Match flag

enumerator kSPI\_TxBufferEmptyFlag

Transmit buffer empty flag

enumerator kSPI\_ModeFaultFlag

Mode fault flag

enumerator kSPI\_RxFifoNearFullFlag

Rx FIFO near full

enumerator kSPI\_TxFifoNearEmptyFlag

Tx FIFO near empty

enumerator kSPI\_TxFifoFullFlag

Tx FIFO full

enumerator kSPI\_RxFifoEmptyFlag

Rx FIFO empty

enumerator kSPI\_TxFifoError  
Tx FIFO error

enumerator kSPI\_RxFifoError  
Rx FIFO error

enumerator kSPI\_TxOverflow  
Tx FIFO Overflow

enumerator kSPI\_RxOverflow  
Rx FIFO Overflow

enum \_spi\_wlc\_interrupt  
SPI FIFO write-1-to-clear interrupt flags.

*Values:*

enumerator kSPI\_RxFifoFullClearInterrupt  
Receive FIFO full interrupt

enumerator kSPI\_TxFifoEmptyClearInterrupt  
Transmit FIFO empty interrupt

enumerator kSPI\_RxNearFullClearInterrupt  
Receive FIFO nearly full interrupt

enumerator kSPI\_TxNearEmptyClearInterrupt  
Transmit FIFO nearly empty interrupt

enum \_spi\_txfifo\_watermark  
SPI TX FIFO watermark settings.

*Values:*

enumerator kSPI\_TxFifoOneFourthEmpty  
SPI tx watermark at 1/4 FIFO size

enumerator kSPI\_TxFifoOneHalfEmpty  
SPI tx watermark at 1/2 FIFO size

enum \_spi\_rxfifo\_watermark  
SPI RX FIFO watermark settings.

*Values:*

enumerator kSPI\_RxFifoThreeFourthsFull  
SPI rx watermark at 3/4 FIFO size

enumerator kSPI\_RxFifoOneHalfFull  
SPI rx watermark at 1/2 FIFO size

enum \_spi\_dma\_enable\_t  
SPI DMA source.

*Values:*

enumerator kSPI\_TxDmaEnable  
Tx DMA request source

enumerator kSPI\_RxDmaEnable  
Rx DMA request source

enumerator kSPI\_DmaAllEnable  
All DMA request source

```
typedef enum _spi_clock_polarity spi_clock_polarity_t
    SPI clock polarity configuration.

typedef enum _spi_clock_phase spi_clock_phase_t
    SPI clock phase configuration.

typedef enum _spi_shift_direction spi_shift_direction_t
    SPI data shifter direction options.

typedef enum _spi_ss_output_mode spi_ss_output_mode_t
    SPI slave select output mode options.

typedef enum _spi_pin_mode spi_pin_mode_t
    SPI pin mode options.

typedef enum _spi_data_bitcount_mode spi_data_bitcount_mode_t
    SPI data length mode options.

typedef enum _spi_w1c_interrupt spi_w1c_interrupt_t
    SPI FIFO write-1-to-clear interrupt flags.

typedef enum _spi_txfifo_watermark spi_txfifo_watermark_t
    SPI TX FIFO watermark settings.

typedef enum _spi_rxfifo_watermark spi_rxfifo_watermark_t
    SPI RX FIFO watermark settings.

typedef struct _spi_master_config spi_master_config_t
    SPI master user configure structure.

typedef struct _spi_slave_config spi_slave_config_t
    SPI slave user configure structure.

typedef struct _spi_transfer spi_transfer_t
    SPI transfer structure.

typedef struct _spi_master_handle spi_master_handle_t

typedef spi_master_handle_t spi_slave_handle_t
    Slave handle is the same with master handle

typedef void (*spi_master_callback_t)(SPI_Type *base, spi_master_handle_t *handle, status_t
status, void *userData)
    SPI master callback for finished transmit.

typedef void (*spi_slave_callback_t)(SPI_Type *base, spi_slave_handle_t *handle, status_t status,
void *userData)
    SPI master callback for finished transmit.

volatile uint8_t g_spiDummyData[]
    Global variable for dummy data value setting.

SPI_DUMMYDATA
    SPI dummy transfer data, the data is sent while txBuff is NULL.

SPI_RETRY_TIMES
    Retry times for waiting flag.

struct _spi_master_config
    #include <fsl_spi.h> SPI master user configure structure.
```

**Public Members**

`bool enableMaster`  
Enable SPI at initialization time

`bool enableStopInWaitMode`  
SPI stop in wait mode

`spi_clock_polarity_t polarity`  
Clock polarity

`spi_clock_phase_t phase`  
Clock phase

`spi_shift_direction_t direction`  
MSB or LSB

`spi_data_bitcount_mode_t dataMode`  
8bit or 16bit mode

`spi_txfifo_watermark_t txWatermark`  
Tx watermark settings

`spi_rxfifo_watermark_t rxWatermark`  
Rx watermark settings

`spi_ss_output_mode_t outputMode`  
SS pin setting

`spi_pin_mode_t pinMode`  
SPI pin mode select

`uint32_t baudRate_Bps`  
Baud Rate for SPI in Hz

`struct __spi_slave_config`  
`#include <fsl_spi.h>` SPI slave user configure structure.

**Public Members**

`bool enableSlave`  
Enable SPI at initialization time

`bool enableStopInWaitMode`  
SPI stop in wait mode

`spi_clock_polarity_t polarity`  
Clock polarity

`spi_clock_phase_t phase`  
Clock phase

`spi_shift_direction_t direction`  
MSB or LSB

`spi_data_bitcount_mode_t dataMode`  
8bit or 16bit mode

`spi_txfifo_watermark_t txWatermark`  
Tx watermark settings

*spi\_rxfifo\_watermark\_t* rxWatermark

Rx watermark settings

*spi\_pin\_mode\_t* pinMode

SPI pin mode select

struct *\_spi\_transfer*

*#include <fsl\_spi.h>* SPI transfer structure.

### Public Members

const uint8\_t \*txData

Send buffer

uint8\_t \*rxData

Receive buffer

size\_t dataSize

Transfer bytes

uint32\_t flags

SPI control flag, useless to SPI.

struct *\_spi\_master\_handle*

*#include <fsl\_spi.h>* SPI transfer handle structure.

### Public Members

const uint8\_t \*volatile txData

Transfer buffer

uint8\_t \*volatile rxData

Receive buffer

volatile size\_t txRemainingBytes

Send data remaining in bytes

volatile size\_t rxRemainingBytes

Receive data remaining in bytes

volatile uint32\_t state

SPI internal state

size\_t transferSize

Bytes to be transferred

uint8\_t bytePerFrame

SPI mode, 2bytes or 1byte in a frame

uint8\_t watermark

Watermark value for SPI transfer

*spi\_master\_callback\_t* callback

SPI callback

void \*userData

Callback parameter

## 2.42 SYSPMU: System Memory Protection Unit

`void SYSPMU_Init(SYSPMU_Type *base, const sysmpu_config_t *config)`

Initializes the SYSPMU with the user configuration structure.

This function configures the SYSPMU module with the user-defined configuration.

### Parameters

- `base` – SYSPMU peripheral base address.
- `config` – The pointer to the configuration structure.

`void SYSPMU_Deinit(SYSPMU_Type *base)`

Deinitializes the SYSPMU regions.

### Parameters

- `base` – SYSPMU peripheral base address.

`static inline void SYSPMU_Enable(SYSPMU_Type *base, bool enable)`

Enables/disables the SYSPMU globally.

Call this API to enable or disable the SYSPMU module.

### Parameters

- `base` – SYSPMU peripheral base address.
- `enable` – True enable SYSPMU, false disable SYSPMU.

`static inline void SYSPMU_RegionEnable(SYSPMU_Type *base, uint32_t number, bool enable)`

Enables/disables the SYSPMU for a special region.

When SYSPMU is enabled, call this API to disable an unused region of an enabled SYSPMU. Call this API to minimize the power dissipation.

### Parameters

- `base` – SYSPMU peripheral base address.
- `number` – SYSPMU region number.
- `enable` – True enable the special region SYSPMU, false disable the special region SYSPMU.

`void SYSPMU_GetHardwareInfo(SYSPMU_Type *base, sysmpu_hardware_info_t *hardwareInform)`

Gets the SYSPMU basic hardware information.

### Parameters

- `base` – SYSPMU peripheral base address.
- `hardwareInform` – The pointer to the SYSPMU hardware information structure. See “*sysmpu\_hardware\_info\_t*”.

`void SYSPMU_SetRegionConfig(SYSPMU_Type *base, const sysmpu_region_config_t *regionConfig)`

Sets the SYSPMU region.

Note: Due to the SYSPMU protection, the region number 0 does not allow writes from core to affect the start and end address nor the permissions associated with the debugger. It can only write the permission fields associated with the other masters.

### Parameters

- `base` – SYSPMU peripheral base address.

- `regionConfig` – The pointer to the SYSMPU user configuration structure. See “`sysmpu_region_config_t`”.

```
void SYSMPU_SetRegionAddr(SYSMPU_Type *base, uint32_t regionNum, uint32_t startAddr,
                          uint32_t endAddr)
```

Sets the region start and end address.

Memory region start address. Note: bit0 ~ bit4 is always marked as 0 by SYSMPU. The actual start address by SYSMPU is 0-modulo-32 byte address. Memory region end address. Note: bit0 ~ bit4 always be marked as 1 by SYSMPU. The end address used by the SYSMPU is 31-modulo-32 byte address. Note: Due to the SYSMPU protection, the `startAddr` and `endAddr` can't be changed by the core when `regionNum` is 0.

#### Parameters

- `base` – SYSMPU peripheral base address.
- `regionNum` – SYSMPU region number. The range is from 0 to `FSL_FEATURE_SYSMPU_DESCRIPTOR_COUNT - 1`.
- `startAddr` – Region start address.
- `endAddr` – Region end address.

```
void SYSMPU_SetRegionRwxMasterAccessRights(SYSMPU_Type *base, uint32_t regionNum,
                                             uint32_t masterNum, const
                                             sysmpu_rwxrights_master_access_control_t
                                             *accessRights)
```

Sets the SYSMPU region access rights for masters with read, write, and execute rights. The SYSMPU access rights depend on two board classifications of bus masters. The privilege rights masters and the normal rights masters. The privilege rights masters have the read, write, and execute access rights. Except the normal read and write rights, the execute rights are also allowed for these masters. The privilege rights masters normally range from bus masters 0 - 3. However, the maximum master number is device-specific. See the “`SYSMPU_PRIVILEGED_RIGHTS_MASTER_MAX_INDEX`”. The normal rights masters access rights control see “`SYSMPU_SetRegionRwMasterAccessRights()`”.

#### Parameters

- `base` – SYSMPU peripheral base address.
- `regionNum` – SYSMPU region number. Should range from 0 to `FSL_FEATURE_SYSMPU_DESCRIPTOR_COUNT - 1`.
- `masterNum` – SYSMPU bus master number. Should range from 0 to `SYSMPU_PRIVILEGED_RIGHTS_MASTER_MAX_INDEX`.
- `accessRights` – The pointer to the SYSMPU access rights configuration. See “`sysmpu_rwxrights_master_access_control_t`”.

```
bool SYSMPU_GetSlavePortErrorStatus(SYSMPU_Type *base, sysmpu_slave_t slaveNum)
```

Gets the numbers of slave ports where errors occur.

#### Parameters

- `base` – SYSMPU peripheral base address.
- `slaveNum` – SYSMPU slave port number.

#### Returns

The slave ports error status. `true` - error happens in this slave port. `false` - error didn't happen in this slave port.

```
void SYSMPU_GetDetailErrorAccessInfo(SYSMPU_Type *base, sysmpu_slave_t slaveNum,
                                     sysmpu_access_err_info_t *errInform)
```

Gets the SYSMPU detailed error access information.

**Parameters**

- base – SYSMPU peripheral base address.
- slaveNum – SYSMPU slave port number.
- errInform – The pointer to the SYSMPU access error information. See “sysmpu\_access\_err\_info\_t”.

FSL\_SYSMPU\_DRIVER\_VERSION  
SYSMPU driver version 2.2.3.

enum \_\_sysmpu\_region\_total\_num  
Describes the number of SYSMPU regions.

*Values:*

enumerator kSYSMPU\_8Regions  
SYSMPU supports 8 regions.

enumerator kSYSMPU\_12Regions  
SYSMPU supports 12 regions.

enumerator kSYSMPU\_16Regions  
SYSMPU supports 16 regions.

enum \_\_sysmpu\_slave  
SYSMPU slave port number.

*Values:*

enumerator kSYSMPU\_Slave0  
SYSMPU slave port 0.

enumerator kSYSMPU\_Slave1  
SYSMPU slave port 1.

enumerator kSYSMPU\_Slave2  
SYSMPU slave port 2.

enumerator kSYSMPU\_Slave3  
SYSMPU slave port 3.

enumerator kSYSMPU\_Slave4  
SYSMPU slave port 4.

enum \_\_sysmpu\_err\_access\_control  
SYSMPU error access control detail.

*Values:*

enumerator kSYSMPU\_NoRegionHit  
No region hit error.

enumerator kSYSMPU\_NoneOverlappRegion  
Access single region error.

enumerator kSYSMPU\_OverlappRegion  
Access overlapping region error.

enum \_\_sysmpu\_err\_access\_type  
SYSMPU error access type.

*Values:*

enumerator kSYSMPU\_\_ErrTypeRead  
SYSMPU error access type &#8212; read.

enumerator kSYSMPU\_\_ErrTypeWrite  
SYSMPU error access type &#8212; write.

enum \_\_sysmpu\_err\_attributes  
SYSMPU access error attributes.

*Values:*

enumerator kSYSMPU\_\_InstructionAccessInUserMode  
Access instruction error in user mode.

enumerator kSYSMPU\_\_DataAccessInUserMode  
Access data error in user mode.

enumerator kSYSMPU\_\_InstructionAccessInSupervisorMode  
Access instruction error in supervisor mode.

enumerator kSYSMPU\_\_DataAccessInSupervisorMode  
Access data error in supervisor mode.

enum \_\_sysmpu\_supervisor\_access\_rights  
SYSMPU access rights in supervisor mode for bus master 0 ~ 3.

*Values:*

enumerator kSYSMPU\_\_SupervisorReadWriteExecute  
Read write and execute operations are allowed in supervisor mode.

enumerator kSYSMPU\_\_SupervisorReadExecute  
Read and execute operations are allowed in supervisor mode.

enumerator kSYSMPU\_\_SupervisorReadWrite  
Read write operations are allowed in supervisor mode.

enumerator kSYSMPU\_\_SupervisorEqualToUsermode  
Access permission equal to user mode.

enum \_\_sysmpu\_user\_access\_rights  
SYSMPU access rights in user mode for bus master 0 ~ 3.

*Values:*

enumerator kSYSMPU\_\_UserNoAccessRights  
No access allowed in user mode.

enumerator kSYSMPU\_\_UserExecute  
Execute operation is allowed in user mode.

enumerator kSYSMPU\_\_UserWrite  
Write operation is allowed in user mode.

enumerator kSYSMPU\_\_UserWriteExecute  
Write and execute operations are allowed in user mode.

enumerator kSYSMPU\_\_UserRead  
Read is allowed in user mode.

enumerator kSYSMPU\_\_UserReadExecute  
Read and execute operations are allowed in user mode.

enumerator `kSYSMPU_UserReadWrite`

Read and write operations are allowed in user mode.

enumerator `kSYSMPU_UserReadWriteExecute`

Read write and execute operations are allowed in user mode.

typedef enum `_sysmpu_region_total_num` `sysmpu_region_total_num_t`

Describes the number of SYSMPU regions.

typedef enum `_sysmpu_slave` `sysmpu_slave_t`

SYSMPU slave port number.

typedef enum `_sysmpu_err_access_control` `sysmpu_err_access_control_t`

SYSMPU error access control detail.

typedef enum `_sysmpu_err_access_type` `sysmpu_err_access_type_t`

SYSMPU error access type.

typedef enum `_sysmpu_err_attributes` `sysmpu_err_attributes_t`

SYSMPU access error attributes.

typedef enum `_sysmpu_supervisor_access_rights` `sysmpu_supervisor_access_rights_t`

SYSMPU access rights in supervisor mode for bus master 0 ~ 3.

typedef enum `_sysmpu_user_access_rights` `sysmpu_user_access_rights_t`

SYSMPU access rights in user mode for bus master 0 ~ 3.

typedef struct `_sysmpu_hardware_info` `sysmpu_hardware_info_t`

SYSMPU hardware basic information.

typedef struct `_sysmpu_access_err_info` `sysmpu_access_err_info_t`

SYSMPU detail error access information.

typedef struct `_sysmpu_rwxrights_master_access_control`

`sysmpu_rwxrights_master_access_control_t`

SYSMPU read/write/execute rights control for bus master 0 ~ 3.

typedef struct `_sysmpu_rwrights_master_access_control`

`sysmpu_rwrights_master_access_control_t`

SYSMPU read/write access control for bus master 4 ~ 7.

typedef struct `_sysmpu_region_config` `sysmpu_region_config_t`

SYSMPU region configuration structure.

This structure is used to configure the `regionNum` region. The `accessRights1[0] ~ accessRights1[3]` are used to configure the bus master 0 ~ 3 with the privilege rights setting. The `accessRights2[0] ~ accessRights2[3]` are used to configure the high master 4 ~ 7 with the normal read write permission. The master port assignment is the chip configuration. Normally, the core is the master 0, debugger is the master 1. Note that the SYSMPU assigns a priority scheme where the debugger is treated as the highest priority master followed by the core and then all the remaining masters. SYSMPU protection does not allow writes from the core to affect the “`regionNum 0`” start and end address nor the permissions associated with the debugger. It can only write the permission fields associated with the other masters. This protection guarantees that the debugger always has access to the entire address space and those rights can’t be changed by the core or any other bus master. Prepare the region configuration when `regionNum` is 0.

typedef struct `_sysmpu_config` `sysmpu_config_t`

The configuration structure for the SYSMPU initialization.

This structure is used when calling the `SYSMPU_Init` function.

`SYSMPU_MASTER_RWATTRIBUTE_START_PORT`

define the start master port with read and write attributes.

`SYSMPU_REGION_RWXRIGHTS_MASTER_SHIFT(n)`

SYSMPU the bit shift for masters with privilege rights: read write and execute.

`SYSMPU_REGION_RWXRIGHTS_MASTER_MASK(n)`

SYSMPU masters with read, write and execute rights bit mask.

`SYSMPU_REGION_RWXRIGHTS_MASTER_WIDTH`

SYSMPU masters with read, write and execute rights bit width.

`SYSMPU_REGION_RWXRIGHTS_MASTER(n, x)`

SYSMPU masters with read, write and execute rights priority setting.

`SYSMPU_REGION_RWXRIGHTS_MASTER_PE_SHIFT(n)`

SYSMPU masters with read, write and execute rights process enable bit shift.

`SYSMPU_REGION_RWXRIGHTS_MASTER_PE_MASK(n)`

SYSMPU masters with read, write and execute rights process enable bit mask.

`SYSMPU_REGION_RWXRIGHTS_MASTER_PE(n, x)`

SYSMPU masters with read, write and execute rights process enable setting.

`SYSMPU_REGION_RWRIGHTS_MASTER_SHIFT(n)`

SYSMPU masters with normal read write permission bit shift.

`SYSMPU_REGION_RWRIGHTS_MASTER_MASK(n)`

SYSMPU masters with normal read write rights bit mask.

`SYSMPU_REGION_RWRIGHTS_MASTER(n, x)`

SYSMPU masters with normal read write rights priority setting.

`struct _sysmpu_hardware_info`

*#include <fsl\_sysmpu.h>* SYSMPU hardware basic information.

### Public Members

`uint8_t hardwareRevisionLevel`

Specifies the SYSMPU's hardware and definition reversion level.

`uint8_t slavePortsNumbers`

Specifies the number of slave ports connected to SYSMPU.

`sysmpu_region_total_num_t regionsNumbers`

Indicates the number of region descriptors implemented.

`struct _sysmpu_access_err_info`

*#include <fsl\_sysmpu.h>* SYSMPU detail error access information.

### Public Members

`uint32_t master`

Access error master.

`sysmpu_err_attributes_t attributes`

Access error attributes.

`sysmpu_err_access_type_t accessType`

Access error type.

*sysmpu\_err\_access\_control\_t* accessControl

Access error control.

uint32\_t address

Access error address.

uint8\_t processorIdentification

Access error processor identification.

struct \_sysmpu\_rwxrights\_master\_access\_control

*#include <fsl\_sysmpu.h>* SYSMPU read/write/execute rights control for bus master 0 ~ 3.

### Public Members

*sysmpu\_supervisor\_access\_rights\_t* superAccessRights

Master access rights in supervisor mode.

*sysmpu\_user\_access\_rights\_t* userAccessRights

Master access rights in user mode.

bool processIdentifierEnable

Enables or disables process identifier.

struct \_sysmpu\_rwrights\_master\_access\_control

*#include <fsl\_sysmpu.h>* SYSMPU read/write access control for bus master 4 ~ 7.

### Public Members

bool writeEnable

Enables or disables write permission.

bool readEnable

Enables or disables read permission.

struct \_sysmpu\_region\_config

*#include <fsl\_sysmpu.h>* SYSMPU region configuration structure.

This structure is used to configure the regionNum region. The accessRights1[0] ~ accessRights1[3] are used to configure the bus master 0 ~ 3 with the privilege rights setting. The accessRights2[0] ~ accessRights2[3] are used to configure the high master 4 ~ 7 with the normal read write permission. The master port assignment is the chip configuration. Normally, the core is the master 0, debugger is the master 1. Note that the SYSMPU assigns a priority scheme where the debugger is treated as the highest priority master followed by the core and then all the remaining masters. SYSMPU protection does not allow writes from the core to affect the “regionNum 0” start and end address nor the permissions associated with the debugger. It can only write the permission fields associated with the other masters. This protection guarantees that the debugger always has access to the entire address space and those rights can’t be changed by the core or any other bus master. Prepare the region configuration when regionNum is 0.

### Public Members

uint32\_t regionNum

SYSMPU region number, range form 0 ~ FSL\_FEATURE\_SYSMPU\_DESCRIPTOR\_COUNT - 1.

`uint32_t startAddress`

Memory region start address. Note: bit0 ~ bit4 always be marked as 0 by SYSMPU. The actual start address is 0-modulo-32 byte address.

`uint32_t endAddress`

Memory region end address. Note: bit0 ~ bit4 always be marked as 1 by SYSMPU. The actual end address is 31-modulo-32 byte address.

`sysmpu_rwxrights_master_access_control_t accessRights1[4]`

Masters with read, write and execute rights setting.

`sysmpu_rwrights_master_access_control_t accessRights2[4]`

Masters with normal read write rights setting.

`uint8_t processIdentifier`

Process identifier used when “processIdentifierEnable” set with true.

`uint8_t processIdMask`

Process identifier mask. The setting bit will ignore the same bit in process identifier.

`struct __sysmpu_config`

`#include <fsl_sysmpu.h>` The configuration structure for the SYSMPU initialization.

This structure is used when calling the SYSMPU\_Init function.

### Public Members

`sysmpu_region_config_t regionConfig`

Region access permission.

`struct __sysmpu_config *next`

Pointer to the next structure.

## 2.43 UART: Universal Asynchronous Receiver/Transmitter Driver

### 2.44 UART DMA Driver

```
void UART__TransferCreateHandleDMA(UART_Type *base, uart_dma_handle_t *handle,
                                   uart_dma_transfer_callback_t callback, void *userData,
                                   dma_handle_t *txDmaHandle, dma_handle_t
                                   *rxDmaHandle)
```

Initializes the UART handle which is used in transactional functions and sets the callback.

#### Parameters

- `base` – UART peripheral base address.
- `handle` – Pointer to the `uart_dma_handle_t` structure.
- `callback` – UART callback, NULL means no callback.
- `userData` – User callback function data.
- `rxDmaHandle` – User requested DMA handle for the RX DMA transfer.
- `txDmaHandle` – User requested DMA handle for the TX DMA transfer.

```
status_t UART_TransferSendDMA(UART_Type *base, uart_dma_handle_t *handle,  
                               uart_transfer_t *xfer)
```

Sends data using DMA.

This function sends data using DMA. This is non-blocking function, which returns right away. When all data is sent, the send callback function is called.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- xfer – UART DMA transfer structure. See `uart_transfer_t`.

#### Return values

- `kStatus_Success` – if succeeded; otherwise failed.
- `kStatus_UART_TxBusy` – Previous transfer ongoing.
- `kStatus_InvalidArgument` – Invalid argument.

```
status_t UART_TransferReceiveDMA(UART_Type *base, uart_dma_handle_t *handle,  
                                 uart_transfer_t *xfer)
```

Receives data using DMA.

This function receives data using DMA. This is non-blocking function, which returns right away. When all data is received, the receive callback function is called.

#### Parameters

- base – UART peripheral base address.
- handle – Pointer to the `uart_dma_handle_t` structure.
- xfer – UART DMA transfer structure. See `uart_transfer_t`.

#### Return values

- `kStatus_Success` – if succeeded; otherwise failed.
- `kStatus_UART_RxBusy` – Previous transfer on going.
- `kStatus_InvalidArgument` – Invalid argument.

```
void UART_TransferAbortSendDMA(UART_Type *base, uart_dma_handle_t *handle)
```

Aborts the send data using DMA.

This function aborts the sent data using DMA.

#### Parameters

- base – UART peripheral base address.
- handle – Pointer to `uart_dma_handle_t` structure.

```
void UART_TransferAbortReceiveDMA(UART_Type *base, uart_dma_handle_t *handle)
```

Aborts the received data using DMA.

This function abort receive data which using DMA.

#### Parameters

- base – UART peripheral base address.
- handle – Pointer to `uart_dma_handle_t` structure.

```
status_t UART_TransferGetSendCountDMA(UART_Type *base, uart_dma_handle_t *handle,
                                       uint32_t *count)
```

Gets the number of bytes written to UART TX register.

This function gets the number of bytes written to UART TX register by DMA.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- count – Send bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No send in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
status_t UART_TransferGetReceiveCountDMA(UART_Type *base, uart_dma_handle_t *handle,
                                          uint32_t *count)
```

Gets the number of bytes that have been received.

This function gets the number of bytes that have been received.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- count – Receive bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No receive in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
void UART_TransferDMAHandleIRQ(UART_Type *base, void *uartDmaHandle)
```

UART DMA IRQ handle function.

This function handles the UART transmit complete IRQ request and invoke user callback.

#### Parameters

- base – UART peripheral base address.
- uartDmaHandle – UART handle pointer.

```
FSL_UART_DMA_DRIVER_VERSION
```

UART DMA driver version.

```
typedef struct _uart_dma_handle uart_dma_handle_t
```

```
typedef void (*uart_dma_transfer_callback_t)(UART_Type *base, uart_dma_handle_t *handle,
status_t status, void *userData)
```

UART transfer callback function.

```
struct _uart_dma_handle
```

```
#include <fsl_uart_dma.h> UART DMA handle.
```

### Public Members

`UART_Type *base`  
UART peripheral base address.

`uart_dma_transfer_callback_t` callback  
Callback function.

`void *userData`  
UART callback function parameter.

`size_t rxDataSizeAll`  
Size of the data to receive.

`size_t txDataSizeAll`  
Size of the data to send out.

`dma_handle_t *txDmaHandle`  
The DMA TX channel used.

`dma_handle_t *rxDmaHandle`  
The DMA RX channel used.

`volatile uint8_t txState`  
TX transfer state.

`volatile uint8_t rxState`  
RX transfer state

## 2.45 UART Driver

`status_t UART_Init(UART_Type *base, const uart_config_t *config, uint32_t srcClock_Hz)`  
Initializes a UART instance with a user configuration structure and peripheral clock.

This function configures the UART module with the user-defined settings. The user can configure the configuration structure and also get the default configuration by using the `UART_GetDefaultConfig()` function. The example below shows how to use this API to configure UART.

```
uart_config_t uartConfig;  
uartConfig.baudRate_Bps = 115200U;  
uartConfig.parityMode = kUART_ParityDisabled;  
uartConfig.stopBitCount = kUART_OneStopBit;  
uartConfig.txFifoWatermark = 0;  
uartConfig.rxFifoWatermark = 1;  
UART_Init(UART1, &uartConfig, 2000000U);
```

### Parameters

- `base` – UART peripheral base address.
- `config` – Pointer to the user-defined configuration structure.
- `srcClock_Hz` – UART clock source frequency in HZ.

### Return values

- `kStatus_UART_BaudrateNotSupport` – Baudrate is not support in current clock source.
- `kStatus_Success` – Status UART initialize succeed

**void UART\_Deinit(UART\_Type \*base)**

Deinitializes a UART instance.

This function waits for TX complete, disables TX and RX, and disables the UART clock.

#### Parameters

- `base` – UART peripheral base address.

**void UART\_GetDefaultConfig(*uart\_config\_t* \*config)**

Gets the default configuration structure.

This function initializes the UART configuration structure to a default value. The default values are as follows. `uartConfig->baudRate_Bps = 115200U`; `uartConfig->bitCountPerChar = kUART_8BitsPerChar`; `uartConfig->parityMode = kUART_ParityDisabled`; `uartConfig->stopBitCount = kUART_OneStopBit`; `uartConfig->txFifoWatermark = 0`; `uartConfig->rxFifoWatermark = 1`; `uartConfig->idleType = kUART_IdleTypeStartBit`; `uartConfig->enableTx = false`; `uartConfig->enableRx = false`;

#### Parameters

- `config` – Pointer to configuration structure.

**status\_t UART\_SetBaudRate(UART\_Type \*base, uint32\_t baudRate\_Bps, uint32\_t srcClock\_Hz)**

Sets the UART instance baud rate.

This function configures the UART module baud rate. This function is used to update the UART module baud rate after the UART module is initialized by the `UART_Init`.

```
UART_SetBaudRate(UART1, 115200U, 20000000U);
```

#### Parameters

- `base` – UART peripheral base address.
- `baudRate_Bps` – UART baudrate to be set.
- `srcClock_Hz` – UART clock source frequency in Hz.

#### Return values

- `kStatus_UART_BaudrateNotSupport` – Baudrate is not support in the current clock source.
- `kStatus_Success` – Set baudrate succeeded.

**void UART\_Enable9bitMode(UART\_Type \*base, bool enable)**

Enable 9-bit data mode for UART.

This function set the 9-bit mode for UART module. The 9th bit is not used for parity thus can be modified by user.

#### Parameters

- `base` – UART peripheral base address.
- `enable` – true to enable, false to disable.

**static inline void UART\_SetMatchAddress(UART\_Type \*base, uint8\_t address1, uint8\_t address2)**

Set the UART slave address.

This function configures the address for UART module that works as slave in 9-bit data mode. One or two address fields can be configured. When the address field's match enable bit is set, the frame it receives with MSB being 1 is considered as an address frame, otherwise it is considered as data frame. Once the address frame matches one of slave's own addresses, this slave is addressed. This address frame and its following data frames are stored in the receive buffer; otherwise the frames will be discarded. To un-address a slave, just send an address frame with unmatched address.

**Note:** Any UART instance joined in the multi-slave system can work as slave. The position of the address mark is the same as the parity bit when parity is enabled for 8 bit and 9 bit data formats.

---

#### Parameters

- base – UART peripheral base address.
- address1 – UART slave address 1.
- address2 – UART slave address 2.

static inline void UART\_EnableMatchAddress(UART\_Type \*base, bool match1, bool match2)

Enable the UART match address feature.

#### Parameters

- base – UART peripheral base address.
- match1 – true to enable match address1, false to disable.
- match2 – true to enable match address2, false to disable.

static inline void UART\_Set9thTransmitBit(UART\_Type \*base)

Set UART 9th transmit bit.

#### Parameters

- base – UART peripheral base address.

static inline void UART\_Clear9thTransmitBit(UART\_Type \*base)

Clear UART 9th transmit bit.

#### Parameters

- base – UART peripheral base address.

uint32\_t UART\_GetStatusFlags(UART\_Type \*base)

Gets UART status flags.

This function gets all UART status flags. The flags are returned as the logical OR value of the enumerators `_uart_flags`. To check a specific status, compare the return value with enumerators in `_uart_flags`. For example, to check whether the TX is empty, do the following.

```
if (kUART_TxDataRegEmptyFlag & UART_GetStatusFlags(UART1))
{
    ...
}
```

#### Parameters

- base – UART peripheral base address.

#### Returns

UART status flags which are ORed by the enumerators in the `_uart_flags`.

status\_t UART\_ClearStatusFlags(UART\_Type \*base, uint32\_t mask)

Clears status flags with the provided mask.

This function clears UART status flags with a provided mask. An automatically cleared flag can't be cleared by this function. These flags can only be cleared or set by hardware. `kUART_TxDataRegEmptyFlag`, `kUART_TransmissionCompleteFlag`, `kUART_RxDataRegFullFlag`, `kUART_RxActiveFlag`, `kUART_NoiseErrorInRxDataRegFlag`, `kUART_ParityErrorInRxDataRegFlag`, `kUART_TxFifoEmptyFlag`, `kUART_RxFifoEmptyFlag`

---

**Note:** that this API should be called when the Tx/Rx is idle. Otherwise it has no effect.

---

### Parameters

- base – UART peripheral base address.
- mask – The status flags to be cleared; it is logical OR value of `_uart_flags`.

### Return values

- `kStatus_UART_FlagCannotClearManually` – The flag can't be cleared by this function but it is cleared automatically by hardware.
- `kStatus_Success` – Status in the mask is cleared.

`void UART_EnableInterrupts(UART_Type *base, uint32_t mask)`

Enables UART interrupts according to the provided mask.

This function enables the UART interrupts according to the provided mask. The mask is a logical OR of enumeration members. See `_uart_interrupt_enable`. For example, to enable TX empty interrupt and RX full interrupt, do the following.

```
UART_EnableInterrupts(UART1, kUART_TxDataRegEmptyInterruptEnable | kUART_
↳ RxDataRegFullInterruptEnable);
```

### Parameters

- base – UART peripheral base address.
- mask – The interrupts to enable. Logical OR of `_uart_interrupt_enable`.

`void UART_DisableInterrupts(UART_Type *base, uint32_t mask)`

Disables the UART interrupts according to the provided mask.

This function disables the UART interrupts according to the provided mask. The mask is a logical OR of enumeration members. See `_uart_interrupt_enable`. For example, to disable TX empty interrupt and RX full interrupt do the following.

```
UART_DisableInterrupts(UART1, kUART_TxDataRegEmptyInterruptEnable | kUART_
↳ RxDataRegFullInterruptEnable);
```

### Parameters

- base – UART peripheral base address.
- mask – The interrupts to disable. Logical OR of `_uart_interrupt_enable`.

`uint32_t UART_GetEnabledInterrupts(UART_Type *base)`

Gets the enabled UART interrupts.

This function gets the enabled UART interrupts. The enabled interrupts are returned as the logical OR value of the enumerators `_uart_interrupt_enable`. To check a specific interrupts enable status, compare the return value with enumerators in `_uart_interrupt_enable`. For example, to check whether TX empty interrupt is enabled, do the following.

```
uint32_t enabledInterrupts = UART_GetEnabledInterrupts(UART1);

if (kUART_TxDataRegEmptyInterruptEnable & enabledInterrupts)
{
    ...
}
```

### Parameters

- base – UART peripheral base address.

**Returns**

UART interrupt flags which are logical OR of the enumerators in `_uart_interrupt_enable`.

static inline uint32\_t UART\_GetDataRegisterAddress(UART\_Type \*base)

Gets the UART data register address.

This function returns the UART data register address, which is mainly used by DMA/eDMA.

**Parameters**

- base – UART peripheral base address.

**Returns**

UART data register addresses which are used both by the transmitter and the receiver.

static inline void UART\_EnableTxDMA(UART\_Type \*base, bool enable)

Enables or disables the UART transmitter DMA request.

This function enables or disables the transmit data register empty flag, S1[TDRE], to generate the DMA requests.

**Parameters**

- base – UART peripheral base address.
- enable – True to enable, false to disable.

static inline void UART\_EnableRxDMA(UART\_Type \*base, bool enable)

Enables or disables the UART receiver DMA.

This function enables or disables the receiver data register full flag, S1[RDRF], to generate DMA requests.

**Parameters**

- base – UART peripheral base address.
- enable – True to enable, false to disable.

static inline void UART\_EnableTx(UART\_Type \*base, bool enable)

Enables or disables the UART transmitter.

This function enables or disables the UART transmitter.

**Parameters**

- base – UART peripheral base address.
- enable – True to enable, false to disable.

static inline void UART\_EnableRx(UART\_Type \*base, bool enable)

Enables or disables the UART receiver.

This function enables or disables the UART receiver.

**Parameters**

- base – UART peripheral base address.
- enable – True to enable, false to disable.

static inline void UART\_WriteByte(UART\_Type \*base, uint8\_t data)

Writes to the TX register.

This function writes data to the TX register directly. The upper layer must ensure that the TX register is empty or TX FIFO has empty room before calling this function.

**Parameters**

- base – UART peripheral base address.
- data – The byte to write.

static inline uint8\_t UART\_ReadByte(UART\_Type \*base)

Reads the RX register directly.

This function reads data from the RX register directly. The upper layer must ensure that the RX register is full or that the TX FIFO has data before calling this function.

**Parameters**

- base – UART peripheral base address.

**Returns**

The byte read from UART data register.

static inline uint8\_t UART\_GetRxFifoCount(UART\_Type \*base)

Gets the rx FIFO data count.

**Parameters**

- base – UART peripheral base address.

**Returns**

rx FIFO data count.

static inline uint8\_t UART\_GetTxFifoCount(UART\_Type \*base)

Gets the tx FIFO data count.

**Parameters**

- base – UART peripheral base address.

**Returns**

tx FIFO data count.

void UART\_SendAddress(UART\_Type \*base, uint8\_t address)

Transmit an address frame in 9-bit data mode.

**Parameters**

- base – UART peripheral base address.
- address – UART slave address.

status\_t UART\_WriteBlocking(UART\_Type \*base, const uint8\_t \*data, size\_t length)

Writes to the TX register using a blocking method.

This function polls the TX register, waits for the TX register to be empty or for the TX FIFO to have room and writes data to the TX buffer.

**Parameters**

- base – UART peripheral base address.
- data – Start address of the data to write.
- length – Size of the data to write.

**Return values**

- kStatus\_UART\_Timeout – Transmission timed out and was aborted.
- kStatus\_Success – Successfully wrote all data.

*status\_t* UART\_ReadBlocking(UART\_Type \*base, uint8\_t \*data, size\_t length)

Read RX data register using a blocking method.

This function polls the RX register, waits for the RX register to be full or for RX FIFO to have data, and reads data from the TX register.

#### Parameters

- base – UART peripheral base address.
- data – Start address of the buffer to store the received data.
- length – Size of the buffer.

#### Return values

- kStatus\_UART\_RxHardwareOverrun – Receiver overrun occurred while receiving data.
- kStatus\_UART\_NoiseError – A noise error occurred while receiving data.
- kStatus\_UART\_FramingError – A framing error occurred while receiving data.
- kStatus\_UART\_ParityError – A parity error occurred while receiving data.
- kStatus\_UART\_Timeout – Transmission timed out and was aborted.
- kStatus\_Success – Successfully received all data.

void UART\_TransferCreateHandle(UART\_Type \*base, *uart\_handle\_t* \*handle,  
                                  *uart\_transfer\_callback\_t* callback, void \*userData)

Initializes the UART handle.

This function initializes the UART handle which can be used for other UART transactional APIs. Usually, for a specified UART instance, call this API once to get the initialized handle.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- callback – The callback function.
- userData – The parameter of the callback function.

void UART\_TransferStartRingBuffer(UART\_Type \*base, *uart\_handle\_t* \*handle, uint8\_t  
                                      \*ringBuffer, size\_t ringBufferSize)

Sets up the RX ring buffer.

This function sets up the RX ring buffer to a specific UART handle.

When the RX ring buffer is used, data received are stored into the ring buffer even when the user doesn't call the UART\_TransferReceiveNonBlocking() API. If data is already received in the ring buffer, the user can get the received data from the ring buffer directly.

---

**Note:** When using the RX ring buffer, one byte is reserved for internal use. In other words, if ringBufferSize is 32, only 31 bytes are used for saving data.

---

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- ringBuffer – Start address of the ring buffer for background receiving. Pass NULL to disable the ring buffer.

- ringBufferSize – Size of the ring buffer.

**void** UART\_TransferStopRingBuffer(UART\_Type \*base, *uart\_handle\_t* \*handle)

Aborts the background transfer and uninstalls the ring buffer.

This function aborts the background transfer and uninstalls the ring buffer.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.

**size\_t** UART\_TransferGetRxRingBufferLength(*uart\_handle\_t* \*handle)

Get the length of received data in RX ring buffer.

#### Parameters

- handle – UART handle pointer.

#### Returns

Length of received data in RX ring buffer.

**status\_t** UART\_TransferSendNonBlocking(UART\_Type \*base, *uart\_handle\_t* \*handle,  
*uart\_transfer\_t* \*xfer)

Transmits a buffer of data using the interrupt method.

This function sends data using an interrupt method. This is a non-blocking function, which returns directly without waiting for all data to be written to the TX register. When all data is written to the TX register in the ISR, the UART driver calls the callback function and passes the kStatus\_UART\_TxIdle as status parameter.

---

**Note:** The kStatus\_UART\_TxIdle is passed to the upper layer when all data is written to the TX register. However, it does not ensure that all data is sent out. Before disabling the TX, check the kUART\_TransmissionCompleteFlag to ensure that the TX is finished.

---

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- xfer – UART transfer structure. See *uart\_transfer\_t*.

#### Return values

- kStatus\_Success – Successfully start the data transmission.
- kStatus\_UART\_TxBusy – Previous transmission still not finished; data not all written to TX register yet.
- kStatus\_InvalidArgument – Invalid argument.

**void** UART\_TransferAbortSend(UART\_Type \*base, *uart\_handle\_t* \*handle)

Aborts the interrupt-driven data transmit.

This function aborts the interrupt-driven data sending. The user can get the remainBytes to find out how many bytes are not sent out.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.

```
status_t UART_TransferGetSendCount(UART_Type *base, uart_handle_t *handle, uint32_t *count)
```

Gets the number of bytes sent out to bus.

This function gets the number of bytes sent out to bus by using the interrupt method.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- count – Send bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No send in progress.
- kStatus\_InvalidArgument – The parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
status_t UART_TransferReceiveNonBlocking(UART_Type *base, uart_handle_t *handle, uart_transfer_t *xfer, size_t *receivedBytes)
```

Receives a buffer of data using an interrupt method.

This function receives data using an interrupt method. This is a non-blocking function, which returns without waiting for all data to be received. If the RX ring buffer is used and not empty, the data in the ring buffer is copied and the parameter `receivedBytes` shows how many bytes are copied from the ring buffer. After copying, if the data in the ring buffer is not enough to read, the receive request is saved by the UART driver. When the new data arrives, the receive request is serviced first. When all data is received, the UART driver notifies the upper layer through a callback function and passes the status parameter `kStatus_UART_RxIdle`. For example, the upper layer needs 10 bytes but there are only 5 bytes in the ring buffer. The 5 bytes are copied to the `xfer->data` and this function returns with the parameter `receivedBytes` set to 5. For the left 5 bytes, newly arrived data is saved from the `xfer->data[5]`. When 5 bytes are received, the UART driver notifies the upper layer. If the RX ring buffer is not enabled, this function enables the RX and RX interrupt to receive data to the `xfer->data`. When all data is received, the upper layer is notified.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- xfer – UART transfer structure, see `uart_transfer_t`.
- receivedBytes – Bytes received from the ring buffer directly.

#### Return values

- kStatus\_Success – Successfully queue the transfer into transmit queue.
- kStatus\_UART\_RxBusy – Previous receive request is not finished.
- kStatus\_InvalidArgument – Invalid argument.

```
void UART_TransferAbortReceive(UART_Type *base, uart_handle_t *handle)
```

Aborts the interrupt-driven data receiving.

This function aborts the interrupt-driven data receiving. The user can get the `remainBytes` to know how many bytes are not received yet.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.

```
status_t UART_TransferGetReceiveCount(UART_Type *base, uart_handle_t *handle, uint32_t *count)
```

Gets the number of bytes that have been received.

This function gets the number of bytes that have been received.

#### Parameters

- base – UART peripheral base address.
- handle – UART handle pointer.
- count – Receive bytes count.

#### Return values

- kStatus\_NoTransferInProgress – No receive in progress.
- kStatus\_InvalidArgument – Parameter is invalid.
- kStatus\_Success – Get successfully through the parameter count;

```
status_t UART_EnableTxFIFO(UART_Type *base, bool enable)
```

Enables or disables the UART Tx FIFO.

This function enables or disables the UART Tx FIFO.

param base UART peripheral base address. param enable true to enable, false to disable. retval kStatus\_Success Successfully turn on or turn off Tx FIFO. retval kStatus\_Fail Fail to turn on or turn off Tx FIFO.

```
status_t UART_EnableRxFIFO(UART_Type *base, bool enable)
```

Enables or disables the UART Rx FIFO.

This function enables or disables the UART Rx FIFO.

param base UART peripheral base address. param enable true to enable, false to disable. retval kStatus\_Success Successfully turn on or turn off Rx FIFO. retval kStatus\_Fail Fail to turn on or turn off Rx FIFO.

```
static inline void UART_SetRxFifoWatermark(UART_Type *base, uint8_t water)
```

Sets the rx FIFO watermark.

#### Parameters

- base – UART peripheral base address.
- water – Rx FIFO watermark.

```
static inline void UART_SetTxFifoWatermark(UART_Type *base, uint8_t water)
```

Sets the tx FIFO watermark.

#### Parameters

- base – UART peripheral base address.
- water – Tx FIFO watermark.

```
void UART_TransferHandleIRQ(UART_Type *base, void *irqHandle)
```

UART IRQ handle function.

This function handles the UART transmit and receive IRQ request.

#### Parameters

- base – UART peripheral base address.
- irqHandle – UART handle pointer.

void UART\_TransferHandleErrorIRQ(UART\_Type \*base, void \*irqHandle)

UART Error IRQ handle function.

This function handles the UART error IRQ request.

**Parameters**

- base – UART peripheral base address.
- irqHandle – UART handle pointer.

FSL\_UART\_DRIVER\_VERSION

UART driver version.

Error codes for the UART driver.

*Values:*

enumerator kStatus\_UART\_TxBusy

Transmitter is busy.

enumerator kStatus\_UART\_RxBusy

Receiver is busy.

enumerator kStatus\_UART\_TxIdle

UART transmitter is idle.

enumerator kStatus\_UART\_RxIdle

UART receiver is idle.

enumerator kStatus\_UART\_TxWatermarkTooLarge

TX FIFO watermark too large

enumerator kStatus\_UART\_RxWatermarkTooLarge

RX FIFO watermark too large

enumerator kStatus\_UART\_FlagCannotClearManually

UART flag can't be manually cleared.

enumerator kStatus\_UART\_Error

Error happens on UART.

enumerator kStatus\_UART\_RxRingBufferOverrun

UART RX software ring buffer overrun.

enumerator kStatus\_UART\_RxHardwareOverrun

UART RX receiver overrun.

enumerator kStatus\_UART\_NoiseError

UART noise error.

enumerator kStatus\_UART\_FramingError

UART framing error.

enumerator kStatus\_UART\_ParityError

UART parity error.

enumerator kStatus\_UART\_BaudrateNotSupport

Baudrate is not support in current clock source

enumerator kStatus\_UART\_IdleLineDetected

UART IDLE line detected.

enumerator kStatus\_UART\_Timeout

UART times out.

enum \_uart\_parity\_mode

UART parity mode.

*Values:*

enumerator kUART\_ParityDisabled

Parity disabled

enumerator kUART\_ParityEven

Parity enabled, type even, bit setting: PE | PT = 10

enumerator kUART\_ParityOdd

Parity enabled, type odd, bit setting: PE | PT = 11

enum \_uart\_stop\_bit\_count

UART stop bit count.

*Values:*

enumerator kUART\_OneStopBit

One stop bit

enumerator kUART\_TwoStopBit

Two stop bits

enum \_uart\_idle\_type\_select

UART idle type select.

*Values:*

enumerator kUART\_IdleTypeStartBit

Start counting after a valid start bit.

enumerator kUART\_IdleTypeStopBit

Start counting after a stop bit.

enum \_uart\_interrupt\_enable

UART interrupt configuration structure, default settings all disabled.

This structure contains the settings for all of the UART interrupt configurations.

*Values:*

enumerator kUART\_LinBreakInterruptEnable

LIN break detect interrupt.

enumerator kUART\_RxActiveEdgeInterruptEnable

RX active edge interrupt.

enumerator kUART\_TxDataRegEmptyInterruptEnable

Transmit data register empty interrupt.

enumerator kUART\_TransmissionCompleteInterruptEnable

Transmission complete interrupt.

enumerator kUART\_RxDataRegFullInterruptEnable

Receiver data register full interrupt.

enumerator kUART\_IdleLineInterruptEnable

Idle line interrupt.

enumerator kUART\_RxOverrunInterruptEnable  
Receiver overrun interrupt.

enumerator kUART\_NoiseErrorInterruptEnable  
Noise error flag interrupt.

enumerator kUART\_FramingErrorInterruptEnable  
Framing error flag interrupt.

enumerator kUART\_ParityErrorInterruptEnable  
Parity error flag interrupt.

enumerator kUART\_RxFifoOverflowInterruptEnable  
RX FIFO overflow interrupt.

enumerator kUART\_TxFifoOverflowInterruptEnable  
TX FIFO overflow interrupt.

enumerator kUART\_RxFifoUnderflowInterruptEnable  
RX FIFO underflow interrupt.

enumerator kUART\_AllInterruptsEnable

UART status flags.

This provides constants for the UART status flags for use in the UART functions.

*Values:*

enumerator kUART\_TxDataRegEmptyFlag  
TX data register empty flag.

enumerator kUART\_TransmissionCompleteFlag  
Transmission complete flag.

enumerator kUART\_RxDataRegFullFlag  
RX data register full flag.

enumerator kUART\_IdleLineFlag  
Idle line detect flag.

enumerator kUART\_RxOverrunFlag  
RX overrun flag.

enumerator kUART\_NoiseErrorFlag  
RX takes 3 samples of each received bit. If any of these samples differ, noise flag sets

enumerator kUART\_FramingErrorFlag  
Frame error flag, sets if logic 0 was detected where stop bit expected

enumerator kUART\_ParityErrorFlag  
If parity enabled, sets upon parity error detection

enumerator kUART\_LinBreakFlag  
LIN break detect interrupt flag, sets when LIN break char detected and LIN circuit enabled

enumerator kUART\_RxActiveEdgeFlag  
RX pin active edge interrupt flag, sets when active edge detected

enumerator kUART\_RxActiveFlag  
Receiver Active Flag (RAF), sets at beginning of valid start bit

enumerator `kUART_NoiseErrorInRxDataRegFlag`  
Noisy bit, sets if noise detected.

enumerator `kUART_ParityErrorInRxDataRegFlag`  
Parity bit, sets if parity error detected.

enumerator `kUART_TxFifoEmptyFlag`  
TXEMPT bit, sets if TX buffer is empty

enumerator `kUART_RxFifoEmptyFlag`  
RXEMPT bit, sets if RX buffer is empty

enumerator `kUART_TxFifoOverflowFlag`  
TXOF bit, sets if TX buffer overflow occurred

enumerator `kUART_RxFifoOverflowFlag`  
RXOF bit, sets if receive buffer overflow

enumerator `kUART_RxFifoUnderflowFlag`  
RXUF bit, sets if receive buffer underflow

typedef enum `_uart_parity_mode` `uart_parity_mode_t`  
UART parity mode.

typedef enum `_uart_stop_bit_count` `uart_stop_bit_count_t`  
UART stop bit count.

typedef enum `_uart_idle_type_select` `uart_idle_type_select_t`  
UART idle type select.

typedef struct `_uart_config` `uart_config_t`  
UART configuration structure.

typedef struct `_uart_transfer` `uart_transfer_t`  
UART transfer structure.

typedef struct `_uart_handle` `uart_handle_t`

typedef void (\*`uart_transfer_callback_t`)(UART\_Type \*`base`, `uart_handle_t` \*`handle`, `status_t` `status`, void \*`userData`)  
UART transfer callback function.

typedef void (\*`uart_isr_t`)(UART\_Type \*`base`, void \*`handle`)

void \*`s_uartHandle[]`  
Pointers to uart handles for each instance.

const IRQn\_Type `s_uartIRQ[]`

`uart_isr_t` `s_uartIsr`  
Pointer to uart IRQ handler for each instance.

uint32\_t `UART_GetInstance(UART_Type *base)`  
Get the UART instance from peripheral base address.

**Parameters**

- `base` – UART peripheral base address.

**Returns**  
UART instance.

`UART_RETRY_TIMES`  
Retry times for waiting flag.

```
struct __uart_config
    #include <fsl_uart.h> UART configuration structure.
```

### Public Members

```
uint32_t baudRate_Bps
    UART baud rate

uart_parity_mode_t parityMode
    Parity mode, disabled (default), even, odd

uart_stop_bit_count_t stopBitCount
    Number of stop bits, 1 stop bit (default) or 2 stop bits

uint8_t txFifoWatermark
    TX FIFO watermark

uint8_t rxFifoWatermark
    RX FIFO watermark

bool enableRxRTS
    RX RTS enable

bool enableTxCTS
    TX CTS enable

uart_idle_type_select_t idleType
    IDLE type select.

bool enableTx
    Enable TX

bool enableRx
    Enable RX
```

```
struct __uart_transfer
    #include <fsl_uart.h> UART transfer structure.
```

### Public Members

```
size_t dataSize
    The byte count to be transfer.
```

```
struct __uart_handle
    #include <fsl_uart.h> UART handle structure.
```

### Public Members

```
const uint8_t *volatile txData
    Address of remaining data to send.

volatile size_t txDataSize
    Size of the remaining data to send.

size_t txDataSizeAll
    Size of the data to send out.

uint8_t *volatile rxData
    Address of remaining data to receive.
```

`volatile size_t rxDataSize`  
Size of the remaining data to receive.

`size_t rxDataSizeAll`  
Size of the data to receive.

`uint8_t *rxRingBuffer`  
Start address of the receiver ring buffer.

`size_t rxRingBufferSize`  
Size of the ring buffer.

`volatile uint16_t rxRingBufferHead`  
Index for the driver to store received data into ring buffer.

`volatile uint16_t rxRingBufferTail`  
Index for the user to get data from the ring buffer.

`uart_transfer_callback_t callback`  
Callback function.

`void *userData`  
UART callback function parameter.

`volatile uint8_t txState`  
TX transfer state.

`volatile uint8_t rxState`  
RX transfer state

`union __unnamed27__`

### Public Members

`uint8_t *data`  
The buffer of data to be transfer.

`uint8_t *rxData`  
The buffer to receive data.

`const uint8_t *txData`  
The buffer of data to be sent.

## 2.46 VREF: Voltage Reference Driver

`status_t VREF_Init(VREF_Type *base, const vref_config_t *config)`

Enables the clock gate and configures the VREF module according to the configuration structure.

This function must be called before calling all other VREF driver functions, read/write registers, and configurations with user-defined settings. The example below shows how to set up `vref_config_t` parameters and how to call the `VREF_Init` function by passing in these parameters. This is an example.

```
vref_config_t vrefConfig;
vrefConfig.bufferMode = kVREF_ModeHighPowerBuffer;
vrefConfig.enableExternalVoltRef = false;
vrefConfig.enableLowRef = false;
VREF_Init(VREF, &vrefConfig);
```

**Parameters**

- base – VREF peripheral address.
- config – Pointer to the configuration structure.

**Return values**

- kStatus\_\_Success – run success.
- kStatus\_\_Timeout – timeout occurs.

void VREF\_Deinit(VREF\_Type \*base)

Stops and disables the clock for the VREF module.

This function should be called to shut down the module. This is an example.

```
vref_config_t vrefUserConfig;
VREF_Init(VREF);
VREF_GetDefaultConfig(&vrefUserConfig);
...
VREF_Deinit(VREF);
```

**Parameters**

- base – VREF peripheral address.

void VREF\_GetDefaultConfig(vref\_config\_t \*config)

Initializes the VREF configuration structure.

This function initializes the VREF configuration structure to default values. This is an example.

```
vrefConfig->bufferMode = kVREF_ModeHighPowerBuffer;
vrefConfig->enableExternalVoltRef = false;
vrefConfig->enableLowRef = false;
```

**Parameters**

- config – Pointer to the initialization structure.

status\_t VREF\_SetTrimVal(VREF\_Type \*base, uint8\_t trimValue)

Sets a TRIM value for the reference voltage.

This function sets a TRIM value for the reference voltage. Note that the TRIM value maximum is 0x3F.

**Parameters**

- base – VREF peripheral address.
- trimValue – Value of the trim register to set the output reference voltage (maximum 0x3F (6-bit)).

**Return values**

- kStatus\_\_Success – run success.
- kStatus\_\_Timeout – timeout occurs.

static inline uint8\_t VREF\_GetTrimVal(VREF\_Type \*base)

Reads the value of the TRIM meaning output voltage.

This function gets the TRIM value from the TRM register.

**Parameters**

- base – VREF peripheral address.

**Returns**

Six-bit value of trim setting.

`status_t VREF_SetLowReferenceTrimVal(VREF_Type *base, uint8_t trimValue)`

Sets the TRIM value for the low voltage reference.

This function sets the TRIM value for low reference voltage. Note the following.

- The TRIM value maximum is 0x05U
- The values 111b and 110b are not valid/allowed.

**Parameters**

- `base` – VREF peripheral address.
- `trimValue` – Value of the trim register to set output low reference voltage (maximum 0x05U (3-bit)).

**Return values**

- `kStatus_Success` – run success.
- `kStatus_Timeout` – timeout occurs.

`static inline uint8_t VREF_GetLowReferenceTrimVal(VREF_Type *base)`

Reads the value of the TRIM meaning output voltage.

This function gets the TRIM value from the VREFL\_TRM register.

**Parameters**

- `base` – VREF peripheral address.

**Returns**

Three-bit value of the trim setting.

`FSL_VREF_DRIVER_VERSION`

Version 2.1.3.

`VREF_INTERNAL_VOLTAGE_STABLE_TIMEOUT`

Max loops to wait for VREF internal voltage stable.

This parameter defines how many loops to check completion before return timeout. If defined as 0, driver will wait forever until completion.

`enum _vref_buffer_mode`

VREF modes.

*Values:*

enumerator `kVREF_ModeBandgapOnly`

Bandgap on only, for stabilization and startup

enumerator `kVREF_ModeHighPowerBuffer`

High-power buffer mode enabled

enumerator `kVREF_ModeLowPowerBuffer`

Low-power buffer mode enabled

`typedef enum _vref_buffer_mode vref_buffer_mode_t`

VREF modes.

`typedef struct _vref_config vref_config_t`

The description structure for the VREF module.

`VREF_SC_MODE_LV`

VREF\_SC\_REGEN

VREF\_SC\_VREFEN

VREF\_SC\_ICOMPEN

VREF\_SC\_REGEN\_MASK

VREF\_SC\_VREFST\_MASK

VREF\_SC\_VREFEN\_MASK

VREF\_SC\_MODE\_LV\_MASK

VREF\_SC\_ICOMPEN\_MASK

TRM

VREF\_TRM\_TRIM

VREF\_TRM\_CHOPEN\_MASK

VREF\_TRM\_TRIM\_MASK

VREF\_TRM\_CHOPEN\_SHIFT

VREF\_TRM\_TRIM\_SHIFT

VREF\_SC\_MODE\_LV\_SHIFT

VREF\_SC\_REGEN\_SHIFT

VREF\_SC\_VREFST\_SHIFT

VREF\_SC\_ICOMPEN\_SHIFT

struct \_\_vref\_config

*#include <fsl\_vref.h>* The description structure for the VREF module.

### Public Members

*vref\_buffer\_mode\_t* bufferMode

Buffer mode selection

bool enableLowRef

Set VREFL (0.4 V) reference buffer enable or disable

bool enableExternalVoltRef

Select external voltage reference or not (internal)

## 2.47 WDOG: Watchdog Timer Driver

void WDOG\_GetDefaultConfig(*wdog\_config\_t* \*config)

Initializes the WDOG configuration structure.

This function initializes the WDOG configuration structure to default values. The default values are as follows.

```
wdogConfig->enableWdog = true;
wdogConfig->clockSource = kWDOG_LpoClockSource;
wdogConfig->prescaler = kWDOG_ClockPrescalerDivide1;
wdogConfig->workMode.enableWait = true;
wdogConfig->workMode.enableStop = false;
wdogConfig->workMode.enableDebug = false;
wdogConfig->enableUpdate = true;
wdogConfig->enableInterrupt = false;
wdogConfig->enableWindowMode = false;
wdogConfig->windowValue = 0;
wdogConfig->timeoutValue = 0xFFFFU;
```

**See also:**

wdog\_config\_t

**Parameters**

- config – Pointer to the WDOG configuration structure.

void WDOG\_Init(WDOG\_Type \*base, const *wdog\_config\_t* \*config)

Initializes the WDOG.

This function initializes the WDOG. When called, the WDOG runs according to the configuration. To reconfigure WDOG without forcing a reset first, enableUpdate must be set to true in the configuration.

This is an example.

```
wdog_config_t config;
WDOG_GetDefaultConfig(&config);
config.timeoutValue = 0x7ffU;
config.enableUpdate = true;
WDOG_Init(wdog_base, &config);
```

**Parameters**

- base – WDOG peripheral base address
- config – The configuration of WDOG

void WDOG\_Deinit(WDOG\_Type \*base)

Shuts down the WDOG.

This function shuts down the WDOG. Ensure that the WDOG\_STCTRLH.ALLOWUPDATE is 1 which indicates that the register update is enabled.

void WDOG\_SetTestModeConfig(WDOG\_Type \*base, *wdog\_test\_config\_t* \*config)

Configures the WDOG functional test.

This function is used to configure the WDOG functional test. When called, the WDOG goes into test mode and runs according to the configuration. Ensure that the WDOG\_STCTRLH.ALLOWUPDATE is 1 which means that the register update is enabled.

This is an example.

```
wdog_test_config_t test_config;
test_config.testMode = kWDOG_QuickTest;
test_config.timeoutValue = 0xffffu;
WDOG_SetTestModeConfig(wdog_base, &test_config);
```

**Parameters**

- base – WDOG peripheral base address
- config – The functional test configuration of WDOG

static inline void WDOG\_Enable(WDOG\_Type \*base)

Enables the WDOG module.

This function write value into WDOG\_STCTRLH register to enable the WDOG, it is a write-once register, make sure that the WCT window is still open and this register has not been written in this WCT while this function is called.

#### Parameters

- base – WDOG peripheral base address

static inline void WDOG\_Disable(WDOG\_Type \*base)

Disables the WDOG module.

This function writes a value into the WDOG\_STCTRLH register to disable the WDOG. It is a write-once register. Ensure that the WCT window is still open and that register has not been written to in this WCT while the function is called.

#### Parameters

- base – WDOG peripheral base address

static inline void WDOG\_EnableInterrupts(WDOG\_Type \*base, uint32\_t mask)

Enables the WDOG interrupt.

This function writes a value into the WDOG\_STCTRLH register to enable the WDOG interrupt. It is a write-once register. Ensure that the WCT window is still open and the register has not been written to in this WCT while the function is called.

#### Parameters

- base – WDOG peripheral base address
- mask – The interrupts to enable The parameter can be combination of the following source if defined.
  - kWDOG\_InterruptEnable

static inline void WDOG\_DisableInterrupts(WDOG\_Type \*base, uint32\_t mask)

Disables the WDOG interrupt.

This function writes a value into the WDOG\_STCTRLH register to disable the WDOG interrupt. It is a write-once register. Ensure that the WCT window is still open and the register has not been written to in this WCT while the function is called.

#### Parameters

- base – WDOG peripheral base address
- mask – The interrupts to disable The parameter can be combination of the following source if defined.
  - kWDOG\_InterruptEnable

uint32\_t WDOG\_GetStatusFlags(WDOG\_Type \*base)

Gets the WDOG all status flags.

This function gets all status flags.

This is an example for getting the Running Flag.

```
uint32_t status;  
status = WDOG_GetStatusFlags (wdog_base) & kWDOG_RunningFlag;
```

**See also:**`_wdog_status_flags_t`

- true: a related status flag has been set.
- false: a related status flag is not set.

**Parameters**

- base – WDOG peripheral base address

**Returns**

State of the status flag: asserted (true) or not-asserted (false).

`void WDOG_ClearStatusFlags(WDOG_Type *base, uint32_t mask)`

Clears the WDOG flag.

This function clears the WDOG status flag.

This is an example for clearing the timeout (interrupt) flag.

```
WDOG_ClearStatusFlags(wdog_base, kWDOG_TimeoutFlag);
```

**Parameters**

- base – WDOG peripheral base address
- mask – The status flags to clear. The parameter could be any combination of the following values. `kWDOG_TimeoutFlag`

`static inline void WDOG_SetTimeoutValue(WDOG_Type *base, uint32_t timeoutCount)`

Sets the WDOG timeout value.

This function sets the timeout value. It should be ensured that the time-out value for the WDOG is always greater than  $2 \times \text{WCT time} + 20$  bus clock cycles. This function writes a value into `WDOG_TOVALH` and `WDOG_TOVALL` registers which are write-once. Ensure the WCT window is still open and the two registers have not been written to in this WCT while the function is called.

**Parameters**

- base – WDOG peripheral base address
- timeoutCount – WDOG timeout value; count of WDOG clock tick.

`static inline void WDOG_SetWindowValue(WDOG_Type *base, uint32_t windowValue)`

Sets the WDOG window value.

This function sets the WDOG window value. This function writes a value into `WDOG_WINH` and `WDOG_WINL` registers which are write-once. Ensure the WCT window is still open and the two registers have not been written to in this WCT while the function is called.

**Parameters**

- base – WDOG peripheral base address
- windowValue – WDOG window value.

`static inline void WDOG_Unlock(WDOG_Type *base)`

Unlocks the WDOG register written.

This function unlocks the WDOG register written. Before starting the unlock sequence and following configuration, disable the global interrupts. Otherwise, an interrupt may invalidate the unlocking sequence and the WCT may expire. After the configuration finishes, re-enable the global interrupts.

**Parameters**

- base – WDOG peripheral base address

void WDOG\_Refresh(WDOG\_Type \*base)

Refreshes the WDOG timer.

This function feeds the WDOG. This function should be called before the WDOG timer is in timeout. Otherwise, a reset is asserted.

#### Parameters

- base – WDOG peripheral base address

static inline uint16\_t WDOG\_GetResetCount(WDOG\_Type \*base)

Gets the WDOG reset count.

This function gets the WDOG reset count value.

#### Parameters

- base – WDOG peripheral base address

#### Returns

WDOG reset count value.

static inline void WDOG\_ClearResetCount(WDOG\_Type \*base)

Clears the WDOG reset count.

This function clears the WDOG reset count value.

#### Parameters

- base – WDOG peripheral base address

FSL\_WDOG\_DRIVER\_VERSION

Defines WDOG driver version 2.0.2.

WDOG\_FIRST\_WORD\_OF\_UNLOCK

First word of unlock sequence

WDOG\_SECOND\_WORD\_OF\_UNLOCK

Second word of unlock sequence

WDOG\_FIRST\_WORD\_OF\_REFRESH

First word of refresh sequence

WDOG\_SECOND\_WORD\_OF\_REFRESH

Second word of refresh sequence

enum \_\_wdog\_clock\_source

Describes WDOG clock source.

*Values:*

enumerator kWDOG\_LpoClockSource

WDOG clock sourced from LPO

enumerator kWDOG\_AlternateClockSource

WDOG clock sourced from alternate clock source

enum \_\_wdog\_clock\_prescaler

Describes the selection of the clock prescaler.

*Values:*

enumerator kWDOG\_ClockPrescalerDivide1

Divided by 1

enumerator kWDOG\_\_ClockPrescalerDivide2

Divided by 2

enumerator kWDOG\_\_ClockPrescalerDivide3

Divided by 3

enumerator kWDOG\_\_ClockPrescalerDivide4

Divided by 4

enumerator kWDOG\_\_ClockPrescalerDivide5

Divided by 5

enumerator kWDOG\_\_ClockPrescalerDivide6

Divided by 6

enumerator kWDOG\_\_ClockPrescalerDivide7

Divided by 7

enumerator kWDOG\_\_ClockPrescalerDivide8

Divided by 8

enum \_\_wdog\_test\_mode

Describes WDOG test mode.

*Values:*

enumerator kWDOG\_QuickTest

Selects quick test

enumerator kWDOG\_ByteTest

Selects byte test

enum \_\_wdog\_tested\_byte

Describes WDOG tested byte selection in byte test mode.

*Values:*

enumerator kWDOG\_TestByte0

Byte 0 selected in byte test mode

enumerator kWDOG\_TestByte1

Byte 1 selected in byte test mode

enumerator kWDOG\_TestByte2

Byte 2 selected in byte test mode

enumerator kWDOG\_TestByte3

Byte 3 selected in byte test mode

enum \_\_wdog\_interrupt\_enable\_t

WDOG interrupt configuration structure, default settings all disabled.

This structure contains the settings for all of the WDOG interrupt configurations.

*Values:*

enumerator kWDOG\_InterruptEnable

WDOG timeout generates an interrupt before reset

enum \_\_wdog\_status\_flags\_t

WDOG status flags.

This structure contains the WDOG status flags for use in the WDOG functions.

*Values:*

enumerator `kWDOG_RunningFlag`  
Running flag, set when WDOG is enabled

enumerator `kWDOG_TimeoutFlag`  
Interrupt flag, set when an exception occurs

typedef enum `_wdog_clock_source` `wdog_clock_source_t`  
Describes WDOG clock source.

typedef struct `_wdog_work_mode` `wdog_work_mode_t`  
Defines WDOG work mode.

typedef enum `_wdog_clock_prescaler` `wdog_clock_prescaler_t`  
Describes the selection of the clock prescaler.

typedef struct `_wdog_config` `wdog_config_t`  
Describes WDOG configuration structure.

typedef enum `_wdog_test_mode` `wdog_test_mode_t`  
Describes WDOG test mode.

typedef enum `_wdog_tested_byte` `wdog_tested_byte_t`  
Describes WDOG tested byte selection in byte test mode.

typedef struct `_wdog_test_config` `wdog_test_config_t`  
Describes WDOG test mode configuration structure.

`WDOG_WCT_INSTRUCITON_COUNT`  
< Watchdog configuration time window

struct `_wdog_work_mode`  
`#include <fsl_wdog.h>` Defines WDOG work mode.

### Public Members

bool `enableWait`  
Enables or disables WDOG in wait mode

bool `enableStop`  
Enables or disables WDOG in stop mode

bool `enableDebug`  
Enables or disables WDOG in debug mode

struct `_wdog_config`  
`#include <fsl_wdog.h>` Describes WDOG configuration structure.

### Public Members

bool `enableWdog`  
Enables or disables WDOG

`wdog_clock_source_t` `clockSource`  
Clock source select

`wdog_clock_prescaler_t` `prescaler`  
Clock prescaler value

`wdog_work_mode_t` `workMode`  
Configures WDOG work mode in debug stop and wait mode

`bool enableUpdate`  
Update write-once register enable

`bool enableInterrupt`  
Enables or disables WDOG interrupt

`bool enableWindowMode`  
Enables or disables WDOG window mode

`uint32_t windowValue`  
Window value

`uint32_t timeoutValue`  
Timeout value

`struct _wdog_test_config`  
*#include <fsl\_wdog.h>* Describes WDOG test mode configuration structure.

### Public Members

`wdog_test_mode_t testMode`  
Selects test mode

`wdog_tested_byte_t testedByte`  
Selects tested byte in byte test mode

`uint32_t timeoutValue`  
Timeout value

## 2.48 XBAR: Inter-Peripheral Crossbar Switch

`void XBAR_Init(XBAR_Type *base)`  
Initializes the XBAR modules.  
This function un-gates the XBAR clock.

### Parameters

- `base` – XBAR peripheral address.

`void XBAR_Deinit(XBAR_Type *base)`  
Shutdown the XBAR modules.  
This function disables XBAR clock.

### Parameters

- `base` – XBAR peripheral address.

`void XBAR_SetSignalsConnection(XBAR_Type *base, xbar_input_signal_t input, xbar_output_signal_t output)`

Set connection between the selected `XBAR_IN[*]` input and the `XBAR_OUT[*]` output signal.  
This function connects the XBAR input to the selected XBAR output. If more than one XBAR module is available, only the inputs and outputs from the same module can be connected.

Example:

```
XBAR_SetSignalsConnection(XBAR, kXBAR_InputTMR_CH0_Output, kXBAR_OutputXB_DMA_
↪INT2);
```

**Parameters**

- base – XBAR peripheral address
- input – XBAR input signal.
- output – XBAR output signal.

`void XBAR_ClearStatusFlags(XBAR_Type *base, uint32_t mask)`

Clears the edge detection status flags of relative mask.

**Parameters**

- base – XBAR peripheral address
- mask – the status flags to clear.

`uint32_t XBAR_GetStatusFlags(XBAR_Type *base)`

Gets the active edge detection status.

This function gets the active edge detect status of all XBAR\_OUTs. If the active edge occurs, the return value is asserted. When the interrupt or the DMA functionality is enabled for the XBAR\_OUTx, this field is 1 when the interrupt or DMA request is asserted and 0 when the interrupt or DMA request has been cleared.

Example:

```
uint32_t status;  
  
status = XBAR_GetStatusFlags(XBAR);
```

**Parameters**

- base – XBAR peripheral address.

**Returns**

the mask of these status flag bits.

`void XBAR_SetOutputSignalConfig(XBAR_Type *base, xbar_output_signal_t output, const xbar_control_config_t *controlConfig)`

Configures the XBAR control register.

This function configures an XBAR control register. The active edge detection and the DMA/IRQ function on the corresponding XBAR output can be set.

Example:

```
xbar_control_config_t userConfig;  
userConfig.activeEdge = kXBAR_EdgeRising;  
userConfig.requestType = kXBAR_RequestInterruptEnalbe;  
XBAR_SetOutputSignalConfig(XBAR, kXBAR_OutputXB_DMA_INT0, &userConfig);
```

**Parameters**

- base – XBAR peripheral address
- output – XBAR output number.
- controlConfig – Pointer to structure that keeps configuration of control register.

`enum __xbar_active_edge`

XBAR active edge for detection.

Values:

enumerator kXBAR\_EdgeNone

Edge detection status bit never asserts.

enumerator kXBAR\_EdgeRising

Edge detection status bit asserts on rising edges.

enumerator kXBAR\_EdgeFalling

Edge detection status bit asserts on falling edges.

enumerator kXBAR\_EdgeRisingAndFalling

Edge detection status bit asserts on rising and falling edges.

enumerator kXBAR\_EdgeMax

Max value.

enum \_xbar\_request

Defines the XBAR DMA and interrupt configurations.

*Values:*

enumerator kXBAR\_RequestDisable

Interrupt and DMA are disabled.

enumerator kXBAR\_RequestDMAEnable

DMA enabled, interrupt disabled.

enumerator kXBAR\_RequestInterruptEnalbe

Interrupt enabled, DMA disabled.

enumerator kXBAR\_RequestMax

Max value.

enum \_xbar\_status\_flag\_t

XBAR status flags.

This provides constants for the XBAR status flags for use in the XBAR functions.

*Values:*

enumerator kXBAR\_EdgeDetectionOut0

XBAR\_OUT0 active edge interrupt flag, sets when active edge detected.

typedef enum \_xbar\_active\_edge xbar\_active\_edge\_t

XBAR active edge for detection.

typedef enum \_xbar\_request xbar\_request\_t

Defines the XBAR DMA and interrupt configurations.

typedef enum \_xbar\_status\_flag\_t xbar\_status\_flag\_t

XBAR status flags.

This provides constants for the XBAR status flags for use in the XBAR functions.

typedef struct \_xbar\_control\_config xbar\_control\_config\_t

Defines the configuration structure of the XBAR control register.

This structure keeps the configuration of XBAR control register for one output. Control registers are available only for a few outputs. Not every XBAR module has control registers.

FSL\_XBAR\_DRIVER\_VERSION

XBAR\_SELx(base, output)

XBAR\_WR\_SELx\_SELx(base, input, output)

struct `_xbar_control_config`

*#include <fsl\_xbar.h>* Defines the configuration structure of the XBAR control register.

This structure keeps the configuration of XBAR control register for one output. Control registers are available only for a few outputs. Not every XBAR module has control registers.

### Public Members

*xbar\_active\_edge\_t* activeEdge

Active edge to be detected.

*xbar\_request\_t* requestType

Selects DMA/Interrupt request.

# Chapter 3

## Middleware

### 3.1 Motor Control

#### 3.1.1 FreeMASTER

*Communication Driver User Guide*

##### Introduction

**What is FreeMASTER?** FreeMASTER is a PC-based application developed by NXP for NXP customers. It is a versatile tool usable as a real-time monitor, visualization tool, and a graphical control panel of embedded applications based on the NXP processing units.

This document describes the embedded-side software driver which implements an interface between the application and the host PC. The interface covers the following communication:

- **Serial** UART communication either over plain RS232 interface or more typically over a USB-to-Serial either external or built in a debugger probe.
- **USB** direct connection to target microcontroller
- **CAN bus**
- **TCP/IP network** wired or WiFi
- **Segger J-Link RTT**
- **JTAG** debug port communication
- ...and all of the above also using a **Zephyr** generic drivers.

The driver also supports so-called “packet-driven BDM” interface which enables a protocol-based communication over a debugging port. The BDM stands for Background Debugging Module and its physical implementation is different on each platform. Some platforms leverage a semi-standard JTAG interface, other platforms provide a custom implementation called BDM. Regardless of the name, this debugging interface enables non-intrusive access to the memory space while the target CPU is running. For basic memory read and write operations, there is no communication driver required on the target when communicating with the host PC. Use this driver to get more advanced FreeMASTER protocol features over the BDM interface. The driver must be configured for the packet-driven BDM mode, in which the host PC uses the debugging interface to write serial command frames directly to the target memory buffer. The same method is then used to read response frames from that memory buffer.

Similar to “packet-driven BDM”, the FreeMASTER also supports a communication over [J-Link RTT](<https://www.segger.com/products/debug-probes/j-link/technology/about-real-time-transfer/>) interface defined by SEGGER Microcontroller GmbH for ARM CortexM-based microcontrollers. This method also uses JTAG physical interface and enables high-speed real time communication to run over the same channel as used for application debugging.

**Driver version 3** This document describes version 3 of the FreeMASTER Communication Driver. This version features the implementation of the new Serial Protocol, which significantly extends the features and security of its predecessor. The new protocol internal number is v4 and its specification is available in the documentation accompanying the driver code.

Driver V3 is deployed to modern 32-bit MCU platforms first, so the portfolio of supported platforms is smaller than for the previous V2 versions. It is recommended to keep using the V2 driver for legacy platforms, such as S08, S12, ColdFire, or Power Architecture. Reach out to [FreeMASTER community](#) or to the local NXP representative with requests for more information or to port the V3 driver to legacy MCU devices.

Thanks to a layered approach, the new driver simplifies the porting of the driver to new UART, CAN or networking communication interfaces significantly. Users are encouraged to port the driver to more NXP MCU platforms and contribute the code back to NXP for integration into future releases. Existing code and low-level driver layers may be used as an example when porting to new targets.

**Note:** Using the FreeMASTER tool and FreeMASTER Communication Driver is only allowed in systems based on NXP microcontroller or microprocessor unit. Use with non-NXP MCU platforms is **not permitted** by the license terms.

**Target platforms** The driver implementation uses the following abstraction mechanisms which simplify driver porting and supporting new communication modules:

- **General CPU Platform** (see source code in the `src/platforms` directory). The code in this layer is only specific to native data type sizes and CPU architectures (for example; alignment-aware memory copy routines). This driver version brings two generic implementations of 32-bit platforms supporting both little-endian and big-endian architectures. There are also implementations customized for the 56F800E family of digital signal controllers and S12Z MCUs. **Zephyr** is treated as a specific CPU platform as it brings unified user configuration (Kconfig) and generic hardware device drivers. With Zephyr, the transport layer and low-level communication layers described below are configured automatically using Kconfig and Device Tree technologies.
- **Transport Communication Layer** - The Serial, CAN, Networking, PD-BDM, and other methods of transport logic are implemented as a driver layer called `FMSTR_TRANSPORT` with a uniform API. A support of the Network transport also extends single-client modes of operation which are native for Serial, USB and CAN by a concept of multiple client sessions.
- **Low-level Communication Driver** - Each type of transport further defines a low-level API used to access the physical communication module. For example, the Serial transport defines a character-oriented API implemented by different serial communication modules like UART, LPUART, USART, and also USB-CDC. Similarly, the CAN transport defines a message-oriented API implemented by the FlexCAN or MCAN modules. Moreover, there are multiple different implementations for the same kind of communication peripherals. The difference between the implementation is in the way the low-level hardware registers are accessed. The `mcuxsdk` folder contains implementations which use MCUXpresso SDK drivers. These drivers should be used in applications based on the NXP MCUXpresso SDK. The “ampsdk” drivers target automotive-specific MCUs and their respective SDKs. The “dreg” implementations use a plain C-language access to hardware register addresses which makes it a universal and the most portable solution. In this case, users are encouraged to add more drivers for other communication modules or other respective SDKs and contribute the code back to NXP for integration.

The low-level drivers defined for the Networking transport enable datagram-oriented UDP and stream TCP communication. This implementation is demonstrated using the lwIP software stack but shall be portable to other TCP/IP stacks. It may sound surprisingly, but also the Segger J-Link RTT communication driver is linked to the Networking transport (RTT is stream oriented communication handled similarly to TCP).

**Replacing existing drivers** For all supported platforms, the driver described in this document replaces the V2 implementation and also older driver implementations that were available separately for individual platforms (PC Master SCI drivers).

**Clocks, pins, and peripheral initialization** The FreeMASTER communication driver is only responsible for runtime processing of the communication and must be integrated with an user application code to function properly. The user application code is responsible for general initialization of clock sources, pin multiplexers, and peripheral registers related to the communication speed. Such initialization should be done before calling the FMSTR\_Init function.

It is recommended to develop the user application using one of the Software Development Kits (SDKs) available from third parties or directly from NXP, such as MCUXpresso SDK, MCUXpresso IDE, and related tools. This approach simplifies the general configuration process significantly.

**MCUXpresso SDK** The MCUXpresso SDK is a software package provided by NXP which contains the device initialization code, linker files, and software drivers with example applications for the NXP family of MCUs. The MCUXpresso Config Tools may be used to generate the clock-setup and pin-multiplexer setup code suitable for the selected processor.

The MCUXpresso SDK also contains this FreeMASTER communication driver as a “middleware” component which may be downloaded along with the example applications from <https://mcuxpresso.nxp.com/en/welcome>.

**MCUXpresso SDK on GitHub** The FreeMASTER communication driver is also released as one of the middleware components of the MCUXpresso SDK on the GitHub. This release enables direct integration of the FreeMASTER source code Git repository into a target applications including Zephyr applications.

Related links:

- [The official FreeMASTER middleware repository.](#)
- [Online version of this document](#)

**FreeMASTER in Zephyr** The FreeMASTER middleware repository can be used with MCUXpresso SDK as well as a Zephyr module. Zephyr-specific samples which include examples of Kconfig and Device Tree configurations for Serial, USB and Network communications are available in separate repository. West manifest in this sample repository fetches the full Zephyr package including the FreeMASTER middleware repository used as a Zephyr module.

## Example applications

**MCUX SDK Example applications** There are several example applications available for each supported MCU platform.

- **fmstr\_uart** demonstrates a plain serial transmission, typically connecting to a computer’s physical or virtual COM port. The typical transmission speed is 115200 bps.

- **fmstr\_can** demonstrates CAN bus communication. This requires a suitable CAN interface connected to the computer and interconnected with the target MCU using a properly terminated CAN bus. The typical transmission speed is 500 kbps. A FreeMASTER-over-CAN communication plug-in must be used.
- **fmstr\_usb\_cdc** uses an on-chip USB controller to implement a CDC communication class. It is connected directly to a computer's USB port and creates a virtual COM port device. The typical transmission speed is above 1 Mbps.
- **fmstr\_net** demonstrates the Network communication over UDP or TCP protocol. Existing examples use lwIP stack to implement the communication, but in general, it shall be possible to use any other TCP/IP stack to achieve the same functionality.
- **fmstr\_wifi** is the fmstr\_net application modified to use a WiFi network interface instead of a wired Ethernet connection.
- **fmstr\_rtt** demonstrates the communication over SEGGER J-Link RTT interface. Both fmstr\_net and fmstr\_rtt examples require the FreeMASTER TCP/UDP communication plug-in to be used on the PC host side.
- **fmstr\_eonce** uses the real-time data unit on the JTAG EOnCE module of the 56F800E family to implement pseudo-serial communication over the JTAG port. The typical transmission speed is around 10 kbps. This communication requires FreeMASTER JTAG/EOnCE communication plug-in.
- **fmstr\_pd\_bdm** uses JTAG or BDM debugging interface to access the target RAM directly while the CPU is running. Note that such approach can be used with any MCU application, even without any special driver code. The computer reads from and writes into the RAM directly without CPU intervention. The Packet-Driven BDM (PD-BDM) communication uses the same memory access to exchange command and response frames. With PD-BDM, the FreeMASTER tool is able to go beyond basic memory read/write operations and accesses also advanced features like Recorder, TSA, or Pipes. The typical transmission speed is around 10 kbps. A PD-BDM communication plug-in must be used in FreeMASTER and configured properly for the selected debugging interface. Note that this communication cannot be used while a debugging interface is used by a debugger session.
- **fmstr\_any** is a special example application which demonstrates how the NXP MCUXpresso Config Tools can be used to configure pins, clocks, peripherals, interrupts, and even the FreeMASTER “middleware” driver features in a graphical and user friendly way. The user can switch between the Serial, CAN, and other ways of communication and generate the required initialization code automatically.

**Zephyr sample applications** Zephyr sample applications demonstrate Kconfig and Device Tree configuration which configure the FreeMASTER middleware module for a selected communication option (Serial, CAN, Network or RTT).

Refer to *readme.md* files in each sample directory for description of configuration options required to implement FreeMASTER connectivity.

## Description

This section shows how to add the FreeMASTER Communication Driver into application and how to configure the connection to the FreeMASTER visualization tool.

**Features** The FreeMASTER driver implements the FreeMASTER protocol V4 and provides the following features which may be accessed using the FreeMASTER visualization tool:

- Read/write access to any memory location on the target.
- Optional password protection of the read, read/write, and read/write/flash access levels.

- Atomic bit manipulation on the target memory (bit-wise write access).
- Optimal size-aligned access to memory which is also suitable to access the peripheral register space.
- Oscilloscope access—real-time access to target variables. The sample rate may be limited by the communication speed.
- Recorder— access to the fast transient recorder running on the board as a part of the FreeMASTER driver. The sample rate is only limited by the MCU CPU speed. The length of the data recorded depends on the amount of available memory.
- Multiple instances of Oscilloscopes and Recorders without the limitation of maximum number of variables.
- Application commands—high-level message delivery from the PC to the application.
- TSA tables—describing the data types, variables, files, or hyperlinks exported by the target application. The TSA newly supports also non-memory mapped resources like external EEPROM or SD Card files.
- Pipes—enabling the buffered stream-oriented data exchange for a general-purpose terminal-like communication, diagnostic data streaming, or other data exchange.

The FreeMASTER driver features:

- Full FreeMASTER protocol V4 implementation with a new V4 style of CRC used.
- Layered approach supporting Serial, CAN, Network, PD-BDM, and other transports.
- Layered low-level Serial transport driver architecture enabling to select UART, LPUART, USART, and other physical implementations of serial interfaces, including USB-CDC.
- Layered low-level CAN transport driver architecture enabling to select FlexCAN, msCAN, MCAN, and other physical implementations of the CAN interface.
- Layered low-level Networking transport enabling to select TCP, UDP or J-Link RTT communication.
- TSA support to write-protect memory regions or individual variables and to deny the access to the unsafe memory.
- The pipe callback handlers are invoked whenever new data is available for reading from the pipe.
- Two Serial Single-Wire modes of operation are enabled. The “external” mode has the RX and TX shorted on-board. The “true” single-wire mode interconnects internally when the MCU or UART modules support it.

The following sections briefly describe all FreeMASTER features implemented by the driver. See the PC-based FreeMASTER User Manual for more details on how to use the features to monitor, tune, or control an embedded application.

**Board Detection** The FreeMASTER protocol V4 defines the standard set of configuration values which the host PC tool reads to identify the target and to access other target resources properly. The configuration includes the following parameters:

- Version of the driver and the version of the protocol implemented.
- MTU as the Maximum size of the Transmission Unit (for example; communication buffer size).
- Application name, description, and version strings.
- Application build date and time as a string.
- Target processor byte ordering (little/big endian).
- Protection level that requires password authentication.

- Number of the Recorder and Oscilloscope instances.
- RAM Base Address for optimized memory access commands.

**Memory Read** This basic feature enables the host PC to read any data memory location by specifying the address and size of the required memory area. The device response frame must be shorter than the MTU to fit into the outgoing communication buffer. To read a device memory of any size, the host uses the information retrieved during the Board Detection and splits the large-block request to multiple partial requests.

The driver uses size-aligned operations to read the target memory (for example; uses proper read-word instruction when an address is aligned to 4 bytes).

**Memory Write** Similarly to the Memory Read operation, the Memory Write feature enables to write to any RAM memory location on the target device. A single write command frame must be shorter than the MTU to fit into the target communication buffer. Larger requests must be split into smaller ones.

The driver uses size-aligned operations to write to the target memory (for example; uses proper write-word instruction when an address is aligned to 4 bytes).

**Masked Memory Write** To implement the write access to a single bit or a group of bits of target variables, the Masked Memory Write feature is available in the FreeMASTER protocol and it is supported by the driver using the Read-Modify-Write approach.

Be careful when writing to bit fields of volatile variables that are also modified in an application interrupt. The interrupt may be serviced in the middle of a read-modify-write operation and it may cause data corruption.

**Oscilloscope** The protocol and driver enables any number of variables to be read at once with a single request from the host. This feature is called Oscilloscope and the FreeMASTER tool uses it to display a real-time graph of variable values.

The driver can be configured to support any number of Oscilloscope instances and enable simultaneously running graphs to be displayed on the host computer screen.

**Recorder** The protocol enables the host to select target variables whose values are then periodically recorded into a dedicated on-board memory buffer. After such data sampling stops (either on a host request or by evaluating a threshold-crossing condition), the data buffer is downloaded to the host and displayed as a graph. The data sampling rate is not limited by the speed of the communication line, so it enables displaying the variable transitions in a very high resolution.

The driver can be configured to support multiple Recorder instances and enable multiple recorder graphs to be displayed on the host screen. Having multiple recorders also enables setting the recording point differently for each instance. For example; one instance may be recording data in a general timer interrupt while another instance may record at a specific control algorithm time in the PWM interrupt.

**TSA** With the TSA feature, data types and variables can be described directly in the application source code. Such information is later provided to the FreeMASTER tool which may use it instead of reading symbol data from the application ELF executable file.

The information is encoded as so-called TSA tables which become direct part of the application code. The TSA tables contain descriptors of variables that shall be visible to the host tool. The descriptors can describe the memory areas by specifying the address and size of the memory

block or more conveniently using the C variable names directly. Different set of TSA descriptors can be used to encode information about the structure types, unions, enumerations, or arrays.

The driver also supports special types of TSA table entries to describe user resources like external EEPROM and SD Card files, memory-mapped files, virtual directories, web URL hyperlinks, and constant enumerations.

**TSA Safety** When the TSA is enabled in the application, the TSA Safety can be enabled and validate the memory accesses directly by the embedded-side driver. When the TSA Safety is turned on, any memory request received from the host is validated and accepted only if it belongs to a TSA-described object. The TSA entries can be declared as Read-Write or Read-Only so that the driver can actively deny the write access to the Read-Only objects.

**Application commands** The Application Commands are high-level messages that can be delivered from the PC Host to the embedded application for further processing. The embedded application can either poll the status, or be called back when a new Application Command arrives to be processed. After the embedded application acknowledges that the command is handled, the host receives the Result Code and reads the other return data from memory. Both the Application Commands and the Result Codes are specific to a given application and it is user's responsibility to define them. The FreeMASTER protocol and the FreeMASTER driver only implement the delivery channel and a set of API calls to enable the Application Command processing in general.

**Pipes** The Pipes enable buffered and stream-oriented data exchange between the PC Host and the target application. Any pipe can be written to and read from at both ends (either on the PC or the MCU). The data transmission is acknowledged using the special FreeMASTER protocol commands. It is guaranteed that the data bytes are delivered from the writer to the reader in a proper order and without losses.

**Serial single-wire operation** The MCU Serial Communication Driver natively supports normal dual-wire operation. Because the protocol is half-duplex only, the driver can also operate in two single-wire modes:

- “External” single-wire operation where the Receiver and Transmitter pins are shorted on the board. This mode is supported by default in the MCU driver because the Receiver and Transmitter units are enabled or disabled whenever needed. It is also easy to extend this operation for the RS485 communication.
- “True” single-wire mode which uses only a single pin and the direction switching is made by the UART module. This mode of operation must be enabled by defining the FMSTR\_SERIAL\_SINGLEWIRE configuration option.

**Multi-session support** With networking interface it is possible for multiple clients to access the target MCU simultaneously. Reading and writing of target memory is processed atomically so there is no risk of data corruption. The state-full resources such as Recorders or Oscilloscopes are locked to a client session upon first use and access is denied to other clients until lock is released..

## Zephyr-specific

**Dedicated communication task** FreeMASTER communication may run isolated in a dedicated task. The task automates the FMSTR\_Init and FMSTR\_Poll calls together with periodic activities enabling the FreeMASTER UI to fetch information about tasks and CPU utilization. The task can be started automatically or manually, and it must be assigned a priority to be able to react on interrupts and other communication events. Refer to Zephyr FreeMASTER sample applications which all use this communication task.

**Zephyr shell and logging over FreeMASTER pipe** FreeMASTER implements a shell backend which may use FreeMASTER pipe as a I/O terminal and logging output. Refer to Zephyr FreeMASTER sample applications which all use this feature.

**Automatic TSA tables** TSA tables can be declared as “automatic” in Zephyr which make them automatically registered in the table list. This may be very useful when there are many TSA tables or when the tables are defined in different (often unrelated) libraries linked together. In this case user does not need to build a list of all tables manually.

**Driver files** The driver source files can be found in a top-level src folder, further divided into the sub-folders:

- **src/platforms** platform-specific folder—one folder exists for each supported processor platform (for example; 32-bit Little Endian platform). Each such folder contains a platform header file with data types and a code which implements the potentially platform-specific operations, such as aligned memory access.
- **src/common** folder—contains the common driver source files shared by the driver for all supported platforms. All the .c files must be added to the project, compiled, and linked together with the application.
  - *freemaster.h* - master driver header file, which declares the common data types, macros, and prototypes of the FreeMASTER driver API functions.
  - *freemaster\_cfg.h.example* - this file can serve as an example of the FreeMASTER driver configuration file. Save this file into a project source code folder and rename it to *freemaster\_cfg.h*. The FreeMASTER driver code includes this file to get the project-specific configuration options and to optimize the compilation of the driver.
  - *freemaster\_defcfg.h* - defines the default values for each FreeMASTER configuration option if the option is not set in the *freemaster\_cfg.h* file.
  - *freemaster\_protocol.h* - defines the FreeMASTER protocol constants used internally by the driver.
  - *freemaster\_protocol.c* - implements the FreeMASTER protocol decoder and handles the basic Get Configuration Value, Memory Read, and Memory Write commands.
  - *freemaster\_rec.c* - handles the Recorder-specific commands and implements the Recorder sampling and triggering routines. When the Recorder is disabled by the FreeMASTER driver configuration file, this file only compiles to empty API functions.
  - *freemaster\_scope.c* - handles the Oscilloscope-specific commands. If the Oscilloscope is disabled by the FreeMASTER driver configuration file, this file compiles as void.
  - *freemaster\_pipes.c* - implements the Pipes functionality when the Pipes feature is enabled.
  - *freemaster\_appcmd.c* - handles the communication commands used to deliver and execute the Application Commands within the context of the embedded application. When the Application Commands are disabled by the FreeMASTER driver configuration file, this file only compiles to empty API functions.

- *freemaster\_tsa.c* - handles the commands specific to the TSA feature. This feature enables the FreeMASTER host tool to obtain the TSA memory descriptors declared in the embedded application. If the TSA is disabled by the FreeMASTER driver configuration file, this file compiles as void.
- *freemaster\_tsa.h* - contains the declaration of the macros used to define the TSA memory descriptors. This file is indirectly included into the user application code (via *freemaster.h*).
- *freemaster\_sha.c* - implements the SHA-1 hash code used in the password authentication algorithm.
- *freemaster\_private.h* - contains the declarations of functions and data types used internally in the driver. It also contains the C pre-processor statements to perform the compile-time verification of the user configuration provided in the *freemaster\_cfg.h* file.
- *freemaster\_serial.c* - implements the serial protocol logic including the CRC, FIFO queuing, and other communication-related operations. This code calls the functions of the low-level communication driver indirectly via a character-oriented API exported by the specific low-level driver.
- *freemaster\_serial.h* - defines the low-level character-oriented Serial API.
- *freemaster\_can.c* - implements the CAN protocol logic including the CAN message preparation, signalling using the first data byte in the CAN frame, and other communication-related operations. This code calls the functions of the low-level communication driver indirectly via a message-oriented API exported by the specific low-level driver.
- *freemaster\_can.h* - defines the low-level message-oriented CAN API.
- *freemaster\_net.c* - implements the Network protocol transport logic including multiple session management code.
- *freemaster\_net.h* - definitions related to the Network transport.
- *freemaster\_pdbdm.c* - implements the packet-driven BDM communication buffer and other communication-related operations.
- *freemaster\_utils.c* - aligned memory copy routines, circular buffer management and other utility functions
- *freemaster\_utils.h* - definitions related to utility code.
- **src/drivers/[sdk]/serial** - contains the code related to the serial communication implemented using one of the supported SDK frameworks.
  - *freemaster\_serial\_XXX.c* and *.h* - implement low-level access to the communication peripheral registers. Different files exist for the UART, LPUART, USART, and other kinds of Serial communication modules.
- **src/drivers/[sdk]/can** - contains the code related to the serial communication implemented using one of the supported SDK frameworks.
  - *freemaster\_XXX.c* and *.h* - implement low-level access to the communication peripheral registers. Different files exist for the FlexCAN, msCAN, MCAN, and other kinds of CAN communication modules.
- **src/drivers/[sdk]/network** - contains low-level code adapting the FreeMASTER Network transport to an underlying TCP/IP or RTT stack.
  - *freemaster\_net\_lwip\_tcp.c* and *\_udp.c* - default networking implementation of TCP and UDP transports using lwIP stack.
  - *freemaster\_net\_segger\_rtt.c* - implementation of network transport using Segger J-Link RTT interface

**Driver configuration** The driver is configured using a single header file (*freemaster\_cfg.h*). Create this file and save it together with other project source files before compiling the driver code. All FreeMASTER driver source files include the *freemaster\_cfg.h* file and use the macros defined here for the conditional and parameterized compilation. The C compiler must locate the configuration file when compiling the driver files. Typically, it can be achieved by putting this file into a folder where the other project-specific included files are stored.

As a starting point to create the configuration file, get the *freemaster\_cfg.h.example* file, rename it to *freemaster\_cfg.h*, and save it into the project area.

**Note:** It is NOT recommended to leave the *freemaster\_cfg.h* file in the FreeMASTER driver source code folder. The configuration file must be placed at a project-specific location, so that it does not affect the other applications that use the same driver.

**Configurable items** This section describes the configuration options which can be defined in *freemaster\_cfg.h*.

### Interrupt modes

```
#define FMSTR_LONG_INTR    [0|1]
#define FMSTR_SHORT_INTR   [0|1]
#define FMSTR_POLL_DRIVEN [0|1]
```

**Value Type** boolean (0 or 1)

**Description** Exactly one of the three macros must be defined to non-zero. The others must be defined to zero or left undefined. The non-zero-defined constant selects the interrupt mode of the driver. See [Driver interrupt modes](#).

- FMSTR\_LONG\_INTR — long interrupt mode
- FMSTR\_SHORT\_INTR — short interrupt mode
- FMSTR\_POLL\_DRIVEN — poll-driven mode

**Note:** Some options may not be supported by all communication interfaces. For example, the FMSTR\_SHORT\_INTR option is not supported by the USB\_CDC interface.

### Protocol transport

```
#define FMSTR_TRANSPORT [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER source code. Specify one of existing instances to make use of the protocol transport.

**Description** Use one of the pre-defined constants, as implemented by the FreeMASTER code. The current driver supports the following transports:

- FMSTR\_SERIAL - serial communication protocol
- FMSTR\_CAN - using CAN communication
- FMSTR\_PDBDM - using packet-driven BDM communication
- FMSTR\_NET - network communication using TCP or UDP protocol

**Serial transport** This section describes configuration parameters used when serial transport is used:

```
#define FMSTR_TRANSPORT FMSTR_SERIAL
```

**FMSTR\_SERIAL\_DRV** Select what low-level driver interface will be used when implementing the Serial communication.

```
#define FMSTR_SERIAL_DRV [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing serial driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/serial* implementation):

- **FMSTR\_SERIAL\_MCUX\_UART** - UART driver
- **FMSTR\_SERIAL\_MCUX\_LPUART** - LPUART driver
- **FMSTR\_SERIAL\_MCUX\_USART** - USART driver
- **FMSTR\_SERIAL\_MCUX\_MINIUSART** - miniUSART driver
- **FMSTR\_SERIAL\_MCUX\_QSCI** - DSC QSCI driver
- **FMSTR\_SERIAL\_MCUX\_USB** - USB/CDC class driver (also see code in the */support/mcuxsdk\_usb* folder)
- **FMSTR\_SERIAL\_56F800E\_EONCE** - DSC JTAG EOnCE driver

Other SDKs or BSPs may define custom low-level driver interface structure which may be used as **FMSTR\_SERIAL\_DRV**. For example:

- **FMSTR\_SERIAL\_DREG\_UART** - demonstrates the low-level interface implemented without the MCUXpresso SDK and using direct access to peripheral registers.

## FMSTR\_SERIAL\_BASE

```
#define FMSTR_SERIAL_BASE [address|symbol]
```

**Value Type** Optional address value (numeric or symbolic)

**Description** Specify the base address of the UART, LPUART, USART, or other serial peripheral module to be used for the communication. This value is not defined by default. User application should call `FMSTR_SetSerialBaseAddress()` to select the peripheral module.

## FMSTR\_COMM\_BUFFER\_SIZE

```
#define FMSTR_COMM_BUFFER_SIZE [number]
```

**Value Type** 0 or a value in range 32...255

**Description** Specify the size of the communication buffer to be allocated by the driver. Default value, which suits all driver features, is used when this option is defined as 0.

### FMSTR\_COMM\_RQUEUE\_SIZE

```
#define FMSTR_COMM_RQUEUE_SIZE [number]
```

**Value Type** Value in range 0...255

**Description** Specify the size of the FIFO receiver queue used to quickly receive and store characters in the FMSTR\_SHORT\_INTR interrupt mode. The default value is 32 B.

### FMSTR\_SERIAL\_SINGLEWIRE

```
#define FMSTR_SERIAL_SINGLEWIRE [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Set to non-zero to enable the “True” single-wire mode which uses a single MCU pin to communicate. The low-level driver enables the pin direction switching when the MCU peripheral supports it.

**CAN Bus transport** This section describes configuration parameters used when CAN transport is used:

```
#define FMSTR_TRANSPORT FMSTR_CAN
```

**FMSTR\_CAN\_DRV** Select what low-level driver interface will be used when implementing the CAN communication.

```
#define FMSTR_CAN_DRV [identifier]
```

**Value Type** Driver identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing CAN driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/can implementation*):

- **FMSTR\_CAN\_MCUX\_FLEXCAN** - FlexCAN driver
- **FMSTR\_CAN\_MCUX\_MCAN** - MCAN driver
- **FMSTR\_CAN\_MCUX\_MSCAN** - msCAN driver
- **FMSTR\_CAN\_MCUX\_DSCFLEXCAN** - DSC FlexCAN driver
- **FMSTR\_CAN\_MCUX\_DSCMSCAN** - DSC msCAN driver

Other SDKs or BSPs may define the custom low-level driver interface structure which may be used as FMSTR\_CAN\_DRV.

### FMSTR\_CAN\_BASE

```
#define FMSTR_CAN_BASE [address|symbol]
```

**Value Type** Optional address value (numeric or symbolic)

**Description** Specify the base address of the FlexCAN, msCAN, or other CAN peripheral module to be used for the communication. This value is not defined by default. User application should call `FMSTR_SetCanBaseAddress()` to select the peripheral module.

#### FMSTR\_CAN\_CMDID

```
#define FMSTR_CAN_CMDID [number]
```

**Value Type** CAN identifier (11-bit or 29-bit number)

**Description** CAN message identifier used for FreeMASTER commands (direction from PC Host tool to target application). When declaring 29-bit identifier, combine the numeric value with `FMSTR_CAN_EXTID` bit. Default value is 0x7AA.

#### FMSTR\_CAN\_RSPID

```
#define FMSTR_CAN_RSPID [number]
```

**Value Type** CAN identifier (11-bit or 29-bit number)

**Description** CAN message identifier used for responding messages (direction from target application to PC Host tool). When declaring 29-bit identifier, combine the numeric value with `FMSTR_CAN_EXTID` bit. Note that both *CMDID* and *RSPID* values may be the same. Default value is 0x7AA.

#### FMSTR\_FLEXCAN\_TXMB

```
#define FMSTR_FLEXCAN_TXMB [number]
```

**Value Type** Number in range of 0..N where N is number of CAN message-buffers supported by HW module.

**Description** Only used when the FlexCAN low-level driver is used. Define the FlexCAN message buffer for CAN frame transmission. Default value is 0.

#### FMSTR\_FLEXCAN\_RXMB

```
#define FMSTR_FLEXCAN_RXMB [number]
```

**Value Type** Number in range of 0..N where N is number of CAN message-buffers supported by HW module.

**Description** Only used when the FlexCAN low-level driver is used. Define the FlexCAN message buffer for CAN frame reception. Note that the FreeMASTER driver may also operate with a common message buffer used by both TX and RX directions. Default value is 1.

**Network transport** This section describes configuration parameters used when Network transport is used:

```
#define FMSTR_TRANSPORT FMSTR_NET
```

**FMSTR\_NET\_DRV** Select network interface implementation.

```
#define FMSTR_NET_DRV [identifier]
```

**Value Type** Identifiers are structure instance names defined in FreeMASTER drivers code. Specify one of existing NET driver instances.

**Description** When using MCUXpresso SDK, use one of the following constants (see */drivers/mcuxsdk/network implementation*):

- **FMSTR\_NET\_LWIP\_TCP** - TCP communication using lwIP stack
- **FMSTR\_NET\_LWIP\_UDP** - UDP communication using lwIP stack
- **FMSTR\_NET\_SEGGER\_RTT** - Communication using SEGGER J-Link RTT interface

Other SDKs or BSPs may define the custom networking interface which may be used as FMSTR\_CAN\_DRV.

Add another row below:

#### FMSTR\_NET\_PORT

```
#define FMSTR_NET_PORT [number]
```

**Value Type** TCP or UDP port number (short integer)

**Description** Specifies the server port number used by TCP or UDP protocols.

#### FMSTR\_NET\_BLOCKING\_TIMEOUT

```
#define FMSTR_NET_BLOCKING_TIMEOUT [number]
```

**Value Type** Timeout as number of milliseconds

**Description** This value specifies a timeout in milliseconds for which the network socket operations may block the execution inside *FMSTR\_Poll*. This may be set high (e.g. 250) when a dedicated RTOS task is used to handle FreeMASTER protocol polling. Set to a lower value when the polling task is also responsible for other operations. Set to 0 to attempt to use non-blocking socket operations.

## FMSTR\_NET\_AUTODISCOVERY

```
#define FMSTR_NET_AUTODISCOVERY [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** This option enables the FreeMASTER driver to use a separate UDP socket to broadcast auto-discovery messages to network. This helps the FreeMASTER tool to discover the target device address, port and protocol options.

## Debugging options

### FMSTR\_DISABLE

```
#define FMSTR_DISABLE [0|1]
```

**Value Type** boolean (0 or 1)

**Description** Define as non-zero to disable all FreeMASTER features, exclude the driver code from build, and compile all its API functions empty. This may be useful to remove FreeMASTER without modifying any application source code. Default value is 0 (false).

### FMSTR\_DEBUG\_TX

```
#define FMSTR_DEBUG_TX [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to enable the driver to periodically transmit test frames out on the selected communication interface (SCI or CAN). With the debug transmission enabled, it is simpler to detect problems in the baudrate or other communication configuration settings.

The test frames are transmitted until the first valid command frame is received from the PC Host tool. The test frame is a valid error status frame, as defined by the protocol format. On the serial line, the test frame consists of three printable characters (+©W) which are easy to capture using the serial terminal tools.

This feature requires the FMSTR\_Poll() function to be called periodically. Default value is 0 (false).

### FMSTR\_APPLICATION\_STR

```
#define FMSTR_APPLICATION_STR
```

**Value Type** String.

**Description** Name of the application visible in FreeMASTER host application.

## Memory access

**FMSTR\_USE\_READMEM**

```
#define FMSTR_USE_READMEM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Memory Read command and enable FreeMASTER to have read access to memory and variables. The access can be further restricted by using a TSA feature.  
Default value is 1 (true).

**FMSTR\_USE\_WRITEMEM**

```
#define FMSTR_USE_WRITEMEM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Memory Write command.  
The default value is 1 (true).

**Oscilloscope options****FMSTR\_USE\_SCOPE**

```
#define FMSTR_USE_SCOPE [number]
```

**Value Type** Integer number.

**Description** Number of Oscilloscope instances to be supported. Set to 0 to disable the Oscilloscope feature.  
Default value is 0.

**FMSTR\_MAX\_SCOPE\_VARS**

```
#define FMSTR_MAX_SCOPE_VARS [number]
```

**Value Type** Integer number larger than 2.

**Description** Number of variables to be supported by each Oscilloscope instance.  
Default value is 8.

**Recorder options****FMSTR\_USE\_RECORDER**

```
#define FMSTR_USE_RECORDER [number]
```

**Value Type** Integer number.

**Description** Number of Recorder instances to be supported. Set to 0 to disable the Recorder feature.  
Default value is 0.

#### FMSTR\_REC\_BUFF\_SIZE

```
#define FMSTR_REC_BUFF_SIZE [number]
```

**Value Type** Integer number larger than 2.

**Description** Defines the size of the memory buffer used by the Recorder instance #0.  
Default: not defined, user shall call 'FMSTR\_RecorderCreate()' API function to specify this parameter in run time.

#### FMSTR\_REC\_TIMEBASE

```
#define FMSTR_REC_TIMEBASE [time specification]
```

**Value Type** Number (nanoseconds time).

**Description** Defines the base sampling rate in nanoseconds (sampling speed) Recorder instance #0.

Use one of the following macros:

- FMSTR\_REC\_BASE\_SECONDS(x)
- FMSTR\_REC\_BASE\_MILLISEC(x)
- FMSTR\_REC\_BASE\_MICROSEC(x)
- FMSTR\_REC\_BASE\_NANOSEC(x)

Default: not defined, user shall call 'FMSTR\_RecorderCreate()' API function to specify this parameter in run time.

#### FMSTR\_REC\_FLOAT\_TRIG

```
#define FMSTR_REC_FLOAT_TRIG [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the floating-point triggering. Be aware that floating-point triggering may grow the code size by linking the floating-point standard library.  
Default value is 0 (false).

### Application Commands options

**FMSTR\_USE\_APPCMD**

```
#define FMSTR_USE_APPCMD [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Define as non-zero to implement the Application Commands feature. Default value is 0 (false).

**FMSTR\_APPCMD\_BUFF\_SIZE**

```
#define FMSTR_APPCMD_BUFF_SIZE [size]
```

**Value Type** Numeric buffer size in range 1..255

**Description** The size of the Application Command data buffer allocated by the driver. The buffer stores the (optional) parameters of the Application Command which waits to be processed.

**FMSTR\_MAX\_APPCMD\_CALLS**

```
#define FMSTR_MAX_APPCMD_CALLS [number]
```

**Value Type** Number in range 0..255

**Description** The number of different Application Commands that can be assigned a callback handler function using FMSTR\_RegisterAppCmdCall(). Default value is 0.

**TSA options****FMSTR\_USE\_TSA**

```
#define FMSTR_USE_TSA [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the FreeMASTER TSA feature to be used. With this option enabled, the TSA tables defined in the applications are made available to the FreeMASTER host tool. Default value is 0 (false).

**FMSTR\_USE\_TSA\_SAFETY**

```
#define FMSTR_USE_TSA_SAFETY [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the memory access validation in the FreeMASTER driver. With this option, the host tool is not able to access the memory which is not described by at least one TSA descriptor. Also a write access is denied for objects defined as read-only in TSA tables. Default value is 0 (false).

#### FMSTR\_USE\_TSA\_INROM

```
#define FMSTR_USE_TSA_INROM [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Declare all TSA descriptors as *const*, which enables the linker to put the data into the flash memory. The actual result depends on linker settings or the linker commands used in the project. Default value is 0 (false).

#### FMSTR\_USE\_TSA\_DYNAMIC

```
#define FMSTR_USE_TSA_DYNAMIC [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable runtime-defined TSA entries to be added to the TSA table by the FMSTR\_SetUpTsaBuff() and FMSTR\_TsaAddVar() functions. Default value is 0 (false).

### Pipes options

#### FMSTR\_USE\_PIPES

```
#define FMSTR_USE_PIPES [0|1]
```

**Value Type** Boolean 0 or 1.

**Description** Enable the FreeMASTER Pipes feature to be used. Default value is 0 (false).

#### FMSTR\_MAX\_PIPES\_COUNT

```
#define FMSTR_MAX_PIPES_COUNT [number]
```

**Value Type** Number in range 1..63.

**Description** The number of simultaneous pipe connections to support. The default value is 1.

**Driver interrupt modes** To implement the communication, the FreeMASTER driver handles the Serial or CAN module's receive and transmit requests. Use the *freemaster\_cfg.h* configuration file to select whether the driver processes the communication automatically in the interrupt service routine handler or if it only polls the status of the module (typically during the application idle time).

This section describes each of the interrupt mode in more details.

### Completely Interrupt-Driven operation Activated using:

```
#define FMSTR_LONG_INTR 1
```

In this mode, both the communication and the FreeMASTER protocol decoding is done in the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, or other interrupt service routine. Because the protocol execution may be a lengthy task (especially with the TSA-Safety enabled) it is recommended to use this mode only if the interrupt prioritization scheme is possible in the application and the FreeMASTER interrupt is assigned to a lower (the lowest) priority.

In this mode, the application code must register its own interrupt handler for all interrupt vectors related to the selected communication interface and call the *FMSTR\_SerialIsr* or *FMSTR\_CanIsr* functions from that handler.

### Mixed Interrupt and Polling Modes Activated using:

```
#define FMSTR_SHORT_INTR 1
```

In this mode, the communication processing time is split between the interrupt routine and the main application loop or task. The raw communication is handled by the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, or other interrupt service routine, while the protocol decoding and execution is handled by the *FMSTR\_Poll* routine. Call *FMSTR\_Poll* during the idle time in the application main loop.

The interrupt processing in this mode is relatively fast and deterministic. Upon a serial-receive event, the received character is only placed into a FIFO-like queue and it is not further processed. Upon a CAN receive event, the received frame is stored into a receive buffer. When transmitting, the characters are fetched from the prepared transmit buffer.

In this mode, the application code must register its own interrupt handler for all interrupt vectors related to the selected communication interface and call the *FMSTR\_SerialIsr* or *FMSTR\_CanIsr* functions from that handler.

When the serial interface is used as the serial communication interface, ensure that the *FMSTR\_Poll* function is called at least once per *N* character time periods. *N* is the length of the FreeMASTER FIFO queue (*FMSTR\_COMM\_QUEUE\_SIZE*) and the character time is the time needed to transmit or receive a single byte over the SCI line.

### Completely Poll-driven

```
#define FMSTR_POLL_DRIVEN 1
```

In this mode, both the communication and the FreeMASTER protocol decoding are done in the *FMSTR\_Poll* routine. No interrupts are needed and the *FMSTR\_SerialIsr*, *FMSTR\_CanIsr*, and similar handlers compile to an empty code.

When using this mode, ensure that the *FMSTR\_Poll* function is called by the application at least once per the serial "character time" which is the time needed to transmit or receive a single character.

In the latter two modes (*FMSTR\_SHORT\_INTR* and *FMSTR\_POLL\_DRIVEN*), the protocol handling takes place in the *FMSTR\_Poll* routine. An application interrupt can occur in the middle of the

Read Memory or Write Memory commands' execution and corrupt the variable being accessed by the FreeMASTER driver. In these two modes, some issues or glitches may occur when using FreeMASTER to visualize or monitor volatile variables modified in interrupt servicing code.

The same issue may appear even in the full interrupt mode (FMSTR\_LONG\_INTR), if volatile variables are modified in the interrupt code with a priority higher than the priority of the communication interrupt.

**Data types** Simple portability was one of the main requirements when writing the FreeMASTER driver. This is why the driver code uses the privately-declared data types and the vast majority of the platform-dependent code is separated in the platform-dependent source files. The data types used in the driver API are all defined in the platform-specific header file.

To prevent name conflicts with the symbols used in the application, all data types, macros, and functions have the FMSTR\_ prefix. The only global variables used in the driver are the transport and low-level API structures exported from the driver-implementation layer to upper layers. Other than that, all private variables are declared as static and named using the fmstr\_ prefix.

**Communication interface initialization** The FreeMASTER driver does not perform neither the initialization nor the configuration of the peripheral module that it uses to communicate. It is the application startup code responsibility to configure the communication module before the FreeMASTER driver is initialized by the FMSTR\_Init call.

When the Serial communication module is used as the FreeMASTER communication interface, configure the UART receive and transmit pins, the serial communication baud rate, parity (no-parity), the character length (eight bits), and the number of stop bits (one) before initializing the FreeMASTER driver. For either the long or the short interrupt modes of the driver (see [Driver interrupt modes](#)), configure the interrupt controller and register an application-specific interrupt handler for all interrupt sources related to the selected serial peripheral module. Call the FMSTR\_SerialIsr function from the application handler.

When a CAN module is used as the FreeMASTER communication interface, configure the CAN receive and transmit pins and the CAN module bit rate before initializing the FreeMASTER driver. For either the long or the short interrupt modes of the driver (see [Driver interrupt modes](#)), configure the interrupt controller and register an application-specific interrupt handler for all interrupt sources related to the selected CAN peripheral module. Call the FMSTR\_CanIsr function from the application handler.

**Note:** It is not necessary to enable or unmask the serial nor the CAN interrupts before initializing the FreeMASTER driver. The driver enables or disables the interrupts and communication lines, as required during runtime.

**FreeMASTER Recorder calls** When using the FreeMASTER Recorder in the application (FMSTR\_USE\_RECORDER > 0), call the FMSTR\_RecorderCreate function early after FMSTR\_Init to set up each recorder instance to be used in the application. Then call the FMSTR\_Recorder function periodically in the code where the data recording should occur. A typical place to call the Recorder routine is at the timer or PWM interrupts, but it can be anywhere else. The example applications provided together with the driver code call the FMSTR\_Recorder in the main application loop.

In applications where FMSTR\_Recorder is called periodically with a constant period, specify the period in the Recorder configuration structure before calling FMSTR\_RecorderCreate. This setting enables the PC Host FreeMASTER tool to display the X-axis of the Recorder graph properly scaled for the time domain.

**Driver usage** Start using or evaluating FreeMASTER by opening some of the example applications available in the driver setup package.

Follow these steps to enable the basic FreeMASTER connectivity in the application:

- Make sure that all \*.c files of the FreeMASTER driver from the *src/common/platforms/[your\_platform]* folder are a part of the project. See [Driver files](#) for more details.
- Configure the FreeMASTER driver by creating or editing the *freemaster\_cfg.h* file and by saving it into the application project directory. See [Driver configuration](#) for more details.
- Include the *freemaster.h* file into any application source file that makes the FreeMASTER API calls.
- Initialize the Serial or CAN modules. Set the baud rate, parity, and other parameters of the communication. Do not enable the communication interrupts in the interrupt mask registers.
- For the FMSTR\_LONG\_INTR and FMSTR\_SHORT\_INTR modes, install the application-specific interrupt routine and call the FMSTR\_SerialIsr or FMSTR\_CanIsr functions from this handler.
- Call the FMSTR\_Init function early on in the application initialization code.
- Call the FMSTR\_RecorderCreate functions for each Recorder instance to enable the Recorder feature.
- In the main application loop, call the FMSTR\_Poll API function periodically when the application is idle.
- For the FMSTR\_SHORT\_INTR and FMSTR\_LONG\_INTR modes, enable the interrupts globally so that the interrupts can be handled by the CPU.

**Communication troubleshooting** The most common problem that causes communication issues is a wrong baud rate setting or a wrong pin multiplexer setting of the target MCU. When a communication between the PC Host running FreeMASTER and the target MCU cannot be established, try enabling the FMSTR\_DEBUG\_TX option in the *freemaster\_cfg.h* file and call the FMSTR\_Poll function periodically in the main application task loop.

With this feature enabled, the FreeMASTER driver periodically transmits a test frame through the Serial or CAN lines. Use a logic analyzer or an oscilloscope to monitor the signals at the communication pins of the CPU device to examine whether the bit rate and signal polarity are configured properly.

## Driver API

This section describes the driver Application Programmers' Interface (API) needed to initialize and use the FreeMASTER serial communication driver.

**Control API** There are three key functions to initialize and use the driver.

### FMSTR\_Init

#### Prototype

```
FMSTR_BOOL FMSTR_Init(void);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_protocol.c*

**Description** This function initializes the internal variables of the FreeMASTER driver and enables the communication interface. This function does not change the configuration of the selected communication module. The hardware module must be initialized before the *FMSTR\_Init* function is called.

A call to this function must occur before calling any other FreeMASTER driver API functions.

## FMSTR\_Poll

### Prototype

```
void FMSTR_Poll(void);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_protocol.c*

**Description** In the poll-driven or short interrupt modes, this function handles the protocol decoding and execution (see *Driver interrupt modes*). In the poll-driven mode, this function also handles the communication interface with the PC. Typically, the *FMSTR\_Poll* function is called during the “idle” time in the main application task loop.

To prevent the receive data overflow (loss) on a serial interface, make sure that the *FMSTR\_Poll* function is called at least once per the time calculated as:

$$N * Tchar$$

where:

- *N* is equal to the length of the receive FIFO queue (configured by the *FMSTR\_COMM\_RQUEUE\_SIZE* macro). *N* is 1 for the poll-driven mode.
- *Tchar* is the character time, which is the time needed to transmit or receive a single byte over the SCI line.

**Note:** In the long interrupt mode, this function typically compiles as an empty function and can still be called. It is worthwhile to call this function regardless of the interrupt mode used in the application. This approach enables a convenient switching between the different interrupt modes only by changing the configuration macros in the *freemaster\_cfg.h* file.

## FMSTR\_SerialIsr / FMSTR\_CanIsr

### Prototype

```
void FMSTR_SerialIsr(void);
void FMSTR_CanIsr(void);
```

- Declaration: *freemaster.h*
- Implementation: *hw-specific low-level driver C file*

**Description** This function contains the interrupt-processing code of the FreeMASTER driver. In long or short interrupt modes (see *Driver interrupt modes*), this function must be called from the application interrupt service routine registered for the communication interrupt vector. On platforms where the communication module uses multiple interrupt vectors, the application should register a handler for all vectors and call this function at each interrupt.

**Note:** In a poll-driven mode, this function is compiled as an empty function and does not have to be used.

## Recorder API

### FMSTR\_RecorderCreate

#### Prototype

```
FMSTR_BOOL FMSTR_RecorderCreate(FMSTR_INDEX recIndex, FMSTR_REC_BUFF* buffCfg);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function registers a recorder instance and enables it to be used by the PC Host tool. Call this function for all recorder instances from 0 to the maximum number defined by the FMSTR\_USE\_RECORDER configuration option (minus one). An exception to this requirement is the recorder of instance 0 which may be automatically configured by FMSTR\_Init when the *freemaster\_cfg.h* configuration file defines the *FMSTR\_REC\_BUFF\_SIZE* and *FMSTR\_REC\_TIMEBASE* options.

For more information, see [Configurable items](#).

### FMSTR\_Recorder

#### Prototype

```
void FMSTR_Recorder(FMSTR_INDEX recIndex);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function takes a sample of the variables being recorded using the FreeMASTER Recorder instance *recIndex*. If the selected Recorder is not active when the *FMSTR\_Recorder* function is being called, the function returns immediately. When the Recorder is active, the values of the variables being recorded are copied into the recorder buffer and the trigger conditions are evaluated.

If a trigger condition is satisfied, the Recorder enters the post-trigger mode, where it counts down the follow-up samples (number of *FMSTR\_Recorder* function calls) and de-activates the Recorder when the required post-trigger samples are finished.

The *FMSTR\_Recorder* function is typically called in the timer or PWM interrupt service routines. This function can also be called in the application main loop (for testing purposes).

### FMSTR\_RecorderTrigger

#### Prototype

```
void FMSTR_RecorderTrigger(FMSTR_INDEX recIndex);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_rec.c*

**Description** This function forces the Recorder trigger condition to happen, which causes the Recorder to be automatically deactivated after the post-trigger samples are sampled. Use this function in the application code for programmatic control over the Recorder triggering. This can be useful when a more complex triggering conditions need to be used.

**Fast Recorder API** The Fast Recorder feature is not available in the FreeMASTER driver version 3. This feature was heavily dependent on the target platform and it was only available for the 56F8xxxx DSCs.

**TSA Tables** When the TSA is enabled in the FreeMASTER driver configuration file (by setting the FMSTR\_USE\_TSA macro to a non-zero value), it defines the so-called TSA tables in the application. This section describes the macros that must to be used to define the TSA tables.

There can be any number of TSA tables spread across the application source files. There must be always exactly one TSA Table List defined, which informs the FreeMASTER driver about the active TSA tables.

When there is at least one TSA table and one TSA Table List defined in the application, the TSA information automatically appears in the FreeMASTER symbols list. The symbols can then be used to create FreeMASTER variables for visualization or control.

**TSA table definition** The TSA table describes the static or global variables together with their address, size, type, and access-protection information. If the TSA-described variables are of a structure type, the TSA table may also describe this type and provide an access to the individual structure members of the variable.

The TSA table definition begins with the FMSTR\_TSA\_TABLE\_BEGIN macro with a *table\_id* identifying the table. The *table\_id* shall be a valid C-language symbol.

```
FMSTR_TSA_TABLE_BEGIN(table_id)
```

After this opening macro, the TSA descriptors are placed using these macros:

```
/* Adding variable descriptors */
FMSTR_TSA_RW_VAR(name, type) /* read/write variable entry */
FMSTR_TSA_RO_VAR(name, type) /* read-only variable entry */

/* Description of complex data types */
FMSTR_TSA_STRUCT(struct_name) /* structure or union type entry */
FMSTR_TSA_MEMBER(struct_name, member_name, type) /* structure member entry */

/* Memory blocks */
FMSTR_TSA_RW_MEM(name, type, address, size) /* read/write memory block */
FMSTR_TSA_RO_MEM(name, type, address, size) /* read-only memory block */
```

The table is closed using the FMSTR\_TSA\_TABLE\_END macro:

```
FMSTR_TSA_TABLE_END()
```

**TSA descriptor parameters** The TSA descriptor macros accept these parameters:

- *name* — variable name. The variable must be defined before the TSA descriptor references it.
- *type* — variable or member type. Only one of the pre-defined type constants may be used (see below).
- *struct\_name* — structure type name. The type must be defined (typedef) before the TSA descriptor references it.

- *member\_name* — structure member name.

**Note:** The structure member descriptors (FMSTR\_TSA\_MEMBER) must immediately follow the parent structure descriptor (FMSTR\_TSA\_STRUCT) in the table.

**Note:** To write-protect the variables in the FreeMASTER driver (FMSTR\_TSA\_RO\_VAR), enable the TSA-Safety feature in the configuration file.

**TSA variable types** The table lists *type* identifiers which can be used in TSA descriptors:

| Constant                           | Description                                                    |
|------------------------------------|----------------------------------------------------------------|
| FMSTR_TSA_UINTn                    | Unsigned integer type of size <i>n</i> bits (n=8,16,32,64)     |
| FMSTR_TSA_SINTn                    | Signed integer type of size <i>n</i> bits (n=8,16,32,64)       |
| FMSTR_TSA_FRACn                    | Fractional number of size <i>n</i> bits (n=16,32,64).          |
| FMSTR_TSA_FRAC_Q( <i>m,n</i> )     | Signed fractional number in general Q form (m+n+1 total bits)  |
| FMSTR_TSA_FRAC_UQ( <i>m,n</i> )    | Unsigned fractional number in general UQ form (m+n total bits) |
| FMSTR_TSA_FLOAT                    | 4-byte standard IEEE floating-point type                       |
| FMSTR_TSA_DOUBLE                   | 8-byte standard IEEE floating-point type                       |
| FMSTR_TSA_POINTER                  | Generic pointer type defined (platform-specific 16 or 32 bit)  |
| FM-STR_TSA_USERTYPE( <i>name</i> ) | Structure or union type declared with FMSTR_TSA_STRUCT record  |

**TSA table list** There shall be exactly one TSA Table List in the application. The list contains one entry for each TSA table defined anywhere in the application.

The TSA Table List begins with the FMSTR\_TSA\_TABLE\_LIST\_BEGIN macro and continues with the TSA table entries for each table.

```
FMSTR_TSA_TABLE_LIST_BEGIN()
```

```
FMSTR_TSA_TABLE(table_id)
FMSTR_TSA_TABLE(table_id2)
FMSTR_TSA_TABLE(table_id3)
...
```

The list is closed with the FMSTR\_TSA\_TABLE\_LIST\_END macro:

```
FMSTR_TSA_TABLE_LIST_END()
```

**TSA Active Content entries** FreeMASTER v2.0 and higher supports TSA Active Content, enabling the TSA tables to describe the memory-mapped files, virtual directories, and URL hyperlinks. FreeMASTER can access such objects similarly to accessing the files and folders on the local hard drive.

With this set of TSA entries, the FreeMASTER pages can be embedded directly into the target MCU flash and accessed by FreeMASTER directly over the communication line. The HTML-coded pages rendered inside the FreeMASTER window can access the TSA Active Content resources using a special URL referencing the *fmrstr:* protocol.

This example provides an overview of the supported TSA Active Content entries:

```
FMSTR_TSA_TABLE_BEGIN(files_and_links)
```

```
/* Directory entry applies to all subsequent MEMFILE entries */
```

```
FMSTR_TSA_DIRECTORY("/text_files") /* entering a new virtual directory */
```

(continues on next page)

(continued from previous page)

```

/* The readme.txt file will be accessible at the fmstr://text_files/readme.txt URL */
FMSTR_TSA_MEMFILE("readme.txt", readme_txt, sizeof(readme_txt)) /* memory-mapped file */

/* Files can also be specified with a full path so the DIRECTORY entry does not apply */
FMSTR_TSA_MEMFILE("/index.htm", index, sizeof(index)) /* memory-mapped file */
FMSTR_TSA_MEMFILE("/prj/demo.pmp", demo_pmp, sizeof(demo_pmp)) /* memory-mapped file */

/* Hyperlinks can point to a local MEMFILE object or to the Internet */
FMSTR_TSA_HREF("Board's Built-in Welcome Page", "/index.htm")
FMSTR_TSA_HREF("FreeMASTER Home Page", "http://www.nxp.com/freemaster")

/* Project file links simplify opening the projects from any URLs */
FMSTR_TSA_PROJECT("Demonstration Project (embedded)", "/prj/demo.pmp")
FMSTR_TSA_PROJECT("Full Project (online)", "http://mycompany.com/prj/demo.pmp")

FMSTR_TSA_TABLE_END()

```

## TSA API

### FMSTR\_SetUpTsaBuff

#### Prototype

```
FMSTR_BOOL FMSTR_SetUpTsaBuff(FMSTR_ADDR buffAddr, FMSTR_SIZE buffSize);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_tsa.c*

#### Arguments

- *buffAddr* [in] - address of the memory buffer for the dynamic TSA table
- *buffSize* [in] - size of the memory buffer which determines the maximum number of TSA entries to be added in the runtime

**Description** This function must be used to assign the RAM memory buffer to the TSA subsystem when FMSTR\_USE\_TSA\_DYNAMIC is enabled. The memory buffer is then used to store the TSA entries added dynamically to the runtime TSA table using the FMSTR\_TsaAddVar function call. The runtime TSA table is processed by the FreeMASTER PC Host tool along with all static tables as soon as the communication port is open.

The size of the memory buffer determines the number of TSA entries that can be added dynamically. Depending on the MCU platform, one TSA entry takes either 8 or 16 bytes.

### FMSTR\_TsaAddVar

#### Prototype

```

FMSTR_BOOL FMSTR_TsaAddVar(FMSTR_TSATBL_STRPTR tsaName, FMSTR_TSATBL_STRPTR
↪ tsaType,
    FMSTR_TSATBL_VOIDPTR varAddr, FMSTR_SIZE32 varSize,
    FMSTR_SIZE flags);

```

- Declaration: *freemaster.h*

- Implementation: *freemaster\_tsa.c*

### Arguments

- *tsaName* [in] - name of the object
- *tsaType* [in] - name of the object type
- *varAddr* [in] - address of the object
- *varSize* [in] - size of the object
- *flags* [in] - access flags; a combination of these values:
  - *FMSTR\_TSA\_INFO\_RO\_VAR* — read-only memory-mapped object (typically a variable)
  - *FMSTR\_TSA\_INFO\_RW\_VAR* — read/write memory-mapped object
  - *FMSTR\_TSA\_INFO\_NON\_VAR* — other entry, describing structure types, structure members, enumerations, and other types

**Description** This function can be called only when the dynamic TSA table is enabled by the *FMSTR\_USE\_TSA\_DYNAMIC* configuration option and when the *FMSTR\_SetUpTsaBuff* function call is made to assign the dynamic TSA table memory. This function adds an entry into the dynamic TSA table. It can be used to register a read-only or read/write memory object or describe an item of the user-defined type.

See [TSA table definition](#) for more details about the TSA table entries.

## Application Commands API

### FMSTR\_GetAppCmd

#### Prototype

```
FMSTR_APPCMD_CODE FMSTR_GetAppCmd(void);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

**Description** This function can be used to detect if there is an Application Command waiting to be processed by the application. If no command is pending, this function returns the *FMSTR\_APPCMDRESULT\_NOCMD* constant. Otherwise, this function returns the code of the Application Command that must be processed. Use the *FMSTR\_AppCmdAck* call to acknowledge the Application Command after it is processed and to return the appropriate result code to the host.

The *FMSTR\_GetAppCmd* function does not report the commands for which a callback handler function exists. If the *FMSTR\_GetAppCmd* function is called when a callback-registered command is pending (and before it is actually processed by the callback function), this function returns *FMSTR\_APPCMDRESULT\_NOCMD*.

### FMSTR\_GetAppCmdData

## Prototype

```
FMSTR_APPCMD_PDATA FMSTR_GetAppCmdData(FMSTR_SIZE* dataLen);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *dataLen* [out] - pointer to the variable that receives the length of the data available in the buffer. It can be NULL when this information is not needed.

**Description** This function can be used to retrieve the Application Command data when the application determines that an Application Command is pending (see [FMSTR\\_GetAppCmd](#)).

There is just a single buffer to hold the Application Command data (the buffer length is FMSTR\_APPCMD\_BUFF\_SIZE bytes). If the data are to be used in the application after the command is processed by the FMSTR\_AppCmdAck call, copy the data out to a private buffer.

## FMSTR\_AppCmdAck

### Prototype

```
void FMSTR_AppCmdAck(FMSTR_APPCMD_RESULT resultCode);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

## Arguments

- *resultCode* [in] - the result code which is to be returned to FreeMASTER

**Description** This function is used when the Application Command processing finishes in the application. The resultCode passed to this function is returned back to the host and the driver is re-initialized to expect the next Application Command.

After this function is called and before the next Application Command arrives, the return value of the FMSTR\_GetAppCmd function is FMSTR\_APPCMDRESULT\_NOCMD.

## FMSTR\_AppCmdSetResponseData

### Prototype

```
void FMSTR_AppCmdSetResponseData(FMSTR_ADDR resultDataAddr, FMSTR_SIZE resultDataLen);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

### Arguments

- *resultDataAddr* [in] - pointer to the data buffer that is to be copied to the Application Command data buffer
- *resultDataLen* [in] - length of the data to be copied. It must not exceed the FMSTR\_APPCMD\_BUFF\_SIZE value.

**Description** This function can be used before the Application Command processing finishes, when there are data to be returned back to the PC.

The response data buffer is copied into the Application Command data buffer, from where it is accessed when the host requires it. Do not use FMSTR\_GetAppCmdData and the data buffer after FMSTR\_AppCmdSetResponseData is called.

**Note:** The current version of FreeMASTER does not support the Application Command response data.

### FMSTR\_RegisterAppCmdCall

#### Prototype

```
FMSTR_BOOL FMSTR_RegisterAppCmdCall(FMSTR_APPCMD_CODE appCmdCode, FMSTR_
↳PAPPCMDFUNC callbackFunc);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_appcmd.c*

### Arguments

- *appCmdCode* [in] - the Application Command code for which the callback is to be registered
- *callbackFunc* [in] - pointer to the callback function that is to be registered. Use NULL to unregister a callback registered previously with this Application Command.

**Return value** This function returns a non-zero value when the callback function was successfully registered or unregistered. It can return zero when trying to register a callback function for more than FMSTR\_MAX\_APPCMD\_CALLS different Application Commands.

**Description** This function can be used to register the given function as a callback handler for the Application Command. The Application Command is identified using single-byte code. The callback function is invoked automatically by the FreeMASTER driver when the protocol decoder obtains a request to get the application command result code.

The prototype of the callback function is

```
FMSTR_APPCMD_RESULT HandlerFunction(FMSTR_APPCMD_CODE nAppcmd,
FMSTR_APPCMD_PDATA pData, FMSTR_SIZE nDataLen);
```

Where:

- *nAppcmd* -Application Command code
- *pData* —points to the Application Command data received (if any)
- *nDataLen* —information about the Application Command data length

The return value of the callback function is used as the Application Command Result Code and returned to FreeMASTER.

**Note:** The FMSTR\_MAX\_APPCMD\_CALLS configuration macro defines how many different Application Commands may be handled by a callback function. When FMSTR\_MAX\_APPCMD\_CALLS is undefined or defined as zero, the FMSTR\_RegisterAppCmdCall function always fails.

## Pipes API

### FMSTR\_PipeOpen

#### Prototype

```
FMSTR_HPIPE FMSTR_PipeOpen(FMSTR_PIPE_PORT pipePort, FMSTR_PPIPEFUNC pipeCallback,
    FMSTR_ADDR pipeRxBuff, FMSTR_PIPE_SIZE pipeRxSize,
    FMSTR_ADDR pipeTxBuff, FMSTR_PIPE_SIZE pipeTxSize,
    FMSTR_U8 type, const FMSTR_CHAR *name);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

#### Arguments

- *pipePort* [in] - port number that identifies the pipe for the client
- *pipeCallback* [in] - pointer to the callback function that is called whenever a pipe data status changes
- *pipeRxBuff* [in] - address of the receive memory buffer
- *pipeRxSize* [in] - size of the receive memory buffer
- *pipeTxBuff* [in] - address of the transmit memory buffer
- *pipeTxSize* [in] - size of the transmit memory buffer
- *type* [in] - a combination of FMSTR\_PIPE\_MODE\_XXX and FMSTR\_PIPE\_SIZE\_XXX constants describing primary pipe data format and usage. This type helps FreeMASTER decide how to access the pipe by default. Optional, use 0 when undetermined.
- *name* [in] - user name of the pipe port. This name is visible to the FreeMASTER user when creating the graphical pipe interface.

**Description** This function initializes a new pipe and makes it ready to accept or send the data to the PC Host client. The receive memory buffer is used to store the received data before they are read out by the FMSTR\_PipeRead call. When this buffer gets full, the PC Host client denies the data transmission into this pipe until there is enough free space again. The transmit memory buffer is used to store the data transmitted by the application to the PC Host client using the FMSTR\_PipeWrite call. The transmit buffer can get full when the PC Host is disconnected or when it is slow in receiving and reading out the pipe data.

The function returns the pipe handle which must be stored and used in the subsequent calls to manage the pipe object.

The callback function (if specified) is called whenever new data are received through the pipe and available for reading. This callback is also called when the data waiting in the transmit buffer are successfully pushed to the PC Host and the transmit buffer free space increases. The prototype of the callback function provided by the user application must be as follows. The *PipeHandler* name is only a placeholder and must be defined by the application.

```
void PipeHandler(FMSTR_HPIPE pipeHandle);
```

## FMSTR\_PipeClose

### Prototype

```
void FMSTR_PipeClose(FMSTR_HPIPE pipeHandle);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

### Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call

**Description** This function de-initializes the pipe object. No data can be received or sent on the pipe after this call.

## FMSTR\_PipeWrite

### Prototype

```
FMSTR_PIPE_SIZE FMSTR_PipeWrite(FMSTR_HPIPE pipeHandle, FMSTR_ADDR pipeData,  
    FMSTR_PIPE_SIZE pipeDataLen, FMSTR_PIPE_SIZE writeGranularity);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

### Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call
- *pipeData* [in] - address of the data to be written
- *pipeDataLen* [in] - length of the data to be written
- *writeGranularity* [in] - size of the minimum unit of data which is to be written

**Description** This function puts the user-specified data into the pipe's transmit memory buffer and schedules it for transmission. This function returns the number of bytes that were successfully written into the buffer. This number may be smaller than the number of the requested bytes if there is not enough free space in the transmit buffer.

The *writeGranularity* argument can be used to split the data into smaller chunks, each of the size given by the *writeGranularity* value. The FMSTR\_PipeWrite function writes as many data chunks as possible into the transmit buffer and does not attempt to write an incomplete chunk. This feature can prove to be useful to avoid the intermediate caching when writing an array of integer values or other multi-byte data items. When making the *nGranularity* value equal to the *nLength* value, all data are considered as one chunk which is either written successfully as a whole or not at all. The *nGranularity* value of 0 or 1 disables the data-chunk approach.

## FMSTR\_PipeRead

## Prototype

```
FMSTR_PIPE_SIZE FMSTR_PipeRead(FMSTR_HPIPE pipeHandle, FMSTR_ADDR pipeData,  
    FMSTR_PIPE_SIZE pipeDataLen, FMSTR_PIPE_SIZE readGranularity);
```

- Declaration: *freemaster.h*
- Implementation: *freemaster\_pipes.c*

## Arguments

- *pipeHandle* [in] - pipe handle returned from the FMSTR\_PipeOpen function call
- *pipeData* [in] - address of the data buffer to be filled with the received data
- *pipeDataLen* [in] - length of the data to be read
- *readGranularity* [in] - size of the minimum unit of data which is to be read

**Description** This function copies the data received from the pipe from its receive buffer to the user buffer for further processing. The function returns the number of bytes that were successfully copied to the buffer. This number may be smaller than the number of the requested bytes if there is not enough data bytes available in the receive buffer.

The *readGranularity* argument can be used to copy the data in larger chunks in the same way as described in the FMSTR\_PipeWrite function.

**API data types** This section describes the data types used in the FreeMASTER driver. The information provided here can be useful when modifying or porting the FreeMASTER Communication Driver to new NXP platforms.

**Note:** The licensing conditions prohibit use of FreeMASTER and the FreeMASTER Communication Driver with non-NXP MPU or MCU products.

**Public common types** The table below describes the public data types used in the FreeMASTER driver API calls. The data types are declared in the *freemaster.h* header file.

| Type name                                                                                                                                                                                                                 | Description                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <i>FM-STR_ADDR</i><br>For example, this type is defined as long integer on the 56F8xxx platform where the 24-bit addresses must be supported, but the C-pointer may be only 16 bits wide in some compiler configurations. | Data type used to hold the memory address. On most platforms, this is normally a C-pointer, but it may also be a pure integer type. |
| <i>FM-STR_SIZE</i><br>It is required that this type is unsigned and at least 16 bits wide integer.                                                                                                                        | Data type used to hold the memory block size.                                                                                       |
| <i>FM-STR_BOOL</i><br>This type is used only in zero/non-zero conditions in the driver code.                                                                                                                              | Data type used as a general boolean type.                                                                                           |
| <i>FM-STR_APPCM</i><br>Generally, this is an unsigned 8-bit value.                                                                                                                                                        | Data type used to hold the Application Command code.                                                                                |
| <i>FM-STR_APPCM</i><br>Generally, this is an unsigned 8-bit value.                                                                                                                                                        | Data type used to create the Application Command data buffer.                                                                       |
| <i>FM-STR_APPCM</i><br>Generally, this is an unsigned 8-bit value.                                                                                                                                                        | Data type used to hold the Application Command result code.                                                                         |

**Public TSA types** The table describes the TSA-specific public data types. These types are declared in the *freemaster\_tsa.h* header file, which is included in the user application indirectly by the *freemaster.h* file.

|                       |                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>FM-STR_TSA_TII</i> | Data type used to hold a descriptor index in the TSA table or a table index in the list of TSA tables.<br>By default, this is defined as <i>FM-STR_SIZE</i> . |
| <i>FM-STR_TSA_TS</i>  | Data type used to hold a memory block size, as used in the TSA descriptors.<br>By default, this is defined as <i>FM-STR_SIZE</i> .                            |

**Public Pipes types** The table describes the data types used by the FreeMASTER Pipes API:

|                       |                                                                                                                |
|-----------------------|----------------------------------------------------------------------------------------------------------------|
| <i>FM-STR_HPIPE</i>   | Pipe handle that identifies the open-pipe object.<br>Generally, this is a pointer to a void type.              |
| <i>FM-STR_PIPE_PC</i> | Integer type required to hold at least 7 bits of data.<br>Generally, this is an unsigned 8-bit or 16-bit type. |
| <i>FM-STR_PIPE_SI</i> | Integer type required to hold at least 16 bits of data.<br>This is used to store the data buffer sizes.        |
| <i>FM-STR_PPIPEF</i>  | Pointer to the pipe handler function.<br>See <a href="#">FM-STR_PipeOpen</a> for more details.                 |

**Internal types** The table describes the data types used internally by the FreeMASTER driver. The data types are declared in the platform-specific header file and they are not available in the application code.

|                                                                                                          |                                                                         |
|----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| <i>FMSTR_U8</i>                                                                                          | The smallest memory entity.                                             |
| On the vast majority of platforms, this is an unsigned 8-bit integer.                                    |                                                                         |
| On the 56F8xx DSP platform, this is defined as an unsigned 16-bit integer.                               |                                                                         |
| <i>FMSTR_U16</i>                                                                                         | Unsigned 16-bit integer.                                                |
| <i>FMSTR_U32</i>                                                                                         | Unsigned 32-bit integer.                                                |
| <i>FMSTR_S8</i>                                                                                          | Signed 8-bit integer.                                                   |
| <i>FMSTR_S16</i>                                                                                         | Signed 16-bit integer.                                                  |
| <i>FMSTR_S32</i>                                                                                         | Signed 32-bit integer.                                                  |
| <i>FMSTR_FLOAT</i>                                                                                       | 4-byte standard IEEE floating-point type.                               |
| <i>FMSTR_FLAGS</i>                                                                                       | Data type forming a union with a structure of flag bit-fields.          |
| <i>FMSTR_SIZE8</i>                                                                                       | Data type holding a general size value, at least 8 bits wide.           |
| <i>FMSTR_INDEX</i>                                                                                       | General for-loop index. Must be signed, at least 16 bits wide.          |
| <i>FMSTR_BCHR</i>                                                                                        | A single character in the communication buffer.                         |
| Typically, this is an 8-bit unsigned integer, except for the DSP platforms where it is a 16-bit integer. |                                                                         |
| <i>FMSTR_BPTR</i>                                                                                        | A pointer to the communication buffer (an array of <i>FMSTR_BCHR</i> ). |

## Document references

### Links

- This document online: <https://mcuxpresso.nxp.com/mcuxsdk/latest/html/middleware/freemaster/doc/index.html>

- FreeMASTER tool home: [www.nxp.com/freemaster](http://www.nxp.com/freemaster)
- FreeMASTER community area: [community.nxp.com/community/freemaster](http://community.nxp.com/community/freemaster)
- FreeMASTER GitHub code repo: <https://github.com/nxp-mcuxpresso/mcux-freemaster>
- MCUXpresso SDK home: [www.nxp.com/mcuxpresso](http://www.nxp.com/mcuxpresso)
- MCUXpresso SDK builder: [mcuxpresso.nxp.com/en](http://mcuxpresso.nxp.com/en)

## Documents

- *FreeMASTER Usage Serial Driver Implementation* (document [AN4752](#))
- *Integrating FreeMASTER Time Debugging Tool With CodeWarrior For Microcontrollers v10.X Project* (document [AN4771](#))
- *Flash Driver Library For MC56F847xx And MC56F827xx DSC Family* (document [AN4860](#))

**Revision history** This Table summarizes the changes done to this document since the initial release.

| Revision | Date    | Description                                                                                                                                                                                                                                                                                                          |
|----------|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.0      | 03/2006 | Limited initial release                                                                                                                                                                                                                                                                                              |
| 2.0      | 09/2007 | Updated for FreeMASTER version. New Freescale document template used.                                                                                                                                                                                                                                                |
| 2.1      | 12/2007 | Added description of the new Fast Recorder feature and its API.                                                                                                                                                                                                                                                      |
| 2.2      | 04/2010 | Added support for MPC56xx platform, Added new API for use CAN interface.                                                                                                                                                                                                                                             |
| 2.3      | 04/2011 | Added support for Kxx Kinetis platform and MQX operating system.                                                                                                                                                                                                                                                     |
| 2.4      | 06/2011 | Serial driver update, adds support for USB CDC interface.                                                                                                                                                                                                                                                            |
| 2.5      | 08/2011 | Added Packet Driven BDM interface.                                                                                                                                                                                                                                                                                   |
| 2.7      | 12/2013 | Added FLEXCAN32 interface, byte access and isr callback configuration option.                                                                                                                                                                                                                                        |
| 2.8      | 06/2014 | Removed obsolete license text, see the software package content for up-to-date license.                                                                                                                                                                                                                              |
| 2.9      | 03/2015 | Update for driver version 1.8.2 and 1.9: FreeMASTER Pipes, TSA Active Content, LIN Transport Layer support, DEBUG-TX communication troubleshooting, Kinetis SDK support.                                                                                                                                             |
| 3.0      | 08/2016 | Update for driver version 2.0: Added support for MPC56xx, MPC57xx, KEAxx and S32Kxx platforms. New NXP document template as well as new license agreement used. added MCAN interface. Folders structure at the installation destination was rearranged.                                                              |
| 4.0      | 04/2019 | Update for driver released as part of FreeMASTER v3.0 and MCUXpresso SDK 2.6. Updated to match new V4 serial communication protocol and new configuration options. This version of the document removes substantial portion of outdated information related to S08, S12, ColdFire, Power and other legacy platforms. |
| 4.1      | 04/2020 | Minor update for FreeMASTER driver included in MCUXpresso SDK 2.8.                                                                                                                                                                                                                                                   |
| 4.2      | 09/2020 | Added example applications description and information about the MCUXpresso Config Tools. Fixed the pipe-related API description.                                                                                                                                                                                    |
| 4.3      | 10/2024 | Added description of Network and Segger J-Link RTT interface configuration. Accompanying the MCUXpresso SDK version 24.12.00.                                                                                                                                                                                        |
| 4.4      | 04/2025 | Added Zephyr-specific information. Accompanying the MCUXpresso SDK version 25.06.00.                                                                                                                                                                                                                                 |

# Chapter 4

## RTOS

### 4.1 FreeRTOS

#### 4.1.1 FreeRTOS kernel

Open source RTOS kernel for small devices.

[FreeRTOS kernel for MCUXpresso SDK Readme](#)

[FreeRTOS kernel for MCUXpresso SDK ChangeLog](#)

[FreeRTOS kernel Readme](#)

#### 4.1.2 FreeRTOS drivers

This is set of NXP provided FreeRTOS reentrant bus drivers.

#### 4.1.3 backoffalgorithm

Algorithm for calculating exponential backoff with jitter for network retry attempts.

[Readme](#)

#### 4.1.4 corehttp

C language HTTP client library designed for embedded platforms.

#### 4.1.5 corejson

JSON parser.

## **Readme**

### **4.1.6 coremqtt**

MQTT publish/subscribe messaging library.

### **4.1.7 corepkcs11**

PKCS #11 key management library.

## **Readme**

### **4.1.8 freertos-plus-tcp**

Open source RTOS FreeRTOS Plus TCP.

## **Readme**