



MCUXpresso SDK Documentation

Release 25.12.00-pvw1



NXP
Oct 20, 2025



Table of contents

1	TWR-MC56F8400	3
1.1	Overview	3
1.2	Getting Started with MCUXpresso SDK Package	3
1.2.1	Getting Started with Package	3
1.3	Getting Started with MCUXpresso SDK GitHub	13
1.3.1	Getting Started with MCUXpresso SDK Repository	13
1.4	Release Notes	25
1.4.1	MCUXpresso SDK Release Notes	25
1.5	ChangeLog	28
1.5.1	MCUXpresso SDK Changelog	28
2	MC56F84789	43
2.1	ADC16:Combinational logic inputs Driver	43
2.2	The Driver Change Log	52
2.3	ADC16 Peripheral and Driver Overview	52
2.4	AOI:Combinational logic inputs Driver	52
2.5	The Driver Change Log	55
2.6	AOI Peripheral and Driver Overview	55
2.7	CADC: 12-bit Cyclic Analog-to-Digital Converter Driver	55
2.8	The Driver Change Log	90
2.9	CADC Peripheral and Driver Overview	90
2.10	Clock Driver	90
2.11	Driver Change Log	103
2.12	CMP: Comparator Driver	103
2.13	The Driver Change Log	113
2.14	CMP Peripheral and Driver Overview	113
2.15	COP: Computer Operating Properly(Watchdog) Driver	113
2.16	The Driver Change Log	117
2.17	COP Peripheral and Driver Overview	117
2.18	CRC: Cyclic Redundancy Check Driver	117
2.19	The Driver Change Log	121
2.20	CRC Peripheral and Driver Overview	121
2.21	DAC: 12-bit Digital-to-Analog Converter Driver	121
2.22	The Driver Change Log	131
2.23	DAC Peripheral and Driver Overview	131
2.24	DMA: Direct Memory Access Driver	131
2.25	The Driver Change Log	142
2.26	DMA Peripheral and Driver Overview	142
2.27	The Driver Change Log	142
2.28	EWM: External Watchdog Monitor Driver	142
2.29	The Driver Change Log	144
2.30	EWM Peripheral and Driver Overview	144
2.31	C90TFS Flash Driver	144
2.32	FlexCAN Driver	144
2.33	The Driver Change Log	171
2.34	FlexCAN Peripheral and Driver Overview	171

2.35	ftfx adapter	171
2.36	ftfx controller	171
2.37	ftfx feature	181
2.38	Ftftx FLASH Driver	182
2.39	ftfx utilities	189
2.40	GPIO: General-Purpose Input/Output Driver	190
2.41	The Driver Change Log	202
2.42	GPIO Peripheral and Driver Overview	202
2.43	I2C: Inter-Integrated Circuit Driver	202
2.44	I2C_DMA: DMA based I2C Driver	225
2.45	The Driver Change Log	226
2.46	I2C Peripheral and Driver Overview	226
2.47	INTC: Interrupt Controller Driver	226
2.48	The Driver Change Log	229
2.49	INTC Peripheral and Driver Overview	229
2.50	Common Driver	229
2.51	MCM: Miscellaneous Control Module Driver	244
2.52	The Driver Change Log	252
2.53	MCM Peripheral and Driver Overview	252
2.54	PDB: Programmable Delay Block	252
2.55	The Driver Change Log	261
2.56	PDB Peripheral and Driver Overview	262
2.57	PIT: Periodic Interrupt Timer (PIT) Driver	262
2.58	The Driver Change Log	267
2.59	PIT Peripheral and Driver Overview	267
2.60	PMC: Power Management Controller Driver	267
2.61	The Driver Change Log	270
2.62	PMC Peripheral and Driver Overview	270
2.63	eFlexPWM: Enhanced Flexible Pulse Width Modulator Driver	270
2.64	The Driver Change Log	308
2.65	eFlexPWM Peripheral and Driver Overview	308
2.66	QDC: Quadrature Decoder Driver	308
2.67	QDC Peripheral and Driver Overview	320
2.68	QSCI: Queued Serial Communications Interface Driver	320
2.69	QSCI_DMA: DMA based QSCI Driver	336
2.70	The Driver Change Log	339
2.71	QSCI Peripheral and Driver Overview	339
2.72	QSPI_DMA: DMA based QSPI Driver	339
2.73	QSPI: Queued SPI Driver	342
2.74	QSPI Peripheral and Driver Overview	360
2.75	QTMR: Quad Timer Driver	360
2.76	The Driver Change Log	384
2.77	QTMR Peripheral and Driver Overview	384
2.78	The Driver Change Log	384
2.79	SIM: System Integration Module Driver	384
2.80	The Driver Change Log	397
2.81	SIM Peripheral and Driver Overview	397
2.82	XBAR: Inter-Peripheral Crossbar Switch Driver	397
2.83	The Driver Change Log	402
2.84	XBAR Peripheral and Driver Overview	402
2.85	XBARB: Inter-Peripheral Crossbar Switch Driver	402
2.86	The Driver Change Log	402
2.87	XBARB Peripheral and Driver Overview	402
3	Middleware	403
4	RTOS	405
4.1	FreeRTOS	405

4.1.1	FreeRTOS kernel	405
4.1.2	FreeRTOS drivers	405
4.1.3	backoffalgorithm	405
4.1.4	corehttp	405
4.1.5	corejson	405
4.1.6	coremqtt	406
4.1.7	corepkcs11	406
4.1.8	freertos-plus-tcp	406

This documentation contains information specific to the twrmc56f8400 board.


Chapter 1

TWR-MC56F8400

1.1 Overview

The TWR-MC56F8400 is a standalone development board ideally suited for Motor and Digital Power control applications.

- It can be used in conjunction with the Tower® System peripheral boards, including the LV3PH motor control kit TWR-MC-LV3PH module.
- The MC56F84789 included on the board comes pre-loaded with an application demonstrating the ADC with an FIR filter application.
- The module features serial I/O over USB, CAN circuits and access to each pin.
- All signals are also available on the headers for easy and neat coupling to your project.
- It can also be used as the main control board with an APMOTOR56F8000E motor control board.



MCU device and part on board is shown below:

- Device: MC56F84789
- PartNumber: MC56F84789VLL

1.2 Getting Started with MCUXpresso SDK Package


1.2.1 Getting Started with Package

Overview

The NXP MCUXpresso software and tools offer comprehensive development solutions designed to optimize, ease, and help accelerate embedded system development of applications based on general purpose, crossover, and Bluetooth-enabled MCUs from NXP. The MCUXpresso SDK includes a flexible set of peripheral drivers designed to speed up and simplify development of embedded applications. Along with the peripheral drivers, the MCUXpresso SDK provides an extensive and rich set of example applications covering everything from basic peripheral use case examples to full demo applications. The MCUXpresso SDK contains optional RTOS integrations such as FreeRTOS and Azure RTOS, and various other middleware to support rapid development.

For supported toolchain versions, see *MCUXpresso SDK Release Notes* (document MCUXSDKRN).

For more details about MCUXpresso SDK, see [MCUXpresso Software Development Kit \(SDK\)](#).




Build and run SDK example on codewarrior

Install CodeWarrior Take below codewarrior specific combination as example

- CodeWarrior Development Studio v11.2 + CodeWarrior for DSC v11.2 SP1 (Service Pack 1)

Steps to install CodeWarrior


- Download the following packages from [CodeWarrior for 56800 Digital Signal Controller v11.2](#), and ensure to keep them in the same folder.
 - CodeWarrior for DSC v11.2: CW_MCU_v11.2_b221206.exe.
 - DSC support package: com.freescale.mcu11_2.dsc.updatesite.zip.
 - DSC device ServicePack1: com.freescale.mcu11_2.DSC_devices.win.sp.v1.0.26.zip.
- Install CodeWarrior for DSC v11.2.
- Install ServicePack1 within CodeWarrior from the menu. Click the **Help** menu -> select **Install new software** -> **Add** -> **Archive** -> select the downloaded SP1 -> open -> check **MCU v11.2 DSC Service Packs** -> click **Next**.

**NOTE**


- CodeWarrior for DSC only support Windows.
- Check the corresponding board release note for specific requirement of codewarrior and service pack version.

Build an example application To build the hello_world example application, perform the following example steps:


1. Launch CodeWarrior and in the workspace launcher, choose a workspace which holds the projects to use. If the dialogue box does not pop up, enter a workspace folder and create one workspace.



Then the CodeWarrior Development Studio workspace with empty projects appears.



2. Import the project into the workspace. Click **Import project** in the **Commander** pane. A form pops up. Click **Browse** to the SDK install directory. Take TWR-MC56F8400 SDK as an example, all available demo projects are shown. Select the `hello_world` project in the list and click **Finish**.

**NOTE**


- If you already know the project location, navigate to the folder when clicking **Browse**, and only one project can be seen. To locate most example application workspace files, use the following path

```
<install_dir>/boards/<board_name>/<example_type>/<application_name>/codewarrior
```

Take TWR-MC56F8400 SDK as an example, the hello_world workspace is located in

```
<install_dir>/boards/twrmc56f8400/demo_apps/hello_world/codewarrior
```

3. Select the desired build target from the drop-down menu. For this example, select **hello_world** – **flash_sdm_lpm_debug**



4. To build the demo application, click **Build (All)** in the **Commander** pane.
5. The build completes without errors.

Board debugger setup Board debugger info:


- Default debugger is OSJTAG.
- Onboard debugger USB port is J18, which set the debugger and COM port.
- Onboard debugger firmware update jumper is J17.

To download and run the application, perform the following steps:

- Connect USB cable between the host PC and the debugger USB port.
- Install the debugger driver and USB CDC driver as PC hint if it is the first time you run it on the PC. The debugger and USB CDC driver are provided by CodeWarrior by default.
- The CodeWarrior may prompt to update the debugger firmware, which requires to connect the firmware update jumper on board and then follow the instruction by CodeWarrior to finish the firmware update.

Run an example application To download and run the application, perform the following steps:


1. Open the terminal application on the PC, such as PuTTY or TeraTerm, and connect to the debug COM port (see [How to determine COM port](#)). Configure the terminal with these settings:
 - 115200, defined by BOARD_DEBUG_UART_BAUDRATE in the *board.h* file
 - No parity
 - 8 data bits




- 1 stop bit

- For this example (TWR-MC56F8400 hello_world), click **Debug** in the **Commander** pane, and select the hello_world_flash_sdm_lpm_debug_OSJTAG launch configuration. Then the application is downloaded onto target board and automatically runs to the main() function in the CodeWarrior Development Studio.


MQX Tools Processor Expert Run Window Help



tion.

**Note:**

- Generally there are four build configurations for DSC SDK examples: flash_sdm_lpm_debug, flash_sdm_lpm_release, flash_ldm_lpm_debug, and flash_ldm_lpm_release.
 - *_debug: uses optimization level 1
 - *_release: uses optimization level 4
 - sdm: small data memory model
 - ldm: large data memory model
 - lpm: large program memory model
- Select corresponding launch configuration based on build target and debugger type.
- Some examples may require specific hardware settings, check each demo readme document, which includes detail instructions for HW and SW settings.



3. To run the code, click **Run** on the toolbar.
4. The hello_world application is now running and a banner is displayed on the terminal.




Project template for a specific DSC part

For device with specific part number, the easiest way to set up customer own project based on MCUXpresso DSC SDK peripheral driver, is the project_template. MCUXpresso Config Tool is used to generate the project_template.

The project_template provides basic MCUXpresso DSC SDK software framework, including startup, linker file, device header file, debug setting, peripheral driver, FreeMASTER, and so on.

Steps to generate the project_template for specific derivative part number by MCUXpresso Config Tool

1. Download the specific device SDK package and unzip it. note: The project template requires FreeMASTER, middleware FreeMASTER selection is a must when downloading DSC SDK from nxp website
2. Use MCUXpresso Config Tool to create a project_template project as below(take



MC56F84442 as example).

3. Import the generated template_project into CodeWarrior IDE and start the development.

NOTE

- The default created project template by Config Tool is `project_template_{part_number}`. User could modify the default name in **Project name** textbox.
- All peripheral drivers files are included in the generated `project_template` project. They are same as the peripheral drivers within SDK package. If some drivers are not used or required, users may delete them in CodeWarrior, or delete them directly under folder `${project_path}/drivers`.

How to determine COM port

This section describes the steps necessary to determine the debug COM port number of your NXP hardware development platform. All NXP boards ship with a factory programmed, onboard debug interface, whether it is based on MCU-Link or the legacy OpenSDA, LPC-Link2, P&E Micro OSJTAG interface. To determine what your specific board ships with, see Default debug interfaces.

1. **Linux:** The serial port can be determined by running the following command after the USB Serial is connected to the host:

```
$ dmesg | grep "ttyUSB"
[503175.307873] usb 3-12: cp210x converter now attached to ttyUSB0
[503175.309372] usb 3-12: cp210x converter now attached to ttyUSB1
```

There are two ports, one is for core0 debug console and the other is for core1.


2. **Windows:** To determine the COM port open Device Manager in the Windows operating system. Click the **Start** menu and type **Device Manager** in the search bar.

In the Device Manager, expand the **Ports (COM & LPT)** section to view the available ports. The COM port names are different for all the NXP boards.


1. **CMSIS-DAP/mbed/DAPLink** interface:




2. **P&E Micro:**




3. **J-Link:**



4. **P&E Micro OSJTAG:**



5. **MRB-KW01:**



1.3 Getting Started with MCUXpresso SDK GitHub


1.3.1 Getting Started with MCUXpresso SDK Repository

Installation

NOTE

If the installation instruction asks/selects whether to have the tool installation path added to the PATH variable, agree/select the choice. This option ensures that the tool can be used in any terminal in any path. [Verify the installation](#) after each tool installation.

Install Prerequisites with MCUXpresso Installer The MCUXpresso Installer offers a quick and easy way to install the basic tools needed. The MCUXpresso Installer can be obtained from <https://github.com/nxp-mcuxpresso/vscode-for-mcux/wiki/Dependency-Installation>. The MCUXpresso Installer is an automated installation process, simply select MCUXpresso SDK Developer from the menu and click install. If you prefer to install the basic tools manually, refer to the next section.



Alternative: Manual Installation

Basic tools

Git Git is a free and open source distributed version control system. Git is designed to handle everything from small to large projects with speed and efficiency. To install Git, visit the official

Git website. Download the appropriate version(you may use the latest one) for your operating system (Windows, macOS, Linux). Then run the installer and follow the installation instructions.

User `git --version` to check the version if you have a version installed.

Then configure your username and email using the commands:

```
git config --global user.name "Your Name"
git config --global user.email "youremail@example.com"
```

Python Install python 3.10 or latest. Follow the [Python Download](#) guide.

Use `python --version` to check the version if you have a version installed.

West Please use the west version equal or greater than 1.2.0

```
# Note: you can add option '--default-timeout=1000' if you meet connection issue. Or you may set a different
↪source using option '-i'.
# for example, in China you could try: pip install -U west -i https://pypi.tuna.tsinghua.edu.cn/simple
pip install -U west
```

Build And Configuration System

CMake It is strongly recommended to use CMake version equal or later than 3.30.0. You can get latest CMake distributions from [the official CMake download page](#).

For Windows, you can directly use the .msi installer like `cmake-3.31.4-windows-x86_64.msi` to install.

For Linux, CMake can be installed using the system package manager or by getting binaries from [the official CMake download page](#).

After installation, you can use `cmake --version` to check the version.

Ninja Please use the ninja version equal or later than 1.12.1.

By default, Windows comes with the Ninja program. If the default Ninja version is too old, you can directly download the [ninja binary](#) and register the ninja executor location path into your system path variable to work.

For Linux, you can use your [system package manager](#) or you can directly download the [ninja binary](#) to work.

After installation, you can use `ninja --version` to check the version.

Kconfig MCUXpresso SDK uses Kconfig python implementation. We customize it based on our needs and integrate it into our build and configuration system. The Kconfiglib sources are placed under `mcuxsdk/scripts/kconfig` folder.

Please make sure [python](#) environment is setup ready then you can use the Kconfig.

Ruby Our build system supports IDE project generation for iar, mdk, codewarrior and xtensa to provide OOB from build to debug. This feature is implemented with ruby. You can follow the guide [ruby environment setup](#) to setup the ruby environment. Since we provide a built-in portable ruby, it is just a simple one cmd installation.

If you only work with CLI, you can skip this step.


Toolchain MCUXpresso SDK supports all mainstream toolchains for embedded development. You can install your used or interested toolchains following the guides.

Toolchain	Download and Installation Guide	Note
Armgcc	Arm GNU Toolchain Install Guide	ARMGCC is default toolchain
IAR	IAR Installation and Licensing quick reference guide	
MDK	MDK Installation	
Armclang	Installing Arm Compiler for Embedded	
Zephyr	Zephyr SDK	
Codewarrior	NXP CodeWarrior	
Xtensa	Tensilica Tools	
NXP S32Compiler RISC-V Zen-V	NXP Website	

After you have installed the toolchains, register them in the system environment variables. This will allow the west build to recognize them:

Toolchain	Environment Variable	Example	Cmd Line Argument
Armgcc	AR-MGCC_DIR	C:\armgcc for windows/usr for Linux. Typically arm-none-eabi-* is installed under /usr/bin	– toolchain armgcc
IAR	IAR_DIR	C:\iar\ewarm-9.60.3 for Windows/opt/iarsystems/bxarm-9.60.3 for Linux	– toolchain iar
MDK	MDK_DIR	C:\Keil_v5 for Windows.MDK IDE is not officially supported with Linux.	– toolchain mdk
Armclang	ARM-CLANG_DIR	C:\ArmCompilerforEmbedded6.22 for Windows/opt/ArmCompilerforEmbedded6.21 for Linux	– toolchain mdk
Zephyr	ZEPHYR_DIR	c:\NXP\zephyr-sdk-<version> for windows/opt/zephyr-sdk-<version> for Linux	– toolchain zephyr
CodeWarrior	CW_DIR	C:\Freescall\CW MCU v11.2 for windowsCodeWarrior is not supported with Linux	– toolchain code-warrior
Xtensa	XCC_DIR	C:\xtensa\XtDevTools\install\tools\RI-2023.11-win32\XtensaTools for windows/opt/xtensa/XtDevTools/install/tools/RI-2023.11-Linux/XtensaTools for Linux	– toolchain xtensa
NXP S32Compiler RISC-V Zen-V	RISCV-LVM_DIR	C:\riscv-llvm-win32_b298_b298_2024.08.12 for Windows/opt/riscv-llvm-Linux-x64_b298_b298_2024.08.12 for Linux	– toolchain riscv-llvm

- The <toolchain>_DIR is the root installation folder, not the binary location folder. For IAR, it is directory containing following installation folders:



- MDK IDE using armclang toolchain only officially supports Windows. In Linux, please directly use armclang toolchain by setting ARMCLANG_DIR. In Windows, since most Keil users will install MDK IDE instead of standalone armclang toolchain, the MDK_DIR has higher priority than ARMCLANG_DIR.
- For Xtensa toolchain, please set the XTENSA_CORE environment variable. Here's an example list:

Device Core	XTENSA_CORE
RT500 fusion1	nxp_rt500_RI23_11_newlib
RT600 hifi4	nxp_rt600_RI23_11_newlib
RT700 hifi1	rt700_hifi1_RI23_11_nlib
RT700 hifi4	t700_hifi4_RI23_11_nlib
i.MX8ULP fusion1	fusion_nxp02_dsp_prod

- In Windows, the short path is used in environment variables. If any toolchain is using the long path, you can open a command window from the toolchain folder and use below command to get the short path: for %i in (.) do echo %~fsi

Tool installation check Once installed, open a terminal or command prompt and type the associated command to verify the installation.

If you see the version number, you have successfully installed the tool. Else, check whether the tool's installation path is added into the PATH variable. You can add the installation path to the PATH with the commands below:

- Windows: Open command prompt or powershell, run below command to show the user PATH variable.

```
reg query HKEY_CURRENT_USER\Environment /v PATH
```

The tool installation path should be C:\Users\xxx\AppData\Local\Programs\Git\cmd. If the path is not seen in the output from above, append the path value to the PATH variable with the command below:

```
reg add HKEY_CURRENT_USER\Environment /v PATH /d "%PATH%;C:\Users\xxx\AppData\Local\Programs\Git\cmd"
```

Then close the command prompt or powershell and verify the tool command again.

- Linux:
 1. Open the \$HOME/.bashrc file using a text editor, such as vim.
 2. Go to the end of the file.
 3. Add the line which appends the tool installation path to the PATH variable and export PATH at the end of the file. For example, export PATH="/Directory1:\$PATH".
 4. Save and exit.

5. Execute the script with `source .bashrc` or reboot the system to make the changes live. To verify the changes, run `echo $PATH`.
- macOS:
 1. Open the `$HOME/.bash_profile` file using a text editor, such as `nano`.
 2. Go to the end of the file.
 3. Add the line which appends the tool installation path to the `PATH` variable and export `PATH` at the end of the file. For example, export `PATH="/Directory1:$PATH"`.
 4. Save and exit.
 5. Execute the script with `source .bash_profile` or reboot the system to make the changes live. To verify the changes, run `echo $PATH`.

Get MCUXpresso SDK Repo

Establish SDK Workspace To get the MCUXpresso SDK repository, use the `west` tool to clone the manifest repository and checkout all the west projects.

```
# Initialize west with the manifest repository
west init -m https://github.com/nxp-mcuxpresso/mcuxsdk-manifests/ mcuxpresso-sdk

# Update the west projects
cd mcuxpresso-sdk
west update

# Allow the usage of west extensions provided by MCUXpresso SDK
west config commands.allow__extensions true
```

Install Python Dependency(If do tool installation manually) To create a Python virtual environment in the west workspace core repo directory `mcuxsdk`, follow these steps:

1. Navigate to the core directory:

```
cd mcuxsdk
```

2. [Optional] Create and activate the virtual environment: If you don't want to use the python virtual environment, skip this step. **We strongly suggest you use `venv` to avoid conflicts with other projects using python.**

```
python -m venv .venv

# For Linux/MacOS
source .venv/bin/activate

# For Windows
.\.venv\Scripts\activate
# If you are using powershell and see the issue that the activate script cannot be run.
# You may fix the issue by opening the powershell as administrator and run below command:
powershell Set-ExecutionPolicy RemoteSigned
# then run above activate command again.
```

Once activated, your shell will be prefixed with `(.venv)`. The virtual environment can be deactivated at any time by running `deactivate` command.

Remember to activate the virtual environment every time you start working in this directory. If you are using some modern shell like `zsh`, there are some powerful plugins to help you auto switch `venv` among workspaces. For example, [zsh-autoswitch-virtualenv](#).

3. Install the required Python packages:

```
# Note: you can add option '--default-timeout=1000' if you meet connection issue. Or you may set a ↵
↵different source using option '-i'.
# for example, in China you could try: pip3 install -r mcuxsdk/scripts/requirements.txt -i https://pypi.
↵tuna.tsinghua.edu.cn/simple
pip install -r scripts/requirements.txt
```

Explore Contents

This section helps you build basic understanding of current fundamental project content and guides you how to build and run the provided example project in whole SDK delivery.

Folder View The whole MCUXpresso SDK project, after you have done the west init and west update operations follow the guideline at [Getting Started Guide](#), have below folder structure:

Folder	Description
mani-fests	Manifest repo, contains the manifest file to initialize and update the west workspace.
mcuxsdk	The MCUXpresso SDK source code, examples, middleware integration and script files.

All the projects record in the [Manifest repo](#) are checked out to the folder mcuxsdk/, the layout of mcuxsdk folder is shown as below:

Folder	Description
arch	Arch related files such as ARM CMSIS core files, RISC-V files and the build files related to the architecture.
cmake	The cmake modules, files which organize the build system.
com-po-nents	Software components.
de-vices	Device support package which categorized by device series. For each device, header file, feature file, startup file and linker files are provided, also device specific drivers are included.
docs	Documentation source and build configuration for this sphinx built online documentation.
drivers	Peripheral drivers.
ex-am-ples	Various demos and examples, support files on different supported boards. For each board support, there are board configuration files.
mid-dle-ware	Middleware components integrated into SDK.
rtos	Rtos components integrated into SDK.
scripts	Script files for the west extension command and build system support.
svd	Svd files for devices, this is optional because of large size. Customers run west manifest config group.filter +optional and west update mcux-soc-svd to get this folder.

Examples Project The examples project is part of the whole SDK delivery, and locates in the folder mcuxsdk/examples of west workspace.

Examples files are placed in folder of <example_category>, these examples include (but are not limited to)

- **demo_apps:** Basic demo set to start using SDK, including `hello_world` and `led_blinky`.
- **driver_examples:** Simple applications that show how to use the peripheral drivers for a single use case. These applications typically only use a single peripheral but there are cases where multiple peripherals are used (for example, SPI transfer using DMA).

Board porting layers are placed in folder of `_boards/<board_name>` which aims at providing the board specific parts for examples code mentioned above.


Run a demo using MCUXpresso for VS Code

This section explains how to configure MCUXpresso for VS Code to build, run, and debug example applications. This guide uses the `hello_world` demo application as an example. However, these steps can be applied to any example application in the MCUXpresso SDK.

Build an example application This section assumes that the user has already obtained the SDK as outlined in [Get MCUXpresso SDK Repo](#).


To build an example application:

1. Import the SDK into your workspace. Click **Import Repository** from the **QUICKSTART PANEL**.




Note: You can import the SDK in several ways. Refer to [MCUXpresso for VS Code Wiki](#) for details.


Select **Local** if you've already obtained the SDK as seen in [Get MCUXpresso SDK Repo](#). Select your location and click **Import**.



2. Click **Import Example from Repository** from the **QUICKSTART PANEL**.




In the dropdown menu, select the MCUXpresso SDK, the Arm GNU Toolchain, your board, template, and application type. Click **Import**.




Note: The MCUXpresso SDK projects can be imported as **Repository applications** or **Freestanding applications**. The difference between the two is the import location. Projects imported as Repository examples will be located inside the MCUXpresso SDK, whereas Freestanding examples can be imported to a user-defined location. Select between these by designating your selection in the **App type** dropdown menu.

- VS Code will prompt you to confirm if the imported files are trusted. Click **Yes**.
- Navigate to the **PROJECTS** view. Find your project and click the **Build Project** icon.




The integrated terminal will open at the bottom and will display the build output.




Run an example application **Note:** for full details on MCUXpresso for VS Code debug probe support, see [MCUXpresso for VS Code Wiki](#).

1. Open the **Serial Monitor** from the VS Code's integrated terminal. Select the VCom Port for your device and set the baud rate to 115200.



2. Navigate to the **PROJECTS** view and click the play button to initiate a debug session.



The debug session will begin. The debug controls are initially at the top.

```

C hello_world.c x
frdm-mxc444_hello_world > examples > demo_apps > hello_world > C hello_v
18  /*****
21
22  /*****
23  * Variables
24  *****/
25
26  /*****
27  * Code
28  *****/
29  /*!
30  * @brief Main function
31  */
32  int main(void)
33  {
34      char ch;
35
36      /* Init board hardware. */
37  BOARD_InitHardware();
38
39      PRINTF("hello world.\r\n");
40
41      while (1)
42      {
43          ch = GETCHAR();
44          PUTCHAR(ch);
45      }
46  }
47

```

3. Click **Continue** on the debug controls to resume execution of the code. Observe the output on the **Serial Monitor**.

```

PROBLEMS  OUTPUT  TERMINAL  PERIPHERALS  RTOS DETAILS  PORTS  DEBUG CONSOLE  SERIAL MONITOR
+ Open an additional monitor
Monitor Mode Serial View Mode Text Port COM40 - MCU-Link VCom Port (COM40)
[Stop Monitoring] [Icons]
---- Opened the serial port COM40 ----
hello world.
|

```

Running a demo using ARMGCC CLI/IAR/MDK

Supported Boards Use the west extension `west list_project` to understand the board support scope for a specified example. All supported build command will be listed in output:

```
west list_project -p examples/demo_apps/hello_world [-t armgcc]
```

```
INFO: [ 1][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↳ evk9mimx8ulp -Dcore_id=cm33]
```

```
INFO: [ 2][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↳ evkbimxrt1050]
```

```
INFO: [ 3][west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
```

(continues on next page)

(continued from previous page)

```

↪ evkbnmimxrt1060]
INFO: [ 4]west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↪ evkbnmimxrt1170 -Dcore_id=cm4]
INFO: [ 5]west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↪ evkbnmimxrt1170 -Dcore_id=cm7]
INFO: [ 6]west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↪ evkbnmimxrt1060]
INFO: [ 7]west build -p always examples/demo_apps/hello_world --toolchain armgcc --config release -b_
↪ evkbnmimxrt7ulp]
...

```

The supported toolchains and build targets for an example are decided by the example-self example.yml and board example.yml, please refer Example Toolchains and Targets for more details.

Build the project Use west build -h to see help information for west build command. Compared to zephyr's west build, MCUXpresso SDK's west build command provides following additional options for mcux examples:

- --toolchain: specify the toolchain for this build, default armgcc.
- --config: value for CMAKE_BUILD_TYPE. If not provided, build system will get all the example supported build targets and use the first debug target as the default one. Please refer Example Toolchains and Targets for more details about example supported build targets.

Here are some typical usages for generating a SDK example:

```

# Generate example with default settings, default used device is the mainset MK22F51212
west build -b frdmk22f examples/demo_apps/hello_world

# Just print cmake commands, do not execute it
west build -b frdmk22f examples/demo_apps/hello_world --dry-run

# Generate example with other toolchain like iar, default armgcc
west build -b frdmk22f examples/demo_apps/hello_world --toolchain iar

# Generate example with other config type
west build -b frdmk22f examples/demo_apps/hello_world --config release

# Generate example with other devices with --device
west build -b frdmk22f examples/demo_apps/hello_world --device MK22F12810 --config release

```

For multicore devices, you shall specify the corresponding core id by passing the command line argument -Dcore_id. For example

```

west build -b evkbnmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config_
↪ flexspi_nor_debug

```

For shield, please use the --shield to specify the shield to run, like

```

west build -b mimxrt700evk --shield a8974 examples/issdk_examples/sensors/fxls8974cf/fxls8974cf_poll -
↪ Dcore_id=cm33_core0

```

Sysbuild(System build) To support multicore project building, we ported Sysbuild from Zephyr. It supports combine multiple projects for compilation. You can build all projects by adding --sysbuild for main application. For example:

```

west build -b evkbnmimxrt1170 --sysbuild ./examples/multicore_examples/hello_world/primary -Dcore_
↪ id=cm7 --config flexspi_nor_debug --toolchain=armgcc -p always

```

For more details, please refer to System build.

Config a Project Example in MCUXpresso SDK is configured and tested with pre-defined configuration. You can follow steps blow to change the configuration.

1. Run cmake configuration


```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world -Dcore_id=cm7 --cmake-only -p
```

Please note the project will be built without --cmake-only parameter.

2. Run guiconfig target

```
west build -t guiconfig
```

Then you will get the Kconfig GUI launched, like



You can reconfigure the project by selecting/deselecting Kconfig options.

After saving and closing the Kconfig GUI, you can directly run `west build` to build with the new configuration.

Flash *Note:* Please refer Flash and Debug The Example to enable west flash/debug support.

Flash the hello_world example:

```
west flash -r linkserver
```

Debug Start a gdb interface by following command:


```
west debug -r linkserver
```

Work with IDE Project The above build functionalities are all with CLI. If you want to use the toolchain IDE to work to enjoy the better user experience especially for debugging or you are already used to develop with IDEs like IAR, MDK, Xtensa and CodeWarrior in the embedded world, you can play with our IDE project generation functionality.

This is the cmd to generate the evkbmimxrt1170 hello_world IAR IDE project files.

```
west build -b evkbmimxrt1170 examples/demo_apps/hello_world --toolchain iar -Dcore_id=cm7 --config_
↪ flexspi_nor_debug -p always -t guiproject
```

By default, the IDE project files are generated in mcuxsdk/build/<toolchain> folder, you can open the project file with the IDE tool to work:



Note, please follow the [Installation](#) to setup the environment especially make sure that [ruby](#) has been installed.

1.4 Release Notes

1.4.1 MCUXpresso SDK Release Notes

Overview

The MCUXpresso SDK is a comprehensive software enablement package designed to simplify and accelerate application development with Arm Cortex-M-based devices from NXP, including its general purpose, crossover and Bluetooth-enabled MCUs. MCUXpresso SW and Tools for DSC

further extends the SDK support to current 32-bit Digital Signal Controllers. The MCUXpresso SDK includes production-grade software with integrated RTOS (optional), integrated enabling software technologies (stacks and middleware), reference software, and more.

In addition to working seamlessly with the MCUXpresso IDE, the MCUXpresso SDK also supports and provides example projects for various toolchains. The Development tools chapter in the associated Release Notes provides details about toolchain support for your board. Support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

Underscoring our commitment to high quality, the MCUXpresso SDK is MISRA compliant and checked with Coverity static analysis tools. For details on MCUXpresso SDK, see [MCUXpresso-SDK: Software Development Kit for MCUXpresso](#).

MCUXpresso SDK

As part of the MCUXpresso software and tools, MCUXpresso SDK is the evolution of Kinetis SDK, includes support for LPC, DSC, PN76, and i.MX System-on-Chip (SoC). The same drivers, APIs, and middleware are still available with support for Kinetis, LPC, DSC, and i.MX silicon. The MCUXpresso SDK adds support for the MCUXpresso IDE, an Eclipse-based toolchain that works with all MCUXpresso SDKs. Easily import your SDK into the new toolchain to access to all of the available components, examples, and demos for your target silicon. In addition to the MCUXpresso IDE, support for the MCUXpresso Config Tools allows easy cloning of existing SDK examples and demos, allowing users to leverage the existing software examples provided by the SDK for their own projects.

In order to maintain compatibility with legacy Freescale code, the filenames and source code in MCUXpresso SDK containing the legacy Freescale prefix FSL has been left as is. The FSL prefix has been redefined as the NXP Foundation Software Library.

Development tools

The MCUXpresso SDK was tested with following development tools. Same versions or above are recommended.

- CodeWarrior Development Studio v11.2 with CodeWarrior for DSC v11.2 SP1 (Service Pack 1)

Supported development systems

This release supports board and devices listed in following table. The board and devices in bold were tested in this release.

De- vel- op- ment boards	MCU devices			
TWR-MC56F	MC56F84441VLF, MC56F844462VLH, MC56F84553VLH, MC56F84763VLH, MC56F84789VLL	MC56F84442VLH, MC56F84540VLF, MC56F84565VLK, MC56F84766VLK,	MC56F84451VLF, MC56F84543VLH, MC56F84567VLL, MC56F84769VLL,	MC56F84452VLH, MC56F84550VLF, MC56F84587VLL, MC56F84786VLK,

Release contents

Table 1 provides an overview of the MCUXpresso DSC SDK release package contents and locations.

Deliverable	Location
Boards	<install_dir>/boards
Demo applications	<install_dir>/boards/<board_name>/demo_apps
Driver examples	<install_dir>/boards/<board_name>/driver_examples
Documentation	<install_dir>/docs
Driver, SoC header files, extension header files and feature header files	<install_dir>/devices/<device_name>
Peripheral Drivers	<install_dir>/devices/<device_name>/drivers
Utilities such as debug console	<install_dir>/devices/<device_name>/utilities
Middleware	<install_dir>/middleware

MCUXpresso SDK release package

The MCUXpresso SDK release package content is aligned with the silicon subfamily it supports. This includes the boards, CMSIS, devices, middleware, and RTOS support.

Device support The device folder contains the whole software enablement available for the specific System-on-Chip (SoC) subfamily. This folder includes clock-specific implementation, device register header files, device register feature header files, and the system configuration source files. Included with the standard SoC support are folders containing peripheral drivers, toolchain support, and a standard debug console. The device-specific header files provide a direct access to the microcontroller peripheral registers. The device header file provides an overall SoC memory mapped register definition. The folder also includes the feature header file for each peripheral on the microcontroller. The toolchain folder contains the startup code and linker files for each supported toolchain. The startup code efficiently transfers the code execution to the main() function.

Board support The boards folder provides the board-specific demo applications, driver examples, and middleware examples.

Demo application and other examples The demo applications demonstrate the usage of the peripheral drivers to achieve a system level solution. Each demo application contains a readme file that describes the operation of the demo and required setup steps. The driver examples demonstrate the capabilities of the peripheral drivers. Each example implements a common use case to help demonstrate the driver functionality.

Middleware

Motor Control Software (ACIM, BLDC, PMSM) Motor control examples.

FreeMASTER FreeMASTER communication driver for 32-bit platforms.

Known issues

This section lists the known issues, limitations, and/or workarounds.

PRINTF issue for program address space When project is compiled with SDM, print the address in program address space malfunction.

- Failed example when SDM
 - `PRINTF("%p", main);` Root cause: in SDM, `%p` is treated as 16-bit value, however `main` in program address space is still considered as 32-bit.
- Workaround(compliant with SDM and LDM)
 - `PRINTF("0x%lx", (uint32_t)main);`

1.5 ChangeLog

1.5.1 MCUXpresso SDK Changelog

Board Support Files

board

[25.06.00]

- Initial version

clock_config

[25.06.00]

- Initial version

pin_mux

[25.06.00]

- Initial version
-

DSC_ADC16

[2.0.0]

- Initial version.
-

AOI

[2.0.0]

- Initial version.
-

CADC

[2.2.0]

- New Features
- Supported platforms which don't have ANA4 expansion MUX.

[2.1.0]

- Improvements
- Added some APIs to support some devices that equipped expansion mux.

[2.0.1]

- Bug Fixes
- Fixed the bug that channel mode set to wrong value.
- Fixed the bug that independent parallel mode set to wrong value.
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

CLOCK

[2.1.0]

- Accumulated bug fix
- MISRA warning fix

[2.0.0]

- Initial version.
-

CMP

[2.0.1]

- Improvements
- Supported MC56F82xxxx and MC56F84xxxx.
 - Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

COMMON

[2.6.0]

- Bug Fixes
 - Fix CERT-C violations.

[2.5.0]

- New Features
 - Added new APIs `InitCriticalSectionMeasurementContext`, `DisableGlobalIRQEx` and `EnableGlobalIRQEx` so that user can measure the execution time of the protected sections.

[2.4.3]

- Improvements
 - Enable irqs that mount under `irqsteer` interrupt extender.

[2.4.2]

- Improvements
 - Add the macros to convert peripheral address to secure address or non-secure address.

[2.4.1]

- Improvements
 - Improve for the macro redefinition error when integrated with `zephyr`.

[2.4.0]

- New Features
 - Added `EnableIRQWithPriority`, `IRQ_SetPriority`, and `IRQ_ClearPendingIRQ` for ARM.
 - Added `MSDK_EnableCpuCycleCounter`, `MSDK_GetCpuCycleCount` for ARM.

[2.3.3]

- New Features
 - Added `NETC` into status group.

[2.3.2]

- Improvements
 - Make driver `aarch64` compatible

[2.3.1]

- Bug Fixes
 - Fixed MAKE_VERSION overflow on 16-bit platforms.

[2.3.0]

- Improvements
 - Split the driver to common part and CPU architecture related part.

[2.2.10]

- Bug Fixes
 - Fixed the ATOMIC macros build error in cpp files.

[2.2.9]

- Bug Fixes
 - Fixed MISRA C-2012 issue, 5.6, 5.8, 8.4, 8.5, 8.6, 10.1, 10.4, 17.7, 21.3.
 - Fixed SDK_Malloc issue that not allocate memory with required size.

[2.2.8]

- Improvements
 - Included stddef.h header file for MDK tool chain.
- New Features:
 - Added atomic modification macros.

[2.2.7]

- Other Change
 - Added MECC status group definition.

[2.2.6]

- Other Change
 - Added more status group definition.
- Bug Fixes
 - Undef __VECTOR_TABLE to avoid duplicate definition in cmsis_clang.h

[2.2.5]

- Bug Fixes
 - Fixed MISRA C-2012 rule-15.5.

[2.2.4]

- Bug Fixes
 - Fixed MISRA C-2012 rule-10.4.

[2.2.3]

- New Features
 - Provided better accuracy of SDK_DelayAtLeastUs with DWT, use macro SDK_DELAY_USE_DWT to enable this feature.
 - Modified the Cortex-M7 delay count divisor based on latest tests on RT series boards, this setting lets result be closer to actual delay time.

[2.2.2]

- New Features
 - Added include RTE_Components.h for CMSIS pack RTE.

[2.2.1]

- Bug Fixes
 - Fixed violation of MISRA C-2012 Rule 3.1, 10.1, 10.3, 10.4, 11.6, 11.9.

[2.2.0]

- New Features
 - Moved SDK_DelayAtLeastUs function from clock driver to common driver.

[2.1.4]

- New Features
 - Added OTFAD into status group.

[2.1.3]

- Bug Fixes
 - MISRA C-2012 issue fixed.
 - * Fixed the rule: rule-10.3.

[2.1.2]

- Improvements
 - Add SUPPRESS_FALL_THROUGH_WARNING() macro for the usage of suppressing fallthrough warning.

[2.1.1]

- Bug Fixes
 - Deleted and optimized repeated macro.

[2.1.0]

- New Features
 - Added IRQ operation for XCC toolchain.
 - Added group IDs for newly supported drivers.

[2.0.2]

- Bug Fixes
 - MISRA C-2012 issue fixed.
 - * Fixed the rule: rule-10.4.

[2.0.1]

- Improvements
 - Removed the implementation of LPC8XX Enable/DisableDeepSleepIRQ() function.
 - Added new feature macro switch “FSL_FEATURE_HAS_NO_NONCACHEABLE_SECTION” for specific SoCs which have no noncacheable sections, that helps avoid an unnecessary complex in link file and the startup file.
 - Updated the align(x) to **attribute**(aligned(x)) to support MDK v6 armclang compiler.

[2.0.0]

- Initial version.
-

COP

[2.2.3]

- Bug Fixes
 - Fixed violations of MISRA C-2012 rule 10.3.

[2.2.2]

- Bug Fixes
- Added configuration of CWP bits in COP_Init, fixed write protection bEnableWriteProtect cannot be configured as part of cop_config_t.

[2.2.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.2.0]

- Improvements
- Updated cop_config_t member naming.
- Deleted COP_Disable API, added COP_Enable to enable/disable COP.

[2.1.0]

- Improvements
- API interface changes:
 - Renamed “COP_EnableInterrupts/COP_DisableInterrupts” to “COP_EnableInterrupt/COP_DisableInterrupt” and remove unnecessary parameter.
 - New Features
- Added APIs to enable/disable the COP COP Loss of Reference counter.

[2.0.0]

- Initial version.
-

CRC

[2.0.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

DAC

[2.0.1]

- Improvements
- Supported MC56F82xxx and MC56F84xxx.
 - Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

DMA

[2.0.0]

- Initial version.
-

EWM

[2.0.2]

- Bug Fixes
- Fixed violations of MISRA C-2012 rule 10.3.

[2.0.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

FLASH

[3.0.0]

- Initial version — Basic FTFx IP command support
-

FLEXCAN

[2.1.2]

- Bug Fixes
- Fixed the violation of MISRA-2012 rule : 10.1, 14.3, 17.7.

[2.1.1]

- Bug Fixes
- Fixed the violation of MISRA-2012 rule.
- Fixed CBT SEG2 potential overflow issue.

[2.1.0]

- Improvement
- Add bEnableTimingCalc member in flexcan_config_t structure to make users can choose to use their desired timing values or use auto calculate timing values to initialize FLEXCAN module.
- Update FLEXCAN_CalculateImprovedTimingValues/FLEXCAN_FDCalculateImprovedTimingValues APIs to improvement the bit timing calculate.
- Add FLEXCAN_CalculateImprovedTimingValuesWithCBT API.
- Move TDC config operations to FLEXCAN_SetFDTimingConfig API.
- Add FLEXCAN_SetBaudRate/FLEXCAN_SetFDBaudRate APIs to enable auto update CAN bit timing configuration base on baud rate parameter.
- Update FLEXCAN_WriteFDTxMb to make it can send both CAN FD frame and classic frame.

[2.0.2]

- Bug Fixes
- Fixed build error by adding macro isolation to all CAN FD codes.

[2.0.1]

- Bug Fixes
- Fixed build warnings.

[2.0.0]

- Initial version.
-

GPIO

[2.0.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

I2C

[2.0.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

INTC

[2.0.1]

- Improvements
- Added doxygen comments.

[2.0.0]

- Initial version.
-

MCM

[2.0.1]

- Improvements
- Supported MC56F82xxx and MC56F84xxx.

[2.0.0]

- Initial version.
-

PDB

[2.0.0]

- Initial version.
-

PIT

[2.3.1]

- Bug Fixes
- Fixed violations of MISRA C-2012 rule 10.3.

[2.3.0]

- Improvements
- Filtered Preset input to reset PIT counter.
- Support SYNC_OUT output stretch and toggle mode.
- Added PIT_SetPresetFiltConfig() to set FILT register configurations.
- Added PIT_SetSyncOutConfig() to set SYNC register configurations.

[2.2.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.2.0]

- Improvements
- Updated pit_config_t member naming.
- Removed some APIs for prescaler and clock source selection.

[2.1.0]

- Improvements
- Updated PIT clock source and PIT prescaler with more meaningful comments.
- Updated PIT_SetTimerPeriod() and PIT_GetCurrentTimerCount() with 16-bit parameter.
- Deleted mask parameter for PIT_ClearStatusFlags/PIT_EnableInterrupts/PIT_DisableInterrupts.
- Added PIT_SetTimerClockSource() API to configure clock source.
- Added PIT_EnableSlaveMode() API to configure slave mode.

[2.0.1]

- New Features
- Added PIT_SetTimerPrescaler() API to configure clock prescaler value.

[2.0.0]

- Initial version.
-

PMC

[2.1.0]

- Improvements
- Added PMC_SetVrefTrim() and PMC_SetVcapTrim() APIs to support MC56F80xxx.

[2.0.0]

- Initial version.
-

eFlexPWM

[2.2.0]

- New Features
- Supported capture PWM input filter.
- Supported different PWM deadtime count register width.
 - Bug Fixes
- Fixed wrong pwm_sm_pwm_out_t enum order issue.

[2.1.1]

- Bug Fixes
- Fixed build error when soc not support Capture A/B features.

[2.1.0]

- Improvements
- Supported MC56F80xxx.

[2.0.2]

- Bug Fixes
- Fixed clear status flags API doesn't work issue.

[2.0.1]

- Improvements
- Supported MC56F82xxx and MC56F84xxx .
 - Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

QDC**[2.1.0]**

- New Features
- Supported input filter prescaler.
- Supported the feature that the position counter to be initialized by Index Event Edge Mark.

[2.0.1]

- Improvements
- Supported MC56F84xxx.

[2.0.0]

- Initial version.
-

QSCI**[2.0.4]**

- Bug Fixes
- Fixed DMA transfer blocking issue by enabling tx idle interrupt after DMA transmission finishes, and invoke completion callback after tx idle interrupt occurs.

[2.0.3]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.2]

- Improvements
- Supported QSCI which has 13-bit integer and 3-bit fractional baud rate selection.

[2.0.1]

- Bug Fixes
- Fixed bug that when starting the non-blocking receive, the rx idle interrupt is not enabled, and when receiving is done the rx idle interrupt is not disabled.

[2.0.0]

- Initial version.
-

QTMR

[2.0.1]

- Improvements
- Supported to get TMR capture register address.
 - Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

Queued SPI

[2.1.1]

- Bug Fixes
- Fixed wrong baudrate calculation method.

[2.1.0]

- Bug Fixes
- Fixed wrong definitions of interrupt enable/disable masks.
- Fixed wrong usage of QSPI_DisableInterrupts.
- Fixed wrong type casts.
- Fixed bug for master blocking transfer of rx FIFO overflow.

[2.0.0]

- Initial version.
-

SIM

[2.1.0]

- Improvements
- Updated support for MC56F82xxx and MC56F84xxx.
 - Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

DSC_XBARA

[2.0.1]

- Bug Fixes
- Fixed violations of the MISRA C-2012 rules.

[2.0.0]

- Initial version.
-

XBARB

[2.0.0]

- Initial version.
-

Chapter 2

MC56F84789

2.1 ADC16:Combinational logic inputs Driver

`void ADC16_Init(SADC_Type *base, const adc16_config_t *psConfig)`

Initializes the ADC16 module.

Parameters

- base – ADC16 peripheral base address.
- psConfig – Pointer to configuration structure.

`void ADC16_GetDefaultConfig(adc16_config_t *psConfig)`

Gets an available pre-defined settings for the converter's configuration.

This function initializes the converter configuration structure with available settings. The default values are as follows.

```
psConfig->eReferenceVoltageSource      = kADC16_ReferenceVoltageSourceVref;
psConfig->eClockSource                  = kADC16_ClockSourceAsynchronousClock;
psConfig->bEnableAsynchronousClock      = true;
psConfig->eClockDivider                 = kADC16_ClockDivider8;
psConfig->eResolution                   = KADC16_Resolution12bit;
psConfig->eLongSampleMode               = kADC16_LongSampleDisabled;
psConfig->bEnableHighSpeed              = false;
psConfig->bEnableLowPower               = false;
psConfig->eChannelInput                 = kADC16_ModuleDisabled;
psConfig->u32GroupId                   = 0U;
psConfig->bEnableInterruptOnConversionCompleted = false;
psConfig->bEnableDMA                   = false;
psConfig->eConversionTrigger           = kADC16_SoftWareTrigger;
psConfig->eHardwareAverageMode          = kADC16_HardwareAverageDisabled;
psConfig->bEnableContinuousConversion  = false;
psConfig->psHardwareCompare            = NULL;
```

Parameters

- psConfig – Pointer to the configuration structure. See *adc16_config_t*.

`void ADC16_Deinit(SADC_Type *base)`

De-initializes the ADC16 module.

Parameters

- base – ADC16 peripheral base address

status_t ADC16_DoAutoCalibration(SADC_Type *base)

Automates the hardware calibration.

This auto calibration helps to adjust the plus/minus side gain automatically. Execute the calibration before using the converter. Note that the hardware trigger should be used during the calibration.

Parameters

- base – ADC16 peripheral base address.

Return values

- kStatus_Success – Calibration is done successfully.
- kStatus_Fail – Calibration has failed.

Returns

Execution status.

static inline void ADC16_SetOffsetValue(SADC_Type *base, int16_t i16Value)

Sets the offset value for the conversion result.

This offset value takes effect on the conversion result. If the offset value is not zero, the reading result is subtracted by it. Note, the hardware calibration fills the offset value automatically.

Parameters

- base – ADC16 peripheral base address.
- i16Value – Setting offset value.

static inline void ADC16_EnableAssistTrigger(SADC_Type *base, bool enable)

Enables assist trigger.

This ASSITRGEN register is used to help correctly generate the conversion type. When ASSITRGEN is set, the write to the ADCSC1 COCO bit will be reflected in the ADTRG register, and the operation of ADCSC1 will be delayed by 1/2 cycle. When ASSITRGEN is set, the user must ensure that no hardware trigger occurs when writing ADCSC1 COCO, so that the correct conversion type can be generated when the value of the ADTRG register changes.

Parameters

- base – ADC16 peripheral base address.
- enable – Switcher of the assist trigger feature. “true” means enabled, “false” means not enabled.

static inline void ADC16_EnableDMA(SADC_Type *base, bool enable)

Enables generating the DMA trigger when the conversion is complete.

Parameters

- base – ADC16 peripheral base address.
- enable – Switcher of the DMA feature. “true” means enabled, “false” means not enabled.

static inline void ADC16_EnableInterrupt(SADC_Type *base, uint32_t u32GroupId)

Enables the conversion interrupt.

The u32GroupId is for Group registers. For example, u32GroupId 0 is for Group A registers.

Parameters

- base – ADC16 peripheral base address.
- u32GroupId – group identification.

```
static inline void ADC16_DisableInterrupt(SADC_Type *base, uint32_t u32GroupId)
```

Disables the conversion interrupt .

The u32GroupId is for Group registers. For example,u32GroupId 0 is for Group A registers.

Parameters

- base – ADC16 peripheral base address.
- u32GroupId – group identification.

```
void ADC16_SetTriggerSource(SADC_Type *base, adc16_trigger_source_t eTriggerSource)
```

Settings ADC16 trigger mode.

Parameters

- base – ADC16 peripheral base address.
- eTriggerSource – Setting the trigger conversion mode. See `adc16_trigger_source_t`.

```
void Adc16_DoSoftwareTrigger(SADC_Type *base, uint32_t u32GroupId)
```

Turns on the ADC16 conversion .

The u32GroupId is for Group registers. For example,u32GroupId 0 is for Group A registers.

Parameters

- base – ADC16 peripheral base address.
- u32GroupId – group identification.

```
void Adc16_AbortSoftwareTrigger(SADC_Type *base, uint32_t u32GroupId)
```

Aborts the ADC16 conversion.

The u32GroupId is for Group registers. For example,u32GroupId 0 is for Group A registers.

Parameters

- base – ADC16 peripheral base address.
- u32GroupId – group identification.

```
void ADC16_SetHardwareCompareConfig(SADC_Type *base, const adc16_hardware_compare_t  
*psConfig)
```

Configures the hardware compare mode.

The hardware compare mode provides a way to process the conversion result automatically by using hardware. Only the result in the compare range is available. To compare the range, see “`adc16_hardware_compare_mode_t`” or the appropriate reference manual for more information.

Parameters

- base – ADC16 peripheral base address.
- psConfig – Pointer to the “`adc16_hardware_compare_config_t`” structure. Passing “NULL” disables the feature.

```
void ADC16_SetHardwareAverage(SADC_Type *base, adc16_hardware_average_mode_t  
eHardwareAverageMode)
```

Sets the hardware average mode.

The hardware average mode provides a way to process the conversion result automatically by using hardware. The multiple conversion results are accumulated and averaged internally making them easier to read.

Parameters

- base – ADC16 peripheral base address.

- `eHardwareAverageMode` – Setting the hardware average mode. See `adc16_hardware_average_mode_t`.

`void ADC16_ClearCalibrationCompletedFlag(SADC_Type *base)`

Clears calibration completed flag .

Parameters

- `base` – ADC16 peripheral base address.

`void ADC16_AssginChannelToGroup(SADC_Type *base, uint32_t u32GroupId,
 adc16_input_channel_t eChannel)`

Configures the conversion Group channel.

This operation triggers the conversion when in software trigger mode. When in hardware trigger mode, this API configures the channel while the external trigger source helps to trigger the conversion.

Note: that the “ `u32GroupId` “ has a detailed description. one for each conversion. The `u32GroupId` parameter indicates which group of registers are used, for example, `u32GroupId 0` is for Group A registers. At any point, only one of the `u32GroupId` is actively controlling ADC conversions. The `u32GroupId 0` is used for both software and hardware trigger modes. See the chip configuration information in the appropriate MCU reference manual for the number of SC1n registers (`u32GroupId`) specific to this device. Therefore, writing to these `u32GroupId` does not initiate a new conversion. Writing any of the `u32GroupId` registers while that specific `u32GroupId` is actively controlling a conversion aborts the current conversion.

Parameters

- `base` – ADC16 peripheral base address.
- `u32GroupId` – group identification. `u32GroupId` is for Group registers.
- `eChannel` – Setting the conversion channel . See `adc16_input_channel_t`.

`static inline uint32_t ADC16_GetGroupConversionValue(SADC_Type *base, uint32_t u32GroupId)`

Gets the group conversion value.

The `u32GroupId` is for Group registers. For example, `u32GroupId 0` is for Group A registers.

Parameters

- `base` – ADC16 peripheral base address.
- `u32GroupId` – group identification.

Returns

Conversion value.

`bool ADC16_IsGroupConversionCompleted(SADC_Type *base, uint32_t u32GroupId)`

Checks the status of group conversion.

The `u32GroupId` is for Group registers. For example, `u32GroupId 0` is for Group A registers.

Parameters

- `base` – ADC16 peripheral base address.
- `u32GroupId` – group identification.

`FSL_ADC16_DRIVER_VERSION`

ADC16 driver version.

enum _adc16_input_channel

The enumeration all of ADC16 Input channels.

Values:

enumerator kADC16__Input0Channel

AD0 is selected as input

enumerator kADC16__Input1Channel

AD1 is selected as input

enumerator kADC16__Input2Channel

AD2 is selected as input

enumerator kADC16__Input3Channel

AD3 is selected as input

enumerator kADC16__Input4Channel

AD4 is selected as input

enumerator kADC16__Input5Channel

AD5 is selected as input

enumerator kADC16__Input6Channel

AD6 is selected as input

enumerator kADC16__Input7Channel

AD7 is selected as input

enumerator kADC16__Input8Channel

AD8 is selected as input

enumerator kADC16__Input9Channel

AD9 is selected as input

enumerator kADC16__Input10Channel

AD10 is selected as input

enumerator kADC16__Input11Channel

AD11 is selected as input

enumerator kADC16__Input12Channel

AD12 is selected as input

enumerator kADC16__Input13Channel

AD13 is selected as input

enumerator kADC16__Input14Channel

AD14 is selected as input

enumerator kADC16__Input15Channel

AD15 is selected as input

enumerator kADC16__Input16Channel

AD16 is selected as input

enumerator kADC16__Input17Channel

AD17 is selected as input

enumerator kADC16__Input18Channel

AD18 is selected as input

enumerator kADC16__Input19Channel
AD19 is selected as input

enumerator kADC16__Input20Channel
AD20 is selected as input

enumerator kADC16__Input21Channel
AD21 is selected as input

enumerator kADC16__Input22Channel
AD22 is selected as input

enumerator kADC16__Input23Channel
AD23 is selected as input

enumerator kADC16__Reserved1
Reserved

enumerator kADC16__Reserved2
Reserved

enumerator kADC16__TempSensor
Temp Sensor (single-ended) is selected as input

enumerator kADC16__ABandgap
ABandgap (single-ended) is selected as input

enumerator kADC16__Reserved3
Reserved

enumerator kADC16__VREFSH
High reference voltage is selected as input

enumerator kADC16__VREFSL
Low reference voltage is selected as input

enumerator kADC16__ModuleDisabled
Module is disabled

enum _adc16_clock_divider

The enumeration ADC16 clock divider.

Values:

enumerator kADC16__ClockDivider1
For divider 1 from the input clock to the module.

enumerator kADC16__ClockDivider2
For divider 2 from the input clock to the module.

enumerator kADC16__ClockDivider4
For divider 4 from the input clock to the module.

enumerator kADC16__ClockDivider8
For divider 8 from the input clock to the module.

enum _adc16_resolution

The enumeration ADC16 Conversion resolution mode.

Values:

enumerator kADC16__Resolution8bit
single-ended 8-bit conversion

enumerator kADC16__Resolution12bit
single-ended 12-bit conversion

enumerator kADC16__Resolution10bit
single-ended 10-bit conversion

enumerator kADC16__Resolution16bit
single-ended 16-bit conversion

enum __adc16__clock__source

The enumeration of ADC16 clock source.

Values:

enumerator kADC16__ClockSourceAlt0
Selection Bus clock.

enumerator kADC16__ClockSourceAlt1
Selection (Bus clock)/2.

enumerator kADC16__ClockSourceAlt2
Selection Alternate clock (ALTCLK).

enumerator kADC16__ClockSourceAlt3
Selection Asynchronous clock (ADACK).

enumerator kADC16__ClockSourceAsynchronousClock
Using internal asynchronous clock.

enum __adc16__sample__mode

The enumeration of ADC16 sample mode.

Values:

enumerator kADC16__SampleCycle24
20 extra ADCK cycles, 24 ADCK cycles total.

enumerator kADC16__SampleCycle16
12 extra ADCK cycles, 16 ADCK cycles total.

enumerator kADC16__SampleCycle10
6 extra ADCK cycles, 10 ADCK cycles total.

enumerator kADC16__SampleCycle6
2 extra ADCK cycles, 6 ADCK cycles total.

enumerator kADC16__SampleDisabled
Disable the sample feature.

enum __adc16__compare__mode

The enumeration ADC16 Automatic compare mode.

Values:

enumerator kADC16__LessThanThreshold
Less than threshold

enumerator kADC16__GreaterThanOrEqualThreshold
Greater than or equal to threshold

enumerator kADC16__TriggerOutsideCompareRangeModel
Compare true if the result is less than CV1 Or the result is greater than CV2.

enumerator kADC16__TriggerInsideCompareRangeMode1

Compare true if the result is less than CV1 And the result is greater than CV2.

enumerator kADC16__TriggerInsideCompareRangeMode2

Compare true if the result is greater than or equal to CV1 And the result is less than or equal to CV2.

enumerator kADC16__TriggerOutsideCompareRangeMode2

Compare true if the result is greater than or equal to CV1 Or the result is less than or equal to CV2.

enum _adc16_reference_voltage_source

The enumeration ADC16 Reference voltage source.

Values:

enumerator kADC16__ReferenceVoltageSourceVref

For external pins pair of VrefH and VrefL.

enumerator kADC16__ReferenceVoltageSourceValt

For alternate reference pair of ValtH and ValtL.

enumerator kADC16__ReferenceVoltageSourceBandgap

For bandgap voltage from V BGH and V BGL.

enum _adc16_hardware_average_mode

The enumeration ADC16's Hardware average mode.

Values:

enumerator kADC16__HardwareAverageCount4

For hardware average with 4 samples.

enumerator kADC16__HardwareAverageCount8

For hardware average with 8 samples.

enumerator kADC16__HardwareAverageCount16

For hardware average with 16 samples.

enumerator kADC16__HardwareAverageCount32

For hardware average with 32 samples.

enumerator kADC16__HardwareAverageDisabled

Disable the hardware average feature.

enum _adc16_trigger_source

The enumeration ADC16's conversion trigger source.

Values:

enumerator kADC16__SoftWareTrigger

Software trigger Conversion

enumerator kADC16__HardWareTrigger

Hardware trigger Conversion

typedef enum _adc16_input_channel adc16_input_channel_t

The enumeration all of ADC16 Input channels.

typedef enum _adc16_clock_divider adc16_clock_divider_t

The enumeration ADC16 clock divider.

typedef enum _adc16_resolution adc16_resolution_t

The enumeration ADC16 Conversion resolution mode.

typedef enum *_adc16_clock_source* adc16_clock_source_t

The enumeration of ADC16 clock source.

typedef enum *_adc16_sample_mode* adc16_sample_mode_t

The enumeration of ADC16 sample mode.

typedef enum *_adc16_compare_mode* adc16_compare_mode

The enumeration ADC16 Automatic compare mode.

typedef enum *_adc16_reference_voltage_source* adc16_reference_voltage_source_t

The enumeration ADC16 Reference voltage source.

typedef enum *_adc16_hardware_average_mode* adc16_hardware_average_mode_t

The enumeration ADC16's Hardware average mode.

typedef enum *_adc16_trigger_source* adc16_trigger_source_t

The enumeration ADC16's conversion trigger source.

typedef struct *_adc16_hardware_compare* adc16_hardware_compare_t

The structure for configuration the ADC16's hardware compare setting.

typedef struct *_adc16_config* adc16_config_t

The structure for configuration the ADC16's setting.

struct *_adc16_hardware_compare*

#include <fsl_adc.h> The structure for configuration the ADC16's hardware compare setting.

Public Members

adc16_compare_mode eCompareMode

Select the compare mode. See *adc16_compare_mode*.

int16_t i16Value1

Setting i16Value1 for hardware compare mode.

int16_t i16Value2

Setting i16Value2 for hardware compare mode.

struct *_adc16_config*

#include <fsl_adc.h> The structure for configuration the ADC16's setting.

Public Members

adc16_reference_voltage_source_t eReferenceVoltageSource

Select the reference voltage source.

adc16_clock_source_t eClockSource

Select the input clock source to converter.

bool bEnableAsynchronousClock

Enable the asynchronous clock output.

adc16_clock_divider_t eClockDivider

Select the divider of input clock source.

adc16_resolution_t eResolution

Select the sample resolution mode.

adc16_sample_mode_t eSampleMode

Select the sample mode.

`bool bEnableHighSpeed`
Enable the high-speed mode.

`bool bEnableLowPower`
Enable low power.

`adc16_input_channel_t eChannelInput`
Select input channel

`uint32_t u32GroupId`
Set group identification, `u32GroupId` is for Group registers.

`bool bEnableInterruptOnConversionCompleted`
Generate an interrupt request once the conversion is completed.

`adc16_trigger_source_t eConversionTrigger`
Select Conversion Trigger mode.

`bool bEnableDMA`
Enable adc DMA function

`bool bEnableContinuousConversion`
Enable continuous conversion mode.

`adc16_hardware_average_mode_t eHardwareAverageMode`
Set hardware average mode.

`adc16_hardware_compare_t *psHardwareCompare`
Set hardware compare mode

2.2 The Driver Change Log

2.3 ADC16 Peripheral and Driver Overview

2.4 AOI:Combinational logic inputs Driver

`void AOI_Init(AOI_Type *base)`
Initializes an AOI instance for operation.
Reserved function, enable clock preparation.

Parameters

- `base` – AOI peripheral address.

`void AOI_Deinit(AOI_Type *base)`
Deinitializes an AOI instance for operation.
Reserved function, disable clock preparation.

Parameters

- `base` – AOI peripheral address.

`void AOI_GetEventLogicConfig(AOI_Type *base, aoi_event_t eEvent, aoi_event_config_t *psEventconfig)`

Gets the Boolean evaluation associated.
This function returns the Boolean evaluation associated.
Example:

```

aoi_event_config_t demoEventLogicStruct;

AOI_GetEventLogicConfig(AOI, kAOI_Event0, &demoEventLogicStruct);

```

Parameters

- base – AOI peripheral address.
- eEvent – Index of the event which will be set of type `aoi_event_t`.
- psEventconfig – Selected input configuration.

```

void AOI_SetEventLogicConfig(AOI_Type *base, aoi_event_t eEvent, const aoi_event_config_t
                             *psEventconfig)

```

Configures an AOI event.

This function configures an AOI event according to the `aoiEventConfig` structure. This function configures all inputs (A, B, C, and D) of all product terms (0, 1, 2, and 3) of a desired event.

Example:

```

aoi_event_config_t demoEventLogicStruct;

demoEventLogicStruct.PT0AC = kAOI_InvInputSignal;
demoEventLogicStruct.PT0BC = kAOI_InputSignal;
demoEventLogicStruct.PT0CC = kAOI_LogicOne;
demoEventLogicStruct.PT0DC = kAOI_LogicOne;

demoEventLogicStruct.PT1AC = kAOI_LogicZero;
demoEventLogicStruct.PT1BC = kAOI_LogicOne;
demoEventLogicStruct.PT1CC = kAOI_LogicOne;
demoEventLogicStruct.PT1DC = kAOI_LogicOne;

demoEventLogicStruct.PT2AC = kAOI_LogicZero;
demoEventLogicStruct.PT2BC = kAOI_LogicOne;
demoEventLogicStruct.PT2CC = kAOI_LogicOne;
demoEventLogicStruct.PT2DC = kAOI_LogicOne;

demoEventLogicStruct.PT3AC = kAOI_LogicZero;
demoEventLogicStruct.PT3BC = kAOI_LogicOne;
demoEventLogicStruct.PT3CC = kAOI_LogicOne;
demoEventLogicStruct.PT3DC = kAOI_LogicOne;

AOI_SetEventLogicConfig(AOI, kAOI_Event0, &demoEventLogicStruct);

```

Parameters

- base – AOI peripheral address.
- eEvent – Event which will be configured of type `aoi_event_t`.
- psEventconfig – Pointer to type `aoi_event_config_t` structure. The user is responsible for filling out the members of this structure and passing the pointer to this function.

FSL_AOI_DRIVER_VERSION

Version 2.0.0.

enum _aoi_input_config

AOI input configurations.

The selection item represents the Boolean evaluations.

Values:

enumerator kAOI_LogicZero
Forces the input to logical zero.

enumerator kAOI_InputSignal
Passes the input signal.

enumerator kAOI_InvInputSignal
Inverts the input signal.

enumerator kAOI_LogicOne
Forces the input to logical one.

enum _aoi_event

AOI event indexes, where an event is the collection of the four product terms (0, 1, 2, and 3) and the four signal inputs (A, B, C, and D).

Values:

enumerator kAOI_Event0
Event 0 index

enumerator kAOI_Event1
Event 1 index

enumerator kAOI_Event2
Event 2 index

enumerator kAOI_Event3
Event 3 index

enumerator KAOI_EventMax
Max event.

typedef enum _aoi_input_config aoi_input_config_t
AOI input configurations.

The selection item represents the Boolean evaluations.

typedef enum _aoi_event aoi_event_t

AOI event indexes, where an event is the collection of the four product terms (0, 1, 2, and 3) and the four signal inputs (A, B, C, and D).

typedef struct _aoi_event_config aoi_event_config_t
AOI event configuration structure.

Defines structure _aoi_event_config and use the AOI_SetEventLogicConfig() function to make whole event configuration.

struct _aoi_event_config

#include <fsl_aoi.h> AOI event configuration structure.

Defines structure _aoi_event_config and use the AOI_SetEventLogicConfig() function to make whole event configuration.

Public Members

aoi_input_config_t PT0AC
Product term 0 input A

aoi_input_config_t PT0BC
Product term 0 input B

aoi_input_config_t PT0CC
Product term 0 input C

aoi_input_config_t PT0DC
Product term 0 input D

aoi_input_config_t PT1AC
Product term 1 input A

aoi_input_config_t PT1BC
Product term 1 input B

aoi_input_config_t PT1CC
Product term 1 input C

aoi_input_config_t PT1DC
Product term 1 input D

aoi_input_config_t PT2AC
Product term 2 input A

aoi_input_config_t PT2BC
Product term 2 input B

aoi_input_config_t PT2CC
Product term 2 input C

aoi_input_config_t PT2DC
Product term 2 input D

aoi_input_config_t PT3AC
Product term 3 input A

aoi_input_config_t PT3BC
Product term 3 input B

aoi_input_config_t PT3CC
Product term 3 input C

aoi_input_config_t PT3DC
Product term 3 input D

2.5 The Driver Change Log

2.6 AOI Peripheral and Driver Overview

2.7 CADC: 12-bit Cyclic Analog-to-Digital Converter Driver

void CADC_Init(ADC_Type *base, const *cadc_config_t* *psConfig)

Initializes the CADC module, such as scan mode, DMA trigger source, interrupt mask and so on.

This function is to make the initialization for using CADC module. The operations are:

- Enable the clock for CADC.
- Set power up delay and Idle work mode.
- Set DMA trigger source.

- Enable the interrupts(Including High/Low limit interrupt, zero crossing interrupt interrupt, end of scan interrupt and each sample slot's scan interrupt).
- Set scan mode.
- Set disabled sample slot for the scan.
- Set scan control options.
- Set selected channels' mode.
- Set gain for each channel.
- Config conterA and converterB.

Note: The high limit value, low limit value, offset value and zerocrossing mode of each sample slot will not be configured in this function, to set those options, the APIs in “Sample Slot Control Interfaces” function group can be used.

Parameters

- base – ADC peripheral base address.
- psConfig – Pointer to configuration structure. See `adc_config_t`.

`void ADC_GetDefaultConfig(adc_config_t *psConfig)`

Gets an available pre-defined options(such as scan mode, DMA trigger source, interrupt mask and so on) for module's configuration.

This function initializes the module's configuration structure with an available settings. The default value are:

```
psConfig->eDMATriggerSource = kADC_DMATrigSrcEndofScan;
psConfig->eIdleWorkMode = kADC_IdleKeepNormal;
psConfig->u16PowerUpDelay = 26U;
psConfig->u32EnabledInterruptMask = 0U;
psConfig->eScanMode = kADC_ScanModeTriggeredParallelSimultaneous;
psConfig->uDisabledSampleSlot.u32SampleDisVal = 0xFF0F0UL;
psConfig->uScanControl.u32ScanCtrlVal = 0x0UL;
psConfig->eChannelGain[x] = kADC_SignalGainX1;
psConfig->sampleSlotScanInterruptEnableMask = kADC_NonSampleSlotMask;
For the default setting of converter, please see ADC_GetConverterDefaultConfig().
```

Parameters

- psConfig – Pointer to configuration structure. See `adc_config_t`.

`void ADC_Deinit(ADC_Type *base)`

De-initializes the ADC module, including power down both converter and disable the clock(Optional).

This function is to make the de-initialization for using ADC module. The operations are:

- Power down both converter.
- Disable the clock for ADC.

Parameters

- base – ADC peripheral base address.

`static inline void ADC_SetScanMode(ADC_Type *base, adc_scan_mode_t eScanMode)`

Sets the scan mode(such as Sequential scan mode, Simultaneous parallel scan mode, Independent parallel scan

mode) of dual converters.

Parameters

- base – ADC peripheral base address.
- eScanMode – Dual converters' scan mode, please see `cadc_scan_mode_t` for details.

static inline void `CADC_SetScanControl(ADC_Type *base, cadc_scan_control_t uScanControl)`

The function provides the ability to pause and await new sync in the conversion sequence.

Parameters

- base – ADC peripheral base address.
- uScanControl – The scan control value, please refer to `cadc_scan_control_t` for details.

void `CADC_SetChannelMode(ADC_Type *base, cadc_channel_mode_t eChannelMode)`

Sets mode for the specific channel(Each channel can be set as single-end, fully differential and unipolar differential(Optional) mode).

Parameters

- base – ADC peripheral base address.
- eChannelMode – The channel mode to be set, please refer to `cadc_channel_mode_t` for details.

void `CADC_SetChannelGain(ADC_Type *base, cadc_channel_number_t eChannelNumber, cadc_channel_gain_t eChannelGain)`

Sets the gain(Supports X1, X2, X4) of selected channel.

Parameters

- base – ADC peripheral base address.
- eChannelNumber – The number of channel, please refer to `cadc_channel_number_t`.
- eChannelGain – The gain amplification, please refer to `cadc_channel_gain_t` for details.

void `CADC_GetSampleSlotDefaultConfig(cadc_sample_slot_config_t *psConfig)`

Gets sample slot default configuration including zero crossing mode, high limit value, low limit value and offset value.

```
psConfig->eZeroCrossingMode = kCADC_ZeroCrossingDisabled;
psConfig->u16HighLimitValue = 0x7FF8U;
psConfig->u16LowLimitValue = 0x0U;
psConfig->u16OffsetValue = 0x0U;
```

Parameters

- psConfig – Pointer to configuration structure. See `cadc_sample_slot_config_t`.

void `CADC_SetSampleSlotConfig(ADC_Type *base, cadc_sample_slot_index_t eSampleIndex, const cadc_sample_slot_config_t *psConfig)`

Configures the options(including zero crossing mode, high limit value, low limit value and offset value) for sample slot.

Note: This function can be used to set high limit value, low limit value, offset value and zerocrossing mode of the sample slot.

Parameters

- base – ADC peripheral base address.
- eSampleIndex – Index of sample slot in conversion sequence. Please refer to `cadc_sample_slot_index_t`.
- psConfig – Pointer to configuration structure. See `cadc_sample_slot_config_t`.

```
void CADC_SetSampleSlotZeroCrossingMode(ADC_Type *base, cadc_sample_slot_index_t
                                         eSampleIndex,
                                         cadc_sample_slot_zero_crossing_mode_t
                                         eZeroCrossingMode)
```

Sets zero-crossing mode for the selected sample slot.

Parameters

- base – ADC peripheral base address.
- eSampleIndex – The index of sample slot. Please refer to `cadc_sample_slot_index_t` for details.
- eZeroCrossingMode – Zero crossing mode, please refer to `cadc_sample_slot_zero_crossing_mode_t` for details.

```
void CADC_RouteChannelToSampleSlot(ADC_Type *base, cadc_sample_slot_index_t
                                     eSampleIndex, cadc_channel_number_t
                                     eChannelNumber)
```

Routes the channel to the sample slot.

Parameters

- base – ADC peripheral base address.
- eSampleIndex – The index of sample slot, please refer to `cadc_sample_slot_index_t` for details.
- eChannelNumber – Sample channel number, please refer to `cadc_channel_number_t` for details.

```
static inline void CADC_SetSampleSlotLowLimitValue(ADC_Type *base,
                                                    cadc_sample_slot_index_t eSampleIndex,
                                                    uint16_t u16LowLimitValue)
```

Sets the low limit value(-32768 ~ 32767 with lower three bits of fixed value 0) for the specific sample slot.

Parameters

- base – ADC peripheral base address.
- eSampleIndex – The index of sample slot. Please refer to `cadc_sample_slot_index_t` for details.
- u16LowLimitValue – Low limit value(-32768 ~ 32767 with lower three bits of fixed value 0). Original value formation as hardware register, with 3-bits left shifted.

```
static inline void CADC_SetSampleSlotHighLimitValue(ADC_Type *base,
                                                    cadc_sample_slot_index_t eSampleIndex,
                                                    uint16_t u16HighLimitValue)
```

Sets the high limit value(-32768 ~ 32767 with lower three bits of fixed value 0) for the specific sample slot.

Parameters

- base – ADC peripheral base address.

- `eSampleIndex` – The index of sample slot. Please refer to `cadc_sample_slot_index_t` for details.
- `u16HighLimitValue` – High limit value(-32768 ~ 32767 with lower three bits of fixed value 0). Original value formation as hardware register, with 3-bits left shifted.

```
static inline void CADC_SetSampleSlotOffsetValue(ADC_Type *base, cadc_sample_slot_index_t
                                                eSampleIndex, uint16_t u16OffsetValue)
```

Sets the offset value(-32768 ~ 32767 with lower three bits of fixed value 0) for the specific sample slot.

Parameters

- `base` – CADC peripheral base address.
- `eSampleIndex` – The index of sample slot. Please refer to `cadc_sample_slot_index_t` for details.
- `u16OffsetValue` – Offset value(-32768 ~ 32767 with lower three bits of fixed value 0). Original value formation as hardware register, with 3-bits left shifted.

```
static inline uint16_t CADC_GetSampleSlotResultValue(ADC_Type *base,
                                                    cadc_sample_slot_index_t eSampleIndex)
```

Gets the sample result value.

This function is to get the sample result value. The returned value keeps its original formation just like in hardware result register. It includes the sign bit as the MSB and 3-bit left shifted value.

Parameters

- `base` – CADC peripheral base address.
- `eSampleIndex` – Index of sample slot. For the counts of sample slots, please refer to `cadc_sample_slot_index_t` for details.

Returns

Sample's conversion value.

```
void CADC_GetConverterDefaultConfig(cadc_converter_config_t *psConfig)
```

Gets available pre-defined settings(such as clock divisor, reference voltage source, and so on) for each converter's configuration.

This function initializes each converter's configuration structure with an available settings. The default value are:

```
psConfig->u16ClockDivisor = 4U; (ADC clock = Peripheral clock / 5)
psConfig->eSpeedMode = kCADC_SpeedMode0; (Chip specific)
psConfig->eHighReferenceVoltageSource = kCADC_ReferenceVoltageVrefPad;
psConfig->eLowReferenceVoltageSource = kCADC_ReferenceVoltageVrefPad;
psConfig->u16SampleWindowCount = 0U; (Chip specific)
psConfig->bEnableDMA = false;
psConfig->bPowerUp = false;
psConfig->bScanInitBySync = true;
```

Parameters

- `psConfig` – Pointer to configuration structure. See `cadc_converter_config_t`.

```
void CADC_SetConverterConfig(ADC_Type *base, cadc_converter_id_t eConverterId, const
                             cadc_converter_config_t *psConfig)
```

Configures the options(such as clock divisor, reference voltage source, and so on) for the converter.

This function can be used to configure the converter. The operations are:

- Set clock divisor;
- Set reference voltage source
- Enable/Disable DMA
- Power-up/power-down converter

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter Id. See `adc_converter_id_t`.
- psConfig – Pointer to configuration structure. See `adc_converter_config_t`.

```
static inline void ADC_EnableConverter(ADC_Type *base, adc_converter_id_t eConverterId,
                                     bool bEnable)
```

Changes the converter to stop mode or normal mode.

The conversion should only be launched after the converter is in normal mode. When in stop mode, the current scan is stopped and no further scans can start. All the software trigger and hardware trigger are ignored.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter Id. See `adc_converter_id_t`.
- bEnable – Used to change the operation mode.
 - **true** Changed to normal mode.
 - **false** Changed to stop mode

```
static inline void ADC_EnableConverterSyncInput(ADC_Type *base, adc_converter_id_t
                                              eConverterId, bool bEnable)
```

Enables/Disables the external sync input pulse to initiate a scan.

Note: When in “Once” scan mode, this gate would be off automatically after an available sync is received. User needs to enable the input again manually if another sync signal is wanted.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter Id. See `adc_converter_id_t`.
- bEnable – Enable the feature or not.
 - **true** Used a SYNC input pulse or START command to initiate a scan.
 - **false** Only use the START command to initiate a scan.

```
static inline void ADC_DoSoftwareTriggerConverter(ADC_Type *base, adc_converter_id_t
                                                eConverterId)
```

Uses software trigger to start a conversion sequence.

This function is to do the software trigger to the converter. The software trigger can be used to start a conversion sequence.

Parameters

- base – ADC peripheral base address.

- `eConverterId` – The ID of the converter to be started. See `cadc_converter_id_t`.

```
static inline void CADC_SetConverterClockDivisor(ADC_Type *base, cadc_converter_id_t
                                                eConverterId, uint16_t u16ClockDivisor)
```

Sets clock divisor(Range from 0 to 63) for converterA and conveter B.

Parameters

- `base` – CADC peripheral base address.
- `eConverterId` – The converter Id. See `cadc_converter_id_t`.
- `u16ClockDivisor` – Converter's clock divisor for the clock source. Available setting range is 0-63.
 - When the `clockDivisor` is 0, the divisor is 2.
 - For all other `clockDivisor` values, the divisor is 1 more than the decimal value of `clockDivisor`: `clockDivisor + 1`

```
void CADC_SetConverterReferenceVoltageSource(ADC_Type *base, cadc_converter_id_t
                                              eConverterId, cadc_reference_voltage_source_t
                                              eHighReferenceVoltage,
                                              cadc_reference_voltage_source_t
                                              eLowReferenceVoltage)
```

Sets converter's reference voltage source(Including high reference voltage source and low reference voltage source).

Parameters

- `base` – CADC peripheral base address.
- `eConverterId` – The converter Id. See `cadc_converter_id_t`.
- `eHighReferenceVoltage` – High voltage reference source, please refer to `cadc_reference_voltage_source_t`.
- `eLowReferenceVoltage` – Low voltage reference source, please refer to `cadc_reference_voltage_source_t`.

```
void CADC_EnableConverterPower(ADC_Type *base, cadc_converter_id_t eConverterId, bool
                               bEnable)
```

Powers up/down the specific converter.

This function is to enable the power for the converter. The converter should be powered up before the conversion. Once this API is called to power up the converter, the converter would be powered on after a few moment (so-called power up delay, the function `CADC_SetPowerUpDelay()` can be used to set the power up delay), so that the power would be stable.

Parameters

- `base` – CADC peripheral base address.
- `eConverterId` – The converter to be powered. See `cadc_converter_id_t`.
- `bEnable` – Powers up/down the converter.
 - **true** Power up the specific converter.
 - **false** Power down the specific converter.

```
static inline void CADC_EnableConverterDMA(ADC_Type *base, cadc_converter_id_t
                                          eConverterId, bool bEnable)
```

Enables/Disables the converter's DMA feature.

Parameters

- base – CADC peripheral base address.
- eConverterId – The converter id. See *cadc_converter_id_t*.
- bEnable – Enables/Disables the DMA.
 - **true** Enable the converter's DMA.
 - **false** Disable the converter's DMA.

```
void CADC_SetConverterMuxAuxConfig(ADC_Type *base, cadc_converter_id_t eConverterId,
                                   const cadc_exp_mux_aux_config_t *psMuxAuxConfig)
```

Configures selected converter's expansion mux and aux settings.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.
- psMuxAuxConfig – Pointer to *cadc_exp_mux_aux_config_t* structure.

```
static inline void CADC_ResetConverterExpMuxScan(ADC_Type *base, cadc_converter_id_t
                                                  eConverterId)
```

Resets selected converter's expansion mux scan.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.

```
static inline void CADC_SetConverterExpansionMuxOperateMode(ADC_Type *base,
                                                            cadc_converter_id_t
                                                            eConverterId,
                                                            cadc_expansion_mux_operate_mode_t
                                                            eOperateMode)
```

Sets selected converter's expansion mux operate mode.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.
- eOperateMode – Used to set expansion mux operate mode.

```
static inline void CADC_SetConverterAuxiliaryControl(ADC_Type *base, cadc_converter_id_t
                                                      eConverterId, uint16_t u16AuxControl)
```

Sets selected converter's auxiliary control set.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.
- u16AuxControl – The mask of auxiliary control, should be the OR'ed value of *cadc_auxiliary_control_t*.

```
static inline void CADC_SetConverterMuxChannels(ADC_Type *base, cadc_converter_id_t
                                              eConverterId, uint32_t
                                              u32MuxChannelMask)
```

Sets selected converter's mux channels.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.
- u32MuxChannelMask – The mask of mux selection of all mux slots, should be the OR'ed value of *cadc_expansion_mux_selection_t*.

```
static inline void CADC_SetExpansionMuxAuxDisabledSlot(ADC_Type *base, cadc_converter_id_t
                                                       eConverterId,
                                                       cadc_expansion_disabled_mux_slot_t
                                                       eDisabledMuxSlot)
```

Set selected converter's mux and aux disabled slot.

Parameters

- base – ADC peripheral base address.
- eConverterId – The converter id, see *cadc_converter_id_t*.
- eDisabledMuxSlot – The mux slot to disabled, please refer to *cadc_expansion_disabled_mux_slot_t*.

```
static inline void CADC_SetPowerUpDelay(ADC_Type *base, uint16_t u16PowerUpDelay)
```

Sets power up delay(The number of ADC clocks to power up the converters before allowing a scan to start).

Parameters

- base – CADC peripheral base address.
- u16PowerUpDelay – The number of ADC clocks to power up an ADC converter. Ranges from 0 to 63.

```
static inline void CADC_EnableAutoPowerDownMode(ADC_Type *base, bool bEnable)
```

Enables/Disables auto-powerdown converters when the module is not in use for a scan.

Parameters

- base – CADC peripheral base address.
- bEnable – Enable/Disable auto-powerdown mode.
 - **true** Enable auto-powerdown mode, so when the module is not in use, it will auto-powerdown.
 - **false** Disable auto-powerdown mode, so when the module is not in use, the power will still on.

```
static inline void CADC_SetDMATriggerSource(ADC_Type *base, cadc_dma_trigger_source_t
                                             eDMATriggerSource)
```

Sets DMA trigger source(available selections are “End of scan” and “Sample Ready”).

Parameters

- base – CADC peripheral base address.
- eDMATriggerSource – DMA trigger source. Please refer to *cadc_dma_trigger_source_t* for details.

static inline void CADC_EnableInterrupts(ADC_Type *base, uint32_t u32Mask)

Enables the interrupts(such as high/low limit interrupts, end of scan interrupts, and so on).

Parameters

- base – CADC peripheral base address.
- u32Mask – Mask value for converters interrupt events. Should be the OR'ed value of _cadc_interrupt_enable.

static inline void CADC_DisableInterrupts(ADC_Type *base, uint32_t u32Mask)

Disables the interrupts(such as high/low limit interrupts, end of scan interrupts, and so on).

Parameters

- base – CADC peripheral base address.
- u32Mask – Mask value for converts interrupt events. Should be the OR'ed value of _cadc_interrupt_enable.

static inline uint16_t CADC_GetMiscStatusFlags(ADC_Type *base)

Gets Miscellaneous status flags, such as end of scan status flag, high/low limit interrupt flags and so on.

Note: This API will return the current status of the ADC module, including high limit interrupt status, low limit status flag, zero crossing interrupt status, End of scan interrupt status, conversion in progress status. But some status flags are not included in this function. To get sample slot ready status flag, please invoking CADC_GetSampleSlotReadyStatusFlags(), to get sample slot limit violations status please invoking CADC_ClearSampleSlotLowLimitStatusFlags() and CADC_GetSampleSlotHighLimitStatusFlags(), to get zerocrossing status please invoking CADC_GetSampleSlotZeroCrossingStatusFlags(). To get converters' power status please invoke CADC_GetPowerStatusFlag().

Parameters

- base – CADC peripheral base address.

Returns

Mask value for the event flags. See _cadc_misc_status_flags.

static inline void CADC_ClearMiscStatusFlags(ADC_Type *base, uint16_t u16Flags)

Clears Miscellaneous status flags(Only for “end of scan” status flags).

Note: Only kCADC_ConverterAEndOfScanFlag and kCADC_ConverterBEndOfScanFlag can be cleared. And sample slot related status flags can not be cleared in this function. To clear the status flags of limit violations, please invoking CADC_ClearSampleSlotLowLimitStatusFlags() and CADC_ClearSampleSlotHighLimitStatusFlags(), to clear the status flags of zero crossing mode, please invoking CADC_ClearSampleSlotZeroCrossingStatusFlags().

Parameters

- base – CADC peripheral base address.
- u16Flags – Mask value for the event flags to be cleared. See _cadc_misc_status_flags. Only the enumeration kCADC_ConverterAEndOfScanFlag and kCADC_ConverterBEndOfScanFlag are useful.

```
static inline uint32_t ADC_GetSampleSlotReadyStatusFlags(ADC_Type *base)
```

Gets sample slots ready status flag, those status flags are cleared by reading the corresponding sample slots' result.

Parameters

- base – ADC peripheral base address.

```
static inline uint32_t ADC_GetSampleSlotLowLimitStatusFlags(ADC_Type *base)
```

Gets sample slot low limit status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.

Returns

The value of all sample slots' low limit status. Each bit represents one sample slot.

```
static inline void ADC_ClearSampleSlotLowLimitStatusFlags(ADC_Type *base, uint32_t  
                                                         u32SampleMask)
```

Clears sample slot's low limit status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.
- u32SampleMask – Mask value of sample slots. This parameter should be the OR'ed value of `adc_sample_slot_mask_t`.

```
static inline uint32_t ADC_GetSampleSlotHighLimitStatusFlags(ADC_Type *base)
```

Gets sample slot high limit status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.

Returns

The value of all sample slots' high limit status. Each bit represents each sample slot.

```
static inline void ADC_ClearSampleSlotHighLimitStatusFlags(ADC_Type *base, uint32_t  
                                                         u32SampleMask)
```

Clears sample slot's high limit status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.
- u32SampleMask – Mask value of sample slots. This parameter should be the OR'ed value of `adc_sample_slot_mask_t`.

```
static inline uint32_t ADC_GetSampleSlotZeroCrossingStatusFlags(ADC_Type *base)
```

Gets sample slot zero crossing status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.

Returns

The value of all sample slots' zero crossing status. Each bit represents each sample slot.

```
static inline void ADC_ClearSampleSlotZeroCrossingStatusFlags(ADC_Type *base, uint32_t  
                                                            u32SampleMask)
```

Clears sample slot's zero crossing status flags(Each bit represents one sample slot).

Parameters

- base – ADC peripheral base address.
- u32SampleMask – Mask value of sample slots. This parameter should be the OR'ed value of `cadc_sample_slot_mask_t`.

static inline uint16_t ADC_GetPowerStatusFlags(ADC_Type *base)

Gets converters power status(Those power status can not be cleared).

Parameters

- base – ADC peripheral base address.

Returns

The mask value of the converters' power status flag, see `_cadc_converter_power_status_flags`.

static inline uint16_t ADC_GetConverterExpMuxChannelScanCompStatusFlags(ADC_Type *base)

Gets converter's expansion mux channel scan complete status flags.

Parameters

- base – ADC peripheral base address.

Returns

uint16_t The mask value of converters' expansion mux channel scan status flags, see `_cadc_expansion_mux_status_flags`.

static inline void ADC_ClearConverterExpMuxChannelScanCompStatusFlags(ADC_Type *base,
uint16_t
u16FlagMask)

Clears converter's expansion mux channel scan complete status flags.

Parameters

- base – ADC peripheral base address.
- u16FlagMask – The mask value of `_cadc_expansion_mux_status_flags`.

FSL_CADC_DRIVER_VERSION

CADC driver version.

enum _cadc_misc_status_flags

CADC miscellaneous status flags used to tell peripheral's miscellaneous status, such as zero-crossing, end of scan flags.

Values:

enumerator kCADC_ZeroCrossingInterruptFlag

Zero crossing encountered. IRQ pending if enabled Zero Crossing Interrupt.

enumerator kCADC_HighLimitInterruptFlag

High limit exceeded flag. IRQ pending if enabled high limit interrupt.

enumerator kCADC_LowLimitInterruptFlag

Low limit exceeded flag. IRQ pending if enabled low limit interrupt.

enumerator kCADC_ConverterAInProgressFlag

Conversion in progress, converter A.

enumerator kCADC_ConverterBInProgressFlag

Conversion in progress, converter B.

enumerator kCADC_ConverterAEndOfScanFlag

End of scan, converter A.

enumerator kCADC_ConverterBEndOfScanFlag

End of scan, converter B.

enumerator kCADC_StatusAllFlags

enum _cadc_converter_power_status_flags

The enumeration of converter power status.

Values:

enumerator kCADC_ConverterAPowerDownFlag

The converterA is powered down.

enumerator kCADC_ConverterBPowerDownFlag

The converterB is powered down.

enum _cadc_expansion_mux_status_flags

The enumeration of expansion mux channel scan complete interrupt request status flag.

Values:

enumerator kCADC_ANA4ExpMuxAuxScanCompInterruptFlag

ANA4 Expansion MUX Channel Scan Complete Interrupt flag.

enumerator kCADC_ANB4ExpMuxAuxScanCompInterruptFlag

ANB4 Expansion MUX Channel Scan Complete Interrupt flag.

enum _cadc_interrupt_enable

CADC Interrupts enumeration.

Values:

enumerator kCADC_Sample0ScanInterruptEnable

If sample0 is converted, generate the scan interrupt.

enumerator kCADC_Sample1ScanInterruptEnable

If sample1 is converted, generate the scan interrupt.

enumerator kCADC_Sample2ScanInterruptEnable

If sample2 is converted, generate the scan interrupt.

enumerator kCADC_Sample3ScanInterruptEnable

If sample3 is converted, generate the scan interrupt.

enumerator kCADC_Sample4ScanInterruptEnable

If sample4 is converted, generate the scan interrupt.

enumerator kCADC_Sample5ScanInterruptEnable

If sample5 is converted, generate the scan interrupt.

enumerator kCADC_Sample6ScanInterruptEnable

If sample6 is converted, generate the scan interrupt.

enumerator kCADC_Sample7ScanInterruptEnable

If sample7 is converted, generate the scan interrupt.

enumerator kCADC_Sample8ScanInterruptEnable

If sample8 is converted, generate the scan interrupt.

enumerator kCADC_Sample9ScanInterruptEnable

If sample9 is converted, generate the scan interrupt.

enumerator kCADC_Sample10ScanInterruptEnable

If sample10 is converted, generate the scan interrupt.

enumerator kCADC_Sample11ScanInterruptEnable

If sample11 is converted, generate the scan interrupt.

enumerator kCADC_Sample12ScanInterruptEnable

If sample12 is converted, generate the scan interrupt.

enumerator kCADC_Sample13ScanInterruptEnable

If sample13 is converted, generate the scan interrupt.

enumerator kCADC_Sample14ScanInterruptEnable

If sample14 is converted, generate the scan interrupt.

enumerator kCADC_Sample15ScanInterruptEnable

If sample15 is converted, generate the scan interrupt.

enumerator kCADC_ANA4ExpMuxScanCompleteInterruptEnable

If ANA4 expansion MUX channel scan complete, generate the interrupt.

enumerator kCADC_ANB4ExpMuxScanCompleteInterruptEnable

If ANB4 expansion MUX channel scan complete, generate the interrupt.

enumerator kCADC_HighLimitInterruptEnable

If the result value is greater than the high limit value, generate high limit interrupt.

enumerator kCADC_LowLimitInterruptEnable

If the result value is less than the low limit value, generate low limit interrupt.

enumerator kCADC_ZeroCrossingInterruptEnable

If the current value has a sign change from the previous result in the selected zero crossing mode, generate the zero crossing mode

enumerator kCADC_ConversionCompleteInterrupt0Enable

Upon the completion of the scan, generate the end of scan interrupt, when the scan mode is selected as sequential mode or simultaneous parallel mode. For looping scan mode, the interrupt will trigger after the completion of each iteration of loop.

enumerator kCADC_ConversionCompleteInterrupt1Enable

When the scan mode is independent parallel mode, up the completion of the converter scan, generate the end of scan interrupt. For looping scan mode, the interrupt will trigger after the completion of each iteration of loop.

enumerator kCADC_ALLInterruptEnable

enum _cadc_converter_id

CADC Converter identifier.

Values:

enumerator kCADC_ConverterA

Converter A.

enumerator kCADC_ConverterB

Converter B.

enum _cadc_idle_work_mode

The enumeration of work mode when the module is not used.

Values:

enumerator kCADC_IdleKeepNormal

Keep normal.

enumerator kCADC_IdleAutoPowerDown

Fall into power down mode automatically.

enum _cadc_dma_trigger_source

The enumeration of DMA trigger source.

Values:

enumerator kCADC_DMATrigSrcEndofScan

DMA trigger source is end of scan interrupt.

enumerator kCADC_DMATrigSrcSampleReady

DMA trigger source is RDY bits.

enum _cadc_scan_mode

The enumeration of dual converter's scan mode.

Values:

enumerator kCADC_ScanModeOnceSequential

Once (single) sequential.

enumerator kCADC_ScanModeOnceParallelIndependent

Once parallel independently.

enumerator kCADC_ScanModeLoopSequential

Loop sequential.

enumerator kCADC_ScanModeLoopParallelIndependent

Loop parallel independently.

enumerator kCADC_ScanModeTriggeredSequential

Triggered sequential.

enumerator kCADC_ScanModeTriggeredParallelIndependent

Triggered parallel independently.

enumerator kCADC_ScanModeOnceParallelSimultaneous

Once parallel simultaneously.

enumerator kCADC_ScanModeLoopParallelSimultaneous

Loop parallel simultaneously.

enumerator kCADC_ScanModeTriggeredParallelSimultaneous

Triggered parallel simultaneously.

enum _cadc_reference_voltage_source

The enumeration of converter's reference voltage source.

Values:

enumerator kCADC_ReferenceVoltageVrefPad

VREF pin.

enumerator kCADC_ReferenceVoltageChannelPad

ANx2 or ANx3 pin.

enum _cadc_channel_gain

The enumeration of sample slot connected channel gain.

Values:

enumerator kCADC_SignalGainX1

Gain x1.

enumerator kCADC_SignalGainX2

Gain x2.

enumerator kCADC_SignalGainX4

Gain x4.

enum __cadc_channel_mode

The enumeration of all channels' channel mode.

Values:

enumerator kCADC_ANA0_1_SingleEnd

ANA0 and ANA1 both configured as single ended inputs.

enumerator kCADC_ANA0_1_FullyDifferential

ANA0 configured as fully differential positive input, ANA1 configured as fully differential negative input.

enumerator kCADC_ANA0_1_UnipolarDifferential

ANA0 configured as unipolar differential positive input, ANA1 configured as unipolar differential negative input.

enumerator kCADC_ANA2_3_SingleEnd

ANA2 and ANA3 both configured as single ended inputs.

enumerator kCADC_ANA2_3_FullyDifferential

ANA2 configured as fully differential positive input, ANA3 configured as fully differential negative input.

enumerator kCADC_ANA2_3_UnipolarDifferential

ANA2 configured as unipolar differential positive input, ANA3 configured as unipolar differential negative input.

enumerator kCADC_ANB0_1_SingleEnd

ANB0 and ANB1 both configured as single ended inputs.

enumerator kCADC_ANB0_1_FullyDifferential

ANB0 configured as fully differential positive input, ANB1 configured as fully differential negative input.

enumerator kCADC_ANB0_1_UnipolarDifferential

ANB0 configured as unipolar differential positive input, ANB1 configured as unipolar differential negative input.

enumerator kCADC_ANB2_3_SingleEnd

ANB2 and ANB3 both configured as single ended inputs.

enumerator kCADC_ANB2_3_FullyDifferential

ANB2 configured as fully differential positive input, ANB3 configured as fully differential negative input.

enumerator kCADC_ANB2_3_UnipolarDifferential

ANB2 configured as unipolar differential positive input, ANB3 configured as unipolar differential negative input.

enumerator kCADC_ANA4_5_SingleEnd

ANA4 and ANA5 both configured as single ended inputs.

enumerator kCADC_ANA4_5_FullyDifferential

ANA4 configured as fully differential positive input, ANA5 configured as fully differential negative input.

enumerator kCADC_ANA4_5_UnipolarDifferential

ANA4 configured as unipolar differential positive input, ANA5 configured as unipolar differential negative input.

enumerator kCADC_ANA6_7_SingleEnd

ANA6 and ANA7 both configured as single ended inputs.

enumerator kCADC_ANA6_7_FullyDifferential

ANA6 configured as fully differential positive input, ANA7 configured as fully differential negative input.

enumerator kCADC_ANA6_7_UnipolarDifferential

ANA6 configured as unipolar differential positive input, ANA7 configured as unipolar differential negative input.

enumerator kCADC_ANB4_5_SingleEnd

ANB4 and ANB5 both configured as single ended inputs.

enumerator kCADC_ANB4_5_FullyDifferential

ANB4 configured as fully differential positive input, ANB5 configured as fully differential negative input.

enumerator kCADC_ANB4_5_UnipolarDifferential

ANB4 configured as unipolar differential positive input, ANB5 configured as unipolar differential negative input.

enumerator kCADC_ANB6_7_SingleEnd

ANB6 and ANB7 both configured as single ended inputs.

enumerator kCADC_ANB6_7_FullyDifferential

ANB6 configured as fully differential positive input, ANB7 configured as fully differential negative input.

enumerator kCADC_ANB6_7_UnipolarDifferential

ANB6 configured as unipolar differential positive input, ANB7 configured as unipolar differential negative input.

enum _cadc_channel_number

The enumerator of all channels that can be routed to the specific sample slot.

Values:

enumerator kCADC_SingleEndANA0_DiffANA0pANA1n

Single Ended ANA0 Signal Or Differential ANA0+, ANA1- signal.

enumerator kCADC_SingleEndANA1_DiffANA0pANA1n

Single Ended ANA1 Signal Or Differential ANA0+, ANA1- signal.

enumerator kCADC_SingleEndANA2_DiffANA2pANA3n

Single Ended ANA2 Signal Or Differential ANA2+, ANA3- signal.

enumerator kCADC_SingleEndANA3_DiffANA2pANA3n

Single Ended ANA3 Signal Or Differential ANA2+, ANA3- signal.

enumerator kCADC_SingleEndANA4_DiffANA4pANA5n

Single Ended ANA4 Signal Or Differential ANA4+, ANA5- signal.

enumerator kCADC_SingleEndANA5_DiffANA4pANA5n

Single Ended ANA5 Signal Or Differential ANA4+, ANA5- signal.

enumerator kCADC_SingleEndANA6_DiffANA6pANA7n

Single Ended ANA6 Signal Or Differential ANA6+, ANA7- signal.

enumerator kCADC_SingleEndANA7_DiffANA6pANA7n
Single Ended ANA7 Signal Or Differential ANA6+, ANA7- signal.

enumerator kCADC_SingleEndANB0_DiffANB0pANB1n
Single Ended ANB0 Signal Or Differential ANB0+, ANB1- signal.

enumerator kCADC_SingleEndANB1_DiffANB0pANB1n
Single Ended ANB1 Signal Or Differential ANB0+, ANB1- signal.

enumerator kCADC_SingleEndANB2_DiffANB2pANB3n
Single Ended ANB2 Signal Or Differential ANB2+, ANB3- signal.

enumerator kCADC_SingleEndANB3_DiffANB2pANB3n
Single Ended ANB3 Signal Or Differential ANB2+, ANB3- signal.

enumerator kCADC_SingleEndANB4_DiffANB4pANB5n
Single Ended ANB4 Signal Or Differential ANB4+, ANB5- signal.

enumerator kCADC_SingleEndANB5_DiffANB4pANB5n
Single Ended ANB5 Signal Or Differential ANB4+, ANB5- signal.

enumerator kCADC_SingleEndANB6_DiffANB6pANB7n
Single Ended ANB6 Signal Or Differential ANB6+, ANB7- signal.

enumerator kCADC_SingleEndANB7_DiffANB6pANB7n
Single Ended ANB7 Signal Or Differential ANB6+, ANB7- signal.

enum _cadc_sample_slot_mask

The enumeration of sample slot mask.

Values:

enumerator kCADC_NonSampleSlotMask

enumerator kCADC_SampleSlot0Mask

The mask of sample slot0.

enumerator kCADC_SampleSlot1Mask

The mask of sample slot1.

enumerator kCADC_SampleSlot2Mask

The mask of sample slot2.

enumerator kCADC_SampleSlot3Mask

The mask of sample slot3.

enumerator kCADC_SampleSlot4Mask

The mask of sample slot4.

enumerator kCADC_SampleSlot5Mask

The mask of sample slot5.

enumerator kCADC_SampleSlot6Mask

The mask of sample slot6.

enumerator kCADC_SampleSlot7Mask

The mask of sample slot7.

enumerator kCADC_SampleSlot8Mask

The mask of sample slot8.

enumerator kCADC_SampleSlot9Mask

The mask of sample slot9.

enumerator kCADC_SampleSlot10Mask

The mask of sample slot10.

enumerator kCADC_SampleSlot11Mask

The mask of sample slot11.

enumerator kCADC_SampleSlot12Mask

The mask of sample slot12.

enumerator kCADC_SampleSlot13Mask

The mask of sample slot13.

enumerator kCADC_SampleSlot14Mask

The mask of sample slot14.

enumerator kCADC_SampleSlot15Mask

The mask of sample slot15.

enumerator kCADC_AllSampleSlotsMask

The mask of all sample slots.

enum _cadc_sample_slot_index

The enumeration of sample slot index.

Values:

enumerator kCADC_SampleSlot0Index

The index of sample slot0.

enumerator kCADC_SampleSlot1Index

The index of sample slot1.

enumerator kCADC_SampleSlot2Index

The index of sample slot2.

enumerator kCADC_SampleSlot3Index

The index of sample slot3.

enumerator kCADC_SampleSlot4Index

The index of sample slot4.

enumerator kCADC_SampleSlot5Index

The index of sample slot5.

enumerator kCADC_SampleSlot6Index

The index of sample slot6.

enumerator kCADC_SampleSlot7Index

The index of sample slot7.

enumerator kCADC_SampleSlot8Index

The index of sample slot8.

enumerator kCADC_SampleSlot9Index

The index of sample slot9.

enumerator kCADC_SampleSlot10Index

The index of sample slot10.

enumerator kCADC_SampleSlot11Index

The index of sample slot11.

enumerator kCADC_SampleSlot12Index

The index of sample slot12.

enumerator kCADC_SampleSlot13Index

The index of sample slot13.

enumerator kCADC_SampleSlot14Index

The index of sample slot14.

enumerator kCADC_SampleSlot15Index

The index of sample slot15.

enum _cadc_sample_slot_sequential_mode_disabled

The enumeration for the sample slot to be disabled in sequential mode.

Values:

enumerator kCADC_Sample0Disabled

Disable Sample slot0, the scan will stop at sample slot0 in sequential scan mode

enumerator kCADC_Sample1Disabled

Disable Sample slot1, the scan will stop at sample slot1 in sequential scan mode

enumerator kCADC_Sample2Disabled

Disable Sample slot2, the scan will stop at sample slot2 in sequential scan mode

enumerator kCADC_Sample3Disabled

Disable Sample slot3, the scan will stop at sample slot3 in sequential scan mode

enumerator kCADC_Sample4Disabled

Disable Sample slot4, the scan will stop at sample slot4 in sequential scan mode

enumerator kCADC_Sample5Disabled

Disable Sample slot5, the scan will stop at sample slot5 in sequential scan mode

enumerator kCADC_Sample6Disabled

Disable Sample slot6, the scan will stop at sample slot6 in sequential scan mode

enumerator kCADC_Sample7Disabled

Disable Sample slot7, the scan will stop at sample slot7 in sequential scan mode

enumerator kCADC_Sample8Disabled

Disable Sample slot8, the scan will stop at sample slot8 in sequential scan mode

enumerator kCADC_Sample9Disabled

Disable Sample slot9, the scan will stop at sample slot9 in sequential scan mode

enumerator kCADC_Sample10Disabled

Disable Sample slot10, the scan will stop at sample slot10 in sequential scan mode

enumerator kCADC_Sample11Disabled

Disable Sample slot11, the scan will stop at sample slot11 in sequential scan mode

enumerator kCADC_Sample12Disabled

Disable Sample slot12, the scan will stop at sample slot12 in sequential scan mode

enumerator kCADC_Sample13Disabled

Disable Sample slot13, the scan will stop at sample slot13 in sequential scan mode

enumerator kCADC_Sample14Disabled

Disable Sample slot14, the scan will stop at sample slot14 in sequential scan mode

enumerator kCADC_Sample15Disabled

Disable Sample slot15, the scan will stop at sample slot15 in sequential scan mode

enum _cadc_sample_slot_simultParallel_mode_disabled

The enumeration for the sample slot to be disabled in simultaneous parallel mode.

Values:

enumerator kCADC_Sample0_8Disabled

Disable Sample slot0 and Sample Slot 8, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot0 and Sample slot 8.

enumerator kCADC_Sample1_9Disabled

Disable Sample slot1 and Sample Slot 9, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot1 and Sample slot 9.

enumerator kCADC_Sample2_10Disabled

Disable Sample slot2 and Sample Slot 10, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot2 and Sample slot 10.

enumerator kCADC_Sample3_11Disabled

Disable Sample slot3 and Sample Slot 11, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot3 and Sample slot 11.

enumerator kCADC_Sample4_12Disabled

Disable Sample slot4 and Sample Slot 12, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot4 and Sample slot 12.

enumerator kCADC_Sample5_13Disabled

Disable Sample slot5 and Sample Slot 13, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot5 and Sample slot 13.

enumerator kCADC_Sample6_14Disabled

Disable Sample slot6 and Sample Slot 14, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot7 and Sample slot 14.

enumerator kCADC_Sample7_15Disabled

Disable Sample slot7 and Sample Slot 15, in the simultaneous parallel mode the converter A and converter B will stop at Sample slot7 and Sample slot 15.

enum _cadc_sample_slot_independentParallel_mode_convA_disabled

The enumeration for the sample slot to be disabled for the converter A in independent parallel mode.

Values:

enumerator kCADC_ConvASample0Disabled

Disable Sample slot0, the scan will stop at sample slot0 in sequential scan mode

enumerator kCADC_ConvASample1Disabled

Disable Sample slot1, the scan will stop at sample slot1 in sequential scan mode

enumerator kCADC_ConvASample2Disabled

Disable Sample slot2, the scan will stop at sample slot2 in sequential scan mode

enumerator kCADC_ConvASample3Disabled

Disable Sample slot3, the scan will stop at sample slot3 in sequential scan mode

enumerator kCADC_ConvASample4Disabled

Disable Sample slot4, the scan will stop at sample slot4 in sequential scan mode

enumerator kCADC_ConvASample5Disabled

Disable Sample slot5, the scan will stop at sample slot5 in sequential scan mode

enumerator kCADC_ConvASample6Disabled

Disable Sample slot6, the scan will stop at sample slot6 in sequential scan mode

enumerator kCADC_ConvASample7Disabled

Disable Sample slot7, the scan will stop at sample slot7 in sequential scan mode

enumerator kCADC_ConvASampleReserved

Reserved

enum _cadc_sample_slot_indParallel_mode_convB_disabled

The enumeration for the sample slot to be disabled for the converter B in independent parallel mode.

Values:

enumerator kCADC_ConvBSample8Disabled

Disable Sample slot8, the scan will stop at sample slot8 in sequential scan mode

enumerator kCADC_ConvBSample9Disabled

Disable Sample slot9, the scan will stop at sample slot9 in sequential scan mode

enumerator kCADC_ConvBSample10Disabled

Disable Sample slot10, the scan will stop at sample slot10 in sequential scan mode

enumerator kCADC_ConvBSample11Disabled

Disable Sample slot11, the scan will stop at sample slot11 in sequential scan mode

enumerator kCADC_ConvBSample12Disabled

Disable Sample slot12, the scan will stop at sample slot12 in sequential scan mode

enumerator kCADC_ConvBSample13Disabled

Disable Sample slot13, the scan will stop at sample slot13 in sequential scan mode

enumerator kCADC_ConvBSample14Disabled

Disable Sample slot14, the scan will stop at sample slot14 in sequential scan mode

enumerator kCADC_ConvBSample15Disabled

Disable Sample slot15, the scan will stop at sample slot15 in sequential scan mode

enumerator kCADC_ConvBSampleReserved

Reserved

enum _cadc_sample_slot_zero_crossing_mode

The enumeration for the sample slot's zero crossing event.

Values:

enumerator kCADC_ZeroCrossingDisabled

Zero Crossing disabled.

enumerator kCADC_ZeroCrossingForPtoNSign

Zero Crossing enabled for positive to negative sign change.

enumerator kCADC_ZeroCrossingForNtoPSign

Zero Crossing enabled for negative to positive sign change.

enumerator kCADC_ZeroCrossingForAnySignChanged

Zero Crossing enabled for any sign change.

enum _cadc_expansion_mux_operate_mode

The enumeration for expansion multiplexer.

Values:

enumerator kCADC_ExpMuxManualMode

MUX channel feeding to ANA4/ANB4 is selected as MUXSEL0.

enumerator kCADC_ExpMuxScanMode0

The sample completion of ANA4/ANB4 enables subsequent selected channel.

enumerator kCADC_ExpMuxScanMode1

The sample completion of ANA7/ANB7 enables subsequent selected channel.

enumerator kCADC_ExpMuxScanMode2

The sample completion of ANA4/ANB4 or ANA7/ANB7 enables subsequent selected channel.

enum _cadc_auxiliary_control

The enumeration of converter's auxiliary control.

Values:

enumerator kCADC_AuxSel0_Config0

Auxiliary select 0 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel0_Config1

Auxiliary select 0 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel0_Config2

Auxiliary select 0 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel0_Config3

Auxiliary select 0 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel1_Config0

Auxiliary select 1 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel1_Config1

Auxiliary select 1 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel1_Config2

Auxiliary select 1 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel1_Config3

Auxiliary select 1 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel2_Config0

Auxiliary select 2 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel2_Config1

Auxiliary select 2 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel2_Config2

Auxiliary select 2 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel2_Config3

Auxiliary select 2 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel3_Config0

Auxiliary select 3 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel3_Config1

Auxiliary select 3 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel3_Config2

Auxiliary select 3 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel3_Config3

Auxiliary select 3 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel4_Config0

Auxiliary select 4 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel4_Config1

Auxiliary select 4 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel4_Config2

Auxiliary select 4 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel4_Config3

Auxiliary select 4 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel5_Config0

Auxiliary select 5 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel5_Config1

Auxiliary select 5 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel5_Config2

Auxiliary select 5 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel5_Config3

Auxiliary select 5 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel6_Config0

Auxiliary select 6 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel6_Config1

Auxiliary select 6 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel6_Config2

Auxiliary select 6 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel6_Config3

Auxiliary select 6 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enumerator kCADC_AuxSel7_Config0

Auxiliary select 7 controls AUX_SEL0 = 0, AUX_SEL1 = 0.

enumerator kCADC_AuxSel7_Config1

Auxiliary select 7 controls AUX_SEL0 = 1, AUX_SEL1 = 0.

enumerator kCADC_AuxSel7_Config2

Auxiliary select 7 controls AUX_SEL0 = 0, AUX_SEL1 = 1.

enumerator kCADC_AuxSel7_Config3

Auxiliary select 7 controls AUX_SEL0 = 1, AUX_SEL1 = 1.

enum _cadc_expansion_disabled_mux_slot

The enumeration for the expansion mux slot to be disabled.

Values:

enumerator kCADC_ExpaMuxNoDisable

Expansion mux scan not disabled.

enumerator kCADC_ExpMux0Disable

Expansion mux slot 0.

enumerator kCADC_ExpMux1Disable

Expansion mux slot 1.

enumerator kCADC_ExpMux2Disable

Expansion mux slot 2.

enumerator kCADC_ExpMux3Disable

Expansion mux slot 3.

enumerator kCADC_ExpMux4Disable

Expansion mux slot 4.

enumerator kCADC_ExpMux5Disable

Expansion mux slot 5.

enumerator kCADC_ExpMux6Disable

Expansion mux slot 6.

enumerator kCADC_ExpMux7Disable

Expansion mux slot 7.

enum _cadc_expansion_mux_selection

The enumeration of expansion mux selection.

Values:

enumerator kCADC_MuxSel0_Channel0

MUX's channel 0 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel1

MUX's channel 1 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel2

MUX's channel 2 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel3

MUX's channel 3 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel4

MUX's channel 4 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel5

MUX's channel 5 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel6

MUX's channel 6 for MUXSEL0.

enumerator kCADC_MuxSel0_Channel7

MUX's channel 7 for MUXSEL0.

enumerator kCADC_MuxSel1_Channel0

MUX's channel 0 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel1

MUX's channel 1 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel2

MUX's channel 2 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel3

MUX's channel 3 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel4
MUX's channel 4 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel5
MUX's channel 5 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel6
MUX's channel 6 for MUXSEL1.

enumerator kCADC_MuxSel1_Channel7
MUX's channel 7 for MUXSEL1.

enumerator kCADC_MuxSel2_Channel0
MUX's channel 0 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel1
MUX's channel 1 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel2
MUX's channel 2 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel3
MUX's channel 3 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel4
MUX's channel 4 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel5
MUX's channel 5 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel6
MUX's channel 6 for MUXSEL2.

enumerator kCADC_MuxSel2_Channel7
MUX's channel 7 for MUXSEL2.

enumerator kCADC_MuxSel3_Channel0
MUX's channel 0 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel1
MUX's channel 1 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel2
MUX's channel 2 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel3
MUX's channel 3 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel4
MUX's channel 4 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel5
MUX's channel 5 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel6
MUX's channel 6 for MUXSEL3.

enumerator kCADC_MuxSel3_Channel7
MUX's channel 7 for MUXSEL3.

enumerator kCADC_MuxSel4_Channel0
MUX's channel 0 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel1
MUX's channel 1 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel2
MUX's channel 2 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel3
MUX's channel 3 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel4
MUX's channel 4 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel5
MUX's channel 5 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel6
MUX's channel 6 for MUXSEL4.

enumerator kCADC_MuxSel4_Channel7
MUX's channel 7 for MUXSEL4.

enumerator kCADC_MuxSel5_Channel0
MUX's channel 0 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel1
MUX's channel 1 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel2
MUX's channel 2 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel3
MUX's channel 3 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel4
MUX's channel 4 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel5
MUX's channel 5 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel6
MUX's channel 6 for MUXSEL5.

enumerator kCADC_MuxSel5_Channel7
MUX's channel 7 for MUXSEL5.

enumerator kCADC_MuxSel6_Channel0
MUX's channel 0 for MUXSEL6.

enumerator kCADC_MuxSel6_Channel1
MUX's channel 1 for MUXSEL6.

enumerator kCADC_MuxSel6_Channel2
MUX's channel 2 for MUXSEL6.

enumerator kCADC_MuxSel6_Channel3
MUX's channel 3 for MUXSEL6.

enumerator kCADC_MuxSel6_Channel4
MUX's channel 4 for MUXSEL6.

enumerator kCADC_MuxSel6_Channel5
MUX's channel 5 for MUXSEL6.

enumerator `kCADC_MuxSel6_Channel6`
MUX's channel 6 for MUXSEL6.

enumerator `kCADC_MuxSel6_Channel7`
MUX's channel 7 for MUXSEL6.

enumerator `kCADC_MuxSel7_Channel0`
MUX's channel 0 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel1`
MUX's channel 1 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel2`
MUX's channel 2 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel3`
MUX's channel 3 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel4`
MUX's channel 4 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel5`
MUX's channel 5 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel6`
MUX's channel 6 for MUXSEL7.

enumerator `kCADC_MuxSel7_Channel7`
MUX's channel 7 for MUXSEL7.

typedef enum *`_cadc_converter_id`* `cadc_converter_id_t`
CADC Converter identifier.

typedef enum *`_cadc_idle_work_mode`* `cadc_idle_work_mode_t`
The enumeration of work mode when the module is not used.

typedef enum *`_cadc_dma_trigger_source`* `cadc_dma_trigger_source_t`
The enumeration of DMA trigger source.

typedef enum *`_cadc_scan_mode`* `cadc_scan_mode_t`
The enumeration of dual converter's scan mode.

typedef enum *`_cadc_reference_voltage_source`* `cadc_reference_voltage_source_t`
The enumeration of converter's reference voltage source.

typedef enum *`_cadc_channel_gain`* `cadc_channel_gain_t`
The enumeration of sample slot connected channel gain.

typedef enum *`_cadc_channel_mode`* `cadc_channel_mode_t`
The enumeration of all channels' channel mode.

typedef enum *`_cadc_channel_number`* `cadc_channel_number_t`
The enumerator of all channels that can be routed to the specific sample slot.

typedef enum *`_cadc_sample_slot_mask`* `cadc_sample_slot_mask_t`
The enumeration of sample slot mask.

typedef enum *`_cadc_sample_slot_index`* `cadc_sample_slot_index_t`
The enumeration of sample slot index.

typedef enum *`_cadc_sample_slot_sequential_mode_disabled`*
`cadc_sample_slot_sequential_mode_disabled_t`
The enumeration for the sample slot to be disabled in sequential mode.

```
typedef enum _cadc_sample_slot_simultParallel_mode_disabled  
cadc_sample_slot_simultParallel_mode_disabled_t
```

The enumeration for the sample slot to be disabled in simultaneous parallel mode.

```
typedef enum _cadc_sample_slot_independentParallel_mode_convA_disabled  
cadc_sample_slot_independentParallel_mode_convA_disabled_t
```

The enumeration for the sample slot to be disabled for the converter A in independent parallel mode.

```
typedef enum _cadc_sample_slot_indParallel_mode_convB_disabled  
cadc_sample_slot_independentParallel_mode_convB_disabled_t
```

The enumeration for the sample slot to be disabled for the converter B in independent parallel mode.

```
typedef enum _cadc_sample_slot_zero_crossing_mode cadc_sample_slot_zero_crossing_mode_t
```

The enumeration for the sample slot's zero crossing event.

```
typedef enum _cadc_expansion_mux_operate_mode cadc_expansion_mux_operate_mode_t
```

The enumeration for expansion multiplexer.

```
typedef struct _cadc_sample_slot_independentParallel_mode_disabled  
cadc_sample_slot_independentParallel_mode_disabled_t
```

The structure of the disabled sample slots in independent parallel mode.

```
typedef union _cadc_sample_slot_disabled cadc_sample_slot_disabled_t
```

The union of disabled sample slot for each scan mode.

```
typedef struct _cadc_sample_config cadc_sample_slot_config_t
```

The structure for configuring the sample slot.

```
typedef struct _cadc_scan_ctrl_sequential_mode cadc_scan_ctrl_seq_mode_t
```

Cadc scan control for sequential scan mode.

Note: Each member of this structure represent one bit of the word. Asserted the structure's member means delay sample until a new sync input occurs. Cleared the structure's member means perform sample immediately after the completion of the current sample.

```
typedef struct _cadc_scan_ctrl_simultParallel_mode cadc_scan_ctrl_simultParallel_mode_t
```

Cadc scan control for simultaneous parallel scan mode.

Note: Each member of this structure represent one bit of the word. Asserted the structure's member means delay sample until a new sync input occurs. Cleared the structure's member means perform sample immediately after the completion of the current sample.

```
typedef struct _cadc_scan_ctrl_independent_parallel_mode_converterA  
cadc_scan_ctrl_independent_parallel_mode_converterA_t
```

The scan ctrl struture for converterA in independent scan mode.

```
typedef struct _cadc_scan_ctrl_independent_parallel_mode_converterB  
cadc_scan_ctrl_independent_parallel_mode_converterB_t
```

The scan ctrl struture for converterB in independent scan mode.

```
typedef union _cadc_scan_ctrl_independent_parallel_mode  
cadc_scan_ctrl_independent_parallel_mode_t
```

The union for converters in independent parallel mode.

```
typedef union _cadc_scan_control cadc_scan_control_t
```

The union of the scan control for each scan mode.

`typedef enum _cadc_auxiliary_control cadc_auxiliary_control_t`

The enumeration of converter's auxiliary control.

`typedef enum _cadc_expansion_disabled_mux_slot cadc_expansion_disabled_mux_slot_t`

The enumeration for the expansion mux slot to be disabled.

`typedef enum _cadc_expansion_mux_selection cadc_expansion_mux_selection_t`

The enumeration of expansion mux selection.

`typedef struct _cadc_exp_mux_aux_config cadc_exp_mux_aux_config_t`

The structure for configuring Cyclic ADC's expansion setting.

`typedef struct _cadc_converter_config cadc_converter_config_t`

The structure for configuring each converter.

`typedef struct _cadc_config cadc_config_t`

The structure for configuring the Cyclic ADC's setting.

`CADC_SAMPLE_SLOTS_COUNT`

Macro for CADC sample slot count.

`struct _cadc_sample_slot_independentParallel_mode_disabled`

`#include <fsl_cadc.h>` The structure of the disabled sample slots in independent parallel mode.

Public Members

`cadc_sample_slot_independentParallel_mode_convA_disabled_t` eConverterA

The sample slot to be disabled for the converter A, when the scan mode is set as independent parallel mode.

`cadc_sample_slot_independentParallel_mode_convB_disabled_t` eConverterB

The sample slot to be disabled for the converter B, when the scan mode is set as independent parallel mode.

`union _cadc_sample_slot_disabled`

`#include <fsl_cadc.h>` The union of disabled sample slot for each scan mode.

Public Members

`uint32_t` u32SampleDisVal

The 32 bits width of disabled sample slot value. This member used to get the disabled sample slot which sets in different scan modes in word type. This member is not recommended to be used to set the disabled sample slot. This member is designed to be used in driver level only, the application should not use this member.

`cadc_sample_slot_sequential_mode_disabled_t` eSequentialModeDisSample

If the scan mode is selected as sequential mode, the application must use this member to set the disabled sample slot. This member is used to set disabled sample slot when the scan mode is selected as sequential mode. The scan will stop at the first disabled sample slot in that mode. So for the application, this member should be set as one sample slot index that the scan will stop.

`cadc_sample_slot_simultParallel_mode_disabled_t` eSimultParallelModeDisSample

In simultaneous parallel scan mode, the application must use this member to set the disabled sample slot. In that scan mode, the scan will stop when either converter encounters a disabled sample.

cadc_sample_slot_independentParallel_mode_disabled_t sIndependentParallelModeDisSample

In independent parallel scan mode, the application must use this member to set the disabled sample slot. In that scan mode, the converter will stop scan when it encounters a disabled sample slot. In this mode, the disabled sample slot for converterA and converterB may different.

struct __cadc_sample_config

#include <fsl_cadc.h> The structure for configuring the sample slot.

Public Members

cadc_sample_slot_zero_crossing_mode_t eZeroCrossingMode

Zero crossing mode.

uint16_t u16HighLimitValue

High limit value. Original value formation as hardware register, with 3-bits left shifted.

uint16_t u16LowLimitValue

Low limit value. Original value formation as hardware register, with 3-bits left shifted.

uint16_t u16OffsetValue

Offset value. Original value formation as hardware register, with 3-bits left shifted.

struct __cadc_scan_ctrl_sequential_mode

#include <fsl_cadc.h> Cadc scan control for sequential scan mode.

Note: Each member of this structure represent one bit of the word. Asserted the structure's member means delay sample until a new sync input occurs. Cleared the structure's member means perform sample immediately after the completion of the current sample.

Public Members

uint32_t bitSample0

Control whether delay sample0 until a new sync input occurs.

uint32_t bitSample1

Control whether delay sample1 until a new sync input occurs.

uint32_t bitSample2

Control whether delay sample2 until a new sync input occurs.

uint32_t bitSample3

Control whether delay sample3 until a new sync input occurs.

uint32_t bitSample4

Control whether delay sample4 until a new sync input occurs.

uint32_t bitSample5

Control whether delay sample5 until a new sync input occurs.

uint32_t bitSample6

Control whether delay sample6 until a new sync input occurs.

uint32_t bitSample7

Control whether delay sample7 until a new sync input occurs.

uint32_t bitSample8

Control whether delay sample8 until a new sync input occurs.

uint32_t bitSample9

Control whether delay sample9 until a new sync input occurs.

uint32_t bitSample10

Control whether delay sample10 until a new sync input occurs.

uint32_t bitSample11

Control whether delay sample11 until a new sync input occurs.

uint32_t bitSample12

Control whether delay sample12 until a new sync input occurs.

uint32_t bitSample13

Control whether delay sample13 until a new sync input occurs.

uint32_t bitSample14

Control whether delay sample14 until a new sync input occurs.

uint32_t bitSample15

Control whether delay sample15 until a new sync input occurs.

uint32_t bitsReserved

Reserved 16 bits.

struct _cadc_scan_ctrl_simultParallel_mode

#include <fsl_cadc.h> Cadc scan control for simultaneous parallel scan mode.

Note: Each member of this structure represent one bit of the word. Asserted the structure's member means delay sample until a new sync input occurs. Cleared the structure's member means perform sample immediately after the completion of the current sample.

Public Members

uint32_t bitSample0_8

Control whether delay sample0 and sample8 until a new sync input occurs.

uint32_t bitSample1_9

Control whether delay sample1 and sample9 until a new sync input occurs.

uint32_t bitSample2_10

Control whether delay sample2 and sample10 until a new sync input occurs.

uint32_t bitSample3_11

Control whether delay sample3 and sample11 until a new sync input occurs.

uint32_t bitsReserved1

Reserved 4 bits.

uint32_t bitSample4_12

Control whether delay sample4 and sample12 until a new sync input occurs.

uint32_t bitSample5_13

Control whether delay sample5 and sample13 until a new sync input occurs.

uint32_t bitSample6_14

Control whether delay sample6 and sample14 until a new sync input occurs.

uint32_t bitSample7_15

Control whether delay sample7 and sample15 until a new sync input occurs.

uint32_t bitsReserved2
Reserved 4 bits.

uint32_t bitsReserved3
Reserved 16 bits.

struct __cadsc_scan_ctrl_independent_parallel_mode_converterA
#include <fsl_cadc.h> The scan ctrl struture for converterA in independent scan mode.

Public Members

uint32_t bitSample0
Control whether delay converterA's sample0 until a new sync input occurs.

uint32_t bitSample1
Control whether delay converterA's sample1 until a new sync input occurs.

uint32_t bitSample2
Control whether delay converterA's sample2 until a new sync input occurs.

uint32_t bitSample3
Control whether delay converterA's sample3 until a new sync input occurs.

uint32_t bitsReserved1
Reserved 4 bits.

uint32_t bitSample4
Control whether delay converterA's sample4 until a new sync input occurs.

uint32_t bitSample5
Control whether delay converterA's sample5 until a new sync input occurs.

uint32_t bitSample6
Control whether delay converterA's sample6 until a new sync input occurs.

uint32_t bitSample7
Control whether delay converterA's sample7 until a new sync input occurs.

uint32_t bitsReserved2
Reserved 4 bits

uint32_t bitsReserved3
Reserved 16 bits.

struct __cadsc_scan_ctrl_independent_parallel_mode_converterB
#include <fsl_cadc.h> The scan ctrl struture for converterB in independent scan mode.

Public Members

uint32_t bitsReserved1
Reserved 4 bits.

uint32_t bitSample8
Control whether delay converterB's sample8 until a new sync input occurs.

uint32_t bitSample9
Control whether delay converterB's sample9 until a new sync input occurs.

uint32_t bitSample10
Control whether delay converterB's sample10 until a new sync input occurs.

uint32_t bitSample11

Control whether delay converterB's sample11 until a new sync input occurs.

uint32_t bitsReserved2

Reserved 4 bits.

uint32_t bitSample12

Control whether delay converterB's sample12 until a new sync input occurs.

uint32_t bitSample13

Control whether delay converterB's sample13 until a new sync input occurs.

uint32_t bitSample14

Control whether delay converterB's sample14 until a new sync input occurs.

uint32_t bitSample15

Control whether delay converterB's sample15 until a new sync input occurs.

uint32_t bitsReserved3

Reserved 16 bits.

union __cadc_scan_ctrl_independent_parallel_mode

#include <fsl_cadc.h> The union for converters in independent parallel mode.

Public Members

cadc_scan_ctrl_independent_parallel_mode_converterA_t sConverterA

Scan control for converterA.

cadc_scan_ctrl_independent_parallel_mode_converterB_t sConverterB

Scan control for converterB.

union __cadc_scan_control

#include <fsl_cadc.h> The union of the scan control for each scan mode.

Public Members

uint32_t u32ScanCtrlVal

The 32 bits value of the scan control value.

cadc_scan_ctrl_seq_mode_t sSequential

Scan control for sequential scan mode.

cadc_scan_ctrl_simultParallel_mode_t sSimultParallel

Scan control for simultaneous parallel scan mode.

cadc_scan_ctrl_independent_parallel_mode_t uIndependentParallel

Scan control for independent scan mode.

struct __cadc_exp_mux_aux_config

#include <fsl_cadc.h> The structure for configuring Cyclic ADC's expansion setting.

Public Members

uint16_t u16AuxControl

The mask of auxiliary control, should be the OR'ed value of *cadc_auxiliary_control_t*.

uint32_t u32MuxChannelMask

The mask of mux selection of all mux slots, should be the OR'ed value of `cadc_expansion_mux_selection_t`.

cadc_expansion_disabled_mux_slot_t disabledMuxSlot

mux slot to disabled in the scan.

struct `_cadc_converter_config`

#include <fsl_cadc.h> The structure for configuring each converter.

Public Members

uint16_t u16ClockDivisor

Converter's clock divisor for the clock source. Available setting range is 0-63.

- When the clockDivisor is 0, the divisor is 2.
- For all other clockDivisor values, the divisor is 1 more than the decimal value of clockDivisor: `clockDivisor + 1`

cadc_reference_voltage_source_t eHighReferenceVoltageSource

High voltage reference source.

cadc_reference_voltage_source_t eLowReferenceVoltageSource

Low reference voltage source.

bool bEnableDMA

Enable/Disable DMA.

bool bPowerUp

Power up or power down the converter.

bool bScanInitBySync

The member user to control the initiate method of the scan.

- **true** Use a SYNC input pulse or START command to initiate a scan.
- **false** Scan is initiated by the assertion of START command only.

cadc_exp_mux_aux_config_t muxAuxConfig

Configuration of expansion mux and auxiliary control.

struct `_cadc_config`

#include <fsl_cadc.h> The structure for configuring the Cyclic ADC's setting.

Public Members

cadc_idle_work_mode_t eIdleWorkMode

Idle work mode for the module.

cadc_dma_trigger_source_t eDMATriggerSource

Selects the dma trigger source for the module.

uint16_t u16PowerUpDelay

The number of ADC clocks to power up the converters (if powered up), before allowing a scan to start. The available range is 0 to 63 .

uint32_t u32EnabledInterruptMask

The mask of the interrupts to be enabled, should be the OR'ed value of `_cadc_interrupt_enable`.

cadsc_scan_mode_t eScanMode

The scan mode of the module.

cadsc_sample_slot_disabled_t uDisabledSampleSlot

The member used to config the which sample slot is disabled for the scan. The scan will continue until the first disabled sample slot is encountered.

cadsc_scan_control_t uScanControl

Scan control provides the ability to pause and await a new sync signal while current sample completed.

uint32_t u32ChannelModeMask

The mask of each channel's mode, should be the OR'ed value of *cadsc_channel_mode_t*. Each channel supports single-end and differential(Fully differentail and Unipolar differential). Some devices also support alternate source mode.

cadsc_channel_gain_t eChannelGain[(ADC_RSLT_COUNT)]

The gain value for each channel. Each element of the array represents the gain of the channel. E.g. eChannelGain[0] means channel gain of channel0, which is ANA0.

cadsc_channel_number_t eSampleSlot[(ADC_RSLT_COUNT)]

The channel assigned to each sample slot. The index of the array represents sample slot index.

cadsc_converter_config_t sConverterA

The configuration for converterA.

cadsc_converter_config_t sConverterB

The configuration for converterB.

2.8 The Driver Change Log

2.9 CADC Peripheral and Driver Overview

2.10 Clock Driver

enum __clock_ip_name

List of IP clock name.

Definition for delay API in clock driver, users can redefine it to the real application.

Values:

enumerator kCLOCK_GPIOG

GPIOG clock

enumerator kCLOCK_GPIOF

GPIOF clock

enumerator kCLOCK_GPIOE

GPIOE clock

enumerator kCLOCK_GPIOD

GPIOD clock

enumerator kCLOCK_GPIOC
GPIOC clock

enumerator kCLOCK_GPIOB
GPIOB clock

enumerator kCLOCK_GPIOA
GPIOA clock

enumerator kCLOCK_TB3
Timer B3 clock

enumerator kCLOCK_TB2
Timer B2 clock

enumerator kCLOCK_TB1
Timer B1 clock

enumerator kCLOCK_TB0
Timer B0 clock

enumerator kCLOCK_TA3
Timer A3 clock

enumerator kCLOCK_TA2
Timer A2 clock

enumerator kCLOCK_TA1
Timer A1 clock

enumerator kCLOCK_TA0
Timer A0 clock

enumerator kCLOCK_FLEXCAN
Flex CAN clock

enumerator kCLOCK_I2C1
I2C1 clock

enumerator kCLOCK_I2C0
I2C0 clock

enumerator kCLOCK_QSPI2
QSPI2 clock

enumerator kCLOCK_QSPI1
QSPI1 clock

enumerator kCLOCK_QSPI0
QSPI0 clock

enumerator kCLOCK_QSCI2
QSCI2 clock

enumerator kCLOCK_QSCI1
QSCI1 clock

enumerator kCLOCK_QSCI0
QSCI0 clock

enumerator kCLOCK_DAC
DAC clock

enumerator kCLOCK_PDB1
PDB 1 clock

enumerator kCLOCK_PDB0
PDB 0 clock

enumerator kCLOCK_PIT1
PIT 1 clock

enumerator kCLOCK_PIT0
PIT 0 clock

enumerator kCLOCK_QDC
QDC clock

enumerator kCLOCK_CRC
CRC clock

enumerator kCLOCK_CYCADC
Cyclic ADC clock

enumerator kCLOCK_SARADC
SAR ADC clock

enumerator kCLOCK_CMPD
Comparator D clock

enumerator kCLOCK_CMPC
Comparator C clock

enumerator kCLOCK_CMPB
Comparator B clock

enumerator kCLOCK_CMPA
Comparator A clock

enumerator kCLOCK_PWMBCH3
Enhanced Flexible PWM B3 clock

enumerator kCLOCK_PWMBCH2
Enhanced Flexible PWM B2 clock

enumerator kCLOCK_PWMBCH1
Enhanced Flexible PWM B1 clock

enumerator kCLOCK_PWMBCH0
Enhanced Flexible PWM B0 clock

enumerator kCLOCK_PWMACH3
Enhanced Flexible PWM A3 clock

enumerator kCLOCK_PWMACH2
Enhanced Flexible PWM A2 clock

enumerator kCLOCK_PWMACH1
Enhanced Flexible PWM A1 clock

enumerator kCLOCK_PWMACH0
Enhanced Flexible PWM A0 clock

enumerator kCLOCK_NOGATE
No clock gate for the IP

enumerator kCLOCK_COP

enumerator kCLOCK_EWM

enumerator kCLOCK_XBARA

enumerator kCLOCK_DMA

enumerator kCLOCK_NUM

Total IP clock number

enum _clock_name

List of system-level clock name.

Values:

enumerator kCLOCK_Mstr2xCk

Master 2x clock which feed to core and peripheral

enumerator kCLOCK_SysCk

MCU system/core clock

enumerator kCLOCK_BusCk

Bus clock

enumerator kCLOCK_Bus2xCk

Bus 2x clock

enumerator kCLOCK_FlashCk

Flash clock

enumerator kCLOCK_FastIrcCk

Fast internal RC oscillator, 8M/400K

enumerator kCLOCK_SlowIrcCk

Slow internal RC oscillator, 32K

enumerator kCLOCK_CrystalOscCk

Crystal oscillator

enumerator kCLOCK_ExtCk

The selected external clock, it could be crystal oscillator, clkin0, clkin1

enumerator kCLOCK_MstrOscCk

The selected master oscillator clock

enumerator kCLOCK_PllDiv2Ck

PLL output divide 2

enum _clock_crystal_osc_mode

Crystal oscillator mode.

Values:

enumerator kCLOCK_CrystalOscModeFSP

Full swing pierce, high power mode

enumerator kCLOCK_CrystalOscModeLCP

Loop controlled pierce, low power mode

enum _clock_ext_clk_src

List of external clock source.

Values:

enumerator kCLOCK_ExtClkSrcCrystalOsc
External clock source is crystal oscillator

enumerator kCLOCK_ExtClkSrcClkin
External clock source is clock in

enum _clock_ext_clkin_sel
List of clock-in source.

Values:

enumerator kCLOCK_SelClkIn0
Clock in 0 is selected as CLKIN

enumerator kCLOCK_SelClkIn1
Clock in 1 is selected as CLKIN

enum _clock_mstr_osc_clk_src
List of master oscillator source.

Values:

enumerator kCLOCK_MstrOscClkSrcFirc
8M/400K, fast internal RC oscillator

enumerator kCLOCK_MstrOscClkSrcExt
External clock

enumerator kCLOCK_MstrOscClkSrcSirc
32K, slow internal RC oscillator

enum _clock_mstr_2x_clk_src
List of master 2x clock source.

Values:

enumerator kCLOCK_Mstr2xClkSrcMstrOsc
Master oscillator clock

enumerator kCLOCK_Mstr2xClkSrcPlldiv2
PLL output divide 2

enum _clock_output_clk_src
List of output clock source.

Values:

enumerator kCLOCK_OutputClkSrc_Bus
Bus clock

enumerator kCLOCK_OutputClkSrc_Bus2x
Bus 2x clock

enumerator kCLOCK_OutputClkSrc_BusDiv4
Bus clock div 4

enumerator kCLOCK_OutputClkSrc_MstrOSC
Master oscillator clock

enumerator kCLOCK_OutputClkSrc_Firc
8M/400K clock

enumerator kCLOCK_OutputClkSrc_Sirc
32K clock, SIRC

enum _clock_output_clk_div

List of output clock divider.

Values:

enumerator kCLOCK_OutputDiv1

output clock = selectedClock/1U

enumerator kCLOCK_OutputDiv2

output clock = selectedClock/2U

enumerator kCLOCK_OutputDiv4

output clock = selectedClock/4U

enumerator kCLOCK_OutputDiv8

output clock = selectedClock/8U

enumerator kCLOCK_OutputDiv16

output clock = selectedClock/16U

enumerator kCLOCK_OutputDiv32

output clock = selectedClock/32U

enumerator kCLOCK_OutputDiv64

output clock = selectedClock/64U

enumerator kCLOCK_OutputDiv128

output clock = selectedClock/128U

enum _clock_protection

List of clock register protection mode.

Values:

enumerator kCLOCK_Protection_Off

No protection, and could be changed any time

enumerator kCLOCK_Protection_On

Protected, and could be changed any time

enumerator kCLOCK_Protection_OffLock

No protection and get locked until chip reset

enumerator kCLOCK_Protection_OnLock

Protected and get locked until chip reset

enum _clock_ip_clk_src

List of specific IP's clock source.

Values:

enumerator kCLOCK_IPClkSrc_BusClk

Bus clock

enumerator kCLOCK_IPClkSrc_Bus2xClk

Bus 2x clock

enum _clock_firc_sel

Fast IRC selection.

Values:

enumerator kCLOCK_FircSel_8M

FIRC normal mode, output 8M

enumerator kCLOCK_FircSel_400K
FIRC standby mode, output 400K

enum _clock_postsacle

Mstr 2x clock postsacle divider.

Values:

enumerator kCLOCK_PostscaleDiv1
Mast 2X clock = clkSrc / 1

enumerator kCLOCK_PostscaleDiv2
Mast 2X clock = clkSrc / 2

enumerator kCLOCK_PostscaleDiv4
Mast 2X clock = clkSrc / 4

enumerator kCLOCK_PostscaleDiv8
Mast 2X clock = clkSrc / 8

enumerator kCLOCK_PostscaleDiv16
Mast 2X clock = clkSrc / 16

enumerator kCLOCK_PostscaleDiv32
Mast 2X clock = clkSrc / 32

enumerator kCLOCK_PostscaleDiv64
Mast 2X clock = clkSrc / 64

enumerator kCLOCK_PostscaleDiv128
Mast 2X clock = clkSrc / 128

enumerator kCLOCK_PostscaleDiv256
Mast 2X clock = clkSrc / 256

enum _clock_pll_monitor_type

PLL monitor type structure.

Values:

enumerator kCLOCK_PllMonitorUnLockCoarse
PLL coarse unlock, due to loss of reference clock, power unstable...etc.

enumerator kCLOCK_PllMonitorUnLockFine
PLL fine unlock, due to loss of reference clock, power unstable...etc.

enumerator kCLOCK_PllMonitorLostofReferClk
PLL lost reference clock.

enumerator kCLOCK_PllMonitorAll
All PLL monitor type.

enum _pit_count_clock_source

Describes PIT clock source.

Values:

enumerator kPIT_CountClockSource0
PIT count clock sourced from IP bus clock

enumerator kPIT_CountClockSource1
PIT count clock sourced from alternate clock 1

enumerator kPIT_CountClockSource2

PIT count clock sourced from alternate clock 2

enumerator kPIT_CountClockSource3

PIT count clock sourced from alternate clock 3

enumerator kPIT_CountBusClock

PIT count clock sourced from IP bus clock

enumerator kPIT_CountCrystalClock

PIT count clock sourced from crystal clock

enumerator kPIT_Count8MHzIRCClock

PIT count clock sourced from 8M/400KHz IRC clock

enumerator kPIT_Count32KHzIRCClock

PIT count clock sourced from 32KHz IRC clock

enum _ewm_lpo_clock_source

Describes EWM clock source.

Values:

enumerator kEWM_LpoClockSource0

EWM clock sourced from lpo_clk[0]

enumerator kEWM_LpoClockSource1

EWM clock sourced from lpo_clk[1]

enumerator kEWM_LpoClockSource2

EWM clock sourced from lpo_clk[2]

enumerator kEWM_LpoClockSource3

EWM clock sourced from lpo_clk[3]

enumerator kEWM_Lpo8MHzIRCClock

EWM clock sourced from 8M/400K Hz IRC clock

enumerator kEWM_LpoCrystalClock

EWM clock sourced from crystal clock

enumerator kEWM_LpoBusClock

EWM clock sourced from IP Bus clock

enumerator kEWM_Lpo32KHzIRCClock

EWM clock sourced from 32KHz IRC clock

typedef enum _clock_ip_name clock_ip_name_t

List of IP clock name.

Definition for delay API in clock driver, users can redefine it to the real application.

typedef enum _clock_name clock_name_t

List of system-level clock name.

typedef enum _clock_crystal_osc_mode clock_crystal_osc_mode_t

Crystal oscillator mode.

typedef enum _clock_ext_clk_src clock_ext_clk_src_t

List of external clock source.

typedef enum _clock_ext_clkin_sel clock_ext_clkin_sel_t

List of clock-in source.

```
typedef enum _clock_mstr_osc_clk_src clock_mstr_osc_clk_src_t
```

List of master oscillator source.

```
typedef enum _clock_mstr_2x_clk_src clock_mstr_2x_clk_src_t
```

List of master 2x clock source.

```
typedef enum _clock_output_clk_src clock_output_clk_src_t
```

List of output clock source.

```
typedef enum _clock_output_clk_div clock_output_clk_div_t
```

List of output clock divider.

```
typedef enum _clock_protection clock_protection_t
```

List of clock register protection mode.

```
typedef enum _clock_ip_clk_src clock_ip_clk_src_t
```

List of specific IP's clock source.

```
typedef enum _clock_firc_sel clock_firc_sel_t
```

Fast IRC selection.

```
typedef enum _clock_postscale clock_postscale_t
```

Mstr 2x clock postscale divider.

```
typedef struct _clock_protection_config clock_protection_config_t
```

Clock register protection configuration.

```
typedef struct _clock_output_config clock_output_config_t
```

Clock output configuration.

```
typedef struct _clock_config clock_config_t
```

mcu clock configuration structure.

This is the key configuration structure of clock driver, which define the system clock behavior. The function `CLOCK_SetClkConfig` deploy this configuration structure onto SOC.

```
typedef enum _clock_pll_monitor_type clock_pll_monitor_type_t
```

PLL monitor type structure.

```
typedef enum _pit_count_clock_source pit_count_clock_source_t
```

Describes PIT clock source.

```
typedef enum _ewm_lpo_clock_source ewm_lpo_clock_source_t
```

Describes EWM clock source.

```
static inline void CLOCK_EnableClock(clock_ip_name_t eIpClkName)
```

Enable IPs clock.

Parameters

- eIpClkName – IP clock name.

```
static inline void CLOCK_DisableClock(clock_ip_name_t eIpClkName)
```

Disable IPs clock.

Parameters

- eIpClkName – IP clock name.

```
static inline void CLOCK_EnableClockInStopMode(clock_ip_name_t eIpClkName)
```

Enable IPs clock in STOP mode.

Parameters

- eIpClkName – IP clock name.

```
static inline void CLOCK_DisableClockInStopMode(clock_ip_name_t eIpClkName)
```

Disable IPs clock in STOP mode.

Parameters

- eIpClkName – IP clock name.

```
static inline void CLOCK_ConfigQsciClockSrc(clock_ip_name_t eQsciClkName, clock_ip_clk_src_t  
eClkSrc)
```

Configure QSCI clock source.

QSCI clock could be bus or bus_2x clock. Default is bus clock.

Parameters

- eQsciClkName – IP(only QSCI is valid) clock name.
- eClkSrc – Clock source.

```
static inline bool CLOCK_GetCrystalOscFailureStatus(void)
```

Get crystal oscillator failure status.

Note: This function should be called only when crystal osc is on and its monitor(MON_ENABLE in OSCTL2 register) is enabled.

Returns

Crystal oscillator status. true: Crystal oscillator failure. false: No clock failure or crystal oscillator is off.

```
static inline void CLOCK_SetPllLossOfRefererntTripPoint(uint8_t u8Trip)
```

Set PLL loss of reference trip point.

The trip point default value is 2.

Parameters

- u8Trip – Trip point for loss of reference.

```
static inline void CLOCK_ClearPLLMonitorFlag(clock_pll_monitor_type_t eType)
```

Clear PLL monitor flag.

Parameters

- eType – PLL monitor type.

```
uint32_t CLOCK_GetFreq(clock_name_t eClkName)
```

Get system-level clock frequency.

Parameters

- eClkName – System-level clock name.

Returns

The required clock's frequency in Hz.

```
uint32_t CLOCK_GetIpClkSrcFreq(clock_ip_name_t eIpClkName)
```

Get IP clock frequency.

Parameters

- eIpClkName – IP clock name.

Returns

The required IP clock's frequency in Hz.

void CLOCK_SetClkin0Freq(uint32_t u32Freq)

Set Clock IN 0 frequency.

It is a must to call this function in advance if system is operated by clkin0.

Parameters

- u32Freq – Clock IN 0 frequency in Hz.

void CLOCK_SetClkin1Freq(uint32_t u32Freq)

Set Clock IN 1 frequency.

It is a must to call this function in advance if system is operated by clkin1.

Parameters

- u32Freq – Clock IN 1 frequency in Hz.

void CLOCK_SetXtalFreq(uint32_t u32Freq)

Set crystal oscillator frequency.

It is a must to call this function in advance if system is operated by crystal oscillator.

Parameters

- u32Freq – Crystal oscillator frequency in Hz.

void CLOCK_SetProtectionConfig(*clock_protection_config_t* *psConfig)

Config clock register access protection mode.

Parameters

- psConfig – Pointer for protection configuration.

void CLOCK_SetOutputClockConfig(*clock_output_config_t* *psConfig)

Config output clock.

Parameters

- psConfig – Pointer for clock output configuration.

void CLOCK_SetClkConfig(*clock_config_t* *psConfig)

Config mcu operation clock.

Parameters

- psConfig – Pointer for clock configuration.

uint32_t CLOCK_EvaluateExtClkFreq(void)

Evaluate external clock frequency and return its frequency in Hz.

This function should be called only when internal FIRC(48M) is on. The evaluated result accuracy depends on:

- a. FIRC accuracy, now it is +/-3%.
- b. Truncation error, because the external clock and FIRC is not synchronised.
- c. External clock frequency, low accuracy for lower external clock frequency.
- d. MCU mstr 2x clock.

For example, for namely 8M external clock, evaluated result may be range in 8M+/-8%.

Returns

Evaluated external frequency in Hz.

```
void CLOCK_EnablePLLMonitorInterrupt(clock_pll_monitor_type_t eType, bool bEnable)
```

Enable/Disable PLL monitor interrupt.

This function should be called only when PLL is on and its reference clock is external clock. This function is for safety purpose when external clock is lost due to HW failure. The normal flow to call this function:

- a. Call `CLOCK_SetClkConfig` to enable PLL and external clock to feed the PLL.
- b. Call `CLOCK_ClearPLLMonitorFlag`.
- c. Call `CLOCK_SetPllLossofRefererntTripPoint` (optional, setting value is for `kCLOCK_PllMonitorLostofReferClk` type).
- d. Call this function.
- e. Enable OCCS interrupt with highest priority 3.
- f. When OCCS interrupt occurs, recover clock from the disaster in `OCCS_DriveISRHandler` function. Such kind of clock recovery is application dependent, and a demo `OCCS_DriveISRHandler` has been shown in `fsl_clock.c`

Parameters

- `eType` – PLL monitor type.
- `bEnable` – Enable or disable.

`FSL_CLOCK_DRIVER_VERSION`

CLOCK driver version 2.1.0.

`GPIO_CLOCKS`

Clock ip name array for GPIO.

`TMR_CLOCKS`

Clock ip name array for quad timer.

`FLEXCAN_CLOCKS`

Clock ip name array for FLEXCAN.

`I2C_CLOCKS`

Clock ip name array for I2C.

`QSPI_CLOCKS`

Clock ip name array for queued SPI.

`QSCI_CLOCKS`

Clock ip name array for queued SCI.

`DAC_CLOCKS`

Clock ip name array for DAC.

`DMA_CLOCKS`

Clock ip name array for DMA.

`PDB_CLOCKS`

Clock ip name array for PDB.

`PIT_CLOCKS`

Clock ip name array for PIT.

`QDC_CLOCKS`

Clock ip name array for QDC.

CRC_CLOCKS

Clock ip name array for CRC.

CADC_CLOCKS

Clock ip name array for cyclic ADC.

SARADC_CLOCKS

Clock ip name array for SAR ADC.

CMP_CLOCKS

Clock ip name array for CMP.

PWM_CLOCKS

Clock ip name array for PWM.

COP_CLOCKS

Clock ip name array for COP.

EWM_CLOCKS

Clock ip name array for EWM.

XBARA_CLOCKS

Clock ip name array for XBARA.

CLK_GATE_GET_REG_INDEX(x)

CLK_GATE_GET_BIT_INDEX(x)

clock_protection_t eFrqEP

FRQEP bit field in OCCS PROT register, protect COD & ZSRC.

clock_protection_t eOscEP

OSCEP bit field in OCCS PROT register, protect OSCTL1, OSCTL2, PRECS.

clock_protection_t ePllEP

PLLEP bit field in OCCS PROT register, protect PLLDP, LOCIE, LORTP, PLLDB bitfield.

bool bClkOut0En

Clock output 0 enable, CLKDIS0 bit field in SIM CLKOUT register

bool bClkOut1En

Clock output 1 enable, CLKDIS1 bit field in SIM CLKOUT register

clock_output_clk_src_t eClkOut0Src

Clock output 0 clock source, CLKOSL0 bit field in SIM CLKOUT register

clock_output_clk_src_t eClkOut1Src

Clock output 1 clock source, CLKOSL1 bit field in SIM CLKOUT register

clock_output_clk_div_t eClkDiv

Clock output divider, CLKODIV bit field in SIM CLKOUT register ,it apply to clkout0 & clkout1

bool bCrystalOscEnable

Crystal oscillator enable, COPD bit field in OCCS OSCTL2 register

bool bFircEnable

Fast internal RC oscillator enable, ROPD bit field in OCCS OSCTL1 register

bool bSircEnable

Slow internal RC oscillator enable, ROPD32K bit field in OCCS OSCTL2 register

bool bPllEnable

PLL enable, PLLPD bit field in OCCS CTRL register

bool bCrystalOscMonitorEnable

Crystal oscillator monitor enable, MON_ENABLE bit field in OCCS OSCTL2 register

bool bCrystalFreqDiv2

Crystal oscillator frequency divide 2, prior to output

clock_firc_sel_t eFircSel

Fast IRC mode selection, 8M or 400K, ROSB bit field in OCCS OSCTL1 register

clock_crystal_osc_mode_t eCrystalOscMode

Crystal oscillator mode, COHL bit field in OCCS OSCTL1 register

clock_ext_clk_src_t eExtClkSrc

External clock source, EXT_SEL bit field in OCCS OSCTL1 register

clock_ext_clkin_sel_t eClkInSel

Clock IN selection(0 or 1), CLKINSEL bit field in SIM MISC0 register

clock_mstr_osc_clk_src_t eMstrOscClkSrc

Master oscillator selection, PRECS bit field in OCCS CTRL register. When selected kCLOCK_MstrOscClkSrcExt, make sure corresponding pins(crystal osc or clkin pin) has been configured.

clock_mstr_2x_clk_src_t eMstr2xClkSrc

Master 2x clock selection, ZSRC bit field in OCCS CTRL register

clock_postscale_t eMstr2xClkPostScale

Master 2x clock post scale, COD bit field in OCCS DIVBY register

uint32_t u32PllClkFreq

Required PLL output frequency before divide 2

FSL_SDK_DISABLE_DRIVER_CLOCK_CONTROL

Configure whether driver controls clock.

When set to 0, peripheral drivers will enable clock in initialize function and disable clock in de-initialize function. When set to 1, peripheral driver will not control the clock, application could control the clock out of the driver.

Note: All drivers share this feature switcher. If it is set to 1, application should handle clock enable and disable for all drivers.

struct _clock_protection_config

#include <fsl_clock.h> Clock register protection configuration.

struct _clock_output_config

#include <fsl_clock.h> Clock output configuration.

struct _clock_config

#include <fsl_clock.h> mcu clock configuration structure.

This is the key configuration structure of clock driver, which define the system clock behavior. The function CLOCK_SetClkConfig deploy this configuration structure onto SOC.

2.11 Driver Change Log

2.12 CMP: Comparator Driver

void CMP_GetDefaultConfig(*cmp_config_t* *psConfig)

Initializes the CMP user configuration structure.

This function initializes the user configuration structure to the default values. It is corresponding to the continuous mode configurations.

Parameters

- psConfig – pointer of *cmp_config_t*.

void CMP_Init(CMP_Type *base, const *cmp_config_t* *psConfig)

Initializes the CMP.

This function initializes the CMP module. The operations included are as follows.

- Enable the clock for CMP module.
- Configure the comparator according to the CMP configuration structure.

Parameters

- base – CMP peripheral base address.
- psConfig – Pointer to the configuration structure.

void CMP_Deinit(CMP_Type *base)

De-initializes the CMP module.

This function de-initializes the CMP module. The operations included are as follows.

- Disabling the CMP module.
- Disabling the clock for CMP module.

Parameters

- base – CMP peripheral base address.

static inline void CMP_Enable(CMP_Type *base, bool bEnable)

Enables/disables the CMP module.

Parameters

- base – CMP peripheral base address.
- bEnable – Enables or disables the module.

static inline void CMP_SetInputChannel(CMP_Type *base, *cmp_input_mux_t* ePlusChannel,
cmp_input_mux_t eMinusChannel)

Sets the input channels for the comparator.

This function sets the input channels for the comparator. Note that two input channels cannot be set the same way in the application. When the user selects the same input from the analog mux to the positive and negative port, the comparator is disabled automatically.

Parameters

- base – CMP peripheral base address.
- ePlusChannel – Plus side input channel number.
- eMinusChannel – Minus side input channel number.

static inline void CMP_SelectOutputSource(CMP_Type *base, *cmp_output_source_t*
eOutputSource)

Select comparator output source.

Parameters

- base – CMP peripheral base address.

- `eOutputSource` – The output signal to be set, please reference `cmp_output_source_t` for details.

static inline void `CMP_EnableOutputPin(CMP_Type *base, bool bEnable)`

Enable/Disable Comparator output pin.

Parameters

- `base` – CMP peripheral base address.
- `bEnable` – Enable/Disable comparator output pin. true — CMPO is available on the associate CMPO output pin. false — CMPO is not available on the associate CMPO output pin.

static inline uint8_t `CMP_GetComparatorOutput(CMP_Type *base)`

Get Comparator output.

Parameters

- `base` – CMP peripheral base address.

Return values

current – analog comparator output 0 or 1

static inline void `CMP_SetHysteresisLevel(CMP_Type *base, cmp_hysteresis_level_t eHysteresisLevel)`

Sets hysteresis level.

Parameters

- `base` – CMP peripheral base address.
- `eHysteresisLevel` – The programmable hysteresis level to be set, please refer to `cmp_hysteresis_level_t` for details.

static inline void `CMP_SetComparasionSpeedMode(CMP_Type *base, cmp_comparasion_speed_mode_t eComparatorSpeedMode)`

Sets comparison speed mode.

Parameters

- `base` – CMP peripheral base address.
- `eComparatorSpeedMode` – The comparison speed mode, please reference `cmp_comparasion_speed_mode_t` for details.

static inline void `CMP_EnableInvertOutput(CMP_Type *base, bool bEnable)`

Enable/Disable comparator invert feature.

Parameters

- `base` – CMP peripheral base address.
- `bEnable` – Enable/Disable comparator invert feature. true — Inverts the comparator output. false — Does not invert the comparator output.

static inline void `CMP_EnableWindow(CMP_Type *base, bool bEnable)`

Enable the window function.

Parameters

- `base` – CMP peripheral base address.
- `bEnable` – true is enable, false is disable.

```
static inline void CMP_SetWindowOutputMode(CMP_Type *base, cmp_window_output_mode_t
                                          eWindowOutputMode)
```

Set the window output mode.

Parameters

- base – CMP peripheral base address.
- eWindowOutputMode – cmp_window_output_mode_t.

```
static inline void CMP_EnableExternalSampleMode(CMP_Type *base, bool bEnable)
Enable/Disable external Sample mode.
```

Parameters

- base – CMP peripheral base address.
- bEnable – true is using external sample mode, false is using interface sample mode.

```
static inline void CMP_SetExternalSampleCount(CMP_Type *base, cmp_external_sample_count_t
                                              eSampleCount)
```

Sets external sample count.

Parameters

- base – CMP peripheral base address.
- eSampleCount – The number of consecutive samples that must agree prior to the comparator output filter accepting a new output state, cmp_external_sample_count_t.

```
static inline void CMP_SetInternalFilterCount(CMP_Type *base, cmp_filter_count_t eFilterCount)
Sets internal filter count.
```

Parameters

- base – CMP peripheral base address.
- eFilterCount – The number of consecutive samples that must agree prior to the comparator output filter accepting a new output state, cmp_filter_count_t.

```
static inline void CMP_SetInternalFilterPeriod(CMP_Type *base, uint8_t u8FilterPeriod)
Sets the internal filter period. It is used as the divider to bus clock.
```

Parameters

- base – CMP peripheral base address.
- u8FilterPeriod – Filter Period. The divider to the bus clock. Available range is 0-255.

```
void CMP_SetDACConfig(CMP_Type *base, const cmp_dac_config_t *psConfig)
Configures the internal DAC.
```

Parameters

- base – CMP peripheral base address.
- psConfig – Pointer to the configuration structure.

```
static inline void CMP_SetDACOutputVoltage(CMP_Type *base, uint8_t
                                           u8OutputVoltageDivider)
```

Sets DAC output voltage.

Parameters

- base – CMP peripheral base address.

- `u8OutputVoltageDivider` – The digital value which is related to the desired DAC output voltage,

static inline void `CMP__EnableInternalDAC(CMP_Type *base, bool bEnable)`
Enable/Disable internal DAC.

Parameters

- `base` – CMP peripheral base address.
- `bEnable` – Enable/Disable internal DAC. `true` – Enable internal DAC. `false` – Disable internal DAC.

static inline void `CMP__SetDACReferenceVoltageSource(CMP_Type *base, cmp_dac_vref_source_t eDACVrefSource)`

Sets internal DAC's reference voltage source.

Parameters

- `base` – CMP peripheral base address.
- `eDACVrefSource` – reference voltage source, please `cmp_dac_vref_source_t`

static inline void `CMP__EnableInterrupt(CMP_Type *base, cmp_interrupt_request_t eInterruptRequest)`

Interrupt request to enable.

Parameters

- `base` – CMP peripheral base address.
- `eInterruptRequest` – Mask value for interrupts. See `cmp_interrupt_request_t`.

static inline `cmp_output_flag_t` `CMP__GetStatusFlags(CMP_Type *base)`

Gets the status flags.

Parameters

- `base` – CMP peripheral base address.

Return values

Mask – value for the asserted flags. `cmp_output_flag_t`.

static inline void `CMP__ClearStatusFlags(CMP_Type *base, cmp_output_flag_t eOutputFlag)`

Clears the status flags.

Parameters

- `base` – CMP peripheral base address.
- `eOutputFlag` – Mask value for the output flags, `cmp_output_flag_t`

static inline void `CMP__EnableDMA(CMP_Type *base, cmp_dma_request_t eDMARequestType)`

Enables CMP DMA request.

Parameters

- `base` – CMP peripheral base address.
- `eDMARequestType` – eDMA request type, `cmp_dma_request_t`

static inline uint32_t `CMP__GetComparatorResultRegisterAddress(CMP_Type *base)`

Get CMP result register address for DMA access.

Parameters

- `base` – CMP peripheral base address.

Returns

The CMP result register address.

FSL_CMP_DRIVER_VERSION

CMP driver version.

enum __cmp_interrupt_request

CMP Interrupt request type definition.

Values:

enumerator kCMP_InterruptRequestDisabled
interrupt disabled

enumerator kCMP_InterruptRequestEnableOutputRisingEdge
Comparator interrupt request enable rising edge.

enumerator kCMP_InterruptRequestEnableOutputFallingEdge
Comparator interrupt request enable falling edge.

enumerator kCMP_InterruptRequestEnableAll
comparator interrupt request enable on rising edge or falling edge

enum __cmp_dma_request

CMP DMA request type definition.

Values:

enumerator kCMP_DMAResultRequestDisabled
DMA disabled

enumerator kCMP_DMAResultRequestEnableOutputRisingEdge
Comparator dma request enable on rising edge.

enumerator kCMP_DMAResultRequestEnableOutputFallingEdge
Comparator dnma request enable on falling edge.

enumerator kCMP_DMAResultRequestEnableAll
comparator dma request enable on rising edge or falling edge

enum __cmp_output_flag

CMP output flags' mask.

Values:

enumerator kCMP_OutputFlagRisingEdge
Rising-edge on the comparison output has occurred.

enumerator kCMP_OutputFlagFallingEdge
Falling-edge on the comparison output has occurred.

enumerator kCMP_OutputFlagBothEdge
Rising-edge and Falling-edge on the comparison output has occurred.

enum __cmp_hysteresis_level

CMP Hysteresis level.

Values:

enumerator kCMP_HysteresisLevel0
Hysteresis level 0.

enumerator kCMP_HysteresisLevel1
Hysteresis level 1.

enumerator kCMP_HysteresisLevel2

Hysteresis level 2.

enumerator kCMP_HysteresisLevel3

Hysteresis level 3.

enum _cmp_comparasion_speed_mode

CMP compassion speed mode enumerator.

Values:

enumerator kCMP_ComparsionModeLowSpeed

Low-Speed Comparison mode has lower current consumption

enumerator kCMP_ComparsionModeHighSpeed

High-Speed Comparison mode has higher current consumption.

enum _cmp_dac_vref_source

CMP DAC Voltage Reference source.

Values:

enumerator kCMP_DACVrefSourceVin1

Vin1 is selected as a resistor ladder network supply reference Vin.

enumerator kCMP_DACVrefSourceVin2

Vin2 is selected as a resistor ladder network supply reference Vin.

enum _cmp_window_output_mode

CMP output value of window.

Values:

enumerator kCMP_WindowOuputLastLatchedValue

When WINDOW signal changes from 1 to 0, COUTA output holds the last latched value before WINDOW signal falls to 0

enumerator kCMP_WindowOutputZeroValue

When WINDOW signal changes from 1 to 0, COUTA output is forced to 0

enum _cmp_filter_count

CMP filter count.

Values:

enumerator kCMP_FilterCountDisable

filter is disabled

enumerator kCMP_FilterCount1

1 sample must agrees, the comparator output is simply sampled

enumerator kCMP_FilterCount2

2 consecutive samples must agrees

enumerator kCMP_FilterCount3

3 consecutive samples must agrees

enumerator kCMP_FilterCount4

4 consecutive samples must agrees

enumerator kCMP_FilterCount5

5 consecutive samples must agrees

enumerator kCMP_FilterCount6

6 consecutive samples must agrees

enumerator kCMP_FilterCount7

7 consecutive samples must agrees

enum _cmp_external_sample_count

CMP external sample count.

Values:

enumerator kCMP_ExternalSampleCount1

1 sample must agrees, the comparator output is simply sampled

enumerator kCMP_ExternalSampleCount2

2 consecutive samples must agrees

enumerator kCMP_ExternalSampleCount3

3 consecutive samples must agrees

enumerator kCMP_ExternalSampleCount4

4 consecutive samples must agrees

enumerator kCMP_ExternalSampleCount5

5 consecutive samples must agrees

enumerator kCMP_ExternalSampleCount6

6 consecutive samples must agrees

enumerator kCMP_ExternalSampleCount7

7 consecutive samples must agrees

enum _cmp_output_source

CMP output source enumerator.

Values:

enumerator kCMP_OutputSourceFromFilterCOUT

Set the filtered comparator output to equal COUT.

enumerator kCMP_OutputSourceFromUnfilteredCOUTA

Set the unfiltered comparator output to equal COUTA.

enum _cmp_work_mode

CMP work mode definition.

Values:

enumerator kCMP_WorkModeWindowBypassAndNoExternalSample

window block bypassed, external sampling mode disabled

enumerator kCMP_WorkModeWindowBypassAndExternalSample

window block bypassed, external SAMPLE mode enable

enumerator kCMP_WorkModeWindowEnabledAndNoExternalSample

window block enabled, external sampling mode disabled

typedef enum _cmp_interrupt_request cmp_interrupt_request_t

CMP Interrupt request type definition.

typedef enum _cmp_dma_request cmp_dma_request_t

CMP DMA request type definition.

`typedef enum _cmp_output_flag` `cmp_output_flag_t`
CMP output flags' mask.

`typedef enum _cmp_hysteresis_level` `cmp_hysteresis_level_t`
CMP Hysteresis level.

`typedef enum _cmp_comparasion_speed_mode` `cmp_comparasion_speed_mode_t`
CMP compassion speed mode enumerator.

`typedef enum _cmp_dac_vref_source` `cmp_dac_vref_source_t`
CMP DAC Voltage Reference source.

`typedef enum _cmp_window_output_mode` `cmp_window_output_mode_t`
CMP output value of window.

`typedef enum _cmp_filter_count` `cmp_filter_count_t`
CMP filter count.

`typedef enum _cmp_external_sample_count` `cmp_external_sample_count_t`
CMP external sample count.

`typedef enum _cmp_output_source` `cmp_output_source_t`
CMP output source enumerator.

`typedef enum _cmp_work_mode` `cmp_work_mode_t`
CMP work mode definition.

`typedef struct _cmp_dac_config` `cmp_dac_config_t`
CMP internal DAC configuration structure.

`typedef union _cmp_dma_interrupt_config` `cmp_dma_interrupt_config_t`
CMP dma/interrupt configure union.

Note: , the interrupt request and dma request cannot be used at the same time, that is to say When DMA support is enabled by setting SCR[DMAEN] and the interrupt is enabled by setting SCR[IER], SCR[IEF], or both, the corresponding change on COUT forces a DMA transfer request rather than a CPU interrupt instead

`typedef struct _cmp_config` `cmp_config_t`
CMP configuration structure.

`struct _cmp_dac_config`
`#include <fsl_cmp.h>` CMP internal DAC configuration structure.

Public Members

`cmp_dac_vref_source_t` `eDACVrefSource`
DAC reference voltage source.

`uint8_t` `u8DACOutputVoltageDivider`
divider Value for the DAC Output Voltage, $\text{DAC output voltage} = (\text{VREF} / 256) * (\text{u8DACOutputVoltageDivider} + 1)$.

`bool` `bEnableInternalDAC`
flag to control if the internal DAC need to be enabled

```
union _cmp_dma_interrupt_config
#include <fsl_cmp.h> CMP dma/interrupt configure union.
```

Note: , the interrupt request and dma request cannot be used at the same time, that is to say When DMA support is enabled by setting SCR[DMAEN] and the interrupt is enabled by setting SCR[IER], SCR[IEF], or both, the corresponding change on COUT forces a DMA transfer request rather than a CPU interrupt instead

Public Members

cmp_dma_request_t eDMARequest
dma request type

cmp_interrupt_request_t eInterruptRequest
interrupt request type

```
struct _cmp_config
#include <fsl_cmp.h> CMP configuration structure.
```

Public Members

cmp_hysteresis_level_t eHysteresisLevel
CMP hysteresis level

cmp_comparasion_speed_mode_t eComparasionSpeedMode
CMP comparison speed mode

cmp_work_mode_t eWorkMode
CMP work mode

cmp_input_mux_t ePlusInput
CMP plus input mux, the definition of this enum is in soc header file

cmp_input_mux_t eMinusInput
CMP minus input mux, the definition of this enum is in soc header file

cmp_dac_config_t sDacConfig
CMP internal DAC configuration structure *cmp_dac_config_t*

bool bInvertComparatorOutputPolarity
Inverted comparator output polarity.

cmp_window_output_mode_t eWindowOutputMode
only works when cmp work mode is kCMP_WorkModeWindowEnabledAndNoExternalSample

cmp_filter_count_t eFilterCount
Filter Count.Available range is 0-7, 0 is disable internal filter can be used in internal sampling mode only.

uint8_t u8FilterPeriod
Filter Period. The divider to the bus clock. Available range is 0-255, can be used in internal sampling mode. When the filter clock from internal divided bus clock, setting the sample period to 0 will disable the filter

cmp_external_sample_count_t eExternalSampleCount
Available range is 1 - 7, used in external sampling mode only

cmp_output_source_t eOutputSource

cmp output source

bool bEnableOutputPin

the comparator output(CMPO) is driven out on the associated CMPO output pin

cmp_dma_interrupt_config_t uDmaInterruptConfig

CMP interrupt/dma configuration

bool bCMPEnable

flag to control if CMP module start immediately when the configuration is done

2.13 The Driver Change Log

2.14 CMP Peripheral and Driver Overview

2.15 COP: Computer Operating Properly(Watchdog) Driver

void COP_Init(COP_Type *base, const *cop_config_t* *psConfig)

Initializes the COP module with input configuration.

Call this function to do initialization configuration for COP module. The configurations are:

- COP configuration write protect enablement
- Clock source selection for COP module
- Prescaler configuration to the input clock source
- Counter timeout value
- Window value
- WAIT/STOP work mode enablement
- Interrupt enable/disable and interrupt timing value
- Loss of reference counter enablement
- COP enable/disable

note: Once set bEnableWriteProtect=true, the CTRL, INTVAL, WINDOW and TOUT registers are read-only.

Parameters

- base – COP peripheral base address.
- psConfig – The pointer to COP configuration structure, *cop_config_t*.

void COP_GetDefaultConfig(*cop_config_t* *psConfig)

Prepares an available pre-defined setting for module's configuration.

This function initializes the COP configuration structure to default values.

```
psConfig->bEnableWriteProtect = false;
psConfig->bEnableWait = false;
psConfig->bEnableStop = false;
psConfig->bEnableLossOfReference = false;
psConfig->bEnableInterrupt = false;
psConfig->bEnableCOP = false;
psConfig->ePrescaler = kCOP_ClockPrescalerDivide1;
```

(continues on next page)

(continued from previous page)

```
psConfig->u16TimeoutCount = 0xFFFFU;  
psConfig->u16WindowCount = 0xFFFFU;  
psConfig->u16InterruptCount = 0xFFU;  
psConfig->eClockSource = kCOP_RoscClockSource;
```

Parameters

- psConfig – Pointer to the COP configuration structure, cop_config_t.

static inline void COP_Enable(COP_Type *base, bool bEnable)

Enable/Disable the COP module.

This function disables the COP Watchdog. To disable the COP Watchdog, call COP_Enable(base, false).

Parameters

- base – COP peripheral base address.
- bEnable – Enable the feature or not.

static inline void COP_EnableLossOfReferenceCounter(COP_Type *base, bool bEnable)

Enables or disables the COP Loss of Reference counter.

This function writes a value into the COP_CTRL register to enable or disable the COP Loss of Reference counter.

Parameters

- base – COP peripheral base address.
- bEnable – Enable the feature or not.

static inline void COP_SetTimeoutCount(COP_Type *base, uint16_t u16TimeoutCount)

Sets the COP timeout value.

This function sets the COP timeout value, if psConfig->bEnableWriteProtect is set to true for calling WDOG_Init, the set does not take effect. It should be ensured that the time-out value for the COP is always greater than interrupt time + 40 bus clock cycles. This function writes a value into COP_TOUT register, when COP count down to zero from the timeout count value, COP_RST_B signal will be asserted. There are some considerations for setting the timeout count after COP is enabled:

- The recommended procedure for changing TIMEOUT is to disable the COP by invoking COP_Enable(), then call the function COP_SetTimeoutCount, and then re-enable the by invoking COP_Enable() again.
- Alternatively, call the function COP_SetTimeoutCount, then feed the COP by invoking COP_Refresh() to reload the timeout.

Parameters

- base – COP peripheral base address
- u16TimeoutCount – COP timeout value, count of COP clock tick. Use macro definition MSEC_TO_COUNT to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

static inline void COP_SetInterruptCount(COP_Type *base, uint16_t u16InterruptCount)

Sets the COP interrupt value.

This function sets the COP interrupt value, if psConfig->bEnableWriteProtect is set to true for calling WDOG_Init, the set does not take effect. This function writes a value into COP_INTVAL register, if COP interrupt is enabled and COP count down to the interrupt

value configured, an interrupt will be triggered. Ensure the COP counter is disabled while the function is called.

Parameters

- base – COP peripheral base address
- u16InterruptCount – COP interrupt value, count of COP clock tick. Use macro definition MSEC_TO_COUNT to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

static inline void COP_SetWindowCount(COP_Type *base, uint16_t u16WindowCount)

Sets the COP window value.

This function sets the COP window value, if psConfig->bEnableWriteProtect is set to true for calling WDOG_Init, the set does not take effect. This function writes a value into COP_WINDOW register. Ensure the COP counter is disabled while the function is called.

Parameters

- base – COP peripheral base address
- u16WindowCount – COP window value, count of COP clock tick. Use macro definition MSEC_TO_COUNT to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

void COP_Refresh(COP_Type *base)

Refreshes the COP timer.

This function feeds/services the COP.

Parameters

- base – COP peripheral base address.

static inline void COP_EnableInterrupt(COP_Type *base)

Enables the COP interrupt, if psConfig->bEnableWriteProtect is set to true for calling WDOG_Init, the operation does not take effect.

This function writes a value into the COP_CTRL register to enable the COP interrupt.

Parameters

- base – COP peripheral base address

static inline void COP_DisableInterrupt(COP_Type *base)

Disables the COP interrupt, if psConfig->bEnableWriteProtect is set to true for calling WDOG_Init, the operation does not take effect.

This function writes a value into the COP_CTRL register to disable the COP interrupt.

Parameters

- base – COP peripheral base address

FSL_COP_DRIVER_VERSION

COP driver version.

COP_FIRST_WORD_OF_REFRESH

COP refresh key word.

First word of refresh sequence

COP_SECOND_WORD_OF_REFRESH

Second word of refresh sequence

enum `_cop_clock_source`

enumeration for COP clock source selection.

Values:

enumerator `kCOP_RoscClockSource`

COP clock sourced from Relaxation oscillator (ROSC)

enumerator `kCOP_CoscClockSource`

COP clock sourced from Crystal oscillator (COSC)

enumerator `kCOP_BusClockSource`

COP clock sourced from IP Bus clock

enumerator `kCOP_LpoClockSource`

COP clock sourced from Low speed oscillator

enum `_cop_clock_prescaler`

enumeration for COP clock prescaler to input source clock.

Values:

enumerator `kCOP_ClockPrescalerDivide1`

Divided by 1

enumerator `kCOP_ClockPrescalerDivide16`

Divided by 16

enumerator `kCOP_ClockPrescalerDivide256`

Divided by 256

enumerator `kCOP_ClockPrescalerDivide1024`

Divided by 1024

typedef enum `_cop_clock_source` `cop_clock_source_t`

enumeration for COP clock source selection.

typedef enum `_cop_clock_prescaler` `cop_clock_prescaler_t`

enumeration for COP clock prescaler to input source clock.

typedef struct `_cop_config` `cop_config_t`

structure for COP module initialization configuration.

struct `_cop_config`

#include <fsl_cop.h> structure for COP module initialization configuration.

Public Members

bool `bEnableWriteProtect`

Set COP Write protected

bool `bEnableStop`

Enable or disable COP in STOP mode

bool `bEnableWait`

Enable or disable COP in WAIT mode

bool `bEnableLossOfReference`

Enable or disable COP loss of reference counter

bool `bEnableInterrupt`

Enables or disables COP interrupt

`bool bEnableCOP`

Enables or disables COP module

`cop_clock_source_t eClockSource`

Set COP clock source

`cop_clock_prescaler_t ePrescaler`

Set COP clock prescaler

`uint16_t u16TimeoutCount`

Timeout count in clock cycles, Use macro definition `MSEC_TO_COUNT` to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

`uint16_t u16WindowCount`

Window count in clock cycles, Use macro definition `MSEC_TO_COUNT` to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

`uint16_t u16InterruptCount`

Interrupt count in clock cycles, Use macro definition `MSEC_TO_COUNT` to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

2.16 The Driver Change Log

2.17 COP Peripheral and Driver Overview

2.18 CRC: Cyclic Redundancy Check Driver

`void CRC_Init(CRC_Type *base, const crc_config_t *psConfig)`

Enables and configures the CRC peripheral module.

This function enables the clock gate in the SIM module for the CRC peripheral. It also configures the CRC module and starts a checksum computation by writing the seed.

Parameters

- `base` – CRC peripheral address.
- `psConfig` – CRC module configuration structure.

`void CRC_Deinit(CRC_Type *base)`

Disables the CRC peripheral module.

This function disables the clock gate in the SIM module for the CRC peripheral.

Parameters

- `base` – CRC peripheral address.

`static inline void CRC_GetDefaultConfig(crc_config_t *psConfig, crc_protocol_type_t eCrcProtocol)`

Provide default CRC protocol configuration.

The purpose of this API is to initialize the configuration structure to default value for `CRC_Init` to use. Provides the configuration of commonly used CRC protocols. refer to `crc_protocol_type_t`.

This is an example:

```
crc_config_t sConfig;  
//LoadCRC-16/MAXIM protocol configuration.  
CRC_GetDefaultConfig(&sConfig, kCRC_Crc16);  
CRC_Init(CRC, &sConfig);
```

Parameters

- psConfig – CRC protocol configuration structure.
- eCrcProtocol – CRC protocol type. refer to `crc_protocol_type_t`

static inline void CRC_SetSeedValue(CRC_Type *base, uint32_t u32CrcSeedValue)

Set the CRC seed value.

This function is help to write a 16/32 bit CRC seed value.

Parameters

- base – CRC peripheral address.
- u32CrcSeedValue – The value of seed.

static inline void CRC_SetPolynomial(CRC_Type *base, uint32_t u32CrcPolynomial)

Set the value of the polynomial for the CRC calculation.

Write a 16-bit or 32-bit polynomial to CRC Polynomial register for the CRC calculation.

Parameters

- base – CRC peripheral address.
- u32CrcPolynomial – The CRC polynomial.

static inline void CRC_SetWriteTransposeType(CRC_Type *base, *crc_transpose_type_t*
eTransposeIn)

Set CRC type of transpose of write data.

This function help to configure CRC type of transpose of write data.

Parameters

- base – CRC peripheral address.
- eTransposeIn – Type Of transpose for input. See `crc_transpose_type_t`

static inline void CRC_SetReadTransposeType(CRC_Type *base, *crc_transpose_type_t*
eTransposeOut)

Set CRC type of transpose of read data.

This function help to configure CRC type of transpose of read data.

Parameters

- base – CRC peripheral address.
- eTransposeOut – Type Of transpose for output. See `crc_transpose_type_t`

static inline void CRC_EnableComplementChecksum(CRC_Type *base, bool bEnable)

Enable/Disable complement of read CRC checksum.

Set complement of read CRC checksum. Some CRC protocols require the final checksum to be XORed with 0xFFFFFFFF or 0xFFFF.

Parameters

- base – CRC peripheral address.
- bEnable – True or false. True if the result shall be complement of the actual checksum.

```
static inline void CRC_SetProtocolWidth(CRC_Type *base, crc_bits_t eCrcBits)
```

Set bit width of CRC protocol.

Selects 16-bit or 32-bit CRC protocol.

Parameters

- base – CRC peripheral address.
- eCrcBits – 16 or 32 bit CRC protocol. See `crc_bits_t`

```
void CRC_WriteData(CRC_Type *base, const uint8_t *pu8Data, uint32_t u32DataSize)
```

Writes data to the CRC module.

Writes input data buffer bytes to the CRC data register. The configured type of transpose is applied.

Parameters

- base – CRC peripheral address.
- pu8Data – Input data stream, MSByte in data[0].
- u32DataSize – Size in bytes of the input data buffer.

```
static inline uint32_t CRC_Get32bitResult(CRC_Type *base)
```

Reads the 32-bit checksum from the CRC module.

Reads the CRC data register (either an intermediate or the final checksum). The configured type of transpose and complement is applied.

Parameters

- base – CRC peripheral address.

Returns

An intermediate or the final 32-bit checksum, after transpose and complement operations configured.

```
uint16_t CRC_Get16bitResult(CRC_Type *base)
```

Reads a 16-bit checksum from the CRC module.

Reads the CRC data register (either an intermediate or the final checksum). The configured type of transpose and complement is applied.

Parameters

- base – CRC peripheral address.

Returns

An intermediate or the final 16-bit checksum, after transpose and complement operations configured.

```
FSL_CRC_DRIVER_VERSION
```

CRC driver version. Version.

```
enum _crc_protocol_type
```

CRC protocol type.

Values:

```
enumerator kCRC_Crc16
```

CRC-16/MAXIM protocol.

```
enumerator kCRC_Crc16CCITT
```

CRC-16-CCITT protocol.

enumerator kCRC_Crc16Kermit
CRC-16/KERMIT protocol.

enumerator kCRC_Crc32
CRC-32 protocol.

enumerator kCRC_Crc32Posix
CRC-32/POSIX protocol.

enum __crc_bits
CRC protocol bit width.

Values:

enumerator kCRC_Bits16
Generate 16-bit CRC code.

enumerator kCRC_Bits32
Generate 32-bit CRC code.

enum __crc_transpose_type
CRC type of transpose of read/write data.

Values:

enumerator kCRC_TransposeNone
No transpose.

enumerator kCRC_TransposeBits
Transpose bits in bytes.

enumerator kCRC_TransposeBitsAndBytes
Transpose bytes and bits in bytes.

enumerator kCRC_TransposeBytes
Transpose bytes.

typedef enum __crc_protocol_type crc_protocol_type_t
CRC protocol type.

typedef enum __crc_bits crc_bits_t
CRC protocol bit width.

typedef enum __crc_transpose_type crc_transpose_type_t
CRC type of transpose of read/write data.

typedef struct __crc_config crc_config_t
CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

struct __crc_config
#include <fsl_crc.h> CRC protocol configuration.

This structure holds the configuration for the CRC protocol.

Public Members

uint32_t u32CrcPolynomial

CRC Polynomial, MSBit first. Example polynomial: $0x1021 = 1_0000_0010_0001 = x^{12} + x^5 + 1$

`uint32_t` `u32CrcSeedValue`

Starting checksum value

`bool` `bEnableComplementChecksum`

Enable/Disable complement of read CRC checksum.

`crc_transpose_type_t` `eTransposeIn`

Select type of transpose of input data.

`crc_transpose_type_t` `eTransposeOut`

Select type of transpose of output data.

`crc_bits_t` `eCrcBits`

Select 16-bit or 32-bit CRC protocol.

2.19 The Driver Change Log

2.20 CRC Peripheral and Driver Overview

2.21 DAC: 12-bit Digital-to-Analog Converter Driver

`void` `DAC_Init`(`DAC_Type` *`base`, `const` `dac_config_t` *`psConfig`)

Initializes the DAC resource, including data format, sync signal, operation mode, etc.

Parameters

- `base` – DAC peripheral base address.
- `psConfig` – The pointer to `dac_config_t`.

`void` `DAC_Deinit`(`DAC_Type` *`base`)

De-initializes the DAC resource, the clock and power will be gated off.

Invoking this function to power down the analog portion of DAC and disable the DAC clock.

Parameters

- `base` – DAC peripheral base address.

`void` `DAC_GetDefaultConfig`(`dac_config_t` *`psConfig`)

Gets the default DAC configs, such as operation mode, watermark level, sync signal, etc.

```
psConfig->eOperationMode = kDAC_NormalOperationMode;
psConfig->uOperationConfig.sNormalModeConfig.u16DataFIFO = 0U;
psConfig->bEnableDMA = false;
psConfig->eWatermarkLevel = kDAC_WatermarkValue2;
psConfig->eSyncInputEdge = kDAC_RisingEdge;
psConfig->eSpeedMode = kDAC_HighSpeedMode;
psConfig->eDataFormat = kDAC_DataWordRightJustified;
psConfig->eSyncSignal = kDAC_InternalClockSignal;
psConfig->bEnableAnalogPortion = false;
psConfig->bEnableGlitchFilter = true;
psConfig->u8GlitchFilterCount = 29U;
```

Parameters

- `psConfig` – The pointer to `dac_config_t`.

```
static inline void DAC_SetSyncEdge(DAC_Type *base, dac_sync_input_edge_t eSyncEdge)
```

Selects which SYNC input edge is used for updates, available selections are “no active edge”, “falling edge”, “rising edge”, “both edge”.

Parameters

- base – DAC peripheral base address.
- eSyncEdge – The input edge to be set, please refer to `dac_sync_input_edge_t` for details.

```
static inline void DAC_SetLDOK(DAC_Type *base)
```

Updates the buffered value of `stepSize`, `minValue`, and `maxValue` at the active edge of the SYNC_IN signal.

Note: Allows new values of minimum, maximum, and step value to be updated by active edge of SYNC_IN. This function should be invoked once new values of these buffered registers have been written by software. The LDOK bit will be cleared by an active edge of SYNC_IN.

Note: This function is only useful when the operation mode is selected as Automatic operation mode.

Parameters

- base – DAC peripheral base address.

```
static inline bool DAC_GetLDOKValue(DAC_Type *base)
```

Gets the value of load Okay bit field.

Note: When the SYNC signal is selected as external SYNC_IN signal, the load okay bit will be cleared by an active edge of the SYNC_IN signal. This function can be used to check whether the active edge of the SYNC_IN signal has reached.

Note: This function is only useful when the operation mode is selected as Automatic operation mode.

Parameters

- base – DAC peripheral base address.

Returns

- **true** The active edge of SYNC_IN signal has not reached when the SYNC signal is selected as external SYNC_IN signal.
- **false** The active edge of SYNC_IN signal has reached when the SYNC signal is selected as external SYNC_IN signal

```
static inline void DAC_EnableOneShot(DAC_Type *base, bool bEnable)
```

Enables/Disables Oneshot feature, oneshot feature used to determines whether automatic waveform generation creates one waveform or a repeated waveform within the period defined by the active SYNC edges.

Note: This function only useful when the operation mode is selected as automatic operation mode.

Parameters

- base – DAC peripheral base address.
- bEnable – Enable/Disable oneshot feature.
 - **true** Automatic waveform generation logic will create a single pattern and stop at the final value.
 - **false** Automatic waveform generation logic will create a repeated (continuous) waveform upon receiving an active SYNC edge.

static inline void DAC_WriteDataFIFO(DAC_Type *base, uint16_t u16Data)

Writes DAC buffered data value based on the data format when the DAC is in normal operation mode.

Parameters

- base – DAC peripheral base address.
- u16Data – The DAC data to be converted to analog. If the data format is set as kDAC_DataWordRightJustified then u16Data should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as kDAC_DataWordLeftJustified, then the u16Data should range from 16 to 65520, which means the lower 4 bits is useless.

static inline void DAC_WriteStepSize(DAC_Type *base, uint16_t u16StepSize)

Writes Step size based on the data format when the DAC is in automatic operation mode.

Note: This function only useful when the operation mode is selected as automatic operation mode.

Parameters

- base – DAC peripheral base address.
- u16StepSize – The step value to be added to or subtracted from the current value. If the data format is set as kDAC_DataWordRightJustified then u16StepSize should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as kDAC_DataWordLeftJustified, then the u16StepSize should range from 16 to 65520, which means the lower 4 bits is useless.

static inline void DAC_WriteMinValue(DAC_Type *base, uint16_t u16MinValue)

Writes the minimum value based on the data format when the DAC is in automatic operation mode.

Note: This function only useful when the operation mode is selected as automatic operation mode. If DAC input data is less than the minimum value, output is limited to the minimum value during automatic waveform generation.

Parameters

- base – DAC peripheral base address.

- `u16MinValue` – The lower range limit during automatic waveform generation. If the data format is set as `kDAC_DataWordRightJustified` then `u16MinValue` should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as `kDAC_DataWordLeftJustified`, then the `u16MinValue` should range from 16 to 65520, which means the lower 4 bits is useless.

static inline void DAC_WriteMaxValue(DAC_Type *base, uint16_t u16MaxValue)

Writes the maximum value based on the data format when the DAC is in automatic operation mode.

Note: This function only useful when the operation mode is selected as automatic operation mode. If DAC input data is greater than maximum value, output is limited to maximum value during automatic waveform generation.

Parameters

- `base` – DAC peripheral base address.
- `u16MaxValue` – The upper range limit during automatic waveform generation. If the data format is set as `kDAC_DataWordRightJustified` then `u16MaxValue` should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as `kDAC_DataWordLeftJustified`, then the `u16MaxValue` should range from 16 to 65520, which means the lower 4 bits is useless.

static inline void DAC_ConfigRefreshFrequency(DAC_Type *base, uint16_t u16CompareValue)

Sets refresh frequency that used to decide when the automatically generated waveform value is updated.

Note: This function only useful when the operation mode is selected as automatic operation mode.

Parameters

- `base` – DAC peripheral base address.
- `u16CompareValue` – The compare value(0~65535).
 - **`u16CompareValue=0`** The generated waveform will be updated every clock cycle.
 - **`u16CompareValue=N(N!=0)`** The generated waveform will be updated every N+1 clock cycles.

static inline void DAC_EnableDMA(DAC_Type *base, bool bEnable)

Enables/Disables DMA request that to be generated when the FIFO is below the watermark level.

Note: This function is only useful when the operation mode is selected as Normal mode.

Parameters

- `base` – DAC peripheral base address.
- `bEnable` – Enable/Disable DMA support.
 - **`true`** Enable DMA support.

- **false** Disable DMA support.

```
static inline void DAC_SetWatermarkLevel(DAC_Type *base, dac_watermark_level_t
                                         eWatermarkLevel)
```

Sets watermark level which is used for asserting a DMA request.

Note: When the level of FIFO is less than or equal to the Watermark level, a DMA request will be sent. This function is only useful when the operation mode is selected as Normal mode.

Parameters

- base – DAC peripheral base address.
- eWatermarkLevel – The watermark level of FIFO, please refer to *dac_watermark_level_t* for details.

```
static inline void DAC_EnableGlitchFilter(DAC_Type *base, bool bEnable)
```

Enables/Disables Glitch filter.

Parameters

- base – DAC peripheral base address.
- bEnable – Enable/Disable Glitch filter.
 - **true** Enable glitch filter.
 - **false** Disable glitch filter.

```
static inline void DAC_SetGlitchFilterCount(DAC_Type *base, uint8_t u8FilterCount)
```

Sets glitch filter count value (ranges from 0 to 63) that represents the number of clock cycles for which the DAC output is held unchanged after new data is presented to the analog DAC's inputs.

Parameters

- base – DAC peripheral base address.
- u8FilterCount – The count of glitch filter. This count represents the number of clock cycles for which the DAC output is held unchanged after new data is presented to the analog DAC's inputs.

```
static inline void DAC_SetSpeedMode(DAC_Type *base, dac_speed_mode_t eSpeedMode)
```

Selects speed mode, high speed mode uses more power and low speed mode saves power.

Parameters

- base – DAC peripheral base address.
- eSpeedMode – The speedMode to be set, please refer to *dac_speed_mode_t* for details.

```
static inline void DAC_EnableAnalogPortion(DAC_Type *base, bool bEnable)
```

Enables/Disables the operation of the analog portion of the DAC.

The function controls the power-up of the analog portion of the DAC. If powered up the analog portion, the DAC module will output the value currently presented to the Data register. The analog portion should be powered up when the DAC is in use. If power down the analog portion, the output of the DAC module will be pulled low. The analog portion should be powered down when the DAC is not in use.

Parameters

- base – DAC peripheral base address.

- **bEnable** – Power up/down the analog portion of the DAC.
 - **true** Power up the analog portion of the DAC, and the DAC will output the value currently presented to its inputs.
 - **false** Power down the analog portion of the DAC, and its output will be pulled down.

static inline uint16_t DAC_GetFIFOStatusFlags(DAC_Type *base)

Gets the fifo status flag of selected DAC instance.

Parameters

- **base** – DAC peripheral base address.

Returns

The status flags of DAC module, should be the OR'ed value of `_dac_fifo_status_flags`.

FSL_DAC_DRIVER_VERSION

DAC driver version.

enum _dac_fifo_status_flags

The enumeration of DAC status flags, including FIFO full status flag and FIFO empty status flag.

Values:

enumerator kDAC_FIFOFullStatusFlag

Indicate the FIFO is full.

enumerator kDAC_FIFOEemptyStatusFlag

Indicate the FIFO is empty.

enum _dac_operation_mode

The enumeration of DAC operation mode, including normal operation mode and automatic operation mode.

Values:

enumerator kDAC_NormalOperationMode

Normal Mode to generate an analog representation of digital words.

enumerator kDAC_AutomaticOperationMode

Automatic Mode to generate waveform without requiring CPU or core assistance.

enum _dac_sync_signal_selection

The enumeration of DAC sync signal mode, including internal clock signal and external SYNC_IN signal.

Values:

enumerator kDAC_InternalClockSignal

Internal Clock signal is selected as SYNC signal, data written to the buffered registers is used on the next clock cycle

enumerator kDAC_ExternalSyncInSignal

Peripheral external signal is selected as SYNC signal, the update occurs on the active edge of SYNC_IN signal.

enum _dac_waveform_type

The enumeration of waveform type, such as square waveform, triangle waveform, etc.

Values:

enumerator kDAC_RepeatSawtoothWaveform0

DAC generates repeated sawtooth waveform0. The automatic waveform generation logic will create a repeated sawtooth waveform0 upon receiving an active SYNC edge, and the waveform repeats when it reaches its minimum and maximum value. The waveform increases from starting value to max value firstly. Like this following shown:

**enumerator kDAC_RepeatSawtoothWaveform1**

DAC generates sawtooth waveform1. The automatic waveform generation logic will create a repeated sawtooth waveform1 upon receiving an active SYNC edge, and the waveform repeats when it reaches its minimum and maximum value. The waveform decreases from starting value to min value firstly. Like this following shown:

**enumerator kDAC_RepeatTriangleWaveform0**

The automatic waveform generation logic will create a repeated triangle waveform0 upon receiving an active SYNC edge, and the waveform repeats when it reaches its minimum and maximum value. In this type the generated triangle waveform rises from the starting value. Like this following shown:

**enumerator kDAC_RepeatTriangleWaveform1**

The automatic waveform generation logic will create a repeated triangle waveform1 upon receiving an active SYNC edge, and the waveform repeats when it reaches its minimum and maximum value. In this type the generated triangle waveform drops from the starting value. Like this following shown:

**enumerator kDAC_OneShotSawtoothWaveform0**

Automatic waveform generation logic will create a single pattern and stop at the final value. It will remain at the final value until a new active edge occurs on the SYNC input, and then the waveform will be repeated. Like this following shown:

**enumerator kDAC_OneShotSawtoothWaveform1**

Automatic waveform generation logic will create a single pattern and stop at the final value. It will remain at the final value until a new active edge occurs on the SYNC input, and then the waveform will be repeated. Like this following shown:



enum _dac_sync_input_edge

The enumeration of sync input edge that used for updates buffered registers, such as Falling edge, etc.

Values:

enumerator kDAC_NoActiveEdge

No active edge is selected, it means the SYNC input is ignored.

enumerator kDAC_FallingEdge

Updates occur on the falling edge of the SYNC input.

enumerator kDAC_RisingEdge

Updates occur on the rising edge of the SYNC input.

enumerator kDAC_BothEdges

Updates occur on both edges of the SYNC input.

enum _dac_speed_mode

The enumeration of DAC speed mode, including high speed mode and low speed mode.

Values:

enumerator kDAC_HighSpeedMode

In High Speed Mode, the setting time of the DAC module is 1us, but the DAC module uses more power.

enumerator kDAC_LowSpeedMode

In Low Speed Mode, the DAC module uses less power but takes more time to settle.

enum _dac_watermark_level

The enumeration of FIFO watermark level.

Values:

enumerator kDAC_WatermarkValue0

Watermark value is 0.

enumerator kDAC_WatermarkValue2

Watermark value is 2.

enumerator kDAC_WatermarkValue4

Watermark value is 4.

enumerator kDAC_WatermarkValue6

Watermark value is 6

enum _dac_data_format

The enumeration of DAC data format, including right right-justified and left-justified.

Values:

enumerator kDAC_DataWordRightJustified

The 12 bits data is right-justified.

enumerator kDAC_DataWordLeftJustified

The 12 bits data iss left-justified.

typedef enum *_dac_operation_mode* dac_operation_mode_t

The enumeration of DAC operation mode, including normal operation mode and automatic operation mode.

typedef enum *_dac_sync_signal_selection* dac_sync_signal_selection_t

The enumeration of DAC sync signal mode, including internal clock signal and external SYNC_IN signal.

typedef enum *_dac_waveform_type* dac_waveform_type_t

The enumeration of waveform type, such as square waveform, triangle waveform, etc.

typedef enum *_dac_sync_input_edge* dac_sync_input_edge_t

The enumeration of sync input edge that used for updates buffered registers, such as Falling edge, etc.

typedef enum *_dac_speed_mode* dac_speed_mode_t

The enumeration of DAC speed mode, including high speed mode and low speed mode.

typedef enum *_dac_watermark_level* dac_watermark_level_t

The enumeration of FIFO watermark level.

typedef enum *_dac_data_format* dac_data_format_t

The enumeration of DAC data format, including right right-justified and left-justified.

typedef struct *_dac_normal_mode_config* dac_normal_mode_config_t

The structure of configuration when the operation mode is selected are normal operation mode.

typedef struct *_dac_automatic_mode_config* dac_automatic_mode_config_t

The structure of configuration when the operation mode is selected as automatic operation mode.

typedef union *_dac_operation_config* dac_operation_config_u

The union of operation modes' configuration.

typedef struct *_dac_config* dac_config_t

The structure for configuring the DAC.

This structure is used to config the DAC module, to initialize the DAC module, user must set the member of this structure. This structure will cost 20 Byte memory space.

struct *_dac_normal_mode_config*

#include <fsl_dac.h> The structure of configuration when the operation mode is selected are normal operation mode.

Public Members

bool bEnableDMA

Enable/Disable DMA support.

- **true** Enable DMA support.
- **false** Disable DMA support.

uint16_t u16DataFIFO

The FIFO watermark level, if the level of FIFO is less than or equal to the watermark level field, a DMA request should be sent. The DAC data to be converted to analog. If the data format is set as kDAC_DataWordRightJustified then u16DataFIFO should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as kDAC_DataWordLeftJustified, then the u16DataFIFO should range from 16 to 65520, which means the lower 4 bits is useless.

struct __dac_automatic_mode_config

#include <fsl_dac.h> The structure of configuration when the operation mode is selected as automatic operation mode.

Public Members

dac_waveform_type_t eWaveformType

The type of waveform to be generated.

uint16_t u16MinValue

The step size to be added to or subtracted from the current value. If the data format is set as `kDAC_DataWordRightJustified` then `u16StepSize` should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as `kDAC_DataWordLeftJustified`, then the `u16StepSize` should range from 16 to 65520, which means the lower 4 bits is useless.

The minimum value is the lower range limit during automatic waveform generation. If the data format is set as `kDAC_DataWordRightJustified` then `u16MinValue` should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as `kDAC_DataWordLeftJustified`, then the `u16MinValue` should range from 16 to 65520, which means the lower 4 bits is useless.

uint16_t u16MaxValue

The maximum value is the upper range limit during automatic waveform generation. If the data format is set as `kDAC_DataWordRightJustified` then `u16MaxValue` should range from 0 to 4095, which means the higher 4 bits is useless. If the data format is set as `kDAC_DataWordLeftJustified`, then the `u16MaxValue` should range from 16 to 65520, which means the lower 4 bits is useless.

uint16_t u16StartValue

The start value of the waveform, should larger than the minium value and smaller than the maximum value.

uint16_t u16CompareValue

The compare value that used to decide the frequency of REFRESH signal. The available range is 0 ~ 65535.

- **u16CompareValue=0** The REFRESH signal's frequency is equal to the clock's frequency so that the generated waveform will be updated every clock cycle.
- **u16CompareValue=N(N!=0)** The REFRESH signal's frequency is equal to clock's frequency divided N+1 so that the generated waveform will be updated every N+1 clock cycles

union __dac_operation_config

#include <fsl_dac.h> The union of operation modes' configuration.

Public Members

dac_normal_mode_config_t sNormalModeConfig

The configuration of normal operation mode, such as buffered data, watermark level, etc.

dac_automatic_mode_config_t sAutomaticModeConfig

The configuration of automatic operation mode, such as step size, minimum value, maximum value, etc.

struct `_dac_config`

`#include <fsl_dac.h>` The structure for configuring the DAC.

This structure is used to config the DAC module, to initialize the DAC module, user must set the member of this structure. This structure will cost 20 Byte memory space.

Public Members

`dac_operation_mode_t` `eOperationMode`

The operation mode. The available selections are `kDAC_NormalOperationMode` and `kDAC_AutomaticOperationMode`.

`dac_sync_signal_selection_t` `eSyncSignal`

The selected sync signal that used to update buffered data, the available selections are `kDAC_InternalClockSignal` and `kDAC_ExternalSyncInSignal`

`dac_sync_input_edge_t` `eSyncInputEdge`

The SYNC input edge used to update buffered registers. The buffered value will be updated at the selected active edge of SYNC_IN signal.

`dac_data_format_t` `eDataFormat`

The data format of DAC instance. The available selections are `kDAC_DataWordRightJustified` and `kDAC_DataWordLeftJustified`

`dac_operation_config_u` `uOperationConfig`

The configuration of operation mode.

bool `bEnableGlitchFilter`

Enable/Disable glitch suppression filter.

- **true** Enable glitch filter.
- **false** Disable glitch filter.

uint8_t `u8GlitchFilterCount`

The count(ranges from 0 to 63) represents the number of clock cycles for which the DAC output is held unchanged after new data is presented to the analog DAC's inputs.

`dac_speed_mode_t` `eSpeedMode`

The speed mode of DAC instance. The available selections are `kDAC_HighSpeedMode` and `kDAC_LowSpeedMode`.

bool `bEnableAnalogPortion`

Power up/down the analog portion.

- **true** Power up the analog portion of the DAC, and the DAC will output the value currently presented to its inputs.
- **false** Power down the analog portion of the DAC, and its output will be pulled down.

2.22 The Driver Change Log

2.23 DAC Peripheral and Driver Overview

2.24 DMA: Direct Memory Access Driver

void DMA_Init(DMA_Type *base, *dma_config_t* *psConfig)

DMA initialization.

Parameters

- base – DMA peripheral base address.
- psConfig – pointer to user's DMA configure structure, see *dma_config_t* for detail.

void DMA_Deinit(DMA_Type *base)

DMA De-initialization.

Parameters

- base – DMA peripheral base address.

void DMA_ResetChannel(DMA_Type *base, *dma_channel_t* eChannel)

Resets the DMA channel.

Sets all register values to reset values and enables the cycle steal and auto stop channel request features.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.

void DMA_GetChannelDefaultTransferConfig(*dma_channel_transfer_config_t* *psTransfer, uint32_t u32SrcAddr, uint32_t u32DstAddr, uint32_t u32TotalBytes, *dma_channel_transfer_width_t* eTransferWidth, *dma_channel_transfer_type_t* eTransferType)

Get channel default transfer configuration.

Note: 1. This function will reset all of the configuration structure members to zero firstly, then apply default configurations to the structure.

- a. No interrupt enabled by this function by default, if application would like to use DMA interrupt please enable it manually by `psTransfer->u16EnabledInterruptMask = _dma_channel_interrupt`
-

Parameters

- psTransfer – pointer to user's DMA channel configure structure, see *dma_channel_transfer_config_t* for detail.
- u32SrcAddr – source address, must be byte address.
- u32DstAddr – destination address, must be byte address.
- u32TotalBytes – total bytes to be transferred.
- eTransferWidth – it represents how many bits are transferred in each read/write.
- eTransferType – DMA channel transfer type.

void DMA_SetChannelTransferConfig(DMA_Type *base, *dma_channel_t* eChannel, *dma_channel_transfer_config_t* *psTransfer)

DMA set channel transfer configurations.

Parameters

- base – DMA peripheral base address.

- eChannel – DMA channel number.
- psTransfer – pointer to user's DMA channel configure structure, see `dma_channel_transfer_config_t` for detail.

```
void DMA_SetChannelLinkConfig(DMA_Type *base, dma_channel_t eChannel,  
                             dma_channel_link_config_t *pLinkConfig)
```

Configures the DMA channel link feature.

This function allows DMA channels to have their transfers linked. The current DMA channel triggers a DMA request to the linked channels (LCH1 or LCH2) depending on the channel link type. Perform a link to channel LCH1 after each cycle-steal transfer followed by a link to LCH2 after the BCR decrements to 0 if the type is `kDMA_ChannelLinkChannel1AndChannel2`. Perform a link to LCH1 after each cycle-steal transfer if the type is `kDMA_ChannelLinkChannel1`. Perform a link to LCH1 after the BCR decrements to 0 if the type is `kDMA_ChannelLinkChannel1AfterBCR0`.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.
- pLinkConfig – Pointer to the channel link configuration structure.

```
static inline void DMA_SetChannelSourceAddress(DMA_Type *base, dma_channel_t eChannel,  
                                              uint32_t u32SrcAddr)
```

Sets the DMA source address for the DMA transfer.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.
- u32SrcAddr – DMA source address.

```
static inline void DMA_SetChannelDestinationAddress(DMA_Type *base, dma_channel_t  
                                                  eChannel, uint32_t u32DestAddr)
```

Sets the DMA destination address for the DMA transfer.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.
- u32DestAddr – DMA destination address.

```
static inline void DMA_SetChannelTransferSize(DMA_Type *base, dma_channel_t eChannel,  
                                             uint32_t u32TransferSize)
```

Sets the DMA transfer size for the DMA transfer.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.
- u32TransferSize – The number of bytes to be transferred.

```
void DMA_SetChannelPeripheralRequest(DMA_Type *base, dma_channel_t eChannel,  
                                    dma_channel_request_source_t  
                                    eChannelRequestSource)
```

Sets the DMA transfer peripheral number for the DMA transfer.

Parameters

- base – DMA peripheral base address.

- `eChannel` – DMA channel number.
- `eChannelRequestSource` – The number of request source.

```
void DMA_SetChannelModulo(DMA_Type *base, dma_channel_t eChannel,  
                          dma_channel_modulo_t eSrcModulo, dma_channel_modulo_t  
                          eDestModulo)
```

Sets the source address range and the destination address range for the DMA transfer.

This function defines a specific address range of source/destination address, after the source/destination address hits the range boundary, source/destination address will wrap to origin value.

Setting this field provides the ability to implement a circular data queue easily. For data queues require loop power-of-2 size bytes, the queue should start at a 0-modulo-size address and the SMOD field should be set to the appropriate value for the queue, freezing the desired number of upper address bits. The value programmed into this field specifies the number of lower address bits allowed to change

Parameters

- `base` – DMA peripheral base address.
- `eChannel` – DMA channel number.
- `eSrcModulo` – A source modulo value.
- `eDestModulo` – A destination modulo value.

```
static inline void DMA_EnableChannelCycleSteal(DMA_Type *base, dma_channel_t eChannel,  
                                              bool bEnable)
```

Enables the DMA cycle steal for the DMA transfer.

If the cycle steal feature is enabled (true), the DMA controller forces a single read/write transfer per request, or it continuously makes read/write transfers until the BCR decrements to 0.

Parameters

- `base` – DMA peripheral base address.
- `eChannel` – DMA channel number.
- `bEnable` – The command for enable (true) or disable (false).

```
static inline void DMA_EnableChannelAutoAlign(DMA_Type *base, dma_channel_t eChannel,  
                                             bool bEnable)
```

Enables the DMA auto align for the DMA transfer.

If the auto align feature is enabled (true), the appropriate address register increments regardless of DINC or SINC.

Parameters

- `base` – DMA peripheral base address.
- `eChannel` – DMA channel number.
- `bEnable` – The command for enable (true) or disable (false).

```
static inline void DMA_EnableChannelInterrupt(DMA_Type *base, dma_channel_t eChannel, bool  
                                             bEnable)
```

Enables an interrupt for the DMA transfer.

Parameters

- `base` – DMA peripheral base address.
- `eChannel` – DMA channel number.

- bEnable – The command for enable (true) or disable (false).

```
static inline void DMA__EnableChannelPeripheralRequest(DMA_Type *base, dma_channel_t eChannel, bool bEnable)
```

Enables the DMA hardware channel request.

Parameters

- base – DMA peripheral base address.
- eChannel – The DMA channel number.
- bEnable – The command for enable (true) or disable (false).

```
static inline void DMA__TriggerChannelStart(DMA_Type *base, dma_channel_t eChannel)
```

Starts the DMA transfer with a software trigger.

This function starts only one read/write iteration.

Parameters

- base – DMA peripheral base address.
- eChannel – The DMA channel number.

```
static inline void DMA__EnableChannelAutoStopRequest(DMA_Type *base, dma_channel_t eChannel, bool bEnable)
```

Starts the DMA enable/disable auto disable request.

Parameters

- base – DMA peripheral base address.
- eChannel – The DMA channel number.
- bEnable – true is enable, false is disable.

```
static inline uint32_t DMA__GetChannelRemainingBytes(DMA_Type *base, dma_channel_t eChannel)
```

Gets the remaining bytes of the current DMA transfer.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.

Returns

The number of bytes which have not been transferred yet.

```
static inline uint32_t DMA__GetChannelStatusFlags(DMA_Type *base, dma_channel_t eChannel)
```

Gets the DMA channel status flags.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.

Returns

The mask of the channel status. Use the `_dma_channel_status_flags` type to decode the return 32 bit variables.

```
static inline void DMA__ClearChannelDoneStatus(DMA_Type *base, dma_channel_t eChannel)
```

Clears the DMA channel status flags.

Parameters

- base – DMA peripheral base address.
- eChannel – DMA channel number.

```
void DMA_TransferChannelCreateHandle(DMA_Type *base, dma_handle_t *psHandle,  
                                     dma_channel_t eChannel, dma_transfer_callback_t  
                                     pfCallback, void *pUserData)
```

Creates the DMA handle.

This function is called first if using the transactional API for the DMA. This function initializes the internal state of the DMA handle.

Parameters

- base – DMA peripheral base address.
- psHandle – DMA handle pointer. The DMA handle stores callback function and parameters.
- eChannel – DMA channel number.
- pfCallback – DMA callback function pointer.
- pUserData – A parameter for the callback function.

```
status_t DMA_TransferChannelSubmit(dma_handle_t *psHandle, dma_channel_transfer_config_t  
                                   *psTransfer)
```

Submits the DMA transfer request.

This function submits the DMA transfer request according to the transfer configuration structure.

Note: This function can't process multi transfer request.

Parameters

- psHandle – DMA handle pointer.
- psTransfer – Pointer to DMA transfer configuration structure.

Return values

- kStatus_DMA_Success – It indicates that the DMA submit transfer request succeeded.
- kStatus_DMA_ChannelBusy – It indicates that the DMA is busy. Submit transfer request is not allowed.

```
void DMA_TransferChannelStart(dma_handle_t *psHandle, bool bIsPeripheral)
```

DMA starts transfer.

This function enables the channel request. Call this function after submitting a transfer request.

Parameters

- psHandle – DMA handle pointer.
- bIsPeripheral – For true: enable DMA hardware request peripheral. For false: disable DMA hardware request peripheral.

```
void DMA_TransferChannelStop(dma_handle_t *psHandle)
```

DMA stops a transfer.

This function disables the channel request to stop a DMA transfer. The transfer can be resumed by calling the DMA_StartTransfer.

Parameters

- psHandle – DMA handle pointer.

void DMA_TransferChannelAbort(*dma_handle_t* *psHandle)

DMA aborts transfer.

This function disables the channel request and clear transfer status bits. Users can submit another transfer after calling this API.

Parameters

- psHandle – DMA handle pointer.

void DMA_TransferChannelHandleIRQ(*dma_handle_t* *psHandle)

DMA IRQ handler for current transfer complete.

This function clears the channel interrupt flag and calls the callback function if it is not NULL.

Parameters

- psHandle – DMA handle pointer.

FSL_DMA_DRIVER_VERSION

DMA driver version.

_dma_channeltransfer_status DMA transfer status The enumerator used for transactional interface only.

Values:

enumerator kStatus_DMA_ChannelBusy

Channel is busy and can't handle the transfer request.

enum *_dma_channel_transfer_type*

DMA channel transfer type.

Values:

enumerator kDMA_ChannelTransferMemoryToMemory

Transfer type from memory to memory assume that the both source and destination address are incremental

enumerator kDMA_ChannelTransferPeripheralToMemory

Transfer type peripher to memory assume that the source address is fixed

enumerator kDMA_ChannelTransferMemoryToPeripheral

Transfer type from memory to peripheral assume that the destination address is fixed

enum *_dma_channel_interrupt_enable*

DMA interrupt source .

Values:

enumerator kDMA_ChannelInterruptEnable

Enable interrupt while transfer complete.

enum *_dma_channel_status_flags*

_dma_channel_status_flags DMA channel status flags.

Values:

enumerator kDMA_ChannelTransactionsBCRFlag

Contains the number of bytes yet to be transferred for a given block

enumerator kDMA_ChannelTransactionsDoneFlag

Transactions Done

enumerator kDMA_ChannelTransactionsBusyFlag
Transactions Busy

enumerator kDMA_ChannelTransactionsRequestFlag
Transactions Request

enum _dma_error_status_flags
_dma_error_status_flags DMA channel detail error status flags.

Values:

enumerator kDMA_ChannelConfigurationErrorFlag
Any of the following conditions causes a configuration error: BCR, SAR, or DAR does not match the requested transfer size. SSIZE or DSIZE is set to an unsupported value. BCR equals 0 when the DMA receives a start condition. CE is cleared at hardware reset or by writing a 1 to DONE.

enumerator kDMA_ChannelBusErrorOnSourceFlag
BES is cleared at hardware reset or by writing a 1 to DONE.

enumerator kDMA_ChannelBusErrorOnDestinationFlag
BED is cleared at hardware reset or by writing a 1 to DONE.

enum _dma_channel
DMA channel index.

Values:

enumerator kDMA_Channel0
DMA channel 0

enumerator kDMA_Channel1
DMA channel 1

enumerator kDMA_Channel2
DMA channel 2

enumerator kDMA_Channel3
DMA channel 3

enum _dma_channel_transfer_width
DMA transfer width configuration.

Values:

enumerator kDMA_ChannelTransferWidth32Bits
Source/Destination data transfer width is 4 byte every time

enumerator kDMA_ChannelTransferWidth8Bits
Source/Destination data transfer width is 1 bytes every time

enumerator kDMA_ChannelTransferWidth16Bits
Source/Destination data transfer width is 2 bytes every time

enum _dma_channel_modulo
DMA channel modulo configuration.

The DMA modulo feature can be used to specify the address range of the source/destination address, it is useful to implement a circular data queue.

Values:

enumerator kDMA_ChannelModuloDisable
Disable modulo

enumerator kDMA_ChannelModulo16bytes

Circular buffer size is 16 bytes.

enumerator kDMA_ChannelModulo32bytes

Circular buffer size is 32 bytes.

enumerator kDMA_ChannelModulo64bytes

Circular buffer size is 64 bytes.

enumerator kDMA_ChannelModulo128bytes

Circular buffer size is 128 bytes.

enumerator kDMA_ChannelModulo256bytes

Circular buffer size is 256 bytes.

enumerator kDMA_ChannelModulo512bytes

Circular buffer size is 512 bytes.

enumerator kDMA_ChannelModulo1Kbytes

Circular buffer size is 1 K bytes.

enumerator kDMA_ChannelModulo2Kbytes

Circular buffer size is 2 K bytes.

enumerator kDMA_ChannelModulo4Kbytes

Circular buffer size is 4 K bytes.

enumerator kDMA_ChannelModulo8Kbytes

Circular buffer size is 8 K bytes.

enumerator kDMA_ChannelModulo16Kbytes

Circular buffer size is 16 K bytes.

enumerator kDMA_ChannelModulo32Kbytes

Circular buffer size is 32 K bytes.

enumerator kDMA_ChannelModulo64Kbytes

Circular buffer size is 64 K bytes.

enumerator kDMA_ChannelModulo128Kbytes

Circular buffer size is 128 K bytes.

enumerator kDMA_ChannelModulo256Kbytes

Circular buffer size is 256 K bytes.

enum _dma_channel_link_type

DMA channel link type.

Values:

enumerator kDMA_ChannelLinkDisable

No channel link.

enumerator kDMA_ChannelLinkChannel1AndChannel2

Perform a link to channel LCH1 after each cycle-steal transfer. followed by a link to LCH2 after the BCR decrements to 0.

enumerator kDMA_ChannelLinkChannel1

Perform a link to LCH1 after each cycle-steal transfer.

enumerator kDMA_ChannelLinkChannel1AfterBCR0

Perform a link to LCH1 after the BCR decrements.

enum `_dma_channel_address_increment_type`

DMA transfer address increment definition.

Values:

enumerator `kDMA_ChannelAddressFix`

Address Fix

enumerator `kDMA_ChannelAddressIncrement`

Address increment

typedef enum `_dma_channel_transfer_type` `dma_channel_transfer_type_t`

DMA channel transfer type.

typedef enum `_dma_channel` `dma_channel_t`

DMA channel index.

typedef enum `_dma_channel_transfer_width` `dma_channel_transfer_width_t`

DMA transfer width configuration.

typedef enum `_dma_channel_modulo` `dma_channel_modulo_t`

DMA channel modulo configuration.

The DMA modulo feature can be used to specify the address range of the source/destination address, it is useful to implement a circular data queue.

typedef enum `_dma_channel_link_type` `dma_channel_link_type_t`

DMA channel link type.

typedef struct `_dma_channel_link_config` `dma_channel_link_config_t`

DMA channel link configuration structure.

typedef enum `_dma_channel_address_increment_type` `dma_channel_address_increment_type_t`

DMA transfer address increment definition.

typedef struct `_dma_channel_transfer_config` `dma_channel_transfer_config_t`

DMA channel transfer configuration structure.

The transfer configuration structure support full feature configuration of the transfer control descriptor.

typedef struct `_dma_config` `dma_config_t`

DMA configuration structure.

This structure target for whole dma module configurations.

typedef struct `_dma_handle` `dma_handle_t`

handler for DMA

typedef void (*`dma_transfer_callback_t`)(`dma_handle_t` *`psHandle`, void *`pUserData`)

Define callback function for DMA.

This callback function is called in the DMA interrupt handler function. In normal mode, running into callback function means the transfer users need is done.

Param `psHandle`

DMA handle pointer, users shall not touch the values inside.

Param `pUserData`

The callback user parameter pointer. Users can use this parameter to involve things users need to change in DMA callback function.

struct `_dma_channel_link_config`

`#include <fsl_dma.h>` DMA channel link configuration structure.

Public Members

dma_channel_link_type_t linkType
Channel link type.

dma_channel_t eChannel1
The index of channel 1.

dma_channel_t eChannel2
The index of channel 2.

struct *_dma_channel_transfer_config*

#include <fsl_dma.h> DMA channel transfer configuration structure.

The transfer configuration structure support full feature configuration of the transfer control descriptor.

Public Members

uint32_t u32SrcAddr
source byte address

uint32_t u32DstAddr
destination byte address

dma_channel_transfer_width_t eSrcWidthOfEachTransfer
source width of each transfer

dma_channel_transfer_width_t eDstWidthOfEachTransfer
destination width of each transfer

dma_channel_modulo_t eSrcAddrModulo
Defines the size of the source data circular buffer used by the DMA Controller

dma_channel_modulo_t eDstAddrModulo
defines the size of the destination data circular buffer used by the DMA Controller

dma_channel_address_increment_type_t eEnableSrcIncrement
Source address increase after each transfer

dma_channel_address_increment_type_t eEnableDestIncrement
destination address increase after each transfer

dma_channel_link_config_t *pChannelLinkControl
allows DMA channels to have their transfers linked

uint32_t u32TransferSize
the number of bytes to be transferred

bool bEnableInterrupt
enable interrupt on completion of transfer

bool bEnableAutoAlign
enable the channel auto align

bool bEnableAutoStopPeripheralRequest
DMA hardware automatically clears the corresponding DCRn[ERQ] bit when the byte count register reaches 0.

bool bEnableCycleSteal
enable cycle steal, forces a single read/write transfer per request

struct `_dma_config`

#include <fsl_dma.h> DMA configuration structure.

This structure target for whole dma module configurations.

Public Members

dma_channel_transfer_config_t *psChannelTransferConfig[1]
channel transfer configuration pointer

struct `_dma_handle`

#include <fsl_dma.h> DMA transfer handle structure.

Public Members

dma_transfer_callback_t pfCallback
DMA callback function.

void *pUserData
Callback function parameter.

DMA_Type *psBase
DMA peripheral base address.

dma_channel_t eChannel
DMA channel used.

2.25 The Driver Change Log

2.26 DMA Peripheral and Driver Overview

2.27 The Driver Change Log

2.28 EWM: External Watchdog Monitor Driver

void EWM_Init(EWM_Type *base, const *ewm_config_t* *psConfig)

Initializes the EWM peripheral.

This function is used to initialize the EWM. After calling, the EWM runs immediately according to the configuration.

This is an example.

```
ewm_config_t psConfig;  
EWM_GetDefaultConfig(&psConfig);  
psConfig.compareHighValue = 0xA00U;  
EWM_Init(ewm_base,&psConfig);
```

Note: Except for the interrupt enable control bit, other control bits and registers are write once after a CPU reset. Modifying them more than once generates a bus transfer error.

Parameters

- base – EWM peripheral base address
- psConfig – The configuration of the EWM

void EWM_Deinit(EWM_Type *base)

Deinitializes the EWM peripheral.

This function is used to shut down the EWM.

Parameters

- base – EWM peripheral base address

void EWM_GetDefaultConfig(*ewm_config_t* *psConfig)

Initializes the EWM configuration structure.

This function initializes the EWM configuration structure to default values. The default values are as follows.

```
ewmConfig->bEnableEWM = true;
ewmConfig->bEnableEWMInput = false;
ewmConfig->eInputAssertState = kEWM_EwmInZeroAssert;
ewmConfig->bEnableInterrupt = false;
ewmConfig->eClockSource = kEWM_LpoClockSource0;
ewmConfig->u8ClockDivder = 0;
ewmConfig->u8CompareLowValue = 0;
ewmConfig->u8CompareHighValue = 0xFEU;
```

See also:

`ewm_config_t`

Parameters

- psConfig – Pointer to the EWM configuration structure.

static inline void EWM_EnableInterrupt(EWM_Type *base)

Enables the EWM interrupt.

This function enables the EWM interrupt.

Parameters

- base – EWM peripheral base address

static inline void EWM_DisableInterrupt(EWM_Type *base)

Disables the EWM interrupt.

This function disables the EWM interrupt.

Parameters

- base – EWM peripheral base address

void EWM_Refresh(EWM_Type *base)

Services the EWM.

This function resets the EWM counter to zero.

Parameters

- base – EWM peripheral base address

FSL_EWM_DRIVER_VERSION

EWM driver version.

enum `_ewm_input_assert_state`
Assert pin voltage configuration.
Values:
enumerator `kEWM_EwmInZeroAssert`
EWM-in assert with low-voltage logic
enumerator `kEWM_EwmInOneAssert`
EWM-in assert with high-voltage logic
typedef enum `_ewm_input_assert_state` `ewm_input_assert_state_t`
Assert pin voltage configuration.
typedef struct `_ewm_config` `ewm_config_t`
Data structure for EWM configuration.
This structure is used to configure the EWM.
struct `_ewm_config`
#include <fsl_ewm.h> Data structure for EWM configuration.
This structure is used to configure the EWM.

Public Members

uint8_t `bEnableEWM`
Enable EWM module
uint8_t `bEnableEWMInput`
Enable EWM_in input
uint8_t `bEnableInterrupt`
Enable EWM interrupt
`ewm_input_assert_state_t` `eInputAssertState`
EWM_in signal assertion state select
`ewm_lpo_clock_source_t` `eClockSource`
Clock source select
uint8_t `u8ClockDivder`
EWM counter clock is `clockSource/(clockDivder+1)`
uint8_t `u8CompareLowValue`
Compare low-register value
uint8_t `u8CompareHighValue`
Compare high-register value, maximum setting is 0xFE

2.29 The Driver Change Log

2.30 EWM Peripheral and Driver Overview

2.31 C90TFS Flash Driver

2.32 FlexCAN Driver

```
void FLEXCAN_Init(CAN_Type *base, const flexcan_config_t *psConfig)
```

Initializes a FlexCAN instance with classic / FD mode supported.

This function initializes the FlexCAN module with user-defined settings. User can call the FLEXCAN_GetDefaultConfig function as a starting point for the needed init configuration structure.

Note: If user wants to initialize the peripheral in CAN FD mode, user can call the FLEXCAN_GetFDDefaultConfig to get the flexcan_fd_config_t and assign the address of the data structure to the member psFDConfig of flexcan_config_t

Parameters

- base – FlexCAN peripheral base address.
- psConfig – Pointer to the user-defined configuration structure.

```
void FLEXCAN_Deinit(CAN_Type *base)
```

De-initializes a FlexCAN instance.

This function disables the FlexCAN module clock and sets all register values to the reset value.

Parameters

- base – FlexCAN peripheral base address.

```
void FLEXCAN_GetDefaultConfig(flexcan_config_t *psConfig, uint32_t u32ClkFreqHz)
```

Gets the default configuration structure.

This API does not provide specific classic CAN bit timing configuration values (sTiming-Config), but sets bEnableTimingCalc to true by default, and it will make FLEXCAN_Init() calculate and configure bit timing parameters based on the frequency of the peripheral (u32ClkFreqHz) and classic CAN bit rate (u32BaudRateBps).

```
psConfig->bEnableTimingCalc      = true;
psConfig->u32ClkFreqHz          = u32ClkFreqHz;
psConfig->eClkSrc                = kFLEXCAN_ClkSrc0;
psConfig->u32BaudRateBps        = 500000U;
psConfig->u8MaxMsgBufNum         = 16;
psConfig->bEnableLoopBack        = false;
psConfig->bEnableTimerSync       = true;
psConfig->bEnableSelfWakeup      = false;
psConfig->eWakeupSrc             = kFLEXCAN_WakeupSrcUnfiltered;
psConfig->bEnableIndivMask       = false;
psConfig->bDisableSelfReception  = false;
psConfig->bEnableListenOnlyMode  = false;
psConfig->bEnableDoze            = false;
psConfig->psFDConfig = NULL;
```

Note: By default, CAN FD mode is disabled and not configured.

Parameters

- psConfig – Pointer to the FlexCAN configuration structure.
- u32ClkFreqHz – Flexcan peripheral clock

```
void FLEXCAN_GetFDDefaultConfig(flexcan_config_t *psConfig, flexcan_fd_config_t *psFDConfig)
```

Gets the default configuration structure for Flexcan FD mode.

The function provided the default value of the data structure as code below

```
psConfig->u32BaudRateBps      = 2000000U;  
psConfig->eMsgSize            = kFLEXCAN_64BperMB;  
psConfig->bEnableTxDelayCompensation = true;  
psConfig->bEnableBitRateSwitch  = true;
```

Parameters

- psConfig – Pointer to the FlexCAN configuration structure.
- psFDConfig – Pointer to FD configuration structure.

```
void FLEXCAN_EnterFreezeMode(CAN_Type *base)
```

Enter FlexCAN Freeze Mode.

This function makes the FlexCAN work under Freeze Mode.

Parameters

- base – FlexCAN peripheral base address.

```
void FLEXCAN_ExitFreezeMode(CAN_Type *base)
```

Exit FlexCAN Freeze Mode.

This function makes the FlexCAN leave Freeze Mode.

Parameters

- base – FlexCAN peripheral base address.

```
bool FLEXCAN_CalculateImprovedTimingValuesWithCBT(flexcan_timing_config_t *psTimingConfig, uint32_t u32IdealSp,  
                                                    uint32_t u32BaudRateBps, uint32_t u32SrcClkHz)
```

Calculates the improved timing values by specific baud rates for classical CAN (use CBT register)

Note: The CBT register support 8 ~ 129 time quanta

Parameters

- psTimingConfig – Pointer to the FlexCAN timing configuration structure.
- u32IdealSp – The desired sample point, unit is one thousandth. (like 875, 800, 750).
- u32BaudRateBps – The classical CAN speed in bps defined by user.
- u32SrcClkHz – The Source clock data speed in bps.

Returns

TRUE if timing configuration found, FALSE if failed to find configuration

```
bool FLEXCAN_FDCalculateImprovedTimingValues(flexcan_timing_config_t *psTimingConfig,  
                                              flexcan_timing_config_t *psFDTimingConfig,  
                                              uint32_t u32BaudRateBps, uint32_t u32FDBaudRateBps, uint32_t u32SrcClkHz)
```

Calculates the improved timing values by specific baudrates for CANFD.

Parameters

- psTimingConfig – Pointer to the FlexCAN timing configuration structure.
- psFDTimingConfig – Pointer to the FlexCAN FD timing configuration structure.
- u32BaudRateBps – The CANFD bus control speed in bps defined by user.
- u32FDBaudRateBps – The CANFD bus data speed in bps defined by user.
- u32SrcClkHz – The Source clock data speed in bps.

Returns

TRUE if timing configuration found, FALSE if failed to find configuration

bool FLEXCAN_CalculateImprovedTimingValues(*flexcan_timing_config_t* *psTimingConfig,
uint32_t u32BaudRateBps, uint32_t
u32SrcClkHz)

Calculates the improved timing values by specific baud rates for classical CAN (use CTRL1 register)

Note: The CTRL1 register support 8 ~ 25 time quanta

Parameters

- psTimingConfig – Pointer to the FlexCAN timing configuration structure.
- u32BaudRateBps – The classical CAN speed in bps defined by user.
- u32SrcClkHz – The Source clock data speed in bps.

Returns

TRUE if timing configuration found, FALSE if failed to find configuration

status_t FLEXCAN_SetFDBaudRate(CAN_Type *base, uint32_t u32SrcClkHz, uint32_t
u32BaudRateBps, uint32_t u32FDBaudRateBps)

Set Baud Rate of FlexCAN FD mode.

This function set the baud rate of FlexCAN FD frame.

Parameters

- base – FlexCAN peripheral base address.
- u32SrcClkHz – Source Clock in Hz.
- u32BaudRateBps – Frame Baud Rate in Bps.
- u32FDBaudRateBps – FD frame Baud Rate in Bps.

Return values

- kStatus_Success – Set baud rate success.
- kStatus_Fail – Set baud rate fail.

void FLEXCAN_SetFDTimingConfig(CAN_Type *base, const *flexcan_timing_config_t* *psConfig)

Sets the FlexCAN FD protocol timing characteristic.

This function gives user settings to CAN bus timing characteristic. The function is for an experienced user. For less experienced users, call the FLEXCAN_Init() and fill the baud rate field with a desired value. This provides the default timing characteristics to the module.

Note that calling FLEXCAN_SetFDTimingConfig() overrides the baud rate set in FLEXCAN_Init().

Parameters

- base – FlexCAN peripheral base address.

- psConfig – Pointer to the timing configuration structure.

status_t FLEXCAN_SetBaudRate(CAN_Type *base, uint32_t u32SrcClkHz, uint32_t u32BaudRateBps)

Set Baud Rate of FlexCAN classic mode.

This function calculates the improved timing values base on specific baud rates and sets these values in timing register (CTRL1/CBT).

Parameters

- base – FlexCAN peripheral base address.
- u32SrcClkHz – Source Clock in Hz.
- u32BaudRateBps – Desired classic CAN Baud Rate in Bps.

Return values

- kStatus_Success – Set baud rate success.
- kStatus_Fail – Set baud rate fail.

void FLEXCAN_SetTimingConfig(CAN_Type *base, const *flexcan_timing_config_t* *psConfig)

Sets the FlexCAN protocol timing characteristic.

This function gives user settings to classic CAN timing characteristic. The function is for an experienced user. For less experienced users, call the FLEXCAN_GetDefaultConfig and FLEXCAN_Init() to fill the baud rate field with auto-calculates values (base on the default baud rate). Users also can call FLEXCAN_SetBaudRate() to set auto-calculates timing values base on the desired baud rate.

Note: that calling FLEXCAN_SetTimingConfig() overrides the baud rate set in FLEXCAN_Init() or FLEXCAN_SetBaudRate().

Parameters

- base – FlexCAN peripheral base address.
- psConfig – Pointer to the timing configuration structure.

void FLEXCAN_SetRxMbGlobalMask(CAN_Type *base, uint32_t u32RecMsgBufs)

Sets the FlexCAN receive message buffer global mask.

This function sets the global mask for the FlexCAN message buffer in a matching process. The configuration is only effective when the Rx individual mask is disabled in the FLEXCAN_Init().

Parameters

- base – FlexCAN peripheral base address.
- u32RecMsgBufs – Rx Message Buffer Global Mask value.

void FLEXCAN_SetRxFifoGlobalMask(CAN_Type *base, uint32_t u32RecFifos)

Sets the FlexCAN receive FIFO global mask.

This function sets the global mask for FlexCAN FIFO in a matching process.

Parameters

- base – FlexCAN peripheral base address.
- u32RecFifos – Rx Fifo Global Mask value.

`void FLEXCAN_SetRxIndividualMask(CAN_Type *base, uint8_t u8MaskIdx, uint32_t u32Mask)`

Sets the FlexCAN receive individual mask.

This function sets the individual mask for the FlexCAN matching process. The configuration is only effective when the Rx individual mask is enabled in the `FLEXCAN_Init()`. If the Rx FIFO is disabled, the individual mask is applied to the corresponding Message Buffer. If the Rx FIFO is enabled, the individual mask for Rx FIFO occupied Message Buffer is applied to the Rx Filter with the same index. Note that only the first 32 individual masks can be used as the Rx FIFO filter mask.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MaskIdx` – The Index of individual Mask.
- `u32Mask` – Rx Individual Mask value.

`void FLEXCAN_SetTxMbConfig(CAN_Type *base, uint8_t u8MsgBufIdx, bool bEnable)`

Configures a FlexCAN transmit message buffer.

This function aborts the previous transmission, cleans the Message Buffer, and configures it as a Transmit Message Buffer.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MsgBufIdx` – The Message Buffer index.
- `bEnable` – Enable/disable Tx Message Buffer.
 - `true`: Enable Tx Message Buffer.
 - `false`: Disable Tx Message Buffer.

`void FLEXCAN_SetFDTxMbConfig(CAN_Type *base, uint8_t u8MsgBufIdx, bool bEnable)`

Configures a FlexCAN transmit message buffer.

This function aborts the previous transmission, cleans the Message Buffer, and configures it as a Transmit Message Buffer.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MsgBufIdx` – The Message Buffer index.
- `bEnable` – Enable/disable Tx Message Buffer.
 - `true`: Enable Tx Message Buffer.
 - `false`: Disable Tx Message Buffer.

`void FLEXCAN_SetRxMbConfig(CAN_Type *base, uint8_t u8MsgBufIdx, const
flexcan_rx_mb_config_t *psRxMsgBufConfig, bool bEnable)`

Configures a FlexCAN Receive Message Buffer.

This function cleans a FlexCAN build-in Message Buffer and configures it as a Receive Message Buffer.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MsgBufIdx` – The Message Buffer index.
- `psRxMsgBufConfig` – Pointer to the FlexCAN Message Buffer configuration structure.
- `bEnable` – Enable/disable Rx Message Buffer.

- true: Enable Rx Message Buffer.
- false: Disable Rx Message Buffer.

```
void FLEXCAN_SetFDRxMbConfig(CAN_Type *base, uint8_t u8MsgBufIdx, const  
                             flexcan_rx_mb_config_t *psRxMsgBufConfig, bool bEnable)
```

Configures a FlexCAN Receive Message Buffer.

This function cleans a FlexCAN build-in Message Buffer and configures it as a Receive Message Buffer.

Parameters

- base – FlexCAN peripheral base address.
- u8MsgBufIdx – The Message Buffer index.
- psRxMsgBufConfig – Pointer to the FlexCAN Message Buffer configuration structure.
- bEnable – Enable/disable Rx Message Buffer.
 - true: Enable Rx Message Buffer.
 - false: Disable Rx Message Buffer.

```
void FLEXCAN_SetRxFifoConfig(CAN_Type *base, const flexcan_rx_fifo_config_t  
                             *psRxFifoConfig, bool bEnable)
```

Configures the FlexCAN Rx FIFO.

This function configures the Rx FIFO with given Rx FIFO configuration.

Parameters

- base – FlexCAN peripheral base address.
- psRxFifoConfig – Pointer to the FlexCAN Rx FIFO configuration structure.
- bEnable – Enable/disable Rx FIFO.
 - true: Enable Rx FIFO.
 - false: Disable Rx FIFO.

```
static inline uint32_t FLEXCAN_GetStatusFlags(CAN_Type *base)
```

Gets the FlexCAN module interrupt flags.

This function gets all FlexCAN status flags. The flags are returned as the logical OR value of the enumerators `_flexcan_status_flags`. To check the specific status, compare the return value with enumerators in `_flexcan_status_flags`.

Parameters

- base – FlexCAN peripheral base address.

Returns

FlexCAN status flags which are ORed by the enumerators in the `_flexcan_status_flags`.

```
static inline void FLEXCAN_ClearStatusFlags(CAN_Type *base, uint32_t u32StatusFlags)
```

Clears status flags with the provided mask.

This function clears the FlexCAN status flags with a provided mask. An automatically cleared flag can't be cleared by this function.

Parameters

- base – FlexCAN peripheral base address.
- u32StatusFlags – The status flags to be cleared, it is logical OR value of `_flexcan_status_flags`.

```
static inline void FLEXCAN_GetBusErrCount(CAN_Type *base, uint8_t *pu8TxErrBuf, uint8_t *pu8RxErrBuf)
```

Gets the FlexCAN Bus Error Counter value.

This function gets the FlexCAN Bus Error Counter value for both Tx and Rx direction. These values may be needed in the upper layer error handling.

Parameters

- base – FlexCAN peripheral base address.
- pu8TxErrBuf – Buffer to store Tx Error Counter value.
- pu8RxErrBuf – Buffer to store Rx Error Counter value.

```
static inline uint64_t FLEXCAN_GetMbStatusFlags(CAN_Type *base, uint64_t mask)
```

Gets the FlexCAN Message Buffer interrupt flags.

This function gets the interrupt flags of a given Message Buffers.

Parameters

- base – FlexCAN peripheral base address.
- mask – The ORed FlexCAN Message Buffer mask.

Returns

The status of given Message Buffers.

```
static inline void FLEXCAN_ClearMbStatusFlags(CAN_Type *base, uint64_t mask)
```

Clears the FlexCAN Message Buffer interrupt flags.

This function clears the interrupt flags of a given Message Buffers.

Parameters

- base – FlexCAN peripheral base address.
- mask – The ORed FlexCAN Message Buffer mask.

```
static inline void FLEXCAN_EnableInterrupts(CAN_Type *base, uint32_t u32InterruptFlags)
```

Enables FlexCAN interrupts according to the provided mask.

This function enables the FlexCAN interrupts according to the provided mask. The mask is a logical OR of enumeration members, see `_flexcan_interrupt_enable`.

Parameters

- base – FlexCAN peripheral base address.
- u32InterruptFlags – The interrupts to enable. Logical OR of `_flexcan_interrupt_enable`.

```
static inline void FLEXCAN_DisableInterrupts(CAN_Type *base, uint32_t u32InterruptFlags)
```

Disables FlexCAN interrupts according to the provided mask.

This function disables the FlexCAN interrupts according to the provided mask. The mask is a logical OR of enumeration members, see `_flexcan_interrupt_enable`.

Parameters

- base – FlexCAN peripheral base address.
- u32InterruptFlags – The interrupts to disable. Logical OR of `_flexcan_interrupt_enable`.

```
static inline void FLEXCAN_EnableMbInterrupts(CAN_Type *base, uint64_t mask)
```

Enables FlexCAN Message Buffer interrupts.

This function enables the interrupts of given Message Buffers.

Parameters

- base – FlexCAN peripheral base address.
- mask – The ORed FlexCAN Message Buffer mask.

static inline void FLEXCAN_DisableMbInterrupts(CAN_Type *base, uint64_t mask)

Disables FlexCAN Message Buffer interrupts.

This function disables the interrupts of given Message Buffers.

Parameters

- base – FlexCAN peripheral base address.
- mask – The ORed FlexCAN Message Buffer mask.

void FLEXCAN_EnableRxFifoDMA(CAN_Type *base, bool bEnable)

Enables or disables the FlexCAN Rx FIFO DMA request.

This function enables or disables the DMA feature of FlexCAN build-in Rx FIFO.

Parameters

- base – FlexCAN peripheral base address.
- bEnable – true to enable, false to disable.

static inline uint32_t FLEXCAN_GetRxFifoHeadAddr(CAN_Type *base)

Gets the Rx FIFO Head address.

This function returns the FlexCAN Rx FIFO Head address, which is mainly used for the DMA/eDMA use case.

Parameters

- base – FlexCAN peripheral base address.

Returns

FlexCAN Rx FIFO Head address.

static inline void FLEXCAN_Enable(CAN_Type *base, bool bEnable)

Enables or disables the FlexCAN module operation.

This function enables or disables the FlexCAN module.

Parameters

- base – FlexCAN base pointer.
- bEnable – true to enable, false to disable.

status_t FLEXCAN_WriteTxMb(CAN_Type *base, uint8_t u8MsgBufIdx, const flexcan_frame_t *psTxFrame)

Writes a classic CAN frame to the Transmit Message Buffer.

This function writes a classic CAN frame to the specified Transmit Message Buffer and changes the Message Buffer state to start CAN Message transmit. After that the function returns immediately.

Parameters

- base – FlexCAN peripheral base address.
- u8MsgBufIdx – The FlexCAN Message Buffer index.
- psTxFrame – Pointer to CAN message frame to be sent.

Return values

- kStatus_Success – - Write Tx Message Buffer Successfully.

- `kStatus_Fail` – Tx Message Buffer is currently in use.

`status_t FLEXCAN_ReadRxMb(CAN_Type *base, uint8_t u8MsgBufIdx, flexcan_frame_t *psRxFrame)`

Reads a classic CAN frame from Receive Message Buffer.

This function reads a classic CAN frame from a specified Receive Message Buffer. The function fills a receive CAN message frame structure with just received data and activates the Message Buffer again. The function returns immediately.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MsgBufIdx` – The FlexCAN Message Buffer index.
- `psRxFrame` – Pointer to CAN message frame structure for reception.

Return values

- `kStatus_Success` – Rx Message Buffer is full and has been read successfully.
- `kStatus_FLEXCAN_RxOverflow` – Rx Message Buffer is already overflowed and has been read successfully.
- `kStatus_Fail` – Rx Message Buffer is empty.

`status_t FLEXCAN_ReadRxFifo(CAN_Type *base, flexcan_frame_t *psRxFrame)`

Reads a FlexCAN Message from Rx FIFO.

This function reads a CAN message from the FlexCAN build-in Rx FIFO.

Parameters

- `base` – FlexCAN peripheral base address.
- `psRxFrame` – Pointer to CAN message frame structure for reception.

Return values

- `kStatus_Success` – Read Message from Rx FIFO successfully.
- `kStatus_Fail` – Rx FIFO is not enabled.

`status_t FLEXCAN_WriteFDTxMb(CAN_Type *base, uint8_t u8MsgBufIdx, const flexcan_fd_frame_t *psTxFrame)`

Writes a CAN frame to the Transmit Message Buffer.

This function writes a CAN FD frame or classic CAN frame to the specified Transmit Message Buffer and changes the Message Buffer state to start CAN FD Message transmit. After that the function returns immediately.

Parameters

- `base` – FlexCAN peripheral base address.
- `u8MsgBufIdx` – The FlexCAN FD Message Buffer index.
- `psTxFrame` – Pointer to CAN FD message frame to be sent.

Return values

- `kStatus_Success` – Write Tx Message Buffer Successfully.
- `kStatus_Fail` – Tx Message Buffer is currently in use.

`status_t FLEXCAN_ReadFDRxMb(CAN_Type *base, uint8_t u8MsgBufIdx, flexcan_fd_frame_t *psRxFrame)`

Reads a CAN frame from Receive Message Buffer.

This function reads a CAN FD frame or classic CAN frame from a specified Receive Message Buffer. The function fills a receive CAN FD message frame structure with just received data and activates the Message Buffer again. The function returns immediately.

Parameters

- base – FlexCAN peripheral base address.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.
- psRxFrame – Pointer to CAN FD message frame structure for reception.

Return values

- kStatus_Success -- Rx Message Buffer is full and has been read successfully.
- kStatus_FLEXCAN_RxOverflow -- Rx Message Buffer is already overflowed and has been read successfully.
- kStatus_Fail -- Rx Message Buffer is empty.

status_t FLEXCAN_TransferSendBlocking(CAN_Type *base, uint8_t u8MsgBufIdx, *flexcan_frame_t* *psTxFrame)

Performs a polling send transaction on the CAN bus.

Note that a transfer handle does not need to be created before calling this API.

Parameters

- base – FlexCAN peripheral base pointer.
- u8MsgBufIdx – The FlexCAN Message Buffer index.
- psTxFrame – Pointer to CAN message frame to be sent.

Return values

- kStatus_Success -- Write Tx Message Buffer Successfully.
- kStatus_Fail -- Tx Message Buffer is currently in use.

status_t FLEXCAN_TransferReceiveBlocking(CAN_Type *base, uint8_t u8MsgBufIdx, *flexcan_frame_t* *psRxFrame)

Performs a polling receive transaction on the CAN bus.

Note that a transfer handle does not need to be created before calling this API.

Parameters

- base – FlexCAN peripheral base pointer.
- u8MsgBufIdx – The FlexCAN Message Buffer index.
- psRxFrame – Pointer to CAN message frame structure for reception.

Return values

- kStatus_Success -- Rx Message Buffer is full and has been read successfully.
- kStatus_FLEXCAN_RxOverflow -- Rx Message Buffer is already overflowed and has been read successfully.
- kStatus_Fail -- Rx Message Buffer is empty.

status_t FLEXCAN_TransferReceiveFifoBlocking(CAN_Type *base, *flexcan_frame_t* *psRxFrame)

Performs a polling receive transaction from Rx FIFO on the CAN bus.

Note that a transfer handle does not need to be created before calling this API.

Parameters

- base – FlexCAN peripheral base pointer.

- psRxFrame – Pointer to CAN message frame structure for reception.

Return values

- kStatus_Success – Read Message from Rx FIFO successfully.
- kStatus_Fail – Rx FIFO is not enabled.

status_t FLEXCAN_TransferFDSendBlocking(CAN_Type *base, uint8_t u8MsgBufIdx, *flexcan_fd_frame_t* *psTxFrame)

Performs a polling send transaction on the CAN bus.

Note that a transfer handle does not need to be created before calling this API.

Parameters

- base – FlexCAN peripheral base pointer.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.
- psTxFrame – Pointer to CAN FD message frame to be sent.

Return values

- kStatus_Success – Write Tx Message Buffer Successfully.
- kStatus_Fail – Tx Message Buffer is currently in use.

status_t FLEXCAN_TransferFDReceiveBlocking(CAN_Type *base, uint8_t u8MsgBufIdx, *flexcan_fd_frame_t* *psRxFrame)

Performs a polling receive transaction on the CAN bus.

Note that a transfer handle does not need to be created before calling this API.

Parameters

- base – FlexCAN peripheral base pointer.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.
- psRxFrame – Pointer to CAN FD message frame structure for reception.

Return values

- kStatus_Success – Rx Message Buffer is full and has been read successfully.
- kStatus_FLEXCAN_RxOverflow – Rx Message Buffer is already overflowed and has been read successfully.
- kStatus_Fail – Rx Message Buffer is empty.

void FLEXCAN_TransferCreateHandle(CAN_Type *base, *flexcan_handle_t* *psHandle, *flexcan_transfer_callback_t* pfCallback, void *pUserData)

Initializes the FlexCAN handle.

This function initializes the FlexCAN handle, which can be used for other FlexCAN transactional APIs. Usually, for a specified FlexCAN instance, call this API once to get the initialized handle.

Parameters

- base – FlexCAN peripheral base address.
- psHandle – FlexCAN handle pointer.
- pfCallback – The callback function.
- pUserData – The parameter of the callback function.

status_t FLEXCAN_TransferSendNonBlocking(*flexcan_handle_t* *psHandle, *flexcan_mb_transfer_t* *psMsgBufXfer)

Sends a message using IRQ.

This function sends a message using IRQ. This is a non-blocking function, which returns right away. When messages have been sent out, the send callback function is called.

Parameters

- psHandle – FlexCAN handle pointer.
- psMsgBufXfer – FlexCAN Message Buffer transfer structure. See the *flexcan_mb_transfer_t*.

Return values

- kStatus_Success – Start Tx Message Buffer sending process successfully.
- kStatus_Fail – Write Tx Message Buffer failed.
- kStatus_FLEXCAN_TxBusy – Tx Message Buffer is in use.

status_t FLEXCAN_TransferReceiveNonBlocking(*flexcan_handle_t* *psHandle, *flexcan_mb_transfer_t* *psMsgBufXfer)

Receives a message using IRQ.

This function receives a message using IRQ. This is non-blocking function, which returns right away. When the message has been received, the receive callback function is called.

Parameters

- psHandle – FlexCAN handle pointer.
- psMsgBufXfer – FlexCAN Message Buffer transfer structure. See the *flexcan_mb_transfer_t*.

Return values

- kStatus_Success – - Start Rx Message Buffer receiving process successfully.
- kStatus_FLEXCAN_RxBusy – - Rx Message Buffer is in use.

status_t FLEXCAN_TransferReceiveFifoNonBlocking(*flexcan_handle_t* *psHandle, *flexcan_fifo_transfer_t* *psFifoXfer)

Receives a message from Rx FIFO using IRQ.

This function receives a message using IRQ. This is a non-blocking function, which returns right away. When all messages have been received, the receive callback function is called.

Parameters

- psHandle – FlexCAN handle pointer.
- psFifoXfer – FlexCAN Rx FIFO transfer structure. See the *flexcan_fifo_transfer_t*.

Return values

- kStatus_Success – - Start Rx FIFO receiving process successfully.
- kStatus_FLEXCAN_RxFifoBusy – - Rx FIFO is currently in use.

uint32_t FLEXCAN_GetTimeStamp(*flexcan_handle_t* *psHandle, *uint8_t* u8MsgBufIdx)

Gets the detail index of Mailbox's Timestamp by handle.

Then function can only be used when calling non-blocking Data transfer (TX/RX) API, After TX/RX data transfer done (User can get the status by handler's callback function), we can get the detail index of Mailbox's timestamp by handle, Detail non-blocking data transfer API (TX/RX) contain. -FLEXCAN_TransferSendNonBlocking

-FLEXCAN_TransferFDSendNonBlocking -FLEXCAN_TransferReceiveNonBlocking -
FLEXCAN_TransferFDReceiveNonBlocking -FLEXCAN_TransferReceiveFifoNonBlocking

Parameters

- psHandle – FlexCAN handle pointer.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.

Return values

the – index of mailbox 's timestamp stored in the handle.

void FLEXCAN_TransferAbortSend(*flexcan_handle_t* *psHandle, uint8_t u8MsgBufIdx)

Aborts the interrupt driven message send process.

This function aborts the interrupt driven message send process.

Parameters

- psHandle – FlexCAN handle pointer.
- u8MsgBufIdx – The FlexCAN Message Buffer index.

void FLEXCAN_TransferAbortReceive(*flexcan_handle_t* *psHandle, uint8_t u8MsgBufIdx)

Aborts the interrupt driven message receive process.

This function aborts the interrupt driven message receive process.

Parameters

- psHandle – FlexCAN handle pointer.
- u8MsgBufIdx – The FlexCAN Message Buffer index.

void FLEXCAN_TransferAbortReceiveFifo(*flexcan_handle_t* *psHandle)

Aborts the interrupt driven message receive from Rx FIFO process.

This function aborts the interrupt driven message receive from Rx FIFO process.

Parameters

- psHandle – FlexCAN handle pointer.

void FLEXCAN_TransferHandleIRQ(*flexcan_handle_t* *psHandle)

FlexCAN IRQ handle function.

This function handles the FlexCAN Error, the Message Buffer, and the Rx FIFO IRQ request.

Parameters

- psHandle – FlexCAN handle pointer.

status_t FLEXCAN_TransferFDSendNonBlocking(*flexcan_handle_t* *psHandle,
flexcan_mb_transfer_t *psMsgBufXfer)

Sends a message using IRQ.

This function sends a message (classic CAN frame or CAN FD frame) using IRQ. This is a non-blocking function, which returns right away. When messages have been sent out, the send callback function is called.

Parameters

- psHandle – FlexCAN handle pointer.
- psMsgBufXfer – FlexCAN FD Message Buffer transfer structure. See the flexcan_mb_transfer_t.

Return values

- kStatus_Success – Start Tx Message Buffer sending process successfully.
- kStatus_Fail – Write Tx Message Buffer failed.

- kStatus_FLEXCAN_TxBusy – Tx Message Buffer is in use.

status_t FLEXCAN_TransferFDReceiveNonBlocking(*flexcan_handle_t* *psHandle,
flexcan_mb_transfer_t *psMsgBufXfer)

Receives a message using IRQ.

This function receives a message using IRQ. This is non-blocking function, which returns right away. When the message has been received, the receive callback function is called.

Parameters

- psHandle – FlexCAN handle pointer.
- psMsgBufXfer – FlexCAN FD Message Buffer transfer structure. See the *flexcan_mb_transfer_t*.

Return values

- kStatus_Success – - Start Rx Message Buffer receiving process successfully.
- kStatus_FLEXCAN_RxBusy – - Rx Message Buffer is in use.

void FLEXCAN_TransferFDAbortSend(*flexcan_handle_t* *psHandle, *uint8_t* u8MsgBufIdx)

Aborts the interrupt driven message send process.

This function aborts the interrupt driven message send process.

Parameters

- psHandle – FlexCAN handle pointer.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.

void FLEXCAN_TransferFDAbortReceive(*flexcan_handle_t* *psHandle, *uint8_t* u8MsgBufIdx)

Aborts the interrupt driven message receive process.

This function aborts the interrupt driven message receive process.

Parameters

- psHandle – FlexCAN handle pointer.
- u8MsgBufIdx – The FlexCAN FD Message Buffer index.

FSL_FLEXCAN_DRIVER_VERSION

FlexCAN driver version.

FlexCAN transfer status codes, used by bus operation APIs and transactional APIs as return value to indicate the current status as the API's execution result, or used in the callback to indicate transfer results.

Values:

enumerator kStatus_FLEXCAN_TxBusy
Tx Message Buffer is Busy.

enumerator kStatus_FLEXCAN_TxIdle
Tx Message Buffer is Idle.

enumerator kStatus_FLEXCAN_TxSwitchToRx
Remote Message is send out and Message buffer changed to Receive one.

enumerator kStatus_FLEXCAN_RxBusy
Rx Message Buffer is Busy.

enumerator kStatus_FLEXCAN_RxIdle
Rx Message Buffer is Idle.

enumerator kStatus_FLEXCAN_RxOverflow
Rx Message Buffer is Overflowed.

enumerator kStatus_FLEXCAN_RxFifoBusy
Rx Message FIFO is Busy.

enumerator kStatus_FLEXCAN_RxFifoIdle
Rx Message FIFO is Idle.

enumerator kStatus_FLEXCAN_RxFifoOverflow
Rx Message FIFO is overflowed.

enumerator kStatus_FLEXCAN_RxFifoWarning
Rx Message FIFO is almost overflowed.

enumerator kStatus_FLEXCAN_ErrorStatus
FlexCAN Module Error and Status.

enumerator kStatus_FLEXCAN_WakeUp
FlexCAN is waken up from STOP mode.

enumerator kStatus_FLEXCAN_UnHandled
UnHandled Interrupt asserted.

enumerator kStatus_FLEXCAN_RxRemote
Rx Remote Message Received in Mail box.

enum _flexcan_frame_format
FlexCAN frame format.

Values:

enumerator kFLEXCAN_FrameFormatStandard
Standard frame format attribute.

enumerator kFLEXCAN_FrameFormatExtend
Extend frame format attribute.

enum _flexcan_frame_type
FlexCAN frame type.

Values:

enumerator kFLEXCAN_FrameTypeData
Data frame type attribute.

enumerator kFLEXCAN_FrameTypeRemote
Remote frame type attribute.

enum _flexcan_clock_source
FlexCAN clock source.

Note: The user must ensure the protocol engine clock tolerance according to the CAN Protocol standard (ISO 11898-1).

Values:

enumerator kFLEXCAN_ClkSrc0
FlexCAN Protocol Engine clock selected by user as SRC == 0.

enumerator kFLEXCAN_ClkSrc1
FlexCAN Protocol Engine clock selected by user as SRC == 1.

enum _flexcan_wake_up_source

FlexCAN wake up source.

Values:

enumerator kFLEXCAN_WakeupSrcUnfiltered

FlexCAN uses unfiltered Rx input to detect edge.

enumerator kFLEXCAN_WakeupSrcFiltered

FlexCAN uses filtered Rx input to detect edge.

enum _flexcan_rx_fifo_filter_type

FlexCAN Rx Fifo Filter type.

Values:

enumerator kFLEXCAN_RxFifoFilterTypeA

One full ID (standard and extended) per ID Filter element.

enumerator kFLEXCAN_RxFifoFilterTypeB

Two full standard IDs or two partial 14-bit ID slices per ID Filter Table element.

enumerator kFLEXCAN_RxFifoFilterTypeC

Four partial 8-bit Standard or extended ID slices per ID Filter Table element.

enumerator kFLEXCAN_RxFifoFilterTypeD

All frames rejected.

enum _flexcan_mb_size

FlexCAN Message Buffer Data Size.

Values:

enumerator kFLEXCAN_8BperMB

Selects 8 bytes per Message Buffer.

enumerator kFLEXCAN_16BperMB

Selects 16 bytes per Message Buffer.

enumerator kFLEXCAN_32BperMB

Selects 32 bytes per Message Buffer.

enumerator kFLEXCAN_64BperMB

Selects 64 bytes per Message Buffer.

enum _flexcan_rx_fifo_priority

FlexCAN Rx FIFO priority.

The matching process starts from the Rx MB(or Rx FIFO) with higher priority. If no MB(or Rx FIFO filter) is satisfied, the matching process goes on with the Rx FIFO(or Rx MB) with lower priority.

Values:

enumerator kFLEXCAN_RxFifoPriorityLow

Matching process start from Rx Message Buffer first.

enumerator kFLEXCAN_RxFifoPriorityHigh

Matching process start from Rx FIFO first.

enum _flexcan_interrupt_enable

FlexCAN interrupt configuration structure, default settings all disabled.

This structure contains the settings for all of the FlexCAN Module interrupt configurations.

Note: FlexCAN Message Buffers and Rx FIFO have their own interrupts.

Values:

enumerator kFLEXCAN_BusOffInterruptEnable

Bus Off interrupt.

enumerator kFLEXCAN_ErrorInterruptEnable

Error interrupt.

enumerator kFLEXCAN_RxWarningInterruptEnable

Rx Warning interrupt.

enumerator kFLEXCAN_TxWarningInterruptEnable

Tx Warning interrupt.

enumerator kFLEXCAN_WakeUpInterruptEnable

Wake Up interrupt.

enumerator kFLEXCAN_AllInterruptEnable

enum _flexcan_status_flags

FlexCAN status flags.

This provides constants for the FlexCAN status flags for use in the FlexCAN functions. Note: The CPU read action will clear all error flag in kFLEXCAN_ErrorFlag.

Values:

enumerator kFLEXCAN_FDStuffingError

Stuffing Error.

enumerator kFLEXCAN_FDFormError

Form Error.

enumerator kFLEXCAN_FDCrcError

Cyclic Redundancy Check Error.

enumerator kFLEXCAN_FDBit0Error

Unable to send dominant bit.

enumerator kFLEXCAN_FDBit1Error

Unable to send recessive bit.

enumerator kFLEXCAN_StuffingError

Stuffing Error.

enumerator kFLEXCAN_FormError

Form Error.

enumerator kFLEXCAN_CrcError

Cyclic Redundancy Check Error.

enumerator kFLEXCAN_AckError

Received no ACK on transmission.

enumerator kFLEXCAN_Bit0Error

Unable to send dominant bit.

enumerator kFLEXCAN_Bit1Error

Unable to send recessive bit.

enumerator kFLEXCAN_ErrorFlag

All FlexCAN read clear Error Status.

enumerator kFLEXCAN_FDErrorIntFlag
FD frames Error Interrupt Flag.

enumerator kFLEXCAN_BusoffDoneIntFlag
Bus Off Done Interrupt Flag.

enumerator kFLEXCAN_OverrunError
Error Overrun Status.

enumerator kFLEXCAN_TxWarningIntFlag
Tx Warning Interrupt Flag.

enumerator kFLEXCAN_RxWarningIntFlag
Rx Warning Interrupt Flag.

enumerator kFLEXCAN_BusOffIntFlag
Bus Off Interrupt Flag.

enumerator kFLEXCAN_ErrorIntFlag
Error Interrupt Flag.

enumerator kFLEXCAN_WakeUpIntFlag
Wake-Up Interrupt Flag.

enumerator kFLEXCAN_SynchFlag
CAN Synchronization Status Flag.

enumerator kFLEXCAN_TxErrorWarningFlag
Tx Error Warning Status Flag.

enumerator kFLEXCAN_RxErrorWarningFlag
Rx Error Warning Status Flag.

enumerator kFLEXCAN_IdleFlag
CAN IDLE Status Flag.

enumerator kFLEXCAN_FaultConfinementFlag
Fault Confinement Status Flag.

enumerator kFLEXCAN_TransmittingFlag
FlexCAN In Transmission Status Flag.

enumerator kFLEXCAN_ReceivingFlag
FlexCAN In Reception Status Flag.

enumerator kFLEXCAN_StatusAllFlags
All status/interrupt flags which are write clearable.

enum _flexcan_mb_flags

FlexCAN Rx FIFO status flags.

The FlexCAN Rx FIFO Status enumerations are used to determine the status of the Rx FIFO. Because Rx FIFO occupy the MB0 ~ MB7 (Rx Fifo filter also occupies more Message Buffer space), Rx FIFO status flags are mapped to the corresponding Message Buffer status flags.

Values:

enumerator kFLEXCAN_RxFifoOverflowFlag
Rx FIFO overflow flag.

enumerator kFLEXCAN_RxFifoWarningFlag
Rx FIFO almost full flag.

enumerator `kFLEXCAN_RxFifoFrameAvlFlag`

Frames available in Rx FIFO flag.

typedef enum *flexcan_frame_format* flexcan__frame__format__t
FlexCAN frame format.

typedef enum *flexcan_frame_type* flexcan__frame__type__t
FlexCAN frame type.

typedef enum *flexcan_clock_source* flexcan__clock__source__t
FlexCAN clock source.

Note: The user must ensure the protocol engine clock tolerance according to the CAN Protocol standard (ISO 11898-1).

typedef enum *flexcan_wake_up_source* flexcan__wake__up__source__t
FlexCAN wake up source.

typedef enum *flexcan_rx_fifo_filter_type* flexcan__rx__fifo__filter__type__t
FlexCAN Rx Fifo Filter type.

typedef enum *flexcan_mb_size* flexcan__mb__size__t
FlexCAN Message Buffer Data Size.

typedef enum *flexcan_rx_fifo_priority* flexcan__rx__fifo__priority__t
FlexCAN Rx FIFO priority.

The matching process starts from the Rx MB(or Rx FIFO) with higher priority. If no MB(or Rx FIFO filter) is satisfied, the matching process goes on with the Rx FIFO(or Rx MB) with lower priority.

typedef struct *flexcan_frame* flexcan__frame__t
FlexCAN message frame structure.

typedef struct *flexcan_fd_frame* flexcan__fd__frame__t
CAN FD message frame structure.

Note: This structure can contain a CAN FD frame (bitEdl equal 1) or classic CAN frame (bitEdl equal 0).

typedef struct *flexcan_timing_config* flexcan__timing__config__t
FlexCAN protocol timing characteristic configuration structure.

typedef struct *flexcan_fd_config* flexcan__fd__config__t
Configuration for the Flexcan CAN FD mode. It only cover FD related parts.

It is used as member of `flexcan_config_t` to do the CAN FD specific init on init this peripheral.

typedef struct *flexcan_config* flexcan__config__t
FlexCAN module configuration structure.

typedef struct *flexcan_rx_mb_config* flexcan__rx__mb__config__t
FlexCAN Receive Message Buffer configuration structure.

This structure is used as the parameter of `FLEXCAN_SetRxMbConfig()` function. The `FLEXCAN_SetRxMbConfig()` function is used to configure FlexCAN Receive Message Buffer. The function abort previous receiving process, clean the Message Buffer and activate the Rx Message Buffer using given Message Buffer setting.

`typedef struct _flexcan_rx_fifo_config flexcan_rx_fifo_config_t`

FlexCAN Rx FIFO configuration structure.

`typedef struct _flexcan_mb_transfer flexcan_mb_transfer_t`

FlexCAN Message Buffer transfer.

`typedef struct _flexcan_fifo_transfer flexcan_fifo_transfer_t`

FlexCAN Rx FIFO transfer.

`typedef struct _flexcan_handle flexcan_handle_t`

FlexCAN handle structure definition. .

`typedef void (*flexcan_transfer_callback_t)(flexcan_handle_t *psHandle, status_t status, uint32_t result, void *pUserData)`

FlexCAN transfer callback function.

The FlexCAN transfer callback returns a value from the underlying layer. If the status equals to `kStatus_FLEXCAN_ErrorStatus`, the result parameter is the Content of FlexCAN status register which can be used to get the working status(or error status) of FlexCAN module. If the status equals to other FlexCAN Message Buffer transfer status, the result is the index of Message Buffer that generate transfer event. If the status equals to other FlexCAN Message Buffer transfer status, the result is meaningless and should be Ignored.

`uint32_t FLEXCAN_GetInstance(CAN_Type *base)`

Get the FlexCAN instance from peripheral base address.

Parameters

- `base` – FlexCAN peripheral base address.

Returns

FlexCAN instance.

`FLEXCAN_WAIT_TIMEOUT`

`DLC_LENGTH_DECODE(dlc)`

FlexCAN frame length helper macro.

`FLEXCAN_ID_STD(id)`

FlexCAN Frame ID helper macro.

Standard Frame ID helper macro.

`FLEXCAN_ID_EXT(id)`

Extend Frame ID helper macro.

`FLEXCAN_RX_MB_STD_MASK(id, rtr, ide)`

FlexCAN Rx Message Buffer Mask helper macro.

Standard Rx Message Buffer Mask helper macro.

`FLEXCAN_RX_MB_EXT_MASK(id, rtr, ide)`

Extend Rx Message Buffer Mask helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_A(id, rtr, ide)`

FlexCAN Rx FIFO Mask helper macro.

Standard Rx FIFO Mask helper macro Type A helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_B_HIGH(id, rtr, ide)`

Standard Rx FIFO Mask helper macro Type B upper part helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_B_LOW(id, rtr, ide)`

Standard Rx FIFO Mask helper macro Type B lower part helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_C_HIGH(id)`

Standard Rx FIFO Mask helper macro Type C upper part helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_C_MID_HIGH(id)`

Standard Rx FIFO Mask helper macro Type C mid-upper part helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_C_MID_LOW(id)`

Standard Rx FIFO Mask helper macro Type C mid-lower part helper macro.

`FLEXCAN_RX_FIFO_STD_MASK_TYPE_C_LOW(id)`

Standard Rx FIFO Mask helper macro Type C lower part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_A(id, rtr, ide)`

Extend Rx FIFO Mask helper macro Type A helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_B_HIGH(id, rtr, ide)`

Extend Rx FIFO Mask helper macro Type B upper part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_B_LOW(id, rtr, ide)`

Extend Rx FIFO Mask helper macro Type B lower part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_C_HIGH(id)`

Extend Rx FIFO Mask helper macro Type C upper part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_C_MID_HIGH(id)`

Extend Rx FIFO Mask helper macro Type C mid-upper part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_C_MID_LOW(id)`

Extend Rx FIFO Mask helper macro Type C mid-lower part helper macro.

`FLEXCAN_RX_FIFO_EXT_MASK_TYPE_C_LOW(id)`

Extend Rx FIFO Mask helper macro Type C lower part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_A(id, rtr, ide)`

FlexCAN Rx FIFO Filter helper macro.

Standard Rx FIFO Filter helper macro Type A helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_B_HIGH(id, rtr, ide)`

Standard Rx FIFO Filter helper macro Type B upper part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_B_LOW(id, rtr, ide)`

Standard Rx FIFO Filter helper macro Type B lower part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_C_HIGH(id)`

Standard Rx FIFO Filter helper macro Type C upper part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_C_MID_HIGH(id)`

Standard Rx FIFO Filter helper macro Type C mid-upper part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_C_MID_LOW(id)`

Standard Rx FIFO Filter helper macro Type C mid-lower part helper macro.

`FLEXCAN_RX_FIFO_STD_FILTER_TYPE_C_LOW(id)`

Standard Rx FIFO Filter helper macro Type C lower part helper macro.

`FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_A(id, rtr, ide)`

Extend Rx FIFO Filter helper macro Type A helper macro.

`FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_B_HIGH(id, rtr, ide)`

Extend Rx FIFO Filter helper macro Type B upper part helper macro.

FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_B_LOW(id, rtr, ide)

Extend Rx FIFO Filter helper macro Type B lower part helper macro.

FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_C_HIGH(id)

Extend Rx FIFO Filter helper macro Type C upper part helper macro.

FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_C_MID_HIGH(id)

Extend Rx FIFO Filter helper macro Type C mid-upper part helper macro.

FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_C_MID_LOW(id)

Extend Rx FIFO Filter helper macro Type C mid-lower part helper macro.

FLEXCAN_RX_FIFO_EXT_FILTER_TYPE_C_LOW(id)

Extend Rx FIFO Filter helper macro Type C lower part helper macro.

struct _flexcan_frame

#include <fsl_flexcan.h> FlexCAN message frame structure.

struct _flexcan_fd_frame

#include <fsl_flexcan.h> CAN FD message frame structure.

Note: This structure can contain a CAN FD frame (bitEdl equal 1) or classic CAN frame (bitEdl equal 0).

struct _flexcan_timing_config

#include <fsl_flexcan.h> FlexCAN protocol timing characteristic configuration structure.

Public Members

uint16_t u16PreDivider

Clock Pre-scaler Division Factor.

uint8_t u8RJumpWidth

Re-sync Jump Width.

uint8_t u8PhaseSeg1

Phase Segment 1.

uint8_t u8PhaseSeg2

Phase Segment 2.

uint8_t u8PropSeg

Propagation Segment.

struct _flexcan_fd_config

#include <fsl_flexcan.h> Configuration for the Flexcan CAN FD mode. It only cover FD related parts.

It is used as member of flexcan_config_t to do the CAN FD specific init on init this peripheral.

struct _flexcan_config

#include <fsl_flexcan.h> FlexCAN module configuration structure.

Public Members

bool bEnableTimingCalc

Enable or Disable the bit timing calculation in FLEXCAN_Init() API.

uint32_t u32BaudRateBps

FlexCAN baud rate in bps (for classical CAN or CANFD nominal phase). Only meaningful when the bEnableTimingCalc is true.

uint32_t u32ClkFreqHz

FlexCAN peripheral clock frequency in HZ. Only meaningful when the bEnableTimingCalc is true.

flexcan_timing_config_t sTimingConfig

Protocol timing configuration. Only meaningful when the bEnableTimingCalc is false.

flexcan_clock_source_t eClkSrc

Clock source for FlexCAN Protocol Engine.

uint8_t u8MaxMsgBufNum

The maximum number of Message Buffers used by user.

bool bEnableIndividMask

Enable or Disable Rx Individual Mask.

flexcan_wake_up_source_t eWakeupSrc

Wake up source selection.

bool bEnableSelfWakeup

Enable or Disable Self Wakeup Mode.

bool bEnableLoopBack

Enable or Disable Loop Back Self Test Mode.

bool bEnableTimerSync

Enable or Disable Timer Synchronization.

bool bDisableSelfReception

Enable or Disable Self Reflection.

bool bEnableListenOnlyMode

Enable or Disable Listen Only Mode.

bool bEnableDoze

Enable or Disable Doze Mode.

struct *_flexcan_rx_mb_config*

#include <fsl_flexcan.h> FlexCAN Receive Message Buffer configuration structure.

This structure is used as the parameter of FLEXCAN_SetRxMbConfig() function. The FLEXCAN_SetRxMbConfig() function is used to configure FlexCAN Receive Message Buffer. The function abort previous receiving process, clean the Message Buffer and activate the Rx Message Buffer using given Message Buffer setting.

Public Members

uint32_t u32Id

CAN Message Buffer Frame Identifier; should be set using FLEXCAN_ID_EXT() or FLEXCAN_ID_STD() macro.

flexcan_frame_format_t eFormat

CAN Frame Identifier format(Standard or Extend).

flexcan_frame_type_t eType

CAN Frame Type(Data or Remote).

struct *_flexcan_rx_fifo_config*

#include <fsl_flexcan.h> FlexCAN Rx FIFO configuration structure.

Public Members

uint32_t *pu32IdFilterTable

Pointer to the FlexCAN Rx FIFO identifier filter table.

uint8_t u8IdFilterNum

The quantity of filter elements.

flexcan_rx_fifo_filter_type_t eIdFilterType

The FlexCAN Rx FIFO Filter type.

flexcan_rx_fifo_priority_t ePriority

The FlexCAN Rx FIFO receive priority.

struct *_flexcan_mb_transfer*

#include <fsl_flexcan.h> FlexCAN Message Buffer transfer.

Public Members

flexcan_frame_t *psFrame

The buffer of CAN Message to be transfer.

uint8_t u8MsgBufIdx

The index of Message buffer used to transfer Message.

struct *_flexcan_fifo_transfer*

#include <fsl_flexcan.h> FlexCAN Rx FIFO transfer.

Public Members

flexcan_frame_t *psFrame

The buffer of CAN Message to be received from Rx FIFO.

struct *_flexcan_handle*

#include <fsl_flexcan.h> FlexCAN handle structure.

Public Members

flexcan_transfer_callback_t pfCallback

Callback function.

void *pUserData

FlexCAN callback function parameter.

flexcan_fd_frame_t *volatile psFDMbFrameBufs[CAN_WORD1_COUNT]

The buffer for received data from Message Buffers.

flexcan_frame_t *volatile psRxFifoFrameBuf

The buffer for received data from Rx FIFO.

volatile uint8_t u8MsgBufStates[CAN_WORD1_COUNT]

Message Buffer transfer state.

volatile uint8_t u8RxFifoState

Rx FIFO transfer state.

volatile uint32_t u32TimeStamps[CAN_WORD1_COUNT]

Mailbox transfer timestamp.

struct *__unnamed12__*

Public Members

uint32_t bitsTimestamp

FlexCAN internal Free-Running Counter Time Stamp.

uint32_t bitsLength

CAN frame payload length in bytes(Range: 0~8).

uint32_t bitType

CAN Frame Type(DATA or REMOTE).

uint32_t bitFormat

CAN Frame Identifier(STD or EXT format).

uint32_t __pad0__

Reserved.

uint32_t bitsIdHit

CAN Rx FIFO filter hit id(This value is only used in Rx FIFO receive mode).

struct __unnamed14__

Public Members

uint32_t bitsId

CAN Frame Identifier, should be set using FLEXCAN_ID_EXT() or FLEXCAN_ID_STD() macro.

uint32_t __pad0__

Reserved.

union __unnamed16__

Public Members

struct _flexcan_frame

struct _flexcan_frame

struct __unnamed18__

Public Members

uint32_t u32DataWord0

CAN Frame payload word0.

uint32_t u32DataWord1

CAN Frame payload word1.

struct __unnamed20__

Public Members

uint8_t u8DataByte3

CAN Frame payload byte3.

uint8_t u8DataByte2

CAN Frame payload byte2.

```
uint8_t u8DataByte1
    CAN Frame payload byte1.
uint8_t u8DataByte0
    CAN Frame payload byte0.
uint8_t u8DataByte7
    CAN Frame payload byte7.
uint8_t u8DataByte6
    CAN Frame payload byte6.
uint8_t u8DataByte5
    CAN Frame payload byte5.
uint8_t u8DataByte4
    CAN Frame payload byte4.
struct ____unnamed22____
```

Public Members

```
uint32_t bitsTimestamp
    FlexCAN internal Free-Running Counter Time Stamp.
uint32_t bitsLength
    CAN FD frame data length code (DLC), range see _flexcan_fd_frame_length, When the
    length <= 8, it equals to the data length in bytes, otherwise the number of valid frame
    data is not equal to the length value. User can use DLC_LENGTH_DECODE(length)
    macro to get the number of valid data bytes.
uint32_t bitType
    CAN Frame Type(DATA or REMOTE).
uint32_t bitFormat
    CAN Frame Identifier(STD or EXT format).
uint32_t bitSrr
    Substitute Remote request.
uint32_t bitsCode
    Message Buffer Code.
uint32_t bitEsi
    Error State Indicator.
uint32_t bitBrs
    Bit Rate Switch.
uint32_t bitEdl
    Extended Data Length.
struct ____unnamed24____
```

Public Members

```
uint32_t bitsId
    CAN Frame Identifier, should be set using FLEXCAN_ID_EXT() or FLEXCAN_ID_STD()
    macro.
```

```
uint32_t __pad0__  
    Reserved.  
union __unnamed26__
```

Public Members

```
struct __flexcan_fd_frame  
struct __flexcan_fd_frame  
struct __unnamed28__
```

Public Members

```
uint32_t u32DataWord[16]  
    CAN FD Frame payload, 16 double word maximum.  
struct __unnamed30__
```

Public Members

```
uint8_t u8DataByte3  
    CAN Frame payload byte3.  
uint8_t u8DataByte2  
    CAN Frame payload byte2.  
uint8_t u8DataByte1  
    CAN Frame payload byte1.  
uint8_t u8DataByte0  
    CAN Frame payload byte0.  
uint8_t u8DataByte7  
    CAN Frame payload byte7.  
uint8_t u8DataByte6  
    CAN Frame payload byte6.  
uint8_t u8DataByte5  
    CAN Frame payload byte5.  
uint8_t u8DataByte4  
    CAN Frame payload byte4.
```

2.33 The Driver Change Log

2.34 FlexCAN Peripheral and Driver Overview

2.35 ftfx adapter

2.36 ftfx controller

FTFx driver status codes.

Values:

enumerator kStatus_FTFx_Success

API is executed successfully

enumerator kStatus_FTFx_InvalidArgument

Invalid argument

enumerator kStatus_FTFx_SizeError

Error size

enumerator kStatus_FTFx_AlignmentError

Parameter is not aligned with the specified baseline

enumerator kStatus_FTFx_AddressError

Address is out of range

enumerator kStatus_FTFx_AccessError

Invalid instruction codes and out-of bound addresses

enumerator kStatus_FTFx_ProtectionViolation

The program/erase operation is requested to execute on protected areas

enumerator kStatus_FTFx_CommandFailure

Run-time error during command execution.

enumerator kStatus_FTFx_UnknownProperty

Unknown property.

enumerator kStatus_FTFx_EraseKeyError

API erase key is invalid.

enumerator kStatus_FTFx_RegionExecuteOnly

The current region is execute-only.

enumerator kStatus_FTFx_ExecuteInRamFunctionNotReady

Execute-in-RAM function is not available.

enumerator kStatus_FTFx_PartitionStatusUpdateFailure

Failed to update partition status.

enumerator kStatus_FTFx_SetFlexramAsEepromError

Failed to set FlexRAM as EEPROM.

enumerator kStatus_FTFx_RecoverFlexramAsRamError

Failed to recover FlexRAM as RAM.

enumerator kStatus_FTFx_SetFlexramAsRamError

Failed to set FlexRAM as RAM.

enumerator kStatus_FTFx_RecoverFlexramAsEepromError

Failed to recover FlexRAM as EEPROM.

enumerator kStatus_FTFx_CommandNotSupported

Flash API is not supported.

enumerator kStatus_FTFx_SwapSystemNotInUninitialized

Swap system is not in an uninitialized state.

enumerator kStatus_FTFx_SwapIndicatorAddressError

The swap indicator address is invalid.

enumerator kStatus_FTFx_ReadOnlyProperty

The flash property is read-only.

enumerator kStatus_FTFx_InvalidPropertyValue

The flash property value is out of range.

enumerator kStatus_FTFx_InvalidSpeculationOption

The option of flash prefetch speculation is invalid.

enumerator kStatus_FTFx_CommandOperationInProgress

The option of flash command is processing.

kStatusGroupGeneric

FTFx driver status group.

kStatusGroupFtfxDriver

kFTFx_ApiEraseKey

void FTFx_API_Init(*ftfx_config_t* *config)

Initializes the global flash properties structure members.

This function checks and initializes the Flash module for the other Flash APIs.

Parameters

- config – Pointer to the storage for the driver runtime state.

status_t FTFx_CMD_Erase(*ftfx_config_t* *config, uint32_t start, uint32_t lengthInBytes, uint32_t key)

Erases the flash sectors encompassed by parameters passed into function.

This function erases the appropriate number of flash sectors based on the desired start address and length.

Parameters

- config – The pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words) to be erased. Must be word-aligned.
- key – The value used to validate all flash erase APIs.

Return values

- kStatus_FTFx_Success – API was executed successfully.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.
- kStatus_FTFx_AlignmentError – The parameter is not aligned with the specified baseline.
- kStatus_FTFx_AddressError – The address is out of range.
- kStatus_FTFx_EraseKeyError – The API erase key is invalid.
- kStatus_FTFx_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus_FTFx_AccessError – Invalid instruction codes and out-of bounds addresses.

- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_EraseAll(ftfx_config_t *config, uint32_t key)`

Erases entire flash.

Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FTFx_CMD_Program(ftfx_config_t *config, uint32_t start, const uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and the length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.

- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_ProgramOnce(ftfx_config_t *config, uint8_t index, const uint8_t *src, uint32_t lengthInBytes)`

Programs Program Once Field through parameters.

This function programs the Program Once Field with the desired data for a given flash area as determined by the index and length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating which area of the Program Once Field to be programmed.
- `src` – A pointer to the source buffer of data that is to be programmed into the Program Once Field.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_ReadOnce(ftfx_config_t *config, uint8_t index, uint8_t *dst, uint32_t lengthInBytes)`

Reads the Program Once Field through parameters.

This function reads the read once feild with given index and length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating the area of program once field to be read.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_VerifyErase(ftfx_config_t *config, uint32_t start, uint32_t lengthInBytes, uint8_t margin)`

Verifies an erasure of the desired flash area at a specified margin level.

This function checks the appropriate number of flash sectors based on the desired start address and length to check whether the flash is erased to the specified read margin level.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `margin` – Read margin choice.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_VerifyEraseAll(ftfx_config_t *config, uint8_t margin)`

Verifies erasure of the entire flash at a specified margin level.

This function checks whether the flash is erased to the specified read margin level.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `margin` – Read margin choice.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_CMD_VerifyProgram(ftfx_config_t *config, uint32_t start, uint32_t lengthInBytes, const uint8_t *expectedData, uint8_t margin, uint32_t *failedAddress, uint32_t *failedData)`

Verifies programming of the desired flash area at a specified margin level.

This function verifies the data programed in the flash memory using the Flash Program Check Command and compares it to the expected data for a given flash area as determined by the start address and length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. Must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `expectedData` – A pointer to the expected data that is to be verified against.
- `margin` – Read margin choice.
- `failedAddress` – A pointer to the returned failing address.
- `failedData` – A pointer to the returned failing data. Some derivatives do not include failed data as part of the FCCOBx registers. In this case, zeros are returned upon failure.

Return values

- `kStatus_FTFx_Success` – API was executed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FTFx_REG_GetSecurityState(ftfx_config_t *config, ftfx_security_state_t *state)`

Returns the security state via the pointer passed into the function.

This function retrieves the current flash security status, including the security enabling state and the backdoor key enabling state.

Parameters

- config – A pointer to storage for the driver runtime state.
- state – A pointer to the value returned for the current security status code:

Return values

- kStatus_FTFx_Success – API was executed successfully.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.

enum __ftfx_partition_flexram_load_option

Enumeration for the FlexRAM load during reset option.

Values:

enumerator kFTFx_PartitionFlexramLoadOptLoadedWithValidEepromData

FlexRAM is loaded with valid EEPROM data during reset sequence.

enumerator kFTFx_PartitionFlexramLoadOptNotLoaded

FlexRAM is not loaded during reset sequence.

enum __ftfx_security_state

Enumeration for the three possible FTFx security states.

Values:

enumerator kFTFx_SecurityStateNotSecure

Flash is not secure.

enumerator kFTFx_SecurityStateBackdoorEnabled

Flash backdoor is enabled.

enumerator kFTFx_SecurityStateBackdoorDisabled

Flash backdoor is disabled.

enum __ftfx_flexram_function_option

Enumeration for the two possible options of set FlexRAM function command.

Values:

enumerator kFTFx_FlexramFuncOptAvailableAsRam

An option used to make FlexRAM available as RAM

enumerator kFTFx_FlexramFuncOptAvailableForEeprom

An option used to make FlexRAM available for EEPROM

enum __ftfx_swap_state

Enumeration for the possible flash Swap status.

Values:

enumerator kFTFx_SwapStateUninitialized

Flash Swap system is in an uninitialized state.

enumerator kFTFx_SwapStateReady

Flash Swap system is in a ready state.

enumerator kFTFx_SwapStateUpdate

Flash Swap system is in an update state.

enumerator kFTFx_SwapStateUpdateErased

Flash Swap system is in an updateErased state.

enumerator kFTFx_SwapStateComplete

Flash Swap system is in a complete state.

enumerator kFTFx_SwapStateDisabled

Flash Swap system is in a disabled state.

enum _ftfx_memory_type

Enumeration for FTFx memory type.

Values:

enumerator kFTFx_MemTypePflash

enumerator kFTFx_MemTypeFlexnvm

typedef enum _ftfx_partition_flexram_load_option ftfx_partition_flexram_load_opt_t

Enumeration for the FlexRAM load during reset option.

typedef enum _ftfx_security_state ftfx_security_state_t

Enumeration for the three possible FTFx security states.

typedef enum _ftfx_flexram_function_option ftfx_flexram_func_opt_t

Enumeration for the two possible options of set FlexRAM function command.

typedef enum _ftfx_swap_state ftfx_swap_state_t

Enumeration for the possible flash Swap status.

typedef struct _ftfx_special_mem ftfx_spec_mem_t

ftfx special memory access information.

typedef struct _ftfx_mem_descriptor ftfx_mem_desc_t

Flash memory descriptor.

typedef struct _ftfx_ops_config ftfx_ops_config_t

Active FTFx information for the current operation.

typedef struct _ftfx_ifr_descriptor ftfx_ifr_desc_t

Flash IFR memory descriptor.

typedef struct _ftfx_config ftfx_config_t

Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

kFTFx_ResourceOptionFlashIfr

Macro for the two possible options of flash read resource command.

Select code for Program flash 0 IFR, Program flash swap 0 IFR, Data flash 0 IFR

kFTFx_ResourceOptionVersionId

Select code for the version ID

kFTFx_MarginValueNormal

Macro for supported FTFx margin levels.

kFTFx_MarginValueUser

Apply the 'User' margin to the normal read-1 level.

kFTFx_MarginValueFactory

Apply the 'Factory' margin to the normal read-1 level.

kFTFx_MarginValueInvalid

Not real margin level, Used to determine the range of valid margin level.

```
struct _ftfx_special_mem
    #include <fsl_ftfx_controller.h> ftfx special memory access information.
```

Public Members

uint32_t base
Base address of flash special memory.

uint32_t size
size of flash special memory.

uint32_t count
flash special memory count.

```
struct _ftfx_mem_descriptor
    #include <fsl_ftfx_controller.h> Flash memory descriptor.
```

Public Members

uint32_t blockBase
A base address of the flash block

uint32_t totalSize
The size of the flash block.

uint32_t sectorSize
The size in bytes of a sector of flash.

uint32_t blockCount
A number of flash blocks.

```
struct _ftfx_ops_config
    #include <fsl_ftfx_controller.h> Active FTFx information for the current operation.
```

Public Members

uint32_t convertedAddress
A converted address for the current flash type.

```
struct _ftfx_ifr_descriptor
    #include <fsl_ftfx_controller.h> Flash IFR memory descriptor.
```

```
union function_ptr_t
    #include <fsl_ftfx_controller.h>
```

Public Members

uint32_t commadAddr

void (*callFlashCommand)(volatile uint8_t *FTMRx_fstat)

```
struct _ftfx_config
    #include <fsl_ftfx_controller.h> Flash driver state information.
```

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

Public Members

uint32_t flexramBlockBase

The base address of the FlexRAM/acceleration RAM

uint32_t flexramTotalSize

The size of the FlexRAM/acceleration RAM

uint16_t eepromTotalSize

The size of EEPROM area which was partitioned from FlexRAM

function_ptr_t runCmdFuncAddr

An buffer point to the flash execute-in-RAM function.

struct ____unnamed4____

Public Members

uint8_t type

Type of flash block.

uint8_t index

Index of flash block.

struct feature

struct addrAligment

struct feature

struct resRange

Public Members

uint8_t versionIdStart

Version ID start address

uint32_t pflashIfrStart

Program Flash 0 IFR start address

uint32_t dflashIfrStart

Data Flash 0 IFR start address

uint32_t pflashSwapIfrStart

Program Flash Swap IFR start address

struct idxInfo

2.37 ftfx feature

FTFx_DRIVER_IS_FLASH_RESIDENT

Flash driver location.

Used for the flash resident application.

FTFx_DRIVER_IS_EXPORTED

Flash Driver Export option.

Used for the MCUXpresso SDK application.

FTFx_FLASH1_HAS_PROT_CONTROL

Indicates whether the secondary flash has its own protection register in flash module.

FTFx_FLASH1_HAS_XACC_CONTROL

Indicates whether the secondary flash has its own Execute-Only access register in flash module.

FTFx_DRIVER_HAS_FLASH1_SUPPORT

Indicates whether the secondary flash is supported in the Flash driver.

FTFx_FLASH_COUNT

FTFx_FLASH1_IS_INDEPENDENT_BLOCK

2.38 Ftftx FLASH Driver

status_t FLASH_Init(*flash_config_t* *config)

Initializes the global flash properties structure members.

This function checks and initializes the Flash module for the other Flash APIs.

Parameters

- config – Pointer to the storage for the driver runtime state.

Return values

- kStatus_FTFx_Success – API was executed successfully.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.
- kStatus_FTFx_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus_FTFx_PartitionStatusUpdateFailure – Failed to update the partition status.

status_t FLASH_Erase(*flash_config_t* *config, uint32_t start, uint32_t lengthInBytes, uint32_t key)

Erases the Dflash sectors encompassed by parameters passed into function.

This function erases the appropriate number of flash sectors based on the desired start address and length.

Parameters

- config – The pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be erased. The start address does not need to be sector-aligned but must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words) to be erased. Must be word-aligned.
- key – The value used to validate all flash erase APIs.

Return values

- kStatus_FTFx_Success – API was executed successfully; the appropriate number of flash sectors based on the desired start address and length were erased successfully.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.
- kStatus_FTFx_AlignmentError – The parameter is not aligned with the specified baseline.

- `kStatus_FTFx_AddressError` – The address is out of range.
- `kStatus_FTFx_EraseKeyError` – The API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_EraseAll(flash_config_t *config, uint32_t key)`

Erases entire flexnvm.

Parameters

- `config` – Pointer to the storage for the driver runtime state.
- `key` – A value used to validate all flash erase APIs.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the all pflash and flexnvm were erased successfully, the swap and eeprom have been reset to unconfigured state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_EraseKeyError` – API erase key is invalid.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during command execution.
- `kStatus_FTFx_PartitionStatusUpdateFailure` – Failed to update the partition status.

`status_t FLASH_Program(flash_config_t *config, uint32_t start, uint8_t *src, uint32_t lengthInBytes)`

Programs flash with data at locations passed in through parameters.

This function programs the flash memory with the desired data for a given flash area as determined by the start address and the length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be programmed. Must be word-aligned.
- `src` – A pointer to the source buffer of data that is to be programmed into the flash.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the desired data were programmed successfully into flash based on desired start address and length.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with the specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t` FLASH_ProgramOnce(*flash_config_t* *config, uint8_t index, uint8_t *src, uint32_t lengthInBytes)

Program the Program-Once-Field through parameters.

This function Program the Program-once-field with given index and length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `index` – The index indicating the area of program once field to be read.
- `src` – A pointer to the source buffer of data that is used to store data to be write.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; The index indicating the area of program once field was programmed successfully.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t` FLASH_ReadOnce(*flash_config_t* *config, uint8_t index, uint8_t *dst, uint32_t lengthInBytes)

Reads the Program Once Field through parameters.

This function reads the read once field with given index and length.

Parameters

- `config` – A pointer to the storage for the driver runtime state.

- `index` – The index indicating the area of program once field to be read.
- `dst` – A pointer to the destination buffer of data that is used to store data to be read.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be programmed. Must be word-aligned.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the data have been successfully read from Program flash0 IFR map and Program Once field based on index and length.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t FLASH_VerifyErase(flash_config_t *config, uint32_t start, uint32_t lengthInBytes, uint8_t margin)`

Verifies an erasure of the desired flash area at a specified margin level.

This function checks the appropriate number of flash sectors based on the desired start address and length to check whether the flash is erased to the specified read margin level.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `start` – The start address of the desired flash memory to be verified. The start address does not need to be sector-aligned but must be word-aligned.
- `lengthInBytes` – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- `margin` – Read margin choice.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the specified FLASH region has been erased.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_AlignmentError` – Parameter is not aligned with specified baseline.
- `kStatus_FTFx_AddressError` – Address is out of range.
- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

status_t FLASH_VerifyEraseAll(*flash_config_t* *config, uint8_t margin)

Verifies erasure of the entire flash at a specified margin level.

This function checks whether the flash is erased to the specified read margin level.

Parameters

- config – A pointer to the storage for the driver runtime state.
- margin – Read margin choice.

Return values

- kStatus_FTFx_Success – API was executed successfully; all program flash and flexnvm were in erased state.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.
- kStatus_FTFx_ExecuteInRamFunctionNotReady – Execute-in-RAM function is not available.
- kStatus_FTFx_AccessError – Invalid instruction codes and out-of bounds addresses.
- kStatus_FTFx_ProtectionViolation – The program/erase operation is requested to execute on protected areas.
- kStatus_FTFx_CommandFailure – Run-time error during the command execution.

status_t FLASH_VerifyProgram(*flash_config_t* *config, uint32_t start, uint32_t lengthInBytes, const uint8_t *expectedData, uint8_t margin, uint32_t *failedAddress, uint32_t *failedData)

Verifies programming of the desired flash area at a specified margin level.

This function verifies the data programmed in the flash memory using the Flash Program Check Command and compares it to the expected data for a given flash area as determined by the start address and length.

Parameters

- config – A pointer to the storage for the driver runtime state.
- start – The start address of the desired flash memory to be verified. Must be word-aligned.
- lengthInBytes – The length, given in bytes (not words or long-words), to be verified. Must be word-aligned.
- expectedData – A pointer to the expected data that is to be verified against.
- margin – Read margin choice.
- failedAddress – A pointer to the returned failing address.
- failedData – A pointer to the returned failing data. Some derivatives do not include failed data as part of the FCCOBx registers. In this case, zeros are returned upon failure.

Return values

- kStatus_FTFx_Success – API was executed successfully; the desired data have been successfully programed into specified FLASH region.
- kStatus_FTFx_InvalidArgument – An invalid argument is provided.
- kStatus_FTFx_AlignmentError – Parameter is not aligned with specified baseline.
- kStatus_FTFx_AddressError – Address is out of range.

- `kStatus_FTFx_ExecuteInRamFunctionNotReady` – Execute-in-RAM function is not available.
- `kStatus_FTFx_AccessError` – Invalid instruction codes and out-of bounds addresses.
- `kStatus_FTFx_ProtectionViolation` – The program/erase operation is requested to execute on protected areas.
- `kStatus_FTFx_CommandFailure` – Run-time error during the command execution.

`status_t` FLASH_GetSecurityState(*flash_config_t* *config, *ftfx_security_state_t* *state)

Returns the security state via the pointer passed into the function.

This function retrieves the current flash security status, including the security enabling state and the backdoor key enabling state.

Parameters

- `config` – A pointer to storage for the driver runtime state.
- `state` – A pointer to the value returned for the current security status code:

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the security state of flash was stored to state.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.

`status_t` FLASH_GetProperty(*flash_config_t* *config, *flash_property_tag_t* whichProperty, *uint32_t* *value)

Returns the desired flash property.

Parameters

- `config` – A pointer to the storage for the driver runtime state.
- `whichProperty` – The desired property from the list of properties in enum `flash_property_tag_t`
- `value` – A pointer to the value returned for the desired flash property.

Return values

- `kStatus_FTFx_Success` – API was executed successfully; the flash property was stored to value.
- `kStatus_FTFx_InvalidArgument` – An invalid argument is provided.
- `kStatus_FTFx_UnknownProperty` – An unknown property tag.

`FSL_FLASH_DRIVER_VERSION`

Flash driver version for SDK.

Version 3.0.0.

`enum _flash_protection_state`

Enumeration for the three possible flash protection levels.

Values:

enumerator `kFLASH_ProtectionStateUnprotected`

Flash region is not protected.

enumerator `kFLASH_ProtectionStateProtected`

Flash region is protected.

enumerator kFLASH_ProtectionStateMixed

Flash is mixed with protected and unprotected region.

enum _flash_property_tag

Enumeration for various flash properties.

Values:

enumerator kFLASH_PropertyPflash0SectorSize

Pflash sector size property.

enumerator kFLASH_PropertyPflash0TotalSize

Pflash total size property.

enumerator kFLASH_PropertyPflash0BlockSize

Pflash block size property.

enumerator kFLASH_PropertyPflash0BlockCount

Pflash block count property.

enumerator kFLASH_PropertyPflash0BlockBaseAddr

Pflash block base address property.

enumerator kFLASH_PropertyPflash0FacSupport

Pflash fac support property.

enumerator kFLASH_PropertyPflash0AccessSegmentSize

Pflash access segment size property.

enumerator kFLASH_PropertyPflash0AccessSegmentCount

Pflash access segment count property.

enumerator kFLASH_PropertyPflash1SectorSize

Pflash sector size property.

enumerator kFLASH_PropertyPflash1TotalSize

Pflash total size property.

enumerator kFLASH_PropertyPflash1BlockSize

Pflash block size property.

enumerator kFLASH_PropertyPflash1BlockCount

Pflash block count property.

enumerator kFLASH_PropertyPflash1BlockBaseAddr

Pflash block base address property.

enumerator kFLASH_PropertyPflash1FacSupport

Pflash fac support property.

enumerator kFLASH_PropertyPflash1AccessSegmentSize

Pflash access segment size property.

enumerator kFLASH_PropertyPflash1AccessSegmentCount

Pflash access segment count property.

enumerator kFLASH_PropertyFlexRamBlockBaseAddr

FlexRam block base address property.

enumerator kFLASH_PropertyFlexRamTotalSize

FlexRam total size property.

```
typedef enum _flash_protection_state flash_prot_state_t
```

Enumeration for the three possible flash protection levels.

```
typedef union _pflash_protection_status pflash_prot_status_t
```

PFlash protection status.

```
typedef enum _flash_property_tag flash_property_tag_t
```

Enumeration for various flash properties.

```
typedef struct _flash_config flash_config_t
```

Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

```
kStatus_FLASH_Success
```

```
kFLASH_ApiEraseKey
```

```
union _pflash_protection_status
```

#include <fsl_ftfx_flash.h> PFlash protection status.

Public Members

```
uint32_t protl
```

PROT[31:0] .

```
uint32_t proth
```

PROT[63:32].

```
uint8_t protsl
```

PROTS[7:0] .

```
uint8_t protsh
```

PROTS[15:8] .

```
uint8_t reserved[2]
```

```
struct _flash_config
```

#include <fsl_ftfx_flash.h> Flash driver state information.

An instance of this structure is allocated by the user of the flash driver and passed into each of the driver APIs.

2.39 ftfx utilities

```
MAKE_VERSION(major, minor, bugfix)
```

Constructs the version number for drivers.

```
MAKE_STATUS(group, code)
```

Constructs a status code value from a group and a code number.

```
FOUR_CHAR_CODE(a, b, c, d)
```

Constructs the four character code for the Flash driver API key.

```
ALIGN_DOWN(x, a)
```

Alignment(down) utility.

ALIGN_UP(x, a)

Alignment(up) utility.

B1P4(b)

bytes2word utility.

B1P3(b)

B1P2(b)

B1P1(b)

B2P3(b)

B2P2(b)

B2P1(b)

B3P2(b)

B3P1(b)

BYTE2WORD_1_3(x, y)

BYTE2WORD_2_2(x, y)

BYTE2WORD_3_1(x, y)

BYTE2WORD_1_1_2(x, y, z)

BYTE2WORD_1_2_1(x, y, z)

BYTE2WORD_2_1_1(x, y, z)

BYTE2WORD_1_1_1_1(x, y, z, w)

2.40 GPIO: General-Purpose Input/Output Driver

void GPIO_PinInit(GPIO_Type *base, *gpio_pin_t* ePin, const *gpio_config_t* *psConfig)

Initializes a GPIO pin with provided structure *gpio_config_t* covering all configuration fields.

To initialize the GPIO, define a pin configuration, as either input or output, in the user file. Then, call the GPIO_PinInit() function.

This is function to configure all GPIO Pin configurable fields.

```
gpio_config_t sConfig = {
    .eDirection    = kGPIO_DigitalOutput,
    .eMode         = kGPIO_ModeGpio,
    .eOutMode      = kGPIO_OutputOpenDrain,
    .eSlewRate     = kGPIO_SlewRateFast,
    .eOutLevel     = kGPIO_OutputLow,
    .eDriveStrength = kGPIO_DriveStrengthLow,
    .ePull         = kGPIO_PullDisable,
    .eInterruptMode = kGPIO_InterruptDisable,
}
GPIO_PinInit(GPIOA, kGPIO_Pin1, &sConfig);
```

Note: If GPIO glitch is critical for your application, do not use this API instead using the API in GPIO pin configuration interfaces to do with the glitch during GPIO mode transition in accordance to your board design.

Parameters

- `base` – GPIO peripheral base pointer (GPIOA, GPIOB, GPIOC, and so on.)
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- `psConfig` – GPIO pin configuration pointer

```
static inline void GPIO_PinSetPeripheralMode(GPIO_Type *base, gpio_pin_t ePin,  
                                             gpio_peripheral_mode_t eMode)
```

Configure the GPIO Pin as Peripheral mode or GPIO mode for one pin.

Configure GPIO can be configured as Peripheral mode or GPIO mode for one pin.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- `eMode` – Peripheral mode or GPIO mode for this pin. See `gpio_peripheral_mode_t`

```
static inline void GPIO_PinSetPeripheralMux(gpio_peripheral_mux_t eMux)
```

Configure the multiplexing of GPIO pins to different peripheral.

Configure the MUX of GPIO pins to different peripheral functionality.

Note: User still need to call the `GPIO_PinSetPeripheralMode`.

Parameters

- `eMux` – GPIO peripheral MUX when configured as peripheral mode.

```
static inline void GPIO_PinSetDirection(GPIO_Type *base, gpio_pin_t ePin, gpio_direction_t  
                                         eDirection)
```

Configure the GPIO pin as Input or Output for one pin.

Configure the GPIO pin as Input or Output for one pin.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- `eDirection` – Direction of GPIO pin. `gpio_direction_t`

```
static inline void GPIO_PinSetOutputMode(GPIO_Type *base, gpio_pin_t ePin,  
                                          gpio_output_mode_t eOutMode)
```

Configure GPIO pin output as Push-Pull or Open-Drain for one pin.

Configure GPIO pin output as Push-Pull or Open-Drain. This function applies while pin is configured as output. See `gpio_direction_t` and API `GPIO_PinSetDirection`.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- eOutMode – Push-Pull/Open-Drain output mode. See `gpio_output_mode_t`.

```
static inline void GPIO_PinSetDriveStrength(GPIO_Type *base, gpio_pin_t ePin,  
                                           gpio_output_drive_strength_t eDriveStrength)
```

Configure High/Low drive strength when Pin is configured as output for one pin.

Configure High/Low drive strength when Pin is configured as output. See `gpio_direction_t` and API `GPIO_PinSetDirection`.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- eDriveStrength – High/Low driver strength. See `gpio_output_drive_strength_t`

```
static inline void GPIO_PinSetSlewRate(GPIO_Type *base, gpio_pin_t ePin,  
                                       gpio_output_slew_rate_t eSlewRate)
```

Configure GPIO pin Fast/Slow slew rate when pin is configured as output.

Configure GPIO pin Fast/Slow slew rate when pin is configured as output. See `gpio_direction_t` and API `GPIO_PinSetDirection`.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- eSlewRate – Fast/Slow slewrate. See `gpio_output_slew_rate_t`

```
static inline void GPIO_PinSetPullResistorMode(GPIO_Type *base, gpio_pin_t ePin,  
                                              gpio_pull_mode_t ePullMode)
```

Configure Pull resistor for GPIO pin to Disable/Pull-Up/Pull-Down.

Configure Pull resistor for GPIO pin to Disable/Pull-Up/Pull-Down.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- ePullMode – Pull Mode as Disable/Pull-Up/Pull-Down. See `gpio_pull_mode_t`

```
static inline void GPIO_PinWrite(GPIO_Type *base, gpio_pin_t ePin, gpio_output_level_t  
                                eOutput)
```

Set GPIO Pin as High/Low voltage level on Output.

Set GPIO Pin as High/Low voltage level on Output.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- eOutput – Output as High level or Low Level. See `gpio_output_level_t`.

```
static inline void GPIO_PortSet(GPIO_Type *base, uint16_t u16Pins)
```

Set GPIO multiple pins output High voltage level without impact pins.

Set GPIO multiple pins output High voltage level without impact other pins. Multiple pins are configured by OR enumerator from `gpio_pin_t`

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

```
static inline void GPIO_PinSet(GPIO_Type *base, gpio_pin_t ePin)
```

Output High voltage level for GPIO Pin when configured as Output.

Output High voltage level for GPIO Pin when configured as Output.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

```
static inline void GPIO_PortClear(GPIO_Type *base, uint16_t u16Pins)
```

Set GPIO multiple pins belong to same PORT output Low voltage level when these pins are configured as output.

Set GPIO multiple pins belong to same PORT output Low voltage level when these pins are configured as output. Multiple pins are configured by ORing enumerators from `gpio_pin_t`

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

```
static inline void GPIO_PinClear(GPIO_Type *base, gpio_pin_t ePin)
```

Output Low voltage level for GPIO Pin when configured as Output.

Output Low voltage level for GPIO Pin when configured as Output.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

```
static inline void GPIO_PortToggle(GPIO_Type *base, uint16_t u16Pins)
```

Toggle GPIO multiple pins belong to same PORT when these pins are configured as output.

Toggle GPIO multiple pins belong to same PORT when these pins are configured as output. Multiple pins are configured by ORing enumerators from `gpio_pin_t`

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

```
static inline void GPIO_PinToggle(GPIO_Type *base, gpio_pin_t ePin)
```

Toggle the GPIO output voltage level when configured as Output.

Toggle the GPIO output voltage level when configured as Output.

Note: GPIO peripheral register do not get register to toggle directly. It is implemented by read back the GPIO output level and write to the register with reverted level.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

static inline uint16_t GPIO_PortRead(GPIO_Type *base)

Read High/Low voltage level for multiple GPIO pins from the pin or the data bus.

Read High/Low voltage level for multiple GPIO pins from the pin if the pin is configured as input or the data bus. When the device comes out of reset, GPIO pins are configured as inputs with internal pull disabled. As a result, the reset value of this pin is undefined. For different PORT, the available pins number is different. User need use the return value to OR with the `gpio_pin_t` to decide whether that pin is logic high or low.

```
if (GPIO_PortRead(GPIOA) & (uint16_t)kGPIO_Pin0)
{
    //GPIOA Pin 0 is High
}
else
{
    //GPIOA Pin 0 is Low
}
```

Parameters

- base – GPIO peripheral base pointer

Returns

Voltage level for multiple GPIO pins from the pin or the data bus.

static inline uint8_t GPIO_PinRead(GPIO_Type *base, *gpio_pin_t* ePin)

Read High/Low voltage level for one GPIO pin from the pin or the data bus.

Read High/Low voltage level from the pin if the pin is configured as input or the data bus.

Note: When the device comes out of reset, GPIO pins are configured as inputs with internal pull disabled. As a result, the reset value of this pin is undefined.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

Return values

- 1 – Voltage level for one GPIO pin from the pin or the data bus is high.
- 0 – Voltage level for one GPIO pin from the pin or the data bus is low.

static inline uint16_t GPIO_PortReadRawData(GPIO_Type *base)

Read Raw voltage high/low level data from the pins or peripheral bus for multiple pins belong to same PORT.

Read Raw voltage high/low level data from the pins or peripheral bus. Values are not clocked and are subject to change at any time. Read several times to ensure a stable value.

The reset value of this register depends on the default PIN state. User need use the return value to OR with the `gpio_pin_t` to decide whether that pin is logic high or low.

```
if (GPIO_PortReadRawData(GPIOA) & (uint16_t)kGPIO_Pin0)
{
    //GPIOA Pin 0 is High
}
else
{
    //GPIOA Pin 0 is Low
}
```

Parameters

- `base` – GPIO peripheral base pointer

Returns

Voltage high/low level data from the pins or peripheral bus for multiple pins belong to same PORT.

static inline uint8_t GPIO_PinReadRawData(GPIO_Type *base, *gpio_pin_t* ePin)

Read Raw logic level data from the pins or peripheral bus for one pin.

Read Raw voltage high/low level data from the pins or peripheral bus. Values are not clocked and are subject to change at any time. Read several times to ensure a stable value. The reset value of this register depends on the default PIN state.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

Return values

- 1 – Raw voltage level data from the pins or peripheral bus is high.
- 0 – Raw voltage level data from the pins or peripheral bus is low.

static inline void GPIO_PinSetInterruptConfig(GPIO_Type *base, *gpio_pin_t* ePin, *gpio_interrupt_mode_t* eIntConfig)

Configure GPIO Pin interrupt detection condition.

Configure GPIO Pin interrupt detection condition

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.
- `eIntConfig` – Interrupt detection condition for rising edge/down edge or no detection. See `gpio_interrupt_mode_t`

static inline void GPIO_PortAssertSWInterrupts(GPIO_Type *base, uint16_t u16Pins)

Assert software interrupt for multiple pins belong to same port which will generate interrupt.

This API is only for software testing of a software interrupt capability. When the software interrupt is asserted, an interrupt is generated. The interrupt is generated continually until this software interrupt is de-asserted.

Parameters

- `base` – GPIO peripheral base pointer

- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

`static inline void GPIO_PortDeassertSWInterrupts(GPIO_Type *base, uint16_t u16Pins)`

De-Assert software interrupt for multiple pins belong to same port which will stop generating interrupt.

This API is only for software testing of a software interrupt capability.

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

`static inline void GPIO_PinAssertSWInterrupt(GPIO_Type *base, gpio_pin_t ePin)`

Assert software interrupt for one pin which will generate interrupt.

This API is only for software testing of a software interrupt capability. When the software interrupt is asserted, an interrupt is generated. The interrupt is generated continually until this software interrupt is de-asserted.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

`static inline void GPIO_PinDeassertSWInterrupt(GPIO_Type *base, gpio_pin_t ePin)`

De-Assert software interrupt for one pin which will stop generating interrupt.

This API is only for software testing of a software interrupt capability.

Parameters

- `base` – GPIO peripheral base pointer
- `ePin` – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

`static inline void GPIO_PortEnableInterrupts(GPIO_Type *base, uint16_t u16Pins)`

Enable interrupt detection for multiple pins belong to same port.

This API is to enable interrupt detection on rising edge or falling edge.

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

`static inline void GPIO_PortDisableInterrupts(GPIO_Type *base, uint16_t u16Pins)`

Disable interrupt detection for multiple pins belong to same port.

This API is to disable interrupt detection on rising edge or falling edge.

Parameters

- `base` – GPIO peripheral base pointer
- `u16Pins` – GPIO pins which is ORed by `gpio_pin_t`. # `kGPIO_Pin0` | `kGPIO_Pin3` means Pin 0 and Pin 3.

`static inline void GPIO_PinEnableInterrupt(GPIO_Type *base, gpio_pin_t ePin)`

Enable interrupt detection for one pin.

This API is to enable interrupt detection on rising edge or falling edge.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

static inline void GPIO_PinDisableInterrupt(GPIO_Type *base, *gpio_pin_t* ePin)

Disable interrupt detection for one pin.

This API is to disable interrupt detection on rising edge or falling edge.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

static inline uint16_t GPIO_PortGetInterruptPendingStatusFlags(GPIO_Type *base)

Get interrupt pending status flags all pins belong to same port.

Get interrupt pending status flags for all pins belong to same port. User need to use the `gpio_pin_t` to OR with the return value, if the result is not 0, this flag is set. otherwise, this flag is not set.

Note: this flags can only be cleared by calling `GPIO_PortClearEdgeDetectedStatusFlag` if it is caused by edge detected or by calling `GPIO_PortEnableSWInterrupt` if it is caused by SW interrupt.

```
if (GPIO_PortGetInterruptPendingStatusFlags(GPIOA) & (uint16_t)kGPIO_Pin0)
{
    //Interrupt occurred on GPIOA Pin 0.
}
else
{
    //No Interrupt on GPIOA Pin 0.
}
```

Parameters

- base – GPIO peripheral base pointer

Returns

Interrupt pending status flags all pins belong to same port.

static inline uint16_t GPIO_PinGetInterruptPendingStatusFlags(GPIO_Type *base, *gpio_pin_t* ePin)

Get interrupt pending status flags for one pin.

Get interrupt pending status flags for one pin.

Note: this flags can only be cleared by calling `GPIO_PortClearEdgeDetectedStatusFlag` if it is caused by edge detected or by calling `GPIO_PortEnableSWInterrupt` if it is caused by SW interrupt.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by `gpio_pin_t`. Note that not all Pins existed in SoC and user need to check the data sheet.

Return values

- 1 – Interrupt occurred.
- 0 – No Interrupt.

static inline uint16_t GPIO_PortGetEdgeDetectedStatusFlags(GPIO_Type *base)

Get Edge detected status flags for all pins belong to same port.

Get edge detected status flags for all pins in the PORT. This status flag can only be detected when interrupt detection is enabled by GPIO_PortEnableInterrupt or GPIO_PinEnableInterrupt.

```
if (GPIO_PortGetEdgeDetectedStatusFlags(GPIOA) & (uint16_t)kGPIO_Pin0)
{
    //An edge detected on GPIOA Pin 0.
}
else
{
    //No edge detected on GPIOA Pin 0.
}
```

Parameters

- base – GPIO peripheral base pointer

Returns

Detected edge status flags for all pins belong to same port.

static inline uint8_t GPIO_PinGetEdgeDetectedStatusFlag(GPIO_Type *base, gpio_pin_t ePin)

Get Edge detected status flags for one pin.

Get edge detected status flags for one pin. This status flag can only be detected when interrupt detection is enabled by GPIO_PortEnableInterrupt or GPIO_PinEnableInterrupt.

Parameters

- base – GPIO peripheral base pointer
- ePin – GPIO pin identifier. User enumerator provided by gpio_pin_t. Note that not all Pins existed in SoC and user need to check the data sheet.

Return values

- 1 – An edge detected.
- 0 – No edge detected.

static inline void GPIO_PortClearEdgeDetectedStatusFlags(GPIO_Type *base, uint16_t u16Pins)

Clear Edge detected status flags for multiple pins belong to same port.

Clear Edge Detected status flags for multiple pins belong to same port.

Parameters

- base – GPIO peripheral base pointer
- u16Pins – GPIO pins which is Ored by gpio_pin_t. # kGPIO_Pin0 | kGPIO_Pin3 means Pin 0 and Pin 3.

static inline void GPIO_PinClearEdgeDetectedStatusFlags(GPIO_Type *base, gpio_pin_t ePin)

Clear Edge detected status flags for one pin.

Clear Edge Detected status flags for one pin.

Parameters

- base – GPIO peripheral base pointer

- ePin – GPIO pin identifier. User enumerator provided by gpio_pin_t. Note that not all Pins existed in SoC and user need to check the data sheet.

FSL_GPIO_DRIVER_VERSION

GPIO driver version.

enum __gpio_pin

GPIO Pin identifier with each pin get a unique bit thus they can be ORed.

Values:

enumerator kGPIO_Pin0

GPIO PORT Pin 0.

enumerator kGPIO_Pin1

GPIO PORT Pin 1.

enumerator kGPIO_Pin2

GPIO PORT Pin 2.

enumerator kGPIO_Pin3

GPIO PORT Pin 3.

enumerator kGPIO_Pin4

GPIO PORT Pin 4.

enumerator kGPIO_Pin5

GPIO PORT Pin 5.

enumerator kGPIO_Pin6

GPIO PORT Pin 6.

enumerator kGPIO_Pin7

GPIO PORT Pin 7.

enumerator kGPIO_Pin8

GPIO PORT Pin 8.

enumerator kGPIO_Pin9

GPIO PORT Pin 9.

enumerator kGPIO_Pin10

GPIO PORT Pin 10.

enumerator kGPIO_Pin11

GPIO PORT Pin 11.

enumerator kGPIO_Pin12

GPIO PORT Pin 12.

enumerator kGPIO_Pin13

GPIO PORT Pin 13.

enumerator kGPIO_Pin14

GPIO PORT Pin 14.

enumerator kGPIO_Pin15

GPIO PORT Pin 15.

enum __gpio_peripheral_mode

GPIO Pin peripheral/gpio mode option.

Values:

enumerator kGPIO__ModeGpio

Set GPIO pin as GPIO Mode.

enumerator kGPIO__ModePeripheral

Set GPIO pin as Peripheral Mode.

enum __gpio__direction

GPIO Pin input/output direction option.

Values:

enumerator kGPIO__DigitalInput

Set GPIO pin as digital input.

enumerator kGPIO__DigitalOutput

Set GPIO pin as digital output.

enum __gpio__pull__mode

GPIO Pin pull resistor mode option.

Values:

enumerator kGPIO__PullDown

Internal pull-down resistor is enabled.

enumerator kGPIO__PullUp

Internal pull-up resistor is enabled.

enumerator kGPIO__PullDisable

Internal pull-up/down resistor is disabled.

enum __gpio__output__mode

GPIO Pin output mode option.

Values:

enumerator kGPIO__OutputOpenDrain

Open drain output mode.

enumerator kGPIO__OutputPushPull

Push pull output mode.

enum __gpio__output__level

GPIO Pin output High/Low level option.

Values:

enumerator kGPIO__OutputLow

Set GPIO pin output low voltage level.

enumerator kGPIO__OutputHigh

Set GPIO pin output high voltage level.

enum __gpio__output__slew__rate

GPIO Pin output Fast/Slow slew rate option.

Values:

enumerator kGPIO__SlewRateFast

Set GPIO pin output Fast slew rate.

enumerator kGPIO__SlewRateSlow

Set GPIO pin output Slow slew rate.

enum *_gpio_output_drive_strength*

GPIO Pin output High/Low drive strength option.

Values:

enumerator *kGPIO_DriveStrengthLow*

Set GPIO pin output Low-drive strength.

enumerator *kGPIO_DriveStrengthHigh*

Set GPIO pin output High-drive strength.

enum *_gpio_interrupt_mode*

GPIO Pin interrupt detect option.

Values:

enumerator *kGPIO_InterruptRisingEdge*

Interrupt on rising edge.

enumerator *kGPIO_InterruptFallingEdge*

Interrupt on falling edge.

enumerator *kGPIO_InterruptDisable*

Interrupt is disabled.

typedef enum *_gpio_pin* *gpio_pin_t*

GPIO Pin identifier with each pin get a unique bit thus they can be ORed.

typedef enum *_gpio_peripheral_mode* *gpio_peripheral_mode_t*

GPIO Pin peripheral/gpio mode option.

typedef enum *_gpio_direction* *gpio_direction_t*

GPIO Pin input/output direction option.

typedef enum *_gpio_pull_mode* *gpio_pull_mode_t*

GPIO Pin pull resistor mode option.

typedef enum *_gpio_output_mode* *gpio_output_mode_t*

GPIO Pin output mode option.

typedef enum *_gpio_output_level* *gpio_output_level_t*

GPIO Pin output High/Low level option.

typedef enum *_gpio_output_slew_rate* *gpio_output_slew_rate_t*

GPIO Pin output Fast/Slow slew rate option.

typedef enum *_gpio_output_drive_strength* *gpio_output_drive_strength_t*

GPIO Pin output High/Low drive strength option.

typedef enum *_gpio_interrupt_mode* *gpio_interrupt_mode_t*

GPIO Pin interrupt detect option.

typedef struct *_gpio_config* *gpio_config_t*

GPIO Pin configuration covering all configurable fields when GPIO is configured in GPIO mode.

GPIO_MUX_ENUM_TO_PORT_INDEX(emux)

Helper MACRO function to extract Port Index. (GPIOA, GPIOB, GPIOC, and so on.) The fields located in bit 8 - bit 11.

GPIO_MUX_ENUM_TO_PIN_INDEX(emux)

Helper MACRO function to extract Pin Index. The fields located in bit 4 - bit 7.

GPIO_MUX_ENUM_TO_REG_VALUE(emux)

Helper MACRO function to extract Pin mux config register value. The fields located in bit 0 - bit 1.

GPIO_MUX_ENUM_TO_PIN_MASK(emux)

Helper MACRO function to extract Pin mux config mask.

GPIO_MUX_ENUM_TO_PIN_VALUE(emux)

Helper MACRO function to extract Pin mux config register value on a GPIO Pin.

struct __gpio_config

#include <fsl_gpio.h> GPIO Pin configuration covering all configurable fields when GPIO is configured in GPIO mode.

Public Members

gpio_direction_t eDirection

GPIO direction, input or output

gpio_peripheral_mode_t eMode

GPIO mode as peripheral or GPIO

gpio_peripheral_mux_t eMux

Set the peripheral type if GPIO is configured as peripheral

gpio_output_mode_t eOutMode

GPIO Open-Drain/Push-Pull output mode.

gpio_output_slew_rate_t eSlewRate

GPIO Fast/Slow slew rate output mode.

gpio_output_level_t eOutLevel

GPIO Output High/Low level.

gpio_output_drive_strength_t eDriveStrength

GPIO output Drive strength High/Low.

gpio_pull_mode_t ePull

GPIO Pull resistor mode configuration.

gpio_interrupt_mode_t eInterruptMode

GPIO interrupt detection condition configuration.

2.41 The Driver Change Log

2.42 GPIO Peripheral and Driver Overview

2.43 I2C: Inter-Integrated Circuit Driver

void I2C_MasterGetDefaultConfig(*i2c_master_config_t* *psMasterConfig, uint32_t u32SrcClockHz)

Sets the I2C master configuration structure to default values.

The purpose of this API is to initialize the configuration structure to default value for I2C_MasterInit to use. Use the unchanged structure in I2C_MasterInit or modify the structure before calling I2C_MasterInit. This is an example:

```
i2c_master_config_t config;
I2C_MasterGetDefaultConfig(&config, 12000000U);
config.u32BaudRateBps = 100000;
I2C_MasterInit(I2C0, &config);
```

Parameters

- psMasterConfig – Pointer to the master configuration structure.
- u32SrcClockHz – The clock source frequency for I2C module.

void I2C_MasterInit(I2C_Type *base, const i2c_master_config_t *psMasterConfig)

Initializes the I2C peripheral to operate as master.

This API initialize the I2C module for master operation, including the feature configuration of high drive capacity, double buffer, glitch filter, SCL timeout value, stop hold off enable and transfer baudrate. User can also configure whether to enable the module in the function.

The configuration structure can be filled manually or be set with default values by calling I2C_MasterGetDefaultConfig. This is an example.

```
I2C_MasterGetDefaultConfig(&config, 12000000U);
I2C_MasterInit(I2C0, &config);
```

Note: If FSL_SDK_DISABLE_DRIVER_CLOCK_CONTROL is enabled by user, the init function will not ungate I2C clock source before initialization, to avoid hardfault, user has to manually enable ungate the clock source before calling the API

Parameters

- base – I2C base pointer
- psMasterConfig – Pointer to the master configuration structure

void I2C_MasterDeinit(I2C_Type *base)

De-initializes the I2C peripheral. Call this API to disable the I2C module.

Parameters

- base – I2C base pointer

void I2C_SlaveGetDefaultConfig(i2c_slave_config_t *psSlaveConfig, uint16_t u16PrimaryAddress, uint32_t u32SrcClockHz)

Sets the I2C slave configuration structure to default values.

The purpose of this API is to initialize the configuration structure for I2C_SlaveInit to use. Use the unchanged initialized structure in I2C_SlaveInit or modify the structure before calling I2C_SlaveInit. This is an example.

```
i2c_slave_config_t config;
I2C_SlaveGetDefaultConfig(&config, 0x23U, 12000000U);
```

Parameters

- psSlaveConfig – Pointer to the slave configuration structure.
- u16PrimaryAddress – For 7-bit address low 7-bit is used, for 10-bit address low 10-bit is used.
- u32SrcClockHz – The clock source frequency for I2C module.

`void I2C_SlaveInit(I2C_Type *base, const i2c_slave_config_t *psSlaveConfig)`

Initializes the I2C peripheral to operate as slave.

This API initialize the I2C module for slave operation, including the feature configuration of high drive capacity, double buffer, glitch filter, SCL timeout value, stop hold off enable, addressing mode, alert response/general call monitoring, auto baudrate control, low power mode wake up, SCL/SDA setup and hold time. User can also configure whether to enable the module in the function.

The configuration structure can be filled manually or be set with default values by calling `I2C_SlaveGetDefaultConfig`. This is an example.

```
i2c_slave_config_t sConfig;
I2C_SlaveGetDefaultConfig(&sConfig, 12000000U);
sConfig.u8PrimaryAddress = 0x2AU;
I2C_SlaveInit(I2C0, &sConfig);
```

Note: If `FSL_SDK_DISABLE_DRIVER_CLOCK_CONTROL` is enabled by user, the init function will not ungate I2C clock source before initialization, to avoid hardfault, user has to manually enable ungate the clock source before calling the API

Parameters

- `base` – I2C base pointer
- `psSlaveConfig` – Pointer to the slave configuration structure

`static inline void I2C_SlaveDeinit(I2C_Type *base)`

De-initializes the I2C peripheral. Call this API to disable the I2C module.

Parameters

- `base` – I2C base pointer

`void I2C_GetDefaultConfig(i2c_config_t *psConfig, uint16_t u16PrimaryAddress, uint32_t u32SrcClockHz)`

Sets the I2C configuration structure to default values.

The purpose of this API is to initialize the configuration structure for `I2C_Init` to use. Use the unchanged initialized structure in `I2C_Init` or modify the structure before calling `I2C_Init`. This is an example.

```
i2c_config_t config;
I2C_GetDefaultConfig(&config, 0x23U, 12000000U);
```

Parameters

- `psConfig` – Pointer to the slave configuration structure.
- `u16PrimaryAddress` – For 7-bit address low 7-bit is used, for 10-bit address low 10-bit is used.
- `u32SrcClockHz` – The clock source frequency for I2C module.

`void I2C_Init(I2C_Type *base, const i2c_config_t *psConfig)`

Initializes the I2C peripheral.

This API initialize the I2C module, including the feature configuration of high drive capacity, double buffer, glitch filter, SCL timeout value, stop hold off enable, addressing mode, alert response/general call monitoring, auto baudrate control, low power mode wake up and baudrate. User can also configure whether to enable the module in the function.

The configuration structure can be filled manually or be set with default values by calling `I2C_GetDefaultConfig`. This is an example.

```
i2c_config_t sConfig;  
I2C_GetDefaultConfig(&sConfig, 0x23U, 12000000U);  
I2C_Init(I2C0, &sConfig);
```

Note: If `FSL_SDK_DISABLE_DRIVER_CLOCK_CONTROL` is enabled by user, the init function will not ungate I2C clock source before initialization, to avoid hardfault, user has to manually enable ungate the clock source before calling the API

Parameters

- base – I2C base pointer
- psConfig – Pointer to the I2C configuration structure

static inline void I2C_Deinit(I2C_Type *base)

De-initializes the I2C peripheral. Call this API to disable the I2C module.

Parameters

- base – I2C base pointer

uint16_t I2C_MasterGetStatusFlags(I2C_Type *base)

Gets the I2C master hardware status flags.

Parameters

- base – I2C base pointer

Returns

the mask of status flags, can be a single flag or several flags in `_i2c_status_flags` ORed together.

static inline void I2C_MasterClearStatusFlags(I2C_Type *base, uint16_t u16StatusFlags)

Clears the I2C master status flags.

Parameters

- base – I2C base pointer
- u16StatusFlags – The status flag mask, can be a single flag or several flags in `_i2c_status_flags` ORed together. These flags among `_i2c_status_flags` can be cleared:
 - `kI2C_StartDetectInterruptFlag` (only supported on certain SoCs)
 - `kI2C_StopDetectInterruptFlag` (only supported on certain SoCs)
 - `kI2C_ArbitrationLostInterruptFlag`
 - `kI2C_InterruptPendingFlag`
 - `kI2C_RangeAddressMatchInterruptFlag`
 - `kI2C_AddressAsSlaveInterruptFlag`
 - `kI2C_SclLowTimeoutFlag`
 - `kI2C_SdaLowTimeoutInterruptFlag`

```
static inline uint16_t I2C_SlaveGetStatusFlags(I2C_Type *base)
```

Gets the I2C slave hardware status flags.

Parameters

- base – I2C base pointer

Returns

the mask of status flags, can be a single flag or several flags in `_i2c_status_flags` ORed together.

```
static inline void I2C_SlaveClearStatusFlags(I2C_Type *base, uint16_t u16StatusFlags)
```

Clears the I2C slave status flags.

Parameters

- base – I2C base pointer
- u16StatusFlags – The status flag mask, can be a single flag or several flags in `_i2c_status_flags` ORed together. These flags among `_i2c_status_flags` can be cleared:
 - `kI2C_StartDetectInterruptFlag` (only supported on certain SoCs)
 - `kI2C_StopDetectInterruptFlag` (only supported on certain SoCs)
 - `kI2C_ArbitrationLostInterruptFlag`
 - `kI2C_InterruptPendingFlag`
 - `kI2C_RangeAddressMatchInterruptFlag`
 - `kI2C_AddressAsSlaveInterruptFlag`
 - `kI2C_SclLowTimeoutFlag`
 - `kI2C_SdaLowTimeoutInterruptFlag`

```
void I2C_EnableInterrupts(I2C_Type *base, uint8_t u8Interrupts)
```

Enables I2C interrupt source.

Note: Before enabling `kI2C_GlobalInterruptEnable`, check `kI2C_RangeAddressMatchInterruptFlag` and `kI2C_AddressAsSlaveInterruptFlag` first, because any write operation on C1 will clear these 2 bits.

Parameters

- base – I2C base pointer
- u8Interrupts – The interrupt source mask, can be a single source or several sources in `_i2c_interrupt_enable` ORed together.

```
void I2C_DisableInterrupts(I2C_Type *base, uint8_t u8Interrupts)
```

Disables I2C interrupt source.

Note: Before disabling `kI2C_GlobalInterruptEnable`, check `kI2C_RangeAddressMatchInterruptFlag` and `kI2C_AddressAsSlaveInterruptFlag` first, because any write operation on C1 will clear these 2 bits.

Parameters

- base – I2C base pointer
- u8Interrupts – The interrupt source mask, can be a single source or several sources in `_i2c_interrupt_enable` ORed together.

uint8_t I2C_GetEnabledInterrupts(I2C_Type *base)

Get all the enabled interrupt sources.

Parameters

- base – I2C base pointer

Returns

The interrupt source mask, can be a single source or several sources in _i2c_interrupt_enable ORed together.

static inline bool I2C_IsMaster(I2C_Type *base)

Returns whether the I2C module is in master mode.

Parameters

- base – I2C base pointer

Returns

True for master mode, false for slave mode.

static inline void I2C_Reset(I2C_Type *base)

Sets the I2C register value to reset value.

Parameters

- base – I2C base pointer

static inline void I2C_Enable(I2C_Type *base, bool bEnable)

Enables or disables the I2C peripheral operation.

Parameters

- base – I2C base pointer
- bEnable – Pass true to enable and false to disable the module.

static inline void I2C_EnableFastAck(I2C_Type *base, bool bEnable)

Enables/Disables fast NACK/ACK feature.

When enabled, writing 0/1 to TXAK generates an ACK/NACK after receiving a data byte, when disabled, writing 0/1 to TXAK generates an ACK/NACK on the following receiving data byte.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

static inline void I2C_EnableHighDrive(I2C_Type *base, bool bEnable)

Enables/Disables high drive.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

static inline void I2C_EnableStopHold(I2C_Type *base, bool bEnable)

Enables/Disables double buffer.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

static inline void I2C_SetTransferDirection(I2C_Type *base, *i2c_data_direction_t* eDataDirection)
Sets I2C module data direction.

Parameters

- base – I2C base pointer
- eDataDirection – kI2C_Write to write data to bus, kI2C_Read to read data from bus

void I2C_SetSclTimeoutValue(I2C_Type *base, uint16_t u16SclTimeout_Ms, uint32_t u32SrcClockHz)

brief Sets the I2C SCL timeout value.

After the I2C module is initialized, user can call this function to change the timeout value.

param base I2C base pointer. param u16SclTimeout_Ms The SCL timeout value in ms. param u32SrcClockHz I2C peripheral clock frequency in Hz

void I2C_SetGlitchFilter(I2C_Type *base, uint16_t u16GlitchFilter_Ns, uint32_t u32SrcClockHz)
brief Sets the I2C master glitch filter width.

After the I2C module is initialized as master, user can call this function to change the glitch filter width.

param base I2C base pointer. param u16GlitchFilter_Ns The GLitch filter length in nano seconds. param u32SrcClockHz I2C peripheral clock frequency in Hz

static inline void I2C_EnableDMA(I2C_Type *base, bool bEnable)
Enables/disables the I2C DMA request.

Parameters

- base – I2C base pointer
- bEnable – true to enable, false to disable

static inline uint32_t I2C_GetDataRegAddr(I2C_Type *base)

Gets the I2C data register address. This API is used to provide the transfer address for I2C DMA transfer.

Parameters

- base – I2C base pointer

Returns

data register address

static inline void I2C_SlaveEnableAlertResponse(I2C_Type *base, bool bEnable)
Enables/Disables alert response.

When enabled, I2C slave will monitor the bus line, and when alert response address is received address match status flag will be set.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

static inline void I2C_SlaveEnableSecondaryAddress(I2C_Type *base, bool bEnable)
Enables/Disables secondary address.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

```
static inline void I2C_SlaveEnableGeneralCall(I2C_Type *base, bool bEnable)
```

Enables/Disables general call.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

```
static inline void I2C_SlaveEnableWakeUp(I2C_Type *base, bool bEnable)
```

Enables/Disables slave low power wakeup.

Parameters

- base – I2C base pointer
- bEnable – True to enable, false to disable.

```
void I2C_SlaveSetAddressingMode(I2C_Type *base, i2c_slave_address_mode_t eAddressingMode,  
                               uint16_t u16Address, uint8_t u8MaxAddress)
```

Configure the slave addressing mode.

After the I2C module is initialized as slave, user can call this function to change the configuration of slave addressing mode.

Parameters

- base – I2C base pointer.
- eAddressingMode – The slave addressing mode, single address or range address.
- u16Address – I2C slave address. For 7-bit address low 7-bit is used, for 10-bit address low 10-bit is used.
- u8MaxAddress – The maximum boundary of slave address used in a range address match.

```
void I2C_MasterSetBaudRate(I2C_Type *base, uint32_t u32BaudRateBps, uint32_t  
                           u32SrcClockHz)
```

Sets the I2C master transfer baud rate.

After the I2C module is initialized as master, user can call this function to change the transfer baud rate.

Parameters

- base – I2C base pointer.
- u32BaudRateBps – the baud rate value in bits-per-second.
- u32SrcClockHz – I2C peripheral clock frequency in Hz

```
static inline uint8_t I2C_ReadByte(I2C_Type *base)
```

Reads one byte from data register directly.

Parameters

- base – I2C base pointer

Returns

The data read from data register.

```
static inline void I2C_WriteByte(I2C_Type *base, uint8_t u8Data)
```

Writes one byte to the data register directly.

Parameters

- base – I2C base pointer
- u8Data – The byte to write.

```
static inline void I2C_SendAck(I2C_Type *base, bool bIsAck)
```

Sends an acknowledge/non-acknowledge signal to the bus on the following receiving byte if SMB[FAACK] is cleared, or on the current receiving byte if SMB[FAACK] is set.

Parameters

- base – I2C base pointer
- bIsAck – True to send ACK signal, false to send NACK signal

```
status_t I2C_MasterStart(I2C_Type *base, uint8_t u8Address, i2c_master_transfer_direction_t eDirection)
```

Sends a START signal on the I2C bus then the 7-bit slave address with transmit/receive bit.

This function is used to initiate a new transfer in master mode, by sending a START signal, then the slave address with transmit/receive bit to I2C bus.

Note: The return value of this API only indicates whether the start signal is sent to bus, user has to check kI2C_ArbitrationLostInterruptFlag and kI2C_ReceiveNakFlag using I2C_MasterClearStatusFlags to see if valid slave device is available or the arbitration is lost.

Parameters

- base – I2C base pointer
- u8Address – 7-bit slave device address.
- eDirection – Master transfer directions(transmit/receive).

Return values

- kStatus_I2C_Timeout – Transfer error, timeout happens when waiting for status flags to change.
- kStatus_Success – Successfully send the start signal.
- kStatus_I2C_Busy – Current bus is busy.

```
status_t I2C_MasterRepeatedStart(I2C_Type *base, uint8_t u8Address, i2c_master_transfer_direction_t eDirection)
```

Sends a repeated START signal, then the 7-bit slave address with transmit/receive bit to I2C bus.

Parameters

- base – I2C peripheral base pointer
- u8Address – 7-bit slave device address.
- eDirection – Master transfer directions(transmit/receive).

Return values

- kStatus_I2C_Timeout – Transfer error, timeout happens when waiting for status flags to change.
- kStatus_Success – Successfully send the start signal.
- kStatus_I2C_Busy – Current bus is busy but not occupied by current I2C master.

```
status_t I2C_MasterStop(I2C_Type *base)
```

Sends a STOP signal on the I2C bus.

Parameters

- base – I2C base pointer

Return values

- `kStatus_Success` – Successfully send the stop signal.
- `kStatus_I2C_Timeout` – Send stop signal failed, timeout.

status_t I2C_MasterWriteBlocking(I2C_Type *base, const uint8_t *pu8Data, uint16_t txSize, bool bSendStop)

Sends a piece of data to I2C bus in master mode in blocking way.

Call this function when using I2C as master to send certain bytes of data to bus when start signal is already sent. User can specify whether to send a stop signal after the data. This function uses the blocking way, which means it does not return until all the data is sent to bus and stop signal is successfully issued(if user configures the stop signal).

Parameters

- `base` – I2C base pointer.
- `pu8Data` – The pointer to the data to be transmitted.
- `txSize` – The length in bytes of the data to be transmitted.
- `bSendStop` – Whether to send stop signal after the data transfer.

Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.
- `kStatus_I2C_Timeout` – Transfer error, timeout happens when waiting for status flags to change.

status_t I2C_MasterReadBlocking(I2C_Type *base, uint8_t *pu8RxBuff, uint16_t rxSize, bool bSendStop)

Receives a piece of data from I2C bus in master mode in blocking way.

Call this function when using I2C as master to receive certain bytes of data from bus when start signal is already sent. User can specify whether to send a stop signal after the data. This function uses the blocking way, which means it does not return until all the data has been received and stop signal is successfully issued(if user configures the stop signal).

Note: If user configures to send stop signal after the data, this function stops the bus before reading the final byte from data register. Without stopping the bus prior to the final read, the bus will issue another read, resulting in garbage data being read into the data register.

Parameters

- `base` – I2C base pointer.
- `pu8RxBuff` – The pointer to the data to store the received data.
- `rxSize` – The length in bytes of the data to be received.
- `bSendStop` – Whether to send stop signal after the data transfer.

Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_Timeout` – Send stop signal failed, timeout.

status_t I2C_SlaveWriteBlocking(I2C_Type *base, const uint8_t *pu8TxBuff, uint16_t txSize)

Sends a piece of data to I2C bus in slave mode in blocking way.

Call this funtion to let I2C slave poll register status until it is addressed, then slave sends txSize of data to bus until all the data has been sent to bus or untill it is nacked.

Parameters

- `base` – I2C base pointer.
- `pu8TxBuff` – The pointer to the data to be transferred.
- `txSize` – The length in bytes of the data to be transferred.

Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.
- `kStatus_I2C_Timeout` – Transfer error, timeout happens when waiting for status flags to change.

status_t I2C_SlaveReadBlocking(I2C_Type *base, uint8_t *pu8RxBuff, uint16_t rxSize)

Receives a piece of data from I2C bus in slave mode in blocking way.

Call this funtion to let I2C slave poll register status until it is addressed, then slave receives rxSize of data until all the data has been received.

Parameters

- `base` – I2C base pointer.
- `pu8RxBuff` – The pointer to the data to store the received data.
- `rxSize` – The length in bytes of the data to be received.

Return values

- `kStatus_Success` – Successfully complete data receive.
- `kStatus_I2C_Timeout` – Wait status flag timeout.

status_t I2C_MasterTransferBlocking(I2C_Type *base, i2c_master_transfer_t *psTransferConfig)

Performs a master polling transfer on the I2C bus.

Note: The API does not return until the transfer succeeds or fails due to arbitration lost or receiving a NAK.

Parameters

- `base` – I2C peripheral base address.
- `psTransferConfig` – Pointer to the transfer configuration structure.

Return values

- `kStatus_Success` – Successfully complete the data transmission.
- `kStatus_I2C_Busy` – Previous transmission still not finished.
- `kStatus_I2C_Timeout` – Transfer error, timeout happens when waiting for status flagsto change.

- `kStatus_I2C_ArbitrationLost` – Transfer error, arbitration lost.
- `kStatus_I2C_Nak` – Transfer error, receive NAK during transfer.

```
void I2C_MasterTransferCreateHandle(I2C_Type *base, i2c_master_transfer_handle_t *psHandle,  
                                   i2c_master_transfer_callback_t pfCallback, void  
                                   *pUserData)
```

Initializes the I2C master transfer in interrupt way.

This function is responsible for initializing master transfer `psHandle`, installing user callback, registering master IRQ handling function and opening global interrupt.

Parameters

- `base` – I2C base pointer.
- `psHandle` – pointer to `i2c_master_transfer_handle_t` structure to store the transfer state.
- `pfCallback` – pointer to user callback function.
- `pUserData` – User configurable pointer to any data, function, structure etc that user wish to use in the callback

```
status_t I2C_MasterTransferNonBlocking(i2c_master_transfer_handle_t *psHandle,  
                                       i2c_master_transfer_t *psTransferConfig)
```

Initiates a master transfer on the I2C bus in interrupt way.

Note: Transfer in interrupt way is non-blocking which means this API returns immediately after transfer initiates. User can call `I2C_MasterTransferGetCount` to get the count of data that master has transmitted/received and check transfer status. If the return status is `kStatus_NoTransferInProgress`, the transfer is finished. Also if user installs a user callback when calling `I2C_MasterTransferCreateHandle` before, the callback will be invoked when transfer finishes.

Parameters

- `psHandle` – pointer to `i2c_master_transfer_handle_t` structure which stores the transfer state.
- `psTransferConfig` – Pointer to the transfer configuration structure.

Return values

- `kStatus_Success` – Successfully start the data transmission.
- `kStatus_I2C_Busy` – Previous transmission still not finished.
- `kStatus_I2C_Timeout` – Transfer error, timeout happens when waiting for status flag to change.

```
status_t I2C_MasterTransferGetCount(i2c_master_transfer_handle_t *psHandle, uint16_t *count)
```

Gets the master transfer count and status during a interrupt transfer.

Parameters

- `psHandle` – pointer to `i2c_master_transfer_handle_t` structure which stores the transfer state.
- `count` – Pointer to number of bytes transferred so far by the non-blocking transaction.

Return values

- `kStatus_InvalidArgument` – `count` is Invalid.
- `kStatus_NoTransferInProgress` – Current no transfer is in progress.

- `kStatus_Success` – Successfully obtained the count.

status_t I2C_MasterTransferAbort(*i2c_master_transfer_handle_t* *psHandle)

Aborts an in-process transfer in interrupt way.

Note: This API can be called at any time after a transfer of interrupt way initiates and before it finishes to abort the transfer early.

Parameters

- `psHandle` – pointer to `i2c_master_transfer_handle_t` structure which stores the transfer state

Return values

- `kStatus_I2C_Busy` – Master lost arbitration, bus is in use by other master.
- `kStatus_I2C_Timeout` – Transfer error, timeout happens when waiting for status flags to change.
- `kStatus_Success` – Successfully abort the transfer.

void I2C_SlaveTransferCreateHandle(*I2C_Type* *base, *i2c_slave_transfer_handle_t* *psHandle, *i2c_slave_transfer_callback_t* pfCallback, *void* *pUserData)

Initializes the I2C slave transfer in interrupt way.

This function is responsible for initializing slave transfer handle, installing user callback, registering slave IRQ handling function and opening global interrupt.

Parameters

- `base` – I2C base pointer.
- `psHandle` – pointer to `i2c_slave_transfer_handle_t` structure to store the transfer state.
- `pfCallback` – pointer to user callback function.
- `pUserData` – User configurable pointer to any data, function, structure etc that user wish to use in the callback

status_t I2C_SlaveTransferNonBlocking(*i2c_slave_transfer_handle_t* *psHandle, *i2c_slave_transfer_t* *psTransferConfig)

Sets I2C slave ready to process bus events.

Call this API to let I2C start monitoring bus events driven by I2C master on bus. When user specified event occurs, callback will be invoked passes event information to the callback.

Note: When `kI2C_SlaveOutOfTransmitDataEvent` and `kI2C_SlaveOutOfReceiveSpaceEvent` occurred, slave callback will always be revoked regardless which events user choose to enable. This means user need not configure them in the `psTransferConfig`. If user wants to enable all the events, use `kI2C_SlaveAllEvents` for convenience.

Parameters

- `psHandle` – Pointer to `i2c_slave_transfer_handle_t` structure which stores the transfer state.
- `psTransferConfig` – I2C transfer configuration.

Return values

- `kStatus_Success` – I2C slave set to standby state successfully and ready to process events.

- `kStatus_I2C_Busy` – I2C slave has already been started on this handle.

status_t I2C_SlaveTransferGetCount(*i2c_slave_transfer_handle_t* *psHandle, uint16_t *count)

Gets how many bytes slave have transferred in current data buffer.

Parameters

- `psHandle` – pointer to `i2c_slave_transfer_handle_t` structure.
- `count` – Number of bytes slave have transferred after the last start/repeated start.

Return values

- `kStatus_InvalidArgument` – `count` is Invalid.
- `kStatus_NoTransferInProgress` – Current no transfer is in progress.
- `kStatus_Success` – Successfully obtained the count.

void I2C_SlaveTransferAbort(*i2c_slave_transfer_handle_t* *psHandle)

Aborts the slave transfer.

Note: This API can be called at any time to stop slave for handling further bus events.

Parameters

- `psHandle` – pointer to `i2c_slave_transfer_handle_t` structure which stores the transfer state.

FSL_I2C_DRIVER_VERSION

I2C driver version.

I2C API status codes, used by bus operation APIs and transactional APIs as return value to indicate the bus's current status as the API's execution result, or used in the callback to indicate transfer results.

Values:

enumerator `kStatus_I2C_Busy`

I2C bus is busy.

enumerator `kStatus_I2C_Idle`

I2C Bus is idle.

enumerator `kStatus_I2C_Nak`

I2C detected NACK on bus. When in SMBus mode, this means the receiver nacks transmitter before PEC byte.

enumerator `kStatus_I2C_ArbitrationLost`

I2C lost arbitration during addressing.

enumerator `kStatus_I2C_Timeout`

Timeout happens when waiting for status flags to change.

enumerator `kStatus_I2C_Addr_Nak`

NACK was detected during the address probe.

enumerator `kStatus_I2C_Pec_Error`

Detected NACK for the PEC byte in transmit, or the received PEC does not match with the calculated CRC.

enum `_i2c_status_flags`

I2C hardware status flags.

These enumerations can be ORed together to form bit masks. The masks can be used as parameter by `I2C_MasterClearStatusFlags` and `I2C_SlaveClearStatusFlags`, or as return value by `I2C_MasterGetStatusFlags` and `I2C_SlaveGetStatusFlags`.

Values:

enumerator `kI2C_ReceiveNakFlag`

I2C received none ack flag

enumerator `kI2C_InterruptPendingFlag`

I2C interrupt pending flag. Byte transfer complete, address match, arbitration lost, start/stop detection and SMBus timeout can all cause this status bit to set. This flag can be cleared.

enumerator `kI2C_SlaveTransmitFlag`

I2C slave write/read status flag

enumerator `kI2C_RangeAddressMatchInterruptFlag`

Received address is within address range. This flag can be cleared.

enumerator `kI2C_ArbitrationLostInterruptFlag`

This flag can be cleared.

enumerator `kI2C_BusBusyFlag`

I2C bus busy flag.

enumerator `kI2C_AddressAsSlaveInterruptFlag`

Addressed as slave, including general call, alert response, primary/secondary address and range address match. This flag can be cleared.

enumerator `kI2C_ByteTransferCompleteInterruptFlag`

I2C transfer complete flag.

enumerator `kI2C_StopDetectInterruptFlag`

This flag can be cleared.

enumerator `kI2C_StartDetectInterruptFlag`

This flag can be cleared.

enumerator `kI2C_SclLowTimeoutFlag`

I2C SCL signal low timeout flag. This flag can be cleared.

enumerator `kI2C_BusIdleFlag`

I2C SCL and SDA both high timeout flag indicating bus idle.

enumerator `kI2C_SdaLowTimeoutInterruptFlag`

I2C SDA signal low timeout flag. This flag can be cleared.

enumerator `kI2C_StatusAllFlags`

All flags which are clearable.

enum `_i2c_interrupt_enable`

I2C interrupt enable/disable source.

These enumerations can be ORed together to form bit masks. The masks can be used as parameter by `I2C_EnableInterrupts`, `I2C_DisableInterrupts`, or as return value by `I2C_GetEnabledInterrupts`.

Values:

enumerator kI2C_GlobalInterruptEnable

I2C global interrupt.

enumerator kI2C_StartStopDetectInterruptEnable

I2C start&stop detect interrupt.

enumerator kI2C_SdaLowTimeoutInterruptEnable

I2C SDA low timeout interrupt.

enumerator kI2C_AllInterruptEnable

enum _i2c_slave_address_mode

Slave addressing mode, address match or range address match.

Values:

enumerator kI2C_AddressMatch

7-bit addressing mode.

enumerator kI2C_AddressRangeMatch

Range address match addressing mode.

enumerator kI2C_AddressMatch10bit

10-bit addressing mode.

enum _i2c_data_direction

Peripheral data direction.

Values:

enumerator kI2C_Read

I2C read data from bus.

enumerator kI2C_Write

I2C write data to bus.

enum _i2c_master_transfer_control_flags

I2C master transfer control flags.

These flags can be ORed together to form bit mask. The mask is used to configure master transfer's start/stop condition in i2c_master_transfer_t::u8ControlFlagMask.

Values:

enumerator kI2C_TransferStartStopFlag

A transfer starts with a start signal, stops with a stop signal.

enumerator kI2C_TransferNoStartFlag

A transfer starts without a start signal, only support write only or write+read with no start flag, do not support read only with no start flag.

enumerator kI2C_TransferRepeatedStartFlag

A transfer starts with a repeated start signal.

enumerator kI2C_TransferNoStopFlag

A transfer ends without a stop signal.

enum _i2c_master_transfer_direction

Master transfer direction.

Values:

enumerator kI2C_MasterTransmit

Master transmits data to slave.

enumerator `ki2C_MasterReceive`

Master receives data from slave.

enum `_i2c_slave_transfer_event`

Set of slave transfer events.

This enumeration lists all the protocol level events that may happen during slave transfer. They can be used for two related purposes:

- a. User can select certain events and combined them by OR operation to form a mask, and use the mask to configure slave transfer configuration structure `i2c_slave_transfer_t::u8EventMask`. If any of these selected events happens, driver will alert user by invoking callback.
- b. When slave callback is invoked, user has to know which specific event occurred. Callback uses slave transfer configuration structure `i2c_slave_transfer_t` as 2nd parameter; its member `i2c_slave_transfer_t::eEvent` shows which event just happened.

Values:

enumerator `ki2C_SlaveAddressMatchEvent`

Slave detects general call or alert response address, or primary/secondary/range address is matched after a start or repeated start.

enumerator `ki2C_SlaveOutOfTransmitDataEvent`

Slave runs out of data to transmit, request a new data buffer.

enumerator `ki2C_SlaveOutOfReceiveSpaceEvent`

Slave runs out of space to store received data, request a new data buffer.

enumerator `ki2C_SlaveStartEvent`

A start/repeated start was detected.

enumerator `ki2C_SlaveCompletionEvent`

Slave detects a stop signal, or slave is nacked by master during master-receive, or slave has finished transmit/receive previously configured amount of data.

enumerator `ki2C_SlaveGeneralCallEvent`

Received the general call address after a start or repeated start.

enumerator `ki2C_SlaveAllEvents`

A bit mask of all available events.

typedef struct `_i2c_master_config` `i2c_master_config_t`

I2C master configuration structure.

This structure includes all the master operation needed features, user can configure these features one by one manually, or call `I2C_MasterGetDefaultConfig` to set the structure to default value. Then, call `I2C_MasterInit` to initialize I2C module. After initialization, the I2C module can only operate as master. To deinitialize I2C, call `I2C_MasterDeinit`.

typedef enum `_i2c_slave_address_mode` `i2c_slave_address_mode_t`

Slave addressing mode, address match or range address match.

typedef struct `_i2c_slave_config` `i2c_slave_config_t`

I2C slave configuration structure.

This structure includes all the slave operation needed features, user can configure these features one by one manually, or call `I2C_SlaveGetDefaultConfig` to set the structure to default value. Then, call `I2C_SlaveInit` to initialize I2C module. After initialization, the I2C module can only operate as slave. To deinitialize I2C, call `I2C_SlaveDeinit`.

```
typedef struct _i2c_config i2c_config_t
```

I2C configuration structure.

This structure includes all I2C features, user can configure user can configure these features one by one manually, or call `I2C_GetDefaultConfig` to set the structure to default value. Then, call `I2C_Init` to initialize I2C module. To deinitialize I2C, call `I2C_Deinit`.

```
typedef enum _i2c_data_direction i2c_data_direction_t
```

Peripheral data direction.

```
typedef enum _i2c_master_transfer_direction i2c_master_transfer_direction_t
```

Master transfer direction.

```
typedef struct _i2c_master_transfer i2c_master_transfer_t
```

I2C master transfer configuration structure.

This structure definition includes all the user configurable features, that are used to control single I2C transfer of master mode, in polling way or in interrupt way.

```
typedef struct _i2c_master_transfer_handle i2c_master_transfer_handle_t
```

Forward declaration of the I2C master transfer handle structure. .

```
typedef void (*i2c_master_transfer_callback_t)(i2c_master_transfer_handle_t *psHandle)
```

I2C master transfer callback function definition.

Defines the interface of user callback function used in master interrupt transfer. The callback function shall be defined and declared in application level by user. Before starting master transfer by calling `I2C_MasterTransferNonBlocking`, call `I2C_MasterTransferCreateHandle` to install the user callback. When master transfer ends successfully or failed due to any event like arbitration lost or nacked by slave, user callback will be invoked by driver. And then user can decide what to do next in the callback according to its parameter completionStatus which indicates how the transfer ends.

Param psHandle

I2C transfer handle, which contains the information of base pointer, completionStatus and user data.

```
typedef enum _i2c_slave_transfer_event i2c_slave_transfer_event_t
```

Set of slave transfer events.

This enumeration lists all the protocol level events that may happen during slave transfer. They can be used for two related purposes:

- a. User can select certain events and combined them by OR operation to form a mask, and use the mask to configure slave transfer configuration structure `i2c_slave_transfer_t::u8EventMask`. If any of these selected events happens, driver will alert user by invoking callback.
- b. When slave callback is invoked, user has to know which specific event occurred. Callback uses slave transfer configuration structure `i2c_slave_transfer_t` as 2nd parameter, its member `i2c_slave_transfer_t::eEvent` shows which event just happened.

```
typedef struct _i2c_slave_transfer i2c_slave_transfer_t
```

I2C slave transfer configuration structure.

Covers slave transfer data buffer pointer, data size and the events user want driver to alert.

Note: Unlike master who controls the transfer flow, slave has to monitor any bus event and change its configuration accordingly. So this slave transfer configuration structure is also used as second parameter of callback, for user to change the transfer configuration in the callback. The read-only member `eEvent` shows which event occurred that causes the callback being invoked.

```
typedef struct _i2c_slave_transfer_handle i2c_slave_transfer_handle_t
```

Forward declaration of the I2C slave transfer handle structure. .

```
typedef void (*i2c_slave_transfer_callback_t)(i2c_slave_transfer_handle_t *psHandle)
```

I2C slave transfer callback function definition.

Defines the interface of slave user callback function. The callback function shall be defined and declared in application level by user. Before calling I2C_SlaveTransferNonBlocking to let I2C slave ready to process bus events, call I2C_SlaveTransferCreateHandle first to install the user callback to slave handle. When I2C slave meets user selected events, callback will be invoked and user can decide the following steps in the callback. All the events that can trigger callback are listed in i2c_slave_transfer_event_t.

Param psHandle

I2C transfer handle, which contains the information of base pointer, completionStatus transfer data, data length and user data.

```
uint32_t I2C_GetInstance(I2C_Type *base)
```

Gets instance number for I2C module.

Parameters

- base – I2C base pointer.

Return values

The – number of the instance.

```
I2C_HAS_STOP_DETECT
```

```
I2C_RETRY_TIMES
```

Retry times when checking status flags.

```
I2C_SMBUS_ENABLE
```

Control whether to use SMBus features.

```
I2C_MASTER_FACK_CONTROL
```

Control whether to enable FACK for master read operation in non SMBus transfer. This is used to lower transfer speed by clock stretch for MCU with FSL_FEATURE_I2C_HAS_DOUBLE_BUFFERING supported and enabled.

```
I2C_GET_TRANSFER_COMPLETION_STATUS(psHandle)
```

```
I2C_GET_TRANSFER_USER_DATA(psHandle)
```

```
I2C_GET_SLAVE_TRANSFER_EVENT(psHandle)
```

```
I2C_GET_SLAVE_TRANSFER_DATA_POINTER(psHandle)
```

```
I2C_GET_SLAVE_TRANSFER_DATASIZE(psHandle)
```

```
I2C_GET_SLAVE_TRANSFERRED_COUNT(psHandle)
```

```
struct _i2c_master_config
```

#include <fsl_i2c.h> I2C master configuration structure.

This structure includes all the master operation needed features, user can configure these features one by one manually, or call I2C_MasterGetDefaultConfig to set the structure to default value. Then, call I2C_MasterInit to initialize I2C module. After initialization, the I2C module can only operate as master. To deinitialize I2C, call I2C_MasterDeinit.

Public Members

bool bEnableModule

Enable the I2C peripheral during initialization.

bool bEnableStopHold

Control the stop hold enable. I2C_FLT_SHEN

uint8_t u8GlitchFilterWidth

Control the width of the glitch filter. I2C_FLT_FLT

uint8_t u8Interrupts

Mask of the interrupts to be enabled in the init function.

uint32_t u32BaudRateBps

Baud rate value in bits-per-second. I2C_F_MULT, I2C_F_ICR

uint32_t u32SrcClockHz

The clock source frequency for I2C module.

struct __i2c_slave_config

#include <fsl_i2c.h> I2C slave configuration structure.

This structure includes all the slave operation needed features, user can configure these features one by one manually, or call I2C_SlaveGetDefaultConfig to set the structure to default value. Then, call I2C_SlaveInit to initialize I2C module. After initialization, the I2C module can only operate as slave. To deinitialize I2C, call I2C_SlaveDeinit.

Public Members

bool bEnableModule

Enable the I2C peripheral during initialization.

bool bEnableStopHold

Control the stop hold enable. I2C_FLT_SHEN

uint8_t u8GlitchFilterWidth

Control the width of the glitch filter. I2C_FLT_FLT

bool bEnableWakeUp

Enable/disable waking up MCU from low-power mode. I2C_C1_WUEN

bool bEnableGeneralCall

Enable the general call addressing mode, not affected by address length. General call address is 0x00. I2C_C2_GCAEN

i2c_slave_address_mode_t eAddressingMode

Addressing mode chosen from i2c_slave_address_mode_t. I2C_C2_ADEXT
I2C_C2_RMEN

uint16_t bitsPrimaryAddress

Primary Slave address. I2C_A1_AD[7] I2C_C2_AD[3]

uint16_t bitsMaxAddress

The maximum boundary of slave address used in a range address match addressing. In range address match, address greater than primary address and less than or equal to upper address is marked as matched. I2C_RA_RAD[7]

uint8_t u8Interrupts

Mask of the interrupts to be enabled in the init function.

uint32_t u32SclStopHoldTime_ns

the delay from the rising edge of SCL (I2C clock) to the rising edge of SDA (I2C data) while SCL is high (stop condition), SDA hold time and SCL start hold time are also configured according to the SCL stop hold time.

uint32_t u32SrcClockHz

The clock source frequency for I2C module.

struct __i2c_config

#include <fsl_i2c.h> I2C configuration structure.

This structure includes all I2C features, user can configure user can configure these features one by one manually, or call I2C_GetDefaultConfig to set the structure to default value. Then, call I2C_Init to initialize I2C module. To deinitialize I2C, call I2C_Deinit.

Public Members

bool bEnableModule

Enable the I2C peripheral during initialization.

bool bEnableStopHold

Control the stop hold enable. I2C_FLT_SHEN

uint8_t u8GlitchFilterWidth

Control the width of the glitch filter. I2C_FLT_FLT

bool bEnableWakeUp

Enable/disable waking up MCU from low-power mode. I2C_C1_WUEN

bool bEnableGeneralCall

Enable the general call addressing mode, not affected by address length. General call address is 0x00. I2C_C2_GCAEN

i2c_slave_address_mode_t eAddressingMode

Addressing mode chosen from i2c_slave_address_mode_t. I2C_C2_ADEXT
I2C_C2_RMEN

uint16_t bitsPrimaryAddress

Primary Slave address. I2C_A1_AD[7] I2C_C2_AD[3]

uint16_t bitsMaxAddress

The maximum boundary of slave address used in a range address match addressing. In range address match, address greater than primary address and less than or equal to upper address is marked as matched. I2C_RA_RAD[7]

uint8_t u8Interrupts

Mask of the interrupts to be enabled in the init function.

uint32_t u32BaudRateBps

Baud rate value in bits-per-second. I2C_F_MULT, I2C_F_ICR

uint32_t u32SrcClockHz

The clock source frequency for I2C module.

struct __i2c_master_transfer

#include <fsl_i2c.h> I2C master transfer configuration structure.

This structure definition includes all the user configurable features, that are used to control single I2C transfer of master mode, in polling way or in interrupt way.

Public Members

uint8_t u8ControlFlagMask

The transfer flag which controls the transfer start/stop signal, refer `_i2c_master_transfer_flags`.

uint8_t u8SlaveAddress

7-bit slave address.

i2c_master_transfer_direction_t eDirection

Transfer direction, `kI2C_MasterTransmit` or `kI2C_MasterReceive`.

uint8_t *pu8Command

Pointer to command code.

uint8_t u8CommandSize

Size of the command code, max value 4.

uint8_t *volatile pu8Data

Pointer to the send/receive data buffer.

volatile uint16_t u16DataSize

Transfer size.

struct `_i2c_master_transfer_handle`

`#include <fsl_i2c.h>` I2C master transfer handle.

Note: If user wants to use the transactional API to transfer data in interrupt way in master mode, one I2C instance should and can only be allocated one master handle.

Note: The handle is maintained by I2C driver internally, which means the transfer state is retained and user shall not modify its state `u8State` in application level. If user only wish to use transactional APIs without understanding its mechanism, it is not necessary to understand these members.

Public Members

I2C_Type *base

I2C base pointer to the I2C instance that assigned to this handle.

i2c_master_transfer_t sTransfer

I2C master transfer structure.

uint16_t u16TransferSize

Total bytes to be transferred.

uint8_t u8State

A transfer state maintained during transfer.

i2c_master_transfer_callback_t pfCompletionCallback

Callback function invoked when the transfer is finished.

status_t completionStatus

I2C master transfer complete status, indicating how the transfer ends.

void *pUserData

User configurable pointer to any data, function, structure etc that user wish to use in the callback

struct *_i2c_slave_transfer*

#include <fsl_i2c.h> I2C slave transfer configuration structure.

Covers slave transfer data buffer pointer, data size and the events user want driver to alert.

Note: Unlike master who controls the transfer flow, slave has to monitor any bus event and change its configuration accordingly. So this slave transfer configuration structure is also used as second parameter of callback, for user to change the transfer configuration in the callback. The read-only member *eEvent* shows which event occurred that causes the callback being invoked.

Public Members

uint8_t *u8EventMask*

Mask of the events. When these events occur during transfer driver will alert user using callback.

uint8_t *volatile *pu8Data*

Pointer to the buffer of data to send, or to store received data.

volatile uint16_t *u16DataSize*

Transfer size.

i2c_slave_transfer_event_t *eEvent*

The event that caused the callback being invoked. Read-only.

struct *_i2c_slave_transfer_handle*

#include <fsl_i2c.h> I2C slave transfer handle.

Note: If user wants to use the transactional API to transfer data in slave mode, one I2C instance should and can only be allocated one handle.

Note: The handle is maintained by I2C driver internally, which means the transfer state is retained and user shall not modify its state *u8State* in application level. If user only wish to use transactional APIs without understanding its mechanism, it is not necessary to understand these members.

Public Members

I2C_Type **base*

I2C base pointer to the I2C instance that assigned to this handle.

i2c_slave_transfer_t *sTransfer*

I2C slave transfer structure.

uint16_t *u16TransferredCount*

The number of bytes actually transferred for current data buffer.

uint8_t *u8State*

A transfer state maintained during transfer.

i2c_slave_transfer_callback_t *pfCallback*

Callback function invoked at the transfer event.

status_t completionStatus

I2C slave transfer complete status, indicating how the transfer ends, such as kStatus_I2C_Nak indicates the slave was nacked by master before all the data was sent. This parameter is only useful when eEvent is kI2C_SlaveCompletionEvent.

void *pUserData

User configurable pointer to any data, function, structure etc that user wish to use in the callback.

2.44 I2C_DMA: DMA based I2C Driver

```
void I2C_MasterCreateDMAHandle(I2C_Type *base, i2c_master_dma_transfer_handle_t
                               *psHandle, i2c_master_dma_transfer_callback_t pfCallback,
                               void *pUserData, DMA_Type *dmaBase, dma_channel_t
                               eChannel)
```

Initializes the I2C handle which is used in transactional functions.

Parameters

- base – I2C peripheral base address.
- psHandle – A pointer to the i2c_master_dma_transfer_handle_t structure.
- pfCallback – A pointer to the user callback function.
- pUserData – A user parameter passed to the callback function.
- dmaBase – DMA base address.
- eChannel – DMA channel for master transfer.

```
status_t I2C_MasterTransferDMA(i2c_master_dma_transfer_handle_t *psHandle,
                               i2c_master_transfer_t *psTransfer)
```

Performs a master DMA non-blocking transfer on the I2C bus.

Parameters

- psHandle – A pointer to the i2c_master_dma_transfer_handle_t structure.
- psTransfer – A pointer to the transfer structure of i2c_master_transfer_t.

Return values

- kStatus_Success – Successfully completed the data transmission.
- kStatus_I2C_Busy – A previous transmission is still not finished.
- kStatus_I2C_Timeout – Transfer error, waits for a signal timeout.
- kStatus_I2C_ArbitrationLost – Transfer error, arbitration lost.
- kStatus_I2C_Nak – Transfer error, receive NAK during transfer.

```
status_t I2C_MasterTransferGetCountDMA(i2c_master_dma_transfer_handle_t *psHandle,
                                       uint16_t *pu16Count)
```

Gets a master transfer status during the DMA non-blocking transfer.

Parameters

- psHandle – A pointer to the i2c_master_dma_transfer_handle_t structure.
- pu16Count – A number of bytes transferred by the non-blocking transaction.

`void I2C_MasterTransferAbortDMA(i2c_master_dma_transfer_handle_t *psHandle)`

Aborts a master DMA non-blocking transfer early.

Parameters

- `psHandle` – A pointer to the `i2c_master_dma_transfer_handle_t` structure.

`FSL_I2C_DMA_DRIVER_VERSION`

I2C DMA driver version.

`typedef struct i2c_master_dma_transfer_handle i2c_master_dma_transfer_handle_t`

Retry times for waiting flag.

I2C master DMA handle typedef.

`typedef void (*i2c_master_dma_transfer_callback_t)(i2c_master_dma_transfer_handle_t *handle)`

I2C master DMA transfer callback typedef.

`struct i2c_master_dma_transfer_handle`

`#include <fsl_i2c_dma.h>` I2C master DMA transfer structure.

Public Members

`I2C_Type *base`

I2C base pointer to the I2C instance that assigned to this handle.

`i2c_master_transfer_t sTransfer`

I2C master transfer structure.

`uint16_t u16TransferSize`

Total bytes to be transferred.

`uint8_t u8State`

I2C master transfer status.

`dma_handle_t sDmaHandle`

The DMA handler used.

`status_t completionStatus`

I2C master transfer complete status, indicating how the transfer ends.

`i2c_master_dma_transfer_callback_t pfCallback`

A callback function called after the DMA transfer is finished.

`void *pUserData`

User configurable pointer to any data, function, structure etc that user wish to use in the callback

2.45 The Driver Change Log

2.46 I2C Peripheral and Driver Overview

2.47 INTC: Interrupt Controller Driver

```
static inline void INTC_SetIRQPriorityNum(IRQn_Type eIrq, uint8_t u8PriorityNum)
```

Disable IRQ or Enable IRQ with priority.

There are similar function in `fsl_common`:

- `EnableIRQWithPriority`,
- `DisableIRQ`,
- `EnableIRQ`,
- `IRQ_SetPriority`.

This function is faster and simpler than those in `fsl_common`. Generally, this function and IRQ functions in `fsl_common` are either-or, don't use them together for same IRQn type, but feasible that different IRQn type use them simultaneously, for example: It is OK `OCCS_IRQn` use `INTC_SetIRQPriorityLevel`, and `ADC12_CC1_IRQn` use `EnableIRQWithPriority`. It is NOT OK that `OCCS_IRQn` use `INTC_SetIRQPriorityLevel` and `EnableIRQWithPriority` simultaneously.

Note: Please note a none-zero priority number does directly map to priority level, simple summary is as below, you could check RM INTC chapter for more details.

- Some IPs have priority level 1~3, maps priority number 1 to priority 1, 2 to priority 2, 3 to priority 3.
 - Some IPs have priority level 0~2, maps priority number 1 to priority 0, 2 to priority 1, 3 to priority 2.
-

Parameters

- `eIrq` – The IRQ number.
- `u8PriorityNum` – IRQ interrupt priority number.
 - 0: disable IRQ.
 - 1-3: enable IRQ and set its priority, 3 is the highest priority for this IRQ and 1 is the lowest priority.

```
static inline void INTC_SetVectorBaseAddress(uint32_t u32VectorBaseAddr)
```

Set the base address vector table. The value in `INTC_VBA` is used as the upper 13 bits of the interrupt vector `VAB[20:0]`.

Parameters

- `u32VectorBaseAddr` – Vector table base address. The address requires 256 words (512 bytes) aligned. Take the vector table in `MC56F83xxx_Vectors.c` as example for how to implement this table.

```
static inline void INTC_SetFastIRQVectorHandler0(vector_type_t eVector, fast_irq_handler  
                                                pfHandler)
```

Set the IRQ handler for fast IRQ0. The INTC takes the vector address from the appropriate `FIVAL0` and `FIVAH0` registers, instead of generating an address that is an offset from the vector base address (VBA).

Parameters

- `eVector` – The vector number.
- `pfHandler` – Pointer to the fast IRQ handler function, see `fast_irq_handler` definition for more info.

```
static inline void INTC_SetFastIRQVectorHandler1(vector_type_t eVector, fast_irq_handler  
                                              pfHandler)
```

Set the IRQ handler for fast IRQ1. The INTC takes the vector address from the appropriate FIVAL1 and FIVAH1 registers, instead of generating an address that is an offset from the vector base address (VBA).

Parameters

- eVector – The eVector number.
- pfHandler – Pointer to the fast IRQ handler function, see @ ref fast_irq_handler definition for more info.

```
static inline uint8_t INTC_GetIRQPermittedPriorityLevel(void)
```

Get IRQ permitted priority levels. Interrupt exceptions may be nested to allow the servicing of an IRQ with higher priority than the current exception.

The return value indicate the priority level needed for a new IRQ to interrupt the current interrupt being sent to the Core.

Return values

- 0 – Required nested exception priority levels are 0, 1, 2, or 3.
- 1 – Required nested exception priority levels are 1, 2, or 3.
- 2 – Required nested exception priority levels are 2 or 3.
- 3 – Required nested exception priority level is 3.

```
static inline bool INTC_GetPendingIRQ(vector_type_t eVector)
```

Check if IRQ is pending for execution. Before the ISR is entered, IRQ is pending. After the ISR is entered, the IRQ is not pending.

Parameters

- eVector – The IRQ vector number.

Return values

True – if interrupt is pending, otherwise return false.

```
static inline uint16_t INTC_GetLatestRespondedVectorNumber(void)
```

Get the latest responded IRQ's vector number. It shows the Vector Address Bus used at the time the last IRQ was taken.

Note: Return value of the function call could be different according to where the function call is invoked.

- when called in normal ISR handler, it returns current ISR's vector number defined in vector_type_t.
 - when called in fast IRQ handler, it returns the lower address bits of the jump address.
 - when called in none ISR handler code, it returns previous responded IRQ vector number defined in vector_type_t or fast IRQ low address bits.
-

Returns

The latest vector number.

```
FSL_INTC_DRIVER_VERSION
```

INTC driver version.

`typedef void (*fast_irq_handler)(void)`

The handle of the fast irq handler function.

Normally this function should be guarded by: `#pragma interrupt fast` and `#pragma interrupt off`.

`INTC_DisableIRQ(x)`

Macro to disable the IRQ.

`INTC_PEND_REG_INDEX(x)`

Helper Macro function to extract IRQ pending register index comparing to `INTC_IRQP0`.

`INTC_PEND_BIT_INDEX(x)`

Helper Macro function to extract pending IRQs bit index.

`INTC_TYPE_REG_INDEX(x)`

Helper Macro function to extract IRQ priority register index comparing to `INTC_IRP0`.

`INTC_TYPE_BIT_INDEX(x)`

Helper Macro function to extract IRQs priority bit index.

2.48 The Driver Change Log

2.49 INTC Peripheral and Driver Overview

2.50 Common Driver

status_t `EnableIRQWithPriority(IRQn_Type irq, uint8_t priNum)`

Enable the IRQ, and also set the interrupt priority.

- Some IPs maps 1 to priority 1, 2 to priority 2, 3 to priority 3
- Some IPs maps 1 to priority 0, 2 to priority 1, 3 to priority 2

User should check chip's RM to get its corresponding interrupt priority.

When `priNum` set as 0, then `SDK_DSC_DEFAULT_INT_PRIO` is set instead. When `priNum` set as number larger than 3, then only the 2 LSB take effect, for example, setting `priNum` to 5 is the same with setting it to 1.

This function configures INTC module, application could call the INTC driver directly for the same purpose.

Note: The parameter `priNum` is range in 1~3, and its value is **NOT** directly map to interrupt priority.

Parameters

- `irq` – The IRQ to enable.
- `priNum` – Priority number set to interrupt controller register. Larger number means higher priority. The allowed range is 1~3, and its value is **NOT** directly map to interrupt priority. In other words, the same priority number means different interrupt priority levels for different IRQ, please check reference manual for the relationship. When pass in 0, then `SDK_DSC_DEFAULT_INT_PRIO` is set to priority register.

Returns

Currently only returns `kStatus_Success`, will enhance in the future.

status_t DisableIRQ(IRQn_Type irq)

Disable specific interrupt.

This function configures INTC module, application could call the INTC driver directly for the same purpose.

Parameters

- `irq` – The IRQ to disable.

Returns

Currently only returns `kStatus_Success`, will enhance in the future.

status_t EnableIRQ(IRQn_Type irq)

Enable specific interrupt.

The recommended workflow is calling `IRQ_SetPriority` first, then call `EnableIRQ`. If `IRQ_SetPriority` is not called first, then the interrupt is enabled with default priority value `SDK_DSC_DEFAULT_INT_PRIO`.

Another recommended workflow is calling `EnableIRQWithPriority` directly, it is the same with calling `IRQ_SetPriority` + `EnableIRQ`.

This function configures INTC module, application could call the INTC driver directly for the same purpose.

Parameters

- `irq` – The IRQ to enable.

Returns

Currently only returns `kStatus_Success`, will enhance in the future.

status_t IRQ_SetPriority(IRQn_Type irq, uint8_t priNum)

Set the IRQ priority.

- Some IPs maps 1 to priority 1, 2 to priority 2, 3 to priority 3
- Some IPs maps 1 to priority 0, 2 to priority 1, 3 to priority 2

User should check chip's RM to get its corresponding interrupt priority

When `priNum` set as 0, then `SDK_DSC_DEFAULT_INT_PRIO` is set instead. When `priNum` set as number larger than 3, then only the 2 LSB take effect, for example, setting `priNum` to 5 is the same with setting it to 1.

This function configures INTC module, application could call the INTC driver directly for the same purpose.

Note: The parameter `priNum` is range in 1~3, and its value is **NOT** directly map to interrupt priority.

Parameters

- `irq` – The IRQ to set.
- `priNum` – Priority number set to interrupt controller register. Larger number means higher priority, 0 means disable the interrupt. The allowed range is 0~3, and its value is **NOT** directly map to interrupt priority. In other words, the same priority number means different interrupt priority levels for different IRQ, please check reference manual for the relationship.

Returns

Currently only returns `kStatus_Success`, will enhance in the future.

`FSL_COMMON_DRIVER_VERSION`

common driver version.

`DEBUG_CONSOLE_DEVICE_TYPE_NONE`

No debug console.

`DEBUG_CONSOLE_DEVICE_TYPE_UART`

Debug console based on UART.

`DEBUG_CONSOLE_DEVICE_TYPE_LPUART`

Debug console based on LPUART.

`DEBUG_CONSOLE_DEVICE_TYPE_LPSCI`

Debug console based on LPSCI.

`DEBUG_CONSOLE_DEVICE_TYPE_USBCDC`

Debug console based on USB CDC.

`DEBUG_CONSOLE_DEVICE_TYPE_FLEXCOMM`

Debug console based on FLEXCOMM.

`DEBUG_CONSOLE_DEVICE_TYPE_IUART`

Debug console based on i.MX UART.

`DEBUG_CONSOLE_DEVICE_TYPE_VUSART`

Debug console based on LPC_VUSART.

`DEBUG_CONSOLE_DEVICE_TYPE_MINI_USART`

Debug console based on LPC_USART.

`DEBUG_CONSOLE_DEVICE_TYPE_SWO`

Debug console based on SWO.

`DEBUG_CONSOLE_DEVICE_TYPE_QSCI`

Debug console based on QSCI.

`MIN(a, b)`

Computes the minimum of *a* and *b*.

`MAX(a, b)`

Computes the maximum of *a* and *b*.

`UINT16_MAX`

Max value of `uint16_t` type.

`UINT32_MAX`

Max value of `uint32_t` type.

`USEC_TO_COUNT(us, clockFreqInHz)`

Macro to convert a microsecond period to raw count value

`COUNT_TO_USEC(count, clockFreqInHz)`

Macro to convert a raw count value to microsecond

`MSEC_TO_COUNT(ms, clockFreqInHz)`

Macro to convert a millisecond period to raw count value

`COUNT_TO_MSEC(count, clockFreqInHz)`

Macro to convert a raw count value to millisecond

SDK_ALIGN(var, alignbytes)

Macro to define a variable with alignbytes alignment

AT_NONCACHEABLE_SECTION(var)

AT_NONCACHEABLE_SECTION_ALIGN(var, alignbytes)

AT_NONCACHEABLE_SECTION_INIT(var)

AT_NONCACHEABLE_SECTION_ALIGN_INIT(var, alignbytes)

enum __status_groups

Status group numbers.

Values:

enumerator kStatusGroup_Generic

Group number for generic status codes.

enumerator kStatusGroup_FLASH

Group number for FLASH status codes.

enumerator kStatusGroup_LPSPI

Group number for LPSPI status codes.

enumerator kStatusGroup_FLEXIO_SPI

Group number for FLEXIO SPI status codes.

enumerator kStatusGroup_DSPI

Group number for DSPI status codes.

enumerator kStatusGroup_FLEXIO_UART

Group number for FLEXIO UART status codes.

enumerator kStatusGroup_FLEXIO_I2C

Group number for FLEXIO I2C status codes.

enumerator kStatusGroup_LPI2C

Group number for LPI2C status codes.

enumerator kStatusGroup_UART

Group number for UART status codes.

enumerator kStatusGroup_I2C

Group number for I2C status codes.

enumerator kStatusGroup_LPSCI

Group number for LPSCI status codes.

enumerator kStatusGroup_LPUART

Group number for LPUART status codes.

enumerator kStatusGroup_SPI

Group number for SPI status code.

enumerator kStatusGroup_XRDC

Group number for XRDC status code.

enumerator kStatusGroup_SEMA42

Group number for SEMA42 status code.

enumerator kStatusGroup_SDHC

Group number for SDHC status code

enumerator kStatusGroup_SDMMC
Group number for SDMMC status code

enumerator kStatusGroup_SAI
Group number for SAI status code

enumerator kStatusGroup_MCG
Group number for MCG status codes.

enumerator kStatusGroup_SCG
Group number for SCG status codes.

enumerator kStatusGroup_SDSPI
Group number for SDSPI status codes.

enumerator kStatusGroup_FLEXIO_I2S
Group number for FLEXIO I2S status codes

enumerator kStatusGroup_FLEXIO_MCULCD
Group number for FLEXIO LCD status codes

enumerator kStatusGroup_FLASHIAP
Group number for FLASHIAP status codes

enumerator kStatusGroup_FLEXCOMM_I2C
Group number for FLEXCOMM I2C status codes

enumerator kStatusGroup_I2S
Group number for I2S status codes

enumerator kStatusGroup_IUART
Group number for IUART status codes

enumerator kStatusGroup_CSI
Group number for CSI status codes

enumerator kStatusGroup_MIPI_DSI
Group number for MIPI DSI status codes

enumerator kStatusGroup_SDRAMC
Group number for SDRAMC status codes.

enumerator kStatusGroup_POWER
Group number for POWER status codes.

enumerator kStatusGroup_ENET
Group number for ENET status codes.

enumerator kStatusGroup_PHY
Group number for PHY status codes.

enumerator kStatusGroup_TRGMUX
Group number for TRGMUX status codes.

enumerator kStatusGroup_SMARTCARD
Group number for SMARTCARD status codes.

enumerator kStatusGroup_LMEM
Group number for LMEM status codes.

enumerator kStatusGroup_QSPI
Group number for QSPI status codes.

enumerator kStatusGroup_DMA
Group number for DMA status codes.

enumerator kStatusGroup_EDMA
Group number for EDMA status codes.

enumerator kStatusGroup_DMAMGR
Group number for DMAMGR status codes.

enumerator kStatusGroup_FLEXCAN
Group number for FlexCAN status codes.

enumerator kStatusGroup_LTC
Group number for LTC status codes.

enumerator kStatusGroup_FLEXIO_CAMERA
Group number for FLEXIO CAMERA status codes.

enumerator kStatusGroup_LPC_SPI
Group number for LPC_SPI status codes.

enumerator kStatusGroup_LPC_USART
Group number for LPC_USART status codes.

enumerator kStatusGroup_DMIC
Group number for DMIC status codes.

enumerator kStatusGroup_SDIF
Group number for SDIF status codes.

enumerator kStatusGroup_SPIFI
Group number for SPIFI status codes.

enumerator kStatusGroup_OTP
Group number for OTP status codes.

enumerator kStatusGroup_MCAN
Group number for MCAN status codes.

enumerator kStatusGroup_CAAM
Group number for CAAM status codes.

enumerator kStatusGroup_ECSPI
Group number for ECSPI status codes.

enumerator kStatusGroup_USDHC
Group number for USDHC status codes.

enumerator kStatusGroup_LPC_I2C
Group number for LPC_I2C status codes.

enumerator kStatusGroup_DCP
Group number for DCP status codes.

enumerator kStatusGroup_MSCAN
Group number for MSCAN status codes.

enumerator kStatusGroup_ESAI
Group number for ESAI status codes.

enumerator kStatusGroup_FLEXSPI
Group number for FLEXSPI status codes.

enumerator kStatusGroup_MMDC
Group number for MMDC status codes.

enumerator kStatusGroup_PDM
Group number for MIC status codes.

enumerator kStatusGroup_SDMA
Group number for SDMA status codes.

enumerator kStatusGroup_ICS
Group number for ICS status codes.

enumerator kStatusGroup_SPDIF
Group number for SPDIF status codes.

enumerator kStatusGroup_LPC_MINISPI
Group number for LPC_MINISPI status codes.

enumerator kStatusGroup_HASHCRYPT
Group number for Hashcrypt status codes

enumerator kStatusGroup_LPC_SPI_SSP
Group number for LPC_SPI_SSP status codes.

enumerator kStatusGroup_I3C
Group number for I3C status codes

enumerator kStatusGroup_LPC_I2C_1
Group number for LPC_I2C_1 status codes.

enumerator kStatusGroup_NOTIFIER
Group number for NOTIFIER status codes.

enumerator kStatusGroup_DebugConsole
Group number for debug console status codes.

enumerator kStatusGroup_SEMC
Group number for SEMC status codes.

enumerator kStatusGroup_ApplicationRangeStart
Starting number for application groups.

enumerator kStatusGroup_IAP
Group number for IAP status codes

enumerator kStatusGroup_SFA
Group number for SFA status codes

enumerator kStatusGroup_SPC
Group number for SPC status codes.

enumerator kStatusGroup_PUF
Group number for PUF status codes.

enumerator kStatusGroup_TOUCH_PANEL
Group number for touch panel status codes

enumerator kStatusGroup_VBAT
Group number for VBAT status codes

enumerator kStatusGroup_XSPI
Group number for XSPI status codes

enumerator kStatusGroup_PNGDEC
Group number for PNGDEC status codes

enumerator kStatusGroup_JPEGDEC
Group number for JPEGDEC status codes

enumerator kStatusGroup_AUDMIX
Group number for AUDMIX status codes

enumerator kStatusGroup_HAL_GPIO
Group number for HAL GPIO status codes.

enumerator kStatusGroup_HAL_UART
Group number for HAL UART status codes.

enumerator kStatusGroup_HAL_TIMER
Group number for HAL TIMER status codes.

enumerator kStatusGroup_HAL_SPI
Group number for HAL SPI status codes.

enumerator kStatusGroup_HAL_I2C
Group number for HAL I2C status codes.

enumerator kStatusGroup_HAL_FLASH
Group number for HAL FLASH status codes.

enumerator kStatusGroup_HAL_PWM
Group number for HAL PWM status codes.

enumerator kStatusGroup_HAL_RNG
Group number for HAL RNG status codes.

enumerator kStatusGroup_HAL_I2S
Group number for HAL I2S status codes.

enumerator kStatusGroup_HAL_ADC_SENSOR
Group number for HAL ADC SENSOR status codes.

enumerator kStatusGroup_TIMERMANAGER
Group number for TiMER MANAGER status codes.

enumerator kStatusGroup_SERIALMANAGER
Group number for SERIAL MANAGER status codes.

enumerator kStatusGroup_LED
Group number for LED status codes.

enumerator kStatusGroup_BUTTON
Group number for BUTTON status codes.

enumerator kStatusGroup_EXTERN_EEPROM
Group number for EXTERN EEPROM status codes.

enumerator kStatusGroup_SHELL
Group number for SHELL status codes.

enumerator kStatusGroup_MEM_MANAGER
Group number for MEM MANAGER status codes.

enumerator kStatusGroup_LIST
Group number for List status codes.

enumerator kStatusGroup_OSA
Group number for OSA status codes.

enumerator kStatusGroup_COMMON_TASK
Group number for Common task status codes.

enumerator kStatusGroup_MSG
Group number for messaging status codes.

enumerator kStatusGroup_SDK_OCOTP
Group number for OCOTP status codes.

enumerator kStatusGroup_SDK_FLEXSPINOR
Group number for FLEXSPINOR status codes.

enumerator kStatusGroup_CODEC
Group number for codec status codes.

enumerator kStatusGroup_ASRC
Group number for codec status ASRC.

enumerator kStatusGroup_OTFAD
Group number for codec status codes.

enumerator kStatusGroup_SDIO SLV
Group number for SDIO SLV status codes.

enumerator kStatusGroup_MECC
Group number for MECC status codes.

enumerator kStatusGroup_ENET_QOS
Group number for ENET_QOS status codes.

enumerator kStatusGroup_LOG
Group number for LOG status codes.

enumerator kStatusGroup_I3CBUS
Group number for I3CBUS status codes.

enumerator kStatusGroup_QSCI
Group number for QSCI status codes.

enumerator kStatusGroup_ELEMU
Group number for ELEMU status codes.

enumerator kStatusGroup_QUEUE DSPI
Group number for QSPI status codes.

enumerator kStatusGroup_POWER_MANAGER
Group number for POWER_MANAGER status codes.

enumerator kStatusGroup_IPED
Group number for IPED status codes.

enumerator kStatusGroup_ELS_PKC
Group number for ELS PKC status codes.

enumerator kStatusGroup_CSS_PKC
Group number for CSS PKC status codes.

enumerator kStatusGroup_HOSTIF
Group number for HOSTIF status codes.

enumerator kStatusGroup_CLIF
Group number for CLIF status codes.

enumerator kStatusGroup_BMA
Group number for BMA status codes.

enumerator kStatusGroup_NETC
Group number for NETC status codes.

enumerator kStatusGroup_ELE
Group number for ELE status codes.

enumerator kStatusGroup_GLIKEY
Group number for GLIKEY status codes.

enumerator kStatusGroup_AON_POWER
Group number for AON_POWER status codes.

enumerator kStatusGroup_AON_COMMON
Group number for AON_COMMON status codes.

enumerator kStatusGroup_ENDAT3
Group number for ENDAT3 status codes.

enumerator kStatusGroup_HIPERFACE
Group number for HIPERFACE status codes.

enumerator kStatusGroup_NPX
Group number for NPX status codes.

enumerator kStatusGroup_ELA_CSEC
Group number for ELA_CSEC status codes.

enumerator kStatusGroup_FLEXIO_T_FORMAT
Group number for T-format status codes.

enumerator kStatusGroup_FLEXIO_A_FORMAT
Group number for A-format status codes.

Generic status return codes.

Values:

enumerator kStatus_Success
Generic status for Success.

enumerator kStatus_Fail
Generic status for Fail.

enumerator kStatus_ReadOnly
Generic status for read only failure.

enumerator kStatus_OutOfRange
Generic status for out of range access.

enumerator kStatus_InvalidArgument
Generic status for invalid argument check.

enumerator kStatus_Timeout
Generic status for timeout.

enumerator kStatus_NoTransferInProgress

Generic status for no transfer in progress.

enumerator kStatus_Busy

Generic status for module is busy.

enumerator kStatus_NoData

Generic status for no data is found for the operation.

typedef int32_t status_t

Type used for all status and error return values.

uint8_t bool

void *SDK_Malloc(size_t size, size_t alignbytes)

Allocate memory with given alignment and aligned size.

This is provided to support the dynamically allocated memory used in cache-able region.

Parameters

- size – The length required to malloc.
- alignbytes – The alignment size.

Return values

The – allocated memory.

void SDK_Free(void *ptr)

Free memory.

Parameters

- ptr – The memory to be release.

void SDK_DelayAtLeastUs(uint32_t delayTime_us, uint32_t coreClock_Hz)

Delay at least for some time. Please note that, this API uses while loop for delay, different run-time environments make the time not precise, if precise delay count was needed, please implement a new delay function with hardware timer.

Parameters

- delayTime_us – Delay time in unit of microsecond.
- coreClock_Hz – Core clock frequency with Hz.

static inline uint32_t DisableGlobalIRQ(void)

Disable the global IRQ.

static inline void EnableGlobalIRQ(uint32_t irqSts)

Enable the global IRQ.

static inline bool isIRQAllowed(void)

Check if currently core is able to response IRQ.

void SDK_DelayCoreCycles(uint32_t u32Num)

Delay core cycles. Please note that, this API uses software loop for delay, the actual delayed time depends on core clock frequency, where the function is located (ram or flash), flash clock, possible interrupt.

Parameters

- u32Num – Number of core clock cycle which needs to be delayed.

uint32_t SDK_CovertUsToCount(uint32_t u32Us, uint32_t u32Hz)

Covert us to count with fixed-point calculation.

Note: u32Us must not be greater than 4294

Parameters

- u32Us – Time in us
- u32Hz – Clock frequency in Hz

Returns

The count value

uint32_t SDK_CovertCountToUs(uint32_t u32Count, uint32_t u32Hz)

Covert count to us with fixed-point calculation.

Note: u32Hz must not be greater than 429496729UL(0xFFFFFFFFUL/10UL)

Parameters

- u32Count – Count value
- u32Hz – Clock frequency in Hz

Returns

The us value

uint32_t SDK_CovertMsToCount(uint32_t u32Ms, uint32_t u32Hz)

Covert ms to count with fixed-point calculation.

Note: u32Ms must not be greater than 42949UL @ u32Hz = 100M

Parameters

- u32Ms – Time in us
- u32Hz – Clock frequency in Hz

Returns

The count value

uint32_t SDK_CovertCountToMs(uint32_t u32Count, uint32_t u32Hz)

Covert count to ms with fixed-point calculation.

Note: u32Hz must not be greater than 429496729UL(0xFFFFFFFFUL/10UL)

Parameters

- u32Count – Count value
- u32Hz – Clock frequency in Hz

Returns

The us value

`void SDK_DelayAtLeastMs(uint32_t delayTime_ms, uint32_t coreClock_Hz)`

Delay at least for some time in millisecond unit. Please note that, this API uses while loop for delay, different run-time environments make the time not precise, if precise delay count was needed, please implement a new delay function with hardware timer.

Parameters

- `delayTime_ms` – Delay time in unit of millisecond.
- `coreClock_Hz` – Core clock frequency with Hz.

`FSL_DRIVER_TRANSFER_DOUBLE_WEAK_IRQ`

Macro to use the default weak IRQ handler in drivers.

`MAKE_STATUS(group, code)`

Construct a status code value from a group and code number.

`MAKE_VERSION(major, minor, bugfix)`

Construct the version number for drivers.

The driver version is a 32-bit number, for both 32-bit platforms(such as Cortex M) and 16-bit platforms(such as DSC).

Unused		Major Version		Minor Version		Bug Fix	
31	25	24	17	16	9	8	0

`ARRAY_SIZE(x)`

Computes the number of elements in an array.

`UINT64_H(X)`

Macro to get upper 32 bits of a 64-bit value

`UINT64_L(X)`

Macro to get lower 32 bits of a 64-bit value

`SUPPRESS_FALL_THROUGH_WARNING()`

For switch case code block, if case section ends without “break;” statement, there will be fallthrough warning with compiler flag `-Wextra` or `-Wimplicit-fallthrough=n` when using `armgcc`. To suppress this warning, “`SUPPRESS_FALL_THROUGH_WARNING()`,” need to be added at the end of each case section which misses “break;”statement.

true

false

`SDK_ISR_EXIT_BARRIER`

`SDK_DSC_DEFAULT_INT_PRIO`

Default DSC interrupt priority number.

`SetIRQBasePriority(x)`

Set base core IRQ priority, that core will response the interrupt request with priority $\geq$ base IRQ priority.

`PeriphReadReg(reg)`

Read register value.

Example: `val = PeriphReadReg(OCCS->OSCTL2);`

Parameters

- `reg` – Register name.

Returns

The value of register.

PeriphWriteReg(reg, data)

Write data to register.

Example: PeriphWriteReg(OCCS->OSCTL2, 0x278U);

Parameters

- reg – Register name.
- data – Data wrote to register.

PeriphSetBits(reg, bitMask)

Set specified bits in register.

Example: PeriphSetBits(OCCS->OSCTL2, 0x12U);

Parameters

- reg – Register name.
- bitMask – Bits mask, set bits will be set in the register.

PeriphClearBits(reg, bitMask)

Clear specified bits in register.

Example: PeriphClearBits(OCCS->OSCTL2, 0x12U);

Parameters

- reg – Register name.
- bitMask – Bits mask, set bits will be cleared in the register.

PeriphInvertBits(reg, bitMask)

Invert specified bits in register.

Example: PeriphInvertBits(OCCS->OSCTL2, 0x12U);

Parameters

- reg – Register name.
- bitMask – Bits mask, set bits will be inverted in the register.

PeriphGetBits(reg, bitMask)

Get specified bits in register.

Example: val = PeriphGetBits(OCCS->OSCTL2, 0x23U);

Parameters

- reg – Register name.
- bitMask – Bits mask, specify the getting bits.

Returns

The value of specified bits.

PeriphWriteBitGroup(reg, bitMask, bitValue)

Write group of bits to register.

Example: PeriphWriteBitGroup(OCCS->DIVBY, OCCS_DIVBY_COD_MASK, OCCS_DIVBY_COD(23U)); PeriphWriteBitGroup(OCCS->DIVBY, OCCS_DIVBY_COD_MASK | OCCS_DIVBY_PLLDB_MASK, \ OCCS_DIVBY_COD(23U) | OCCS_DIVBY_PLLDB(49U));

Parameters

- reg – Register name.
- bitMask – Bits mask, mask of the group of bits.

- bitValue – This value will be written into the bit group specified by parameter bitMask.

PeriphSafeClearFlags(reg, allFlagsMask, flagMask)

Clear (acknowledge) flags which are active-high and are cleared-by-write-one.

This macro is useful when a register is comprised by normal read-write bits and cleared-by-write-one bits. Example: PeriphSafeClearFlags(PWMA->FAULT[0].FSTS, PWM_FSTS_FFLAG_MASK, PWM_FSTS_FFLAG(2));

Parameters

- reg – Register name.
- allFlagsMask – Mask for all flags which are active-high and are cleared-by-write-one.
- flagMask – The selected flags(cleared-by-write-one) which are supposed to be cleared.

PeriphSafeClearBits(reg, allFlagsMask, bitMask)

Clear selected bits without modifying (acknowledge) bit flags which are active-high and are cleared-by-write-one.

This macro is useful when a register is comprised by normal read-write bits and cleared-by-write-one bits. Example: PeriphSafeClearBits(PWMA->FAULT[0].FSTS, PWM_FSTS_FFLAG_MASK, PWM_FSTS_FHALF(2));

Parameters

- reg – Register name.
- allFlagsMask – Mask for all flags which are active-high and are cleared-by-write-one.
- bitMask – The selected bits which are supposed to be cleared.

PeriphSafeSetBits(reg, allFlagsMask, bitMask)

Set selected bits without modifying (acknowledge) bit flags which are active-high and are cleared-by-write-one.

This macro is useful when a register is comprised by normal read-write bits and cleared-by-write-one bits. Example: PeriphSafeSetBits(PWMA->FAULT[0].FSTS, PWM_FSTS_FFLAG_MASK, PWM_FSTS_FHALF(2));

Parameters

- reg – Register name.
- allFlagsMask – Mask for all flags which are active-high and are cleared-by-write-one.
- bitMask – The selected bits which are supposed to be set.

PeriphSafeWriteBitGroup(reg, allFlagsMask, bitMask, bitValue)

Write group of bits without modifying (acknowledge) bit flags which are active-high and are cleared-by-write-one.

This macro is useful when a register is comprised by normal read-write bits and cleared-by-write-one bits. Example: PeriphSafeWriteBitGroup(PWMA->FAULT[0].FSTS, PWM_FSTS_FFLAG_MASK, PWM_FSTS_FHALF_MASK, PWM_FSTS_FHALF(3U)); PeriphSafeWriteBitGroup(PWMA->FAULT[0].FSTS, PWM_FSTS_FFLAG_MASK, PWM_FSTS_FHALF_MASK | PWM_FSTS_FFULL_MASK, \ PWM_FSTS_FHALF(3U) | PWM_FSTS_FFULL(2U));

Parameters

- reg – Register name.

- `allFlagsMask` – Mask for all flags which are active-high and are cleared-by-write-one.
- `bitMask` – Bits mask, mask of the group of bits.
- `bitValue` – This value will be written into the bit group specified by parameter `bitMask`.

`SDK_GET_REGISTER_BYTE_ADDR(ipType, ipBase, regName)`

Get IP register byte address with `uint32_t` type.

This macro is useful when a register byte address is required, especially in SDM mode.
Example: `SDK_GET_REGISTER_BYTE_ADDR(ADC_Type, ADC, RSLT[0]);`

Parameters

- `ipType` – IP register mapping struct type.
- `ipBase` – IP instance base pointer, WORD address.
- `regName` – Member register name of IP register mapping struct.

`MSDK_REG_SECURE_ADDR(x)`

`MSDK_REG_NONSECURE_ADDR(x)`

2.51 MCM: Miscellaneous Control Module Driver

`static inline mcm_datapath_width_t MCM_GetDataPathWidth(MCM_Type *base)`

Indicates if the datapath is 32 or 64 bits wide.

Parameters

- `base` – MCM base address.

Returns

The device's datapath width, please refer to `mcm_datapath_width_t`.

`static inline uint16_t MCM_GetCrossbarSwitchSlaveConfig(MCM_Type *base)`

Gets crossbar switch (AXBS) slave configuration that indicates the presence/absence of bus slave connections to the device's crossbar switch.

Parameters

- `base` – MCM base address.

Returns

Crossbar switch (AXBS) slave configuration, each bit in the return value indicates if there is a corresponding connection to the AXBS slave input port. For example if the result is 0x1, it means a bus slave connection to AXBS input port 0 is present.

`static inline uint16_t MCM_GetCrossbarSwitchMasterConfig(MCM_Type *base)`

Gets crossbar switch (AXBS) master configuration that indicates the presence/absence of bus master connections to the device's crossbar switch.

Parameters

- `base` – MCM base address.

Returns

Crossbar switch (AXBS) master configuration, each bit in the return value indicates if there is a corresponding connection to the AXBS master input port. For example if the result is 0x1, it means a bus master connection to AXBS input port 0 is present.

static inline void MCM_ClearFlashControllerCache(MCM_Type *base)

Clears Flash Controller Cache, 1 cycle active.

Parameters

- base – MCM base address.

static inline void MCM_DisableFlashControllerDataCaching(MCM_Type *base, bool bDisable)

Disables/Enables flash controller data caching.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable flash controller data caching.
 - **true** Disable flash controller data caching.
 - **false** Enable flash controller data caching.

static inline void MCM_DisableFlashControllerInstructionCaching(MCM_Type *base, bool
bDisable)

Disables/Enables flash controller instruction caching.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable flash controller instruction caching.
 - **true** Disable flash controller instruction caching.
 - **false** Enable flash controller instruction caching.

static inline void MCM_DisableFlashControllerCache(MCM_Type *base, bool bDisable)

Disables/Enables flash controller cache.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable flash controller cache.
 - **true** Disable flash controller cache.
 - **false** Enable flash controller cache.

static inline void MCM_DisableFlashControllerDataSpeculation(MCM_Type *base, bool bDisable)

Disables/Enables flash controller data speculation.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable flash controller data speculation.
 - **true** Disable flash controller data speculation.
 - **false** Enable flash controller data speculation.

static inline void MCM_DisableFlashControllerSpeculation(MCM_Type *base, bool bDisable)

Disables/Enables flash controller speculation.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable flash controller speculation.
 - **true** Disable flash controller speculation.
 - **false** Enable flash controller speculation.

static inline void MCM_DisableDSP56800EXCoreInstructions(MCM_Type *base, bool bDisable)

Disables/Enables the instruction support only by DSP56800EX core, the instructions supported only by the DSP56800EX core are the BPSC and 32-bit multiply and MAC instructions.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable 32-bit multiply and MAC instructions.
 - **true** BFSC and 32-bit multiply and MAC instructions disabled.
 - **false** BFSC and 32-bit multiply and MAC instructions enabled.

static inline void MCM_DisableCoreReverseCarry(MCM_Type *base, bool bDisable)

Disables/Enables core reverse carry.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to enable/disable reverse carry.
 - **true** Disable bit-reverse addressing mode.
 - **false** Enable bit-reverse addressing mode.

static inline void MCM_DisableDSP56800EXNewShadowRegion(MCM_Type *base, bool bDisable)

Disables/Enables the additional AGU shadow registers on the DSP56800EX core.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to disable/enable the additional AGU shadow register on the DPS core.
 - **true** Only the AGU shadow registers supported by the DSP56800E core are enabled.
 - **false** The additional AGU shadow registers on the DSP56800EX core are also enabled.

static inline void MCM_DisableCoreInstructionBuffer(MCM_Type *base, bool bDisable)

Disables/Enables core instruction buffer.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to disable/enable core longword instruction buffer.
 - **true** Disable core longword instruction buffer.
 - **false** Enable core longword instruction buffer.

static inline void MCM_DisableFlashMemoryControllerStall(MCM_Type *base, bool bDisable)

Disables/Enables the flash memory controller's ability to allow flash memory access to initiate when a flash memory command is executing.

Parameters

- base – MCM peripheral base address.
- bDisable – Used to disable/enable stall logic.
 - **true** Stall logic is disabled. While a flash memory command is executing, an attempted flash memory access causes a bus error.

- **false** Stall logic is disabled. While a flash memory command is executing, a flash memory access can occur without causing a bus error. The flash memory command completes execution, and then the flash memory access occurs.

```
static inline void MCM_SetAxsDMAControllerPriority(MCM_Type *base,  
                                                  mcm_axbs_dma_core_priority_t  
                                                  ePriority)
```

Sets the priority of the DMA controller in the AXBS crossbar switch arbitration scheme.

Parameters

- base – MCM base address.
- ePriority – The selected DMA controller priority in Crossbar switch arbitration scheme, please refer to `mcm_axbs_dma_core_priority_t`.

```
static inline uint32_t MCM_GetCoreFaultAddr(MCM_Type *base)
```

Gets the address of the last core access terminated with an error response.

Parameters

- base – MCM base address.

Returns

address of the last core access terminated with an error response.

```
void MCM_GetCoreFaultAttribute(MCM_Type *base, mcm_core_fault_attribute_t *psAttribute)
```

Gets the processor's attributes of the last faulted core access to the system bus.

Parameters

- base – MCM peripheral base address.
- psAttribute – The pointer of structure `mcm_core_fault_attribute_t`.

```
static inline mcm_last_fault_access_location_t MCM_GetCoreFaultLocation(MCM_Type *base)
```

Gets the location of the last captured fault.

Parameters

- base – MCM peripheral base address.

Returns

The location of the last captured fault, please refer to `mcm_last_fault_access_location_t`.

```
static inline uint32_t MCM_GetCoreFaultData(MCM_Type *base)
```

Gets the data associated with the last faulted processor write data access from the device's internal bus.

Parameters

- base – MCM base address.

Returns

The data associated with the last faulted processor write data access.

```
static inline void MCM_EnableCoreFaultInterrupt(MCM_Type *base, bool bEnable)
```

Enables/Disables core fault error interrupt.

Parameters

- base – MCM peripheral base address.
- bEnable – Used to enable/disable the core fault error interrupt.
 - **true** Enables core fault error interrupt, so an error interrupt will be generated to the interrupt controller on a faulted system bus cycle.

- **false** Disables core fault error interrupt, so an error interrupt will not be generated to the interrupt controller on a faulted system bus cycle.

static inline uint8_t MCM_GetCoreFaultStatusFlags(MCM_Type *base)

Gets the core fault error status flags, including core fault error interrupt flag and core fault error data lost flag.

Parameters

- base – MCM peripheral base address.

Returns

The current status flags, should be the OR'ed value of `_mcm_status_flags`.

static inline void MCM_ClearCoreFaultStatusFlags(MCM_Type *base, uint8_t u8StatusFlags)

Clears the core fault error status flags, including core fault error interrupt flag and core fault error data lost flag.

Parameters

- base – MCM peripheral base address.
- u8StatusFlags – The status flags to be cleared, should be the OR'ed value of `_mcm_status_flags`.

static inline void MCM_EnableResourceProtection(MCM_Type *base, bool bEnable)

Enables/Disables resource protection.

Parameters

- base – MCM peripheral base address.
- bEnable – Used to enable/disable memory resource protection.
 - **true** Enable memory resource protection.
 - **false** Disable memory resource protection.

static inline void MCM_LockResourceProtectionRegisters(MCM_Type *base)

Locks the value of the resource protection related registers, after locked the registers' value can not be changed until a system reset.

Parameters

- base – MCM peripheral base address.

status_t MCM_SetResourceProtectionConfig(MCM_Type *base, const
mcm_resource_protection_config_t *psConfig)

Sets the configuration of resource protection, including flash base address, ram base address, etc.

Parameters

- base – MCM peripheral base address.
- psConfig – The pointer of structure `mcm_resource_protection_config_t`.

Return values

- kStatus_Success – Succeed to setting resource protection related options.
- kStatus_Fail – Fail to set resource protection related options.

static inline uint32_t MCM_GetResourceProtectionIllegalFaultPC(MCM_Type *base)

Gets the 21-bit illegal faulting PC that only for a resource protection fault.

Parameters

- base – MCM peripheral base address.

Returns

The resource protection illegal faulting PC.

```
static inline bool MCM_IsResourceProtectionIllegalFaultValid(MCM_Type *base)
```

Indicates whether an resource protection illegal PC fault has occurred.

Parameters

- base – MCM peripheral base address.

Return values

- true – The resource protection illegal PC fault has occurred.
- false – The resource protection illegal PC fault has not occurred.

```
static inline void MCM_ClearResourceProtectionIllegalFaultValid(MCM_Type *base)
```

Clears the resource protection illegal fault bit.

Parameters

- base – MCM peripheral base address.

```
static inline uint32_t MCM_GetResourceProtectionMisalignedFaultPC(MCM_Type *base)
```

Gets the 21-bit misaligned faulting PC that only for a resource protection fault.

Parameters

- base – MCM peripheral base address.

Returns

The resource protection misaligned faulting PC.

```
static inline bool MCM_IsResourceProtectionMisalignedFaultValid(MCM_Type *base)
```

Indicates whether an resource protection misaligned PC fault has occurred.

Parameters

- base – MCM peripheral base address.

Return values

- true – The resource protection misaligned PC fault has occurred.
- false – The resource protection misaligned PC fault has not occurred.

```
static inline void MCM_ClearResourceProtectionMisalignedFaultValid(MCM_Type *base)
```

Clears the resource protection misaligned fault bit.

Parameters

- base – MCM peripheral base address.

```
FSL_MCM_DRIVER_VERSION
```

MCM driver version.

```
enum __mcm_status_flags
```

The enumeration of status flags, including core fault error interrupt flag and core fault error data lost flag.

Values:

```
enumerator kMCM_CoreFaultErrorInterruptFlag
```

A bus error has occurred.

```
enumerator kMCM_CoreFaultErrorDataLostFlag
```

A bus error has occurred before the previous error condition was cleared.

enum `_mcm_datapath_width`

The enumeration of datapath width, including 32 bits and 64 bits.

Values:

enumerator `kMCM_Datapath32b`

Datapath width is 32 bits.

enumerator `kMCM_Datapath64b`

Datapath width is 64 bits.

enum `_mcm_axbs_dma_core_priority`

The enumeration of DMA controller priority in the Crossbar switch arbitration scheme.

Values:

enumerator `kMCM_AxbsPriorityCoreHigherThanDMA`

Fixed-priority arbitration is selected: DSC core has a higher priority than the DMA Controller's priority.

enumerator `kMCM_AxbsPriorityCoreDMARoundRobin`

Round-robin priority arbitration is selected: DMA Controller and DSC core have equal priority.

enum `_mcm_last_fault_access_dir`

The enumeration of last faulted core access direction.

Values:

enumerator `kMCM_CoreRead`

Core read access.

enumerator `kMCM_CoreWrite`

Core write access.

enum `_mcm_last_fault_access_size`

The enumeration of last faulted core access size.

Values:

enumerator `kMCM_Access8b`

Last faulted core access size is 8-bit.

enumerator `kMCM_Access16b`

Last faulted core access size is 16-bit.

enumerator `kMCM_Access32b`

Last faulted core access size is 32-bit.

enum `_mcm_last_fault_access_type`

The enumeration of last faulted core access type.

Values:

enumerator `kMCM_AccessInstruction`

Last faulted core access is instruction.

enumerator `kMCM_AccessData`

Last faulted core access is data.

enum `_mcm_last_fault_access_location`

The enumeration of last captured fault Location.

Values:

enumerator `kMCM_ErrOnInstructionBus`
Error occurred on M0 (instruction bus).

enumerator `kMCM_ErrOnOperandABus`
Error occurred on M1 (operand A bus).

enumerator `kMCM_ErrOnOperandBBus`
Error occurred on M2 (operand B bus).

typedef enum `_mcm_datapath_width` `mcm_datapath_width_t`
The enumeration of datapath width, including 32 bits and 64 bits.

typedef enum `_mcm_axbs_dma_core_priority` `mcm_axbs_dma_core_priority_t`
The enumeration of DMA controller priority in the Crossbar switch arbitration scheme.

typedef enum `_mcm_last_fault_access_dir` `mcm_last_fault_access_dir_t`
The enumeration of last faulted core access direction.

typedef enum `_mcm_last_fault_access_size` `mcm_last_fault_access_size_t`
The enumeration of last faulted core access size.

typedef enum `_mcm_last_fault_access_type` `mcm_last_fault_access_type_t`
The enumeration of last faulted core access type.

typedef enum `_mcm_last_fault_access_location` `mcm_last_fault_access_location_t`
The enumeration of last captured fault Location.

typedef struct `_mcm_core_fault_attribute` `mcm_core_fault_attribute_t`
The structure of core fault attributes, contains access type, access size, access direction, etc.

typedef struct `_mcm_resource_protection_config` `mcm_resource_protection_config_t`
The structure of the resource protection config, the set value can be used only when the resource protection is enabled, and this value can be changed only when the resource protection is disabled.

struct `_mcm_core_fault_attribute`
#include <fsl_mcm.h> The structure of core fault attributes, contains access type, access size, access direction, etc.

Public Members

`mcm_last_fault_access_type_t` `eType`
Indicates the last faulted core access type, please refer to `mcm_last_fault_access_type_t`.

`uint8_t` `bitReserved1`
Reserved 1 bit.

`bool` `bBufferable`
Indicates if last faulted core access was bufferable.

- **true** Last faulted core access is bufferable.
- **false** Last faulted core access is non-bufferable.

`uint8_t` `bitReserved2`
Reserved 1 bit.

`mcm_last_fault_access_size_t` `eSize`
Indicates last faulted core access size.

`mcm_last_fault_access_dir_t` `eDirection`
Indicates the last faulted core access direction.

struct _mcm_resource_protection_config

#include <fsl_mcm.h> The structure of the resource protection config, the set value can be used only when the resource protection is enabled, and this value can be changed only when the resource protection is disabled.

Public Members

bool bEnableResourceProtection

Enable/Disable resource protection.

- **true** Enable Resource protection.
- **false** Disable Resource protection.

uint8_t u8FlashBaseAddress

Flash base address for user region, supports 4 KB granularity.

uint8_t u8RamBaseAddress

Program RAM base address for user region, support 256 byte granularity.

uint32_t u32BootRomBaseAddress

Boot ROM base address for user region

uint32_t u32ResourceProtectionOtherSP

Resource protection other stack pointer.

2.52 The Driver Change Log

2.53 MCM Peripheral and Driver Overview

2.54 PDB: Programmable Delay Block

void PDB_Init(PDB_Type *base, const *pdb_config_t* *psConfig)

Initializes the PDB module.

This function initializes the PDB module. The operations included are as follows.

- Enable the clock for PDB instance.
- Configure the PDB module.
- Enable the PDB module.

Parameters

- base – PDB peripheral base address.
- psConfig – Pointer to the configuration structure. See *pdb_config_t*.

void PDB_Deinit(PDB_Type *base)

De-initializes the PDB module.

Parameters

- base – PDB peripheral base address.

void PDB_GetDefaultConfig(*pdb_config_t* *psConfig)

Initializes the PDB user configuration structure.

This function initializes the user configuration structure to a default value. The default values are as follows.

```
psConfig->bEnableContinuousMode           = false;
psConfig->eInputTrigger                    = kPDB_TriggerInput0;
psConfig->eLoadValueMode                   = kPDB_LoadValueImmediately;
psConfig->ePrescalerDivider                = kPDB_PrescalerDivider1;
psConfig->sPdbTriggerABOutputConfig.bBypassTrigger1 = false;
psConfig->sPdbTriggerABOutputConfig.bBypassTrigger2 = false;
psConfig->sPdbTriggerABOutputConfig.bEnableTrigger1 = false;
psConfig->sPdbTriggerABOutputConfig.bEnableTrigger2 = false;
psConfig->sPdbTriggerABOutputConfig.bEnbleTriggerCombineOutput = false;
psConfig->sPdbTriggerABOutputConfig.eTriggerInitValue = kPDB_InitValue0;
psConfig->sPdbTriggerABOutputConfig.eFaultLength      = kPDB_2IPBusClockCycles;
psConfig->sPdbTriggerABOutputConfig.eFaultPolarity    = kPDB_FaultPolarity0;
psConfig->sPdbTriggerABOutputConfig.bFaultEnable      = false;
psConfig->sPdbTriggerABOutputConfig.uDelay1           = 0xFFFFU;
psConfig->sPdbTriggerABOutputConfig.uDelay2           = 0xFFFFU;
psConfig->sPdbTriggerCDOOutputConfig.bBypassTrigger1 = false;
psConfig->sPdbTriggerCDOOutputConfig.bBypassTrigger2 = false;
psConfig->sPdbTriggerCDOOutputConfig.bEnableTrigger1 = false;
psConfig->sPdbTriggerCDOOutputConfig.bEnableTrigger2 = false;
psConfig->sPdbTriggerCDOOutputConfig.bEnbleTriggerCombineOutput = false;
psConfig->sPdbTriggerCDOOutputConfig.eTriggerInitValue = kPDB_InitValue0;
psConfig->sPdbTriggerCDOOutputConfig.eFaultLength      = kPDB_2IPBusClockCycles;
psConfig->sPdbTriggerCDOOutputConfig.eFaultPolarity    = kPDB_FaultPolarity0;
psConfig->sPdbTriggerCDOOutputConfig.bFaultEnable      = false;
psConfig->sPdbTriggerCDOOutputConfig.uDelay1           = 0xFFFFU;
psConfig->sPdbTriggerCDOOutputConfig.uDelay2           = 0xFFFFU;
psConfig->u16PeriodCount                     = 0xFFFFU;
psConfig->u16EnableInterruptMask              = 0x0u;
psConfig->bEnablePDB                          = false;
```

Parameters

- psConfig – Pointer to configuration structure. See `pdb_config_t`.

void PDB_SetTriggerOutputLogicConfig(PDB_Type *base, *pdb_logic_t* eLogic, const *pdb_trigger_output_logic_config_t* *psConfig)

Set the PDB trigger output logic.

Parameters

- base – PDB peripheral base address.
- eLogic – index for PDB trigger output logic instance. See `pdb_logic_t`.
- psConfig – Pointer to the configuration structure. See `pdb_trigger_output_logic_config_t`.

static inline void PDB_EnableModule(PDB_Type *base, bool bEnablePDBMode)

Enable the PDB module.

Parameters

- base – PDB peripheral base address.
- bEnablePDBMode – Enable the module or not.

static inline void PDB_EnableContinuousMode(PDB_Type *base, bool bEnableContinuousMode)

Enables the PDB continuous mode.

Parameters

- base – PDB peripheral base address.
- bEnableContinuousMode – Enable the module or not.

static inline void PDB_DoSoftwareTrigger(PDB_Type *base)

Triggers the PDB counter by software.

Parameters

- base – PDB peripheral base address.

static inline void PDB_SetLoadOk(PDB_Type *base)

Loads the counter values.

This function loads the counter values from the internal buffer.

Parameters

- base – PDB peripheral base address.

static inline bool PDB_GetPdbLdOk(PDB_Type *base)

Get the PDB LDOK bit status.

Parameters

- base – PDB peripheral base address.

Returns

Mask value for asserted flags. true: LDOK is set; false: LDOK is cleared.

static inline void PDB_EnableTriggerOutput(PDB_Type *base, *pdb_trigger_output_t* eTrigger, bool bEnable)

Enable the PDB trigger output.

When disabled, trigger output will be forced to 0.

Parameters

- base – PDB peripheral base address.
- eTrigger – index for trigger instance. See *pdb_trigger_output_t*.
- bEnable – bEnable the triggers or not.

static inline void PDB_BypassTrigger(PDB_Type *base, *pdb_trigger_output_t* eTrigger, bool bValue)

Bypass the PDB trigger output.

When bypass enabled, Trigger output is a single pulse created by the selected trigger source.

Parameters

- base – PDB peripheral base address.
- eTrigger – index for trigger instance. See *pdb_trigger_output_t*.
- bValue – The PDB bypassA mode enable or not.

static inline void PDB_EnableTriggerCombineMode(PDB_Type *base, *pdb_logic_t* eLogic, bool bMode)

Enable Trigger output A & B combined mode.

When enabled, Trigger A and Trigger B outputs are a function of combined DELAYA and DELAYB. Trigger A is an extended pulse and Trigger B is a dual pulse. When disabled, Trigger A is a function of DELAYA only. Trigger B is a function of DELAYB only.

Parameters

- base – PDB peripheral base address.
- eLogic – index for PDB trigger output logic instance. See *pdb_logic_t*.

- bMode – The trigger A output mode select.

```
static inline void PDB_SetTriggerInitValue(PDB_Type *base, pdb_trigger_output_t eTrigger,  
                                           pdb_init_value_t eInitValue)
```

Initial trigger Value.

Parameters

- base – PDB peripheral base address.
- eTrigger – index for trigger instance. See *pdb_trigger_output_t*.
- eInitValue – set trigger init value. See *pdb_init_value_t*.

```
static inline void PDB_EnableFault(PDB_Type *base, pdb_logic_t eLogic, bool bEnable)
```

Enable PDB fault feature.

Parameters

- base – PDB peripheral base address.
- eLogic – index for PDB trigger output logic instance. See *pdb_logic_t*.
- bEnable – Enable the interrupts or not.

```
static inline void PDB_FaultLength(PDB_Type *base, pdb_logic_t eLogic, pdb_fault_length_t  
                                  ePdbFaultLength)
```

Set the PDB fault length feature.

This bit is used to determine the minimum width requirement of the input fault for it to be recognized as a valid fault condition.

Parameters

- base – PDB peripheral base address.
- eLogic – index for PDB trigger output logic instance. See *pdb_logic_t*.
- ePdbFaultLength – Set the PDB fault length. See *pdb_fault_length_t*.

```
static inline void PDB_SetFaultPolarity(PDB_Type *base, pdb_logic_t eLogic, pdb_fault_polarity_t  
                                       ePolarity)
```

Set fault input polarity.

Parameters

- base – PDB peripheral base address.
- eLogic – index for PDB trigger output logic instance. See *pdb_logic_t*.
- ePolarity – Set the PDB fault polarity. See *pdb_fault_polarity_t*.

```
static inline void PDB_EnableInterrupts(PDB_Type *base, uint16_t u16Mask)
```

The PDB interrupt is enabled according to the provided mask.

Parameters

- base – PDB peripheral base address.
- u16Mask – The PDB interrupts to enable. Logical OR of *_pdb_interrupt_enable*.

```
static inline void PDB_DisableInterrupts(PDB_Type *base, uint16_t u16Mask)
```

The PDB interrupt is disabled according to the provided mask.

Parameters

- base – PDB peripheral base address.
- u16Mask – The PDB interrupts to disable. Logical OR of *_pdb_interrupt_enable*.

```
static inline void PDB_ClearStatusFlags(PDB_Type *base, uint16_t u16Mask)
```

Clears the PDB status flags.

Parameters

- `base` – PDB peripheral base address.
- `u16Mask` – The status flags to clear. This is the logical OR of `_pdb_status_flags`.

```
static inline uint16_t PDB_GetStatusFlags(PDB_Type *base)
```

Gets the status flags of the PDB module.

Parameters

- `base` – PDB peripheral base address.

Returns

Mask value for asserted flags.

```
static inline void PDB_SetTriggerDelay(PDB_Type *base, pdb_trigger_output_t eTrigger, uint16_t u16DelayValue)
```

Sets the PDB trigger delay.

Write logic 1 to the MCTRL[LDMOD] bit, any value written to the DELAY register will be ignored until the value in these registers is loaded into the buffer; and this bit is 0, we need to manually set it to 1.

Parameters

- `base` – PDB peripheral base address.
- `eTrigger` – index for trigger instance. See `pdb_trigger_output_t`.
- `u16DelayValue` – Setting value for PDB counter delay event. 16-bit is available.

```
static inline void PDB_SetModulusValue(PDB_Type *base, uint16_t u16PeriodCount)
```

Specifies the counter period.

Write logic 1 to the MCTRL[LDMOD] bit, any value written to the MOD register will be ignored until the value in these registers is loaded into the buffer; and this bit is 0, we need to manually set it to 1.

Parameters

- `base` – PDB peripheral base address.
- `u16PeriodCount` – Setting value for the modulus. 16-bit is available.

```
static inline uint16_t PDB_GetCounterValue(PDB_Type *base)
```

Gets the PDB counter's current value.

Parameters

- `base` – PDB peripheral base address.

Returns

PDB counter's current value.

```
FSL_PDB_DRIVER_VERSION
```

PDB driver version.

```
enum __pdb_prescaler_divider
```

Clock prescaler select.

The prescaler used for counting is selected by dividing the peripheral clock by the divisor.

Values:

enumerator kPDB_PrescalerDivider1
Divider /1.

enumerator kPDB_PrescalerDivider2
Divider /2.

enumerator kPDB_PrescalerDivider4
Divider /4.

enumerator kPDB_PrescalerDivider8
Divider /8.

enumerator kPDB_PrescalerDivider16
Divider /16.

enumerator kPDB_PrescalerDivider32
Divider /32.

enumerator kPDB_PrescalerDivider64
Divider /64.

enumerator kPDB_PrescalerDivider128
Divider /128.

enum __pdb_load_value_mode
PDB load mode select.

Choose to load the DELAY and MOD registers into a set of buffers to take effect immediately or take effect after the counter is reversed and a trigger signal is received.

Values:

enumerator kPDB_LoadValueImmediately
Load immediately after 1 is written to LDOK.

enumerator kPDB_LoadValueAfterEvent
Load when the PDB counter rolls over or a trigger signal is received after 1 is written to LDOK.

enum __pdb_input_trigger
Trigger Input Source Select.

Selects the trigger input source for the PDB. The trigger input source can be internal or the software trigger. When select kPDB_TriggerSoftware and the module is enabled, writing a one to MCTRL[SWTRIG] will trigger and software trigger. See chip configuration details for the actual PDB input trigger connections.

Values:

enumerator kPDB_TriggerInput0
PDB input trigger 0.

enumerator kPDB_TriggerInput1
PDB input trigger 1.

enumerator kPDB_TriggerInput2
PDB input trigger 2.

enumerator kPDB_TriggerInput3
PDB input trigger 3.

enumerator kPDB_TriggerInput4
PDB input trigger 4.

enumerator kPDB_TriggerInput5

PDB input trigger 5.

enumerator kPDB_TriggerInput6

PDB input trigger 6.

enumerator kPDB_TriggerSoftware

Software Trigger.

enum __pdb_fault_length

PDB fault length.

This bit is used to determine the minimum width requirement of the input fault for it to be recognized as a valid fault condition.

Values:

enumerator kPDB_2IPBusClockCycles

Fault input must be active at least 2 IPBus clock cycles.

enumerator kPDB_4IPBusClockCycles

Fault input must be active at least 4 IPBus clock cycles.

enum __pdb_fault_polarity

PDB fault polarity.

Values:

enumerator kPDB_FaultPolarity0

A logic 0 on Fault pin indicates a fault condition.

enumerator kPDB_FaultPolarity1

A logic 1 on Fault pin indicates a fault condition.

enum __pdb_trigger_output

PDB trigger output signals.

Values:

enumerator kPDB_TriggerA

Trigger A.

enumerator kPDB_TriggerB

Trigger B.

enumerator kPDB_TriggerC

Trigger C.

enumerator kPDB_TriggerD

Trigger D.

enum __pdb_logic

PDB trigger logic enumeration.

Each PDB instance has two trigger output logic and each output logic has two output signals.

Values:

enumerator kPDB_LogicA

PDB trigger output logic A, has two output signals: triggerA and triggerB.

enumerator kPDB_LogicC

PDB trigger output logic C, has two output signals: triggerC and triggerD.

enum `_pdb_init_value`

PDB init value enumeration.

Values:

enumerator `kPDB_InitValue0`

PDB init value 0.

enumerator `kPDB_InitValue1`

PDB init value 1.

enum `_pdb_interrupt_enable`

The enumeration for PDB interrupt enable.

Values:

enumerator `kPDB_EnableOverflowInterrupt`

PDB overflow interrupt.

enumerator `kPDB_EnableDelayAInterrupt`

PDB delayA interrupt.

enumerator `kPDB_EnableDelayBInterrupt`

PDB delayB interrupt.

enumerator `kPDB_EnableDelayCInterrupt`

PDB delayC interrupt.

enumerator `kPDB_EnableDelayDInterrupt`

PDB delayD interrupt.

enumerator `kPDB_ALLInterruptEnable`

enum `_pdb_status_flags`

The enumeration for PDB status flags.

Values:

enumerator `kPDB_OverflowStatusFlag`

PDB overflow interrupt.

enumerator `kPDB_DelayAStatusFlag`

PDB delayA interrupt.

enumerator `kPDB_DelayBStatusFlag`

PDB delayB interrupt.

enumerator `kPDB_DelayCStatusFlag`

PDB delayC interrupt.

enumerator `kPDB_DelayDStatusFlag`

PDB delayD interrupt.

enumerator `kPDB_ALLStatusFlags`

typedef enum `_pdb_prescaler_divider` `pdb_prescaler_divider_t`

Clock prescaler select.

The prescaler used for counting is selected by dividing the peripheral clock by the divisor.

typedef enum `_pdb_load_value_mode` `pdb_load_value_mode_t`

PDB load mode select.

Choose to load the DELAY and MOD registers into a set of buffers to take effect immediately or take effect after the counter is reversed and a trigger signal is received.

`typedef enum _pdb_input_trigger pdb_input_trigger_t`

Trigger Input Source Select.

Selects the trigger input source for the PDB. The trigger input source can be internal or the software trigger. When select kPDB_TriggerSoftware and the module is enabled, writing a one to MCTRL[SWTRIG] will trigger and software trigger. See chip configuration details for the actual PDB input trigger connections.

`typedef enum _pdb_fault_length pdb_fault_length_t`

PDB fault length.

This bit is used to determine the minimum width requirement of the input fault for it to be recognized as a valid fault condition.

`typedef enum _pdb_fault_polarity pdb_fault_polarity_t`

PDB fault polarity.

`typedef enum _pdb_trigger_output pdb_trigger_output_t`

PDB trigger output signals.

`typedef enum _pdb_logic pdb_logic_t`

PDB trigger logic enumeration.

Each PDB instance has two trigger output logic and each output logic has two output signals.

`typedef enum _pdb_init_value pdb_init_value_t`

PDB init value enumeration.

`typedef struct _pdb_trigger_output_logic_config pdb_trigger_output_logic_config_t`

configuring PDB trigger output logic.

PDB has two output logic and each output logic has two output trigger signals: trigger1 and trigger2.

`typedef struct _pdb_config pdb_config_t`

PDB module config structure.

`struct _pdb_trigger_output_logic_config`

`#include <fsl_pdb.h>` configuring PDB trigger output logic.

PDB has two output logic and each output logic has two output trigger signals: trigger1 and trigger2.

Public Members

`bool bFaultEnable`

Set PDB fault input bit, true: PDB fault is enable; false: PDB fault is disable.

`pdb_fault_polarity_t eFaultPolarity`

Selected the PDB fault polarity 0 or 1.

`pdb_fault_length_t eFaultLength`

Selected the PDB fault length, 0: 2 IP bus clock cycles; 1: 4 IP bus clock cycles.

`pdb_init_value_t eTriggerInitValue`

Set fault bit forces the output from trigger logic : fault bit is enabled or trigger logic output is set and the counter is reloaded.

`bool bEnbleTriggerCombineOutput`

Trigger output select. true: Trigger1 and trigger2 Combine Output; false: Trigger1 and trigger2 function is only delay.

bool bEnableTrigger1
Set trigger1 in each trigger output logic of PDB. true: PDB trigger1 is enable; false: PDB trigger1 is disable.

bool bEnableTrigger2
Set trigger2 in each trigger output logic of PDB. true: PDB trigger2 is enable; false: PDB trigger2 is disable.

bool bBypassTrigger1
Set bypass trigger1 in each trigger output logic of PDB. true: PDB bypass trigger is enable; false: PDB bypass trigger is disable.

bool bBypassTrigger2
Set bypass trigger2 in each trigger output logic of PDB. true: PDB bypass trigger is enable; false: PDB bypass trigger is disable.

uint16_t uDelay1
Set the delay of trigger1 in each trigger output logic of the PDB.

uint16_t uDelay2
Set the delay of trigger2 in each trigger output logic of the PDB.

struct __pdb_config
#include <fsl_pdb.h> PDB module config structure.

Public Members

bool bEnableContinuousMode
true: Module is in one-shot mode; false: Module is in continuous mode.

***pdb_load_value_mode_t* eLoadValueMode**
Configures PDB load value mode.0: load immediately; 1: load after the PDB counter rolls over or receives a trigger signal.

***pdb_prescaler_divider_t* ePrescalerDivider**
Configures PDB counter clock source prescaler.

***pdb_input_trigger_t* eInputTrigger**
Configures PDB trigger input source.

***pdb_trigger_output_logic_config_t* sPdbTriggerABOutputConfig**
Configure PDB trigger output logic A .

***pdb_trigger_output_logic_config_t* sPdbTriggerCDOOutputConfig**
Configure PDB trigger output logic C.

uint16_t u16PeriodCount
The period of the counter in terms of peripheral bus cycles.

bool bEnablePDB
true: PDB module id enable; false: PDB module id disable.

uint16_t u16EnableInterruptMask
PDB interrupt enable mask, logic OR of *_pdb_interrupt_enable*.

2.55 The Driver Change Log

2.56 PDB Peripheral and Driver Overview

2.57 PIT: Periodic Interrupt Timer (PIT) Driver

`void PIT_Init(PIT_Type *base, const pit_config_t *psConfig)`

Un-gates the PIT clock, configures the PIT features. The configurations are:

- Clock source selection for PIT module
- Prescaler configuration to the input clock source
- PIT period interval
- PIT slave mode enable/disable
- Interrupt enable/disable
- PIT timer enable/disable
- Preset Polarity positive edge/negative edge

Note: This API should be called at the beginning of the application using the PIT driver and call `PIT_StartTimer()` API to start PIT timer.

Parameters

- `base` – PIT peripheral base address
- `psConfig` – Pointer to the user's PIT config structure

`void PIT_Deinit(PIT_Type *base)`

Gates the PIT clock and disables the PIT module.

Parameters

- `base` – PIT peripheral base address

`void PIT_GetDefaultConfig(pit_config_t *psConfig)`

Fill in the PIT config structure with the default settings.

This function initializes the PIT configuration structure to default values.

```
psConfig->eClockSource = kPIT_CountClockSource0;
psConfig->bEnableTimer = false;
psConfig->bEnableSlaveMode = false;
psConfig->ePrescaler = kPIT_PrescalerDivBy1;
psConfig->bEnableInterrupt = false;
psConfig->u32PeriodCount = 0xFFFFFFFFU;
psConfig->bEnableNegativeEdge = false;
psConfig->sPresetFilter.u16FilterSamplePeriod = 0x0U;
psConfig->sPresetFilter.u16FilterSampleCount = 0x0U;
psConfig->sPresetFilter.bFilterClock = true;
psConfig->sPresetFilter.eFilterPrescalerPeripheral = kPIT_PrescalerDivBy1;
psConfig->sSyncSource.u8StretchCount = 0x0U;
psConfig->sSyncSource.eSyncOutSel = kPIT_Syncout_Default;
```

Parameters

- `psConfig` – Pointer to user's PIT config structure.

```
static inline void PIT_EnableSlaveMode(PIT_Type *base, bool bEnable)
```

Enable/Disable PIT slave mode.

Parameters

- base – PIT peripheral base address
- bEnable – enable/disable slave mode

```
static inline void PIT_SetTimerPrescaler(PIT_Type *base, pit_prescaler_value_t ePrescaler)
```

Sets the PIT clock prescaler.

Parameters

- base – PIT peripheral base address
- ePrescaler – Timer prescaler value

```
static inline void PIT_SetTimerPeriod(PIT_Type *base, uint32_t u32PeriodCount)
```

Sets the timer period in units of count.

Timers begin counting from 0 until it reaches the value set by this function, then it generates an interrupt and counter resumes counting from 0 again.

Note: Users can call the utility macros provided in `fsl_common.h` to convert to ticks.

Parameters

- base – PIT peripheral base address
- u32PeriodCount – Timer period in units of ticks, use macro definition `MSEC_TO_COUNT` to convert value in ms to count of ticks, the PIT clock rate is source clock divide prescaler.

```
static inline uint32_t PIT_GetCurrentTimerCount(PIT_Type *base)
```

Reads the current timer counting value.

This function returns the real-time timer counting value, in a range from 0 to a timer period.

Note: Users can call the utility macros provided in `fsl_common.h` to convert ticks to usec or msec.

Parameters

- base – PIT peripheral base address

Returns

Current timer counting value in ticks, use macro definition `COUNT_TO_MSEC` to convert value in ticks to count of millisecond, the PIT clock rate is source clock divide prescaler.

```
static inline void PIT_StartTimer(PIT_Type *base)
```

Starts the timer counting.

After calling this function, timers load period value, count down to 0 and then load the respective start value again. Each time a timer reaches 0, it generates a trigger pulse and sets the timeout interrupt flag.

Parameters

- base – PIT peripheral base address

static inline void PIT_StopTimer(PIT_Type *base)

Stops the timer counting.

This function stops timer counting, and the counter remains at or returns to a 0 value.

Parameters

- base – PIT peripheral base address

static inline void PIT_EnableInterrupt(PIT_Type *base)

Enables the PIT interrupts.

Parameters

- base – PIT peripheral base address

static inline void PIT_DisableInterrupt(PIT_Type *base)

Disables the selected PIT interrupts.

Parameters

- base – PIT peripheral base address

static inline uint16_t PIT_GetStatusFlags(PIT_Type *base)

Gets the PIT status flags.

Parameters

- base – PIT peripheral base address

Returns

The status flags. This is the logical OR of members of the enumeration `_pit_status_flags`

static inline void PIT_ClearStatusFlags(PIT_Type *base)

Clears the PIT status flags.

Parameters

- base – PIT peripheral base address

static inline void PIT_SetPresetFiltConfig(PIT_Type *base, const *pit_config_filt_t* psConfig)

Set FILT configurations.

Parameters

- base – PIT peripheral base address
- psConfig – Pointer to user's PIT FILT config structure

static inline void PIT_SetSyncOutConfig(PIT_Type *base, const *pit_config_ctrl2_t* psConfig)

Set Sync configurations.

Parameters

- base – PIT peripheral base address
- psConfig – Pointer to user's PIT SYNC config structure

FSL_PIT_DRIVER_VERSION

PIT driver version.

enum __pit_prescaler_value

PIT clock prescaler values.

Values:

enumerator kPIT_PrescalerDivBy1

Clock divided by 1

enumerator kPIT_PrescalerDivBy2

Clock divided by 2

enumerator kPIT_PrescalerDivBy4

Clock divided by 4

enumerator kPIT_PrescalerDivBy8

Clock divided by 8

enumerator kPIT_PrescalerDivBy16

Clock divided by 16

enumerator kPIT_PrescalerDivBy32

Clock divided by 32

enumerator kPIT_PrescalerDivBy64

Clock divided by 64

enumerator kPIT_PrescalerDivBy128

Clock divided by 128

enumerator kPIT_PrescalerDivBy256

Clock divided by 256

enumerator kPIT_PrescalerDivBy512

Clock divided by 512

enumerator kPIT_PrescalerDivBy1024

Clock divided by 1024

enumerator kPIT_PrescalerDivBy2048

Clock divided by 2048

enumerator kPIT_PrescalerDivBy4096

Clock divided by 4096

enumerator kPIT_PrescalerDivBy8192

Clock divided by 8192

enumerator kPIT_PrescalerDivBy16384

Clock divided by 16384

enumerator kPIT_PrescalerDivBy32768

Clock divided by 32768

enum __pit_status_flags

List of PIT status flags.

Values:

enumerator kPIT_Timer_RollOverFlag

Timer roll over flag

enum __pit_syncout_mode

List of SYNC_OUT output mode.

Values:

enumerator kPIT_Syncout_Default

SYNC_OUT takes affect when PIT counter equals to the MODULO value (default)

enumerator kPIT_Syncout_Toggle

SYNC_OUT is in toggle mode

```
typedef enum _pit_prescaler_value pit_prescaler_value_t
```

PIT clock prescaler values.

```
typedef enum _pit_syncout_mode pit_syncout_mode_t
```

List of SYNC_OUT output mode.

```
typedef struct _pit_config_filt pit_config_filt_t
```

PIT FILT configuration structure.

This structure holds the configuration settings for the PIT FILT register. To initialize this structure to reasonable defaults, call the PIT_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

```
typedef struct _pit_config_ctrl2 pit_config_ctrl2_t
```

PIT CTRL2 configuration structure.

This structure holds the configuration settings for the PIT CTRL2 register. To initialize this structure to reasonable defaults, call the PIT_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

```
typedef struct _pit_config pit_config_t
```

PIT configuration structure.

This structure holds the configuration settings for the PIT peripheral. To initialize this structure to reasonable defaults, call the PIT_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

```
struct _pit_config_filt
```

#include <fsl_pit.h> PIT FILT configuration structure.

This structure holds the configuration settings for the PIT FILT register. To initialize this structure to reasonable defaults, call the PIT_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

Public Members

bool bFilterClock

Filter Clock Source selection.

pit_prescaler_value_t eFilterPrescalerPeripheral

Sets the peripheral clock prescaler.

uint8_t u16FilterSampleCount

Input Filter Sample Count.

uint8_t u16FilterSamplePeriod

Input Filter Sample Period.

```
struct _pit_config_ctrl2
```

#include <fsl_pit.h> PIT CTRL2 configuration structure.

This structure holds the configuration settings for the PIT CTRL2 register. To initialize this structure to reasonable defaults, call the PIT_GetDefaultConfig() function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

Public Members

`uint8_t` `u8StretchCount`

The cycle number to be stretched for SYNC_OUT signal.

`pit_syncout_mode_t` `eSyncOutSel`

Select the output mode of SYNC_OUT.

`struct __pit_config`

`#include <fsl_pit.h>` PIT configuration structure.

This structure holds the configuration settings for the PIT peripheral. To initialize this structure to reasonable defaults, call the `PIT_GetDefaultConfig()` function and pass a pointer to your config structure instance.

The configuration structure can be made constant so it resides in flash.

Public Members

`pit_prescaler_value_t` `ePrescaler`

Clock prescaler value

`bool` `bEnableInterrupt`

Enable PIT Roll-Over Interrupt

`bool` `bEnableSlaveMode`

Enable the PIT module in slave mode, in which mode the timer will be triggered by master PIT enable.

`bool` `bEnableTimer`

PIT timer enable flag, which is false by default

`pit_count_clock_source_t` `eClockSource`

Specify the PIT count clock source

`uint32_t` `u32PeriodCount`

Timer period in clock cycles, Use macro definition `MSEC_TO_COUNT` to convert value in ms to count of ticks, the COP clock rate is source clock divide prescaler.

`bool` `bEnableNegativeEdge`

choose the polarity of Preset input.

`pit_config_filt_t` `sPresetFilter`

Specify the PIT preset filter source

`pit_config_ctrl2_t` `sSyncSource`

Specify the PIT Sync source

2.58 The Driver Change Log

2.59 PIT Peripheral and Driver Overview

2.60 PMC: Power Management Controller Driver

```
static inline void PMC_SetBandgapTrim(PMC_Type *base, uint8_t u8TrimValue)
```

Sets the trim value of the bandgap reference in the regulator.

Parameters

- base – PMC peripheral base address.
- u8TrimValue – The bandgap's trim value, ranges from 0 to 15.

```
static inline void PMC_EnableVoltageReferenceBuffer(PMC_Type *base, bool bEnable)
```

Enables/Disables a buffer that drives the 1.2V bandgap reference to the ADC.

If the users want to calibrate the ADC using the 1.2V reference voltage, then the voltage reference buffer should be enabled. When ADC calibration is not being performed, the voltage reference buffer should be disabled to save power.

Parameters

- base – PMC peripheral base address.
- bEnable – Used to control the behaviour of voltage reference buffer.
 - **true** Enable voltage reference buffer.
 - **false** Disable voltage reference buffer.

```
static inline void PMC_EnableInterrupts(PMC_Type *base, uint16_t u16Interrupts)
```

Enables the interrupts, including 2.2V high voltage interrupt, 2.7V/2.65V high voltage interrupt, 2.2V low voltage interrupt, 2.7V/2.65V low voltage interrupt.

Parameters

- base – PMC peripheral base address.
- u16Interrupts – The interrupts to be enabled, should be the OR'ed value of `_pmc_interrupt_enable`.

```
static inline void PMC_DisableInterrupts(PMC_Type *base, uint16_t u16Interrupts)
```

Disables the interrupts, including 2.2V high voltage interrupt, 2.7V/2.65V high voltage interrupt, 2.2V low voltage interrupt, 2.7V/2.65V low voltage interrupt.

Parameters

- base – PMC peripheral base address.
- u16Interrupts – The interrupts to be disabled, should be the OR'ed value of `_pmc_interrupt_enable`.

```
static inline uint16_t PMC_GetStatusFlags(PMC_Type *base)
```

Gets the status flags of PMC module, such as low voltage interrupt flag, small regulator 2.7 active flag, etc.

Parameters

- base – PMC peripheral base address.

Returns

The status flags of PMC module, should be the OR'ed value of `_pmc_status_flags`.

```
static inline void PMC_ClearStatusFlags(PMC_Type *base, uint16_t u16StatusFlags)
```

Clears the status flags of PMC module, only low voltage interrupt flag, sticky 2.7V/2.65V low voltage flag, and sticky 2.2V low voltage flag can be cleared.

Parameters

- base – PMC peripheral base address.

- `u16StatusFlags` – The status flags to be cleared, should be the OR'ed value of `kPMC_LowVoltageInterruptFlag`, and `kPMC_Sticky2P7VLowVoltageFlag`/`kPMC_Sticky2P65VLowVoltageFlag`, and `kPMC_Sticky2P2VLowVoltageFlag`,

static inline void PMC_SetVrefTrim(PMC_Type *base, uint16_t u16TrimValue)

Sets the trim value of the Vref reference in the regulator.

Parameters

- `base` – PMC peripheral base address.
- `u16TrimValue` – The Vref's trim value, ranges from 0 to 31.

static inline void PMC_SetVcapTrim(PMC_Type *base, uint16_t u16TrimValue)

Sets the trim value of the Vcap reference in the regulator.

Parameters

- `base` – PMC peripheral base address.
- `u16TrimValue` – The Vcap's trim value, ranges from 0 to 15.

FSL_PMC_DRIVER_VERSION

PMC driver version.

enum __pmc_interrupt_enable

The enumeration of PMC voltage detection interrupts.

Values:

enumerator `kPMC_2P2VLowVoltageInterruptEnable`

If the input supply is currently dropped below the 2.2V level, generate the low voltage interrupt.

enumerator `kPMC_2P2VHighVoltageInterruptEnable`

If the input supply is currently raised above the 2.2V level, generate the low voltage interrupt.

enumerator `kPMC_AllInterruptsEnable`

enum __pmc_status_flags

The enumeration of PMC status flags.

Values:

enumerator `kPMC_SmallRegulator2P7VActiveFlag`

The small regulator 2.7V supply is ready to be used.

enumerator `kPMC_LowVoltageInterruptFlag`

The low voltage interrupt flag, used to indicate whether the low voltage interrupt is asserted.

enumerator `kPMC_Sticky2P2VLowVoltageFlag`

Input supply has dropped below the 2.2V threshold. This sticky flag indicates that the input supply dropped below the 2.2V level at some point.

enumerator `kPMC_2P2VLowVoltageFlag`

Input supply is below the 2.2V threshold.

enumerator `kPMC_AllStatusFlags`

2.61 The Driver Change Log

2.62 PMC Peripheral and Driver Overview

2.63 eFlexPWM: Enhanced Flexible Pulse Width Modulator Driver

`void PWM_Init(PWM_Type *base, const pwm_config_t *psConfig)`

Initialization PWM module with provided structure `pwm_config_t`.

This function can initial one or more submodules of the PWM module.

This examples shows how only initial submodule 0 without fault protection channel.

```
pwm_config_t sPwmConfig = {0};
pwm_sm_config_t sPwmSm0Config;
sPwmConfig.psPwmSubmoduleConfig[0] = &sPwmSm0Config;
PWM_GetSmDefaultConfig(&sPwmSm0Config);
PWM_Init(PWM, sPwmConfig);
```

Note: This API should be called at the beginning of the application using the PWM driver.

Parameters

- `base` – PWM peripheral base address.
- `psConfig` – Pointer to PWM module configure structure. See `pwm_config_t`.

`void PWM_Deinit(PWM_Type *base)`

De-initialization a PWM module.

Parameters

- `base` – PWM peripheral base address

`void PWM_GetSMDDefaultConfig(pwm_sm_config_t *psConfig)`

Gets an default PWM submodule's configuration.

This function fills in the initialization structure member, which can make submodule generate 50% duty cycle center aligned PWM_A/B output.

The default effective values are:

```
psConfig->enableDebugMode = false;
psConfig->enableWaitMode = false;
psConfig->enableRun = false;
psConfig->sCounterConfig.eCountClockSource = kPWM_ClockSrcBusClock;
psConfig->sCounterConfig.eCountClockPrescale = kPWM_ClockPrescaleDivide1;
psConfig->sCounterConfig.eCountInitSource = kPWM_InitOnLocalSync;
psConfig->sReloadConfig.eReloadSignalSelect = kPWM_LocalReloadSignal;
psConfig->sReloadConfig.eLoclReloadEffectTime = kPWM_TakeEffectAtReloadOportunity;
psConfig->sReloadConfig.eLocalReloadOportunity = kPWM_LoadEveryOportunity;
psConfig->sReloadConfig.bEnableFullCycleReloadOportunity = true;
psConfig->sReloadConfig.bEnableHalfCycleReloadOportunity = false;
psConfig->sValRegisterConfig.u16CounterInitialValue = 0xFF00U;
psConfig->sValRegisterConfig.u16ValRegister0 = 0x0U;
psConfig->sValRegisterConfig.u16ValRegister1 = 0x00FFU;
psConfig->sValRegisterConfig.u16ValRegister2 = 0xFF80U;
psConfig->sValRegisterConfig.u16ValRegister3 = 0x80U;
```

(continues on next page)

(continued from previous page)

```

psConfig->sValRegisterConfig.u16ValRegister4 = 0xFF80U;
psConfig->sValRegisterConfig.u16ValRegister5 = 0x80U;
psConfig->sForceConfig.eForceSignalSelect = kPWM_LocalSoftwareForce;
psConfig->sForceConfig.eSoftOutputFor23 = kPWM_SoftwareOutputLow;
psConfig->sForceConfig.eSoftOutputFor45 = kPWM_SoftwareOutputLow;
psConfig->sForceConfig.eForceOutput23 = kPWM_GeneratedPwm;
psConfig->sForceConfig.eForceOutput45 = kPWM_GeneratedPwm;
psConfig->sDeadTimeConfig.eMode = kPWM_Independent;
psConfig->sOutputConfig.ePwmXSignalSelect = kPWM_RawPwmX;
psConfig->sOutputConfig.bEnablePwmXOutput = true;
psConfig->sOutputConfig.bEnablePwmaOutput = true;
psConfig->sOutputConfig.bEnablePwmbOutput = true;
psConfig->sOutputConfig.ePwmXFaultState = kPWM_OutputLowOnFault;
psConfig->sOutputConfig.ePwmaFaultState = kPWM_OutputLowOnFault;
psConfig->sOutputConfig.ePwmbFaultState = kPWM_OutputLowOnFault;

```

Parameters

- psConfig – Pointer to user's PWM submodule config structure. See `pwm_sm_config_t`.

`void PWM_GetFaultProtectionDefaultConfig(pwm_fault_protection_config_t *psConfig)`

Gets an default fault protection channel's configuration.

The default effective values are:

```

psConfig->sFaultInput[i].eFaultActiveLevel = kPWM_Logic0;
psConfig->sFaultInput[i].bEnableAutoFaultClear = true;
psConfig->sFaultInput[i].bEnableFaultFullCycleRecovery = true;

```

Parameters

- psConfig – Pointer to user's PWM fault protection config structure. See `pwm_fault_protection_config_t`.

`void PWM_SetupSMConfig(PWM_Type *base, pwm_sm_number_t eSubModule, const pwm_sm_config_t *psConfig)`

Sets up the PWM submodule configure.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to submodule configure structure, see `pwm_sm_config_t`.

`static inline void PWM_SetupCounterConfig(PWM_Type *base, pwm_sm_number_t eSubModule, const pwm_sm_counter_config_t *psConfig)`

Sets up the PWM submodule counter configure.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to submodule counter configure structure, see `pwm_sm_counter_config_t`.

`static inline void PWM_SetCounterInitialValue(PWM_Type *base, pwm_sm_number_t eSubModule, uint16_t u16InitialValue)`

Sets the PWM submodule counter initial register value.

This function set the INIT register value, the counter will start counting from INIT register value when initial signal assert or software force set. This write value will be loaded into inner set of buffered registers according to reload logic configure.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- u16InitialValue – The submodule number counter initialize value.

```
static inline void PWM_SetupReloadLogicConfig(PWM_Type *base, pwm_sm_number_t
                                             eSubModule, const
                                             pwm_sm_reload_logic_config_t *psConfig)
```

Sets up the PWM submodule reload logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to submodule reload logic configure structure, see `pwm_sm_reload_logic_config_t`.

```
void PWM_GetValueConfig(pwm_sm_value_register_config_t *psConfig,
                       pwm_sm_typical_output_mode_t eTypicalOutputMode, uint16_t
                       u16PwmPeriod, uint16_t u16PwmAPulseWidth, uint16_t
                       u16PwmBPulseWidth)
```

Update PWM submodule compare value configuration according to the typical output mode.

Parameters

- psConfig – See `pwm_sm_config_t`.
- eTypicalOutputMode – Typical PWM_A/B output mode. See `pwm_sm_typical_output_mode_t`.
- u16PwmPeriod – PWM output period value in counter ticks. This value can be got by (main counter clock in Hz) / (wanted PWM signal frequency in Hz).
- u16PwmAPulseWidth – PWM_A pulse width value in counter ticks. Can got by (wanted PWM duty Cycle) * u16PwmPeriod.
- u16PwmBPulseWidth – PWM_B pulse width value in counter ticks. Can got by (wanted PWM duty Cycle) * u16PwmPeriod.

```
static inline void PWM_SetupValRegisterConfig(PWM_Type *base, pwm_sm_number_t
                                             eSubModule, const
                                             pwm_sm_value_register_config_t *psConfig)
```

Sets up the PWM submodule VALn registers logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to VALn registers configure structure, see `pwm_sm_value_register_config_t`.

```
static inline void PWM_SetValueRegister(PWM_Type *base, pwm_sm_number_t eSubModule,  
                                       pwm_sm_val_register_t eRegister, uint16_t u16Value)
```

Sets the PWM submodule VALn register value.

Note: These write value will be loaded into inner set of buffered registers according to reload logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – Value register index (range in 0~5), see `pwm_sm_val_register_t`.
- u16Value – The value for VALn register.

```
static inline uint16_t PWM_GetValueRegister(PWM_Type *base, pwm_sm_number_t  
                                           eSubModule, pwm_sm_val_register_t eRegister)
```

Gets the PWM submodule VALn register value.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – Value register index (range in 0~5), see `pwm_sm_val_register_t`.

Returns

The VALn register value.

```
static inline void PWM_SetFracvalRegister(PWM_Type *base, pwm_sm_number_t eSubModule,  
                                          pwm_sm_fracval_register_t eRegister, uint16_t  
                                          u16Value)
```

Sets the PWM submodule fractional value register value.

Note: These write value will be loaded into inner set of buffered registers according to reload logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – Fractional value register index (range in 1~5), see `pwm_sm_val_register_t`.
- u16Value – The value for FRACVALn register.

```
static inline uint16_t PWM_GetFracvalRegister(PWM_Type *base, pwm_sm_number_t  
                                              eSubModule, pwm_sm_fracval_register_t  
                                              eRegister)
```

Sets the PWM submodule fractional value register value.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – Fractional value register index (range in 1~5), see `pwm_sm_fracval_register_t`.

Returns

The VALn FRACVALn value.

```
static inline void PWM_SetValueAndFracRegister(PWM_Type *base, pwm_sm_number_t
                                              eSubModule, pwm_sm_fracval_register_t
                                              eRegister, uint32_t u32Value)
```

Set submodule register VALx and its FRAC value with 32bit access.

Parameters

- base – PWM peripheral base address.
- eSubModule – Submodule ID.
- eRegister – Fractional value register index (range in 1~5), see `pwm_sm_fracval_register_t`.
- u32Value – 32bit value for VALx and its FRAC. VALx: BIT16~BIT31. FRAC-VALx: BIT11~BIT15. RESERVED: BIT10~BIT0.

```
static inline uint32_t PWM_GetValueAndFracRegister(PWM_Type *base, pwm_sm_number_t
                                                  eSubModule, pwm_sm_fracval_register_t
                                                  eRegister)
```

Get submodule register VALx and its FRAC value with 32bit access.

Parameters

- base – PWM peripheral base address.
- eSubModule – Submodule ID.
- eRegister – Fractional value register index (range in 1~5), see `pwm_sm_fracval_register_t`.

Returns

The value of submodule register VALx and its FRAC, combined into 32bit. VALx: BIT16~BIT31. FRACVALx: BIT11~BIT15. RESERVED: BIT10~BIT0.

```
static inline void PWM_SetPwmLdok(PWM_Type *base, uint16_t u16Mask)
```

Set the PWM LDOK bit on a single or multiple submodules.

Enable this feature can make buffered CTRL[PRSC] and the INIT, FRACVAL and VAL registers values take effect after next local load signal assert. The timing of take effect can be the next PWM reload or immediately. After loading, MCTRL[LDOK] is automatically cleared and need to enable again before the next register updated.

Note: The VALx, FRACVALx, INIT, and CTRL[PRSC] registers of the corresponding submodule cannot be written while the the corresponding MCTRL[LDOK] bit is set.

Parameters

- base – PWM peripheral base address
- u16Mask – PWM submodules to set the LDOK bit, Logical OR of `_pwm_sm_enable`.

```
static inline void PWM_ClearPwmLdok(PWM_Type *base, uint16_t u16Mask)
```

Clear the PWM LDOK bit on a single or multiple submodules.

Parameters

- base – PWM peripheral base address
- u16Mask – PWM submodules to clear the LDOK bit, Logical OR of `_pwm_sm_enable`.

```
static inline void PWM_SetupForceLogicConfig(PWM_Type *base, pwm_sm_number_t
                                             eSubModule, const pwm_sm_force_logic_config_t
                                             *psConfig)
```

brief Sets up the PWM submodule force logic configure.

param base PWM peripheral base address. param eSubModule PWM submodule number, see pwm_sm_number_t. param psConfig Pointer to submodule force logic configure structure, see pwm_sm_force_logic_config_t.

```
static inline void PWM_SetSoftwareForce(PWM_Type *base, pwm_sm_number_t eSubModule)
Sets up the PWM Sub-Module to trigger a software FORCE_OUT event.
```

Note: Only works when the CTRL2[FORCE_SEL] select kPWM_ForceOutOnLocalSoftware.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see pwm_sm_number_t.

```
void PWM_SetupDeadtimeConfig(PWM_Type *base, pwm_sm_number_t eSubModule, const
                             pwm_sm_deadtime_logic_config_t *psConfig)
```

Sets up the PWM submodule deadtime logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see pwm_sm_number_t.
- psConfig – Pointer to deadtime logic configure structure, see pwm_sm_deadtime_logic_config_t.

```
static inline uint16_t PWM_GetDeadtimeSampleValue(PWM_Type *base, pwm_sm_number_t
                                                  eSubModule)
```

Get the sampled values of the PWM_X input at the end of each deadtime.

When use PWM_A/B in complementary mode and connect to transistor to controls the output voltage. Need insert deadtime to avoid overlap of conducting interval between the top and bottom transistor. And both transistors in complementary mode are off during deadtime. Then connect the PWM_X input to complementary transistors output, then it sampling input at the end of deadtime 0 for DT[0] and the end of deadtime 1 for DT[1]. Which DT value is not 0 indicates that there is a problem with the corresponding deadtime value. This can help to decide if there need do a deadtime correction for current complementary PWM output.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see pwm_sm_number_t.

Returns

The PWM_X input sampled values.

```
void PWM_SetupFractionalDelayConfig(PWM_Type *base, pwm_sm_number_t eSubModule,
                                    const pwm_sm_fractional_delay_logic_config_t *psConfig)
```

Sets up the PWM submodule fractional delay logic configure.

Note: The fractional delay logic can only be used when the IPBus clock is running at 100 MHz.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to fractional delay logic configure structure, see `pwm_sm_fractional_delay_logic_config_t`.

```
void PWM_SetupOutputConfig(PWM_Type *base, pwm_sm_number_t eSubModule, const  
                           pwm_sm_output_logic_config_t *psConfig)
```

Sets up the PWM submodule output logic configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to output logic configure structure, see `pwm_sm_output_logic_config_t`.

```
static inline void PWM_EnableOutput(PWM_Type *base, uint16_t u16SubModules,  
                                   pwm_sm_pwm_out_t eOutput)
```

Enables the PWM submodule pin output.

This function handles PWMX_EN/PWMA_EN/PWMB_EN bit filed of OUTEN register, whcih can enable one or more submodule pin in PWMX/A/B.

Parameters

- base – PWM peripheral base address
- u16SubModules – The submodules that enable eOutput output, logical OR of `_pwm_sm_enable`.
- eOutput – PWM output pin ID, see `pwm_sm_pwm_out_t`.

```
static inline void PWM_DisableOutput(PWM_Type *base, uint16_t u16SubModules,  
                                     pwm_sm_pwm_out_t eOutput)
```

Disables the PWM submodule pin output.

This function handles PWMX_EN/PWMA_EN/PWMB_EN bit filed of OUTEN register, whcih can disable one or more submodule pin in PWMX/A/B.

Parameters

- base – PWM peripheral base address
- u16SubModules – The submodules that disable eOutput output, logical OR of `_pwm_sm_enable`.
- eOutput – PWM output pin ID, see `pwm_sm_pwm_out_t`.

```
static inline void PWM_EnableCombinedOutput(PWM_Type *base, uint16_t u16XSubModules,  
                                             uint16_t u16ASubModules, uint16_t  
                                             u16BSubModules)
```

Enables the PWM pin combination output.

This function handles PWMX_EN/PWMA_EN/PWMB_EN bit filed of OUTEN register at the same time.

Parameters

- base – PWM peripheral base address
- u16XSubModules – The submodules that enable PWMX output, should be logical OR of `_pwm_sm_enable`.

- `u16ASubModules` – The submodules that enable PWMA output, should be logical OR of `_pwm_sm_enable`.
- `u16BSubModules` – The submodules that enable PWMB output, should be logical OR of `_pwm_sm_enable`.

```
static inline void PWM_DisableCombinedOutput(PWM_Type *base, uint16_t u16XSubModules,  
                                             uint16_t u16ASubModules, uint16_t  
                                             u16BSubModules)
```

Disables the PWM pin combination output.

This function handles PWMX_EN/PWMA_EN/PWMB_EN bit filed of OUTEN register at the same time.

Parameters

- `base` – PWM peripheral base address
- `u16XSubModules` – The submodules that disable PWMX output, should be logical OR of `_pwm_sm_enable`.
- `u16ASubModules` – The submodules that disable PWMA output, should be logical OR of `_pwm_sm_enable`.
- `u16BSubModules` – The submodules that disable PWMB output, should be logical OR of `_pwm_sm_enable`.

```
static inline void PWM_MaskOutput(PWM_Type *base, uint16_t u16SubModules,  
                                pwm_sm_pwm_out_t eOutput)
```

Mask the PWM pin output.

This function handles MASKA/MASKB/MASKX bit filed of MASK register, which can mask one or more submodule pin in PWMX/A/B.

Note: The mask bits is buffered and can be updated until a FORCE_OUT event occurs or a software update command.

Parameters

- `base` – PWM peripheral base address.
- `u16SubModules` – The submodules that mask eOutput output, logical OR of `_pwm_sm_enable`.
- `eOutput` – PWM output pin ID, see `pwm_sm_pwm_out_t`.

```
static inline void PWM_UnmaskOutput(PWM_Type *base, uint16_t u16SubModules,  
                                   pwm_sm_pwm_out_t eOutput)
```

Unmask the PWM pin output.

This function handles MASKA/MASKB/MASKX bit filed of MASK register, which can mask one or more submodule pin in PWMX/A/B.

Note: The mask bits is buffered and can be updated until a FORCE_OUT event occurs or a software update command.

Parameters

- `base` – PWM peripheral base address
- `u16SubModules` – The submodules that unmask eOutput output, logical OR of `_pwm_sm_enable`.

- eOutput – PWM output pin ID, see `pwm_sm_pwm_out_t`.

```
static inline void PWM_MaskCombinedOutput(PWM_Type *base, uint16_t u16XSubModules,  
                                         uint16_t u16ASubModules, uint16_t  
                                         u16BSubModules)
```

Mask the PWM pin combination output.

This function handles MASKA/MASKB/MASKX bit field of MASK register at the same time.

Note: The mask bits is buffered and can be updated until a FORCE_OUT event occurs or a software update command.

Parameters

- base – PWM peripheral base address
- u16XSubModules – The submodules that mask PWMX output, should be logical OR of `_pwm_sm_enable`.
- u16ASubModules – The submodules that mask PWMA output, should be logical OR of `_pwm_sm_enable`.
- u16BSubModules – The submodules that mask PWMB output, should be logical OR of `_pwm_sm_enable`.

```
static inline void PWM_UnmaskCombinedOutput(PWM_Type *base, uint16_t u16XSubModules,  
                                           uint16_t u16ASubModules, uint16_t  
                                           u16BSubModules)
```

Unmask the PWM pin combination output.

This function handles MASKA/MASKB/MASKX bit field of MASK register at the same time.

Note: The mask bits is buffered and can be updated until a FORCE_OUT event occurs or a software update command.

Parameters

- base – PWM peripheral base address
- u16XSubModules – The submodules that unmask PWMX output, should be logical OR of `_pwm_sm_enable`.
- u16ASubModules – The submodules that unmask PWMA output, should be logical OR of `_pwm_sm_enable`.
- u16BSubModules – The submodules that unmask PWMB output, should be logical OR of `_pwm_sm_enable`.

```
static inline void PWM_UpdateMask(PWM_Type *base, pwm_sm_number_t eSubModule)  
    Update PWM output mask bits immediately with a software command.
```

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.

```
static inline void PWM_EnablePwmRunInDebug(PWM_Type *base, pwm_sm_number_t  
                                           eSubModule, bool bEnable)
```

Enables/Disables the PWM submodule continue to run while the chip is in DEBUG mode.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- bEnable – Enable the feature or not.
 - **true** Enable load feature.
 - **false** Disable load feature.

```
static inline void PWM_EnablePwmRunInWait(PWM_Type *base, pwm_sm_number_t
                                         eSubModule, bool bEnable)
```

Enables/Disables the PWM submodule continue to run while the chip is in WAIT mode.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- bEnable – Enable the feature or not.
 - **true** Enable load feature.
 - **false** Disable load feature.

```
static inline void PWM_EnableCounters(PWM_Type *base, uint16_t u16Mask)
```

Starts the PWM submodule counter for a single or multiple submodules.

Sets the Run bit which enables the clocks to the PWM submodule. This function can start multiple submodules at the same time.

Parameters

- base – PWM peripheral base address
- u16Mask – PWM submodules to start run, Logical OR of `_pwm_sm_enable`.

```
static inline void PWM_DisableCounters(PWM_Type *base, uint16_t u16Mask)
```

Stops the PWM counter for a single or multiple submodules.

Clears the Run bit which resets the submodule's counter. This function can stop multiple submodules at the same time.

Parameters

- base – PWM peripheral base address
- u16Mask – PWM submodules to start run, Logical OR of `_pwm_sm_enable`.

```
static inline uint16_t PWM_GetCaptureValue(PWM_Type *base, pwm_sm_number_t
                                           eSubModule, pwm_sm_input_capture_register_t
                                           eRegister)
```

Reads PWM submodule input capture value register.

This function read the CVALn register value, stores the value captured from the submodule counter.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – PWM submodule input capture value register, see `pwm_sm_input_capture_register_t`.

Returns

The input capture value.

```
static inline uint16_t PWM_GetCaptureValueCycle(PWM_Type *base, pwm_sm_number_t
                                              eSubModule,
                                              pwm_sm_input_capture_register_t eRegister)
```

Reads PWM submodule input capture value cycle register.

This function read the CVALnCYC register value, stores the cycle number corresponding to the value captured in CVALn. This register is incremented each time the counter is loaded with the INIT value at the end of a PWM modulo cycle.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eRegister – PWM submodule input capture value register, see `pwm_sm_input_capture_register_t`.

Returns

The input capture register cycle value.

```
static inline uint16_t PWM_GetCaptureEdgeCounterVaule(PWM_Type *base, pwm_sm_number_t
                                                    eSubModule,
                                                    pwm_sm_input_capture_pin_t
                                                    eInputPin)
```

Reads the PWM submodule input capture logic edge counter value.

Each input capture logic has a edge counter, which counts both the rising and falling edges of the input capture signal and it compare signal can select as input capture trigger source.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eInputPin – PWM submodule input capture pin number, see `pwm_sm_input_capture_pin_t`.

```
void PWM_SetupInputCaptureConfig(PWM_Type *base, pwm_sm_number_t eSubModule,
                                pwm_sm_input_capture_pin_t eInputPin, const
                                pwm_sm_input_capture_config_t *psConfig)
```

Sets up the PWM submodule input capture configure.

Each PWM submodule has 3 pins that can be configured for use as input capture pins. This function sets up the capture parameters for each pin and enables the input capture operation.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eInputPin – PWM submodule input capture pin number, see `pwm_sm_input_capture_pin_t`.
- psConfig – Pointer to input capture configure structure, see `pwm_sm_input_capture_config_t`.

```
static inline void PWM_EnableInputCapture(PWM_Type *base, pwm_sm_number_t eSubModule,
                                          pwm_sm_input_capture_pin_t eInputPin)
```

Enables the PWM submodule input capture operation.

Enables input capture operation will start the input capture process. The enable bit is self-cleared when in one shot mode and one or more of the enabled capture circuits has had a capture event.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eInputPin – PWM submodule input capture pin number, see `pwm_sm_input_capture_pin_t`.

```
static inline void PWM_DisableInputCapture(PWM_Type *base, pwm_sm_number_t
                                           eSubModule, pwm_sm_input_capture_pin_t
                                           eInputPin)
```

Disables the PWM submodule input capture operation.

The enable bit can be cleared at any time to disable input capture operation.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eInputPin – PWM submodule input capture pin number, see `pwm_sm_input_capture_pin_t`.

```
static inline uint16_t PWM_GetInputValue(PWM_Type *base, pwm_sm_number_t eSubModule,
                                         pwm_sm_input_capture_pin_t eInputPin)
```

Get the logic value currently being driven into the PWM inputs.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eInputPin – PWM submodule input capture pin number, see `pwm_sm_input_capture_pin_t`.

Returns

The PWM submodule input capture pin logic value.

```
void PWM_SetupFaultProtectionConfig(PWM_Type *base, pwm_fault_protection_channel_t
                                    eFaultProtection, const pwm_fault_protection_config_t
                                    *psConfig)
```

Sets up the PWM fault protection channel configure.

Parameters

- base – PWM peripheral base address.
- eFaultProtection – PWM fault protection channel number, see `pwm_fault_protection_channel_t`.
- psConfig – Pointer to fault protection channel configure structure, see `pwm_fault_protection_config_t`.

```
static inline void PWM_SetupSMFaultInputMapping(PWM_Type *base, pwm_sm_number_t
                                                eSubModule, pwm_sm_pwm_out_t
                                                ePwmOutput, const
                                                pwm_sm_fault_input_mapping_t
                                                *psMapping)
```

Mapping fault protection channel fault input status to PWM submodule output.

Note: Each PWM output can be mapping anyone or more fault inputs. The mapped fault protection channel inputs can disable PWM output.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- ePwmOutput – PWM submodule output, see `pwm_sm_pwm_out_t`.
- psMapping – The fault input disable mapping structure, see `pwm_sm_fault_input_mapping_t`.

```
void PWM_SetupDmaConfig(PWM_Type *base, pwm_sm_number_t eSubModule, const  
                        pwm_sm_dma_config_t *psConfig)
```

Sets up the PWM submodule DMA configure.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- psConfig – Pointer to PWM submodule DMA configure, see `pwm_sm_dma_config_t`.

```
static inline void PWM_SetEnabledCaptureDmaSource(PWM_Type *base, pwm_sm_number_t  
                                                  eSubModule,  
                                                  pwm_sm_capture_dma_source_t  
                                                  eCaptureDmaSource)
```

Select the trigger source for enabled capture FIFOs DMA read request.

Note: This function only can be used when the `bEnableCaptureDMA` be true.

Parameters

- base – PWM peripheral base address.
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- eCaptureDmaSource – The PWM DMA capture source.

```
static inline void PWM_EnableSMInterrupts(PWM_Type *base, pwm_sm_number_t eSubModule,  
                                          uint16_t u16Mask)
```

Enables the PWM submodule interrupts according to a provided mask.

This examples shows how to enable VAL 0 compare interrupt and VAL 1 compare interrupt.

```
PWM_EnableSMInterrupts(PWM, kPWM_SubModule0, kPWM_CompareVal0InterruptEnable |  
kPWM_CompareVal1InterruptEnable);
```

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- u16Mask – The PWM submodule interrupts to enable. Logical OR of `_pwm_sm_interrupt_enable`.

```
static inline void PWM_DisbaleSMInterrupts(PWM_Type *base, pwm_sm_number_t eSubModule,  
                                           uint16_t u16Mask)
```

Disables the PWM submodule interrupts according to a provided mask.

This examples shows how to disable VAL 0 compare interrupt and VAL 1 compare interrupt.

```
PWM_DisableSMInterrupts(PWM, kPWM_SubModule0, kPWM_CompareVal0InterruptEnable |
kPWM_CompareVal1InterruptEnable);
```

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- u16Mask – The PWM submodule interrupts to enable. Logical OR of `_pwm_sm_interrupt_enable`.

```
static inline void PWM_EnableFaultInterrupts(PWM_Type *base,
                                             pwm_fault_protection_channel_t eFaultProtection,
                                             uint16_t u16Mask)
```

Enables the PWM fault protection channel interrupt according to a provided mask.

This examples shows how to enable fault pin 0 interrupt and fault pin 1 interrupt.

```
PWM_EnableFaultInterrupts(PWM, kPWM_FaultProtection0, kPWM_Fault0InterruptEnable |
kPWM_Fault1InterruptEnable);
```

Parameters

- base – PWM peripheral base address
- eFaultProtection – PWM fault protection channel number, see `pwm_fault_protection_channel_t`.
- u16Mask – The PWM fault protection channel interrupts to enable. Logical OR of `_pwm_fault_protection_interrupt_enable`.

```
static inline void PWM_DisableFaultInterrupts(PWM_Type *base,
                                              pwm_fault_protection_channel_t
                                              eFaultProtection, uint16_t u16Mask)
```

Disables the PWM fault protection channel interrupt according to a provided mask.

This examples shows how to disable fault pin 0 interrupt and fault pin 1 interrupt.

```
PWM_DisableFaultInterrupts(PWM, kPWM_FaultProtection0, kPWM_Fault0InterruptEnable |
kPWM_Fault1InterruptEnable);
```

Parameters

- base – PWM peripheral base address
- eFaultProtection – PWM fault protection channel number, see `pwm_fault_protection_channel_t`.
- u16Mask – The PWM fault protection channel interrupts to disable. Logical OR of `_pwm_fault_protection_interrupt_enable`.

```
static inline uint16_t PWM_GetSMStatusFlags(PWM_Type *base, pwm_sm_number_t
                                             eSubModule)
```

Gets the PWM submodule status flags.

This examples shows how to check whether the submodule VAL0 compare flag set.

```
if((PWM_GetSMStatusFlags(PWM, kPWM_SubModule0) & kPWM_CompareVal0Flag) != 0U)
{
    ...
}
```

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.

Returns

The PWM submodule status flags. This is the logical OR of `pwm_sm_status_flags_t`.

```
static inline void PWM_ClearSMStatusFlags(PWM_Type *base, pwm_sm_number_t eSubModule,
                                          uint16_t u16Mask)
```

Clears the PWM submodule status flags.

This examples shows how to clear the submodule VAL0 compare flag.

```
PWM_ClearSMStatusFlags(PWM, kPWM_SubModule0, kPWM_CompareVal0Flag);
```

Note: The `kPWM_RegUpdatedFlag` can't be cleared by software.

Parameters

- base – PWM peripheral base address
- eSubModule – PWM submodule number, see `pwm_sm_number_t`.
- u16Mask – The status flags to clear. This is the logical OR of `pwm_sm_status_flags_t`.

```
static inline uint16_t PWM_GetFaultStatusFlags(PWM_Type *base,
                                              pwm_fault_protection_channel_t
                                              eFaultProtection)
```

Gets the PWM fault protection status flags.

This examples shows how to check whether the fault protection channel fault input pin 0 set.

```
if((PWM_GetFaultStatusFlags(PWM, kPWM_FaultProtection0) & kPWM_FaultPin0Flag) != 0U)
{
    ...
}
```

Parameters

- base – PWM peripheral base address
- eFaultProtection – PWM fault protection channel number, see `pwm_fault_protection_channel_t`.

Returns

The PWM fault protection channel status flags. This is the logical OR of `_pwm_fault_protection_status_flags`.

```
static inline void PWM_ClearFaultStatusFlags(PWM_Type *base,
                                             pwm_fault_protection_channel_t eFaultProtection,
                                             uint16_t u16Mask)
```

Clears the PWM fault protection status flags according to a provided mask.

This examples shows how to clear the fault protection channel fault 0 flag.

```
PWM_ClearFaultStatusFlags(PWM, kPWM_FaultProtection0, kPWM_Fault0Flag);
```

Note: The kPWM_FaultPin0ActiveFlag ~ kPWM_FaultPin3ActiveFlag can't be cleared by software.

Parameters

- base – PWM peripheral base address
- eFaultProtection – PWM fault protection channel number, see `pwm_fault_protection_channel_t`.
- u16Mask – The PWM fault protection status flags to be clear. Logical OR of `_pwm_fault_protection_status_flags`.

FSL_PWM_DRIVER_VERSION

PWM driver version.

enum _pwm_sm_number

The enumeration for PWM submodule number.

Values:

enumerator kPWM_SubModule0

PWM Submodule 0

enumerator kPWM_SubModule1

PWM Submodule 1

enumerator kPWM_SubModule2

PWM Submodule 2

enumerator kPWM_SubModule3

PWM Submodule 3

enum _pwm_sm_enable

The enumeration for PWM submodule enable.

Values:

enumerator kPWM_SubModule0Enable

PWM Submodule 0 enable.

enumerator kPWM_SubModule1Enable

PWM Submodule 1 enable.

enumerator kPWM_SubModule2Enable

PWM Submodule 2 enable.

enumerator kPWM_SubModule3Enable

PWM Submodule 3 enable.

enumerator kPWM_ALLSubModuleEnable

enum _pwm_sm_count_clock_source

The enumeration for PWM submodule clock source.

Values:

enumerator kPWM_ClockSrcBusClock

The IPBus clock is used as the source clock

enumerator kPWM_ClockSrcExternalClock

EXT_CLK is used as the source clock

enumerator kPWM__ClockSrcSubmodule0Clock

Clock of the submodule 0 (AUX_CLK) is used as the source clock

enum __pwm_sm_count_clock_prescaler

The enumeration for PWM submodule prescaler factor selection for clock source.

Values:

enumerator kPWM__ClockPrescaleDivide1

PWM submodule clock frequency = fclk/1

enumerator kPWM__ClockPrescaleDivide2

PWM submodule clock frequency = fclk/2

enumerator kPWM__ClockPrescaleDivide4

PWM submodule clock frequency = fclk/4

enumerator kPWM__ClockPrescaleDivide8

PWM submodule clock frequency = fclk/8

enumerator kPWM__ClockPrescaleDivide16

PWM submodule clock frequency = fclk/16

enumerator kPWM__ClockPrescaleDivide32

PWM submodule clock frequency = fclk/32

enumerator kPWM__ClockPrescaleDivide64

PWM submodule clock frequency = fclk/64

enumerator kPWM__ClockPrescaleDivide128

PWM submodule clock frequency = fclk/128

enum __pwm_sm_count_init_source

The enumeration for PWM submodule counter initialization options.

Values:

enumerator kPWM__InitOnLocalSync

Local sync causes initialization

enumerator kPWM__InitOnMasterReload

Master reload from submodule 0 causes initialization

enumerator kPWM__InitOnMasterSync

Master sync from submodule 0 causes initialization

enumerator kPWM__InitOnExtSync

EXT_SYNC causes initialization

enum __pwm_ml2_stretch_count_clock_prescaler

The enumeration for PWM stretch IPBus clock count prescaler for mux0_trig/mux1_trig/out0_trig/out1_trig/pwma_trig/pwmb_trig.

Values:

enumerator kPWM__StretchIPBusClockPrescaler1

Stretch count is zero, no stretch.

enumerator kPWM__StretchIPBusClockPrescaler2

Stretch mux0_trig/mux1_trig/out0_trig/out1_trig/pwma_trig/pwmb_trig for 2 IPBus clock period.

enumerator kPWM_StretchIPBusClockPrescaler4

Stretch mux0_trig/mux1_trig/out0_trig/out1_trig/pwma_trig/pwmb_trig for 4 IPBus clock period.

enumerator kPWM_StretchIPBusClockPrescaler8

Stretch mux0_trig/mux1_trig/out0_trig/out1_trig/pwma_trig/pwmb_trig for 8 IPBus clock period.

enum __pwm_sm_reload_signal_select

The enumeration for PWM submodule local reload take effect timing.

Values:

enumerator kPWM_LocalReloadSignal

The local RELOAD signal is used to reload buffered-registers.

enumerator kPWM_MasterReloadSignal

The master RELOAD signal (from submodule 0) is used to reload buffered-registers (should not be used in submodule 0).

enum __pwm_sm_local_reload_effect_timing

The enumeration for PWM submodule local reload take effect timing.

Values:

enumerator kPWM_TakeEffectAtReloadOpportunity

Buffered-registers reload after one/more reload opportunities, and a load opportunity can generate on a PWM half or/and full cycle.

enumerator kPWM_TakeEffectImmediately

Buffered-registers reload with new values as soon as MCTRL[LDOK] bit is set when choose local reload.

enum __pwm_sm_local_reload_opportunity

The enumeration for PWM submodule reload opportunities selection under kPWM_ReloadWithLocalReloadOpportunity.

Values:

enumerator kPWM_LoadEveryOpportunity

Every PWM submodule reload opportunity

enumerator kPWM_LoadEvery2Opportunity

Every 2 PWM submodule reload opportunities

enumerator kPWM_LoadEvery3Opportunity

Every 3 PWM submodule reload opportunities

enumerator kPWM_LoadEvery4Opportunity

Every 4 PWM submodule reload opportunities

enumerator kPWM_LoadEvery5Opportunity

Every 5 PWM submodule reload opportunities

enumerator kPWM_LoadEvery6Opportunity

Every 6 PWM submodule reload opportunities

enumerator kPWM_LoadEvery7Opportunity

Every 7 PWM submodule reload opportunities

enumerator kPWM_LoadEvery8Opportunity

Every 8 PWM submodule reload opportunities

enumerator kPWM_LoadEvery9Opportunity
Every 9 PWM submodule reload opportunities

enumerator kPWM_LoadEvery10Opportunity
Every 10 PWM submodule reload opportunities

enumerator kPWM_LoadEvery11Opportunity
Every 11 PWM submodule reload opportunities

enumerator kPWM_LoadEvery12Opportunity
Every 12 PWM submodule reload opportunities

enumerator kPWM_LoadEvery13Opportunity
Every 13 PWM submodule reload opportunities

enumerator kPWM_LoadEvery14Opportunity
Every 14 PWM submodule reload opportunities

enumerator kPWM_LoadEvery15Opportunity
Every 15 PWM submodule reload opportunities

enumerator kPWM_LoadEvery16Opportunity
Every 16 PWM submodule reload opportunities

enum _pwm_sm_val_compare_mode
The enumeration for PWM submodule VALn register compare mode.

Values:

enumerator kPWM_CompareOnEqual
The VALn registers and the PWM counter are compared using an “equal to” method.

enumerator kPWM_CompareOnEqualOrGreater
The VALn registers and the PWM counter are compared using an “equal to or greater than” method.

enum _pwm_sm_val_register
The enumeration for PWM submodule VAL registers.

Values:

enumerator kPWM_VAL0
PWM submodule value register 0.

enumerator kPWM_VAL1
PWM submodule value register 1.

enumerator kPWM_VAL2
PWM submodule value register 2.

enumerator kPWM_VAL3
PWM submodule value register 3.

enumerator kPWM_VAL4
PWM submodule value register 4.

enumerator kPWM_VAL5
PWM submodule value register 5.

enum _pwm_sm_force_signal_select

The enumeration for PWM submodule FORCE_OUT source which can trigger force logic output update.

Values:

enumerator kPWM_LocalSoftwareForce

The local software force signal CTRL2[FORCE] is used to force updates.

enumerator kPWM_MasterSoftwareForce

The master software force signal from submodule 0 is used to force updates.

enumerator kPWM_LocalReloadForce

The local reload signal from this submodule is used to force updates without regard to the state of LDOK.

enumerator kPWM_MasterReloadForce

The master reload signal from submodule 0 is used to force updates if LDOK is set, should not be used in submodule 0.

enumerator kPWM_LocalSyncForce

The local sync (VAL1 match event) signal from this submodule is used to force updates.

enumerator kPWM_MasterSyncForce

The master sync signal from submodule0 is used to force updates.

enumerator kPWM_ExternalForceForce

The external force signal EXT_FORCE, from outside the PWM module causes updates.

enumerator kPWM_ExternalSyncForce

The external sync signal EXT_SYNC, from outside the PWM module causes updates.

enum _pwm_sm_force_deadtime_source

The enumeration for PWM submodule force out logic output (PWM23 and PWM45) source, which will transfer to output logic when a FORCE_OUT signal is asserted.

Values:

enumerator kPWM_GeneratedPwm

Generated PWM signal is used as the deadtime logic output.

enumerator kPWM_InvertedGeneratedPwm

Inverted PWM signal is used as the deadtime logic output.

enumerator kPWM_SoftwareControlValue

Software controlled value is used as the deadtime logic output.

enumerator kPWM_UseExternal

PWM_EXT_A signal is used as the deadtime logic output.

enum _pwm_sm_force_software_output_value

The enumeration for PWM submodule software controlled force out signal value.

Values:

enumerator kPWM_SoftwareOutputLow

A logic 0 is supplied to the deadtime generator when chose Software controlled value as output source.

enumerator kPWM_SoftwareOutputHigh

A logic 1 is supplied to the deadtime generator when chose Software controlled value as output source.

enum _pwm_sm_deadtime_logic_mode

The enumeration for PWM submodule deadtime logic mode, which decide how the dead-time logic process the force logic output signal.

Values:

enumerator kPWM_Independent

The PWMA (PWM23) and PWMB (PWM45) signal from force logic transfer to output logic independent.

enumerator kPWM_IndependentWithDoubleSwitchPwm

The PWMA (PWM23) and PWMB (PWM45) signals from force logic will XOR first, then the XOR signal transfer to output logic independent.

enumerator kPWM_IndependentWithSplitDoubleSwitchPwm

The PWMA (PWM23) and PWMB (PWM45) signals from force_out logic will XOR first, then the XOR signal transfer to output logic independent.

enumerator kPWM_ComplementaryWithPwmA

The PWMA (PWM23) signal from force logic will transfer to output logic with complementary mode.

enumerator kPWM_ComplementaryWithPwmB

The PWMB (PWM45) signal from force logic will transfer to output logic with complementary mode.

enumerator kPWM_ComplementaryWithDoubleSwitchPwm

The PWMA (PWM23) and PWMB (PWM45) signals from force logic will XOR first, then the XOR signal transfer to output logic with complementary mode.

enum _pwm_sm_fracval_register

The enumeration for PWM submodule FRACVAL registers.

Values:

enumerator kPWM_FRACVAL1

PWM submodule fractional value register 1.

enumerator kPWM_FRACVAL2

PWM submodule fractional value register 2.

enumerator kPWM_FRACVAL3

PWM submodule fractional value register 3.

enumerator kPWM_FRACVAL4

PWM submodule fractional value register 4.

enumerator kPWM_FRACVAL5

PWM submodule fractional value register 5.

enum _pwm_sm_mux_trigger_source

The enumeration for PWM submodule output logic final trigger output port signal.

Values:

enumerator kPWM_ActualCompareEvent

Route the PWM_OUT_TRIG signal (OR of VALx compare signal) to the mux trigger output port.

enumerator kPWM_PwmOutput

Route the PWM output (after polarity/mask/enable control) to the mux trigger output port.

enum `_pwm_sm_pwm_output_on_fault`

The enumeration for PWM submodule output logic PWM output fault status.

Values:

enumerator `kPWM_OutputLowOnFault`

The output is forced to logic 0 state prior to consideration of output polarity/mask/enable control during fault conditions and STOP mode.

enumerator `kPWM_OutputHighOnFault`

The output is forced to logic 1 state prior to consideration of output polarity/mask/enable control during fault conditions and STOP mode.

enumerator `kPWM_OutputTristatedOnFault`

The output status be tristated during fault conditions and STOP mode.

enum `_pwm_sm_pwmX_signal_select`

The enumeration for PWM submodule output logic PwmX signal input source (before output polarity/mask/enable control).

Values:

enumerator `kPWM_RawPwmX`

The PWM_X source is raw Pwm01_fractional_delay signal.

enumerator `kPWM_DoubleSwitch`

The PWM_X source is Pwm23_fractional_delay XOR Pwm23_fractional_delay signal.

enum `_pwm_sm_pwm_out`

The enumeration for PWM submodule PWM output.

Values:

enumerator `kPWM_PwmX`

The PWM output PWM_X.

enumerator `kPWM_PwmB`

The PWM output PWM_B.

enumerator `kPWM_PwmA`

The PWM output PWM_A.

enum `_pwm_sm_input_capture_pin`

The enumeration for PWM submodule input capture pins.

Values:

enumerator `kPWM_InputCapturePwmX`

The input capture pin PwmX, need disable PwmX output when enable input capture.

enumerator `kPWM_InputCapturePwmA`

The input capture pin PwmA, need disable PwmA output when enable input capture.

enumerator `kPWM_InputCapturePwmB`

The input capture pin PwmB, need disable PwmB output when enable input capture.

enum `_pwm_sm_input_capture_source`

The enumeration for PWM submodule input capture source.

Values:

enumerator `kPWM_RawInput`

The capture source is the raw input signal.

enumerator kPWM_InputEdgeCounter

The capture source is edge counter which counts rising and falling edges on the raw input signal.

enum _pwm_sm_input_capture_edge

The enumeration for PWM submodule input capture edge when choose raw input as capture source.

Values:

enumerator kPWM_Noedge

Disabled capture on source falling/falling edge.

enumerator kPWM_FallingEdge

Enable input capture, and capture on source falling edge when chose the raw input signal as capture source.

enumerator kPWM_RisingEdge

Enable input capture, and capture on source rising edge when chose the raw input signal as capture source.

enumerator kPWM_RiseAndFallEdge

Enable input capture, and capture on source rising or falling edge when chose the raw input signal as capture source.

enum _pwm_sm_input_capture_register

The enumeration for PWM submodule input capture value register.

Values:

enumerator kPWM_InpCaptureVal0

Stores the value captured from the submodule counter when the PWM_X circuitry 0 logic capture occurs.

enumerator kPWM_InpCaptureVal1

Stores the value captured from the submodule counter when the PWM_X circuitry 1 logic capture occurs.

enumerator kPWM_InpCaptureVal2

Stores the value captured from the submodule counter when the PWM_A circuitry 0 logic capture occurs.

enumerator kPWM_InpCaptureVal3

Stores the value captured from the submodule counter when the PWM_A circuitry 1 logic capture occurs.

enumerator kPWM_InpCaptureVal4

Stores the value captured from the submodule counter when the PWM_B circuitry 0 logic capture occurs.

enumerator kPWM_InpCaptureVal5

Stores the value captured from the submodule counter when the PWM_B circuitry 1 logic capture occurs.

enum _pwm_sm_input_capture_filter_count

The enumeration for input filter count Represent the number of consecutive samples that must agree prior to the input filter accepting an input transition.

Values:

enumerator kPWM_InputCaptureFilterCount3Samples

3 samples.

enumerator kPWM__InputCaptureFilterCount4Samples
4 samples.

enumerator kPWM__InputCaptureFilterCount5Samples
5 samples.

enumerator kPWM__InputCaptureFilterCount6Samples
6 samples.

enumerator kPWM__InputCaptureFilterCount7Samples
7 samples.

enumerator kPWM__InputCaptureFilterCount8Samples
8 samples.

enumerator kPWM__InputCaptureFilterCount9Samples
9 samples.

enumerator kPWM__InputCaptureFilterCount10Samples
10 samples.

enum __pwm_sm_capture_dma_source

The enumeration for the source which can trigger the DMA read requests for the capture FIFOs.

Values:

enumerator kPWM__FIFOWatermarksORDma
Selected FIFO watermarks are OR'ed together to sets the read DMA request.

enumerator kPWM__FIFOWatermarksANDDma
Selected FIFO watermarks are AND'ed together to sets the read DMA request.

enumerator kPWM__LocalSyncDma
A local sync (VAL1 match event) sets the read DMA request.

enumerator kPWM__LocalReloadDma
A local reload (STS[RF] being set) sets the read DMA request.

enum __pwm_sm_interrupt_enable

The enumeration for PWM submodule interrupt enable.

Values:

enumerator kPWM__CompareVal0InterruptEnable
PWM submodule VAL0 compare interrupt.

enumerator kPWM__CompareVal1InterruptEnable
PWM submodule VAL1 compare interrupt.

enumerator kPWM__CompareVal2InterruptEnable
PWM submodule VAL2 compare interrupt.

enumerator kPWM__CompareVal3InterruptEnable
PWM submodule VAL3 compare interrupt.

enumerator kPWM__CompareVal4InterruptEnable
PWM submodule VAL4 compare interrupt.

enumerator kPWM__CompareVal5InterruptEnable
PWM submodule VAL5 compare interrupt.

enumerator kPWM__CaptureX0InterruptEnable
PWM submodule capture X0 interrupt.

enumerator kPWM__CaptureX1InterruptEnable
PWM submodule capture X1 interrupt.

enumerator kPWM__CaptureB0InterruptEnable
PWM submodule capture B0 interrupt.

enumerator kPWM__CaptureB1InterruptEnable
PWM submodule capture B1 interrupt.

enumerator kPWM__CaptureA0InterruptEnable
PWM submodule capture A0 interrupt.

enumerator kPWM__CaptureA1InterruptEnable
PWM submodule capture A1 interrupt.

enumerator kPWM__ReloadInterruptEnable
PWM submodule reload interrupt.

enumerator kPWM__ReloadErrorInterruptEnable
PWM submodule reload error interrupt.

enumerator kPWM__ALLSubModuleInterruptEnable

enum __pwm_sm_status_flags

The enumeration for PWM submodule status flags.

Values:

enumerator kPWM__CompareVal0Flag
PWM submodule VAL0 compare flag.

enumerator kPWM__CompareVal1Flag
PWM submodule VAL1 compare flag.

enumerator kPWM__CompareVal2Flag
PWM submodule VAL2 compare flag.

enumerator kPWM__CompareVal3Flag
PWM submodule VAL3 compare flag.

enumerator kPWM__CompareVal4Flag
PWM submodule VAL4 compare flag.

enumerator kPWM__CompareVal5Flag
PWM submodule VAL5 compare flag.

enumerator kPWM__CaptureX0Flag
PWM submodule capture X0 flag.

enumerator kPWM__CaptureX1Flag
PWM submodule capture X1 flag.

enumerator kPWM__CaptureB0Flag
PWM submodule capture B0 flag.

enumerator kPWM__CaptureB1Flag
PWM submodule capture B1 flag.

enumerator kPWM__CaptureA0Flag
PWM submodule capture A0 flag.

enumerator kPWM__CaptureA1Flag
PWM submodule capture A1 flag.

enumerator kPWM_ReloadFlag

PWM submodule reload flag.

enumerator kPWM_ReloadErrorFlag

PWM submodule reload error flag.

enumerator kPWM_RegUpdatedFlag

PWM submodule registers updated flag.

enumerator kPWM_ALLSMStatusFlags

enum _pwm_sm_typical_output_mode

The enumeration for some PWM submodule PWM_A/B typical output mode.

Values:

enumerator kPWM_SignedCenterAligned

Center-aligned PWM with signed compare value.

enumerator kPWM_CenterAligned

Center-aligned PWM with unsigned compare value.

enumerator kPWM_SignedEdgeAligned

Edge-aligned PWM with signed compare value.

enumerator kPWM_EdgeAligned

Edge-aligned PWM with signed compare value.

enum _pwm_fault_protection_channel

The enumeration for PWM fault protection channel number.

Values:

enumerator kPWM_FaultProtection0

PWM fault protection channel 0

enum _pwm_fault_protection_interrupt_enable

The enumeration for PWM module fault protection channel interrupt enable.

Values:

enumerator kPWM_Fault0InterruptEnable

Fault protection channel fault 0 interrupt

enumerator kPWM_Fault1InterruptEnable

Fault protection channel fault 1 interrupt

enumerator kPWM_Fault2InterruptEnable

Fault protection channel fault 2 interrupt

enumerator kPWM_Fault3InterruptEnable

Fault protection channel fault 3 interrupt

enumerator kPWM_ALLfaultInterruptEnable

enum _pwm_fault_protection_status_flags

The enumeration for PWM module fault protection status flags.

Values:

enumerator kPWM_Fault0Flag

Fault protection channel fault 0 flag, set within two CPU cycles after a transition to active on the fault input pin 0.

enumerator kPWM_Fault1Flag

Fault protection channel fault 1 flag, set within two CPU cycles after a transition to active on the fault input pin 1.

enumerator kPWM_Fault2Flag

Fault protection channel fault 2 flag, set within two CPU cycles after a transition to active on the fault input pin 2.

enumerator kPWM_Fault3Flag

Fault protection channel fault 3 flag, set within two CPU cycles after a transition to active on the fault input pin 3.

enumerator kPWM_FaultPin0ActiveFlag

Fault protection channel fault input pin 0 active flag.

enumerator kPWM_FaultPin1ActiveFlag

Fault protection channel fault input pin 1 active flag.

enumerator kPWM_FaultPin2ActiveFlag

Fault protection channel fault input pin 2 active flag.

enumerator kPWM_FaultPin3ActiveFlag

Fault protection channel fault input pin 3 active flag.

enumerator kPWM_ALLFaultStatusFlags

enum _pwm_fault_active_level

The enumeration for PWM fault protection channel number.

Values:

enumerator kPWM_Logic0

A logic 0 on the fault input indicates a fault condition.

enumerator kPWM_Logic1

A logic 0 on the fault input indicates a fault condition.

typedef enum _pwm_sm_number pwm_sm_number_t

The enumeration for PWM submodule number.

typedef enum _pwm_sm_count_clock_source pwm_sm_count_clock_source_t

The enumeration for PWM submodule clock source.

typedef enum _pwm_sm_count_clock_prescaler pwm_sm_count_clock_prescaler_t

The enumeration for PWM submodule prescaler factor selection for clock source.

typedef enum _pwm_sm_count_init_source pwm_sm_count_init_source_t

The enumeration for PWM submodule counter initialization options.

typedef enum _pwm_ml2_stretch_count_clock_prescaler

pwm_ml2_stretch_count_clock_prescaler_t

The enumeration for PWM stretch IPBus clock count prescaler for mux0_trig/mux1_trig/out0_trig/out1_trig/pwma_trig/pwmb_trig.

typedef struct _pwm_sm_counter_config pwm_sm_counter_config_t

The structure for configuring PWM submodule counter logic.

typedef enum _pwm_sm_reload_signal_select pwm_sm_reload_signal_select_t

The enumeration for PWM submodule local reload take effect timing.

typedef enum _pwm_sm_local_reload_effect_timing pwm_sm_local_reload_effect_timing_t

The enumeration for PWM submodule local reload take effect timing.

`typedef enum _pwm_sm_local_reload_opportunity` `pwm_sm_local_reload_opportunity_t`
The enumeration for PWM submodule reload opportunities selection under `kPWM_ReloadWithLocalReloadOpportunity`.

`typedef struct _pwm_sm_reload_logic_config` `pwm_sm_reload_logic_config_t`
The structure for configuring PWM submodule reload logic.

`typedef enum _pwm_sm_val_compare_mode` `pwm_sm_val_compare_mode_t`
The enumeration for PWM submodule VALn register compare mode.

`typedef enum _pwm_sm_val_register` `pwm_sm_val_register_t`
The enumeration for PWM submodule VAL registers.

`typedef struct _pwm_sm_value_register_config` `pwm_sm_value_register_config_t`
The structure for configuring PWM submodule value registers.

`typedef enum _pwm_sm_force_signal_select` `pwm_sm_force_signal_select_t`
The enumeration for PWM submodule FORCE_OUT source which can trigger force logic output update.

`typedef enum _pwm_sm_force_deadtime_source` `pwm_sm_force_deadtime_source_t`
The enumeration for PWM submodule force out logic output (PWM23 and PWM45) source, which will transfer to output logic when a FORCE_OUT signal is asserted.

`typedef enum _pwm_sm_force_software_output_value` `pwm_sm_force_software_output_value_t`
The enumeration for PWM submodule software controlled force out signal value.

`typedef struct _pwm_sm_force_logic_config` `pwm_sm_force_logic_config_t`
The structure for configuring PWM submodule force logic.

`typedef enum _pwm_sm_deadtime_logic_mode` `pwm_sm_deadtime_logic_mode_t`
The enumeration for PWM submodule deadtime logic mode, which decide how the dead-time logic process the force logic output signal.

`typedef struct _pwm_sm_deadtime_value` `pwm_sm_deadtime_value_t`
The structure of the inserted dead time value, applies only to `KPWM_Complementaryxxx` mode.

`typedef struct _pwm_sm_deadtime_logic_config` `pwm_sm_deadtime_logic_config_t`
The structure for configuring PWM submodule force out logic, works on the deadtime logic output.

`typedef enum _pwm_sm_fracval_register` `pwm_sm_fracval_register_t`
The enumeration for PWM submodule FRACVAL registers.

`typedef struct _pwm_sm_fractional_delay_logic_config` `pwm_sm_fractional_delay_logic_config_t`
The structure for configuring PWM submodule fractional delay logic, works on the dead-time logic output.

`typedef enum _pwm_sm_mux_trigger_source` `pwm_sm_mux_trigger_source_t`
The enumeration for PWM submodule output logic final trigger output port signal.

`typedef enum _pwm_sm_pwm_output_on_fault` `pwm_sm_pwm_output_on_fault_t`
The enumeration for PWM submodule output logic PWM output fault status.

`typedef enum _pwm_sm_pwm_x_signal_select` `pwm_sm_pwm_x_signal_select_t`
The enumeration for PWM submodule output logic PwmX signal input source (before output polarity/mask/enable control).

`typedef enum _pwm_sm_pwm_out` `pwm_sm_pwm_out_t`
The enumeration for PWM submodule PWM output.

`typedef struct _pwm_sm_output_logic_config_t pwm_sm_output_logic_config_t`

The structure for configuring PWM submodule output logic.

`typedef enum _pwm_sm_input_capture_pin pwm_sm_input_capture_pin_t`

The enumeration for PWM submodule input capture pins.

`typedef enum _pwm_sm_input_capture_source pwm_sm_input_capture_source_t`

The enumeration for PWM submodule input capture source.

`typedef enum _pwm_sm_input_capture_edge pwm_sm_input_capture_edge_t`

The enumeration for PWM submodule input capture edge when choose raw input as capture source.

`typedef enum _pwm_sm_input_capture_register pwm_sm_input_capture_register_t`

The enumeration for PWM submodule input capture value register.

`typedef enum _pwm_sm_input_capture_filter_count pwm_sm_input_capture_filter_count_t`

The enumeration for input filter count Represent the number of consecutive samples that must agree prior to the input filter accepting an input transition.

`typedef struct _pwm_sm_input_capture_config pwm_sm_input_capture_config_t`

The structure for configuring PWM submodule input capture logic.

Note: When choosing kPWM_InputEdgeCounter as circuit 0/1 capture source, the eCircuit0CaptureEdge and eCircuit1CaptureEdge selected trigger edge will be ignored, but still need place a value other than kPWM_Noedge in either or both of the eCaptureCircuit0 and/or CaptureCircuit1 fields in order to enable one or both of the capture registers.

`typedef enum _pwm_sm_capture_dma_source pwm_sm_capture_dma_source_t`

The enumeration for the source which can trigger the DMA read requests for the capture FIFOs.

`typedef struct _pwm_sm_capture_dma_config pwm_sm_capture_dma_config_t`

The structure for configuring PWM submodule read capture DMA.

`typedef struct _pwm_sm_dma_config pwm_sm_dma_config_t`

The structure for configuring PWM submodule DMA.

`typedef struct _pwm_sm_fault_input_mapping pwm_sm_fault_input_mapping_t`

The enumeration for PWM submodule output fault enable mask for one fault protection channel.

The structure for configuring PWM submodule fault input disable mapping.

Note: The channel 0 input 0 and channel 1 input 0 are different pins.

Note: Each PWM output can be mapping anyone or more fault inputs. The mapped fault protection channel inputs can disable PWM output.

`typedef enum _pwm_sm_status_flags pwm_sm_status_flags_t`

The enumeration for PWM submodule status flags.

`typedef enum _pwm_sm_typical_output_mode pwm_sm_typical_output_mode_t`

The enumeration for some PWM submodule PWM_A/B typical output mode.

```
typedef struct _pwm_sm_config pwm_sm_config_t
```

PWM submodule config structure.

This structure holds the configuration settings for the PWM peripheral. To initialize this structure to reasonable defaults, call the PWM_GetDefaultConfig() function and pass a pointer to your config structure instance.

```
typedef enum _pwm_fault_protection_channel pwm_fault_protection_channel_t
```

The enumeration for PWM fault protection channel number.

```
typedef enum _pwm_fault_active_level pwm_fault_input_active_level_t
```

The enumeration for PWM fault protection channel number.

```
typedef struct _pwm_fault_protection_input_config pwm_fault_protection_input_config_t
```

```
typedef struct _pwm_fault_protection_config pwm_fault_protection_config_t
```

The structure for configuring PWM fault protection channel, a PWM module can have multiple fault protection channels, PWM sub-module can choose to mapping any one or more fault input from fault protection channels.

```
typedef struct _pwm_config pwm_config_t
```

PWM module config structure which contain submodule config structure pointers and fault protection filter config structure pointers.

Note: Need use submodule structure address to init the structure pointers, when the submodule or fault protection structure pointers is NULL, it will be ignored by PWM_Init API. This can save stack space when only one or two submodules are used.

```
struct _pwm_sm_counter_config
```

#include <fsl_pwm.h> The structure for configuring PWM submodule counter logic.

Public Members

pwm_sm_count_clock_source_t eCountClockSource

Configures PWM submodule counter clock source.

pwm_sm_count_clock_prescaler_t eCountClockPrescaler

Configures PWM submodule counter clock source prescaler.

pwm_sm_count_init_source_t eCountInitSource

Configures PWM submodule counter initial source.

bool bEnableForceInitial

Enable force-controlled initialization. The assert FORCE_OUT signal can to initialize the counter without regard to the selected initial source.

uint16_t u16PhaseDelayValue

Defines the delay from the master sync signal of submodule 0 to this submodule counter (the unit of delay is the PWM clock cycle), only works when chose kPWM_InitOnMasterSync as initial source.

```
struct _pwm_sm_reload_logic_config
```

#include <fsl_pwm.h> The structure for configuring PWM submodule reload logic.

Public Members

pwm_sm_reload_signal_select_t eReloadSignalSelect

Configures PWM submodule RELOAD signal source to be local reload signal or master reload signal.

pwm_sm_local_reload_effect_timing_t eLoclReloadEffectTime

Configures PWM submodule local reload signal effective timing when choose it as RELOAD signal source.

bool bEnableFullCycleReloadOportunity

Enable generate a reload opportunity on PWM half cycle (count from INIT value to VAL0).

bool bEnableHalfCycleReloadOportunity

Enable generate a reload opportunity on PWM full cycle (count from INIT value to VAL1).

pwm_sm_local_reload_oportunity_t eLocalReloadOportunity

Configures PWM submodule reload frequency when using local reload opportunities mode .

struct __pwm_sm_value_register_config

#include <fsl_pwm.h> The structure for configuring PWM submodule value registers.

Public Members

uint16_t u16CounterInitialValue

Configures PWM submodule counter initial value.

uint16_t u16ValRegister0

Configures PWM submodule value register 0 (VAL0) value.

uint16_t u16ValRegister1

Configures PWM submodule value register 1 (VAL1) value.

uint16_t u16ValRegister2

Configures PWM submodule value register 2 (VAL2) value.

uint16_t u16ValRegister3

Configures PWM submodule value register 3 (VAL3) value.

uint16_t u16ValRegister4

Configures PWM submodule value register 4 (VAL4) value.

uint16_t u16ValRegister5

Configures PWM submodule value register 5 (VAL5) value.

struct __pwm_sm_force_logic_config

#include <fsl_pwm.h> The structure for configuring PWM submodule force logic.

Public Members

uint8_t bitPWM23OutputInitialVaule

Configures PWM submodule compare output x (PwmX) initial value.

uint8_t bitPWM45OutputInitialVaule

Configures PWM submodule compare output A (PwmA) initial value.

uint8_t bitPWMXOutputInitialVaule

Configures PWM submodule compare output B (PwmB) initial value.

pwm_sm_force_signal_select_t eForceSignalSelect

Configures PWM submodule force out select update trigger source.

pwm_sm_force_software_output_value_t eSoftOutputFor23

Configures PWM submodule force out PwmA value when select software as output source.

pwm_sm_force_software_output_value_t eSoftOutputFor45

Configures PWM submodule force out PwmB value when select software as output source.

pwm_sm_force_deadtime_source_t eForceOutput23

Configures the source of Pwm23, which will be force to deadtime logic.

pwm_sm_force_deadtime_source_t eForceOutput45

Configures the source of Pwm45, which will be force to deadtime logic.

struct *_pwm_sm_deadtime_value*

#include <fsl_pwm.h> The structure of the inserted dead time value, applies only to KPWM_Complementaryxxx mode.

struct *_pwm_sm_deadtime_logic_config*

#include <fsl_pwm.h> The structure for configuring PWM submodule force out logic, works on the deadtime logic output.

Public Members

pwm_sm_deadtime_logic_mode_t eMode

The mode in which Deadtime logic process the force logic output signal.

pwm_sm_deadtime_value_t sDeadTimeValue0

Control the deadtime during 0 to 1 transitions of the PWM_23 output (assuming normal polarity). When disable fractional delays, the maximum value is 0x7FF which represents 2047 cycles of IP bus cycles. When enable fractional delays, the maximum value is 0xFFFF which represents 2047 31/32 cycles cycles of IP bus cycles.

pwm_sm_deadtime_value_t sDeadTimeValue1

Control the deadtime during 0 to 1 transitions of the PWM_45 output (assuming normal polarity). When disable fractional delays, the maximum value is 0x7FF which represents 2047 cycles of IP bus cycles. When enable fractional delays, the maximum value is 0xFFFF which represents 2047 31/32 cycles cycles of IP bus cycles.

struct *_pwm_sm_fractional_delay_logic_config*

#include <fsl_pwm.h> The structure for configuring PWM submodule fractional delay logic, works on the deadtime logic output.

Public Members

uint8_t bitsFracValue1

Configures PWM submodule compare register VAL1 fractional delay value, the unit is 1/32 IP bus clock.

bool bEnableVal1FractionalDelay

Enable the fractional delay feature of bitsFracValue1.

uint8_t bitsFracValue2

Configures PWM submodule compare register VAL2 fractional delay value, the unit is 1/32 IP bus clock.

uint8_t bitsFracValue3

Configures PWM submodule compare register VAL3 fractional delay value, the unit is 1/32 IP bus clock.

bool bEnableVal23FractionalDelay

Enable the fractional delay feature of bitsFracValue2 and bitsFracValue3.

uint8_t bitsFracValue4

Configures PWM submodule compare register VAL4 fractional delay value, the unit is 1/32 IP bus clock.

uint8_t bitsFracValue5

Configures PWM submodule compare register VAL5 fractional delay value, the unit is 1/32 IP bus clock.

bool bEnableVal45FractionalDelay

Enable the fractional delay feature of bitsFracValue4 and bitsFracValue5.

struct _pwm_sm_output_logic_config_t

#include <fsl_pwm.h> The structure for configuring PWM submodule output logic.

Public Members

bool bVal0TriggerEnable

Enable VAL0 register compare event trigger.

bool bVal1TriggerEnable

Enable VAL1 register compare event trigger.

bool bVal2TriggerEnable

Enable VAL2 register compare event trigger.

bool bVal3TriggerEnable

Enable VAL3 register compare event trigger.

bool bVal4TriggerEnable

Enable VAL4 register compare event trigger.

bool bVal5TriggerEnable

Enable VAL5 register compare event trigger.

bool bEnableTriggerPostScaler

True : Trigger outputs are generated only during the final PWM period prior to a reload opportunity, false : Trigger outputs are generated during every PWM period. Configures PWM submodule mux trigger output signal 0 source.

pwm_sm_mux_trigger_source_t eMuxTrigger0

Configures PWM submodule mux trigger output signal 1 source.

pwm_sm_mux_trigger_source_t eMuxTrigger1

Configures PWM submodule PWM_X output source (before polarity/mask/enable control).

bool bInvertPwmXOutput

True : invert PWM_X output, false : no invert PWM_X output.

bool bInvertPwmaOutput

True : invert PWM_A output, false : no invert PWM_A output.

bool bInvertPwmbOutput

True : invert PWM_B output, false : no invert PWM_B output.

bool bMaskPwmXOutput

True : PWM_X output masked, false : PWM_X output normal. Mask bit is buffered, and take effect until FORCE_OUT event or software update command.

bool bMaskPwmaOutput

True : PWM_A output masked, false : PWM_A output normal. Mask bit is buffered, and take effect until FORCE_OUT event or software update command.

bool bMaskPwmbOutput

True : PWM_B output masked, false : PWM_B output normal. Mask bit is buffered, and take effect until FORCE_OUT event or software update command.

bool bEnablePwmXOutput

True : Enable PWM_X output. false : PWM_X is disabled and output is tristated.

bool bEnablePwmaOutput

True : Enable PWM_A output. false : PWM_A is disabled and output is tristated.

bool bEnablePwmbOutput

True : Enable PWM_B output. false : PWM_B is disabled and output is tristated. Configures PWM submodule PWM_X output during fault status (only works when fault status enable).

pwm_sm_pwm_output_on_fault_t ePwmXFaultState

Configures PWM submodule PWM_A output during fault status (only works when fault status enable).

pwm_sm_pwm_output_on_fault_t ePwmaFaultState

Configures PWM submodule PWM_B output during fault status (only works when fault status enable).

struct __pwm_sm_input_capture_config

#include <fsl_pwm.h> The structure for configuring PWM submodule input capture logic.

Note: When choosing kPWM_InputEdgeCounter as circuit 0/1 capture source, the eCircuit0CaptureEdge and eCircuit1CaptureEdge selected trigger edge will be ignored, but still need place a value other than kPWM_Noedge in either or both of the eCaptureCircuit0 and/or CaptureCircuit1 fields in order to enable one or both of the capture registers.

Public Members

bool bEnableInputCapture

True: enable the input capture process, false : disable the input capture process.

pwm_sm_input_capture_source_t eInCaptureSource

Configures capture circuit 0/1 input source

pwm_sm_input_capture_edge_t eCircuit0CaptureEdge

Configures which edge causes a capture for capture circuit 0 , will be ignore when use edge counter as capture source.

pwm_sm_input_capture_edge_t eCircuit1CaptureEdge

Configures which edge causes a capture for capture circuit 1 , will be ignore when use edge counter as capture source.

bool bEnableOneShotCapture

True: Enable one-shot capture mode, the bEnableInputCapture will self-cleared when one or more of the enabled capture circuits has had a capture event; false: Capture circuit 0/1 will perform capture continue;

uint8_t bitsCaptureFifoWatermark

Watermark level for circuit 0/1 capture FIFO. The capture flags in the status register will set if the word count in the circuit 0/1 capture FIFO is greater than this watermark level

uint8_t u8EdgeCounterCompareValue

Edge counter compare value, used only if edge counter is used as capture circuit 0/1 input source

uint8_t u8FilterPeriod

Sampling period (in IPBus clock cycles) of the input filter, set to 0 to bypass the filter.

pwm_sm_input_capture_filter_count_t eFilterCount

Filter sample count.

struct *_pwm_sm_capture_dma_config*

#include <fsl_pwm.h> The structure for configuring PWM submodule read capture DMA.

Public Members

bool bEnableCaptureDMA

Enables DMA read requests for the Capture FIFOs.

pwm_sm_capture_dma_source_t eCaptureDMASource

Select the source to enables DMA read requests for the Capture FIFOs. Will be ignored when bEnableCaptureDMA be false.

struct *_pwm_sm_dma_config*

#include <fsl_pwm.h> The structure for configuring PWM submodule DMA.

Public Members

bool bEnableWriteValDMA

STS[RF] set enables DMA write requests for VALx and FRACVALx registers.

bool bEnableReadCaptureX0DMA

STS[CFX0] set enables DMA read requests for Capture X0 FIFO. And X0 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

bool bEnableReadCaptureX1DMA

STS[CFX1] set enables DMA read requests for Capture X1 FIFO. And X1 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

bool bEnableReadCaptureA0DMA

STS[CFA0] set enables DMA read requests for Capture A0 FIFO. And A0 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

bool bEnableReadCaptureA1DMA

STS[CFA1] set enables DMA read requests for Capture A1 FIFO. And A1 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

bool bEnableReadCaptureB0DMA

STS[CFB0] set enables DMA read requests for Capture B0 FIFO. And B0 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

bool bEnableReadCaptureB1DMA

STS[CFB1] set enables DMA read requests for Capture B1 FIFO. And B1 FIFO watermark is selected for sCaptureDma *pwm_sm_capture_dma_config_t*.

pwm_sm_capture_dma_config_t sCaptureDma

DMA read requests for the capture FIFOs configure.

struct *_pwm_sm_fault_input_mapping*

#include <fsl_pwm.h> The enumeration for PWM submodule output fault enable mask for one fault protection channel.

The structure for configuring PWM submodule fault input disable mapping.

Note: The channel 0 input 0 and channel 1 input 0 are different pins.

Note: Each PWM output can be mapping anyone or more fault inputs. The mapped fault protection channel inputs can disable PWM output.

Public Members

bool bFaultInput0Mapping

Mapping fault input 0 (from fault protection channel 0) to PWM output.

bool bFaultInput1Mapping

Mapping fault input 1 (from fault protection channel 0) to PWM output.

bool bFaultInput2Mapping

Mapping fault input 2 (from fault protection channel 0) to PWM output.

bool bFaultInput3Mapping

Mapping fault input 3 (from fault protection channel 0) to PWM output.

bool bFaultInput4Mapping

Mapping fault input 4 (from fault protection channel 1) to PWM output.

bool bFaultInput5Mapping

Mapping fault input 5 (from fault protection channel 1) to PWM output.

bool bFaultInput6Mapping

Mapping fault input 6 (from fault protection channel 1) to PWM output.

bool bFaultInput7Mapping

Mapping fault input 7 (from fault protection channel 1) to PWM output.

struct *_pwm_sm_config*

#include <fsl_pwm.h> PWM submodule config structure.

This structure holds the configuration settings for the PWM peripheral. To initialize this structure to reasonable defaults, call the *PWM_GetDefaultConfig()* function and pass a pointer to your config structure instance.

Public Members

bool enableDebugMode

true: PWM continues to run in debug mode; false: PWM is paused in debug mode.

bool enableWaitMode

true: PWM continues to run in WAIT mode; false: PWM is paused in WAIT mode.

`bool enableRun`

true: PWM submodule is enabled; false: PWM submodule is disabled. Configures submodule value registers compare mode, only can be written one time.

`pwm_sm_counter_config_t sCounterConfig`

Submodule counter logic config.

`pwm_sm_reload_logic_config_t sReloadConfig`

Submodule reload control logic config.

`pwm_sm_value_register_config_t sValRegisterConfig`

Submodule value registers config.

`pwm_sm_force_logic_config_t sForceConfig`

Submodule force out logic config.

`pwm_sm_deadtime_logic_config_t sDeadTimeConfig`

Submodule deadtime logic config.

`pwm_sm_fractional_delay_logic_config_t sFracDelayConfig`

Submodule fractional logic config.

`pwm_sm_output_logic_config_t sOutputConfig`

Submodule output logic config.

`pwm_sm_input_capture_config_t sInCaptureConfig[3]`

Submodule input capture config for PWM_X/A/B pins.

`pwm_sm_dma_config_t sDMAConfig`

Submodule DMA config. PWM_X output fault input mapping, determines which fault inputs can disable PWM_X output.

`pwm_sm_fault_input_mapping_t sPwmXFaultInputMapping`

PWM_A output fault input mapping, determines which fault inputs can disable PWM_A output.

`pwm_sm_fault_input_mapping_t sPwmAFaultInputMapping`

PWM_B output fault input mapping, determines which fault inputs can disable PWM_B output.

`pwm_sm_fault_input_mapping_t sPwmBFaultInputMapping`

Submodule interrupt enable mask, logic OR of `_pwm_sm_interrupt_enable`.

`pwm_ml2_stretch_count_clock_prescaler_t eStrBusClock`

PWM stretch IPBus clock count prescaler.

`struct _pwm_fault_protection_input_config`

`#include <fsl_pwm.h>`

Public Members

`pwm_fault_input_active_level_t eFaultActiveLevel`

Select the active logic level of the fault input.

`bool bEnableAutoFaultClear`

True : Enable automatic fault clearing, fault recovery (PWM outputs can re-enable) occurs when FSTS[FFPINx] is clear , false : Use manual fault clearing, fault recovery (PWM outputs can re-enable) occurs when FSTS[FFLAGx] is manual clear (and FSTS[FFPINx] is clear).

bool bEnableManualFaultClearSafeMode

True : fault recovery (PWM outputs can re-enable) occurs when FSTS[FFLAGx] is manual clear and FSTS[FFPINx] is clear, false : fault recovery (PWM outputs can re-enable) occurs when FSTS[FFLAGx] is manual clear.

bool bEnableFaultFullCycleRecovery

Enable full cycle fault recovery, which make PWM outputs are re-enabled at the start of a half cycle after fault recovery occurs.

bool bEnableFaultHalfCycleRecovery

Enable half cycle fault recovery, which make PWM outputs are re-enabled at the start of a half cycle after fault recovery occurs.

bool bEnableFaultNoCombinationalPath

True : The fault inputs are combined with the filtered and latched fault signals to disable the PWM outputs, false : the filtered and latched fault signals are used to disable the PWM outputs.

bool bEnableFaultInterrupt

Enable the fault input interrupt.

struct __pwm_fault_protection_config

#include <fsl_pwm.h> The structure for configuring PWM fault protection channel, a PWM module can have multiple fault protection channels, PWM sub-module can choose to maping any one or more fault input from fault protection channels.

Public Members

bool bEnableFaultGlitchStretch

Fault Glitch Stretch Enable: A logic 1 means that input fault signals will be stretched to at least 2 IPBus clock cycles.

uint8_t bitsFaultFilterCount

Configures PWM fault protection channel fault filter count.

uint8_t u8FaultFilterPeriod

Configures PWM fault protection channel fault filter period, value of 0 will bypass the filter.

struct __pwm_config

#include <fsl_pwm.h> PWM module config structure which contain submodule config structure pointers and fault protection filter config structure pointers.

Note: Need use submodule structure address to init the structure pointers, when the submodule or fault protection structure pointers is NULL, it will be ignored by PWM_Init API. This can save stack space when only one or two submodules are used.

Public Members

pwm_sm_config_t *psPwmSubmoduleConfig[1]

< PWM submodule config. PWM fault protection channel config, will take effect for all submodules.

2.64 The Driver Change Log

2.65 eFlexPWM Peripheral and Driver Overview

2.66 QDC: Quadrature Decoder Driver

`void QDC_Init(QDC_Type *base, const qdc_config_t *psConfig)`

Initializes the QDC module.

This function initializes the QDC by:

- a. Enable the IP bus clock (optional).
- b. Configure module based on the configuration structure.

Parameters

- `base` – QDC peripheral base address.
- `psConfig` – Pointer to configuration structure.

`void QDC_GetDefaultConfig(qdc_config_t *psConfig)`

Gets an available pre-defined configuration.

The default value are:

```
psConfig->bEnableReverseDirection      = false;
psConfig->eDecoderWorkMode              = kQDC_DecoderQuadratureMode;
psConfig->eHomeInitPosCounterMode      = kQDC_HomeInitPosCounterDisabled;
psConfig->eIndexInitPosCounterMode     = kQDC_IndexInitPosCounterDisabled;
psConfig->bEnableTriggerInitPositionCounter = false;
psConfig->bEnableTriggerClearPositionRegisters = false;
psConfig->bEnableTriggerHoldPositionRegisters = false;
psConfig->bEnableWatchdog                = false;
psConfig->u16WatchdogTimeoutValue       = 0xFFFFU;
psConfig->eFilterSampleCount            = kQDC_Filter3Samples;
psConfig->u8FilterSamplePeriod          = 0U;
psConfig->eOutputPulseMode              = kQDC_OutputPulseOnCounterEqualCompare;
psConfig->u32PositionCompareValue       = 0xFFFFFFFFU;
psConfig->u32PositionCompare1Value      = 0xFFFFFFFFU;
psConfig->eRevolutionCountCondition     = kQDC_RevolutionCountOnIndexPulse;
psConfig->bEnableModuloCountMode         = false;
psConfig->u32PositionModulusValue       = 0U;
psConfig->u32PositionInitialValue       = 0U;
psConfig->u32PositionCounterValue       = 0U;
psConfig->bEnablePeriodMeasurement       = false;
psConfig->ePrescaler                    = kQDC_Prescaler1;
psConfig->u16EnabledInterruptsMask      = 0U;
```

Parameters

- `psConfig` – Pointer to configuration structure.

`void QDC_Deinit(QDC_Type *base)`

De-initializes the QDC module.

This function deinitializes the QDC by:

- a. Disables the IP bus clock (optional).

Parameters

- base – QDC peripheral base address.

static inline void QDC_EnableWatchdog(QDC_Type *base, bool bEnable)

Enable watchdog for QDC module.

Parameters

- base – QDC peripheral base address
- bEnable – Enables or disables the watchdog

static inline void QDC_SetWatchdogTimeout(QDC_Type *base, uint16_t u16Timeout)

Set watchdog timeout value.

Parameters

- base – QDC peripheral base address
- u16Timeout – Number of clock cycles, plus one clock cycle that the watchdog timer counts before timing out

static inline uint16_t QDC_GetStatusFlags(QDC_Type *base)

Get the status flags.

Parameters

- base – QDC peripheral base address.

Returns

Logical OR'ed value of the status flags, `_qdc_status_flags`.

static inline void QDC_ClearStatusFlags(QDC_Type *base, uint16_t u16Flags)

Clear the status flags.

Parameters

- base – QDC peripheral base address.
- u16Flags – Logical OR'ed value of the flags to clear, `_qdc_status_flags`.

static inline uint16_t QDC_GetSignalStatusFlags(QDC_Type *base)

Get the signals' real-time status.

Parameters

- base – QDC peripheral base address.

Returns

Logical OR'ed value of the real-time signal status, `_qdc_signal_status`.

static inline *qdc_count_direction_flag_t* QDC_GetLastCountDirection(QDC_Type *base)

Get the direction of the last count.

Parameters

- base – QDC peripheral base address.

Returns

Direction of the last count.

static inline void QDC_EnableInterrupts(QDC_Type *base, uint16_t u16Interrupts)

Enable the interrupts.

Parameters

- base – QDC peripheral base address.
- u16Interrupts – Logical OR'ed value of the interrupts, `_qdc_interrupt_enable`.

```
static inline void QDC_DisableInterrupts(QDC_Type *base, uint16_t u16Interrupts)
```

Disable the interrupts.

Parameters

- base – QDC peripheral base address.
- u16Interrupts – Logical OR'ed value of the interrupts, `_qdc_interrupt_enable`.

```
static inline void QDC_DoSoftwareLoadInitialPositionValue(QDC_Type *base)
```

Load the initial position value to position counter.

Software trigger to load the initial position value (UNIT and LINIT) contents to position counter (UPOS and LPOS), so that to provide the consistent operation the position counter registers.

Parameters

- base – QDC peripheral base address.

```
static inline void QDC_SetInitialPositionValue(QDC_Type *base, uint32_t u32PositionInitValue)
```

Set initial position value for QDC module.

Set the position counter initial value (INIT or UNIT, LINIT).

Parameters

- base – QDC peripheral base address
- u32PositionInitValue – Position initial value

```
static inline void QDC_SetPositionCounterValue(QDC_Type *base, uint32_t  
                                              u32PositionCounterValue)
```

Set position counter value.

Set the position counter value (POS or UPOS, LPOS).

Parameters

- base – QDC peripheral base address
- u32PositionCounterValue – Position counter value

```
static inline void QDC_SetPositionModulusValue(QDC_Type *base, uint32_t  
                                              u32PositionModulusValue)
```

Set position counter modulus value.

Set the position counter modulus value (MOD or UMOD, LMOD).

Parameters

- base – QDC peripheral base address
- u32PositionModulusValue – Position modulus value

```
static inline void QDC_SetPositionCompareValue(QDC_Type *base, uint32_t  
                                              u32PositionCompValue)
```

Set position counter compare value.

Set the position counter compare value (COMP or UCOMP, LCOMP).

Parameters

- base – QDC peripheral base address
- u32PositionCompValue – Position modulus value

```
static inline void QDC_SetPositionCompare1Value(QDC_Type *base, uint32_t
                                              u32PositionComp1Value)
```

Set position counter compare 1 value.

Set the position counter compare 1 value (COMP1 or UCOMP1, LCOMP1).

Parameters

- base – QDC peripheral base address
- u32PositionComp1Value – Position modulus value

```
static inline uint32_t QDC_GetPosition(QDC_Type *base)
```

Get the current position counter's value.

Parameters

- base – QDC peripheral base address.

Returns

Current position counter's value.

```
static inline uint32_t QDC_GetHoldPosition(QDC_Type *base)
```

Get the hold position counter's value.

The position counter (POS or UPOS, LPOS) value is loaded to hold position (POSH or UPOSH, LPOSH) when:

- a. Position register (POS or UPOS, LPOS), or position difference register (POSD), or revolution register (REV) is read.
- b. TRIGGER happens and TRIGGER is enabled to update the hold registers.

Parameters

- base – QDC peripheral base address.

Returns

Hold position counter's value.

```
static inline uint16_t QDC_GetPositionDifference(QDC_Type *base)
```

Get the position difference counter's value.

Parameters

- base – QDC peripheral base address.

Returns

The position difference counter's value.

```
static inline uint16_t QDC_GetHoldPositionDifference(QDC_Type *base)
```

Get the hold position difference counter's value.

The position difference (POSD) value is loaded to hold position difference (POSDH) when:

- a. Position register (POS or UPOS, LPOS), or position difference register (POSD), or revolution register (REV) is read. When Period Measurement is enabled (CTRL3[PMEN] = 1), POSDH will only be updated when reading POSD.
- b. TRIGGER happens and TRIGGER is enabled to update the hold registers.

Parameters

- base – QDC peripheral base address.

Returns

Hold position difference counter's value.

```
static inline uint16_t QDC_GetRevolution(QDC_Type *base)
```

Get the revolution counter's value.

Get the revolution counter (REV) value.

Parameters

- base – QDC peripheral base address.

Returns

The revolution counter's value.

```
static inline uint16_t QDC_GetHoldRevolution(QDC_Type *base)
```

Get the hold revolution counter's value.

The revolution counter (REV) value is loaded to hold revolution (REXH) when:

- a. Position register (POS or UPOS, LPOS), or position difference register (POSD), or revolution register (REV) is read.
- b. TRIGGER happens and TRIGGER is enabled to update the hold registers.

Parameters

- base – QDC peripheral base address.

Returns

Hold position revolution counter's value.

```
static inline uint16_t QDC_GetLastEdgeTime(QDC_Type *base)
```

Get the last edge time.

Last edge time (LASTEDGE) is the time since the last edge occurred on PHASEA or PHASEB. The last edge time register counts up using the peripheral clock after prescaler. Any edge on PHASEA or PHASEB will reset this register to 0 and start counting. If the last edge timer count reaches 0xffff, the counting will stop in order to prevent an overflow.

Parameters

- base – QDC peripheral base address.

Returns

The last edge time.

```
static inline uint16_t QDC_GetHoldLastEdgeTime(QDC_Type *base)
```

Get the hold last edge time.

The hold of last edge time(LASTEDGEH) is update to last edge time(LASTEDGE) when the position difference register register (POSD) is read.

Parameters

- base – QDC peripheral base address.

Returns

Hold of last edge time.

```
static inline uint16_t QDC_GetPositionDifferencePeriod(QDC_Type *base)
```

Get the Position Difference Period counter value.

The Position Difference Period counter (POSDPER) counts up using the prescaled peripheral clock. When reading the position difference register(POSD), the last edge time (LASTEDGE) will be loaded to position difference period counter(POSDPER). If the POSDPER count reaches 0xffff, the counting will stop in order to prevent an overflow. Counting will continue when an edge occurs on PHASEA or PHASEB.

Parameters

- base – QDC peripheral base address.

Returns

The position difference period counter value.

```
static inline uint16_t QDC_GetBufferedPositionDifferencePeriod(QDC_Type *base)
```

Get buffered Position Difference Period counter value.

The Bufferd Position Difference Period (POSDPERBFR) value is updated with the position difference period counter(POSDPER) when any edge occurs on PHASEA or PHASEB.

Parameters

- base – QDC peripheral base address.

Returns

The buffered position difference period counter value.

```
static inline uint16_t QDC_GetHoldPositionDifferencePeriod(QDC_Type *base)
```

Get Hold Position Difference Period counter value.

The hold position difference period(POSDPERH) is updated with the value of buffered position difference period(POSDPERBFR) when the position difference(POSD) register is read.

Parameters

- base – QDC peripheral base address.

Returns

The hold position difference period counter value.

```
FSL_QDC_DRIVER_VERSION
```

QDC driver version.

```
enum _qdc_status_flags
```

QDC status flags, these flags indicate the counter's events. .

Values:

```
enumerator kQDC_HomeTransitionFlag
```

HOME signal transition occurred.

```
enumerator kQDC_IndexPulseFlag
```

INDEX pulse occurred.

```
enumerator kQDC_WatchdogTimeoutFlag
```

Watchdog timeout occurred.

```
enumerator kQDC_PositionCompareFlag
```

Position counter match the COMP value.

```
enumerator kQDC_SimultPhaseChangeFlag
```

Simultaneous change of PHASEA and PHASEB occurred.

```
enumerator kQDC_PositionRollOverFlag
```

Position counter rolls over from 0xFFFFFFFF to 0, or from MOD value to INIT value.

```
enumerator kQDC_PositionRollUnderFlag
```

Position register roll under from 0 to 0xFFFFFFFF, or from INIT value to MOD value.

```
enumerator kQDC_PositionCompare1Flag
```

Position counter match the COMP1 value.

```
enumerator kQDC_StatusAllFlags
```

```
enum _qdc_signal_status
```

Signal status, these flags indicate the raw and filtered input signal status. .

Values:

enumerator kQDC_SignalStatusRawHome
Raw HOME input.

enumerator kQDC_SignalStatusRawIndex
Raw INDEX input.

enumerator kQDC_SignalStatusRawPhaseB
Raw PHASEB input.

enumerator kQDC_SignalStatusRawPhaseA
Raw PHASEA input.

enumerator kQDC_SignalStatusFilteredHome
The filtered HOME input.

enumerator kQDC_SignalStatusFilteredIndex
The filtered INDEX input.

enumerator kQDC_SignalStatusFilteredPhaseB
The filtered PHASEB input.

enumerator kQDC_SignalStatusFilteredPhaseA
The filtered PHASEA input.

enumerator kQDC_SignalStatusAllFlags

enum _qdc_interrupt_enable
Interrupt enable/disable mask. .

Values:

enumerator kQDC_HomeTransitionInterruptEnable
HOME signal transition interrupt enable.

enumerator kQDC_IndexPulseInterruptEnable
INDEX pulse interrupt enable.

enumerator kQDC_WatchdogTimeoutInterruptEnable
Watchdog timeout interrupt enable.

enumerator kQDC_PositionCompareInterruptEnable
Position compare interrupt enable.

enumerator kQDC_SimultPhaseChangeInterruptEnable
Simultaneous PHASEA and PHASEB change interrupt enable.

enumerator kQDC_PositionRollOverInterruptEnable
Roll-over interrupt enable.

enumerator kQDC_PositionRollUnderInterruptEnable
Roll-under interrupt enable.

enumerator kQDC_PositionCompare1InterruptEnable
Position compare 1 interrupt enable.

enumerator kQDC_AllInterruptEnable

enum _qdc_home_init_pos_counter_mode
Define HOME signal's trigger mode.

Values:

enumerator kQDC_HomeInitPosCounterDisabled
Don't use HOME signal to initialize the position counter.

enumerator kQDC_HomeInitPosCounterOnRisingEdge

Use positive going edge to trigger initialization of position counters.

enumerator kQDC_HomeInitPosCounterOnFallingEdge

Use negative going edge to trigger initialization of position counters.

enum __qdc_index_init_pos_counter_mode

Define INDEX signal's trigger mode.

Values:

enumerator kQDC_IndexInitPosCounterDisabled

INDEX pulse does not initialize the position counter.

enumerator kQDC_IndexInitPosCounterOnRisingEdge

Use INDEX pulse rising edge to initialize position counter.

enumerator kQDC_IndexInitPosCounterOnFallingEdge

Use INDEX pulse falling edge to initialize position counter.

enum __qdc_decoder_work_mode

Define type for decoder work mode.

In normal work mode uses the standard quadrature decoder with PHASEA and PHASEB. In signal phase count mode, a positive transition of the PHASEA input generates a count signal while the PHASEB input and the reverse direction control the counter direction. If the reverse direction is not enabled, PHASEB = 0 means counting up and PHASEB = 1 means counting down. If the reverse direction is enabled, PHASEB = 0 means counting down and PHASEB = 1 means counting up.

Values:

enumerator kQDC_DecoderQuadratureMode

Use standard quadrature decoder with PHASEA and PHASEB.

enumerator kQDC_DecoderSignalPhaseCountMode

PHASEA input generates a count signal while PHASEB input control the direction.

enum __qdc_output_pulse_mode

Define type for the condition of POSMATCH pulses.

Values:

enumerator kQDC_OutputPulseOnCounterEqualCompare

POSMATCH pulses when a match occurs between the position counters (POS) and the compare value (COMP, COMP1).

enumerator kQDC_OutputPulseOnReadingPositionCounter

POSMATCH pulses when reading position counter(POS), revolution counter(REV), position difference counter(POSD).

enum __qdc_revolution_count_condition

Define type for determining how the revolution counter (REV) is incremented/decremented.

Values:

enumerator kQDC_RevolutionCountOnIndexPulse

Use INDEX pulse to increment/decrement revolution counter.

enumerator kQDC_RevolutionCountOnRollOverModulus

Use modulus counting roll-over/under to increment/decrement revolution counter.

enum _qdc_filter_sample_count

Input Filter Sample Count.

The Input Filter Sample Count represents the number of consecutive samples that must agree, before the input filter accepts an input transition

Values:

enumerator kQDC_Filter3Samples
3 samples.

enumerator kQDC_Filter4Samples
4 samples.

enumerator kQDC_Filter5Samples
5 samples.

enumerator kQDC_Filter6Samples
6 samples.

enumerator kQDC_Filter7Samples
7 samples.

enumerator kQDC_Filter8Samples
8 samples.

enumerator kQDC_Filter9Samples
9 samples.

enumerator kQDC_Filter10Samples
10 samples.

enum _qdc_filter_prescaler

Prescaler Divide IPBus Clock to filter Clock.

Values:

enumerator kQDC_FilterPrescaler1
Prescaler value 1.

enumerator kQDC_FilterPrescaler2
Prescaler value 2.

enumerator kQDC_FilterPrescaler4
Prescaler value 4.

enumerator kQDC_FilterPrescaler8
Prescaler value 8.

enumerator kQDC_FilterPrescaler16
Prescaler value 16.

enumerator kQDC_FilterPrescaler32
Prescaler value 32.

enumerator kQDC_FilterPrescaler64
Prescaler value 64.

enumerator kQDC_FilterPrescaler128
Prescaler value 128.

enum _qdc_count_direction_flag

Count direction.

Values:

enumerator kQDC_CountDirectionDown

Last count was in down direction.

enumerator kQDC_CountDirectionUp

Last count was in up direction.

enum _qdc_prescaler

Prescaler used by Last Edge Time (LASTEDGE) and Position Difference Period Counter (POS-DPER).

Values:

enumerator kQDC_Prescaler1

Prescaler value 1.

enumerator kQDC_Prescaler2

Prescaler value 2.

enumerator kQDC_Prescaler4

Prescaler value 4.

enumerator kQDC_Prescaler8

Prescaler value 8.

enumerator kQDC_Prescaler16

Prescaler value 16.

enumerator kQDC_Prescaler32

Prescaler value 32.

enumerator kQDC_Prescaler64

Prescaler value 64.

enumerator kQDC_Prescaler128

Prescaler value 128.

enumerator kQDC_Prescaler256

Prescaler value 256.

enumerator kQDC_Prescaler512

Prescaler value 512.

enumerator kQDC_Prescaler1024

Prescaler value 1024.

enumerator kQDC_Prescaler2048

Prescaler value 2048.

enumerator kQDC_Prescaler4096

Prescaler value 4096.

enumerator kQDC_Prescaler8192

Prescaler value 8192.

enumerator kQDC_Prescaler16384

Prescaler value 16384.

enumerator kQDC_Prescaler32768

Prescaler value 32768.

typedef enum _qdc_home_init_pos_counter_mode qdc_home_init_pos_counter_mode_t

Define HOME signal's trigger mode.

`typedef enum _qdc_index_init_pos_counter_mode qdc_index_init_pos_counter_mode_t`

Define INDEX signal's trigger mode.

`typedef enum _qdc_decoder_work_mode qdc_decoder_work_mode_t`

Define type for decoder work mode.

In normal work mode uses the standard quadrature decoder with PHASEA and PHASEB. In signal phase count mode, a positive transition of the PHASEA input generates a count signal while the PHASEB input and the reverse direction control the counter direction. If the reverse direction is not enabled, PHASEB = 0 means counting up and PHASEB = 1 means counting down. If the reverse direction is enabled, PHASEB = 0 means counting down and PHASEB = 1 means counting up.

`typedef enum _qdc_output_pulse_mode qdc_output_pulse_mode_t`

Define type for the condition of POSMATCH pulses.

`typedef enum _qdc_revolution_count_condition qdc_revolution_count_condition_t`

Define type for determining how the revolution counter (REV) is incremented/decremented.

`typedef enum _qdc_filter_sample_count qdc_filter_sample_count_t`

Input Filter Sample Count.

The Input Filter Sample Count represents the number of consecutive samples that must agree, before the input filter accepts an input transition

`typedef enum _qdc_filter_prescaler qdc_filter_prescaler_t`

Prescaler Divide IPBus Clock to filter Clock.

`typedef enum _qdc_count_direction_flag qdc_count_direction_flag_t`

Count direction.

`typedef enum _qdc_prescaler qdc_prescaler_t`

Prescaler used by Last Edge Time (LASTEDGE) and Position Difference Period Counter (POSDPER).

`typedef struct _qdc_config qdc_config_t`

Define user configuration structure for QDC module.

`QDC_CTRL_W1C_FLAGS`

W1C bits in QDC CTRL registers.

`QDC_CTRL2_W1C_FLAGS`

W1C bits in QDC CTRL2 registers.

`QDC_CTRL3_W1C_FLAGS`

W1C bits in QDC CTRL3 registers.

`QDC_CTRL_INT_EN`

Interrupt enable bits in QDC CTRL registers.

`QDC_CTRL2_INT_EN`

Interrupt enable bits in QDC CTRL2 registers.

`QDC_CTRL3_INT_EN`

Interrupt enable bits in QDC CTRL3 registers.

`QDC_CTRL_INT_FLAGS`

Interrupt flag bits in QDC CTRL registers.

`QDC_CTRL2_INT_FLAGS`

Interrupt flag bits in QDC CTRL2 registers.

QDC_CTRL3_INT_FLAGS

Interrupt flag bits in QDC CTRL3 registers.

struct __qdc_config

#include <fsl_qdc.h> Define user configuration structure for QDC module.

Public Members

bool bEnableReverseDirection

Enable reverse direction counting.

qdc_decoder_work_mode_t eDecoderWorkMode

Use standard quadrature decoder mode or signal phase count mode.

qdc_home_init_pos_counter_mode_t eHomeInitPosCounterMode

Select how HOME signal used to initialize position counters.

qdc_index_init_pos_counter_mode_t eIndexInitPosCounterMode

Select how INDEX signal used to initialize position counters.

bool bEnableTriggerInitPositionCounter

Initialize position counter with initial register(UNIT, LINIT) value on TRIGGER's rising edge.

bool bEnableTriggerClearPositionRegisters

Clear position counter(POS), revolution counter(REV), position difference counter(POSD) on TRIGGER's rising edge.

bool bEnableTriggerHoldPositionRegisters

Load position counter(POS), revolution counter(REV), position difference counter(POSD) values to hold registers on TRIGGER's rising edge.

bool bEnableIndexInitPositionCounter

Enables the feature that the position counter to be initialized by Index Event Edge Mark.

This option works together with eIndexInitPosCounterMode and bEnableReverseDirection. If enabled, the behavior is like this:

When PHA leads PHB (Clockwise): If eIndexInitPosCounterMode is kQDC_IndexInitPosCounterOnRisingEdge, then INDEX rising edge reset position counter. If eIndexInitPosCounterMode is kQDC_IndexInitPosCounterOnFallingEdge, then INDEX falling edge reset position counter. If bEnableReverseDirection is false, then Reset position counter to initial value. If bEnableReverseDirection is true, then reset position counter to modulus value.

When PHA lags PHB (Counter Clockwise): If eIndexInitPosCounterMode is kQDC_IndexInitPosCounterOnRisingEdge, then INDEX falling edge reset position counter. If eIndexInitPosCounterMode is kQDC_IndexInitPosCounterOnFallingEdge, then INDEX rising edge reset position counter. If bEnableReverseDirection is false, then Reset position counter to modulus value. If bEnableReverseDirection is true, then reset position counter to initial value.

bool bEnableWatchdog

Enable the watchdog to detect if the target is moving or not.

uint16_t u16WatchdogTimeoutValue

Watchdog timeout count value. It stores the timeout count for the quadrature decoder module watchdog timer.

qdc_filter_prescaler_t eFilterPrescaler

Input signal filter prescaler.

qdc_filter_sample_count_t eFilterSampleCount

Input Filter Sample Count. This value should be chosen to reduce the probability of noisy samples causing an incorrect transition to be recognized. The value represent the number of consecutive samples that must agree prior to the input filter accepting an input transition.

uint8_t u8FilterSamplePeriod

Input Filter Sample Period. This value should be set such that the sampling period is larger than the period of the expected noise. This value represents the sampling period (in IPBus clock cycles) of the decoder input signals. The available range is 0 - 255.

qdc_output_pulse_mode_t eOutputPulseMode

The condition of POSMATCH pulses.

uint32_t u32PositionCompareValue

Position compare value. The available value is a 32-bit number.

uint32_t u32PositionCompare1Value

Position compare 1 value. The available value is a 32-bit number.

qdc_revolution_count_condition_t eRevolutionCountCondition

Revolution Counter Modulus Enable.

bool bEnableModuloCountMode

Enable Modulo Counting.

uint32_t u32PositionModulusValue

Position modulus value. Only used when bEnableModuloCountMode is true. The available value is a 32-bit number.

uint32_t u32PositionInitialValue

Position initial value. The available value is a 32-bit number.

uint32_t u32PositionCounterValue

Position counter value. When Modulo mode enabled, the u32PositionCounterValue should be in the range of u32PositionInitialValue and u32PositionModulusValue.

bool bEnablePeriodMeasurement

Enable period measurement. When enabled, the position difference hold register (POSDH) is only updated when position difference register (POSD) is read.

qdc_prescaler_t ePrescaler

Prescaler.

uint16_t u16EnabledInterruptsMask

Mask of interrupts to be enabled, should be OR'ed value of *_qdc_interrupt_enable*.

2.67 QDC Peripheral and Driver Overview

2.68 QSCI: Queued Serial Communications Interface Driver

```
void QSCI_GetDefaultConfig(qsci_config_t *psConfig, uint32_t u32BaudRateBps, uint32_t
                        u32SrcClockHz)
```

Sets the QSCI configuration structure to default values.

The purpose of this API is to initialize the configuration structure to default value for QSCI_Init to use. Use the unchanged structure in QSCI_Init or modify the structure before calling QSCI_Init. This is an example:

```
qsci_config_t sConfig;
QSCI_GetDefaultConfig(&sConfig, 115200, 12000000U);
QSCI_Init(QSCI0, &sConfig);
```

Parameters

- psConfig – Pointer to configuration structure.
- u32BaudRateBps – Baudrate setting.
- u32SrcClockHz – The clock source frequency for QSCI module.

```
status_t QSCI_Init(QSCI_Type *base, qsci_config_t *psConfig)
```

Initializes the QSCI instance with a user configuration structure.

This function configures the QSCI module with the customized settings. User can configure the configuration structure manually or get the default configuration by using the QSCI_GetDefaultConfig function. The example below shows how to use this API to configure QSCI.

```
qsci_config_t sConfig;
QSCI_GetDefaultConfig(&sConfig, 115200, 12000000U);
QSCI_Init(QSCI0, &sConfig);
```

Parameters

- base – QSCI peripheral base address.
- psConfig – Pointer to the user-defined configuration structure.

Return values

- kStatus_QSCI_BaudrateNotSupport – Baudrate is not supported in the current clock source.
- kStatus_Success – Set baudrate succeeded.

```
void QSCI_Deinit(QSCI_Type *base)
```

Deinitializes a QSCI instance.

This function waits for transmitting complete, then disables TX and RX.

Parameters

- base – QSCI peripheral base address.

```
static inline uint16_t QSCI_GetStatusFlags(QSCI_Type *base)
```

Gets QSCI hardware status flags.

Parameters

- base – QSCI peripheral base address.

Returns

QSCI status flags, can be a single flag or several flags in `_qsci_status_flags` combined by OR.

`void QSCI_ClearStatusFlags(QSCI_Type *base, uint16_t u16StatusFlags)`

Clears QSCI status flags.

This function clears QSCI status flags. Members in `kQSCI_Group0Flags` can't be cleared by this function, they are cleared or set by hardware.

Parameters

- `base` – QSCI peripheral base address.
- `u16StatusFlags` – The status flag mask, can be a single flag or several flags in `_qsci_status_flags` combined by OR.

`void QSCI_EnableInterrupts(QSCI_Type *base, uint8_t u8Interrupts)`

Enables QSCI interrupts according to the provided mask.

This function enables the QSCI interrupts according to the provided mask. The mask is a logical OR of enumeration members in `_qsci_interrupt_enable`.

Parameters

- `base` – QSCI peripheral base address.
- `u8Interrupts` – The interrupt source mask, can be a single source or several sources in `_qsci_interrupt_enable` combined by OR.

`void QSCI_DisableInterrupts(QSCI_Type *base, uint8_t u8Interrupts)`

Disables QSCI interrupts according to the provided mask.

This function disables the QSCI interrupts according to the provided mask. The mask is a logical OR of enumeration members in `_qsci_interrupt_enable`.

Parameters

- `base` – QSCI peripheral base address.
- `u8Interrupts` – The interrupt source mask, can be a single source or several sources in `_qsci_interrupt_enable` combined by OR.

`uint8_t QSCI_GetEnabledInterrupts(QSCI_Type *base)`

Gets the enabled QSCI interrupts.

This function gets the enabled QSCI interrupts. The enabled interrupts are returned as the logical OR value of the enumerators `_qsci_interrupt_enable`.

Parameters

- `base` – QSCI peripheral base address.

Returns

The interrupt source mask, can be a single source or several sources in `_qsci_interrupt_enable` combined by OR.

`static inline void QSCI_Reset(QSCI_Type *base)`

Sets the QSCI register value to reset value.

Parameters

- `base` – QSCI peripheral base address.

`static inline void QSCI_EnableTx(QSCI_Type *base, bool bEnable)`

Enables or disables the QSCI transmitter.

This function enables or disables the QSCI transmitter.

Parameters

- `base` – QSCI peripheral base address.
- `bEnable` – True to enable, false to disable.

```
static inline void QSCI_EnableRx(QSCI_Type *base, bool bEnable)
```

Enables or disables the QSCI receiver.

This function enables or disables the QSCI receiver.

Parameters

- base – QSCI peripheral base address.
- bEnable – True to enable, false to disable.

```
static inline void QSCI_EnableStopInWait(QSCI_Type *base, bool bEnable)
```

Enables/disables stop in wait.

Parameters

- base – QSCI peripheral base address.
- bEnable – true to enable, QSCI stops working in wait mode, false to disable, QSCI keeps working in wait mode

```
static inline void QSCI_Enable9bitMode(QSCI_Type *base, bool bEnable)
```

Enables/Disables 9-bit data mode for QSCI.

Parameters

- base – QSCI peripheral base address.
- bEnable – true to enable, false to disable.

```
static inline void QSCI_EnableStandbyMode(QSCI_Type *base, bool bEnable)
```

Enables/Disables standby mode.

When QSCI is in standby mode, further receiver interrupt requests are inhibited waiting to be wake up. The wakeup mode can be configured by QSCI_SetWakeupMode. Hardware wakes the receiver by automatically disabling standby.

Parameters

- base – QSCI peripheral base address.
- bEnable – true to enable, false to disable.

```
static inline void QSCI_EnableLINSlaveMode(QSCI_Type *base, bool bEnable)
```

Enable/Disable LIN slave mode.

If enabled QSCI is in LIN slave mode. When break is detected, the baudrate register is automatically adjusted to match the value measured from the sync character that follows.

Parameters

- base – QSCI peripheral base address.
- bEnable – true to enable, false to disable.

```
static inline void QSCI_EnableStopHold(QSCI_Type *base, bool bEnable)
```

Enable/Disable stop mode hold off.

When enabled, if chip level stop mode occurs and transmitter or receiver is still busy, QSCI will hold off stop mode until both transmitter and receiver are idle.

Parameters

- base – QSCI peripheral base address.
- bEnable – true to enable, false to disable.

```
static inline void QSCI_SetTransferMode(QSCI_Type *base, qsci_transfer_mode_t
                                     eTransferMode)
```

Sets the QSCI transfer mode.

Parameters

- base – QSCI peripheral base address.
- eTransferMode – The QSCI tx/rx loop mode, kQSCI_Normal to use normal transfer, kQSCI_LoopInternal to let internal tx feed back to rx, kQSCI_SingleWire to use single wire mode using tx pin as tx and rx.

```
static inline void QSCI_SetWakeupMode(QSCI_Type *base, qsci_wakeup_mode_t eWakeupMode)
```

Sets wakeup mode for QSCI.

Parameters

- base – QSCI peripheral base address.
- eWakeupMode – Wakeup mode, kQSCI_WakeupOnIdleLine or kQSCI_WakeupOnAddressMark.

```
static inline void QSCI_SetPolarityMode(QSCI_Type *base, qsci_polarity_mode_t ePolarityMode)
```

Sets polarity mode for QSCI.

Parameters

- base – QSCI peripheral base address.
- ePolarityMode – Polarity mode, kQSCI_PolarityNormal or kQSCI_PolarityInvert.

```
static inline void QSCI_SetParityMode(QSCI_Type *base, qsci_parity_mode_t eParityMode)
```

Sets parity mode for QSCI.

Parameters

- base – QSCI peripheral base address.
- eParityMode – Polarity mode, kQSCI_ParityDisabled, kQSCI_ParityEven or kQSCI_ParityOdd.

```
status_t QSCI_SetBaudRate(QSCI_Type *base, uint32_t u32BaudRateBps, uint32_t
                        u32SrcClockHz)
```

Sets the QSCI instance baud rate.

This function configures the QSCI module baud rate. This function can be used to update QSCI module baud rate after the QSCI module is initialized by the QSCI_Init.

Parameters

- base – QSCI peripheral base address.
- u32BaudRateBps – QSCI baudrate to be set.
- u32SrcClockHz – QSCI clock source frequency in Hz.

Return values

- kStatus_QSCI_BaudrateNotSupport – Baudrate is not supported in the current clock source.
- kStatus_Success – Set baudrate succeeded.

```
static inline void QSCI_EnableFifo(QSCI_Type *base, bool bEnable)
```

Enables/Disables transmitter/receiver FIFO.

Parameters

- base – QSCI peripheral base address.

- `bEnable` – true to enable, false to disable.

static inline void QSCI_SetTxWaterMark(QSCI_Type *base, *qsci_tx_water_t* eTxFifoWatermark)
Sets transmitter watermark.

Parameters

- `base` – QSCI peripheral base address.
- `eTxFifoWatermark` – Tx water mark level.

static inline void QSCI_SetRxWaterMark(QSCI_Type *base, *qsci_rx_water_t* eRxFifoWatermark)
Sets receiver watermark.

Parameters

- `base` – QSCI peripheral base address.
- `eRxFifoWatermark` – Rx water mark level.

static inline void QSCI_EnableTxDMA(QSCI_Type *base, bool bEnable)
Enables or disables the QSCI transmitter DMA request.

This function enables or disables CTRL2[TDE], to generate the DMA requests when Tx data register is empty.

Parameters

- `base` – QSCI peripheral base address.
- `bEnable` – True to enable, false to disable.

static inline void QSCI_EnableRxDMA(QSCI_Type *base, bool bEnable)
Enables or disables the QSCI receiver DMA request.

This function enables or disables CTRL2[RDE], to generate DMA requests when receiver data register is full.

Parameters

- `base` – QSCI peripheral base address.
- `bEnable` – True to enable, false to disable.

static inline uint32_t QSCI_GetDataRegisterAddress(QSCI_Type *base)
Gets the QSCI data register byte address.

This function returns the QSCI data register address, which is mainly used by DMA/eDMA.

Parameters

- `base` – QSCI peripheral base address.

Returns

QSCI data register byte addresses which are used both by the transmitter and the receiver.

static inline void QSCI_WriteByte(QSCI_Type *base, uint8_t u8Data)
Writes to the TX register.

This function writes data to the TX register directly. The upper layer must ensure that the TX register is empty or TX FIFO has room before calling this function.

Parameters

- `base` – QSCI peripheral base address.
- `u8Data` – The byte to write.

```
static inline void QSCI_SendAddress(QSCI_Type *base, uint8_t u8Address)
```

Sends an address frame in 9-bit data mode.

Parameters

- base – QSCI peripheral base address.
- u8Address – QSCI slave address.

```
static inline uint8_t QSCI_ReadByte(QSCI_Type *base)
```

Reads the RX register directly.

This function reads data from the RX register directly. The upper layer must ensure that the RX register is full or that the TX FIFO has data before calling this function.

Parameters

- base – QSCI peripheral base address.

Returns

The byte read from QSCI data register.

```
void QSCI_WriteBlocking(QSCI_Type *base, const uint8_t *pu8Data, uint32_t u32Length)
```

Writes TX register using a blocking method.

This function polls the TX register, waits TX register to be empty or TX FIFO have room then writes data to the TX buffer.

Parameters

- base – QSCI peripheral base address.
- pu8Data – Start address of the data to write.
- u32Length – Size of the data to write.

```
status_t QSCI_ReadBlocking(QSCI_Type *base, uint8_t *pu8Data, uint32_t u32Length)
```

Reads RX data register using a blocking method.

This function polls the RX register, waits RX register to be full or RX FIFO have data, then reads data from the RX register.

Parameters

- base – QSCI peripheral base address.
- pu8Data – Start address of the buffer to store the received data.
- u32Length – Size of the buffer.

Return values

- kStatus_Fail – Receiver error occurred while receiving data.
- kStatus_QSCI_RxHardwareOverrun – Receiver overrun occurred while receiving data
- kStatus_QSCI_NoiseError – Noise error occurred while receiving data
- kStatus_QSCI_FramingError – error occurred while receiving data
- kStatus_QSCI_ParityError – Parity error occurred while receiving data
- kStatus_Success – Successfully received all data.

```
static inline void QSCI_SendBreak(QSCI_Type *base)
```

Sends one break character (10 or 11 bits of zeroes).

Parameters

- base – QSCI peripheral base address.

```
void QSCI_TransferCreateHandle(QSCI_Type *base, qsci_transfer_handle_t *psHandle,  
                             qsci_transfer_callback_t pfCallback, void *pUserData)
```

Initializes the QSCI handle.

This function initializes the QSCI handle which can be used for other QSCI transactional APIs. Usually, for a specified QSCI instance, call this API once to get the initialized handle.

Parameters

- base – QSCI peripheral base address.
- psHandle – QSCI handle pointer.
- pfCallback – The callback function.
- pUserData – The parameter of the callback function.

```
void QSCI_TransferStartRingBuffer(qsci_transfer_handle_t *psHandle, uint8_t *pu8RxRingBuffer,  
                                 uint16_t u16RxRingBufferSize)
```

Sets up the RX ring buffer.

This function sets up the RX ring buffer to a specific QSCI handle.

When the RX ring buffer is used, data received are stored into the ring buffer even when the user doesn't call the QSCI_TransferReceiveNonBlocking() API. If data is already received in the ring buffer, the user can get the received data from the ring buffer directly.

Note: When using the RX ring buffer, one byte is reserved for internal use. In other words, if ringBufferSize is 32, only 31 bytes are used for saving data.

Parameters

- psHandle – QSCI handle pointer.
- pu8RxRingBuffer – Start address of the ring buffer for background receiving. Pass NULL to disable the ring buffer.
- u16RxRingBufferSize – Size of the ring buffer.

```
void QSCI_TransferStopRingBuffer(qsci_transfer_handle_t *psHandle)
```

Aborts the background transfer and uninstalls the ring buffer.

This function aborts the background transfer and uninstalls the ring buffer.

Parameters

- psHandle – QSCI handle pointer.

```
uint16_t QSCI_TransferGetRxRingBufferLength(qsci_transfer_handle_t *psHandle)
```

Get the ring buffer valid data length.

Parameters

- psHandle – QSCI handle pointer.

Returns

Valid data length in ring buffer.

```
status_t QSCI_TransferSendNonBlocking(qsci_transfer_handle_t *psHandle, qsci_transfer_t  
                                     *psTransfer)
```

Transmits a buffer of data using the interrupt method.

This function sends data using an interrupt method. This is a non-blocking function, which returns directly without waiting for all data to be written to the TX register. When all data is sent out, the QSCI driver calls the callback function and passes the kStatus_QSCI_TxIdle as status parameter.

Parameters

- psHandle – QSCI handle pointer.
- psTransfer – QSCI transfer structure. See qsci_transfer_t.

Return values

- kStatus_Success – Successfully start the data transmission.
- kStatus_QSCI_TxBusy – Previous transmission still not finished; data not all written to TX register yet.

void QSCI_TransferAbortSend(*qsci_transfer_handle_t* *psHandle)

Aborts the interrupt-driven data transmit.

This function aborts the interrupt-driven data sending. The user can get the remainBytes to find out how many bytes are not sent out.

Parameters

- psHandle – QSCI handle pointer.

status_t QSCI_TransferGetSendCount(*qsci_transfer_handle_t* *psHandle, *uint32_t* *pu32Count)

Gets the number of bytes sent out to bus.

This function gets the number of bytes sent out to bus by using the interrupt method.

Parameters

- psHandle – QSCI handle pointer.
- pu32Count – Send bytes count.

Return values

- kStatus_NoTransferInProgress – No send in progress.
- kStatus_Success – Get successfully through the parameter count;

status_t QSCI_TransferReceiveNonBlocking(*qsci_transfer_handle_t* *psHandle, *qsci_transfer_t* *psTransfer, *uint32_t* *pu32ReceivedBytes)

Receives a buffer of data using an interrupt method.

This function receives data using an interrupt method. This is a non-blocking function, which returns without waiting for all data to be received. If the RX ring buffer is used and not empty, the data in the ring buffer is copied and the parameter pu32ReceivedBytes shows how many bytes are copied from the ring buffer. After copying, if the data in the ring buffer is not enough to read, the receive request is saved by the QSCI driver. When the new data arrives, the receive request is serviced first. When all data is received, the QSCI driver notifies the upper layer through a callback function and passes the status parameter kStatus_QSCI_RxIdle. For example, the upper layer needs 10 bytes but there are only 5 bytes in the ring buffer. The 5 bytes are copied to the psTransfer->data and this function returns with the parameter pu32ReceivedBytes set to 5. For the left 5 bytes, newly arrived data is saved from the psTransfer->data[5]. When 5 bytes are received, the QSCI driver notifies the upper layer. If the RX ring buffer is not enabled, this function enables the RX and RX interrupt to receive data to the psTransfer->data. When all data is received, the upper layer is notified.

Parameters

- psHandle – QSCI handle pointer.
- psTransfer – QSCI transfer structure, see qsci_transfer_t.
- pu32ReceivedBytes – Bytes received from the ring buffer directly.

Return values

- kStatus_Success – Successfully queue the transfer into transmit queue.

- kStatus_QSCI_RxBusy – Previous receive request is not finished.

void QSCI_TransferAbortReceive(*qsci_transfer_handle_t* *psHandle)

Aborts the interrupt-driven data receiving.

This function aborts the interrupt-driven data receiving. The user can get the remainBytes to know how many bytes are not received yet.

Parameters

- psHandle – QSCI handle pointer.

status_t QSCI_TransferGetReceivedCount(*qsci_transfer_handle_t* *psHandle, uint32_t *pu32Count)

Gets the number of bytes that have been received.

This function gets the number of bytes that have been received.

Parameters

- psHandle – QSCI handle pointer.
- pu32Count – Receive bytes count.

Return values

- kStatus_NoTransferInProgress – No receive in progress.
- kStatus_InvalidArgument – Parameter is invalid.
- kStatus_Success – Get successfully through the parameter pu32Count;

FSL_QSCI_DRIVER_VERSION

QSCI driver version.

Status codes for the QSCI driver.

Values:

enumerator kStatus_QSCI_TxBusy

Transmitter is busy.

enumerator kStatus_QSCI_RxBusy

Receiver is busy.

enumerator kStatus_QSCI_TxIdle

Transmitter is idle.

enumerator kStatus_QSCI_RxIdle

Receiver is idle.

enumerator kStatus_QSCI_FlagCannotClearManually

Status flag can't be manually cleared.

enumerator kStatus_QSCI_RxRingBufferOverrun

QSCI RX software ring buffer overrun.

enumerator kStatus_QSCI_RxHardwareOverrun

QSCI receiver hardware overrun.

enumerator kStatus_QSCI_NoiseError

QSCI noise error.

enumerator kStatus_QSCI_FramingError

QSCI framing error.

enumerator kStatus_QSCI_ParityError

QSCI parity error.

enumerator kStatus_QSCI_BaudrateNotSupport

Baudrate is not supported in current clock source

enumerator kStatus_QSCI_IdleLineDetected

QSCI IDLE line detected.

enumerator kStatus_QSCI_Timeout

Timeout happens when waiting for status flags to change.

enum _qsci_status_flags

QSCI hardware status flags.

These enumerations can be ORed together to form bit masks.

Values:

enumerator kQSCI_TxDataRegEmptyFlag

TX data register empty flag.

enumerator kQSCI_TxIdleFlag

Transmission idle flag.

enumerator kQSCI_RxDataRegFullFlag

RX data register full flag.

enumerator kQSCI_RxIdleLineFlag

Rx Idle line flag.

enumerator kQSCI_RxOverrunFlag

RX overrun flag.

enumerator kQSCI_RxNoiseFlag

RX detect noise on Rx input.

enumerator kQSCI_RxFrameErrorFlag

Rx frame error flag, sets if logic 0 was detected for stop bit

enumerator kQSCI_RxParityErrorFlag

Rx parity error if parity enabled, sets upon parity error detection

enumerator kQSCI_RxInputEdgeFlag

RX pin active edge interrupt flag, sets when active edge detected

enumerator kQSCI_LINSyncErrorFlag

Only for LIN mode.

enumerator kQSCI_TxDMARequestFlag

Tx DMA request is ongoing.

enumerator kQSCI_RxDMARequestFlag

Rx DMA request is ongoing.

enumerator kQSCI_RxActiveFlag

enumerator kQSCI_Group0Flags

Members in kQSCI_Group0Flags can't be cleared by QSCI_ClearStatusFlags, they are handled by HW.

enumerator kQSCI_Group1Flags

Whole kQSCI_Group1Flags will be cleared if trying to clear any member in kQSCI_Group1Flags or kQSCI_Group2Flags in the mask.

enumerator kQSCI_Group2Flags

Member in kQSCI_Group2Flags can be cleared individually

enumerator kQSCI_StatusAllFlags

enum __qsci_interrupt_enable

QSCI interrupt enable/disable source.

These enumerations can be ORed together to form bit masks.

Values:

enumerator kQSCI_TxEmptyInterruptEnable

Transmit data register empty interrupt.

enumerator kQSCI_TxIdleInterruptEnable

Transmission idle interrupt.

enumerator kQSCI_RxFullInterruptEnable

Receive data register full interrupt.

enumerator kQSCI_RxErrorInterruptEnable

Receive error interrupt.

enumerator kQSCI_RxInputEdgeInterruptEnable

Receive input edge interrupt.

enumerator kQSCI_RxIdleLineInterruptEnable

Receive idle interrupt.

enumerator kQSCI_AllInterruptEnable

enum __qsci_transfer_mode

QSCI transmitter/receiver loop mode.

Values:

enumerator kQSCI_Normal

Normal mode, 2 signal pins, no loop.

enumerator kQSCI_LoopInternal

Loop mode with internal TXD fed back to RXD.

enumerator kQSCI_SingleWire

Use tx pin as input and output half-duplex transfer.

enum __qsci_data_bit_mode

QSCI data bit count.

Values:

enumerator kQSCI_Data8Bit

1 start bit, 8 data bit, 1 stop bit

enumerator kQSCI_Data9Bit

1 start bit, 9 data bit, 1 stop bit. This mode actually is not supported yet in driver.

enum __qsci_wakeup_mode

QSCI wakeup mode.

Values:

enumerator kQSCI_WakeupOnIdleLine

Idle condition wakes the QSCI module.

enumerator kQSCI_WakeupOnAddressMark
Address mark wakes the QSCI module.

enum _qsci_polarity_mode
QSCI signal polarity mode.

Values:

enumerator kQSCI_PolarityNormal
Normal mode, no inversion.

enumerator kQSCI_PolarityInvert
Invert transmit and receive data bits.

enum _qsci_parity_mode
QSCI parity mode.

Values:

enumerator kQSCI_ParityDisabled
Parity disabled

enumerator kQSCI_ParityEven
Parity enabled, type even, bit setting: PE | PT = 10

enumerator kQSCI_ParityOdd
Parity enabled, type odd, bit setting: PE | PT = 11

enum _qsci_tx_water
QSCI transmitter watermark level.

Values:

enumerator kQSCI_TxWater0Word
Tx interrupt sets when tx fifo empty.

enumerator kQSCI_TxWater1Word
Tx interrupt sets when tx fifo has 1 or few word.

enumerator kQSCI_TxWater2Word
Tx interrupt sets when tx fifo has 2 or few words.

enumerator kQSCI_TxWater3Word
Tx interrupt sets when tx fifo not full.

enum _qsci_rx_water
QSCI receiver watermark level.

Values:

enumerator kQSCI_RxWater1Word
Rx interrupt sets when rx fifo not empty.

enumerator kQSCI_RxWater2Word
Rx interrupt sets when rx fifo has at least 1 word.

enumerator kQSCI_RxWater3Word
Rx interrupt sets when rx fifo has at least 2 words.

enumerator kQSCI_RxWater4Word
Rx interrupt sets when rx fifo full.

typedef enum _qsci_transfer_mode qsci_transfer_mode_t
QSCI transmitter/receiver loop mode.

```
typedef enum _qsci_data_bit_mode qsci_data_bit_mode_t
    QSCI data bit count.
```

```
typedef enum _qsci_wakeup_mode qsci_wakeup_mode_t
    QSCI wakeup mode.
```

```
typedef enum _qsci_polarity_mode qsci_polarity_mode_t
    QSCI signal polarity mode.
```

```
typedef enum _qsci_parity_mode qsci_parity_mode_t
    QSCI parity mode.
```

```
typedef enum _qsci_tx_water qsci_tx_water_t
    QSCI transmitter watermark level.
```

```
typedef enum _qsci_rx_water qsci_rx_water_t
    QSCI receiver watermark level.
```

```
typedef struct _qsci_config qsci_config_t
    QSCI configuration structure.
```

```
typedef struct _qsci_transfer_handle_t qsci_transfer_handle_t
    Forward declaration of the handle typedef.
```

```
typedef void (*qsci_transfer_callback_t)(qsci_transfer_handle_t *psHandle)
    QSCI interrupt transfer callback function definition.
```

Defines the interface of user callback function used in QSCI interrupt transfer using transactional APIs. The callback function shall be defined and declared in application level by user. Before starting QSCI transmitting or receiving by calling QSCI_TransferSendNonBlocking or QSCI_TransferReceiveNonBlocking, call QSCI_TransferCreateHandle to install the user callback. When the transmitting or receiving ends or any bus error like hardware overrun occurs, user callback will be invoked by driver.

Param psHandle

Transfer handle that contains bus status, user data.

```
typedef struct _qsci_transfer qsci_transfer_t
    QSCI transfer structure.
```

```
typedef void (*qsci_isr_t)(void *handle)
```

```
qsci_isr_t s_pfQsciIsr
```

```
void *s_psQsciHandles[]
```

```
IRQn_Type const s_eQsciTXIdleIRQs[]
```

```
uint16_t QSCI_GetInstance(QSCI_Type *base)
    Get the QSCI instance from peripheral base address.
```

Parameters

- base – QSCI peripheral base address.

Returns

QSCI instance.

```
QSCI_RETRY_TIMES
```

Retry times when checking status flags.

```
QSCI_GET_BUS_STATUS(psHandle)
```

Macros to be used inside user callback.

QSCI_GET_TRANSFER_USER_DATA(psHandle)

struct __qsci_config

#include <fsl_qsci.h> QSCI configuration structure.

Public Members

qsci_transfer_mode_t eTransferMode

Transmitter/receiver loop mode.

bool bStopInWaitEnable

Enable/disable module stops working in wait mode.

qsci_data_bit_mode_t eDataBitMode

Number of data bits.

qsci_wakeup_mode_t eWakeupMode

Receiver wakeup mode, idle line or addressmark.

qsci_polarity_mode_t ePolarityMode

Polarity of transmit/receive data.

qsci_parity_mode_t eParityMode

Parity mode, disabled (default), even, odd.

bool bEnableStopHold

Control the stop hold enable.

bool bEnableTx

Enable TX

bool bEnableRx

Enable RX

bool bEnableFifo

Enable Tx/Rx FIFO

bool bEnableTxDMA

Enable Tx DMA

bool bEnableRxDMA

Enable Rx DMA

qsci_tx_water_t eTxFifoWatermark

TX FIFO watermark

qsci_rx_water_t eRxFifoWatermark

RX FIFO watermark

uint8_t u8Interrupts

Mask of QSCI interrupt sources to enable.

uint32_t u32BaudRateBps

QSCI baud rate

uint32_t u32SrcClockHz

The clock source frequency for QSCI module.

```
struct _qsci_transfer_handle_t
#include <fsl_qsci.h> QSCI transfer handle.
```

Note: If user wants to use the transactional API to transfer data in interrupt way, one QSCI instance should and can only be allocated one handle.

Note: The handle is maintained by QSCI driver internally, which means the transfer state is retained and user shall not modify its state u8TxState or u8RxState in application level. If user only wish to use transactional APIs without understanding its mechanism, it is not necessary to understand these members.

Public Members

QSCI_Type *base
QSCI base pointer to the instance belongs to this handle.

uint8_t *pu8TxData
Address of remaining data to send.

volatile uint32_t u32TxRemainingSize
Size of the remaining data to send.

uint32_t u32TxDataSize
Size of the data to send out.

uint8_t *pu8RxData
Address of remaining data to receive.

volatile uint32_t u32RxRemainingSize
Size of the remaining data to receive.

uint32_t u32RxDataSize
Size of the data to receive.

uint8_t *pu8RxRingBuffer
Start address of the receiver ring buffer.

uint16_t u16RxRingBufferSize
Size of the ring buffer.

volatile uint16_t u16RxRingBufferHead
Index for the driver to store received data into ring buffer.

volatile uint16_t u16RxRingBufferTail
Index for the user to get data from the ring buffer.

qsci_transfer_callback_t pfCallback
Callback function.

void *pUserData
QSCI callback function parameter.

volatile uint8_t u8TxState
TX transfer state.

volatile uint8_t u8RxState
RX transfer state

status_t busStatus
QSCI bus status.

struct __qsci_transfer
#include <fsl_qsci.h> QSCI transfer structure.

Public Members

uint8_t *pu8Data
The buffer pointer of data to be transferred.

uint32_t u32DataSize
The byte count to be transferred.

2.69 QSCI_DMA: DMA based QSCI Driver

```
void QSCI_TransferCreateHandleDMA(QSCI_Type *base, qsci_dma_transfer_handle_t *psHandle,  
    qsci_dma_transfer_callback_t pfCallback, void  
    *pUserData, DMA_Type *dmaBase, dma_channel_t  
    dmaTxChannel, dma_channel_t dmaRxChannel)
```

Initializes the QSCI dma handle.

This function initializes the QSCI dma handle which can be used for other QSCI transactional APIs. Usually, for a specified QSCI instance, call this API once to get the initialized handle.

Parameters

- base – QSCI peripheral base address.
- psHandle – Pointer to qsci_dma_transfer_handle_t structure.
- pfCallback – Callback function.
- pUserData – User data.
- dmaBase – DMA base address.
- dmaTxChannel – DMA channel for TX transfer.
- dmaRxChannel – DMA channel for RX transfer.

```
status_t QSCI_TransferSendDMA(qsci_dma_transfer_handle_t *psHandle, qsci_transfer_t  
    *psTransfer)
```

Initiate data transmit using DMA.

This function initiates a data transmit process using DMA. This is a non-blocking function, which returns right away. When all the data is sent, the send callback function is called.

Parameters

- psHandle – QSCI handle pointer.
- psTransfer – QSCI DMA transfer structure. See qsci_transfer_t.

Return values

- kStatus_Success – if succeed, others failed.
- kStatus_QSCI_TxBusy – Previous transfer on going.
- kStatus_InvalidArgument – Invalid argument.

status_t QSCI_TransferReceiveDMA(*qsci_dma_transfer_handle_t* *psHandle, *qsci_transfer_t* *psTransfer)

Initiate data receive using DMA.

This function initiates a data receive process using DMA. This is a non-blocking function, which returns right away. When all the data is received, the receive callback function is called.

Parameters

- psHandle – Pointer to *qsci_dma_transfer_handle_t* structure.
- psTransfer – QSCI DMA transfer structure, see *qsci_transfer_t*.

Return values

- kStatus_Success – if succeed, others fail.
- kStatus_QSCI_RxBusy – Previous transfer ongoing.
- kStatus_InvalidArgument – Invalid argument.

void QSCI_TransferAbortSendDMA(*qsci_dma_transfer_handle_t* *psHandle)

Aborts the data transmit process using DMA.

Parameters

- psHandle – Pointer to *qsci_dma_transfer_handle_t* structure.

void QSCI_TransferAbortReceiveDMA(*qsci_dma_transfer_handle_t* *psHandle)

Aborts the data receive process using DMA.

Parameters

- psHandle – Pointer to *qsci_dma_transfer_handle_t* structure.

status_t QSCI_TransferGetReceivedCountDMA(*qsci_dma_transfer_handle_t* *psHandle, *uint32_t* *pu32Count)

Gets the number of received bytes.

This function gets the number of received bytes.

Parameters

- psHandle – QSCI handle pointer.
- pu32Count – Receive bytes count.

Return values

- kStatus_NoTransferInProgress – No receive in progress.
- kStatus_Success – Get successfully through the parameter count;

status_t QSCI_TransferGetSendCountDMA(*qsci_dma_transfer_handle_t* *psHandle, *uint32_t* *pu32Count)

Gets the number of bytes written to the QSCI TX register.

This function gets the number of bytes written to the QSCI TX register by DMA.

Parameters

- psHandle – QSCI handle pointer.
- pu32Count – Send bytes count.

Return values

- kStatus_NoTransferInProgress – No send in progress.
- kStatus_Success – Get successfully through the parameter count;

FSL_QSCI_DMA_DRIVER_VERSION

QSCI DMA driver version.

typedef struct *_qsci_dma_transfer_handle* qsci_dma_transfer_handle_t

Forward declaration of the qsci dma handle typedef. .

typedef void (*qsci_dma_transfer_callback_t)(*qsci_dma_transfer_handle_t* *psHandle)

QSCI dma transfer callback function definition.

Defines the interface of user callback function used in QSCI dma transfer using transactional APIs. The callback function shall be defined and declared in application level by user. Before starting QSCI transmitting or receiving by calling QSCI_TransferSendDMA or QSCI_TransferReceiveDMA, call QSCI_TransferCreateHandleDMA to install the user callback. When the transmitting or receiving ends, user callback will be invoked by driver.

Param psHandle

Transfer handle that contains bus status, user data.

struct *_qsci_dma_transfer_handle*

#include <fsl_qsci_dma.h> QSCI dma transfer handle.

This struct address should be sizeof(dma_channel_tcd_t) aligned.

Note: If user wants to use the transactional API to transfer data in dma way, one QSCI instance should and can only be allocated one handle.

Note: The handle is maintained by QSCI driver internally, which means the transfer state is retained and user shall not modify its state u8TxState or u8RxState in application level. If user only wish to use transactional APIs without understanding its mechanism, it is not necessary to understand these members.

Public Members

QSCI_Type *base

Pointer to the QSCI base that belongs to this handle.

qsci_dma_transfer_callback_t pfCallback

Callback function.

uint32_t u32RxDataSizeAll

Size of the data to receive.

uint32_t u32TxDataSizeAll

Size of the data to send out.

dma_handle_t sTxDmaHandle

The DMA TX channel used.

dma_handle_t sRxDmaHandle

The DMA RX channel used.

volatile uint8_t u8TxState

TX transfer state.

volatile uint8_t u8RxState

RX transfer state

status_t busStatus

QSCI bus status.

*void *pUserData*

User configurable pointer to any data, function, structure etc that user wish to use in the callback

2.70 The Driver Change Log

2.71 QSCI Peripheral and Driver Overview

2.72 QSPI_DMA: DMA based QSPI Driver

FSL_QSPI_DMA_DRIVER_VERSION

QSPI DMA driver version.

`typedef struct _qspi_master_dma_handle qspi_master_dma_handle_t`

Forward declaration of the `_qspi_master_dma_handle` typedefs.

`typedef struct _qspi_master_dma_handle qspi_slave_dma_handle_t`

Forward declaration of the `_qspi_master_dma_handle` typedefs.

`typedef void (*qspi_dma_transfer_callback_t)(qspi_master_dma_handle_t *psHandle, status_t eCompletionStatus, void *pUserData)`

Completion callback function pointer type.

Param base

QUEUEDSPI peripheral base address.

Param psHandle

Pointer to the handle for the QUEUEDSPI master.

Param eCompletionStatus

Success or error code describing whether the transfer completed.

Param pUserData

Arbitrary pointer-dataSized value passed from the application.

`void QSPI_MasterTransferCreateHandleDMA(QSPI_Type *base, qspi_master_dma_handle_t *psHandle, qspi_dma_transfer_callback_t pfCallback, void *pUserData, DMA_Type *psDmaBase, dma_channel_t eDmaTxChannel, dma_channel_t eDmaRxChannel)`

Initialize the QUEUEDSPI master DMA handle.

This function initializes the QUEUEDSPI DMA master handle which can be used for QUEUEDSPI DMA master transactional APIs. Usually, for a specified QUEUEDSPI instance, call this API once to get the initialized handle.

Parameters

- base – QUEUEDSPI peripheral base address.
- psHandle – QUEUEDSPI handle pointer to `qspi_master_dma_handle_t`.
- pfCallback – QUEUEDSPI callback.
- pUserData – callback function parameter.
- psDmaBase – base address for the DMA

- eDmaTxChannel – Channel of the DMA used for QSPI Tx
- eDmaRxChannel – Channel of the DMA used for QSPI Rx

status_t QSPI_MasterTransferDMA(*qspi_master_dma_handle_t* *psHandle, *qspi_transfer_t* *psXfer)

DMA method of QUEUEDSPI master transfer.

This function transfers data using DMA. This is a non-blocking function, which returns right away. When all data is transferred, the callback function is called.

Note: : The transfer data size should be even, if the transfer data width is larger than 8.

Parameters

- psHandle – pointer to *qspi_master_dma_handle_t* structure which stores the transfer state.
- psXfer – pointer to *qspi_transfer_t* structure.

Returns

status of *status_t*.

status_t QSPI_MasterTransferGetCountDMA(*qspi_master_dma_handle_t* *psHandle, *uint16_t* *pu16Count)

Get the master DMA transfer count.

Parameters

- psHandle – Pointer to the *qspi_master_dma_handle_t* structure which stores the transfer state.
- pu16Count – The number of bytes transferred by using the DMA transaction.

Returns

status of *status_t*.

void QSPI_MasterTransferAbortDMA(*qspi_master_dma_handle_t* *psHandle)

Abort a transfer that uses DMA for master.

Parameters

- psHandle – Pointer to the *qspi_master_dma_handle_t* structure which stores the transfer state.

void QSPI_SlaveTransferCreateHandleDMA(*QSPI_Type* *base, *qspi_slave_dma_handle_t* *psHandle, *qspi_dma_transfer_callback_t* pfCallback, *void* *pUserData, *DMA_Type* *psDmaBase, *dma_channel_t* eDmaTxChannel, *dma_channel_t* eDmaRxChannel)

Initialize the QUEUEDSPI slave DMA handle.

This function initializes the QUEUEDSPI DMA handle which can be used for other QUEUEDSPI transactional APIs. Usually, for a specified QUEUEDSPI instance, call this API once to get the initialized handle.

Parameters

- base – QUEUEDSPI peripheral base address.
- psHandle – QUEUEDSPI handle pointer to *qspi_slave_dma_handle_t*.
- pfCallback – QUEUEDSPI callback.
- pUserData – callback function parameter.

- psDmaBase – base address for the DMA
- eDmaTxChannel – Channel of the DMA used for QSPI Tx
- eDmaRxChannel – Channel of the DMA used for QSPI Rx

status_t QSPI_SlaveTransferDMA(*qspi_slave_dma_handle_t* *psHandle, *qspi_transfer_t* *psXfer)
DMA method of QUEUEDSPI slave transfer.

This function transfers data using DMA. This is a non-blocking function, which returns right away. When all data is transferred, the callback function is called.

Note: : The transfer data size should be even if the transfer data width is larger than 8.

Parameters

- psHandle – pointer to *qspi_slave_dma_handle_t* structure which stores the transfer state.
- psXfer – pointer to *qspi_transfer_t* structure.

Returns

status of *status_t*.

status_t QSPI_SlaveTransferGetCountDMA(*qspi_slave_dma_handle_t* *psHandle, *uint16_t* *pu16Count)

Get the slave DMA transfer count.

Parameters

- psHandle – Pointer to the *qspi_slave_dma_handle_t* structure which stores the transfer state.
- pu16Count – The number of bytes transferred by using the DMA transaction.

Returns

status of *status_t*.

void QSPI_SlaveTransferAbortDMA(*qspi_slave_dma_handle_t* *psHandle)

Abort a transfer that uses DMA for slave.

Parameters

- psHandle – Pointer to the *qspi_slave_dma_handle_t* structure which stores the transfer state.

struct _qspi_master_dma_handle

#include <fsl_queued_spi_dma.h> QUEUEDSPI master DMA transfer handle structure used for transactional API.

Public Members

QSPI_Type *base

Base address of the QSPI Peripheral

volatile uint8_t u8State

QUEUEDSPI transfer state , defined in *_qspi_transfer_state*.

uint16_t u16TotalByteCount

A number of transfer bytes.

qspi_data_width_t eDataWidth

The desired number of bits per frame.

uint16_t u16TxDummyData

Used if txData is NULL.

uint16_t u16RxDummyData

Used if rxData is NULL.

dma_handle_t sTxHandle

dma_handle_t handle point used for transmitting data.

dma_handle_t sRxHandle

dma_handle_t handle point used for receiving data.

bool bIsTxInProgress

Indicates whether the transmit is in progress.

bool bIsRxInProgress

Indicates whether the receive is in progress.

qspi_dma_transfer_callback_t pfCallback

Completion callback.

void *pUserData

Callback user data.

volatile bool bIsPcsActiveAfterTransfer

Indicates whether the PCS signal is active after the last frame transfer; This is not used in slave transfer.

2.73 QSPI: Queued SPI Driver

void QSPI_MasterInit(QSPI_Type *base, const *qspi_master_config_t* *psConfig)

Initializes the QUEUEDSPI as Master.

Use helper function QSPI_MasterGetDefaultConfig to get ready-to-use structure.

Parameters

- base – QUEUEDSPI peripheral address.
- psConfig – Pointer to the structure *qspi_master_config_t*.

void QSPI_MasterGetDefaultConfig(*qspi_master_config_t* *psConfig, uint32_t u32ClockFreqHz)

Helper function to create ready-to-user maste init structure.

The purpose of this API is to get the configuration structure initialized for the QSPI_MasterInit. Users may use the initialized structure unchanged in the QSPI_MasterInit or modify the structure before calling the QSPI_MasterInit. Example:

```
qspi_master_config_t sMasterConfig;  
QSPI_MasterGetDefaultConfig(&sMasterConfig);
```

The default values are: Example:

```
// Parameter provided by user  
psConfig->u32BaudRateBps = u32BaudRateBps;  
psConfig->u32ClockFrequencyHz = u32ClockFreqHz;  
psConfig->eDataWidth = eDataWidth;
```

(continues on next page)

(continued from previous page)

```
// Default configuration
psConfig->eClkPolarity = kQSPI_ClockPolarityActiveRisingEdge;
psConfig->eClkPhase = kQSPI_ClockPhaseSlaveSelectHighBetweenWords;
psConfig->eShiftDirection = kQSPI_MsbFirst;
psConfig->u16DelayBetweenFrameInCLK = 1U;
psConfig->bEnableWiredOrMode = false;
psConfig->bEnableModeFault = false;
psConfig->u8DmaEnableFlags = 0U; // Disable TX/RX Dma
psConfig->bEnableFIFO = false;
psConfig->bEnableStopModeHoldOff = false;
psConfig->u8Interrupts = 0U;
psConfig->bEnableModule = false;
@todo To be added
```

Parameters

- psConfig – pointer to `qspi_master_config_t` structure.
- u32ClockFreqHz – Peripheral clock frequency in Hz

`void QSPI_SlaveInit(QSPI_Type *base, const qspi_slave_config_t *psConfig)`

Initializes the QUEUEDSPI as slave.

Use helper function `QSPI_SlaveGetDefaultConfig` to get ready-to-use structure.

Parameters

- base – QUEUEDSPI peripheral address.
- psConfig – Pointer to the structure `qspi_slave_config_t`.

`void QSPI_SlaveGetDefaultConfig(qspi_slave_config_t *psConfig)`

Set the `qspi_slave_config_t` structure to default values.

The purpose of this API is to get the configuration structure initialized for the `QSPI_SlaveInit`. Users may use the initialized structure unchanged in the `QSPI_SlaveInit` or modify the structure before calling the `QSPI_SlaveInit`. Example:

```
qspi_slave_config_t slaveConfig;
QSPI_SlaveGetDefaultConfig(&slaveConfig);
```

The default values are: Example:

```
@todo
```

Parameters

- psConfig – Pointer to the `qspi_slave_config_t` structure.

`void QSPI_Deinit(QSPI_Type *base)`

De-initialize the QUEUEDSPI peripheral for either Master or Slave.

Parameters

- base – QUEUEDSPI peripheral address.

`static inline void QSPI_EnableInterrupts(QSPI_Type *base, uint8_t u8Interrupts)`

Enable one or multiple interrupts.

This function enable one or multiple interrupts.

Note: for TX and RX requests, while enabling the interrupt request the DMA request will be disabled as well. Do not use this API while QUEUEDSPI is in running state.

Parameters

- base – QUEUEDSPI peripheral address.
- u8Interrupts – The interrupt mask which is ORed by the _qspi_interrupt_enable.

```
static inline void QSPI_DisableInterrupts(QSPI_Type *base, uint8_t u8Interrupts)
```

Disable one or multiple interrupts.

This function

Parameters

- base – QUEUEDSPI peripheral address.
- u8Interrupts – The interrupt mask which is ORed by the _qspi_interrupt_enable.

```
static inline void QSPI_EnableDMA(QSPI_Type *base, uint8_t u8DmaFlags)
```

Enable one or multiple DMA.

Note that if the DMA is enabled for Transmit or Receive, make sure the interrupt is disabled for Transmit or Receive.

Parameters

- base – QUEUEDSPI peripheral address.
- u8DmaFlags – DMA Flags ORed from _qspi_dma_enable_flags.

```
static inline void QSPI_DisableDMA(QSPI_Type *base, uint8_t u8DmaFlags)
```

Enable one or multiple DMA.

Note that if the DMA is enabled for Transmit or Receive, make sure the interrupt is disabled for Transmit or Receive.

Parameters

- base – QUEUEDSPI peripheral address.
- u8DmaFlags – DMA Flags ORed from _qspi_dma_enable_flags.

```
static inline uint32_t QSPI_GetTxRegisterAddress(QSPI_Type *base)
```

Get the QUEUEDSPI transmit data register address for the DMA operation.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

The QUEUEDSPI master PUSH register address.

```
static inline uint32_t QSPI_GetRxRegisterAddress(QSPI_Type *base)
```

Get the QUEUEDSPI receive data register address for the DMA operation.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

The QUEUEDSPI POPR data register address.

```
static inline uint16_t QSPI_GetStatusFlags(QSPI_Type *base)
```

Get the QUEUEDSPI status flag state.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

QUEUEDSPI status.

static inline void QSPI_ClearStatusFlags(QSPI_Type *base, uint16_t u16StatusFlags)

Clear the status flag only for the mode fault.

Clear the status flag only for mode fault.

Note: only kQSPI_ModeFaultFlag can be cleared by this API.

Parameters

- base – QUEUEDSPI peripheral address.
- u16StatusFlags – status flags ORed from _qspi_status_flags

static inline void QSPI_Enable(QSPI_Type *base, bool bEnable)

Enable or disable the QUEUEDSPI peripheral.

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – true to enable module, otherwise disable module

uint32_t QSPI_MasterSetBaudRate(QSPI_Type *base, uint32_t u32BaudRateBps, uint32_t u32SrcClockHz)

Set the QUEUEDSPI baud rate in bits-per-second.

This function takes in the desired baud rate, calculates the nearest possible baud rate, and returns the calculated baud rate in bits-per-second.

Parameters

- base – QUEUEDSPI peripheral address.
- u32BaudRateBps – The desired baud rate in bits-per-second.
- u32SrcClockHz – Module source input clock in Hertz.

Returns

The actual calculated baud rate.

static inline void QSPI_SetMasterSlaveMode(QSPI_Type *base, *qspi_master_slave_mode_t* eMode)

Set the QUEUEDSPI as master or slave.

Parameters

- base – QUEUEDSPI peripheral address.
- eMode – Mode setting of type *qspi_master_slave_mode_t*.

static inline bool QSPI_IsMaster(QSPI_Type *base)

Return whether the QUEUEDSPI module is in master mode.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

Returns true if the module is in master mode or false if the module is in slave mode.

```
static inline void QSPI_SetDataShiftOrder(QSPI_Type *base, qspi_data_shift_direction_t
                                         eDataShiftOrder)
```

Set Data Shift Order as MSB first or LSB first.

Parameters

- base – QUEUEDSPI peripheral address.
- eDataShiftOrder – MSB or LSB first from *qspi_data_shift_direction_t*

```
static inline void QSPI_EnableModeFault(QSPI_Type *base, bool bEnable)
```

Enable/Disable mode fault detection.

If enable, allows the kQSPI_ModeFaultFlag flag to be set. If the kQSPI_ModeFaultFlag flag is set, disable the Mod detection does not clear the flag. If the mod detection is disabled, the level of the SS_B pin does not affect the operation of an enabled SPI configured as a master. If configured as a master and mod fault detection is enabled, a transaction in progress will stop if SS_B goes low. For an enabled SPI configured as a slave, having this feature disabled only prevents the flag from being set. It does not affect any other part of SPI operation

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – true to enable Mode Fault detection, false to disable

```
static inline void QSPI_SetClockPolarity(QSPI_Type *base, qspi_clock_polarity_t ePolarity)
```

Set clock polarity.

Note: module shall be disabled before change the polarity by calling QSPI_Enable.

Parameters

- base – QUEUEDSPI peripheral address.
- ePolarity – clock polarity option

```
static inline void QSPI_SetClockPhase(QSPI_Type *base, qspi_clock_phase_t eClockPhase)
```

Set clock phase.

Configure whether get the Slave Select signal toggle high during 2 data frames. Get the SS toggle high between data frames will lead to SPI to be triggered with transaction for the falling edge of SS signal. Otherwise, the data transaction is started on the first active SCLK edge.

Note: module shall be disabled before change the polarity by calling QSPI_Enable.

Note: Do not use kQSPI_ClockPhaseSlaveSelectHighBetweenWords in DMA mode.

Parameters

- base – QUEUEDSPI peripheral address.
- eClockPhase – Option for clock phase

```
static inline void QSPI_EnableWiredORMode(QSPI_Type *base, bool bEnable)
```

Enable/Disable Wired OR mode for SPI pins which means open-drain when enabled and push-pull when disabled.

Parameters

- base – QUEUEDSPI peripheral address.

- `bEnable` – true to configure SPI pins as open-drain, false to configure as push-pull

static inline void QSPI_SetTransactionDataSize(QSPI_Type *base, *qspi_data_width_t* eDataWidth)
Set the transaction data width.

Parameters

- `base` – QUEUEDSPI peripheral address.
- `eDataWidth` – datawidth for bits in each data frame.

static inline void QSPI_MasterSetWaitDelay(QSPI_Type *base, uint16_t
u16WaitDelayInPeriClockCount)

For master mode, set wait delay in clock cycle with delay is set value + 1 peripheral bus clock.

This controls the time between data transactions in master mode. Delay will not be added if no word is waiting for transmitting.

Parameters

- `base` – QUEUEDSPI peripheral address.
- `u16WaitDelayInPeriClockCount` – Clock count for the delay during data frames

static inline void QSPI_EnableStopModeHoldOff(QSPI_Type *base, bool bEnable)

Enable/Disable hold off entry to stop mode is a word is being transmitted/received for Master Mode.

When enabled, this bit allows the SPI module to hold off entry to chip level stop mode if a word is being transmitted or received. Stop mode will be entered after the SPI finishes transmitting/receiving. This bit does not allow the SPI to wake the chip from stop mode in any way. The SHEN bit can only delay the entry into stop mode. This bit should not be set in slave mode because the state of SS_B (which would be controlled by an external master device) may cause the logic to hold off stop mode entry forever.

Parameters

- `base` – QUEUEDSPI peripheral address.
- `bEnable` – true to enable hold-off entrying stop mode if there is transmitting/receiving

uint32_t QSPI_GetInstance(QSPI_Type *base)

Helper function exported for QSPI DMA driver.

Get the instance index from the base address. User need not understand this function.

Parameters

- `base` – QUEUEDSPI peripheral address.

Returns

uint32_t Index of the peripheral instance for given base address.

static inline *qspi_ss_data_logic_level_t* QSPI_MasterGetSlaveSelectLogicLevel(QSPI_Type *base)

For master mode, get the SS_B input logic level while true means drive High and false means drive Low.

Get the value to drive on the SS_B pin. This bit is disabled when SSB_AUTO=1 or SSB_STRB=1. Only apply for Master mode.

Parameters

- `base` – QUEUEDSPI peripheral address.

Returns

true SS_B input level High

Returns

false SS_B input level Low

```
static inline void QSPI_MasterSetSlaveSelectLogicLevel(QSPI_Type *base,  
                                                       qspi_ss_data_logic_level_t eLogicLevel)
```

for master mode, drive Slave Select pin logic high or low

This feature is disabled if Slave Select automatic mode is enabled or Slave Select Strobe feature is enabled

Parameters

- base – QUEUEDSPI peripheral address.
- eLogicLevel – logic level

```
static inline void QSPI_MasterEnableSlaveSelectOpenDrainMode(QSPI_Type *base, bool bEnable)
```

For master mode, Enable open drain in SSB pad pin.

Enable it means SS_B is configured for high and low drive. This mode is generally used in single master systems. Disable it means SS_B is configured as an open drain pin (only drives low output level). This mode is useful for multiple master systems

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – Enable/Disable option.

```
static inline void QSPI_MasterEnableSlaveSelectAutomaticMode(QSPI_Type *base, bool bEnable)
```

For master mode, Enable/Disable Slave Select pin automatic mode.

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – Enable/Disable option.

```
static inline void QSPI_SetSlaveSelectDirection(QSPI_Type *base, qspi_ss_direction_t eDirection)
```

Set Input/Output mode for SSB signal.

Parameters

- base – QUEUEDSPI peripheral address.
- eDirection – options from *qspi_ss_direction_t*

```
static inline void QSPI_MasterEnableSlaveSelectStrobe(QSPI_Type *base, bool bEnable)
```

For master, set strobe mode for SSB signal.

If enabled, Slave select pulse high during data frames irrespective of Clock Phase configuration

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – Enable/Disable option.

```
static inline void QSPI_EnableSlaveSelectOverride(QSPI_Type *base, bool bEnable)
```

Enable / Disable SSB signal from Master/Slave configuration or GPIO pin state.

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – Enable/Disable option.

`void QSPI_SetDummyData(QSPI_Type *base, uint8_t u8DummyData)`

Set up the dummy data used when there is not transmit data provided.

Parameters

- base – QUEUEDSPI peripheral address.
- u8DummyData – Data to be transferred when tx buffer is NULL.

`uint8_t QSPI_GetDummyData(QSPI_Type *base)`

Get the dummy data for each peripheral.

Parameters

- base – QUEUEDSPI peripheral base address.

`static inline void QSPI_WriteData(QSPI_Type *base, uint16_t data)`

Write data into the transmit data register without polling the status of shifting.

Parameters

- base – QUEUEDSPI peripheral address.
- data – The data to send.

`static inline uint16_t QSPI_ReadData(QSPI_Type *base)`

Read data from the receive data register.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

The data from the receive data register.

`static inline void QSPI_EnableFifo(QSPI_Type *base, bool bEnable)`

Enable or disable the QUEUEDSPI FIFOs.

This function allows the caller to disable or enable the TX and RX FIFOs together.

Parameters

- base – QUEUEDSPI peripheral address.
- bEnable – Pass true to enable, pass false to disable

`static inline uint16_t QSPI_GetTxFIFOCount(QSPI_Type *base)`

Get TX FIFO level.

This function gets how many words are in the TX FIFO.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

TX FIFO word count.

`static inline uint16_t QSPI_GetRxFIFOCount(QSPI_Type *base)`

Get RX FIFO level.

This function gets how many words are in the RX FIFO.

Parameters

- base – QUEUEDSPI peripheral address.

Returns

RX FIFO word count.

```
static inline void QSPI_SetFifoWatermarks(QSPI_Type *base, uint16_t txWatermark, uint16_t rxWatermark)
```

Set the transmit and receive FIFO watermark values.

Parameters

- base – QUEUEDSPI peripheral address.
- txWatermark – The TX FIFO watermark value. Refer to `qspi_txfifo_watermark_t` for available values.
- rxWatermark – The RX FIFO watermark value. Refer to `qspi_rxfifo_watermark_t` for available values.

```
static inline void QSPI_GetFifoWatermarks(QSPI_Type *base, uint8_t *pu8TxWatermark, uint8_t *pu8RxWatermark)
```

Get the transmit and receive FIFO watermark values.

Parameters

- base – QUEUEDSPI peripheral address.
- pu8TxWatermark – The TX FIFO watermark value.
- pu8RxWatermark – The RX FIFO watermark value.

```
static inline void QSPI_EmptyRxFifo(QSPI_Type *base)
```

Empty the QUEUEDSPI RX FIFO.

Parameters

- base – QUEUEDSPI peripheral address.

```
void QSPI_MasterTransferCreateHandle(QSPI_Type *base, qspi_master_transfer_handle_t *psHandle, qspi_master_transfer_callback_t pfCallback, void *pUserData)
```

Initialize the QUEUEDSPI master handle.

This function initializes the QUEUEDSPI handle, which can be used for other QUEUEDSPI transactional APIs. Usually, for a specified QUEUEDSPI instance, call this API once to get the initialized handle.

Note: If only use the `QSPI_MasterTransferBlocking`, this API is not necessary be called.

Parameters

- base – QUEUEDSPI peripheral address.
- psHandle – QUEUEDSPI handle pointer to `qspi_master_transfer_handle_t`.
- pfCallback – QUEUEDSPI callback.
- pUserData – Callback function parameter.

```
status_t QSPI_MasterTransferBlocking(QSPI_Type *base, qspi_transfer_t *psXfer)
```

Polling method of QUEUEDSPI master transfer.

This function transfers data using a polling method for master. This is a blocking function, which does not return until all transfers have been completed.

Parameters

- base – QUEUEDSPI peripheral address.
- psXfer – Pointer to the `qspi_transfer_t` structure.

Returns

status of status_t.

status_t QSPI_MasterTransferNonBlocking(*qspi_master_transfer_handle_t* *psHandle,
 qspi_transfer_t *psXfer)

Interrupt method of QUEUEDSPI master transfer.

This function transfers data using interrupts for master. This is a non-blocking function, which returns right away. When all data is transferred, the callback function is called.

Parameters

- psHandle – QUEUEDSPI handle pointer to qspi_master_transfer_handle_t.
- psXfer – Pointer to the qspi_transfer_t structure.

Returns

status of status_t.

status_t QSPI_MasterTransferGetCount(*qspi_master_transfer_handle_t* *psHandle, uint16_t
 *pu16Count)

Get the master transfer count.

Parameters

- psHandle – QUEUEDSPI handle pointer to qspi_master_transfer_handle_t.
- pu16Count – The number of bytes transferred by using the non-blocking transaction.

Returns

status of status_t.

void QSPI_MasterTransferAbort(*qspi_master_transfer_handle_t* *psHandle)

Abort a transfer that uses interrupts for master.

Parameters

- psHandle – QUEUEDSPI handle pointer to qspi_master_transfer_handle_t.

void QSPI_MasterTransferHandleIRQ(*qspi_master_transfer_handle_t* *psHandle)

QUEUEDSPI Master IRQ handler function.

This function processes the QUEUEDSPI transmit and receive IRQ.

Parameters

- psHandle – QUEUEDSPI handle pointer to qspi_master_transfer_handle_t.

void QSPI_SlaveTransferCreateHandle(QSPI_Type *base, *qspi_slave_transfer_handle_t* *psHandle,
 qspi_slave_transfer_callback_t pfCallback, void
 *puUserData)

Initialize the QUEUEDSPI slave handle.

This function initializes the QUEUEDSPI handle, which can be used for other QUEUEDSPI transactional APIs. Usually, for a specified QUEUEDSPI instance, call this API once to get the initialized handle.

Parameters

- base – QUEUEDSPI peripheral base address.
- psHandle – QUEUEDSPI handle pointer to the qspi_slave_transfer_handle_t.
- pfCallback – QUEUEDSPI callback.
- puUserData – Callback function parameter.

status_t QSPI_SlaveTransferNonBlocking(*qspi_slave_transfer_handle_t* *psHandle, *qspi_transfer_t* *psXfer)

Interrupt driven method of QUEUEDSPI slave transfer with completion will be notified by registered callback.

This function transfers data using interrupts for slave. This is a non-blocking function, which returns right away. When all data is transferred, the callback function is called.

Parameters

- psHandle – Pointer to the *qspi_slave_transfer_handle_t* structure which stores the transfer state.
- psXfer – Pointer to the *qspi_transfer_t* structure.

Returns

status of *status_t*.

status_t QSPI_SlaveTransferGetCount(*qspi_slave_transfer_handle_t* *psHandle, *uint16_t* *pu16Count)

Get the slave transfer count already transmitted/received.

Parameters

- psHandle – Pointer to the *qspi_slave_transfer_handle_t* structure which stores the transfer state.
- pu16Count – The number of bytes transferred by using the non-blocking transaction.

Returns

status of *status_t*.

void QSPI_SlaveTransferAbort(*qspi_slave_transfer_handle_t* *psHandle)

Abort a transaction.

Parameters

- psHandle – Pointer to the *qspi_slave_transfer_handle_t* structure which stores the transfer state.

void QSPI_SlaveTransferHandleIRQ(*qspi_slave_transfer_handle_t* *psHandle)

QUEUEDSPI slave IRQ handler function.

This function processes the QUEUEDSPI transmit and receive IRQ.

Parameters

- psHandle – Pointer to the *qspi_slave_transfer_handle_t* structure which stores the transfer state.

FSL_QSPI_DRIVER_VERSION

QSPI driver version.

QSPI_TRANSFER_GET_BASE(handle)

Extract Base Address from handle for master or slave handle.

QSPI_TRANSFER_GET_USER_DATA(handle)

Extract user data from handle for master or slave handle.

Status return code for the QUEUEDSPI driver. Only used in transactional layer in this driver.

.

Values:

enumerator kStatus_QSPI_Busy
QUEUEDSPI transfer is busy.

enumerator kStatus_QSPI_Error
QUEUEDSPI driver error.

enumerator kStatus_QSPI_Idle
QUEUEDSPI is idle.

enumerator kStatus_QSPI_OutOfRange
QUEUEDSPI transfer out of range.

enum _qspi_status_flags
QUEUEDSPI peripheral status flags.

Values:

enumerator kQSPI_TxEmptyFlag
Transmitter Empty Flag.

enumerator kQSPI_ModeFaultFlag
Mode Fault Flag.

enumerator kQSPI_RxOverflowFlag
Receiver Overflow Flag.

enumerator kQSPI_RxFullFlag
Receiver Full Flag.

enumerator kQSPI_AllStatusFlags

enum _qspi_interrupt_enable
QUEUEDSPI interrupt source.

Values:

enumerator kQSPI_TxInterruptEnable
SPTE interrupt enable.

enumerator kQSPI_RxInterruptEnable
SPRF interrupt enable.

enumerator kQSPI_RxOverflowInterruptEnable
Bus error interrupt enable.

enumerator kQSPI_AllInterrupts

enum _qspi_ss_direction
options for Slave Select (SSB) signal direction.

Values:

enumerator kQSPI_SlaveSelectDirectionInput
SSB signal as input for slave mode or master mode with Mode fault enabled.

enumerator kQSPI_SlaveSelectDirectionOutput
SSB signal as output.

enum _qspi_ss_data_logic_level
logical level for Slave Select (SSB) signal data

Values:

enumerator kQSPI_SlaveSelectLogicLow
Slave select logic level low

enumerator kQSPI_SlaveSelectLogicHigh

Slave select logic level high

enum __qspi_txfifo_watermark

QUEUEDSPI Transmit FIFO watermark settings.

Values:

enumerator kQSPI_TxFifoWatermarkEmpty

Transmit interrupt active when Tx FIFO is empty

enumerator kQSPI_TxFifoWatermarkOneWord

Transmit interrupt active when Tx FIFO has one or fewer words available

enumerator kQSPI_TxFifoWatermarkTwoWord

Transmit interrupt active when Tx FIFO has two or fewer words available

enumerator kQSPI_TxFifoWatermarkThreeWord

Transmit interrupt active when Tx FIFO has three or fewer words available

enum __qspi_rxfifo_watermark

QUEUEDSPI Receive FIFO watermark settings.

Values:

enumerator kQSPI_RxFifoWatermarkOneWord

Receive interrupt active when Rx FIFO has at least one word used

enumerator kQSPI_RxFifoWatermarkTwoWord

Receive interrupt active when Rx FIFO has at least two words used

enumerator kQSPI_RxFifoWatermarkThreeWord

Receive interrupt active when Rx FIFO has at least three words used

enumerator kQSPI_RxFifowatermarkFull

Receive interrupt active when Rx FIFO is full

enum __qspi_data_width

Transfer data width in each frame.

Values:

enumerator kQSPI_Data2Bits

2 bits data width

enumerator kQSPI_Data3Bits

3 bits data width

enumerator kQSPI_Data4Bits

4 bits data width

enumerator kQSPI_Data5Bits

5 bits data width

enumerator kQSPI_Data6Bits

6 bits data width

enumerator kQSPI_Data7Bits

7 bits data width

enumerator kQSPI_Data8Bits

8 bits data width

enumerator kQSPI_Data9Bits
9 bits data width

enumerator kQSPI_Data10Bits
10 bits data width

enumerator kQSPI_Data11Bits
11 bits data width

enumerator kQSPI_Data12Bits
12 bits data width

enumerator kQSPI_Data13Bits
13 bits data width

enumerator kQSPI_Data14Bits
14 bits data width

enumerator kQSPI_Data15Bits
15 bits data width

enumerator kQSPI_Data16Bits
16 bits data width

enum __qspi_dma_enable_flags
QUEUEDSPI DMA configuration for Transmit and Receive.

Values:

enumerator kQSPI_DmaRx
Receive DMA Enable Flag.

enumerator kQSPI_DmaTx
Transmit DMA Enable Flag.

enum __qspi_master_slave_mode
QUEUEDSPI master or slave mode configuration.

Values:

enumerator kQSPI_Slave
QUEUEDSPI peripheral operates in slave mode.

enumerator kQSPI_Master
QUEUEDSPI peripheral operates in master mode.

enum __qspi_clock_polarity
QUEUEDSPI clock polarity configuration.

Values:

enumerator kQSPI_ClockPolarityActiveRisingEdge
CPOL=0. Active-high QUEUEDSPI clock (idles low), rising edge of SCLK starts transaction.

enumerator kQSPI_ClockPolarityActiveFallingEdge
CPOL=1. Active-low QUEUEDSPI clock (idles high), falling edge of SCLK starts transaction.

enum __qspi_clock_phase
QUEUEDSPI clock phase configuration.

Values:

enumerator kQSPI_ClockPhaseSlaveSelectHighBetweenWords
CPHA=0, Slave Select toggle high during data frames.

enumerator kQSPI_ClockPhaseSlaveSelectLowBetweenWords
CPHA=1, Slave Select keep low during data frames.

enum __qspi_data_shift_direction
QUEUEDSPI data shifter direction options for a given CTAR.

Values:

enumerator kQSPI_MsbFirst
Data transfers start with most significant bit.

enumerator kQSPI_LsbFirst
Data transfers start with least significant bit.

enum __qspi_pcs_polarity_config
QUEUEDSPI Peripheral Chip Select Polarity configuration.

Values:

enumerator kQSPI_PcsActiveHigh
Pcs Active High (idles low).

enumerator kQSPI_PcsActiveLow
Pcs Active Low (idles high).

enum __qspi_master_transfer_flag
transaction layer configuration options for each transaction

Values:

enumerator kQSPI_MasterPCSContinuous
Indicates whether the PCS signal de-asserts during transfer between frames, note this flag should not be used when CPHA is 0.

enumerator kQSPI_MasterActiveAfterTransfer
Indicates whether the PCS signal is active after the last frame transfer, note 1. this flag should not be used when CPHA is 0, 2. this flag can only be used when kQSPI_MasterPCSContinuous is used.

enum __qspi_transfer_state
QUEUEDSPI transfer state, used internally for transactional layer.

Values:

enumerator kQSPI_Idle
Nothing in the transmitter/receiver.

enumerator kQSPI_Busy
Transfer queue is not finished.

enumerator kQSPI_Error
Transfer error.

typedef enum __qspi_ss_direction qspi_ss_direction_t
options for Slave Select (SSB) signal direction.

typedef enum __qspi_ss_data_logic_level qspi_ss_data_logic_level_t
logical level for Slave Select (SSB) signal data

typedef enum __qspi_txfifo_watermark qspi_txfifo_watermark_t
QUEUEDSPI Transmit FIFO watermark settings.

typedef enum *_qspi_rxfifo_watermark* qspi_rxfifo_watermark_t
 QUEUEDSPI Receive FIFO watermark settings.

typedef enum *_qspi_data_width* qspi_data_width_t
 Transfer data width in each frame.

typedef enum *_qspi_master_slave_mode* qspi_master_slave_mode_t
 QUEUEDSPI master or slave mode configuration.

typedef enum *_qspi_clock_polarity* qspi_clock_polarity_t
 QUEUEDSPI clock polarity configuration.

typedef enum *_qspi_clock_phase* qspi_clock_phase_t
 QUEUEDSPI clock phase configuration.

typedef enum *_qspi_data_shift_direction* qspi_data_shift_direction_t
 QUEUEDSPI data shifter direction options for a given CTAR.

typedef struct *_qspi_master_config* qspi_master_config_t
 QUEUEDSPI master configuration structure with all master configuration fields covered.

typedef struct *_qspi_slave_config* qspi_slave_config_t
 QUEUEDSPI slave configuration structure with all slave configuration fields covered.

typedef enum *_qspi_pcs_polarity_config* qspi_pcs_polarity_config_t
 QUEUEDSPI Peripheral Chip Select Polarity configuration.

typedef struct *_qspi_transfer* qspi_transfer_t
 QUEUEDSPI master/slave transfer structure.

typedef struct *_qspi_master_handle* qspi_master_transfer_handle_t
 Forward declaration of the *_qspi_master_handle* typedefs. .

typedef void (*qspi_master_transfer_callback_t)(qspi_master_transfer_handle_t *psHandle, status_t eCompletionStatus, void *pUserData)
 Completion callback function pointer type.

Param base
 QUEUEDSPI peripheral address.

Param psHandle
 Pointer to the handle for the QUEUEDSPI master.

Param eCompletionStatus
 Success or error code describing whether the transfer completed.

Param pUserData
 Arbitrary pointer-dataSized value passed from the application.

typedef struct *_qspi_slave_handle* qspi_slave_transfer_handle_t
 Forward declaration of the *_qspi_slave_handle* typedefs. .

typedef void (*qspi_slave_transfer_callback_t)(qspi_slave_transfer_handle_t *psHandle, status_t eCompletionStatus, void *pUserData)
 Completion callback function pointer type.

Param base
 QUEUEDSPI peripheral address.

Param handle
 Pointer to the handle for the QUEUEDSPI slave.

Param status
 Success or error code describing whether the transfer completed.

Param pUserData

Arbitrary pointer-dataSized value passed from the application.

QSPI_DUMMY_DATA

User Configuraiton item dummy data filled into Output signal if there is no Tx data.

Dummy data used for Tx if there is no txData.

struct __qspi_master_config

#include <fsl_queued_spi.h> QUEUEDSPI master configuration structure with all master configuration fields covered.

Public Members

uint32_t u32BaudRateBps

Baud Rate for QUEUEDSPI.

qspi_data_width_t eDataWidth

Data width in SPI transfer

qspi_clock_polarity_t eClkPolarity

Clock polarity.

qspi_clock_phase_t eClkPhase

Clock phase.

qspi_data_shift_direction_t eShiftDirection

MSB or LSB data shift direction.

bool bEnableWiredOrMode

SPI pin configuration, when enabled the SPI pins are configured as open-drain drivers with the pull-ups disabled.

bool bEnableModeFault

Enable/Disable mode fault detect for Slave Select Signal

bool bEnableStrobe

Enable/Disable strobe between data frames irrespective of clock pahse setting

bool bEnableSlaveSelAutoMode

Enable/Disable Slave Select Auto mode.

bool bEnableSlaveSelOpenDrain

Enable the open-drain mode of SPI Pins, otherwise Push-Pull

uint16_t u16DelayBetweenFrameInCLK

The delay between frame.

bool bEnableFIFO

Enable / Disable FIFO for Transmit/Receive

qspi_txfifo_watermark_t eTxFIFOWatermark

Watermark config for Transmit FIFO

qspi_rxfifo_watermark_t eRxFIFOWatermark

Watermark config for Receive FIFO

bool bEnableModule

Enable / Disable module

uint8_t u8Interrupts

Interrupt enabled ORed from `_qspi_interrupt_enable`

uint8_t u8DmaEnableFlags

Configure DMA Enable/Disable for Transmit/Receive

struct __qspi_slave_config

#include <fsl_queued_spi.h> QUEUEDSPI slave configuration structure with all slave configuration fields covered.

Public Members

qspi_data_width_t eDataWidth

Data width in SPI transfer

qspi_clock_polarity_t eClkPolarity

Clock polarity.

qspi_clock_phase_t eClkPhase

Clock phase.

qspi_data_shift_direction_t eShiftDirection

MSB or LSB data shift direction.

bool bEnableWiredOrMode

SPI pin configuration, when enabled the SPI pins are configured as open-drain drivers with the pull-ups disabled.

bool bEnableModeFault

Enable/Disable mode fault detect for Slave Select Signal

bool bEnableSlaveSelOverride

Enable/Disable override Slave Select (SS) signal with Master/Slave Mode config

bool bEnableFIFO

Enable / Disable FIFO for Transmit/Receive

qspi_txfifo_watermark_t eTxFIFOWatermark

Watermark config for Transmit FIFO

qspi_rxfifo_watermark_t eRxFIFOWatermark

Watermark config for Receive FIFO

bool bEnableModule

Enable/Disable Module

uint8_t u8DmaEnableFlags

Configure DMA Enable/Disable for Transmit/Receive

struct __qspi_transfer

#include <fsl_queued_spi.h> QUEUEDSPI master/slave transfer structure.

Public Members

void *pTxData

Transmit buffer.

void *pRxData

Receive buffer.

volatile uint16_t u16DataSize

Transfer bytes.

uint8_t u8ConfigFlags

Transfer configuration flags; set from `_qspi_master_transfer_flag`. This is not used in slave transfer.

struct __qspi_master_handle

#include <fsl_queued_spi.h> QUEUEDSPI master transfer handle structure used for transactional API.

Public Members

QSPI_Type *base

Base address for the QSPI peripheral

qspi_data_width_t eDataWidth

The desired number of bits per frame.

volatile bool bIsPcsActiveAfterTransfer

Indicates whether the PCS signal is active after the last frame transfer; This is not used in slave transfer.

uint8_t *volatile pu8TxData

Send buffer.

uint8_t *volatile pu8RxData

Receive buffer.

volatile uint16_t u16RemainingSendByteCount

A number of bytes remaining to send.

volatile uint16_t u16RemainingReceiveByteCount

A number of bytes remaining to receive.

uint16_t u16TotalByteCount

A number of transfer bytes

volatile uint8_t u8State

QUEUEDSPI transfer state, see `_qspi_transfer_state`.

qspi_master_transfer_callback_t pfCallback

Completion callback.

void *pUserData

Callback user data.

volatile uint16_t u16ErrorCount

Error count for slave transfer, this is not used in master transfer.

2.74 QSPI Peripheral and Driver Overview

2.75 QTMR: Quad Timer Driver

void QTMR_Init(TMR_Type *base, const qtmr_config_t *psConfig)

Initialization Quad Timer module with provided structure.

This function can initial one or more channels of the Quad Timer module.

This examples shows how only initial channel 0.

```

qtmr_config_t sConfig = {0};
qtmr_channel_config_t sChannel0Config;
sConfig.psChannelConfig[0] = &sChannel0Config;
QTMR_GetChannelDefaultConfig(&sChannel0Config);
QTMR_Init(QTMR, sConfig);

```

Note: This API should be called at the beginning of the application using the Quad Timer module.

Parameters

- base – Quad Timer peripheral base address.
- psConfig – Pointer to user's Quad Timer config structure. See `qtmr_config_t`.

void QTMR_Deinit(TMR_Type *base)

De-initialization Quad Timer module.

Parameters

- base – Quad Timer peripheral base address.

void QTMR_GetChannelDefaultConfig(*qtmr_channel_config_t* *psConfig)

Gets an available pre-defined options for Quad Timer channel module's configuration.

This function initializes the channel configuration structure with a free run 16bit timer work setting. The default values are:

```

psConfig->sInputConfig.ePrimarySource = kQTMR_PrimarySrcIPBusClockDivide2;
psConfig->sInputConfig.eSecondarySource = kQTMR_SecondarySrcInputPin0;
psConfig->sInputConfig.eSecondarySourceCaptureMode = kQTMR_SecondarySrcCaptureNoCapture;
psConfig->sInputConfig.bEnableSecondarySrcFaultFunction = false;
psConfig->sInputConfig.eEnableInputInvert = false;
psConfig->sCountConfig.eCountMode = kQTMR_CountPrimarySrcRiseEdge;
psConfig->sCountConfig.eCountLength = kQTMR_CountLengthUntilRollOver;
psConfig->sCountConfig.eCountDir = kQTMR_CountDirectionUp;
psConfig->sCountConfig.eCountTimes = kQTMR_CountTimesRepeat;
psConfig->sCountConfig.eCountLoadMode = kQTMR_CountLoadNormal;
psConfig->sCountConfig.eCountPreload1 = kQTMR_CountPreloadNoLoad;
psConfig->sCountConfig.eCountPreload2 = kQTMR_CountPreloadNoLoad;
psConfig->sOutputConfig.eOutputMode = kQTMR_OutputAssertWhenCountActive;
psConfig->sOutputConfig.eOutputValueOnForce = kQTMR_OutputValueClearOnForce;
psConfig->sOutputConfig.bEnableOutputInvert = false;
psConfig->sOutputConfig.bEnableSwForceOutput = false;
psConfig->sOutputConfig.bEnableOutputPin = false;
psConfig->sCooperationConfig.bEnableMasterReInit = false;
psConfig->sCooperationConfig.bEnableMasterForceOFLAG = false;
psConfig->sCooperationConfig.bEnableMasterMode = false;
psConfig->eDebugMode = kQTMR_DebugRunNormal;
psConfig->u16EnabledInterruptMask = 0x0U;
psConfig->u16EnabledDMAMask = 0x0U;
psConfig->u16Comp1 = 0x0U;
psConfig->u16Comp2 = 0x0U;
psConfig->u16Comp1Preload = 0x0U;
psConfig->u16Comp1Preload = 0x0U;
psConfig->u16Load = 0x0U;
psConfig->u16Count = 0x0U;
psConfig->bEnableChannel = false;

```

Parameters

- psConfig – Pointer to user's Quad Timer channel config structure. See `qtmr_channel_config_t`.

```
void QTMR_SetupChannleConfig(TMR_Type *base, qtmr_channel_number_t eChannelNumber,  
                             const qtmr_channel_config_t *psConfig)
```

Setup a Quad Timer channel with provided structure.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- psConfig – Pointer to user's Quad Timer channel config structure. See `qtmr_channel_config_t`.

```
static inline void QTMR_SetPrimaryCountSource(TMR_Type *base, qtmr_channel_number_t  
                                              eChannelNumber,  
                                              qtmr_channel_primary_count_source_t  
                                              ePrimarySource)
```

Sets primary input source.

This function select the primary input source, it can select from “input pin 0~3”, “channel output

0~3” and “IP bus clock prescaler”.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- ePrimarySource – The primary input source. See `qtmr_channel_primary_count_source_t`.

```
static inline void QTMR_SetSecondaryCountSource(TMR_Type *base, qtmr_channel_number_t  
                                              eChannelNumber,  
                                              qtmr_channel_secondary_count_source_t  
                                              source)
```

Sets secondary input source.

This function select the secondary input source, it can select from “input pin 0~3”.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- source – The Secondary input source. See `qtmr_channel_secondary_count_source_t`.

```
void QTMR_SetSecondarySourceInputCaptureMode(TMR_Type *base, qtmr_channel_number_t  
                                              eChannelNumber,  
                                              qtmr_channel_secondary_source_capture_mode_t  
                                              eCaptureMode)
```

Sets secondary input capture mode.

This function select the capture mode for secondary input, it can select from “disable capture”, “capture on rising/falling edge” and “capture on both edges”. Need enable capture mode when input edge interrupt is needed.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- eCaptureMode – The capture mode of secondary input. See `qtmr_channel_secondary_source_capture_mode_t`.

```
static inline void QTMR_EnableSecondarySourceFault(TMR_Type *base, qtmr_channel_number_t  
                                                    eChannelNumber, bool bEnable)
```

Enables/Disables secondary input source signal fault feature.

Enable fault feature will make secondary input acts as a fault signal so that the channel output signal (OFLAG) is cleared when the secondary input is set.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- bEnable – Enable the feature or not.
 - **true** Enable secondary source fault feature.
 - **false** Disable secondary source fault feature.

```
static inline void QTMR_EnableInputInvert(TMR_Type *base, qtmr_channel_number_t  
                                           eChannelNumber, bool bEnable)
```

Enables/Disables input pin signal polarity invert feature.

This function enables/disables input pin signal polarity invert feature.

Note: Invert feature only affects “input pin 0~3”, and acts on the channel input node, not the input pin, so it only affect current channel and not share by other channel

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- bEnable – Enable the feature or not.
 - **true** Invert input pin signal polarity.
 - **false** No invert for input pin signal polarity.

```
static inline void QTMR_SetInputFilter(TMR_Type *base, qtmr_input_pin_t ePin, uint8_t  
                                       u8Count, uint8_t u8Period)
```

Sets input filter for one input pin.

Sets input filter if the input signal is noisy.

Note: The input filter acts on the input pin directly, so the input filter config will affect all channels that select this input pin as source. Turning on the input filter(setting `FILT_PER`

to a non-zero value) introduces a latency of $((u8Count + 3) \times u8Period) + 2$ IP bus clock periods.

Parameters

- base – Quad Timer peripheral base address.
- ePin – Quad Timer input pin number. See `qtmr_input_pin_t`.
- u8Count – Range is 0~7, represent the number of consecutive samples that must agree prior to the input filter accepting an input transition. Actual consecutive samples numbers is $(u8Count + 3)$.
- u8Period – Represent the sampling period (in IP bus clock cycles) of the input pin signals. Each input is sampled multiple times at the rate specified by this field. If u8Period is 0, then the input pin filter is bypassed.

```
static inline uint16_t QTMR_GetInputPinValueInSecondarySource(TMR_Type *base,  
                                                             qtmr_channel_number_t  
                                                             eChannelNumber)
```

Gets the external input signal value selected via the secondary input source.

This function read the value of the secondary input source, the input pin IPS and filtering have been applied to the read back value.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.

Returns

The state of the current state of the external input pin selected via the secondary count source after application of IPS and filtering.

```
void QTMR_SetCountMode(TMR_Type *base, qtmr_channel_number_t eChannelNumber,  
                       qtmr_channel_count_mode_t eCountMode)
```

Sets channel count mode.

This function select channel basic count mode which trigger by primary input or/and secondary input events.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- eCountMode – The mode of operation for the count. See `qtmr_channel_count_mode_t`.

```
static inline void QTMR_SetCountLength(TMR_Type *base, qtmr_channel_number_t  
                                       eChannelNumber, qtmr_channel_count_length_t  
                                       eLength)
```

Sets channel count length.

This function select channel single count length from “until roll over” or “until compare”. “until roll over” means count until 0xFFFF, “until compare” means count until reach COMP1 (for count up) or COMP2 (for count up) value (unless the output signal is in alternating compare mode, this mode make channel use COMP1 and COMP2 alternately).

Parameters

- base – Quad Timer peripheral base address.

- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `eLength` – The channel count length. See `qtmr_channel_count_length_t`.

```
static inline void QTMR_SetCountDirection(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, qtmr_channel_count_direction_t
                                         eDirection)
```

Sets channel count direction.

This function select channel count direction from “count up” or “count down”. Under normal count mode, this function decide the count direction directly, when chose “secondary specifies direction” count mode, count direction decide by “the secondary input level” XOR with “the function selection”.

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `eDirection` – The channel count direction. See `qtmr_channel_count_direction_t`.

```
static inline qtmr_channel_count_direction_t QTMR_GetCountDirection(TMR_Type *base,
                                                                    qtmr_channel_number_t
                                                                    eChannelNumber)
```

Gets channel count direction.

This function read the channel count direction of the last count during quadrature encoded count mode.

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.

Returns

The direction of the last count. Value see `qtmr_channel_count_direction_t`.

```
static inline void QTMR_SetCountTimes(TMR_Type *base, qtmr_channel_number_t
                                       eChannelNumber, qtmr_channel_count_times_t
                                       eTimes)
```

Sets channel count times.

This function select channel count times from “once” or “repeatedly”. If select “once” with “until compare”, channel will stop when reach COMP1 (for count up) or COMP2 (for count up) (unless the output signal is in alternating compare mode, this mode will make channel reaching COMP1, re-initializes then count reaching COMP2, and then stops).

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `eTimes` – The channel count times. See `qtmr_channel_count_times_t`.

```
static inline void QTMR_SetCountLoadMode(TMR_Type *base, qtmr_channel_number_t
                                          eChannelNumber,
                                          qtmr_channel_count_load_mode_t eLoadMode)
```

Sets channel count load mode.

This function select channel count re-initialized load mode from “normal” or “alternative”. “normal” means channel counter re-initialized from LOAD register when compare event, “alternative” means channel counter can re-initialized from LOAD (count up) or CMPLD2 (count down) when compare event.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- eLoadMode – The channel count load mode. See `qtmr_channel_count_load_mode_t`.

```
static inline void QTMR_SetCompare1PreloadControl(TMR_Type *base, qtmr_channel_number_t
                                                eChannelNumber,
                                                qtmr_channel_count_preload_mode_t
                                                ePreloadMode)
```

Sets channel preload mode for compare register 1.

This function select channel preload mode for compare register 1. Default the COMP1 register never preload, when enabled, the COMP1 can preload from CMPLD1 register when COMP1 or COMP2 compare event.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- ePreloadMode – The compare register 1 preload mode. See `qtmr_channel_count_preload_mode_t`.

```
static inline void QTMR_SetCompare2PreloadControl(TMR_Type *base, qtmr_channel_number_t
                                                eChannelNumber,
                                                qtmr_channel_count_preload_mode_t
                                                ePreloadMode)
```

Sets channel preload mode for compare register 2.

This function select channel preload mode for compare register 2. Default the COMP2 register never preload, when enabled, the COMP2 can preload from CMPLD2 register when COMP1 or COMP2 compare event.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- ePreloadMode – The compare register 2 preload mode. See `qtmr_channel_count_preload_mode_t`.

```
static inline void QTMR_SetCompare1PreloadValue(TMR_Type *base, qtmr_channel_number_t
                                                eChannelNumber, uint16_t
                                                u16Comp1Preload)
```

Sets channel compare register 1 preload register value.

This function set the CMPLD1 register value. The COMP1 can preload from CMPLD1 register when preload mode is not “never preload”.

Parameters

- base – Quad Timer peripheral base address.

- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Comp1Preload – Value for Channel compare register 1 preload register.

```
static inline void QTMR_SetCompare2PreloadValue(TMR_Type *base, qtmr_channel_number_t
                                                eChannelNumber, uint16_t
                                                u16Comp2Preload)
```

Sets channel compare register 2 preload register value.

This function set the CMPLD2 register value. The COMP2 can preload from CMPLD2 register when preload mode is not “never preload”.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Comp2Preload – Value for Channel compare register 2 preload register.

```
static inline void QTMR_SetLoadValue(TMR_Type *base, qtmr_channel_number_t
                                     eChannelNumber, uint16_t u16Load)
```

Sets channel load register value.

This function set the LOAD register value. The channel will re-initialize the counter value with this register after counter compare or overflow event.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Load – Value used to initialize the counter after counter compare or overflow event.

```
static inline void QTMR_SetCompare1Value(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, uint16_t u16Comp1)
```

Sets channel count compare register 1.

This function set the COMP1 register value. It use to trigger compare event in count up mode or alternating compare mode.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Comp1 – Value for Channel compare register 1.

```
static inline void QTMR_SetCompare2Value(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, uint16_t u16Comp2)
```

Sets channel count compare register 2.

This function set the COMP2 register value. It use to trigger compare event in count down mode or alternating compare mode.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.

- u16Comp2 – Value for Channel compare register 2.

```
static inline uint16_t QTMR_ReadCaptureValue(TMR_Type *base, qtmr_channel_number_t  
                                             eChannelNumber)
```

Gets channel capture register value.

This function read the CAPT register value, which store the real-time channel counter value when input capture event.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See qtmr_channel_number_t.

Returns

The value captured from the channel counter.

```
static inline uint16_t QTMR_GetHoldValue(TMR_Type *base, qtmr_channel_number_t  
                                         eChannelNumber)
```

Gets channel hold register value.

This function read the HOLD register value, which stores the channel counter's values of specific channels whenever any of the four channels within a module is read.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See qtmr_channel_number_t.

Returns

The channel counter value when any read operation occurs.

```
static inline void QTMR_SetCounterValue(TMR_Type *base, qtmr_channel_number_t  
                                        eChannelNumber, uint16_t u16Count)
```

Sets channel counter register value.

This function set the CNTR register value, the channel will start counting based on this value.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See qtmr_channel_number_t.
- u16Count – The channel counter initialize value.

```
static inline uint16_t QTMR_GetCounterValue(TMR_Type *base, qtmr_channel_number_t  
                                             eChannelNumber)
```

Reads channel counter register value.

This function read the CNTR register value, which stores the channel real-time channel counting value. This read operation will trigger HOLD register update.

Note: User can call the utility macros provided in fsl_common.h to convert ticks to usec or msec.

Parameters

- base – Quad Timer peripheral base address.

- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.

Returns

The real-time channel counter value.

```
static inline void QTMR_SetOutputMode(TMR_Type *base, qtmr_channel_number_t
                                     eChannelNumber, qtmr_channel_output_mode_t
                                     eOutputMode)
```

Sets Channel output signal (OFLAG) work mode.

This function select channel output signal (OFLAG) work mode base on different channel event.

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `eOutputMode` – The mode of operation for the OFLAG output signal. See `qtmr_channel_output_mode_t`.

```
static inline void QTMR_SetOutputValueOnForce(TMR_Type *base, qtmr_channel_number_t
                                              eChannelNumber,
                                              qtmr_channel_output_value_on_force_t eValue)
```

Sets the value of output signal when a force event occurs.

This function config the value of output signal when a force event occurs. Force events can be a software command or compare event from a master channel.

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `eValue` – The value of output signal when force event occur. See `qtmr_channel_output_value_on_force_t`.

```
static inline void QTMR_EnableOutputInvert(TMR_Type *base, qtmr_channel_number_t
                                           eChannelNumber, bool bEnable)
```

Enables/Disables output signal polarity invert feature.

This function enables/disables the invert feature of output signal (OFLAG).

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `bEnable` – Enable the feature or not.
 - **true** Invert output signal polarity.
 - **false** No invert for output signal polarity.

```
static inline void QTMR_EnableSwForceOutput(TMR_Type *base, qtmr_channel_number_t
                                           eChannelNumber)
```

Enables software triggers a FORCE command to output signal.

This function uses a software command to trigger force event, which can force the current value of SCTRL[VAL] bit to be written to the OFLAG output.

Note: This function can be called only if the counter is disabled.

```
QTMR_SetOutputValueOnForce(QTMR, kQTMR_Channel0, kQTMR_OutputValueSetOnForce);
QTMR_EnableSwForceOutput(QTMR, kQTMR_Channel0);
```

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.

```
static inline void QTMR_EnableOutputPin(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, bool bEnable)
```

Enables/Disables output signal (OFLAG) drive on the external pin feature.

This function enables/disables output signal (OFLAG) drive on the external pin feature.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- bEnable – Enable the feature or not.
 - **true** The output signal is driven on the external pin.
 - **false** The external pin is configured as an input.

```
static inline void QTMR_EnableMasterMode(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, bool bEnable)
```

Enables/Disables channel master mode.

This function enables/disables channel master mode.

Note: Master channel can broadcast compare event to all channels within the module to re-initialize channel and/or force channel output signal.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- bEnable – Enable the feature or not.
 - **true** Enables channel master mode.
 - **false** Disables channel master mode.

```
static inline void QTMR_EnableMasterForceOFLAG(TMR_Type *base, qtmr_channel_number_t
                                                eChannelNumber, bool bEnable)
```

Enables/Disables force the channel output signal (OFLAG) state by master channel compare event.

This function enables/disables the compare event from master channel within the same module to force the state of this channel OFLAG output signal.

Parameters

- base – Quad Timer peripheral base address.

- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `bEnable` – Enable the feature or not.
 - **true** Enables OFLAG state to be forced by master channel compare event.
 - **false** Disables OFLAG state to be forced by master channel compare event.

```
static inline void QTMR_EnableMasterReInit(TMR_Type *base, qtmr_channel_number_t
                                          eChannelNumber, bool bEnable)
```

Enables/Disables channel be re-initialized by master channel compare event feature.

This function enables/disables the compare event from master channel within the same module to force the re-initialization of this channel.

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `bEnable` – Enable the feature or not.
 - **true** Enables channel be re-initialized by master channel compare event.
 - **false** Disables channel be re-initialized by master channel compare event.

```
static inline void QTMR_EnableDma(TMR_Type *base, qtmr_channel_number_t
                                 eChannelNumber, uint16_t u16Mask)
```

Enables the Quad Timer DMA request according to a provided mask.

This function enables the Quad Timer DMA request according to a provided mask. The mask is a logical OR of enumerators members. See `_qtmr_channel_dma_enable`. This examples shows how to enable compare 1 register preload DMA request and compare 2 register preload DMA request.

```
QTMR_EnableDma((QTMR, kQTMR_Channel0, kQTMR_Compare1PreloadDmaEnable | kQTMR_
↳ Compare2PreloadDmaEnable);
```

Parameters

- `base` – Quad Timer peripheral base address.
- `eChannelNumber` – Quad Timer channel number. See `qtmr_channel_number_t`.
- `u16Mask` – The QTMR DMA requests to enable. Logical OR of `_qtmr_channel_dma_enable`.

```
static inline void QTMR_DisableDma(TMR_Type *base, qtmr_channel_number_t
                                   eChannelNumber, uint16_t u16Mask)
```

Disables the Quad Timer DMA request according to a provided mask.

This function disables the Quad Timer DMA request according to a provided mask. The mask is a logical OR of enumerators members. See `_qtmr_channel_dma_enable`. This examples shows how to disable compare 1 register preload DMA request and compare 2 register preload DMA request.

```
QTMR_DisableDma((QTMR, kQTMR_Channel0, kQTMR_Compare1PreloadDmaEnable | kQTMR_
↳ Compare2PreloadDmaEnable);
```

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Mask – The QTMR DMA requests to disable. Logical OR of `_qtmr_channel_dma_enable`.

```
static inline void QTMR_EnableInterrupts(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, uint16_t u16Mask)
```

Enables the Quad Timer interrupts according to a provided mask.

This function enables the Quad Timer interrupts according to a provided mask. The mask is a logical OR of enumerators members. See `_qtmr_channel_interrupt_enable`. This examples shows how to enable compare 1 interrupt and compare 2 interrupt.

```
QTMR_EnableInterrupts((QTMR, kQTMR_Channel0, kQTMR_Compare1InterruptEnable |
↪kQTMR_Compare2InterruptEnable);
```

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Mask – The QTMR DMA interrupts to enable. Logical OR of `_qtmr_channel_interrupt_enable`.

```
static inline void QTMR_DisableInterrupts(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, uint16_t u16Mask)
```

Disables the Quad Timer interrupts according to a provided mask.

This function disables the Quad Timer interrupts according to a provided mask. The mask is a logical OR of enumerators members. See `_qtmr_channel_interrupt_enable`. This examples shows how to disable compare 1 interrupt and compare 2 interrupt.

```
QTMR_DisableInterrupts((QTMR, kQTMR_Channel0, kQTMR_Compare1InterruptEnable |
↪kQTMR_Compare2InterruptEnable);
```

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- u16Mask – The QTMR DMA interrupts to disable. Logical OR of `_qtmr_channel_interrupt_enable`.

```
static inline uint16_t QTMR_GetStatusFlags(TMR_Type *base, qtmr_channel_number_t
                                           eChannelNumber)
```

Gets the Quad Timer status flags.

This function gets all QTMR channel status flags. The flags are returned as the logical OR value of the enumerators `_qtmr_channel_status_flags`. To check for a specific status, compare the return value with enumerators in the `_qtmr_channel_status_flags`. For example, to check whether the compare flag set.

```
if((QTMR_GetStatusFlags(QTMR, kQTMR_Channel0) & kQTMR_CompareFlag) != 0U)
{
    ...
}
```

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.

Returns

The QTMR status flags which is the logical OR of the enumerators `_qtmr_channel_status_flags`.

```
static inline void QTMR_ClearStatusFlags(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, uint16_t u16Mask)
```

Clears the Quad Timer status flags.

This function clears QTMR channel status flags with a provide mask. The mask is a logical OR of enumerators `_qtmr_channel_status_flags`. This examples shows how to clear compare 1 flag and compare 2 flag.

```
QTMR_ClearStatusFlags((QTMR, kQTMR_Channel0, kQTMR_Compare1Flag | kQTMR_
↳ Compare2Flag);
```

Parameters

- base – Quad Timer peripheral base address
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`
- u16Mask – The QTMR status flags to clear. Logical OR of `_qtmr_channel_status_flags`

```
static inline void QTMR_SetDebugActions(TMR_Type *base, qtmr_channel_number_t
                                         eChannelNumber, qtmr_channel_debug_action_t
                                         eDebugMode)
```

Sets channel debug actions.

This function selects the certain actions which will perform when the chip entering debug mode.

Parameters

- base – Quad Timer peripheral base address.
- eChannelNumber – Quad Timer channel number. See `qtmr_channel_number_t`.
- eDebugMode – The Quad Timer channel actions in response to the chip entering debug mode. See `qtmr_channel_debug_action_t`.

```
static inline void QTMR_EnableChannels(TMR_Type *base, uint16_t u16Mask)
```

Enables the Quad Timer channels according to a provided mask.

This function enables the Quad Timer channels according to a provided mask. The mask is a logical OR of enumerators `_qtmr_channel_enable`. This examples shows how to enable channel 0 and channel 1.

```
QTMR_EnableChannels(QTMR, kQTMR_Channel0Enable | kQTMR_Channel1Enable);
```

Note: If one channel has effective count mode, it will start its counter as soon as the channel be enabled.

Parameters

- `base` – Quad Timer peripheral base address.
- `u16Mask` – The QTMR channels to enable. Logical OR of `_qtmr_channel_enable`.

static inline void QTMR_DisableChannels(TMR_Type *base, uint16_t u16Mask)

Disables the Quad Timer channels according to a provided mask.

This function disables the Quad Timer channels according to a provided mask. The mask is a logical OR of enumerators `_qtmr_channel_enable`. This examples shows how to disable channel 0 and channel 1.

```
QTMR_DisableChannels(QTMR, kQTMR_Channel0Enable | kQTMR_Channel1Enable);
```

Parameters

- `base` – Quad Timer peripheral base address.
- `u16Mask` – The QTMR channels to enable. Logical OR of `_qtmr_channel_enable`.

static inline uint32_t TMR_GetCaptureRegAddr(TMR_Type *base, *qtmr_channel_number_t* nChannel)

Gets the TMR capture register address. This API is used to provide the transfer address for TMR capture transfer.

Parameters

- `base` – TMR base pointer
- `nChannel` – Quad Timer channel number. See `qtmr_channel_number_t`.

Returns

capture register address

FSL_QTMR_DRIVER_VERSION

QTMR driver version.

enum `_qtmr_input_pin`

The enumeration for Quad Timer module input pin source.

Values:

enumerator `kQTMR_InputPin0`

Quad Timer input pin 0.

enumerator `kQTMR_InputPin1`

Quad Timer input pin 1.

enumerator `kQTMR_InputPin2`

Quad Timer input pin 2.

enumerator `kQTMR_InputPin3`

Quad Timer input pin 3.

enum `_qtmr_channel_number`

The enumeration for Quad Timer module channel number.

Values:

enumerator `kQTMR_Channel0`

Quad Timer Channel 0.

enumerator `kQTMR_Channel1`

Quad Timer Channel 1.

enumerator kQTMR_Channel2
Quad Timer Channel 2.

enumerator kQTMR_Channel3
Quad Timer Channel 3.

enum __qtmr_channel_primary_count_source

The enumeration for Quad Timer channel primary input source.

Values:

enumerator kQTMR_PrimarySrcInputPin0
Quad Timer input pin 0.

enumerator kQTMR_PrimarySrcInputPin1
Quad Timer input pin 1.

enumerator kQTMR_PrimarySrcInputPin2
Quad Timer input pin 2.

enumerator kQTMR_PrimarySrcInputPin3
Quad Timer input pin 3.

enumerator kQTMR_PrimarySrcChannel0Output
Quad Timer channel 0 output.

enumerator kQTMR_PrimarySrcChannel1Output
Quad Timer channel 1 output.

enumerator kQTMR_PrimarySrcChannel2Output
Quad Timer channel 2 output.

enumerator kQTMR_PrimarySrcChannel3Output
Quad Timer channel 3 output.

enumerator kQTMR_PrimarySrcIPBusClockDivide1
IP bus clock divide by 1.

enumerator kQTMR_PrimarySrcIPBusClockDivide2
IP bus clock divide by 2.

enumerator kQTMR_PrimarySrcIPBusClockDivide4
IP bus clock divide by 4.

enumerator kQTMR_PrimarySrcIPBusClockDivide8
IP bus clock divide by 8.

enumerator kQTMR_PrimarySrcIPBusClockDivide16
IP bus clock divide by 16.

enumerator kQTMR_PrimarySrcIPBusClockDivide32
IP bus clock divide by 32.

enumerator kQTMR_PrimarySrcIPBusClockDivide64
IP bus clock divide by 64.

enumerator kQTMR_PrimarySrcIPBusClockDivide128
IP bus clock divide by 128.

enum __qtmr_channel_secondary_count_source

The enumeration for Quad Timer channel secondary input source.

Values:

enumerator kQTMR_SecondarySrcInputPin0

Quad Timer input pin 0.

enumerator kQTMR_SecondarySrcInputPin1

Quad Timer input pin 1.

enumerator kQTMR_SecondarySrcInputPin2

Quad Timer input pin 2.

enumerator kQTMR_SecondarySrcInputPin3

Quad Timer input pin 3.

enum _qtmr_channel_secondary_source_capture_mode

The enumeration for Quad Timer channel secondary input source capture mode.

Values:

enumerator kQTMR_SecondarySrcCaptureNoCapture

Secondary source capture is disabled.

enumerator kQTMR_SecondarySrcCaptureRisingEdge

Secondary source capture on rising edge.

enumerator kQTMR_SecondarySrcCaptureFallingEdge

Secondary source capture on falling edge.

enumerator kQTMR_SecondarySrcCaptureRisingAndFallingEdge

Secondary source capture on both edges.

enumerator kQTMR_SecondarySrcCaptureRisingEdgeWithReload

Secondary source capture on rising edge while cause the channel to be reloaded.

enumerator kQTMR_SecondarySrcCaptureFallingEdgeWithReload

Secondary source capture on falling edge while cause the channel to be reloaded.

enumerator kQTMR_SecondarySrcCaptureRisingAndFallingEdgeWithReload

Secondary source capture on both edges while cause the channel to be reloaded.

enum _qtmr_channel_count_mode

The enumeration for Quad Timer channel count mode.

When “channel output 0~3” or “IP bus clock prescaler” is chosen, active edge is the rising edge. When “input pin 0~3” is chosen, active edge and active level is determined by input invert feature (IPS). Disable input invert feature means active edge is rising edge, active level is high level, enable input invert feature means active edge is falling edge, active level is low level.

Values:

enumerator kQTMR_CountNoOperation

No operation.

enumerator kQTMR_CountPrimarySrcRiseEdge

Count active edge of primary input source.

enumerator kQTMR_CountPrimarySrcRiseAndFallEdge

Count rising and falling edges of primary input source.

enumerator kQTMR_CountPrimarySrcRiseEdgeSecondarySrcInHigh

Count active edge of primary input source when secondary input is at a active level.

enumerator kQTMR_CountPrimarySecondarySrcInQuadDecode

Quadrature count mode, uses primary and secondary sources.

enumerator kQTMR_CountPrimarySrcRiseEdgeSecondarySrcDir

Count active edge of primary input source; secondary input source specifies count direction.

enumerator kQTMR_CountPrimarySrcRiseEdgeSecondarySrcRiseEdgeTrig

The active edge of secondary input source triggers count active edge of primary input source, and the channel counter will stop upon receiving a second trigger event while it's still counting from the first trigger event.

enumerator kQTMR_CountCascadeWithOtherChannel

Cascaded count mode, the channel will count as compare events occur in the selected source channel (use a special high-speed signal path rather than the OFLAG output signal). The active edge of secondary input source triggers count active edge of primary input source, and the channel counter will re-initialized upon receiving a second trigger event while it's still counting from the first trigger event.

enumerator kQTMR_CountPrimarySrcRiseEdgeSecondarySrcRiseEdgeTrigWithReInit

enum __qtmr_channel_count_length

The enumeration for Quad Timer channel count length.

Values:

enumerator kQTMR_CountLengthUntilRollOver

Count until roll over at \$FFFF.

enumerator kQTMR_CountLengthUntilCompare

Count until compare.

enum __qtmr_channel_count_direction

The enumeration for Quad Timer channel count direction.

Values:

enumerator kQTMR_CountDirectionUp

Count direction up.

enumerator kQTMR_CountDirectionDown

Count direction down.

enum __qtmr_channel_count_times

The enumeration for Quad Timer channel count times.

Values:

enumerator kQTMR_CountTimesRepeat

Count repeatedly.

enumerator kQTMR_CountTimesOnce

Count time once.

enum __qtmr_channel_count_load_mode

The enumeration for Quad Timer channel count load mode.

Values:

enumerator kQTMR_CountLoadNormal

Count can be re-initialized only with the LOAD register when match event occurs.

enumerator kQTMR_CountLoadAlternative

Channel can be re-initialized with the LOAD register when count up and a match with COMP1 occurs, or with CMPLD2 register when count down and a match with COMP2 occurs.

enum `_qtmr_channel_count_preload_mode`

The enumeration for Quad Timer channel COMP1 & COMP2 preload mode.

Values:

enumerator `kQTMR_CountPreloadNoLoad`

Not load CMPLDn into COMPn register when compare event occurs.

enumerator `kQTMR_CountPreloadOnComp1CompareEvent`

Load CMPLDn register into COMPn when occurs a successful comparison of channel counter value and the COMP1 register.

enumerator `kQTMR_CountPreloadOnComp2CompareEvent`

Load CMPLDn register into COMPn when occurs a successful comparison of channel counter value and the COMP2 register.

enum `_qtmr_channel_output_mode`

The enumeration for Quad Timer channel output signal (OFLAG signal) work mode.

Values:

enumerator `kQTMR_OutputAssertWhenCountActive`

OFLAG output assert while counter is active.

enumerator `kQTMR_OutputClearOnCompare`

OFLAG output clear on successful compare.

enumerator `kQTMR_OutputSetOnCompare`

OFLAG output set on successful compare.

enumerator `kQTMR_OutputToggleOnCompare`

OFLAG output toggle on successful compare.

enumerator `kQTMR_OutputToggleOnAltCompareReg`

OFLAG output toggle using alternating compare registers.

enumerator `kQTMR_OutputSetOnCompareClearOnSecSrcActiveEdge`

OFLAG output set on compare, clear on secondary source input edge.

enumerator `kQTMR_OutputSetOnCompareClearOnCountRoll`

OFLAG output set on compare, clear on counter rollover.

enumerator `kQTMR_OutputGateClockOutWhenCountActive`

OFLAG output gated while count is active.

enum `_qtmr_qtmr_channel_output_value_on_force`

The enumeration for Quad Timer channel output signal (OFLAG) value on force event occur.

Values:

enumerator `kQTMR_OutputValueClearOnForce`

OFLAG output clear (low) when software triggers a FORCE command or master channel force the OFLAG (EEOF need set).

enumerator `kQTMR_OutputValueSetOnForce`

OFLAG output set (high) when software triggers a FORCE command or master channel force the OFLAG (EEOF need set).

enum `_qtmr_channel_debug_action`

The enumeration for Quad Timer channel run options when the chip entering debug mode.

Values:

enumerator kQTMR__DebugRunNormal

Continue with normal operation.

enumerator kQTMR__DebugHaltCounter

Halt counter.

enumerator kQTMR__DebugForceOutToZero

Force output to logic 0.

enumerator kQTMR__DebugHaltCountForceOutZero

Halt counter and force output to logic 0.

enum __qtmr_channel_interrupt_enable

The enumeration for Quad Timer channel interrupts.

Values:

enumerator kQTMR__CompareInterruptEnable

Compare interrupt.

enumerator kQTMR__Compare1InterruptEnable

Compare 1 interrupt.

enumerator kQTMR__Compare2InterruptEnable

Compare 2 interrupt.

enumerator kQTMR__OverflowInterruptEnable

Timer overflow interrupt.

enumerator kQTMR__EdgeInterruptEnable

Input edge interrupt.

enumerator kQTMR__ALLInterruptEnable

enum __qtmr_channel_status_flags

The enumeration for Quad Timer channel work status.

Values:

enumerator kQTMR__CompareFlag

Compare flag.

enumerator kQTMR__Compare1Flag

Compare 1 flag.

enumerator kQTMR__Compare2Flag

Compare 2 flag.

enumerator kQTMR__OverflowFlag

Timer overflow flag.

enumerator kQTMR__EdgeFlag

Input edge flag.

enumerator kQTMR__StatusAllFlags

enum __qtmr_channel_enable

The enumeration for Quad Timer channel enable.

Values:

enumerator kQTMR__Channel0Enable

Channel 0 enable.

enumerator kQTMR_Channel1Enable
Channel 1 enable.

enumerator kQTMR_Channel2Enable
Channel 2 enable.

enumerator kQTMR_Channel3Enable
Channel 3 enable.

enumerator kQTMR_ALLChannelEnable

enum __qtmr_channel_dma_enable

The enumeration for Quad Timer channel DMA trigger source.

Values:

enumerator kQTMR_InputEdgeFlagDmaEnable
Input edge flag setting will trigger DMA read request for CAPT register.

enumerator kQTMR_Compare1PreloadDmaEnable
Channel load CMPLD1 register into COMP1 will trigger DMA write request for CMPLD1.

enumerator kQTMR_Compare2PreloadDmaEnable
Channel load CMPLD2 register into COMP2 will trigger DMA write request for CMPLD2.

enumerator kQTMR_AllDMAEnable

typedef enum __qtmr_input_pin qtmr_input_pin_t

The enumeration for Quad Timer module input pin source.

typedef enum __qtmr_channel_number qtmr_channel_number_t

The enumeration for Quad Timer module channel number.

typedef enum __qtmr_channel_primary_count_source qtmr_channel_primary_count_source_t

The enumeration for Quad Timer channel primary input source.

typedef enum __qtmr_channel_secondary_count_source qtmr_channel_secondary_count_source_t

The enumeration for Quad Timer channel secondary input source.

typedef enum __qtmr_channel_secondary_source_capture_mode

qtmr_channel_secondary_source_capture_mode_t

The enumeration for Quad Timer channel secondary input source capture mode.

typedef enum __qtmr_channel_count_mode qtmr_channel_count_mode_t

The enumeration for Quad Timer channel count mode.

When “channel output 0~3” or “IP bus clock prescaler” is chosen, active edge is the rising edge. When “input pin 0~3” is chosen, active edge and active level is determined by input invert feature (IPS). Disable input invert feature means active edge is rising edge, active level is high level, enable input invert feature means active edge is falling edge, active level is low level.

typedef enum __qtmr_channel_count_length qtmr_channel_count_length_t

The enumeration for Quad Timer channel count length.

typedef enum __qtmr_channel_count_direction qtmr_channel_count_direction_t

The enumeration for Quad Timer channel count direction.

typedef enum __qtmr_channel_count_times qtmr_channel_count_times_t

The enumeration for Quad Timer channel count times.

typedef enum __qtmr_channel_count_load_mode qtmr_channel_count_load_mode_t

The enumeration for Quad Timer channel count load mode.

typedef enum *_qtmr_channel_count_preload_mode* qtmr_channel_count_preload_mode_t

The enumeration for Quad Timer channel COMP1 & COMP2 preload mode.

typedef enum *_qtmr_channel_output_mode* qtmr_channel_output_mode_t

The enumeration for Quad Timer channel output signal (OFLAG signal) work mode.

typedef enum *_qtmr_qtmr_channel_output_value_on_force*

qtmr_channel_output_value_on_force_t

The enumeration for Quad Timer channel output signal (OFLAG) value on force event occur.

typedef enum *_qtmr_channel_debug_action* qtmr_channel_debug_action_t

The enumeration for Quad Timer channel run options when the chip entering debug mode.

typedef struct *_qtmr_channel_input_config* qtmr_channel_input_config_t

The structure for configuring Quad Timer channel input signal.

typedef struct *_qtmr_channel_count_config* qtmr_channel_count_config_t

The structure for configuring Quad Timer channel counting behaviors.

typedef struct *_qtmr_channel_output_config* qtmr_channel_output_config_t

The structure for configuring Quad Timer channel output signal (OFLAG).

typedef struct *_qtmr_channel_cooperation_config* qtmr_channel_cooperation_config_t

The structure for configuring Quad Timer channel cooperation mode with other channels.

typedef struct *_qtmr_channel_config* qtmr_channel_config_t

Quad Timer channel configuration covering all channel configurable fields.

typedef struct *_qtmr_input_pin_filter_config* qtmr_input_pin_filter_config_t

The structure for configuring Quad Timer module input pin filter.

typedef struct *_qtmr_config* qtmr_config_t

Quad Timer module configuration which contain channel config structure pointers and input pin filter config structure pointers.

Note: Need use channel structure address to init the structure pointers, when the channel or input pin structure pointers is NULL, it will be ignored by QTMR_Init API. This can save stack space when only one or two channels are used.

struct *_qtmr_channel_input_config*

#include <fsl_qtmr.h> The structure for configuring Quad Timer channel input signal.

Public Members

qtmr_channel_primary_count_source_t ePrimarySource

Specify the primary input source.

qtmr_channel_secondary_count_source_t eSecondarySource

Specify the secondary input source.

bool bEnableSecondarySrcFaultFunction

true: The selected secondary input acts as a fault signal which can clear the channel output signal when it is set, false: Fault function disabled.

bool eEnableInputInvert

true: Invert input signal value when select input pin as primary or/and secondary input source false: no operation.

struct *_qtmr_channel_count_config*

#include <fsl_qtmr.h> The structure for configuring Quad Timer channel counting behaviors.

Public Members

qtmr_channel_count_mode_t eCountMode

Configures channel count mode.

qtmr_channel_count_length_t eCountLength

Configures channel count length.

qtmr_channel_count_direction_t eCountDir

Configures channel count direction.

qtmr_channel_count_times_t eCountTimes

Configures channel count times.

qtmr_channel_count_load_mode_t eCountLoadMode

Configures channel count load mode.

struct *_qtmr_channel_output_config*

#include <fsl_qtmr.h> The structure for configuring Quad Timer channel output signal (OFLAG).

Public Members

qtmr_channel_output_mode_t eOutputMode

Configures channel output signal work mode.

qtmr_channel_output_value_on_force_t eOutputValueOnForce

The value of output signal when force event occur.

bool bEnableOutputInvert

True: the polarity of output signal will be inverted, false: The output signal is not inverted.

bool bEnableSwForceOutput

True: forces the current value of eOFLAGValueOnForce to output signal. false: no operation.

bool bEnableOutputPin

True: the output signal is driven on the external pin. false: the external pin is configured as an input.

struct *_qtmr_channel_cooperation_config*

#include <fsl_qtmr.h> The structure for configuring Quad Timer channel cooperation mode with other channels.

Public Members

bool bEnableMasterReInit

true: Master channel within the module can re-initialize this channel when it has a compare event, false: no operation.

bool bEnableMasterForceOFLAG

true: Master channel within the module can force this channel OFLAG signal when it has a compare event, false: no operation.

bool bEnableMasterMode

true: This channel is configured as mater channel, it can broadcast compare event to all channels within the module to re-initialize channel and/or force channel output signal, false: no operation.

struct `_qtmr_channel_config`

#include <fsl_qtmr.h> Quad Timer channel configuration covering all channel configurable fields.

Public Members

qtmr_channel_input_config_t sInputConfig

Configures channel input signal.

qtmr_channel_count_config_t sCountConfig

Configures channel count work mode.

qtmr_channel_output_config_t sOutputConfig

Configures channel output signal (OFLAG) work mode.

qtmr_channel_debug_action_t eDebugMode

Configures channel operation in chip debug mode.

uint16_t u16EnabledInterruptMask

The mask of the interrupts to be enabled, should be the OR'ed of `_qtmr_channel_interrupt_enable`.

uint16_t u16EnabledDMAMask

The mask of the interrupts to be enabled, should be the OR'ed of `_qtmr_channel_dma_enable`.

uint16_t u16Comp1

Value for Channel compare register 1.

uint16_t u16Comp2

Value for Channel compare register 2.

uint16_t u16Comp1Preload

Value for Channel compare 1 preload register.

uint16_t u16Comp2Preload

Value for Channel compare 2 preload register.

uint16_t u16Load

Value for Channel load register.

uint16_t u16Count

Value for Channel counter value register.

bool bEnableChannel

True: enable the channel prescaler (if it is being used) and counter false: disable channel.

struct `_qtmr_input_pin_filter_config`

#include <fsl_qtmr.h> The structure for configuring Quad Timer module input pin filter.

Public Members

uint8_t u8Period

Value for input filter sample period.

uint8_t u8Count

Value for input filter sample count (sample count = count +3).

struct __qtmr_config

#include <fsl_qtmr.h> Quad Timer module configuration which contain channel config structure pointers and input pin filter config structure pointers.

Note: Need use channel structure address to init the structure pointers, when the channel or input pin structure pointers is NULL, it will be ignored by QTMR_Init API. This can save stack space when only one or two channels are used.

2.76 The Driver Change Log

2.77 QTMR Peripheral and Driver Overview

2.78 The Driver Change Log

2.79 SIM: System Integration Module Driver

static inline void SIM_SetWaitModeOperation(SIM_Type *base, sim_wait_mode_operation_t eOperation)

Sets the operation of wait mode, enable/disable the entry of wait mode.

Parameters

- base – SIM peripheral base address.
- eOperation – Used to enable/disable the wait mode, please refer to sim_wait_mode_operation_t.

static inline void SIM_SetStopModeOperation(SIM_Type *base, sim_stop_mode_operation_t eOperation)

Sets the operation of stop mode, enable/disable the entry of stop mode.

Parameters

- base – SIM peripheral base address.
- eOperation – Used to enable/disable the stop mode, please refer to sim_stop_mode_operation_t.

static inline void SIM_EnterLPMode(SIM_Type *base)

Enters into LPMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: Please make sure the power mode register is not set as write protected before invoking this function.

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

static inline void SIM_ExitLPMode(SIM_Type *base)

Exits from LPMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: Please make sure the power mode register is not set as write protected before invoking this function.

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

static inline void SIM_EnterVLPMode(SIM_Type *base)

Enters into VLPMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: Please make sure the power mode register is not set as write protected before invoking this function. If both set to enter LPMode and VLPMode, the VLPMode has higher priority.

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

static inline void SIM_ExitVLPMode(SIM_Type *base)

Exits from VLPMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: Please make sure the power mode register is not set as write protected before invoking this function.

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

static inline bool SIM_IsInLPMode(SIM_Type *base)

Indicates whether the chip is in LPMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

Return values

- true – The chip is in LPMode.
- false – The chip is not in LPMode.

static inline bool SIM_IsInVLPMMode(SIM_Type *base)

Indicates whether the chip is in VLPMMode when the advanced power mode is enabled(register FOPT[1] bit is set).

Note: This function is useful only when the FTFE module's FOPT[0] bit is set(advanced power mode is enabled).

Parameters

- base – SIM peripheral base address.

Return values

- true – The chip is in VLPMMode.
- false – The chip is not in VLPMMode.

static inline void SIM_TriggerSoftwareReset(SIM_Type *base)

Triggers the software reset for device.

Parameters

- base – SIM base address.

static inline uint16_t SIM_GetResetStatusFlags(SIM_Type *base)

Gets the cause of the most recent reset.

Note: At any given time, the only one reset source is indicated. When multiple reset source assert simultaneously, the reset source with the highest precedence is indicated. The precedence from highest to lowest is POR, external reset, COP loss of reference reset, COP CPU time-out reset, software reset, COP window time-out reset. The POR is always set during a power-on reset. However, POR is cleared and the external reset is set if the external reset pin is asserted or remains asserted after the power-on reset has de-asserted.

Parameters

- base – SIM peripheral base address.

Returns

The current reset status flags, should be the OR'ed value of _sim_reset_status_flags.

static inline void SIM_TriggerPeripheralSoftwareReset(SIM_Type *base,
sim_swReset_peri_index_t ePeriIndex)

Triggers the software reset of specific peripheral.

Parameters

- base – SIM peripheral base address.
- ePeriIndex – The index of the peripheral to be reset.

```
static inline void SIM_EnableResetPadCellInputFilter(SIM_Type *base, bool bEnable)
```

Enables/Disables the input filter on external reset padcell.

If the input filter is enabled, the filter will remove transient signals on the input at the expense of an increased input delay.

Note: If the input filter is enabled, the filter will affect all input functions supported by that padcell, including GPIO.

Parameters

- base – SIM peripheral base address.
- bEnable – Used to control the behaviour of input filter.
 - **true** Enable the input filter on external input padcell.
 - **false** Disable the input filter on external input padcell.

```
static inline void SIM_SetInternalPeriInput(SIM_Type *base, sim_internal_peri_index_t eIndex,  
                                           sim_internal_peri_input_t eInput)
```

Sets internal peripheral inputs, some peripheral inputs have the ability to be connected to either XBAR outputs or GPIO.

Parameters

- base – SIM base address.
- eIndex – The internal peripherals that supply multi-inputs.
- eInput – The specific input that connected to the selected internal peripheral.

```
static inline void SIM_SetXbarInputPWMSelection(SIM_Type *base,  
                                              sim_xbar_input_pwm_index_t eIndex,  
                                              sim_xbar_input_pwm_selection_t eSelection)
```

Selects the Xbar input from PWMA and PWMB.

Parameters

- base – SIM base address.
- eIndex – SIM PWM select register field index.
- eSelection – Xbar input pwm selection.

```
static inline void SIM_SetXbarInputAdcTmrSelection(SIM_Type *base,  
                                                  sim_xbar_input_adc_tmr_index_t eIndex,  
                                                  sim_xbar_input_adc_tmr_selection_t  
                                                  eSelection)
```

Selects the Xbar input from ADC and TMR A/B.

Parameters

- base – SIM base address.
- eIndex – SIM ADC and TMR select register field index.
- eSelection – Xbar input ADC and TMR selection.

```
static inline void SIM_SetSmallRegulator1P2VControlMode(SIM_Type *base,  
                                                         sim_small_regulator_1P2V_control_mode_t  
                                                         eControlMode)
```

Sets the control mode of small regulator 1.2V supply, the available control modes are normal mode, standby mode, etc.

Note: This function is useful only when the flash module's FOPT[0] bit is 0.

Parameters

- base – SIM peripheral base address.
- eControlMode – The control mode to be set, please refer to `sim_small_regulator_1P2V_control_mode_t`.

```
static inline void SIM_SetSmallRegulator2P7VControlMode(SIM_Type *base,  
                                                         sim_small_regulator_2P7V_control_mode_t  
                                                         eControlMode)
```

Sets the control mode of small regulator 2.7 supply, the available control modes are normal mode, standby mode, etc.

Note: This function is useful only when the flash module's FOPT[0] bit is 0.

Parameters

- base – SIM peripheral base address.
- eControlMode – The control mode to be set, please refer to `sim_small_regulator_2P7V_control_mode_t`.

```
static inline void SIM_SetLargeRegulatorControlMode(SIM_Type *base,  
                                                     sim_large_regulator_control_mode_t  
                                                     eControlMode)
```

Sets the control mode of large regulator, the available control mode are normal mode, standby mode, etc.

Note: This function is useful only when the flash module's FOPT[0] bit is 0.

Parameters

- base – SIM peripheral base address.
- eControlMode – The control mode to be set, please refer to `sim_large_regulator_control_mode_t`.

```
static inline void SIM_SetRegisterProtectionMode(SIM_Type *base,  
                                                  sim_write_protection_module_t eModule,  
                                                  sim_write_protection_mode_t eMode)
```

Sets the write protection mode of the selected register.

Parameters

- base – SIM peripheral base address.
- eModule – The module to be set, please refer to `sim_write_protection_module_t`.
- eMode – The specific write protection mode to be set, please refer to `sim_write_protection_mode_t`.

```
static inline uint32_t SIM_GetJTAGID(SIM_Type *base)
```

Gets JTAG ID, the JTAG ID is 32bits width.

Parameters

- base – SIM base address.

Returns

The 32bits width JTAG ID.

```
static inline uint8_t SIM_GetPMCBandgapTrim(SIM_Type *base)
```

Gets the trim vlaue of the bandgap inside the PMC module, the available range is 0 to 15.

Parameters

- base – SIM peripheral base address.

Returns

The trim value of PMC's bandgap, ranges from 0 to 15.

```
static inline uint16_t SIM_Get200KHzROSCFreqTrim(SIM_Type *base)
```

Gets the trim value of 200KHz Relaxation Osillator Frequency, the available range is 0 to 511.

Parameters

- base – SIM peripheral base address.

Returns

The trim value of 200 khz Relaxation Oscillator frequency, ranges from 0 to 511.

```
static inline uint8_t SIM_Get8MHzROSCTempTrim(SIM_Type *base)
```

Gets the trim value of 8 MHz Relaxation Oscillator Temperature.

Parameters

- base – SIM peripheral base address.

Returns

The trim value of 8 MHz Relaxation Oscillator Temperature.

```
static inline uint16_t SIM_Get8MHzROSCFreqTrim(SIM_Type *base)
```

Gets the trim value of 8 MHz Relaxation Oscillator Frequency Trim.

Parameters

- base – SIM peripheral base address.

Returns

The trim value of 8 MHz Relaxation Oscillator Frequency Trim.

```
static inline uint16_t SIM_Get32KHzROSCFreqTrim(SIM_Type *base)
```

Gets the trim value of 32KHz Relaxation Osillator Frequency.

Parameters

- base – SIM peripheral base address.

Returns

The trim value of 32 khz Relaxation Oscillator frequency.

```
static inline uint16_t SIM_GetSarAdcBandgapRefCap(SIM_Type *base)
```

Gets the SAR ADC Bandgap Reference Capture.

Parameters

- base – SIM peripheral base address.

Returns

The SAR ADC Bandgap Reference Capture.

```
static inline void SIM_SetIOShortAddressValue(SIM_Type *base, uint32_t
                                              u32IOShortAddressValue)
```

Sets the I/O short address location value which specifies the memory referenced through the I/O short address mode.

The I/O short address mode allows the instruction to specify the lower 6 bits of the address. And the upper 18 bits of the address can be controlled by invoking this function.

Note: The pipeline delay between setting the related register set and using short I/O addressing with the new value is five cycles.

Parameters

- base – SIM base address.
- u32IOShortAddressValue – The value of I/O short address location, this address value should be 24 bits width.

```
static inline uint16_t SIM_GetSoftwareControlData(SIM_Type *base,
                                                  sim_software_ctrl_register_index_t
                                                  eIndex)
```

Gets the software control data by the software control register index.

Parameters

- base – SIM base address.
- eIndex – SIM software control register index.

Returns

Software control registers value.

```
static inline void SIM_SetSoftwareControlData(SIM_Type *base,
                                              sim_software_ctrl_register_index_t eIndex,
                                              uint16_t u16Value)
```

Sets the software control data by the software control register index, the data is for general-purpose use by software.

Parameters

- base – SIM base address.
- eIndex – SIM software control register index.
- u16Value – Software control registers value.

```
static inline void SIM_SetOnCEClockOperationMode(SIM_Type *base,
                                                  sim_onceclk_operation_mode_t
                                                  eOperationMode)
```

Sets the operation mode of the OnCE clock, the available operation modes are always enabled and enabled when the core TAP is enabled.

Parameters

- base – SIM peripheral base address.
- eOperationMode – The operation mode of OnCE clock, please refer to `sim_onceclk_operation_mode_t`.

```
static inline void SIM_SetDMAOperationMode(SIM_Type *base, sim_dma_operation_mode_t
                                           eOperationMode)
```

Sets the operation mode of DMA, such as disabled, enabled in run mode only, etc.

Parameters

- base – SIM peripheral base address.
- eOperationMode – The operation mode to be set, please refer to `sim_dma_operation_mode_t`.

static inline `sim_boot_mode_t` SIM_GetBootMode(`SIM_Type` *base)

Gets the device's boot mode, the available boot modes are ROM boot and NVM flash boot.

Parameters

- base – SIM peripheral base address.

Returns

The device's boot mode, please refer to `sim_boot_mode_t`.

static inline void SIM_SetLPI2C1TriggerSelection(`SIM_Type` *base, `sim_lpi2c_trigger_selection_t` eTriggerSelection)

Sets the trigger selection of lpi2c1, the available selections are master trigger and slave trigger.

This function can be used to selection the LPI2C1 output trigger. If selected as master trigger, the LPI2C1 master will generate an output trigger that can be connected to other peripherals on the device. If selected as slave trigger, the LPI2C1 slave will generate an output trigger that can be connected to other peripherals on the device.

Parameters

- base – SIM peripheral base address.
- eTriggerSelection – The trigger selection to set, please refer to `sim_lpi2c_trigger_selection_t`.

static inline void SIM_SetLPI2C0TriggerSelection(`SIM_Type` *base, `sim_lpi2c_trigger_selection_t` eTriggerSelection)

Sets the trigger selection of lpi2c0, the available selections are master trigger and slave trigger.

This function can be used to selection the LPI2C0 output trigger. If selected as master trigger, the LPI2C0 master will generate an output trigger that can be connected to other peripherals on the device. If selected as slave trigger, the LPI2C0 slave will generate an output trigger that can be connected to other peripherals on the device.

Parameters

- base – SIM peripheral base address.
- eTriggerSelection – The trigger selection to set, please refer to `sim_lpi2c_trigger_selection_t`.

static inline `sim_device_operate_mode_t` SIM_GetDeviceOperateMode(`SIM_Type` *base)

Gets device currently operate mode, the possible result is normal operate mode or fast operate mode.

Parameters

- base – SIM peripheral base address.

Returns

Current device's operate mode.

static inline void SIM_SetDeviceOperateMode(`SIM_Type` *base, `sim_device_operate_mode_t` eOperateMode)

Sets device operate mode, including normal operate mode and fast operate mode.

Note: The setting by invoking this function is valid after executing the software reset. To change the device operation mode, the clock-related settings also need to be changed. Please use this API with caution.

Parameters

- base – SIM peripheral base address.
- eOperateMode – The operate mode to be set, please refer to `sim_device_operate_mode_t`.

static inline void SIM_EnableADCScanControlReorder(SIM_Type *base, bool bEnable)

Enables/Disables the ADC scan control register reorder feature.

Parameters

- base – SIM peripheral base address.
- bEnable – Used to control the ADC scan control register reorder feature.
 - **true** Enable the re-ordering of ADC scan control bits.
 - **false** ADC scan control register works in normal order.

static inline void SIM_SetMasterPIT(SIM_Type *base, `sim_master_pit_selection_t` eMasterPit)

Sets master programmable interval timer.

Parameters

- base – SIM peripheral base address.
- eMasterPit – The master PIT to be selected, please refer to `sim_master_pit_selection_t`.

static inline void SIM_SetBootOverride(SIM_Type *base, `sim_boot_override_mode_t` eMode)

Sets the boot over ride mode, this API can be used to determine the boot option in the next reset excluding POR.

Parameters

- base – SIM peripheral base address.
- eMode – The boot over ride mode.

FSL_SIM_DRIVER_VERSION

SIM driver version.

enum `_sim_reset_status_flags`

The enumeration of system reset status flags, such as power on reset, software reset, etc.

Values:

enumerator `kSIM_PowerONResetFlag`

The Power on reset caused the most recent reset.

enumerator `kSIM_ExternalResetFlag`

The external reset caused the most recent reset, that means the external reset pin was asserted or remained asserted after the power-on reset de-asserted.

enumerator `kSIM_COPLossOfReferenceResetFlag`

The computer operating properly module signaled a PLL loss of reference clock reset caused the most recent reset.

enumerator kSIM_COPCPUTimeOutResetFlag

The computer operating properly module signaled a CPU time-out reset caused the most recent reset.

enumerator kSIM_SoftwareResetFlag

The previous system reset occurred as a result of a software reset

enumerator kSIM_COPWindowTimeOutResetFlag

The previous system reset occurred as a result of a cop_window reset.

enum _sim_stop_mode_operation

The enumeration of stop mode operation can be used to enable/disable stop mode enter.

Values:

enumerator kSIM_STOPInstructionEnterStopMode

Stop mode is entered when the DSC core executes a STOP instruction.

enumerator kSIM_STOPInstructionNotEnterStopMode

The DSC core STOP instruction does not cause entry into stop mode.

enumerator kSIM_STOPInstructionEnterStopModeWriteProtect

Stop mode is entered when the DSC core executes a STOP instruction, and the related register bit field is write protected until the next reset.

enumerator kSIM_STOPInstructionNotEnterStopModeWriteProtect

The DSC core STOP instruction does not cause entry into stop mode, and the related register bit field is write protected until the next reset.

enum _sim_wait_mode_operation

The enumeration of wait mode operation can be used to enable/disable wait mode enter.

Values:

enumerator kSIM_WAITInstructionEnterWaitMode

Wait mode is entered when the DSC core executes a WAIT instruction.

enumerator kSIM_WAITInstructionNotEnterWaitMode

The DSC core WAIT instruction does not cause entry into wait mode.

enumerator kSIM_WAITInstructionEnterWaitModeWriteProtect

Wait mode is entered when the DSC core executes a WAIT instruction, and the related register bit field is write protected until the next reset.

enumerator kSIM_WAITInstructionNotEnterWaitModeWriteProtect

The DSC core WAIT instruction does not cause entry into wait mode, and the related register bit field is write protected until the next reset.

enum _sim_onceclk_operation_mode

The enumeration of OnCE clock operation mode, such as enabled when core TAP is enabled and always enabled.

Values:

enumerator kSIM_OnCEClkEnabledWhenCoreTapEnabled

The OnCE clock to the DSC core is enabled when the core TAP is enabled.

enumerator kSIM_OnCEClkAlwaysEnabled

The OnCE clock to the DSC core is always enabled.

enum _sim_dma_operation_mode

The enumeration of dma operation mode, this enumeration can be used to disable/enable DMA module in different power modes.

Values:

enumerator kSIM_DMADisable

DMA module is disabled.

enumerator kSIM_DMAEnableAtRunModeOnly

DMA module is enabled in run mode only.

enumerator kSIM_DMAEnableAtRunModeWaitMode

DMA module is enabled in run and wait modes only.

enumerator kSIM_DMAEnableAtAllPowerModes

DMA module is enabled in all power modes.

enumerator kSIM_DMADisableWriteProtect

DMA module is disabled and the related register bit field is write protected until the next reset.

enumerator kSIM_DMAEnableAtRunModeOnlyWriteProtect

DMA module is enabled in run mode only and the related bit field is write protected until the next reset.

enumerator kSIM_DMAEnableAtRunModeWaitModeWriteProtect

DMA module is enabled in run and wait modes only and the related register bit field is write protected until the next reset.

enumerator kSIM_DMAEnableAtAllPowerModesWriteProtect

DMA module is enabled in all low power modes and the related register bit field is write protected until the next reset.

enum _sim_boot_mode

The enumeration of device's boot mode, including ROM boot and NVM flash boot.

Values:

enumerator kSIM_BootFromNVMFlash

Indicates the chip is boot from NVM Flash.

enumerator kSIM_BootFromROM

Indicates the chip is boot from ROM.

enum _sim_small_regulator_1P2V_control_mode

The enumeration of small regulator 1P2V control mode, such as normal mode and standby mode.

Values:

enumerator kSIM_SmallRegulator1P2VInNormalMode

Small regulator 1.2V supply placed in normal mode.

enumerator kSIM_SmallRegulator1P2VInStandbyMode

Small regulator 1.2V supply placed in standby mode.

enumerator kSIM_SmallRegulator1P2VInNormalModeWriteProtect

Small regulator 1.2V supply placed in normal mode, and the related register bit field is write protected until the next reset.

enumerator kSIM_SmallRegulator1P2VInStandbyModeWriteProtect

Small regulator 1.2V supply placed in standby mode, and the related register bit field is write protected until the next reset.

enum _sim_small_regulator_2P7V_control_mode

The enumeration of small regulator 2P7V control mode, such as normal mode, standby mode, powerdown mode, etc.

Values:

enumerator kSIM_SmallRegulator2P7VInNormalMode
Small regulator 2.7V supply placed in normal mode.

enumerator kSIM_SmallRegulator2P7VInStandbyMode
Small regulator 2.7V supply placed in standby mode.

enumerator kSIM_SmallRegulator2P7VInPowerdownMode
Small regulator 2.7V supply placed in powerdown mode.

enumerator kSIM_SmallRegulator2P7VInNormalModeWriteProtect
Small regulator 2.7V supply placed in normal mode and the related bit field is write protected until chip reset.

enumerator kSIM_SmallRegulator2P7VInStandbyModeWriteProtect
Small regulator 2.7V supply placed in standby mode and the related bit field is write protected until chip reset.

enumerator kSIM_SmallRegulator2P7VInPowerdownModeWriteProtect
Small regulator placed in powerdown mode and the related bit field is write protected until chip reset.

enum _sim_large_regulator_control_mode

The enumeration of large regulator control mode, such as normal mode, standby mode.

Values:

enumerator kSIM_LargeRegulatorInNormalMode
Large regulator placed in normal mode.

enumerator kSIM_LargeRegulatorInStandbyMode
Large regulator placed in standby mode.

enumerator kSIM_LargeRegulatorInNormalModeWriteProtect
Large regulator placed in normal mode, and the related register bit field is write protected until chip reset.

enumerator kSIM_LargeRegulatorInStandbyModeWriteProtect
Large regulator placed in standby mode, and the related register bit field is write protected until chip reset.

enum _sim_write_protection_module

The enumeration of modules that support various protection mode.

Values:

enumerator kSIM_GPIOInternalPeripheralSelectProtection
Used to control the protection mode GPSn and IPSn registers in the SIM, all XBAR, EVTG, GPIO_n_PER, GPIO_n_PPMODE, GPIO_n_DRIVE.

enumerator kSIM_PeripheralClockEnableProtection
Used to control the protection mode of PCEn, SDn, PSWRn, and PCR register.

enumerator kSIM_GPIOPortDPProtection
Used to control the protection mode of GPIO_D_PER, GPIO_D_PPMODE, and GPIO_D_DRIVE register.

enumerator kSIM_PowerModeControlWriteProtection
Used to control the protection mode of the PWRMODE register.

enum _sim_write_protection_mode

The enumeration of write protection mode, such as write protection off, write protection on, etc.

Values:

enumerator kSIM_WriteProtectionOff

Write protection off.

enumerator kSIM_WriteProtectionOn

Write protection on.

enumerator kSIM_WriteProtectionOffAndLocked

Write protection off and locked until chip reset.

enumerator kSIM_WriteProtectionOnAndLocked

Write protection on and locked until chip reset.

enum _sim_lpi2c_trigger_selection

The enumeration of lpi2c trigger selection, including slave trigger and master trigger.

Values:

enumerator kSIM_Lpi2cSlaveTrigger

Selects slave trigger.

enumerator kSIM_Lpi2cMasterTrigger

Selects master trigger.

enum _sim_device_operate_mode

The enumeration of device operate mode, including normal mode and fast mode.

Values:

enumerator kSIM_NormalOperateMode

Device in normal operating mode, core:bus frequency as 1:1

enumerator kSIM_FastOperateMode

Device in fast operate mode, core:bus frequency as 2:1

enum _sim_master_pit_selection

The enumeration of master pit.

Values:

enumerator kSIM_PIT0MasterPIT1Slave

PIT0 is master PIT and PIT1 is slave PIT.

enumerator kSIM_PIT1MasterPIT0Slave

PIT0 is master PIT and PIT1 is slave PIT.

typedef enum _sim_stop_mode_operation sim_stop_mode_operation_t

The enumeration of stop mode operation can be used to enable/disable stop mode enter.

typedef enum _sim_wait_mode_operation sim_wait_mode_operation_t

The enumeration of wait mode operation can be used to enable/disable wait mode enter.

typedef enum _sim_onceclk_operation_mode sim_onceclk_operation_mode_t

The enumeration of OnCE clock operation mode, such as enabled when core TAP is enabled and always enabled.

typedef enum _sim_dma_operation_mode sim_dma_operation_mode_t

The enumeration of dma operation mode, this enumeration can be used to disable/enable DMA module in different power modes.

typedef enum _sim_boot_mode sim_boot_mode_t

The enumeration of device's boot mode, including ROM boot and NVM flash boot.

`typedef enum _sim_small_regulator_1P2V_control_mode`

`sim_small_regulator_1P2V_control_mode_t`

The enumeration of small regulator 1P2V control mode, such as normal mode and standby mode.

`typedef enum _sim_small_regulator_2P7V_control_mode`

`sim_small_regulator_2P7V_control_mode_t`

The enumeration of small regulator 2P7V control mode, such as normal mode, standby mode, powerdown mode, etc.

`typedef enum _sim_large_regulator_control_mode sim_large_regulator_control_mode_t`

The enumeration of large regulator control mode, such as normal mode, standby mode.

`typedef enum _sim_write_protection_module sim_write_protection_module_t`

The enumeration of modules that support various protection mode.

`typedef enum _sim_write_protection_mode sim_write_protection_mode_t`

The enumeration of write protection mode, such as write protection off, write protection on, etc.

`typedef enum _sim_lpi2c_trigger_selection sim_lpi2c_trigger_selection_t`

The enumeration of lpi2c trigger selection, including slave trigger and master trigger.

`typedef enum _sim_device_operate_mode sim_device_operate_mode_t`

The enumeration of device operate mode, including normal mode and fast mode.

`typedef enum _sim_master_pit_selection sim_master_pit_selection_t`

The enumeration of master pit.

`FSL_COMPONENT_ID`

`SIM_RESET_STATUS_MASK`

The macro of RESET status bit field mask.

`SIM_PWR_SR27_CONTROL_MODE_MASK`

The definition of the short regulator control mode bit field mask.

`SIM_PWR_SR27_CONTROL_MODE_SHIFT`

The definition of the short regulator control mode bit field shift.

`SIM_PWR_SR27_CONTROL_MODE(x)`

The macro that can be used to set the bit field of PWR register's short regulator bit field.

`SIM_PROT_BIT_FIELD_MASK(moduleName)`

The definition of the PORT register bit field mask.

`SIM_PORT_SET_MODE_PROTECTION_MODE(moduleName, protectionMode)`

The macro that can be used to set module's protection mode.

2.80 The Driver Change Log

2.81 SIM Peripheral and Driver Overview

2.82 XBAR: Inter-Peripheral Crossbar Switch Driver

`void XBARA_Init(XBARA_Type *base)`

Initializes the XBARA module.

This function un-gates the XBARA clock.

Parameters

- `base` – XBARA peripheral address.

`void XBARA_Deinit(XBARA_Type *base)`

Shuts down the XBARA module.

This function disables XBARA clock.

Parameters

- `base` – XBARA peripheral address.

`static inline void XBARA_SetSignalsConnection(XBARA_Type *base, xbar_input_signal_t eInput, xbar_output_signal_t eOutput)`

Sets a connection between the selected XBARA_IN[*] input and the XBARA_OUT[*] output signal.

This function connects the XBARA input to the selected XBARA output. If more than one XBARA module is available, only the inputs and outputs from the same module can be connected.

Example:

```
XBARA_SetSignalsConnection(XBARA, kXBARA_InputPIT_TRG0, kXBARA_
↪OutputDMAMUX18);
```

Parameters

- `base` – XBARA peripheral address.
- `eInput` – XBARA input signal.
- `eOutput` – XBARA output signal.

`static inline void XBARA_SetActiveEdgeDetectMode(XBARA_Type *base, xbar_output_signal_t eOutput, xbara_active_edge_t eActiveEdgeMode)`

Sets active edge detection mode for the XBARA_OUT[*] output signal.

Parameters

- `base` – XBARA peripheral address.
- `eOutput` – XBARA output signal.
- `eActiveEdgeMode` – Active edge mode.

`static inline void XBARA_SetInterruptDMARequestMode(XBARA_Type *base, xbar_output_signal_t eOutput, xbara_request_t eRequest)`

Sets DMA, Interrupt or disabled request generation mode for the XBARA_OUT[*] output signal.

Parameters

- `base` – XBARA peripheral address.
- `eOutput` – XBARA output signal.
- `eRequest` – Request type.

```
void XBARA_SetOutputSignalConfig(XBARA_Type *base, xbar_output_signal_t eOutput, const
                                xbara_control_config_t *psControlConfig)
```

Configures the XBARA output signal edge detection and interrupt/dma features.

This function configures an XBARA control register. The active edge detection and the DMA/IRQ function on the corresponding XBARA output can be set.

Example:

```
xbara_control_config_t userConfig;
userConfig.activeEdge = kXBARA_EdgeRising;
userConfig.requestType = kXBARA_RequestInterruptEnable;
XBARA_SetOutputSignalConfig(XBARA, kXBARA_OutputDMAMUX18, &userConfig);
```

Note: Only a subset of the XBARA output signal can be called with this API. On debug mode code will check whether the output signal eOutput satisfy the requirement.

Parameters

- base – XBARA peripheral address.
- eOutput – XBARA output number.
- psControlConfig – Pointer to structure that keeps configuration of control register.

```
uint16_t XBARA_GetStatusFlags(XBARA_Type *base)
```

Gets the active edge detection status for all XBAR output signal supporting this feature.

This function gets the active edge detect status of all XBARA_OUTs. If the active edge occurs, the return value is asserted. When the interrupt or the DMA functionality is enabled for the XBARA_OUTx, this field is 1 when the interrupt or DMA request is asserted and 0 when the interrupt or DMA request has been cleared.

Parameters

- base – XBARA peripheral address.

Returns

ORed value from all status flag from xbara_status_flag_t.

```
static inline void XBARA_ClearStatusFlags(XBARA_Type *base, uint16_t u16Flags)
```

Clear the edge detection status flags of relative mask.

Parameters

- base – XBARA peripheral address.
- u16Flags – status flags composed from ORed xbara_status_flag_t indicating flags to be cleared.

```
FSL_XBAR_DRIVER_VERSION
```

XBAR driver version.

```
enum _xbara_active_edge
```

XBARA active edge for detection.

Values:

enumerator kXBARA_EdgeNone

Edge detection status bit never asserts.

enumerator kXBARA_EdgeRising

Edge detection status bit asserts on rising edges.

enumerator kXBARA_EdgeFalling

Edge detection status bit asserts on falling edges.

enumerator kXBARA_EdgeRisingAndFalling

Edge detection status bit asserts on rising and falling edges.

enum _xbara_request

XBARA DMA and interrupt configurations. Note it only apply for a subset of XBARA output signal.

Values:

enumerator kXBARA_RequestDisable

Interrupt and DMA are disabled.

enumerator kXBARA_RequestDMAEnable

DMA enabled, interrupt disabled.

enumerator kXBARA_RequestInterruptEnable

Interrupt enabled, DMA disabled.

enum _xbara_status_flag

XBARA status flags.

This provides constants for the XBARA status flags for use in the XBARA functions. The enumerator value is designed to make sure Flags in same register can be created with register value to write/read register.

Values:

enumerator kXBARA_EdgeDetectionOut0Flag

XBAR_OUT0 active edge interrupt flag, sets when active edge detected.

enumerator kXBARA_EdgeDetectionOut1Flag

XBAR_OUT1 active edge interrupt flag, sets when active edge detected.

enumerator kXBARA_EdgeDetectionOut2Flag

XBAR_OUT2 active edge interrupt flag, sets when active edge detected.

enumerator kXBARA_EdgeDetectionOut3Flag

XBAR_OUT3 active edge interrupt flag, sets when active edge detected.

enumerator kXBARA_AllStatusFlags

typedef enum _xbara_active_edge xbara_active_edge_t

XBARA active edge for detection.

typedef enum _xbara_request xbara_request_t

XBARA DMA and interrupt configurations. Note it only apply for a subset of XBARA output signal.

typedef enum _xbara_status_flag xbara_status_flag_t

XBARA status flags.

This provides constants for the XBARA status flags for use in the XBARA functions. The enumerator value is designed to make sure Flags in same register can be created with register value to write/read register.

```
typedef struct _xbara_control_config xbara_control_config_t
```

Defines the configuration structure of the XBARA control register.

This structure keeps the configuration of XBARA control register for one output. Control registers are available only for a few outputs. Not every XBARA module has control registers.

```
XBARA_SELx(base, output)
```

Macro function to extract the XBAR select register address for a given xbar output signal.

```
XBARA_CTRLx(base, output)
```

Macro function to extract the XBAR Ctrl register address for a given xbar output signal.

```
XBARA_SELx_SELn_SHIFT(output)
```

Macro function to get SELn field shift in XBARA_SELx register for a given output signal.

```
XBARA_SELx_SELn_MASK(output)
```

Macro function to get SELn field mask in XBARA_SELx register for a given output signal.

```
XBARA_SELx_SELn(output, input_signal)
```

Macro function to create SELn field value in XBARA_SELx register for given output signal and input signal value `input_signal`, see `xbar_input_signal_t`.

```
XBARA_CTRLx_DIENn_MASK(output)
```

Macro function to get DIENn field mask in XBARA_CTRLx register for a given output signal.

```
XBARA_CTRLx_DIENn_SHIFT(output)
```

Macro function to get DIENn field shift in XBARA_CTRLx register for a given output signal.

```
XBARA_CTRLx_DIENn(output, x)
```

Macro function to create DIENn field value in XBARA_CTRLx register for given output signal and DMA/Interrupt mode `x`, see `xbara_request_t`.

```
XBARA_CTRLx_EDGEn_MASK(output)
```

Macro function to get EDGEn field mask in XBARA_CTRLx register for a given output signal.

```
XBARA_CTRLx_EDGEn_SHIFT(output)
```

Macro function to get EDGEn field shift in XBARA_CTRLx register for a given output signal.

```
XBARA_CTRLx_EDGEn(output, x)
```

Macro function to create EDGEn field value in XBARA_CTRLx register for given output signal and edge mode `x`, see `xbara_active_edge_t`.

```
XBARA_CTRLx_STS_MASK
```

Macro value for the Status bits in CTRL register.

```
struct _xbara_control_config
```

#include <fsl_xbara.h> Defines the configuration structure of the XBARA control register.

This structure keeps the configuration of XBARA control register for one output. Control registers are available only for a few outputs. Not every XBARA module has control registers.

Public Members

xbara_active_edge_t eActiveEdge

Active edge to be detected.

xbara_request_t eRequestType

Selects DMA/Interrupt request.

2.83 The Driver Change Log

2.84 XBAR Peripheral and Driver Overview

2.85 XBARB: Inter-Peripheral Crossbar Switch Driver

`void XBARB_Init(XBARB_Type *base)`

Initializes an XBARB instance for operation.

Reserved function, enable clock preparation.

Parameters

- `base` – XBARB peripheral address.

`void XBARB_Deinit(XBARB_Type *base)`

Deinitializes an XBARB instance for operation.

Reserved function, disable clock preparation.

Parameters

- `base` – XBARB peripheral address.

`void XBARB_SetSignalsConnection(XBARB_Type *base, xbar_input_signal_t eInput,
xbar_output_signal_t eOutput)`

brief Configures a connection between the selected XBARB_IN[*] input and the XBARB_OUT[*] output signal.

This function configures which XBARB input is connected to the selected XBARB output. If more than one XBARB module is available, only the inputs and outputs from the same module can be connected.

param `base` XBARB peripheral address. param `eInput` XBARB input signal. param `eOutput` XBARB output signal.

`FSL_XBARB_DRIVER_VERSION`

XBARB driver version.

`XBARB_SELx(base, output)`

Macro function to extract the XBAR select register address for a given xbar output signal.

`XBARB_SELx_SELn_SHIFT(output)`

Macro function to get SELn field shift in XBARB_SELx register for a given output signal.

`XBARB_SELx_SELn_MASK(output)`

Macro function to get SELn field mask in XBARB_SELx register for a given output signal.

`XBARB_SELx_SELn(output, input_signal)`

Macro function to create SELn field value in XBARB_SELx register for given output signal and input signal value `input_signal`, see `xbar_input_signal_t`.

2.86 The Driver Change Log

2.87 XBARB Peripheral and Driver Overview

Chapter 3

Middleware

Chapter 4

RTOS

4.1 FreeRTOS

4.1.1 FreeRTOS kernel

Open source RTOS kernel for small devices.

[FreeRTOS kernel for MCUXpresso SDK Readme](#)

[FreeRTOS kernel for MCUXpresso SDK ChangeLog](#)

[FreeRTOS kernel Readme](#)

4.1.2 FreeRTOS drivers

This is set of NXP provided FreeRTOS reentrant bus drivers.

4.1.3 backoffalgorithm

Algorithm for calculating exponential backoff with jitter for network retry attempts.

[Readme](#)

4.1.4 corehttp

C language HTTP client library designed for embedded platforms.

4.1.5 corejson

JSON parser.

Readme

4.1.6 coremqtt

MQTT publish/subscribe messaging library.

4.1.7 corepkcs11

PKCS #11 key management library.

Readme

4.1.8 freertos-plus-tcp

Open source RTOS FreeRTOS Plus TCP.

Readme